

NAVSHIPS 900,810

RESTRICTED

PRELIMINARY INSTRUCTION BOOK

for

**RADIO TRANSMITTING EQUIPMENT
NAVY MODEL TCZ-2**



**COLLINS RADIO COMPANY
CEDAR RAPIDS, IOWA**

NAVY DEPARTMENT

BUREAU OF SHIPS

Contract NXsr-95063

APPROVED _____

520 9264 00

10669

RESTRICTED

SECURITY NOTICE

NOTICE: This document contains information affecting the national defence of the United States within the meaning of the Espionage Act, 50 U.S.C., 31 and 32, as amended. Its transmission or the revelation of its contents in any manner to an unauthorized person is prohibited by law. (ART 76, U.S.N. REGS 1920.) The information contained in restricted documents and the essential characteristics of restricted material will not be communicated to the public or to the press, but may be given to any person known to be in the service of the United States and to persons of undoubted loyalty and discretion who are cooperating in Government work.

RECORD OF CORRECTIONS MADE

CHANGE NO.	DATE	SIGNATURE OF OFFICER MAKING CORRECTIONS

RESTRICTED

TABLE OF CONTENTS

<u>Paragraph</u>	<u>Page</u>
SECTION I GENERAL DESCRIPTION	
1. Equipment	1-1
2. Descriptive Data	1-1
3. General	1-2
4. Transmitter	1-5
a. Types of Emission	1-5
b. Audio Input	1-5
c. Frequency Range	1-5
d. Frequency Change System	1-5
e. Power Output	1-6
f. Control	1-6
5. Power Unit	1-7
6. Remote Control Unit	1-7
7. Antenna Load Coil	1-7
8. Antenna Shunt Capacitor	1-8
9. Accessories	1-8
10. Interchangeability of Units	1-8
11. Power Source	1-8
12. Overload Protection	1-9
13. Abbreviations	1-9
14. Symbol Designations	1-9
15. Technical Summary	1-9
a. Frequency Range	1-9
b. Tuning Bands	1-10
c. Number of Pre-set Frequencies	1-10
d. Type of Modulation	1-10
e. Method of Modulation	1-10
f. Modulation Capability	1-10
g. Audio Frequency Response	1-11
h. Crystal	1-11
i. Frequency Stability Data	1-11
j. Input Impedance	1-11
k. Electrical Characteristics of Recommended Antennas	1-12
l. Tube Designation and Function	1-12
m. Characteristics of Power Supply	1-12
SECTION II INSTALLATION AND ADJUSTMENT	
1. Uncreting	2-1
2. General	2-1
3. Tubes	2-1

RESTRICTED

TABLE OF CONTENTS

<u>Paragraph</u>	<u>Page</u>
SECTION II INSTALLATION AND ADJUSTMENT (Cont.)	
4. Crystals	2-1
5. Operational Check	2-2
6. Mounting of Units	2-2
a. Type -52286-A Transmitter Unit	2-2
b. Power Unit	2-2
c. Dynamotors	2-3
d. Panels	2-3
e. Antenna Loading Coil	2-3
f. Remote Control Unit	2-3
g. Antenna Capacitor	2-3
7. Cables	2-4
8. Connections	2-4
a. Power Connections	2-4
b. Inter-Unit Connections	2-4
c. Antenna Connections	2-5
d. Sidetone Connections	2-6
9. Connections to Navy Circuits	2-6
a. 4 Wire-6 Wire Transmitter Control	2-6
b. Telephone Circuits	2-6
c. Receiver Protecting Relay	2-6
10. Fuses	2-6
11. Pre-Operation Adjustments	2-7
a. Power Unit	2-7
b. RF Circuits	2-9
c. Adjustment of Transmitter On Desired Frequency Using Internal Crystal Frequency Calibrator	2-10
d. Autotune Checks	2-12

SECTION III OPERATION

1. Emergency Shut Down	3-1
a. Operate Emergency Switch to OFF Position	3-1
b. Locate Line Switch to Radio Equipment and Operate to OPEN Position	3-1
2. Local Operation-6 Wire	3-1
a. To Start the Equipment	3-1
b. To Select Emission	3-1
c. To Shift Frequency	3-1
d. To Stop the Equipment	3-2
3. Local Operation - 4 Wire	3-2
a. To Start the Equipment	3-2
b. To Select Emission	3-2
c. To Shift Frequency	3-2
d. To Stop the Equipment	3-2
4. Remote Control - Navy 6 Wire	3-2
a. To Start the Equipment	3-3
b. To Stop the Equipment	3-3

RESTRICTED

TABLE OF CONTENTS

<u>Paragraph</u>	<u>Page</u>
SECTION III OPERATION (Cont.)	
5. Remote Control - Navy 4 Wire	3-3
a. To Start the Equipment	3-3
b. To Stop the Equipment	3-4
6. Remote Control - Navy Type COL-23410 Remote Control Unit	3-4
7. Function of Controls	3-4
a. Power Unit	3-4
b. Transmitter Unit	3-5
c. Antenna Loading Coil Unit	3-7
d. Navy Type COL-23410 Remote Control Unit	3-7
8. Adjustment of Transmitter On Desired Frequency Using Internal Crystal Frequency Calibrator (CFI)	3-8
a. General	3-8
b. For Frequencies Between 200 and 1500 kc	3-8
c. For Frequencies Between 2000 and 18,100 kc	3-9
d. Selection of Frequencies Between Those Given In The Calibration Tables	3-9
9. Tuning Instructions for Low Frequency Operation (200-1500 kc)	3-10
10. Tuning Instructions for High Frequency Operation (2000 to 18,100 kc)	3-11
SECTION I.V THEORY OF OPERATION	
1. Power Control Circuits - Navy Type COL-211624 Power Unit	4-1
a. Primary Power Circuits	4-1
b. Local Power Control - 6 Wire Navy Circuits	4-1
c. Local Power Control - 4 Wire Navy Circuits	4-2
d. Remote Power Control - 6 Wire Navy Circuits	4-2
e. Remote Power Control - 4 Wire Navy Circuits	4-3
2. Power Control Circuits - Transmitter Unit	4-4
3. Keying Circuits	4-6
a. Local Keying Circuits	4-6
b. Remote Keying Circuits	4-6
4. Microphone Circuits	4-7
5. Filament Circuits	4-7
6. Emission Selection and Carrier Control	4-7
7. Applicable Remote Control Circuits	4-8
8. Audio Circuits	4-9
a. Speech Amplifier	4-9
b. Modulator	4-9
c. Sidetone Amplifier	4-10
9. Calibration Oscillator	4-10
a. General	4-10
b. Circuit Function	4-10
10. MCW Audio Oscillator	4-11
11. Radio-Frequency Circuits	4-11
a. Low-Frequency Circuits	4-11
b. High Frequency Exciter Circuits	4-12
c. Power Amplifier and Output Network	4-14

RESTRICTED

TABLE OF CONTENTS

<u>Paragraph</u>	<u>Page</u>
SECTION IV THEORY OF OPERATION (Cont.)	
12. Autotune System	4-16
a. Mechanical Details	4-16
b. Electrical Details	4-20
c. Autotune Operation	4-21
13. Unit Function	4-23
SECTION V MAINTENANCE	
1. Daily Operational Check	5-1
a. Procedure	5-1
2. Routine Check	5-2
a. Equipment Inspection	5-2
b. Operational Checks	5-2
3. Servicing	5-5
a. General	5-5
b. Vacuum Tube Replacement	5-5
c. Vacuum Tube Failure Symptoms	5-6
d. Trouble Shooting	5-8
4. Radio-Frequency Circuit Alignment	5-19
a. Low-Frequency Oscillator Alignment	5-19
b. High-Frequency Oscillator Alignment Using CFI	5-20
c. High-Frequency Oscillator Alignment Using External Frequency Standard (Navy Type LM)	5-22
d. Frequency Multiplier Alignment	5-24
5. MCW-CFI Adjustment	5-27
a. CFI Alignment Using Transmitter Sidetone Circuits	5-27
b. MCW Adjustment	5-29
c. CFI Alignment Using Vacuum Tube Voltmeters	5-29
6. Precision Calibration of MCW-CFI Unit Crystal Oscillator	5-30
a. Procedure	5-31
7. Maintenance of Autotune Mechanism	5-32
a. Lubrication	5-32
b. Synchronization Check	5-33
c. Synchronization	5-34
d. Autotune Positioning Mechanism	5-36
e. Autotune Limit Switch	5-37
8. Replacement of Parts	5-38
a. Removing Component Parts	5-40
b. Servicing The Main Line Shaft Assembly	5-41
c. Replacing a Singleturn Worm	5-42
d. Replacing a Line Shaft Sprocket	5-43
e. Replacing the Chain Drive	5-43
f. Replacing a Line Shaft Bearing	5-43
g. Replacing the Main Line Shaft Thrust Bearing	5-43
h. Replacing the Main Line Shaft	5-43
i. Servicing the Multiturn Line Shaft Assembly	5-44
9. Performance Standards	5-45

RESTRICTED

TABLE OF CONTENTS

<u>Paragraph</u>	<u>Page</u>
SECTION V MAINTENANCE. (Cont.)	
a. Overall Audio-Frequency Response (Either Carbon or Dynamic Input)	5-45
b. Audio Input	5-45
c. Noise Level	5-46
d. Audio Distortion	5-46
e. Sidetone Distortion	5-46
f. Sidetone Output	5-46
10. Tube Complement	5-63
11. The Adjustment and the Replacement of Parts of Commercial Assemblies	5-64
a. General Requirements for Satisfactory Operation	5-64
b. Relay Adjustment	5-65

SECTION VI PARTS AND SPARE PARTS LIST

Table 6-1 List of Major Units.
Table 6-2 Parts List by Symbol Designation
Table 6-3 Parts List by Navy Type Number
Table 6-4 Equipment Spare Parts List by Navy Type Numbers
Table 6-5 List of Manufacturers

SECTION VII PHOTOGRAPHS AND DRAWINGS

RESTRICTED

LIST OF PHOTOGRAPHS AND DRAWINGS

<u>Figure</u>	<u>Title</u>	<u>Page</u>
∅ 1-1	Complete Navy Model TCZ-2 Equipment	
1-2	Navy Type COL-52286-A Transmitter Unit	
1-3	Navy Type COL-52286-A Transmitter Unit - Top Open View - Units in place.	
1-4	Navy Type COL-52286-A Transmitter Unit - Top Open View - Units Removed	
∅ 1-5	Navy Type COL-211624 Dynamotor Assembly Power Unit	
1-6	Navy Type COL-23410 Remote Control Unit	
1-7	Navy Type COL-47505 Antenna Loading Coil Unit	
1-8	Navy Type COL-481628 Antenna Shunt Capacitor	
1-9	Type CR-2-B/U (200 kc) Crystal Unit	
1-10	Overall Frequency Response Curve	
2-1	Complete Navy Model TCZ-2 Installation Diagram	
2-2	Navy Model TCZ-2 Tube and Fuse Placement Diagram	
3-1	Navy Model TCZ-2 Operating Controls	
3-2	Microphone Switch and Sidetone Amp. Gain Control	
3-3	High Frequency Tuning Control	
4-1	Primary Power Circuits	
4-2	Local Power Control - 6 Wire Navy Circuits	
4-3	Local Power Control - 4 Wire Navy Circuits	
4-4	Remote Power Control - 6 Wire Navy Circuits	
4-5	Remote Power Control - 4 Wire Navy Circuits	
4-6	Power Control Circuits - Transmitter Unit	
4-7	Local Keying Circuits	
4-8	Remote Keying Circuits	
4-9	Microphone Circuits	
4-10	Filament Circuits	
4-11	Emission Selection and Carrier Control Circuits	
4-12	Applicable Remote Control Circuits	
4-13	Speech Amplifier Circuits	
4-14	Modulator Circuits	
4-15	Sidetone Amplifier Circuits	
4-16	CFI Circuits	
4-17	MCW Oscillator Circuits	
4-18	Low Frequency Circuits	
4-19	High Frequency Exciter Circuits	
4-20	Power Amplifier and Output Network	
4-21	High Frequency RF Circuits - Block Diagram	
4-22	Collins Autotune System - Mechanical Portion	
4-23	Collins Autotune System - Electrical Portion	
4-24	Collins Autotune Operating Sequence	
5-1	Low Frequency Oscillator	
5-2	Low Frequency Oscillator Adjustment	
5-3	High Frequency Oscillator	
5-4	High Frequency Oscillator Adjustment	
5-5	Frequency Multiplier	
5-6	Frequency Multiplier Adjustment	
5-7	Autotune Singleturn Unit - Left Side	
5-8	Autotune Singleturn Unit - Right Side	

RESTRICTED

<u>Figure</u>	<u>Title</u>	<u>Page</u>
5-9	Autotune Multiturn Unit - Left Side	
5-10	Autotune Multiturn Unit - Right Side	
5-11	Autotune Lubrication Chart	
5-12	Autotune Casting	
5-13	NY-818C-C Autotune Motor Schematic	
5-14	Keying Relay (K-102) Contact Arrangement	
5-15	Keying Relay (K-102) Assembly	
5-16	Voice Relay (K-104) Assembly	
5-17	CW Relay (K-103) Assembly	
5-18	Autotune Motor Assembly	
5-19	Autotune Motor Photograph	
7-1	Navy Type COL-52286-A Transmitter Unit - Front Open View	
7-2	Navy Type COL-52286-A Transmitter Unit - Top Open View	
7-3	Navy Type COL-52286-A Transmitter - Bottom View	
7-4	High Frequency Oscillator - Side Open View	
7-5	Frequency Multiplier - Side Open View	
7-6	Fire Wall Assembly - Top View	
7-7	Fire Wall Assembly - Bottom View	
7-8	Low Frequency Oscillator Unit - Front View	
7-9	Low Frequency Oscillator Unit - Top Open View	
7-10	Low Frequency Oscillator Unit - Bottom Open View	
7-11	MCW-CFI Unit - Top View	
7-12	MCW-CFI Unit - Bottom View	
7-13	Audio Amplifier Unit - Top View	
7-14	Audio Amplifier Unit - Bottom View	
7-15	Multi-Element Switch - Right Side View	
7-16	Multi-Element Switch - Left Side View	
7-17	Navy Type COL-211624 Dynamotor Assembly Power Unit - Front Open View	
7-18	Navy Type COL-211624 Dynamotor Assembly Power Unit - Right Side Open View	
7-19	Navy Type COL-211624 Dynamotor Assembly Power Unit - Left Side Open View	
7-20	Navy Type COL-211624 Dynamotor Assembly Power Unit - Bottom View	
7-21	High Voltage Dynamotor Unit - Bottom View	
7-22	Low Voltage Dynamotor Unit - Bottom View	
7-23	Dynamotor Assembly Filter Unit - Bottom View	
7-24	Navy Type COL-23410 Remote Control Unit - Top View	
7-25	Navy Type COL-23410 Remote Control Unit - Bottom View	
7-26	Navy Type COL-47505 Antenna Loading Coil Unit - Front View	
7-27	Navy Type COL-47505 Antenna Loading Coil Unit - Top Open View	
7-28	Navy Type COL-47505 Antenna Loading Coil Unit - Right Side Open View	
7-29	Navy Type COL-47505 Antenna Loading Coil Unit - Left Side Open View	

RESTRICTED

<u>Figure</u>	<u>Title</u>	<u>Page</u>
7-30	Navy Type COL-481628 Antenna Shunt Capacitor - Top View	
7-31	96J Autotune Singleturn Unit - Left Side View	
7-32	96J Autotune Singleturn Unit - Right Side View	
7-33	96K Autotune Multiturn Unit - Left Side View	
7-34	96K Autotune Multiturn Unit - Right Side View	
7-35	Autotune Casting	
7-36	Navy Type COL-52286-A Radio Transmitter Installation Diagram	
7-37	Navy Type COL-211624 Dynamotor Assembly Power Unit Installation Diagram	
7-38	Navy Type COL-23410 Remote Control Unit Installation Diagram	
7-39	Navy Type COL-47505 Antenna Loading Coil Unit Installation Diagram	
7-40	Navy Type COL-481628 Antenna Shunt Capacitor Installation Diagram	
7-41	65X-7 Control Cable Assembly Diagram	
7-42	65X-8 Power Cable Assembly Diagram	
7-43	65X-9 Antenna Loading Coil Cable Assembly Diagram	
7-44	65X-10 Remote Control Cable Assembly Diagram	
7-45	Navy Model TCZ-2 Complete Schematic	
7-46	Navy Type COL-52286-A Transmitter Schematic	
7-47	Navy Type COL-211624 Dynamotor Assembly Power Unit Schematic	
7-48	Navy Type COL-23410 Remote Control Unit Schematic	
7-49	Navy Type COL-47505 Antenna Loading Coil Schematic	
7-50	Navy Type COL-52286-A Transmitter Practical Wiring Diagram	
7-51	High Frequency Oscillator Practical Wiring Diagram	
7-52	Multiplier Practical Wiring Diagram	
7-53	Low Frequency Oscillator Practical Wiring Diagram	
7-54	MCW-CFI Unit Practical Wiring Diagram	
7-55	Audio Amplifier Practical Wiring Diagram	
7-56	Navy Type COL-211624 Dynamotor Assembly Power Unit Practical Wiring Diagram	
7-57	Navy Type COL-23410 Remote Control Unit Practical Wiring Diagram	
7-58	Navy Type COL-47505 Antenna Loading Coil Practical Wiring Diagram	
7-59	HF Oscillator Grid Inductor L-101	
7-60	First Multiplier Plate Inductor L-105	
7-61	Second Multiplier Plate Inductor L-106	
7-62	PA Plate Feed Choke L-108	
7-63	Output Network Static Drain Choke L-110	
7-64	PA Plate Inductor - Rotor for L-112	
7-65	PA Plate Inductor - Stator for L-112	
7-66	Antenna Loading Inductor L-113	

RESTRICTED

<u>Figure</u>	<u>Title</u>	<u>Page</u>
7-67	PA Plate Tank Padding Inductor L-114	
7-68	LF Oscillator Grid Inductor L-401	
7-69	Antenna Loading Coil L-3001	
7-70	Antenna Loading Coil - Stator for L-3002	
7-71	Antenna Loading Coil - Rotor for L-3002	
7-72	Antenna Loading Coil - Stator for L-3003	
7-73	Antenna Loading Coil - Rotor for L-3003	
7-74	Type CR-2-B/U (200 kc) Crystal Unit	
∅ 7-75	Ceramic Insulator Drawing	
∅ 7-76	Inductor and Reactor Winding Data	
∅ 7-77	Transformer Winding Data	

∅ Inclusion of this sign indicates figures not available for Preliminary Instruction Books. This information will be included in the Final Instruction book.

RESTRICTED

LIST OF TABLES

<u>Table</u>	<u>Title</u>	<u>Page</u>
1-1	Equipment Supplied on Contract.	
1-2	Equipment Required for Operation but not supplied on Contract.	
1-3	Power Output.	
1-4	Interchangeability of Units.	
2-1	Table of Fuses.	
3-1	Low Frequency Oscillator Calibration Data.	
3-2	High Frequency Oscillator Calibration Data. Tuning Charts.	
3-3	Typical Antenna Tuning Data (Without Capacitor).	
3-4	Typical Antenna Tuning Data (With Capacitor).	
5-1	Power Input Requirements.	
5-2	Typical Audio-Frequency Data.	
5-3	MCW-CFI Unit Output Level.	
5-4	Resistance Measurements from Vacuum Tube Terminals to Ground and Typical Operating Voltages and Currents.	
5-5	Voltage and Resistance to Ground from Connector Terminals.	
5-6	Resistance Measurements on Rotating Machines.	
5-7	Tube Complement.	
6-1	List of Major Units.	
6-2	Parts List by Symbol Designation.	
6-3	Parts List by Navy Type Numbers.	
6-4	Equipment Spare Parts List by Navy Type Numbers.	
6-5	List of Manufacturers.	

RESTRICTED

CONTRACTUAL GUARANTEE

The Contractor guarantees that at the time of delivery thereof the articles provided for under this contract will be free from any defects in material or workmanship and will conform to the requirements of this contract. Except as to vacuum tubes, batteries, rubber and material normally consumed in operation, the equipment, including all spare parts, is guaranteed for a period of one (1) year from the date of its delivery to and acceptance by the Government, with the understanding that all items found to be defective as to material, workmanship or manufacture will be repaired or replaced, f.o.b. any point within the continental limits of the United States designated by the Government, without delay and at no expense to the Government; provided, that such guarantee shall not obligate the Contractor to repair or replace any such defective items unless the defect appears within the aforementioned period and the Contractor is notified thereof in writing within a reasonable time and unless the defect is not the result of normal expected shelf life deterioration. This guarantee shall then continue as to corrected or replacing articles or, if only parts of such articles are corrected or replaced, to such corrected or replacing parts, until one year after the date of redelivery.

To the extent the equipment, including all parts and spare parts as defined above, is of the Contractor's design or is of a design selected by the Contractor, it is also guaranteed, subject to the foregoing conditions, against defects in design, with the understanding that if ten per cent (10%) or more of the total quantity comprising such item furnished under the contract (but not less than two thereof) is found to be defective as to design, the entire item will be conclusively presumed to be of defective design and shall be subject to one hundred per cent (100%) correction or replacement by a suitably redesigned item.

All defective items will be subject to ultimate return to the Contractor except that the exigencies of the naval service may necessitate expeditious repair of certain items in order to prevent extended interruption of communications and in such cases the return of the defective items for examination by the Contractor prior to repair or replacement shall not be mandatory. The report of a responsible authority, including details of the conditions surrounding the failure, will be acceptable as a basis for effecting expeditious adjustment under the provisions of this contractual guarantee.

If the Government does not require correction or replacement of a defective or nonconforming article, the Contractor, if required by the contracting officer within a reasonable time after the notice of defect or nonconformance, shall repay such portion of the contract price as is equitable in the circumstances. Equitable in the circumstances is to be determined by mutual agreement between the Contractor and the contracting officer. Failure to agree to such adjustment shall be a dispute concerning a question of fact within the meaning of the section of this contract entitled "Disputes".

RESTRICTED

INSTALLATION RECORD

Contract Number NXsr-95063 Date of Contract: 14 April 1945
Serial Number of Equipment _____
Date of Acceptance by the Navy _____
Date of Delivery to Contract Destination _____
Date of Completion of Installation _____
Date Placed in Service _____

Blank spaces in this table shall be filled in at time of installation. Operating personnel shall also mark the "date placed in service" on the date of acceptance plate located below the model nameplate on the equipment, using suitable methods and care to avoid damaging the equipment.

REPORT OF FAILURE

Report of failure of any part of this equipment, during its service life, shall be made to the Bureau of Ships in accordance with current instructions. The report shall cover all details of the failure and give the date of installation of the equipment. For procedure in reporting failures see Chapter 67 of the "Bureau of Ships Manual," or superseding instructions.

ORDERING PARTS

All requests or requisitions for replacement material should include the following data:

1. Navy stock number or, when ordering from an Army Supply depot, the Army stock number.
2. Name of part.

If the Navy stock number has not been assigned, the requisitions should specify the following:

1. Equipment model designation.
2. Name of part and complete description.
3. Manufacturer's designation.
4. Contractor's drawing and part number.
5. AWS, JAN, or Navy type designation

RESTRICTED

WARNING

The attention of officers and operating personnel is directed to CHAPTER 67 of BUREAU of SHIPS MANUAL or superseding instructions on the subject of "RADIO-SAFETY PRECAUTIONS TO BE OBSERVED."

While every practicable safety precaution has been incorporated in this equipment, the following rules must be strictly observed:

KEEP AWAY FROM LIVE CIRCUITS

Operating personnel must at all times observe all safety regulations. Do not change tubes or make adjustments inside equipment with high voltage supply on. Under certain conditions dangerous potentials may exist in circuits with power controls in the off position due to charges retained by capacitors. To avoid casualties always remove power and discharge and ground circuits prior to touching them.

DON'T SERVICE OR ADJUST ALONE

Under no circumstances should any person reach within or enter the enclosure for the purpose of servicing or adjusting the equipment without the immediate presence or assistance of another person capable of rendering aid.

DON'T TAMPER WITH INTERLOCKS

Do not depend upon door switches or interlocks for protection but always shut down motor generators or other power equipment. Under no circumstances should any access gate, door or safety interlock switch be removed, short circuited, or tampered with in any way, by other than authorized maintenance personnel, nor should reliance be placed upon the interlock switches for removing voltages from the equipment.

RESUSCITATION

AN APPROVED POSTER ILLUSTRATING THE RULES FOR RESUSCITATION BY THE PRONE PRESSURE METHOD SHALL BE PROMINENTLY DISPLAYED IN EACH RADIO, RADAR OR SONAR ENCLOSURE. POSTERS MAY BE OBTAINED UPON REQUEST TO THE BUREAU OF MEDICINE AND SURGERY.

SECTION I

GENERAL DESCRIPTION

1. EQUIPMENT

The Model TCZ-2 Radio Transmitting Equipment covered by this Instruction Book consists of a Transmitter, an Antenna Load Coil Unit, a Remote Control Unit, an Antenna Shunt Capacitor, a Power Supply Unit and the necessary Interconnecting Cables.

2. DESCRIPTIVE DATA

a. Nomenclature: Navy Model TCZ-2 Radio Transmitting Equipment.

b. Contract Number: NXsr-95063 Dated 14 April, 1945.

c. Contractor: Collins Radio Company, Cedar Rapids, Iowa.

d. Frequency Range: 200 to 1500 kc and 2000 to 18,100 kc.

e. Frequency Control: Master oscillator continuously variable.

f. Emission: Voice, CW, MCW.

g. Modulation Capability: At least 90%.

h. Nominal Carrier Output for each type of Emission: Varies with frequency.

i. See Output Table, Paragraph 1-4e.

j. Characteristics of power supply required for operation.

(1) 115 volts DC

(2) Current:

(a) Starting:

(b) Stand-by:

(c) Normal Operation:

(d) Maximum:

k. Number of packages involved per complete shipment of equipments: 6.

l. Inclusion of this sign indicates information not available for Preliminary Instruction Books. This information will be included in the Final Instruction Book.

Ø i. Total cubical contents packed for shipment:

Ø k. Total weight packed for shipment:

l. Crystal complement: One Type CR-2-B/U (200 kc).

m. Vacuum tube complement:

<u>QUANTITY</u>	<u>TYPE NUMBER</u>
2	6V6GT
2	811
1	813
1	837
1	12SJ7
2	12SL7GT
1	12SA7/GT
3	1625

3. GENERAL.

The Model TCZ-2 Series Radio Transmitting Equipment has been designed for installation aboard ship. Particular care has been taken in the design to insure mechanical construction that will withstand the vibration and shock incident to normal service. All materials used in the construction of the equipment are, insofar as practicable, resistant to corrosion resulting from the chemical action of a moist saline atmosphere.

A standard Navy Type-52286-A Transmitter is mounted on top of the Navy Type Col-211624 Dynamotor Assembly Power Unit. The Navy Type COL-47505 Antenna Lead Coil is a separate unit designed to extend the frequency range of the transmitter to include the frequencies from 200 to 1500 kc. The Navy Type COL-23410 Remote Control Box is furnished to facilitate operation of the Model TCZ-2 equipment from a convenient operating position. A shunt capacitor, Navy Type COL-481628, is furnished to assist in loading the transmitter in the 2000 kc region while using a short antenna.

Sub-assembly type of construction has been used extensively in the Type -52286-A Transmitter. This type of construction facilitates the removal of component parts without major disassembly of the unit. The MCW-CFI, the Audio Amplifier, and the LF Oscillator Units are connected by multi-terminal plugs to facilitate removal for servicing. An effort has been made to make all components that may require replacement easily accessible.

The Collins Autotune System has been incorporated in the Model TCZ-2 Series Equipment to permit rapid frequency change. The Autotune system is an electrically controlled means of mechanically repositioning adjustable elements such as switches, variable inductors and variable capacitors. The accuracy of repositioning is of a very high order and is not seriously affected by wear, humidity or temperature changes. No tools are necessary for the changing of the position of any of the controls. Eleven Autotune positions are available, permitting transmission on any one of eleven preset frequencies. Ten of the frequencies are in the frequency range 2000 kc to 18,100 kc, and one is in the frequency range 200 kc to 1500 kc.

Table 1-1 EQUIPMENT SUPPLIED

Name of Unit	Quant.	Numerical Series of Reference Symbols	Navy Type Designation	Collins Part Number	Overall Dimensions (Inches)		Volume (Cu. Ft.)		Weight (lbs.)	
					Crated	Uncrated	Crated	Uncrated	Crated	Uncrated
Radio Transmitter	1	101-199 201-299 401-499 2201-2299	-52286-A	17H-2	HxWxD	HxWxD 10-3/4 x 23-9/16 x 13-1/4		2.5		66
Dynamotor Assembly Power Unit	1	1901-1999	COL- 211624	413D-4		29-7/16 x 23-7/16 x 20-1/8		8.5		—
Remote Control Unit	1	901-999	COL- 23410	314N-2		4-3/4 x 9-31/32 x 6-1/2		.175		8
200 kc Quartz Crystal	1	Y-2201	CR-2- B/U (200 kc)	—		—		—		—
Antenna Load Coil	1	3001-3099	COL- 47505	180H-4		19-3/4 x 18-5/8 x 15-1/2		3.3		48
Antenna Shunt Capacitor	1	1101-1199	COL- 481628	195D-1		3-7/8 x 5 x 4-1/8		.045		1.56
Control Cable (Power Unit to Transmitter)	1	1501-1599	—	65X-7		11-11/32 Long		—		—
Power Cable (Power Unit to Transmitter)	1	1601-1699	—	65X-8		11-9/16 Long		—		—
Power Cable (Transmitter to Load Coil)	1	1701-1799	—	65X-9		120 Long		—		—
Control Cable (Power Unit to Control Box)	1	2301-2399	—	65X-10		120 Long		—		—
Spare Parts	1 Set	—	—	—		—		—		—
Instruction Book	2	—	—	—		—		—		—

10296

RESTRICTED

1-3

RESTRICTED

Section I
Paragraph 3

Table 1-2 EQUIPMENT REQUIRED BUT NOT SUPPLIED

Quantity	Name of Unit	Navy Type Designations	Required Characteristics
1	Microphone		40 ohm carbon or 200 ohm Dynamic for RED coded circuit per Navy Specifications RE 8944A Cord: Three Conductor shielded Cord Plug: 3 circuit, Tip 3/16" Dia. 1-3/16" long
1	Telegraph Key		Any Type. Cord: 2 conductor Cord Plug: 2 circuit, Tip 3/16" Dia. 1-3/16" long.
1	Headphone		500 ohm impedance. Cord Plug: 2 circuit, Tip 1/4" Dia. and 1-5/32" long.



Figure 1-2 Navy Type COL-52286-A Transmitter Unit







Figure 1-3 Navy Type COL-52286-A Transmitter Unit - Top Open View - Units in place



LOW FREQUENCY
OSCILLATOR



AUDIO
UNIT



MCW-CFI
UNIT




Figure 1-4 Navy Type COL-52286-A Transmitter Unit - Top Open
View - Units Removed

4. TRANSMITTER

The transmitter employed by this TCZ-2 equipment is a standard Navy Type -52286-A Aircraft transmitter. This unit employs a slide-track shock-mount system of mounting which makes possible the removal of the transmitter from the top of the power supply in a few seconds time. Since the transmitter was designed primarily for aircraft use, the material used in the structural parts is of aluminum or other light materials. Plug-in type of construction is used where practicable for ease in servicing and replacing parts.

a. TYPES OF EMISSION. - CW, MCW and VOICE types of emission are available with the TCZ-2 equipment. The audio system is capable of modulating the carrier (100 watts nominal) at least 90%. Keying speeds up to 30 words per minute may be used when operating with CW and MCW emission without objectionable chirp or distortion of the length of the keyed characters.

b. AUDIO INPUT. - Either of two types of microphone may be used with this equipment. An input circuit has been incorporated in the equipment to permit the use of either a carbon or dynamic type of microphone. When the microphone switch, S201, is in DYNAMIC position, an audio input of 16 millivolts to the MICROPHONE jack, J102, is required for 90% modulation. When the microphone switch is in the CARBON position 1.45 volt audio input at J102 is required for 90% modulation. The audio frequency response is uniform within 3 db between 300 cps and 4000 cps. The audio frequency distortion is less than 15% rms at 1000 cps and with 90% modulation of the carrier (100 watts nominal).

c. FREQUENCY RANGE. - Two bands of transmission frequencies are available with the TCZ-2 equipment. Output may be obtained in the low frequency range of 200 kc to 1500 kc and in the high frequency range of 2000 kc to 18,100 kc.

When operating in the frequency range 200 kc to 1500 kc an external power amplifier plate tank and antenna loading circuit must be used. The necessary circuit is incorporated in the Navy Type COL-47505 Antenna Loading Coil Unit. Selecting low frequency output automatically makes the proper connections from the power amplifier plate to the external tank circuit.

The output circuits of the transmitter have been designed to match antennas from 25 feet to 35 feet in length in the frequency range 200 kc to 1500 kc and 20 feet to 35 feet in length in the range 2000 kc to 18,100 kc.

d. FREQUENCY CHANGE SYSTEM. - The Autotune frequency system employed in the TCZ-2 equipment is an electrically controlled mechanical system of positioning the transmitter tuning elements. The positioning elements are driven by a single motor. The system will operate to change the frequency of transmission in less than 25 seconds at normal room temperature and with normal operating voltage. A detailed description of both the mechanical and electrical portions of the Autotune is given in the THEORY OF OPERATION section of this Instruction Book.

Manual frequency change and tuning adjustments may be made without disturbing the Autotune stop ring adjustments if the CHANNEL selector switch is placed in the MANUAL position and the Autotune mechanism allowed to operate.

e. POWER OUTPUT. - The power delivered to the antenna varies with frequency and antenna characteristics.

The following table shows the power output obtainable within the two bands of frequencies, 200 kc to 1500 kc and 2000 kc to 18,100 kc, with normal supply voltage and antennas having the characteristics listed under Antenna Resistance and Antenna Reactance:

Table 1-3 POWER OUTPUT

<u>Frequency Kilocycles</u>	<u>Antenna Reactance Ohms</u>	<u>Antenna Resistance Ohms</u>	<u>Power Output Watts</u>	<u>See Note</u>
200	-j6800	71.5	19	(1)a.
300	-j4330	41.0	35	(1)a.
400	-j3250	40.5	47	(1)a.
575	-j2600	40.5	60	(1)a.
575	-j2750	28.0	18	(1)b.
700	-j2000	28.0	24	(1)b.
800	-j1750	28.0	28	(1)b.
1000	-j1350	28.0	40	(1)b.
1300	-j1030	28.0	44	(1)b.
1500	-j 900	28.0	36	(1)b.
2000	-j 450	2.1	31	(2)
3000	-j 200	3.1	60	(2)
4000	0	6.1	80	(2)
5500	+j 380	25.0	90	(2)
7000	0	3500.0	90	(2)
9000	-j 350	50.0	90	(2)
11500	0	50.0	90	(2)
13500	+j 350	100.0	90	(2)
15500	0	1500.0	75	(2)
18000	-j 350	200.0	65	(2)

NOTE

(1) Measurements were made using the Navy Type COL-47505 Antenna Loading Coil.

(a) Low frequency section.

(b) High frequency section.

(2) Measurements were made while operating into a fixed antenna without a loading coil.

f. CONTROL. - The emission of the transmitter may be controlled from the Type COL-52286-A Transmitter panel, the Type COL-23410 Remote Control Unit, or a standard Navy Radiophone Unit. The type of emission and the frequency channel may be selected from the transmitter panel or the remote control unit only.

The Type -52286-A Transmitter controls consist of a TEST switch, a LOCAL-REMOTE switch, a CHANNEL selector switch, a metered circuit selector switch, a power level switch, an EMISSION selector switch, LOW FREQUENCY oscillator TUNING, HIGH FREQUENCY oscillator TUNING, ANTENNA TUNING-COARSE, ANTENNA TUNING-FINE, and ANTENNA LOADING controls, KEY, MICROPHONE and Throttle Switch jacks for control of emission and two jacks, when properly connected, for SIDETONE monitoring.

gives 2.4. Adding 2.4 to 636, which is the dial setting for the next lower frequency, gives 638.4 as the dial setting for 9653 kilocycles.

9. TUNING INSTRUCTIONS FOR LOW FREQUENCY OPERATION (200-1500 kc).

a. Knobs "F" and "G" are coarse and fine frequency controls. Knob "A" MUST be set at 13. Knobs "B", "D", and "E" have no effect on low frequency tuning. They will rotate when automatically shifting to low frequency, but their final position is unimportant. Knob "C" should be set to number 8 since this position allows the least power to be dissipated in the high frequency output circuits. All antenna tuning controls are located on the external loading coil.

b. The following procedure is recommended for tuning the equipment on a desired low frequency:

(1) Set transmitter to desired frequency using Knobs "F" and "G". See instructions paragraph III-8b in this book, and calibration table 3-1.

(2) Place BATTERY-PA GRID-PA PLATE switch in PA PLATE position.

Place CALIBRATE-TUNE OPERATE switch in TUNE position.

Place EMISSION switch in CW position.

See that Knob "A" is in Position 13.

(3) Set the tap switches (Knobs "R" and "T" or "Q") on the loading coil to the desired frequency, using the rough frequency calibration by the knob as a guide.

(4) Press key. Rotate the fine tuning control (Knob "S" or "P" depending on the frequency), for minimum PA plate meter reading. If no sharp dip is found, move the tap switch on the loading coil one position and return the fine tuning control. If no dip is found, move the tap switch one position the other way and try again. Set and lock Knobs "S" or "P" at the position of minimum PA plate meter reading. Release key.

NOTE

The resonant point lowest in frequency must be found to prevent doubling of frequency in the output circuit.

(5) Place CALIBRATE-TUNE-OPERATE switch in OPERATE position. The transmitter is now ready for use.

NOTE

The correct tuning point is at minimum PA plate meter reading. The actual value of PA plate meter reading is of little importance, and will vary between 70 and 130 on the numbered scale, depending on frequency. DO NOT detune any of the knobs to make the meter read in the CW area on the scale. The transmitter is operated below maximum loading on some low frequencies.

(10) The low frequency oscillator is now set on the desired frequency. If it is desired to tune the output and antenna circuits of the transmitter into an antenna, proceed as described in paragraph III-9.

c. FOR FREQUENCIES BETWEEN 2000 AND 18,100 kc.

(1) Turn CHANNEL switch to desired channel.
 (2) Turn EMISSION switch to VOICE.
 (3) After motor stops, loosen locking bar on Knob "A". Set this knob to the position shown in the table for the desired frequency, approaching the setting clockwise through at least one eighth turn, and tighten the locking bar.

(4) Turn CALIBRATE-TUNE-OPERATE switch to CALIBRATE.

(5) Loosen locking bar in Knob "B". Turn Knob "B" to the dial setting of the nearest crystal check point, shown in heavy type in the group of frequencies in the table containing the desired frequency. Adjust Knob "B" accurately for zero beat in the headphones.

(6) Leave Knob "B" at zero beat and adjust the CORRECTOR which moves the indicating mark over "B" until the dial reading at the mark is correct for the check point.

(7) Turn CALIBRATE-TUNE-OPERATE switch to TUNE.

(8) Turn Knob "B" one eighth each side of the given dial setting and advance clockwise to the final position. Hold knob on setting and tighten locking bar.

(9) The high frequency oscillator is now set on desired frequency. If it is desired to tune the output and antenna circuits to an antenna, proceed as described in paragraph III-10.

d. SELECTION OF FREQUENCIES BETWEEN THOSE GIVEN IN THE CALIBRATION TABLES.

- The calibration tables give dial settings at 2 kc intervals from 200 to 500 kilocycles; 5 kc intervals from 500 to 8000 kilocycles; and 10 kc intervals from 8000 to 18,100 kilocycles. The transmitter can also be set to frequencies between those given in the table by the following simple method:

(1) Find the difference between the desired frequency and the next lower frequency given in the table.

(2) Multiply this difference by the number given in parenthesis at the right of the column of figures containing the next lower frequency.

(3) Add the product thus obtained to the dial setting given in the table for the next lower frequency. The result is the dial setting for the desired frequency.

(4) Example: It is desired to work on 9653 kilocycles. The next lower frequency given in the table is 9650, and the difference is 3. The number in parenthesis at the right of the column is 0.8. Multiplying 3 by 0.8

(3) The SPEAKER-PHONES switch is an SPDT switch employed to switch the receiver audio from the speaker to the head phones jack.

(4) The VOLUME CONTROL knob operates a bridged T pad control placed in the receiver audio leads to control receiver volume.

8. ADJUSTMENT OF TRANSMITTER ON DESIRED FREQUENCY USING INTERNAL CRYSTAL FREQUENCY CALIBRATOR (CFI).

a. GENERAL. - Place the equipment in operation using instructions in paragraph III--2 LOCAL OPERATION - 6 WIRE, or paragraph III-3 LOCAL OPERATION - 4 WIRE.

(1) Plug a pair of headphones into the No. 1 sidetone jack on the transmitter. Sidetone No. 2 cannot be used unless proper external connections have been made through remote jack J-106 or terminal board J-1903.

(2) Turn LOCAL-REMOTE switch to LOCAL.

(3) Find desired frequency in calibration table, Table 3-1 or 3-2.

(4) The main frequency controls ("B" for the high frequency range and "G" for the low frequency range) each rotate 20 turns to cover a tuning range. The dial reading given in the table is the number of turns indicated on the small turn counter followed by the dial setting of the large knob. Thus, the dial reading shown in Figure 3-3 is 1447.

b. FOR FREQUENCIES BETWEEN 200 AND 1500 kc.

(1) Turn CHANNEL switch to L. FREQ.

(2) Turn EMISSION switch to VOICE.

(3) After motor stops, see that Knob "A" is at Position 13. If not, loosen locking bar, rotate Knob "A" to 13, approaching the setting clockwise through at least one eighth turn, and tighten locking bar.

(4) Set switch F to the position given in the table for the desired frequency.

(5) Turn CALIBRATE-TUNE-OPERATE switch to CALIBRATE.

(6) Loosen dial lock and turn Knob "G" to the dial setting of the nearest crystal check point, shown in heavy type in the group of frequencies containing the desired frequency. Adjust Knob "G" accurately for zero beat in the headphones.

(7) Leave Knob "G" at zero beat and adjust the CORRECTOR which moves the indicating mark until the dial reading at the mark is correct for the check point.

(8) Turn CALIBRATE-TUNE-OPERATE switch to TUNE.

(9) Turn Knob "G" to the dial setting given in the table for the desired frequency. Tighten dial lock.

(10) The BATTERY - PA GRID - PA PLATE switch transfers the right-hand meter to the circuits named. For tuning and normal operation, leave this switch in the PA PLATE position.

(11) The CALIBRATE-TUNE-OPERATE switch turns on the calibrating oscillator and disables the power amplifier in the CALIBRATE position. In TUNE position the equipment is operative at reduced power to prevent damage to the PA tube during preliminary tuning. In OPERATE position the equipment operates at full power. This switch will normally be left in the OPERATE position except during tuning.

(12) The EMISSION switch controls type of emission.

(13) A test key in the upper left-hand corner of the front panel can be used to operate the keying relay for tuning, etc.

(14) The CARBON-DYNAMIC microphone switch and the sidetone output control are located behind the calibration chart, and are accessible by releasing the snap-slides on the chart and swinging it outward and upward. (Refer to Figure 3-2) The sidetone OUTPUT control varies the sidetone output from one-half to 18 volts in 6 steps. Minimum output is at Position 1, and maximum output at Position 6.

c. ANTENNA LOADING COIL UNIT. - When the CHANNEL selector switch, S-108, is rotated to the LF position controls A, B, C, D and E are ignored and controls G and F are used on the transmitter unit panel. Tuning of the power amplifier and antenna is transferred to the following controls on the antenna loading coil unit.

(1) Knob "R" is the frequency range selector switch. In the counter-clockwise position, tuning is possible in the 200-575 kc band, if knob "R" is turned to the clockwise position, tuning is possible in the 575-1500 kc band.

(2) Knob "T" is the COARSE tuning control in the 200-575 kc range.

(3) Knob "S" controls a variometer used for FINE tuning in the 200-575 kc range.

(4) Knob "Q" controls a tap switch and is employed in the 575-1500 kc range for COARSE tuning.

(5) Knob "P", used for FINE tuning in the 575-1500 kc range, controls a variometer.

d. NAVY TYPE COL-23410 REMOTE CONTROL UNIT. - Control of emission selection, channel selection and of the carrier is transferred to the Remote Control Unit when transmitter unit LOCAL-REMOTE switch S-107 is placed in the REMOTE position.

(1) The TRANSMITTER knob controls a tap switch which selects the type of emission desired (MCW, CW, or VOICE).

(2) The CHANNEL knob also controls a tap switch. All eleven transmitting channels can be selected by this knob.




Figure 3-2 Microphone Switch and Sidetone Amp. Gain Control




Figure 3-3 High Frequency Tuning Control

the keying relay to reduce arcs as the arm on the tap switch moves between points. It is necessary to set this knob accurately to position to permit the relay to operate.

(4) Knob "D" controls fine tuning of the inductive portion of the antenna tuning network. Its scale is graduated 0-100 with maximum inductance occurring at 0 and minimum inductance at 100.

(5) Knob "E" controls the capacitive portion of the antenna tuning network. This knob has two scales, graduated 0-100 and 100-200.

<u>Scale on Knob "E"</u>	<u>Capacity</u>	<u>Maximum Capacity at</u>	<u>Minimum Capacity at</u>
100-200	Variable capacitor alone.	100	200
0-100	Variable capacitor plus fixed section to extend range.	0	100

WARNING

Do not leave Knob "E" set in the blank space between scales or move the Knob between the blank spaces between the two scales with the key closed as an internal switch may become damaged.

(6) Knob "F" is the coarse frequency control for the low frequency oscillator. Its six positions are marked directly in frequency coverage.

(7) Knob "G" is the fine frequency control for the low frequency oscillator. It rotates 20 turns to cover each range. The dial reading is the reading of the small turn counter, followed by the reading of the large knob. For example, if the turn counter is between 8 and 9, and the large knob is at 32, the dial reading for "G" is 832.

NOTE

It is necessary for Knob "A" to be set at 13 for low frequency operation.

(8) The transmitter unit LOCAL-REMOTE switch transfers control of frequency and emission to the panel switches in LOCAL, or to the NAVY Type Col-23410 Remote Control Unit in REMOTE position.

(9) The CHANNEL switch permits selection of the 10 high frequency and 1 low frequency preset channels. In addition, a position marked MANUAL is provided whereby if the AUTOTUNE system is allowed to operate, the knobs can be rotated freely without disturbing preset positions.

CAUTION

See that locking bars in Knobs "A", "B", "C", "D" and "E" are tight before changing channels.

NOTE

It is possible to control the power from the panel when the power unit LOCAL-REMOTE switch is in the REMOTE position but impossible to control the power from the Navy control circuits when the power unit LOCAL-REMOTE switch is in the LOCAL position.

(6) The 4 WIRE-6 WIRE selector switch located behind the bottom front panel on the right hand side of the cabinet is a toggle switch employed to arrange the power unit control circuits for either NAVY 4 WIRE control circuits or NAVY 6 WIRE control circuits.

WARNING

The terminal board at the bottom of the Power Unit carries in excess of 1100 v DC. Do not remove any front panels without first opening the main power line switch and placing the EMERGENCY switch in the OFF position.

b. TRANSMITTER UNIT. - The high frequency control knobs are marked "A", "B", "C", "D", and "E", and are located along the lower part of the front panel. These controls are preset for one channel by loosening locking bar in center of knob, rotating control either direction to desired setting, (but approaching final setting clockwise), then tightening the locking bar. The CHANNEL switch can then be turned to another channel, and after motor stops, all controls can be preset on another frequency, etc.

The Autotune controls are set up most satisfactorily by turning the dials approximately one eighth turn each side of the chosen dial setting and advancing clockwise to the final position.

CAUTION

Always tighten locking bars before changing channels. Failure to do so will result in loss of dial settings.

(1) Knob "A" is the coarse control of the high frequency oscillator. There are 12 high frequency positions, each marked with its frequency coverage in megacycles. Knob "A" also serves in Position 13 as a transfer switch to disconnect the high frequency oscillator and to connect the low frequency oscillator.

(2) Knob "B" is the fine tuning control for high frequency operation. It consists of a main tuning knob, calibrated 0-100 which rotates 20 turns for each tuning range, and a small counter dial which counts turns of the large knob. The dial reading is the reading of the counter dial followed by the reading of the large knob. For example, if the counter dial is between 16 and 17, and the large knob is at 43, the dial would be read as 1643.

(3) Knob "C" is a coarse antenna tuning control, operating a tap switch. This tap switch changes inductance and capacity in various combinations for different frequencies, and to tune different antennas. In general, the dial settings increase with frequency. An interlock on this switch opens

b. TO STOP THE EQUIPMENT.

- (1) Remove the carrier from the air (release the telegraph key or Push-to-Talk button.)
- (2) Operate the NAVY 4 WIRE CONTROL switch to the OFF position.
- (3) The equipment can also be stopped by operating the 4 WIRE POWER switch on the front panel of the power unit to the OFF position.

6. REMOTE CONTROL - NAVY TYPE COL-23410 REMOTE CONTROL UNIT.

Emission selection, Channel selection and Carrier control is possible from the NAVY TYPE COL-23410 Remote Control Unit. However, the power unit must be placed in operation from the front panel or by the use of either the NAVY 4 WIRE or 6 WIRE control circuits. If the NAVY CONTROL circuits are not used, place transmitter unit LOCAL-REMOTE switch S-107 on the transmitter unit panel in the REMOTE position and use the instructions in paragraph III-2 or III-3 to set the equipment in operation, after which the emission can be controlled by Emission selection switch S-903, the channel selection can be made by CHANNEL selector switch S-902 and the carrier controlled by a telegraph key plugged into KEY jack J-904 or by a Push-to-Talk button on a microphone plugged into MIKE jack J-903.

If the Remote Control Unit is used with NAVY CONTROL circuits, the equipment should be started and adjusted using instructions in paragraph III-4 for NAVY 6 WIRE circuits or paragraph III-5 for NAVY 4 WIRE circuits after which emission selection, channel selection, and carrier control can be had as described above. In this instance, however, it is best that the carrier be controlled by the NAVY CONTROL keying circuits since the receiver interlock relay is inoperative when carrier control is attempted from the front panel or the Remote Control Unit when the power unit LOCAL-REMOTE switch is in the REMOTE position.

7. FUNCTION OF CONTROLS.

a. POWER UNIT.

- (1) The ON push button is used to apply primary power to the low voltage dynamotor when 6-WIRE control is employed.
- (2) The OFF push button, when pressed, completely stops the equipment by removing all primary power from the power components in 6 WIRE operation.
- (3) The 4 WIRE POWER switch is a toggle switch connected to apply primary power to the low voltage dynamotor when the 4 WIRE-6 WIRE switch is in the 4 WIRE position. Opening the 4 WIRE POWER removes all power from the power components.
- (4) The EMERGENCY switch is a DPST switch connected in the power line which will, when opened, remove primary power from all components except line fuses.
- (5) The power unit LOCAL-REMOTE switch is a multi-contact key switch which is employed to transfer the power control circuits and carrier control circuits from the equipment panel to NAVY 4 WIRE or 6 WIRE circuits.

a. TO START THE EQUIPMENT.

- (1) Place the power unit LOCAL-REMOTE switch in the REMOTE position.
- (2) Place the transmitter unit LOCAL-REMOTE switch in the LOCAL position.
- (3) Place the 4 WIRE-6 WIRE selector switch in the 6 WIRE position.
- (4) Place the 4 WIRE POWER switch in the OFF position.
- (5) Operate the EMERGENCY switch to the NORMAL position.
- (6) Press the NAVY CONTROL ON push button. Allow 30 seconds for the tubes to heat.
- (7) The carrier can now be controlled by telegraph key or Push-to-Talk button.

b. TO STOP THE EQUIPMENT.

- (1) Open carrier control device (key, push button, etc.)
- (2) Press NAVY CONTROL OFF button.
- (3) The equipment may also be stopped by pressing OFF button on the front panel of the power unit.

5. REMOTE CONTROL - NAVY 4 WIRE. (Refer to Figure 3-1)

Power control and carrier control are the only operations possible with this type of control, therefore, the tuning adjustments and emission selection must have been made previous to the following steps. Follow instructions in paragraph III-3.

a. TO START THE EQUIPMENT.

- (1) Place the power unit LOCAL-REMOTE switch in the REMOTE POSITION.
- (2) Place the transmitter unit LOCAL-REMOTE switch in the LOCAL position.
- (3) Place the 4 WIRE-6WIRE switch in the 4 WIRE position.
- (4) Place the power unit 4 WIRE POWER switch in the ON position.
- (5) Operate the EMERGENCY switch to the NORMAL position.
- (6) Operate the NAVY 4 WIRE CONTROL switch to the ON position. Allow 30 seconds for the tubes to heat.
- (7) The carrier can now be controlled by telegraph key or Push-to-Talk button.

d. TO STOP THE EQUIPMENT.

- (1) Open carrier control device (Key, Push-to-Talk button, etc.)
- (2) Press the OFF push button.

3. LOCAL OPERATION - 4 WIRE. (Refer to Figure 3-1)

CAUTION

Be certain that the 4 WIRE POWER switch is in the OFF position.

a. TO START THE EQUIPMENT.

- (1) Place the power unit LOCAL-REMOTE switch in the LOCAL position.
- (2) Place the 4 WIRE-6 WIRE selector switch in the 4 WIRE position.
- (3) Operate the EMERGENCY switch to the NORMAL position.
- (4) Operate the 4 WIRE POWER switch to the ON position. Allow 30 seconds for the tubes to heat.
- (5) Proceed to tune and adjust the equipment as outlined in paragraphs III-8, a, (1) to III-10.

b. TO SELECT EMISSION.

- (1) Open carrier control device (Key, Push-to-Talk button, etc.)
- (2) Operate the EMISSION selector switch to the desired type of emission.
- (3) Control carrier as desired.

c. TO SHIFT FREQUENCY.

- (1) Open carrier control device (Key, Push-to-Talk button, etc.)
- (2) Operate the channel selector switch to the desired frequency, allow the Autotune to operate.
- (3) Control carrier as desired.

d. TO STOP THE EQUIPMENT.

- (1) Open carrier control device (Key, push button, etc.)
- (2) Operate the 4 WIRE POWER switch to OFF.

4. REMOTE CONTROL - NAVY 6 WIRE. (Refer to Figure 3-1)

Power control and carrier control are the only operations possible with this type of control, therefore, the tuning adjustments and emission selection must have been made previous to the following steps. Follow instructions in paragraph 2 of this section for tuning and emission selection.

SECTION III

OPERATION

1. EMERGENCY SHUT DOWN.

- a. OPERATE EMERGENCY SWITCH TO OFF POSITION.
- b. LOCATE LINE SWITCH TO RADIO EQUIPMENT AND OPERATE TO OPEN POSITION.

WARNING

THIS EQUIPMENT EMPLOYS VOLTAGES WHICH ARE DANGEROUS AND MAY BE FATAL IF CONTACTED BY OPERATING PERSONNEL. EXTREME CAUTION SHOULD BE EXERCISED WHEN WORKING WITH THE EQUIPMENT.

2. LOCAL OPERATION - 6 WIRE. (Refer to Figure 3-1)

a. TO START THE EQUIPMENT.

- (1) Place the power unit LOCAL-REMOTE switch in the LOCAL position.
- (2) Place the 4 WIRE-6 WIRE selector switch in the 6 WIRE position.
- (3) Place the 4 WIRE POWER switch in the Off position.
- (4) Operate the EMERGENCY switch to the NORMAL position.
- (5) Press the ON push button. Allow 30 seconds for the tubes to heat.
- (6) Proceed to tune and adjust the equipment as outlined in paragraphs III-8, a, (1) to III-10.

b. TO SELECT EMISSION.

- (1) Open carrier control device (Key, Push-to-Talk button, etc.)
- (2) Operate the EMISSION selector switch to desired type of emission.
- (3) Control Carrier as desired.

c. TO SHIFT FREQUENCY.

- (1) Open carrier control device (Key, Push-to-Talk button, etc.)
- (2) Operate the CHANNEL selector switch to desired frequency, allow autotune to operate.
- (3) Control carrier as desired.




Figure 3-1 Navy Model TCZ-2 Operating Controls

After Control "A" has been set up, Control "B" and Controls "F" and "G", the oscillator tuning controls may be set to exact frequency with the aid of the CFI unit and calibration tables.

Next in order, Controls "C", "D", and "E" may be set up in the high frequency ranges, also Controls "P," "Q," "R," "S" and "T" on the Antenna Load Coil for the single low frequency position. It is suggested that Control "C" be set at position 8 when the transmitter is being used in the LF range as this position provides the least reaction of the HF network to operation within this range.

After all AUTOTUNE Elements have been set to the desired positions, the CHANNEL selector switch, S-108, may be switched to the various channels and accuracy of reset of AUTOTUNE Elements observed.

It is important that personnel engaged in pre-operation adjustments read the sections of this book on OPERATION and MAINTENANCE. Other checks may suggest themselves from these sections on both pre-installation and pre-operation performance.

(d) Example: It is desired to work on 9653 kilocycles. The next lower frequency given in the table is 9650, and the difference is 3. The number in parenthesis at the right of the column is 0.8. Multiplying 3 by 0.8 gives 2.4. Adding 2.4 to 636, which is the dial setting for the next lower frequency, gives 638.4 as the dial setting for 9653 kilocycles.

d. AUTOTUNE CHECKS.

(1) While checking the AUTOTUNE operation and setting, the EMISSION selector switch, S-110, should be placed in the VOICE position. With S-110 in the VOICE position, the AUTOTUNE system may be operated without starting the high voltage dynamotor. Placing S-110 in the VOICE position operates the voice relay, K-104.

(2) Make certain that the MICROPHONE, KEY and Throttle switch jack circuits are open.

(3) Rotate the CHANNEL selector switch, S-108, to Position 1.

NOTE

If the AUTOTUNE system begins to run, allow it to complete the cycle of operation before proceeding.

(4) Turn the locking bar on the AUTOTUNE Control one-quarter revolution in the counterclockwise direction or until the two red spots appear completely on the dial.

(5) Rotate the Control one eighth turn each side of the desired setting and approach the final setting in a clockwise direction.

NOTE

To prevent displacement of the AUTOTUNE stop rings, and to take out all slack in the mechanism, the controls should be rotated until the desired readings are obtained and the readings noted; then the controls should be rotated one eighth turn each side of the desired setting. The final setting should then be approached in a clockwise rotation.

(6) Lock the AUTOTUNE stop rings in position by holding the dial in the correct position and by turning the locking bar in a clockwise direction until tight. When the dial has been locked, check the position by operating the Control in a clockwise direction until the stop ring prevents any further rotation of the control. Check the position of the control against the indicator mark on the transmitter panel. The settings of controls "A" and "C" are critical. The transmitter will not operate if these Controls are not set properly.

(7) A complete check of the AUTOTUNE System would be to set the transmitter up on all eleven channels. In doing so, Control "A" should be set up for all ten high frequency positions first, setting the lowest frequency on position 1 of Control "A". The LF position would then be set up on Control "A" making sure that the control stops exactly on position 13.

(h) Turn CALIBRATE-TUNE-OPERATE switch to TUNE.

(i) Turn Knob "G" to the dial setting given in the table for the desired frequency. Tighten dial lock.

(j) The low frequency oscillator is now set on the desired frequency. If it is desired to tune the output and antenna circuits of the transmitter into an antenna, proceed as described in Paragraph III-9.

(3) FOR FREQUENCIES BETWEEN 2000 AND 18,100 kc.

(a) Turn CHANNEL switch to desired channel.

(b) After motor stops, loosen locking bar on Knob "A". Set this knob to the position shown in the table for the desired frequency, approaching the setting clockwise through at least one eighth turn and tighten the locking bar.

(c) Turn CALIBRATE-TUNE-OPERATE switch to CALIBR/TE.

(d) Loosen locking bar in Knob "B". Turn Knob "B" to the dial setting of the nearest crystal check point, shown in heavy type in the group of frequencies in the table containing the desired frequency. Adjust Knob "B" accurately for zero beat in the headphones.

(e) Leave Knob "B" at zero beat and adjust the CORRECTOR which moves the indicating mark over "B" until the dial reading at the mark is correct for the check point.

(f) Turn CALIBRATE-TUNE-OPERATE switch to TUNE.

(g) Turn Knob "B" one eighth turn each side of the dial setting given in the table for the desired frequency. Approach the given dial setting clockwise through at least one eighth turn. Hold knob on setting and tighten locking bar.

(h) The high frequency oscillator is now set on desired frequency. If it is desired to tune the output and antenna circuits to an antenna, proceed as described in Paragraph III-10.

(4) The calibration tables give dial settings at 2 kc intervals from 200 to 500 kilocycles; 5 kc intervals from 500 to 8000 kilocycles; and 10 kc intervals from 8000 to 18,100 kilocycles. The transmitter can also be set to frequencies between those given in the table by the following simple method:

(a) Find the difference between the desired frequency and the next lower frequency given in the table.

(b) Multiply this difference by the number given in parenthesis at the right of the column of figures containing the next lower frequency.

(c) Add the product thus obtained to the dial setting given in the table for the next lower frequency. The result is the dial setting for the desired frequency.

If resonance cannot be established with Control "T" in position 1, try other positions of Control "T" until the point of resonance is found. The plate current reading will vary between 70 and 130 on the plate current meter.

NOTE

Since it is possible to double the frequency in the PA stage, the resonance point lowest in frequency will be the correct point.

Check each position of Control "F" in like manner.

c. ADJUSTMENT OF TRANSMITTER ON DESIRED FREQUENCY USING INTERNAL CRYSTAL FREQUENCY CALIBRATOR.

(1) GENERAL.

(a) Plug a pair of headphones into the No. 1 sidetone jack on the transmitter. Sidetone No. 2 cannot be used unless proper external connections have been made through remote jack J-106 or terminal board J-1903. See paragraph II-8d.

(b) Turn LOCAL-REMOTE switch to LOCAL.

(c) Find desired frequency in calibration table, Table 3-1 or Table 3-2.

(d) The main frequency controls ("E" for the high frequency range and "G" for the low frequency range) each rotate 20 turns to cover a tuning range. The dial reading given in the table is the number of turns indicated on the small turn counter followed by the dial setting of the large knob. Thus, the dial reading shown in figure 3-3 is 1447.

(2) FOR FREQUENCIES BETWEEN 200 AND 1500 kc.

(a) Turn CHANNEL switch to L.FREQ.

(b) Turn EMISSION switch to VOICE.

(c) After motor stops, see that Knob "A" is at Position 13. If not, loosen locking bar, rotate Knob "A" to 13, approaching the setting clockwise through at least one eighth turn and tighten locking bar.

(d) Set switch "F" to the position given in the table for the desired frequency.

(e) Turn CALIBRATE-TUNE-OPERATE switch to CALIBRATE.

(f) Loosen dial lock and turn Knob "G" to the dial setting of the nearest crystal check point, shown in heavy type in the group of frequencies containing the desired frequency. Adjust Knob "G" accurately for zero beat in the headphones.

(g) Leave Knob "G" at zero beat and adjust the CORRECTOR which moves the indicating mark until the dial reading at the mark is correct for the check point.

- (21) Place the EMERGENCY switch in the OFF position.
- (22) After rotation of the high voltage dynamotor has stopped, insert the 1150 volt supply fuse F-1908 and replace the fuse cover.
- (23) Turn the EMERGENCY switch to NORMAL and press the ON button.
(The low voltage dynamotor should start and all the filaments should light.)
- (24) Place the meter switch in the PA PLATE position.
- (25) After the filaments have warmed up at least thirty seconds, press the TEST key.
(An indication of plate current should be seen on the voltage-current indicating meter.)
- (26) Release the TEST key and press the OFF button.
- (27) Place the 4 WIRE-6 WIRE switch in the 4 WIRE position.
- (28) Turn the 4 WIRE POWER switch to ON.
(The low voltage dynamotor should start and the transmitter tubes should light.)
- (29) After the filaments have warmed up at least thirty seconds, press the TEST switch.
(An indication of plate current should be observed on the voltage-current indicating meter.)
- (30) Release the TEST key and turn the 4 WIRE POWER switch to the OFF position.
(All of the above operating circuits should turn off.)
- (31) Make certain that the Navy remote control circuits are turned off.
- (32) Place the power unit LOCAL-REMOTE switch in the REMOTE position.
- (33) Turn the 4 WIRE-6 WIRE switch to the proper position for the Navy remote control circuits which are to be used and check the operation of these controls.

b. RF CIRCUITS.

- (1) Place the equipment in LOCAL control and check the transmitter for each position of the Control "A". (By placing CHANNEL selector switch S-108 in the MANUAL position the dials can be turned without unlocking the locking bars.) Position 13 of Control "A" is for the LF range 200 kc to 1500 kc.
- (2) Check the LF circuits by placing CHANNEL selector switch S-108 in the L. FREQ. position. After the AUTOTUNE has operated, Control "A" should be exactly on position 13. If Control "A" is not on position 13, the locking bar should be released and the dial turned to position 13 after which the locking bar should be tightened again. Place Control "F" COARSE tuning in position 1. Place Control "R" on the load coil in the 200 to 575 kc position and Control "T" in position 1. Press TEST key S-104 and seek resonance with Control "S".

- (4) Close the line switch to the radio equipment, place the EMERGENCY switch in the NORMAL position and press the ON button.
(The low voltage dynamotor should start.)
- (5) Press the OFF button.
(The low voltage dynamotor should stop)
- (6) Insert the 28 volt supply fuse F-1905 and the 14 volt supply fuse F-1906.
- (7) Press the ON button.
(The low voltage dynamotor should start and the transmitter tubes should light. If the AUTOTUNE motor starts allow it to complete operation)
- (8) Press the OFF button.
(The low voltage dynamotor should stop and all filaments should go out)
- (9) Turn the EMERGENCY switch to OFF.
- (10) Insert the high voltage dynamotor primary fuse F-1904.
(Be sure that both fuse covers are in place.)
- (11) Turn the EMERGENCY switch to NORMAL and press the ON button.
(The low voltage dynamotor should start and the transmitter tubes should light.)
- (12) Press the TEST switch.
(The high voltage dynamotor should start.)
- (13) Release the TEST switch and press the OFF button.
(Both dynamotors should stop and the filaments should go out.)
- (14) Turn the emergency switch to OFF.
- (15) Be certain that the high voltage dynamotor has ceased to rotate, so that there is no voltage on the 400 volt and 1150 volt supply fuse clips, and then insert the 400 volt supply fuse F-1907 and replace the fuse cover.
- (16) Turn the EMERGENCY switch to NORMAL and press the ON button.
(The low voltage dynamotor should start and all tubes should light.)
- (17) Turn the meter switch to PA GRID.
- (18) Check the position of controls "A" and "C", and if they are not set accurately on numbers unlock the locking bars and set them.
- (19) After the filaments have warmed up at least thirty seconds, press the TEST switch.
(An indication of PA grid current should be observed on the voltage-current indicating meter.)
- (20) Release the TEST switch and press the OFF button.
(All of the above operating circuits should turn off.)

The fuses should be examined and their ratings checked against the table provided. It is good practice to insert each fuse as required during the initial adjustment procedure in order that any faults which may be due to errors in the interconnecting of the units or unintentional grounding of terminals may be quickly determined and also to check and clear each individual circuit in the proper sequence. Refer to paragraph II-11a for detailed instructions. The fuses used in this equipment with the Symbol Designation of the fuses and the circuit in which these are located are tabulated below:

TABLE 2-1 TABLE OF FUSES

<u>Symbol Designation</u>	<u>Rating Amps.</u>	<u>Circuit</u>
F-1901	30	Power Line
F-1902	30	Power Line
F-1903	15	Low Voltage Dynamotor Primary
F-1904	15	High Voltage Dynamotor Primary
F-1905	15	28 v Supply
F-1906	3	14 v Supply
F-1907	1	400 v Supply
F-1908	1	1150 v Supply

11. PRE-OPERATION ADJUSTMENT.

Before placing the equipment in routine service a complete check of all controls should be made. The following steps will prepare the equipment for final adjustment and operation.

a. POWER UNIT.

- (1) Be certain that the line switch to the radio equipment is open.

Remove all fuses from the fuse holders and check their ratings with table 2-1. (The line switch to the radio equipment must always be open when removing or inserting the line fuses F-1901 and F-1902 as these fuses are on the line side of all the power unit switches.)

- (2) Place the EMERGENCY switch in the OFF position.

Place the power unit LOCAL-REMOTE switch in the LOCAL position.

Place the 4 WIRE-6 WIRE selector switch in the 6 WIRE position.

Place the 4 WIRE POWER switch in the OFF position.

Make sure that all local key and microphone circuits and all remote key and microphone circuits are open.

Turn the transmitter power level switch to TUNE.

Turn the EMISSION selector switch to VOICE.

Rotate the CHANNEL selector switch to position 1.

Place the transmitter LOCAL-REMOTE switch in the LOCAL position.

- (3) Insert the line fuses F-1901 and F-1902 and the low voltage dynamotor primary fuse F-1903.

WARNING

Be sure that all panels, covers and enclosures are in place. The high voltages present are dangerous to life.

possible and the leads should be kept short and direct.

The Type COL-481628 Antenna Shunt Capacitor should be connected between terminal, J-118, engraved COND., and ground. A heavy, stranded conductor should be used to make the connections and the lead between J-118 and the capacitor should be formed to clear all metal objects by at least an inch and a half.

A good ground connection to the frame of the ship should be made to the terminal designated as GROUND, J-113, using heavy bus or a heavy stranded conductor and keeping the lead as short as practicable.

To complete the installation connections, connect a jumper between the antenna terminal on the receiver and the RECEIVER terminal, J-110, on the transmitter.

d. SIDETONE CONNECTIONS. - A connection for keying of double sidetone, utilizing auxiliary jack J-105 in connection with SIDETONE jack J-104, can be made by connecting jumper wires from terminals number 26 to 27 of remote jack J-106.

Connection for the purposes described can be made in a dummy plug used in remote jack J-106 if REMOTE control of the transmitter is not desired. In case REMOTE control of the transmitter is desired it will be necessary to jumper terminals 26 and 27 on terminal board J-1903.

9. CONNECTIONS TO NAVY CIRCUITS.

This radio transmitting equipment is designed to operate as a unit controlled by controls contained completely within the equipment or controlled by Standard Navy 4 WIRE-6 WIRE and Telephone Control Circuits (Spec. RE 13A 592B)

a. 4 WIRE-6 WIRE TRANSMITTER CONTROL. - The transmitting equipment can be started, stopped and keyed using either 4 WIRE or 6 WIRE circuits by connecting the 4 WIRE or 6 WIRE circuits through the ship's distribution board to terminals 1 to 6 inclusive on J-1905, in the base of the Power Unit. See figure 4-12 for applicable circuits.

b. TELEPHONE CIRCUITS. - The TCZ-2 equipment is arranged for carrier control and carrier modulation when connected to the ship's distribution board. The equipment also provides a suitable low voltage DC for microphone circuits. Connections for these circuits are provided on J-1905 terminals 7, 8, 9, 10, 11 and 12. Refer to figures 4-12 and 4-13.

c. RECEIVER PROTECTING RELAY. - A set of SPDT contacts have been provided on the keying relay which may be used to turn the receiver off when the transmitter carrier is turned on. The set of SPDT contacts are brought out to terminals 17, 18, and 19 of terminal board J-1905. Refer to the Power Unit schematic figure 7-47.

10. FUSES.

All fuses for the TCZ-2 equipment are located on either side of the power unit control panel. The fuses are protected by covers which may be removed by loosening the four thumb-nuts.

these cables. The type cable using part number 424 0007 00 wire has wires coded by color and various numbers of ridges on the insulation while the type using part number 424 2710 00 wire has wires coded by multi color insulation. The table has information for connecting either type of cable.

J-1903 TERM. NO.	424 0007 00 CABLE DATA		424 2710 00 CABLE DATA		
	CONDUCTOR COLOR	NUMBER OF RIDGES	CONDUCTOR BODY COLOR	FIRST TRACER	SECOND TRACER
1	GRAY	0	GREEN	WHITE	
2	BROWN	0	RED	WHITE	
3	BROWN	1	ORANGE	WHITE	BLACK
4	GRAY	1	BLUE	WHITE	
5	WHITE	1	BLACK		
6	WHITE	2	GREEN	BLACK	
7	BROWN	2	RED	BLACK	
8	GREEN	2	WHITE		
9	WHITE	0	ORANGE	BLACK	
10	BLACK	0	BLACK	WHITE	
11	YELLOW	0	WHITE	BLACK	
12	YELLOW	1	GREEN	BLACK	WHITE
13	GREEN	1	BLACK	RED	
14	RED	0	RED		
15	RED	1	BLUE	BLACK	
16	BLACK	2	BLUE		
17	BLACK	1	WHITE	RED	BLACK
18	YELLOW	2	RED	WHITE	BLACK
19	ORANGE	2	WHITE	RED	
20	WH. & BLACK IN SHIELD		BLUE (SHIELDED)	WHITE	BLACK
21	GREEN	0	GREEN		
22	RED	2	ORANGE		
23	BLUE	0	BLACK	WHITE	RED
24	ORANGE	1	ORANGE	RED	
25	ORANGE	0	BLUE	RED	
26	BLUE	2	RED	GREEN	
27	BLUE	1	ORANGE	GREEN	

The locking rings on the plugs should be tightened.

NOTE

Safety wires should be inserted in the locking rings to prevent them from loosening under conditions of vibration.

c. ANTENNA CONNECTIONS. - Five terminals on the left hand end of the transmitter cabinet provide terminals for connecting the antenna shunt capacitor, the load coil, the receiver antenna terminal and a ground.

A connection should be made from J-3002 on the load box to the LOADING COIL terminal J-117 on the transmitter and a good ground from the frame of the ship should be made to GROUND terminal J-3003 on the load box. Connect terminal J-3004 on the load box to FIXED ANTENNA terminal J-109 on the transmitter. The antenna is connected to ANTENNA terminal J-3005 on the load coil box. Heavy stranded conductors should be used for all connections where

7. CABLES.

The external cables used with this equipment are furnished completely assembled. The construction of the 65X-7 and 65X-8 cables is shown in figures 7-41 and 7-42 respectively while the construction of the 65X-9 cable which furnishes relay power to the load box is shown in figure 7-43. Refer to figure 7-44 for details of the 65X-10 remote control cable. The cables should be installed allowing sufficient length for free action of the shock mounts. Bends in the cables should be made with a radius of not less than eight inches.

8. CONNECTIONS.

After all units have been mounted, the installation may be completed by making the power, inter-unit and antenna connections. Refer to the installation diagram, figure 2-1.

a. POWER CONNECTIONS. - Connections from the power unit to the power source should be made using two heavy cables. Two #12 AWG wires in parallel for each lead are recommended.

Connections to the terminals provided in the base of the power unit should be clean and firm as there is considerable power drawn from the power source.

b. INTER-UNIT CONNECTIONS. - Connections from the transmitter to the power unit are made by pre-assembled cables, see figures 7-41 and 7-42. The 65X-7 cable is a 27 wire cable used to transfer the control circuits from the transmitter to the base terminals of the power unit for use with the remote control box. The 65X-8 cable is a 10 wire cable used to convey the filament and plate power from the power unit to the transmitter. Each of the above cables is approximately 10-1/2" long including the connectors.

The 65X-7 and 65X-8 cable connectors should be inserted in their respective sockets and the locking rings tightened.

The 65X-9 cable is used to connect the relay power to the Antenna Load Coil. While this cable, as supplied, is ten feet long, it may be cut to the proper length for the installation by using instructions shown on figure 7-43. The right angle connector is inserted in J-3006 on the load coil and the straight connector is inserted in J-107 on the transmitter. Receptacle J-107 may be equipped with a dust cap which must be removed by turning counter-clockwise before the cable connector plug can be inserted.

The Remote Control Unit is connected to the base of the Power Unit by the 65X-10, 27 conductor cable. The end of the cable terminated by a plug is connected to the Remote Control Unit. The opposite end which is terminated by spade-type lugs is connected to J-1903 in the base of the Power Unit. Figure 7-44 shows the construction of the 65X-10. Note that the ends of the wires containing the spade-lugs are color coded. The numbers adjacent to the lugs on the illustration represent the terminal numbers on terminal board J-1903.

The following table contains information necessary for connecting the Collins 65X-10 Remote-to-Power Unit cable to connector strip J-1903 in the base of the Power Unit. Two different types of wire were used in making up

ing foot has 2 holes, which are $13/32$ " in diameter, for bolting the unit to the deck. $3/8$ " bolts may be used for this purpose.

Sufficient space should be left between the sides of the cabinet and surrounding objects to permit free circulation of air around and through the cabinet.

The external cable connections are made through the bottom of the power unit near the front edge, to a terminal board that is accessible by removing the bottom front panel.

c. DYNAMOTORS, - Each dynamotor of the power unit is mounted on a removable chassis. All power connections are made to plugs at the rear of the chassis which engage socket terminals as the chassis is inserted into the power unit. The chassis should be shoved straight into their respective positions with the high voltage dynamotor on the right, viewed from the front, and the low voltage dynamotor on the left. The thumb-nut locks should be rotated as far as they will go in the counterclockwise direction and then rotated in the clockwise direction until they secure the units into place.

d. PANELS. - The removable panels and covers on the power unit are equipped with thumb-nuts that may be secured in position by a locking wire. In installations where severe vibration is encountered, locking wires should be inserted through the thumb-nuts and through the tabs on the panels after which the ends of the wires should be twisted.

e. ANTENNA LOADING COIL. - Installation drawing, figure 7-39, shows the outline dimensions and the distances between centers of the mounting holes for the Antenna Loading Coil.

The loading coil cabinet may be mounted on either the bottom or rear. The unit should be mounted within easy reach of the transmitter unit to facilitate the adjustment of the controls on the panel when making tuning adjustments for low-frequency operation.

The mounting centers are $9-1/2$ " x $14-3/4$ " on the bottom and $15-5/8$ " x $14-3/4$ " on the rear. All mounting holes are drilled for $1/4$ " screws.

f. REMOTE CONTROL UNIT. - The Type COL-23410 Control Unit should be mounted in a position convenient to the operator. Figure 7-38 shows the outline dimensions and mounting details of the unit.

g. ANTENNA CAPACITOR. - If operation in the frequency range of 2000 kc to 3000 kc is contemplated and the antenna does not have sufficient capacity to permit the tuning of the output circuit within this frequency range, the Type -481628 Antenna Shunt Capacitor should be connected between the COND. terminal, just below the ANT. terminal on the left-hand end of the transmitter, and ground.

Figure 7-40 shows the outline dimensions and mounting details of the Type -481628 Antenna Shunt Capacitor.

The capacitor should be mounted as close as possible to the left end of the transmitter cabinet so that the lead between the COND. terminal and the capacitor unit will be as short as possible. The length of lead must not exceed 12 inches.

Plug the crystal unit into the two prong socket in the extreme rear right-hand corner of the transmitter as illustrated in figure 2-2.

Replace the cabinet cover and fasten securely in position with the clamping screws.

5. OPERATIONAL CHECK.

It is recommended that the complete equipment be given an operational check before installing the units in the ship. Considerable time and labor may be saved if all units are in working order before installation. Where numerous installations are to be made, it is recommended that a test bench be set up so that each equipment may be given a careful electrical check prior to installation for operation.

In addition to the regular units supplied with the TCZ-2 Series Equipment, it will be necessary to have available a DC source of power of approximately 115 volts potential, a set of test cables with plugs and cabling of the same type as supplied with the equipment, a set of earphones (500 ohm impedance), a single button carbon or dynamic microphone similar to the microphone that is to be used in actual operation of the equipment, a telegraph key and a dummy antenna load consisting of from 3 to 5 ohms of resistance in series with approximately 100 mmf of capacity.

NOTE

Make certain that the microphone circuit switch, S-201, is in the correct position for the type of microphone that is being used.

Using the above mentioned accessories, carefully check the operation of the transmitter unit, the power unit, and the remote control unit. Check the equipment with all types of emission and both remote and panel control. Refer to paragraph II-11 for instructions. If any trouble is found, it will be much less difficult on the work bench than after the installation has been completed. When the equipment has been carefully checked, the installation on shipboard may be made.

6. MOUNTING OF UNITS.

a. TYPE -52286-A TRANSMITTER UNIT. - The transmitter unit is equipped with detachable sliding mounting tracks. Rubber shock mounts incorporated in the mounting tracks reduce the effect of the vibration and shock encountered in normal service to a minimum.

When the power unit is securely bolted in position, the transmitter may be slid into position from the front of the track slide or may be lowered into the slots and then slid backward approximately two inches. When the unit has been placed, the locking knob on the front edge of the track should be rotated in a clockwise direction to the locked position.

b. POWER UNIT. - The overall dimensions for the power unit with the mounting feet positioned as furnished are: 29-7/16" high, 23-7/16" wide, and 20-1/8" deep. Note that the height is 39-5/8" for the power unit and transmitter combined. The dimensions change slightly if the mounting feet are rotated 90 degrees. Refer to figure 7-37 for mounting layout and dimensions. Each mount-

SECTION II

INSTALLATION AND ADJUSTMENT

1. UNCRATING.

Open packing crates with care. When crates are marked with arrows to indicate upright position, remove crate covers only and lift units out carefully. Search all packing material for small packages. Inspect cables and wiring and be sure that all terminal connections are tight. Inspect each unit for loose screws and bolts. Be sure that all controls such as switches, dials, etc., work properly. All claims for damage should be filed promptly with the transportation company. If a claim for damage is to be filed, the original packing case and packing material must be preserved.

2. GENERAL.

Figure 2-1 shows a complete TCZ-2 installation with all the accessories necessary for transmission on any frequency within the frequency range of the transmitter and with transmitter control from either the transmitter panel or from a remote position. If the fixed antenna has sufficient capacity the Type -481628 Antenna Shunt Capacitor Unit may be omitted from the installation.

The first step in preparing the transmitter for installation is to check the vacuum tubes and calibration crystal for placement in the proper sockets. The transmitting tubes and the crystal unit can be installed from the top of the transmitter unit. To remove the transmitter cabinet cover, loosen the cover hold-down screws and lift the cover upward. To remove the shield cover from the low-frequency oscillator unit remove the six screws and lift the cover off.

3. TUBES.

The tube and fuse placement diagram, figure 2-2, includes an outline drawing of the top view of the transmitter unit with cover removed. This drawing shows the proper location of the transmitting tubes and illustrates the operation of the tube clamps. Also refer to figure 7-2.

Place all plate lead connectors firmly on the plate caps of the 811, 813, 837, and 1625 tubes and lock tube clamps.



Fasten the oscillator shield cover securely in position with the securing screws.


4. CRYSTALS.

The quartz crystal has been carefully calibrated, checked and sealed in the holder at the factory.

The Type CR-2-B/U (200 kc) Crystal Unit is designed to mount in a two terminal crystal socket.

Figure 2-2 Navy Model TCZ-2 Tube and Fuse Placement Diagram





* THESE UNITS AND CABLES NOT SUPPLIED ON CONTRACT. BENDING RADIUS OF COLLINS TYPE 65X-9 AND 65X-10 CABLES, NOT LESS THAN 8 INCHES.

Figure 2-1 Complete Navy Model TCZ-2 Installation Diagram

internal resistance. When the circuit selector switch is in the DYNAMIC position the input circuit will match a dynamic microphone of approximately 200 ohms internal resistance.

The audio input to the equipment from Standard Navy Control Circuits (Spec. RE 13A 592B) is through an impedance matching transformer. The primary is tapped at 200, 400, and 600 ohms impedance while the secondary is tapped at 42, 60, 82, and 106 ohms impedance. These taps can be changed to suit the existing conditions.

k. ELECTRICAL CHARACTERISTICS OF RECOMMENDED ANTENNAS. - 25 foot (117 mmf) to 35 foot (135 mmf) whip antenna having a 6 foot lead-in.

1. TUBE DESIGNATION AND FUNCTION.

<u>Symbol</u> <u>Designation</u>	<u>Type</u> <u>Number</u>	<u>Quantity</u>	<u>Circuit Function</u>
V101	837	1	High Frequency Oscillator
V102	1625	1	1st Multiplier
V103	1625	1	2nd Multiplier
V104	813	1	Power Amplifier
V105	811	1	Modulator
V106	811	1	Modulator
V201	12SJ7	1	1st Audio Amplifier
V202	6V6GT	1	Audio Driver
V203	6V6GT	1	Sidetone Amplifier
V401	1625	1	Low Frequency Oscillator
V2201	12SL7GT	1	Osc-Tripler
V2202	12SA7/GT	1	Mixer
V2203	12SL7GT	1	Detector-Audio Osc

Ø m. CHARACTERISTICS OF POWER SUPPLY

(1) Voltage: 115 volts DC

(2) Current required at 115 supply volts for:

(a) Maximum starting:

(b) Standby:

(c) Normal Operation:

1. With filaments on:

2. Locked key CW:

3. Locked key (Voice):

g. AUDIO FREQUENCY RESPONSE.




Figure 1-10 Overall Frequency Response Curve

h. CRYSTAL. - One CR-2-B/U (200 kc). CFI unit crystal, 200 kc output.

i. FREQUENCY STABILITY DATA.

(1) Frequency Variation with Temperature Change:

Temp. Change	% Frequency Deviation			
	2.0 mc	2.4 mc	3.0 mc	6.0 mc
-10°C (14°F) to 0°C (32°F)	0.0006	0.0027	0.0011	0.0116
0°C (32°F) to 10°C (50°F)	0.0014	0.0027	0.0004	0.0147
10°C (50°F) to 20°C (68°F)	0.0009	0.0044	0.0008	0.0123
20°C (68°F) to 30°C (86°F)	0.0030	0.0018	0.0027	0.0124
30°C (86°F) to 40°C (104°F)	0.0000	0.0042	0.0015	0.0109
40°C (104°F) to 50°C (122°F)	0.0042	0.0040	0.0015	0.0126

(2) Frequency Variation with Change in Humidity:

Humidity Change	% Frequency Deviation			
	2.0 mc	2.4 mc	3.0 mc	6.0 mc
30% to 95%	0.0073	0.0058	0.0097	0.0153
95% to 30%	0.0046	0.0000	0.0050	0.0153

i. INPUT IMPEDANCE. - The audio input circuit of the equipment is designed to match the output of either a carbon or dynamic microphone. A switch selects the proper input circuit to correspond to the type of microphone that is to be used. When the microphone circuit selector switch is in the CARBON position the input circuit will match a carbon microphone of approximately 40 ohms

2000 kc to 18,100 kc in the High Frequency Range. The frequency is continuously variable within the two ranges. The transmitter can be pre-set on ten HF positions and one LF position by Local Control only. However, these pre-set positions can be selected by either Local Control or by Remote Control using the Navy Type COL-23410 Remote Control Unit.

b. TUNING BANDS.

<u>Band</u>	<u>Frequency Range</u>
1	2.0 to 2.4 mc
2	2.4 to 3.0 mc
3	3.0 to 3.6 mc
4	3.6 to 4.0 mc
5	4.0 to 4.8 mc
6	4.8 to 6.0 mc
7	6.0 to 7.2 mc
8	7.2 to 9.0 mc
9	9.0 to 10.8 mc
10	10.8 to 12.0 mc
11	12.0 to 14.4 mc
12	14.4 to 18.1 mc
13	200 to 1500 kc

c. NUMBER OF PRE-SET FREQUENCIES. - Ten High Frequencies and one Low Frequency

d. TYPE OF MODULATION.- Amplitude.

e. METHOD OF MODULATION. - Class B modulation to the plate and screen of the PA tube.

f. MODULATION CAPABILITY. - 90 to 100% on all frequencies with nominal power input.

Short, heavy power leads and good connections are desirable to minimize voltage drops. Two #12 AWG wires in parallel for each lead are recommended.

IMPORTANT

Before connecting to a power source check it carefully to make sure that it is a DC source of approximately 115 volts potential.

12. OVERLOAD PROTECTION.

The input circuit of the power unit and the input circuits of both dynamotors are protected by fuses. The 28 volt and 14 volt output circuits of the low voltage dynamotor and the 400 volt and the 1150 volt output circuits of the high voltage dynamotor also are fused to protect circuit components from being damaged by an overload.

13. ABBREVIATIONS.

Throughout the Instruction Book abbreviations are used in place of some of the more common radio terms and phrases. The terms and definitions listed below should help in the understanding of the sections of this book that follow.

PA	- Power Amplifier
CW	- Continuous-Wave
MCW	- Modulated Continuous-Wave
VOICE	- Voice modulated radio-frequency
HF OSCILLATOR	- High-Frequency Oscillator (1000 kc to 1510 kc output)
LF OSCILLATOR	- Low-Frequency Oscillator (200 kc to 1500 kc output)
CFI	- Calibration Frequency Indicator
1st MULTIPLIER	- First radio-frequency multiplier stage
2nd MULTIPLIER	- Second radio-frequency multiplier stage
LOCAL	- Control of the power and emission from the transmitter panel
REMOTE	- Control of the transmitter power and emission from the Remote Control Unit
RF	- Radio Frequency
AF	- Audio Frequency

14. SYMBOL DESIGNATIONS.

The Symbol Designations used throughout this book refer to the symbols used on the schematic diagrams and photographs. These designations are also used in the Parts List and Spare Parts Lists to identify circuit components with component part numbers and description.

15. TECHNICAL SUMMARY.

a. FREQUENCY RANGE. - 200 kc to 1500 kc in the Low Frequency Range.




Figure 1-8 Navy Type COL-481628 Antenna Shunt Capacitor




Figure 1-9 Type CR-2-B/U (200 kc) Crystal Unit

mounts and may be installed on a bulk-head near the transmitter unit.

8. ANTENNA SHUNT CAPACITOR.

The Type COL-481628 Antenna Shunt Capacitor is furnished to permit operation in the range 2000 to 3000 kc using a short whip-type antenna.

9. ACCESSORIES.

a. The Type CR-2-B/U (200 kc) Crystal Unit is mounted in a plug-in holder for convenience in mounting in the crystal oscillator calibration unit.

b. Power, control and unit-interconnecting cables are furnished complete with the fittings and plug connectors necessary to complete the installation.

c. Complete sets of Phillips and Bristo wrenches are fastened on the left side of the transmitter unit.

10. INTERCHANGEABILITY OF UNITS.

Table 1-4 INTERCHANGEABILITY OF UNITS.

<u>Unit Description</u>	<u>Navy Type Designation</u>	<u>Collins Type No.</u>	<u>Model TCZ</u>	<u>Model TCZ-1</u>	<u>Model TCZ-2</u>
Radio Transmitter	-52286	17H-2	X		
Radio Transmitter	-52286-A	17H-2		X	X
Remote Control Unit	COL-23410	314N-2	X	X	X
Antenna Loading Coil (300 kc to 600 kc)	COL-47370	180H-3	X		
Antenna Loading Coil (200 kc to 1500 kc)	COL-47505	180H-4		X	X
Antenna Shunt Capacitor	-481628	195D-1	X	X	X
Quartz Crystal Assembly (200 kc)	-40127		X		
Quartz Crystal Assembly (200 kc)	CR-2-B/U (200 kc)			X	X
AC Power Unit	COL-211101	413D-1	X		
AC Power Unit	COL-211322	413D-3		X	
DC Power Unit	COL-211102	413D-2	X		
DC Power Unit	COL-211624	413D-4			X
27 Conductor Cable		65X-7	X	X	X
10 Conductor Cable		65X-8	X	X	X
2 Conductor Cable		65X-9	X	X	X
27 Conductor Cable		65X-10	X	X	X

This Instruction Book may not be used for installation, operation or maintenance of any units except those supplied on this contract.

11. POWER SOURCE.

The equipment described by this Instruction Book requires approximately 1200 watts of 115 volt DC current. To take care of starting surges and overloads a power source with adequate capacity should be employed.

The controls on the Type COL-23410 Remote Control Unit consist of a CHANNEL selector switch, an EMISSION selector switch, a MICROPHONE jack, and a TELEGRAPH KEY jack.

5. POWER UNIT.

Power for the transmitter unit is furnished by a Navy Type COL-211624 Dynamotor Assembly Power Unit, requiring approximately 1200 watts of power at 115 v DC at rated load.

Channel type of construction is employed in the power unit, therefore, most of the components may be serviced by removing either of the two side plates. Shock mounts are provided for deck mounting.

The power unit employs two dynamotors to generate operating voltages for all the circuits of the installation except the 115 v DC keying circuits. One dynamotor furnishes 28 v DC for tube filaments and relays, and 14 v DC for Navy Control Circuits. Plate voltage for the transmitter unit is obtained from the second dynamotor which has two output voltages, one of which is used for the tubes requiring 400 volts while both voltages are combined for the tubes requiring 1150 v.

Output of the power unit is as follows:

- 14 v DC at 1.2 amp for Navy Control Circuits.
- 28 v DC at 15 amp for transmitter filaments and relays.
- 400 v DC at 0.4 amp for LV transmitter tubes plates.
- 1150 v DC at 0.35 amp for HV transmitter tubes plates.
- 115 v DC line voltage is used for the power unit keying relay.

6. REMOTE CONTROL UNIT.

The Type COL-23410 Remote Control Unit permits the control of power, the selection of the type of emission, the control of the emission and the selection of the frequency channel from a remote position. The unit also contains a loudspeaker, a headphones cord plug receptacle and an audio level control. The input circuits of the speaker and phones jack are brought out to a terminal strip so that the output of the installation receiver may be easily connected to the unit. Either speaker or headphones reception may be selected by the operation of a toggle switch. This unit has mounting holes for mounting the unit in a position convenient to the operator.

7. ANTENNA LOAD COIL.

The external load coil is used only when low frequency operation (200 kc to 1500 kc) is selected. The antenna should be connected to the ANT LEAD IN terminal on the load coil and connections made from the load coil terminals to the transmitter. A relay located in the Type COL-47505 Antenna Load Coil Unit, operated by the telegraph key, TEST switch or the push-to-talk switch on the microphone, connects the tank circuit that is located in the load coil unit to the antenna when operating in the low frequency range. During operation in the frequency range 2000 kc to 18,100 kc the relay remains unoperated and the normally closed contacts connect the output of the transmitter directly to the antenna. The Load Coil unit is equipped with shock-




Figure 1-6 Navy Type COL-23410 Remote Control Unit




Figure 1-7 Navy Type COL-47505 Antenna Loading Coil Unit

10. TUNING INSTRUCTIONS FOR HIGH FREQUENCY OPERATION (2000 to 18,100 kc).

a. Knobs "A" and "B" are coarse and fine frequency controls. Knobs "C", "D" and "E" tune the antenna circuit. Knobs "F" and "G" and all knobs on external loading coils have no effect during high frequency operation.

b. The following procedure is recommended for tuning the equipment to any desired high frequency:

(1) One of the tables of dial settings for "C", "D" and "E" in table 3-3 or 3-4 will be found to be approximately correct for any antenna installation. To determine which table to use, measure the length of the antenna taking the total length of wire from the antenna terminal of the Antenna Loading Coil to the extreme end of the antenna. (Include the length of lead inside the radio room.) If the antenna is a "T" disregard the length of wire in the shorter branch at the top of the "T", or, if the two branches are equal, include the length of only one of them.

(2) To check the choice of table, tune up the set on one of the frequencies given in the table for the antenna length nearest that measured above. Choose a frequency which tunes on Position 7 on the "C" dial. Compare the actual dial settings obtained with the dial settings given in this table and also in the tables for the next shorter and the next longer antenna lengths. Of these tables the one showing dial settings closest to the actual dial settings is the table to use for this particular installation. The above procedure need only be followed once for a given type of antenna installation. Once the particular table which applies is known, it can be used thereafter.

(3) Set transmitter to desired frequency with Knobs "A" and "B". See instructions paragraph III-8c in this book, and calibration table 3-2.

(4) Set knobs "C", "D", and "E" to the dial settings given in the table chosen above for the frequency nearest to the desired frequency. Some of the tables give two sets of dial settings for the same frequency. Use the dial settings which give most nearly correct PA plate meter reading when tuned as described below.

(5) Place BATTERY-PA GRID-PA PLATE switch in PA PLATE position.

(6) Place CALIBRATE-TUNE-OPERATE switch in TUNE position.

(7) Place EMISSION switch in CW position.

(8) Press key. Turn Knob "D" for minimum PA plate meter reading.

(9) Place CALIBRATE-TUNE-OPERATE switch in OPERATE position. The pointer of the meter reading PA plate should be in the white area marked CW. If the needle does not read in the area marked CW, detune Knob "E" a few degrees and retune Knob "D" to minimum PA plate meter reading. If the new meter reading is more nearly correct, detune Knob "E" a few more degrees the same direction and retune with Knob "D". If the new meter reading is farther from correct value, detune Knob "E" a few degrees the other way and find dip in PA plate meter reading with Knob "D". Continue until the dip in PA plate meter reading falls within the area marked CW. Release key.

The object is to make the meter reading at the dip, fall within the white CW area on the meter scale. Knob "E" controls loading while Knob "D" controls fine antenna tuning, but their effects are interlocking. If one knob is turned, it is necessary to readjust the other.

WARNING

The correct tuning is at the minimum dip in PA plate meter reading. If meter reading is too low, follow the procedure described above. Do not detune from dip to get the "correct" meter reading. Always tune to the dip in PA plate meter reading as the final step.

NOTE

Set Knob "C" accurately to mark.

(8) In the tuning process the knobs have been moved either direction as required. It is now necessary to set and lock these knobs so the Autotune quick-shift mechanism will retune them automatically to the correct position. Note the setting of Knob "C". Move it one position counterclockwise (to next lower number), then back clockwise to the original setting, stopping exactly on the mark. Hold knob and tighten locking bar.

Note the setting of Knob "D". Move it one eighth turn counterclockwise, then return it clockwise exactly to the original setting. Hold knob and tighten locking bar.

Turn Knob "E" one eighth turn counterclockwise. Press key. Retune Knob "E" slowly clockwise and stop at minimum PA plate meter reading. If you turn past the point of minimum PA plate meter reading, back up one eighth turn and try again. Set Knob "E" at the point of dip in PA plate meter reading, hold knob, and tighten locking bar. Release key. The equipment is now tuned and ready for use.

(9) A useful check on accuracy of setup is, after all locking bars are tightened, to turn each knob by hand clockwise against its stop, then press key momentarily and note if the set is correctly tuned. If so, the Autotune quick-shift mechanism will repeat the settings thereafter.

(10) The transmitter can be tuned and loaded with low line voltage if proper allowance is made so that the loading will not be too high with normal line voltage. Obtain a power line voltage meter reading and proceed to tune the antenna as described in paragraph (7) above, but adjust minimum PA plate meter reading proportional to the line voltage meter reading obtained above rather than to the area marked CW. Thus when the line voltage is low, the transmitter is loaded proportionately low, and the loading will be correct when line voltage is normal.

(11) All antenna tuning and loading should be done in the CW position. Upon switching to VOICE position the reading of the righthand meter will increase slightly without modulation, and will kick upwards to about 150 on the scale during normal talking. In the MCW position the meter will read in or near the area marked MCW.

NOTE

Under no circumstances should the transmitter be actually operating (key down or microphone push-button closed) when the EMISSION selector switch is operated. Such operation can cause a sustained arc to occur between the contacts of the CW relay.

(12) Antenna tuning data for antennas of various lengths are given in the following tables. Use the data in table 3-3 where the lowest desired frequency can be tuned with the particular antenna in use.

(13) If it is necessary to tune to a lower frequency than is possible with the given antenna alone, the NAVY Type COL-481628 shunt capacitors may be connected between the terminals on the transmitter marked COND and GROUND. This additional capacity will extend the tuning range. Antenna tuning data in table 3-4 shows the amount of shunt capacity to use with each antenna to reach 2000 kc.

IMPORTANT

Use table 3-3 whenever possible. Use table 3-4 only when shunt capacity must be added to extend antenna tuning range.

Frequency 200 to 750 kilocycles

TABLE 3-1 L-F OSCILLATOR CALIBRATION DATA (200 Kc. to 1500 Kc.)

Freq.	A	F	G	Freq.	A	F	G	Freq.	A	F	G	Freq.	A	F	G
200	13	1	393	300	13	2	1114	400	13	3	1090	500	13	4	518
202	13	1	469	302	13	2	1153	402	13	3	1120	505	13	4	565
204	13	1	540	304	13	2	1192	404	13	3	1148	510	13	4	609
206	13	1	609	306	13	2	1229	406	13	3	1177	515	13	4	654
208	13	1	676	308	13	2	1266	408	13	3	1205	520	13	4	697
210	13	1	739	310	13	2	1302	410	13	3	1233				
212	13	1	801	312	13	2	1338	412	13	3	1260	525	13	4	739
214	13	1	861	314	13	2	1373	414	13	3	1288	530	13	4	781
216	13	1	919	316	13	2	1407	416	13	3	1314	535	13	4	821
218	13	1	976	318	13	2	1442	418	13	3	1341	540	13	4	862
220	13	1	1030	320	13	2	1476	420	13	3	1368	545	13	4	901
222	13	1	1084	322	13	2	1508	422	13	3	1394	550	13	4	940
224	13	1	1136	324	13	2	1542	424	13	3	1419	555	13	4	978
												560	13	3	1016
226	13	1	1187	326	13	2	1574	426	13	3	1445	565	13	4	1053
228	13	1	1237	328	13	2	1606	428	13	3	1470	570	13	4	1090
230	13	1	1286	330	13	2	1638	430	13	3	1495				
232	13	1	1334	332	13	2	1670	432	13	3	1519	575	13	4	1127
234	13	1	1381	334	13	2	1701					580	13	4	1163
236	13	1	1426	336	13	2	1732	434	13	3	1544	585	13	4	1198
238	13	1	1472	338	13	2	1763	436	13	3	1569	590	13	4	1234
240	13	1	1515	340	13	2	1793	438	13	3	1593	595	13	4	1270
242	13	1	1560	342	13	2	1823	440	13	3	1616	600	13	4	1304
244	13	1	1603	344	13	2	1854	442	13	3	1641	605	13	4	1340
				346	13	2	1883	444	13	3	1665	610	13	4	1375
246	13	1	1646	348	13	2	1912	446	13	3	1688	615	13	4	1408
248	13	1	1688	350	13	2	1942	448	13	3	1710	620	13	4	1444
250	13	1	1729	352	13	2	1971	450	13	3	1734	625	13	4	1479
252	13	1	1770	354	13	2	2000	452	13	3	1757				
254	13	1	1810	356	13	2	2028	454	13	3	1780	630	13	4	1512
256	13	1	1851					456	13	3	1802	635	13	4	1548
258	13	1	1890	350	13	3	154	458	13	3	1825	640	13	4	1584
260	13	1	1929	352	13	3	205	460	13	3	1847	645	13	4	1618
262	13	1	1968	354	13	3	255	462	13	3	1870	650	13	4	1655
				356	13	3	302	464	13	3	1892	655	13	4	1691
262	13	2	175	358	13	3	347	466	13	3	1913	660	13	4	1728
264	13	2	242	360	13	3	392	468	13	3	1936	665	13	4	1766
266	13	2	305	362	13	3	434	470	13	3	1958	670	13	4	1804
268	13	2	366	364	13	3	476	472	13	3	1980				
270	13	2	423	366	13	3	515	474	13	3	2001	675	13	4	1845
272	13	2	480	368	13	3	555	476	13	3	2022	680	13	4	1886
274	13	2	533	370	13	3	593					685	13	4	1928
276	13	2	585	372	13	3	631	468	13	4	191	690	13	4	1976
278	13	2	635	374	13	3	668	470	13	4	213	695	13	4	2023
280	13	2	684					472	13	4	235				
282	13	2	731	376	13	3	704	474	13	4	257	695	13	5	156
284	13	2	778	378	13	3	739	476	13	4	279	700	13	5	195
286	13	2	823	380	13	3	774	478	13	4	300	705	13	5	231
288	13	2	868	382	13	3	808	480	13	4	321	710	13	5	269
290	13	2	911	384	13	3	841	482	13	4	342	715	13	5	303
292	13	2	953	386	13	3	874	484	13	4	363	720	13	5	338
294	13	2	995	388	13	3	906	486	13	4	383	725	13	5	373
296	13	2	1035	390	13	3	938	488	13	4	402				
298	13	2	1075	392	13	3	970	490	13	4	422	730	13	5	406
300	13	2	1114	394	13	3	1000	492	13	4	442	735	13	5	438
				396	13	3	1030	494	13	4	462	740	13	5	471
				398	13	3	1061	496	13	4	481	745	13	5	502
				400	13	3	1090	498	13	3	499	750	13	5	553
								500	13	4	518				

Use nearest check point shown in heavy type.

Frequency 750 to 1500 kilocycles

TABLE 3-1 L-F OSCILLATOR CALIBRATION DATA (200 Kc. to 1500 Kc.) (Cont.)

Freq.	A	F	G	Freq.	A	F	G	Freq.	A	F	G
750	13	5	533	1000	13	5	1795	1250	13	6	1016
755	13	5	565	1005	13	5	1822	1255	13	6	1032
760	13	5	594	1010	13	5	1850	1260	13	6	1050
765	13	5	624	1015	13	5	1878	1265	13	6	1067
770	13	5	654	1020	13	5	1905	1267	13	6	1073
			(6 div. per kc)	1025	13	5	1935	1270	13	6	1084
				1030	13	5	1966	1275	13	6	1100
775	13	5	683	1035	13	5	1998				(3.4 div. per kc)
780	13	5	711					1280	13	6	1116
785	13	5	739	1035	13	6	145	1285	13	6	1132
790	13	5	768	1040	13	6	171	1290	13	6	1149
795	13	5	795	1045	13	6	196	1295	13	6	1166
800	13	5	821	1050	13	6	219	1300	13	6	1182
805	13	5	849	1055	13	6	244	1305	13	6	1198
810	13	5	876	1060	13	6	270	1310	13	6	1214
815	13	5	901	1065	13	6	293	1315	13	6	1230
820	13	5	927	1070	13	6	315	1320	13	6	1246
825	13	5	953					1325	13	6	1262
			(5.4 divisions per kc)								(3.2 divisions per kc)
830	13	5	979	1075	13	6	338				
835	13	5	1004	1080	13	6	363	1330	13	6	1278
840	13	5	1029	1085	13	6	385	1335	13	6	1294
845	13	5	1054	1090	13	6	407	1340	13	6	1309
850	13	5	1079	1095	13	6	428	1345	13	6	1325
855	13	5	1103	1100	13	6	451	1350	13	6	1341
860	13	5	1127	1105	13	6	473	1355	13	6	1358
865	13	5	1152	1110	13	6	493	1360	13	6	1374
870	13	5	1176	1115	13	6	514	1365	13	6	1389
875	13	5	1199	1120	13	6	534	1370	13	6	1404
880	13	5	1223					1375	13	6	1419
			(4.9 divisions per kc)								(3.1 divisions per kc)
885	13	5	1247	1125	13	6	556				
890	13	5	1270	1130	13	6	576	1380	13	6	1436
895	13	5	1294	1135	13	6	596	1385	13	6	1452
900	13	5	1317	1140	13	6	615	1390	13	6	1468
905	13	5	1341	1145	13	6	635	1395	13	6	1484
910	13	5	1364	1150	13	6	656	1400	13	6	1499
915	13	5	1387	1155	13	6	675	1405	13	6	1514
920	13	5	1410	1160	13	6	694	1410	13	6	1530
			(4.7 divisions per kc)	1165	13	6	712	1415	13	6	1547
				1170	13	6	731	1420	13	6	1563
925	13	5	1433	1175	13	6	751	1425	13	6	1580
930	13	5	1457								(3.2 divisions per kc)
935	13	5	1480	1180	13	6	770				
940	13	5	1503	1185	13	6	788	1430	13	6	1595
945	13	5	1526	1190	13	6	806	1435	13	6	1611
950	13	5	1550	1195	13	6	823	1440	13	6	1627
955	13	5	1574	1200	13	6	842	1445	13	6	1644
960	13	5	1597	1205	13	6	860	1450	13	6	1661
965	13	5	1621	1210	13	6	878	1455	13	6	1678
970	13	5	1645	1215	13	6	895	1460	13	6	1694
			(4.7 divisions per kc)	1220	13	6	913	1465	13	6	1710
				1225	13	6	930	1470	13	6	1727
975	13	5	1670					1475	13	6	1744
980	13	5	1694								(3.3 divisions per kc)
985	13	5	1718	1230	13	6	948				
990	13	5	1744	1235	13	6	966	1480	13	6	1763
995	13	5	1770	1240	13	6	983	1485	13	6	1780
1000	13	5	1795	1245	13	6	999	1490	13	6	1797
			(5 divisions per kc)	1250	13	6	1016	1495	13	6	1813
								1500	13	6	1832
											(3.5 div. per kc)

Use nearest check point shown in heavy type.

Frequency 2000 to 3000 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
2000	1	100	2250	1	1027	2500	2	366	2750	2	1133
2005	1	119	2255	1	1046	2505	2	381	2755	2	1148
2010	1	138	2260	1	1064	2510	2	397	2760	2	1163
2015	1	156	2265	1	1083	2515	2	412	2765	2	1179
2020	1	174	2270	1	1101	2520	2	427	2770	2	1194
2025	1	193	2275	1	1119	2525	2	443	2775	2	1209
2030	1	211	2280	1	1138	2530	2	458	2780	2	1224
2035	1	230	2285	1	1156	2535	2	474	2785	2	1239
2040	1	248	2290	1	1174	2540	2	489	2790	2	1254
2045	1	267	2295	1	1193	2545	2	505	2795	2	1270
2050	1	285	2300	1	1211	2550	2	520	2800	2	1285
			2305	1	1229				2805	2	1300
2055	1	303	2310	1	1247	2555	2	535	2810	2	1315
2060	1	322	2315	1	1265	2560	2	551	2815	2	1330
2065	1	340	2320	1	1284	2565	2	567	2820	2	1345
2070	1	359	2325	1	1302	2570	2	590	2825	2	1361
2075	1	377	2330	1	1321	2575	2	597	2830	2	1376
2080	1	396	2335	1	1339	2580	2	613	2835	2	1391
2085	1	415	2340	1	1357	2585	2	628	2840	2	1406
2090	1	433	2345	1	1376	2590	2	644	2845	2	1421
2095	1	452	2350	1	1394	2595	2	659	2850	2	1436
2100	1	470				2600	2	674			
2105	1	489	2355	1	1412	2605	2	690	2855	2	1452
2110	1	508	2360	1	1430	2610	2	705	2860	2	1469
2115	1	526	2365	1	1449	2615	2	721	2865	2	1482
2120	1	545	2370	1	1468	2620	2	736	2870	2	1498
2125	1	564	2375	1	1486	2625	2	756	2875	2	1513
2130	1	582	2380	1	1504	2630	2	767	2880	2	1528
2135	1	601	2385	1	1523	2635	2	782	2885	2	1544
2140	1	620	2390	1	1541	2640	2	797	2890	2	1559
2145	1	638	2395	1	1560	2645	2	813	2895	2	1574
2150	1	657	2400	1	1578	2650	2	828	2900	2	1590
									2905	2	1605
2155	1	675	2400	2	060	2655	2	844	2910	2	1621
2160	1	693	2405	2	076	2660	2	859	2915	2	1636
2165	1	713	2410	2	091	2665	2	874	2920	2	1653
2170	1	732	2415	2	106	2670	2	890	2925	2	1668
2175	1	750	2420	2	121	2675	2	905	2930	2	1683
2180	1	769	2425	2	137	2680	2	920	2935	2	1699
2185	1	787	2430	2	152				2940	2	1715
2190	1	806	2435	2	168				2945	2	1731
2195	1	824	2440	2	183	2685	2	935	2950	2	1749
2200	1	843	2445	2	198	2690	2	951			
2205	1	862	2450	2	213	2695	2	966	2955	2	1763
2210	1	880				2700	2	981	2960	2	1779
2215	1	898	2455	2	228	2705	2	996	2965	2	1795
2220	1	917	2460	2	243	2710	2	1012	2970	2	1811
2225	1	935	2465	2	259	2715	2	1027	2975	2	1827
2230	1	954	2470	2	274	2720	2	1042	2980	2	1843
2235	1	972	2475	2	290	2725	2	1057	2985	2	1860
2240	1	991	2480	2	305	2730	2	1073	2990	2	1877
2245	1	1009	2485	2	320	2735	2	1088	2995	2	1893
2250	1	1027	2490	2	335	2740	2	1103	3000	2	1910
			2495	2	351	2745	2	1118			
			2500	2	366	2750	2	1133			

Use nearest check point shown in heavy type.

Frequency 3000 to 4000 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.) (Cont.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
3000	3	100	3250	3	719	3500	3	1333	3750	4	366
3005	3	113	3255	3	731	3505	3	1345	3755	4	376
3010	3	126	3260	3	743	3510	3	1357	3760	4	386
3015	3	138	3265	3	755	3515	3	1369	3765	4	397
3020	3	150	3270	3	769	3520	3	1381	3770	4	407
3025	3	162	3275	3	781	3525	3	1394	3775	4	417
3030	3	174	3280	3	793				3780	4	427
3035	3	186	3285	3	806	3530	3	1406	3785	4	437
3040	3	198	3290	3	818	3535	3	1418	3790	4	447
3045	3	211	3295	3	830	3540	3	1430	3795	4	458
3050	3	223	3300	3	843	3545	3	1443	3800	4	469
3055	3	235	3305	3	855	3550	3	1456	3805	4	479
3060	3	248	3310	3	867	3555	3	1468	3810	4	489
3065	3	260	3315	3	880	3560	3	1480	3815	4	499
3070	3	272	3320	3	892	3565	3	1492	3820	4	509
3075	3	285	3325	3	904	3570	3	1504	3825	4	520
			3330	3	917	3575	3	1516			
3080	3	297	3335	3	929	3580	3	1528	3830	4	530
3085	3	309	3340	3	941	3585	3	1541	3835	4	540
3090	3	322	3345	3	954	3590	3	1553	3840	4	551
3095	3	334	3350	3	966	3595	3	1565	3845	4	561
3100	3	346				3600	3	1578	3850	4	571
3105	3	359	3355	3	978				3855	4	582
3110	3	371	3360	3	991	3600	4	060	3860	4	592
3115	3	383	3365	3	1003	3605	4	070	3865	4	602
3120	3	396	3370	3	1015	3610	4	080	3870	4	613
3125	3	408	3375	3	1027	3615	4	091	3875	4	623
3130	3	420				3620	4	101	3880	4	633
3135	3	433	3380	3	1039	3625	4	116	3885	4	644
3140	3	445	3385	3	1051	3630	4	121	3890	4	654
3145	3	457	3390	3	1064	3635	4	131	3895	4	664
3150	3	470	3395	3	1076	3640	4	141	3900	4	674
3155	3	483	3400	3	1088	3645	4	152	3905	4	684
3160	3	496	3405	3	1101	3650	4	162	3910	4	694
3165	3	508	3410	3	1113	3655	4	172	3915	4	705
3170	3	520	3415	3	1125	3660	4	183	3920	4	715
3175	3	532	3420	3	1138	3665	4	193	3925	4	725
			3425	3	1150	3670	4	203	3930	4	736
3180	3	545	3430	3	1162	3675	4	213	3935	4	746
3185	3	557	3435	3	1174				3940	4	756
3190	3	569	3440	3	1186	3680	4	223	3945	4	767
3195	3	582	3445	3	1198	3685	4	233	3950	4	777
3200	3	594	3450	3	1211	3690	4	243			
3205	3	606	3455	3	1223	3695	4	253	3955	4	787
3210	3	620	3460	3	1235	3700	4	264	3960	4	797
3215	3	632	3465	3	1247	3705	4	275	3965	4	807
3220	3	644	3470	3	1259	3710	4	285	3970	4	817
3225	3	657	3475	3	1271	3715	4	295	3975	4	828
			3480	3	1284	3720	4	305	3980	4	838
3230	3	669	3485	3	1296	3725	4	315	3985	4	848
3235	3	681	3490	3	1308	3730	4	325	3990	4	859
3240	3	693	3495	3	1321	3735	4	335	3995	4	869
3245	3	706	3500	3	1333	3740	4	345	4000	4	879
3250	3	719				3745	4	355			
						3750	4	366			

Use nearest check point shown in heavy type.

Frequency 4000 to 5000 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.) (Cont.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
4000	5	100	4200	5	470	4500	5	1027	4750	5	1486
4005	5	109	4250	5	564	4505	5	1036	4755	5	1495
4010	5	119	4255	5	573	4510	5	1046	4760	5	1504
4015	5	128	4260	5	582	4515	5	1055	4765	5	1513
4020	5	138	4265	5	591	4520	5	1064	4770	5	1523
4025	5	147	4270	5	601	4525	5	1073	4775	5	1532
4030	5	156	4275	5	610	4530	5	1083	4780	5	1541
4035	6	165	4280	5	620	4535	5	1092	4785	5	1550
4040	5	174	4285	5	629	4540	5	1101	4790	5	1560
4045	5	183	4290	5	638	4545	5	1110	4795	5	1569
4050	5	193	4295	5	647	4550	5	1119	4800	5	1578
4055	5	202	4300	5	657	4555	5	1128			
4060	5	211				4560	5	1138	4800	6	060
4065	5	220	4305	5	666	4565	5	1147	4805	6	068
4070	5	230	4310	5	675	4570	5	1156	4810	6	076
4075	5	239	4315	5	684	4575	5	1165	4815	6	084
4080	5	248	4320	5	693	4580	5	1174	4820	6	091
4085	5	257	4325	5	702	4585	5	1183	4825	6	099
4090	5	267	4330	5	713	4590	5	1193	4830	6	106
4095	5	276	4335	5	722	4595	5	1202	4835	6	114
4100	5	285	4340	5	732	4600	5	1211	4840	6	121
			4345	5	741	4605	5	1220	4845	6	129
4105	5	293	4350	5	750	4610	5	1229	4850	6	137
4110	5	303	4355	5	759	4615	5	1338	4855	6	145
4115	5	312	4360	5	769	4620	5	1247	4860	6	152
4120	5	322	4365	5	778	4625	5	1256	4865	6	160
4125	5	331	4370	5	787	4630	5	1266	4870	6	168
4130	5	340	4375	5	796	4635	5	1275	4875	6	176
4135	5	349	4380	5	806	4640	5	1284	4880	6	183
4140	5	359	4385	5	815	4645	5	1293	4885	6	191
4145	5	368	4390	5	824	4650	5	1302	4890	6	198
4150	5	377	4395	5	833	4655	5	1311	4895	6	206
4155	5	386	4400	5	843	4660	5	1321	4900	6	213
4160	5	396	4405	5	852	4665	5	1330			
4165	5	405	4410	5	862	4670	5	1339	4905	6	221
4170	5	415	4415	5	871	4675	5	1348	4910	6	228
4175	5	424	4420	5	880	4680	5	1357	4915	6	236
4180	5	433	4425	5	889	4685	5	1366	4920	6	243
4185	5	442	4430	5	898	4690	5	1376	4925	6	251
4190	5	452	4435	5	907	4695	5	1385	4930	6	259
4195	5	461	4440	5	917	4700	5	1394	4935	6	267
4200	5	470	4445	5	926				4940	6	274
4205	5	479	4450	5	935	4705	5	1403	4945	6	282
4210	5	489	4455	5	944	4710	5	1412	4950	6	290
4215	5	498	4460	5	954	4715	5	1421	4955	6	298
4220	5	508	4465	5	963	4720	5	1430	4960	6	305
4225	5	517	4470	5	972	4725	5	1439	4965	6	313
4230	5	526	4475	5	981	4730	5	1449	4970	6	320
4235	5	535	4480	5	991	4735	5	1458	4975	6	328
4240	5	545	4485	5	1000	4740	5	1468	4980	6	335
4245	5	554	4490	5	1009	4745	5	1477	4985	6	343
4250	5	564	4495	5	1018	4750	5	1486	4990	6	351
			4500	5	1027	4800	5	1578	4995	6	359
									5000	6	366

Use nearest check point shown in heavy type.

Frequency 5000 to 6000 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.) (Cont.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
5000	6	366	5200	6	674	5500	6	1133	5750	6	1513
5005	6	374	5250	6	752	5505	6	1141	5755	6	1521
5010	6	381	5255	6	760	5510	6	1148	5760	6	1528
5015	6	389	5260	6	767	5515	6	1156	5765	6	1536
5020	6	397	5265	6	775	5520	6	1163	5770	6	1544
5025	6	405	5270	6	782	5525	6	1171	5775	6	1552
5030	6	412	5275	6	790	5530	6	1179	5780	6	1559
5035	6	420	5280	6	797	5535	6	1187	5785	6	1567
5040	6	427	5285	6	805	5540	6	1194	5790	6	1574
5045	6	435	5290	6	813	5545	6	1202	5795	6	1582
5050	6	443	5295	6	821	5550	6	1209	5800	6	1590
5055	6	451	5300	6	828	5555	6	1217	5805	6	1598
5060	6	458				5560	6	1224	5810	6	1605
5065	6	466	5305	6	836	5565	6	1232	5815	6	1613
5070	6	474	5310	6	844	5570	6	1239	5820	6	1621
5075	6	482	5315	6	852	5575	6	1247	5825	6	1629
5080	6	489	5320	6	859	5580	6	1254	5830	6	1636
5085	6	497	5325	6	867	5585	6	1262	5835	6	1644
5090	6	505	5330	6	874	5590	6	1270	5840	6	1653
5095	6	513	5335	6	882	5595	6	1278	5845	6	1661
5100	6	520	5340	6	890	5600	6	1285	5850	6	1668
			5345	6	898	5605	6	1293	5855	6	1676
5105	6	528	5350	6	905	5610	6	1300	5860	6	1683
5110	6	535	5355	6	913	5615	6	1308	5865	6	1691
5115	6	543	5360	6	920	5620	6	1315	5870	6	1699
5120	6	551	5365	6	928	5625	6	1323	5875	6	1707
5125	6	559	5370	6	935	5630	6	1330	5880	6	1715
5130	6	567	5375	6	943	5635	6	1338	5885	6	1723
5135	6	575	5380	6	951	5640	6	1345	5890	6	1731
5140	6	582	5385	6	959	5645	6	1353	5895	6	1739
5145	6	590	5390	6	966	5650	6	1361	5900	6	1747
5150	6	597	5395	6	974	5655	6	1369			
5155	6	605	5400	6	981	5660	6	1376	5905	6	1755
5160	6	613	5405	6	989	5665	6	1384	5910	6	1763
5165	6	621	5410	6	996	5670	6	1391	5915	6	1771
5170	6	628	5415	6	1004	5675	6	1399	5920	6	1779
5175	6	636	5420	6	1012	5680	6	1406	5925	6	1787
5180	6	644	5425	6	1020	5685	6	1414	5930	6	1795
5185	6	652	5430	6	1027	5690	6	1421	5935	6	1803
5190	6	659	5435	6	1035	5695	6	1429	5940	6	1811
5195	6	667	5440	6	1042	5700	6	1436	5945	6	1819
5200	6	674	5445	6	1050				5950	6	1827
5205	6	682	5450	6	1057	5705	6	1444	5955	6	1835
5210	6	690	5455	6	1065	5710	6	1452	5960	6	1844
5215	6	698	5460	6	1073	5715	6	1460	5965	6	1852
5220	6	705	5465	6	1081	5720	6	1467	5970	6	1860
5225	6	713	5470	6	1088	5725	6	1475	5975	6	1868
5230	6	721	5475	6	1096	5730	6	1482	5980	6	1877
5235	6	729	5480	6	1103	5735	6	1490	5985	6	1885
5240	6	736	5485	6	1111	5740	6	1498	5990	6	1893
5245	6	744	5490	6	1118	5745	6	1506	5995	6	1901
5250	6	752	5495	6	1126	5750	6	1513	6000	6	1910
			5500	6	1133	5800	6	1590			

Use nearest check point shown in heavy type.

Frequency 6000 to 7000 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.) (Cont.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
6000	7	100	6250	7	408	6500	7	719	6750	7	1027
6005	7	106	6255	7	415	6505	7	725	6755	7	1033
6010	7	112	6260	7	421	6510	7	732	6760	7	1039
6015	7	119	6265	7	427	6515	7	738	6765	7	1046
6020	7	125	6270	7	433	6520	7	744	6770	7	1052
6025	7	131	6275	7	439	6525	7	750	6775	7	1058
6030	7	138	6280	7	445	6530	7	756	6780	7	1064
6035	7	144	6285	7	452	6535	7	762 (1.2 divisions per kc)	6785	7	1070
6040	7	150	6290	7	458	6540	7	769	6790	7	1076
6045	7	156	6295	7	464	6545	7	775 (1.2 divisions per kc)	6795	7	1083
6050	7	162	6300	7	470	6550	7	781	6800	7	1089
6055	7	168	6305	7	476	6555	7	787	6805	7	1095
6060	7	174	6310	7	482	6560	7	793 (1.2 divisions per kc)	6810	7	1101
6065	7	180	6315	7	489	6565	7	799	6815	7	1107
6070	7	186	6320	7	495	6570	7	806	6820	7	1113 (1.2 divisions per kc)
6075	7	193	6325	7	501	6575	7	812	6825	7	1119
6080	7	199	6330	7	508	6580	7	818	6830	7	1125
6085	7	205	6335	7	514	6585	7	824	6835	7	1131
6090	7	211	6340	7	520	6590	7	830	6840	7	1138
6095	7	217 (1.2 divisions per kc)	6345	7	526	6595	7	836	6845	7	1144
6100	7	223	6350	7	532	6600	7	843	6850	7	1150
6105	7	230	6355	7	538	6605	7	849	6855	7	1156
6110	7	236	6360	7	545	6610	7	855	6860	7	1162
6115	7	242	6365	7	551	6615	7	862	6865	7	1168
6120	7	248	6370	7	557 (1.2 divisions per kc)	6620	7	868	6870	7	1174
6125	7	254	6375	7	564	6625	7	874	6875	7	1180
6130	7	260	6380	7	570	6630	7	880	6880	7	1186
6135	7	267	6385	7	576	6635	7	886	6885	7	1193
6140	7	273	6390	7	582	6640	7	892	6890	7	1199
6145	7	279	6395	7	588	6645	7	898	6895	7	1205
6150	7	285	6400	7	595	6650	7	904	6900	7	1211
			6405	7	601	6655	7	910	6905	7	1217
6155	7	291	6410	7	607	6660	7	917	6910	7	1223
6160	7	297	6415	7	613	6665	7	923	6915	7	1229
6165	7	303	6420	7	620	6670	7	929	6920	7	1235
6170	7	309	6425	7	626	6675	7	935	6925	7	1241
6175	7	315	6430	7	632	6680	7	941	6930	7	1247
6180	7	322	6435	7	638	6685	7	947	6935	7	1253
6185	7	328	6440	7	644	6690	7	954	6940	7	1259
6190	7	334	6445	7	650	6695	7	960	6945	7	1266
6195	7	340	6450	7	657	6700	7	966 (1.2 divisions per kc)	6950	7	1272
6200	7	346				6705	7	972	6955	7	1278
6205	7	352	6455	7	663	6710	7	978	6960	7	1284
6210	7	359	6460	7	669	6715	7	984	6965	7	1290
6215	7	365	6465	7	675	6720	7	991	6970	7	1296
6220	7	371	6470	7	681	6725	7	997	6975	7	1302
6225	7	377 (1.2 divisions per kc)	6475	7	687	6730	7	1003	6980	7	1308
6230	7	383	6480	7	693	6735	7	1009	6985	7	1314
6235	7	389	6485	7	699	6740	7	1015	6990	7	1321
6240	7	396	6490	7	705	6745	7	1021	6995	7	1327
6245	7	402	6495	7	713 (1.2 divisions per kc)	6750	7	1027	7000	7	1333
6250	7	408	6500	7	719						
6300	7	470	6600	7	843						

Use nearest check point shown in heavy type.

Frequency 7000 to 8000 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.) (Cont.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
6900	7	1211	7200	8	060	7500	8	366	7750	8	623
7000	7	1333	7250	8	111	7505	8	371	7755	8	628
7005	7	1339	7255	8	116	7510	8	376	7760	8	633
7010	7	1345	7260	8	121	7515	8	381	7765	8	638
7015	7	1351	7265	8	126	7520	8	386	7770	8	644
7020	7	1357	7270	8	131	7525	6	391	7775	8	649
7025	7	1363	7275	8	137	7530	8	397	7780	8	654
7030	7	1369	7280	8	142	7535	8	402	7785	8	659
7035	7	1376	7285	8	147	7540	8	407	7790	8	664
7040	7	1382	7290	8	152	7545	8	412	7795	8	669
7045	7	1388	7295	8	157	7550	8	417	7800	8	674
7050	7	1394	7300	8	162				7805	8	679
			7305	8	168	7555	8	422	7810	8	684
7055	7	1400	7310	8	173	7560	8	427	7815	8	690
7060	7	1406	7315	8	178	7565	8	432	7820	8	695
7065	7	1412	7320	8	183	7570	8	437	7825	8	700
7070	7	1418	7325	8	188	7575	8	443	7830	8	705
7075	7	1424	7330	8	193	7580	8	448	7835	8	710
7080	7	1430	7335	8	198	7585	8	453	7840	8	715
7085	7	1436	7340	8	203	7590	8	458	7845	8	721
7090	7	1442	7345	8	208	7595	8	463	7850	8	726
7095	7	1449	7350	8	213	7600	8	469	7855	8	731
7100	7	1455				7605	8	474	7860	8	736
7105	7	1461	7355	8	218	7610	8	479	7865	8	741
7110	7	1468	7360	8	223	7615	8	484	7870	8	746
7115	7	1474	7365	8	228	7620	8	489	7875	8	752
7120	7	1480	7370	8	233	7625	8	494	7880	8	757
7125	7	1486	7375	8	238	7630	8	499	7885	8	762
7130	7	1492	7380	8	243	7635	8	505	7890	8	767
7135	7	1498	7385	8	248	7640	8	510	7895	8	772
7140	7	1504	7390	8	253	7645	8	515	7900	8	777
7145	7	1510	7395	8	259	7650	8	520	7905	8	782
7150	7	1516	7400	8	264				7910	8	787
7155	7	1523	7405	8	269	7655	8	525	7915	8	792
7160	7	1529	7410	8	274	7660	8	530	7920	8	797
7165	7	1535	7415	8	279	7665	8	535	7925	8	802
7170	7	1541	7420	8	284	7670	8	540	7930	8	807
7175	7	1547	7425	8	290	7675	8	545	7935	8	813
7180	7	1553	7430	8	295	7680	8	551	7940	8	818
7185	7	1560	7435	8	300	7685	8	556	7945	8	823
7190	7	1566	7440	8	305	7690	8	561	7950	8	828
7195	7	1572	7445	8	310	7695	8	567			
7200	7	1578	7450	8	315	7700	8	572	7955	8	833
			7455	8	320	7705	8	577	7960	8	838
7200	8	060	7460	8	325	7710	8	582	7965	8	844
7205	8	065	7465	8	330	7715	8	587	7970	8	849
7210	8	070	7470	8	335	7720	8	592	7975	8	854
7215	8	076	7475	8	340	7725	8	597	7980	8	859
7220	8	081	7480	8	345	7730	8	602	7985	8	864
7225	8	086	7485	8	351	7735	8	607	7990	8	869
7230	8	091	7490	8	356	7740	8	613	7995	8	874
7235	8	096	7495	8	361	7745	8	618	8000	8	879
7240	8	101	7500	8	366	7750	8	623	8100	8	981
7245	8	106				7800	8	674			
7250	8	111									

Use nearest check point shown in heavy type.

Frequency 8000 to 10000 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.) (Cont.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
8000	8	879	8400	8	1285	9000	9	100	9450	9	470
8010	8	890	8500	8	1386	9010	9	108	9500	9	510
8020	8	900	8510	8	1396	9020	9	116	9510	9	518
8030	8	910	8520	8	1406	9030	9	124	9520	9	527
8040	8	920	8530	8	1416	9040	9	132	9530	9	536
8050	8	930	8540	8	1426	9050	9	140	9540	9	545
8060	8	940	8550	8	1436	9060	9	148	9550	9	553
8070	8	951				9070	9	156	9560	9	561
8080	8	961	8560	8	1446	9080	9	165	9570	9	570
8090	8	971	8570	8	1456	9090	9	174	9580	9	578
8100	8	981	8580	8	1467	9100	9	182	9590	9	586
8110	8	991	8590	8	1477	9110	9	190	9600	9	595
8120	8	1001	8600	8	1487	9120	9	198	9610	9	601
8130	8	1012	8610	8	1498	9130	9	206	9620	9	610
8140	8	1022	8620	8	1508	9140	9	214	9630	9	620
8150	8	1032	8630	8	1518	9150	9	222	9640	9	628
8160	8	1042	8640	8	1528	9160	9	230	9650	9	636
8170	8	1052	8650	8	1538	9170	9	239	9660	9	644
8180	8	1062	8660	8	1548	9180	9	248	9670	9	652
8190	8	1073	8670	8	1559	9190	9	256			
8200	8	1083	8680	8	1569	9200	9	264	9680	9	660
8210	8	1093	8690	8	1579	9210	9	272	9690	9	668
8220	8	1103	8700	8	1590	9220	9	280	9700	9	676
8230	8	1113	8710	8	1600				9710	9	684
8240	8	1123	8720	8	1610	9230	9	288	9720	9	693
8250	8	1133	8730	8	1621	9240	9	296	9730	9	701
			8740	8	1631	9250	9	304	9740	9	709
8260	8	1143	8750	8	1641	9260	9	313	9750	9	717
8270	8	1153	8760	8	1653	9270	9	322	9760	9	725
8280	8	1163	8770	8	1663	9280	9	330	9770	9	733
8290	8	1173	8780	8	1673	9290	9	338	9780	9	742
8300	8	1183	8790	8	1683	9300	9	346	9790	9	751
8310	8	1194	8800	8	1694	9310	9	354	9800	9	760
8320	8	1204	8810	8	1704	9320	9	362	9810	9	769
8330	8	1214	8820	8	1715	9330	9	370	9820	9	777
8340	8	1224	8830	8	1725	9340	9	378	9830	9	785
8350	8	1234	8840	8	1736	9350	9	387	9840	9	793
8360	8	1244	8850	8	1747	9360	9	396	9850	9	801
8370	8	1254				9370	9	404	9860	9	809
8380	8	1264	8860	8	1757	9380	9	412	9870	9	817
8390	8	1274	8870	8	1768	9390	9	420	9880	9	825
8400	8	1285	8880	8	1779	9400	9	428	9890	9	834
8410	8	1295	8890	8	1789	9410	9	436	9900	9	843
8420	8	1305	8900	8	1799	9420	9	444	9910	9	851
8430	8	1315	8910	8	1811	9430	9	452	9920	9	859
8440	8	1325	8920	8	1821	9440	9	461	9930	9	867
8450	8	1335	8930	8	1832	9450	9	470	9940	9	875
8460	8	1345	8940	8	1843	9460	9	478	9950	9	883
8470	8	1355	8950	8	1854	9470	9	486	9960	9	891
8480	8	1365	8960	8	1865	9480	9	494	9970	9	899
8490	8	1376	8970	8	1877	9490	9	502	9980	9	908
8500	8	1386	8980	8	1888	9500	9	510	9990	9	917
			8990	8	1899				10000	9	925
			9000	8	1910						

Use nearest check point shown in heavy type.

Frequency 10000 to 12000 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.) (Cont.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
9900	9	843	10350	9	1211	10800	10	060	11500	10	538
10000	9	925	10500	9	1333	11000	10	195	11510	10	545
10010	9	933	10510	9	1341	11010	10	202	11520	10	551
10020	9	941	10520	9	1349	11020	10	209	11530	10	557
10030	9	949	10530	9	1357	11030	10	216	11540	10	563
10040	9	957	10540	9	1365	11040	10	223	11550	10	570
10050	9	965	10550	9	1373	11050	10	230	11560	10	577
10060	9	973	10560	9	1381	11060	10	237	11570	10	584
10070	9	982	10570	9	1389	11070	10	243	11580	10	591
10080	9	991				11080	10	249	11590	10	598
10090	9	999	10580	9	1397	11090	10	256	11600	10	605
10100	9	1007	10590	9	1405	11100	10	264	11610	10	613
10110	9	1015	10600	9	1413	11110	10	270	11620	10	619
10120	9	1023	10610	9	1421	11120	10	277	11630	10	625
			10620	9	1430	11130	10	284	11640	10	632
10130	9	1031	10630	9	1438	11140	10	291	11650	10	639
10140	9	1039	10640	9	1446	11150	10	297	11660	10	646
10150	9	1047	10650	9	1454	11160	10	305	11670	10	653
10160	9	1055	10660	9	1462	11170	10	311	11680	10	660
10170	9	1064	10670	9	1470	11180	10	317	11690	10	667
10180	9	1072	10680	9	1478	11190	10	324	11700	10	674
10190	9	1080	10690	9	1486	11200	10	331	11710	10	680
10200	9	1089	10700	9	1494	11210	10	338	11720	10	687
10210	9	1097	10710	9	1504	11220	10	345	11730	10	694
10220	9	1105	10720	9	1512	11230	10	352	11740	10	701
10230	9	1113	10730	9	1520	11240	10	359	11750	10	708
10240	9	1121	10740	9	1528	11250	10	366	11760	10	715
10250	9	1129	10750	9	1536	11260	10	372	11770	10	722
10260	9	1138	10760	9	1544	11270	10	378	11780	10	729
10270	9	1146	10770	9	1552	11280	10	385	11790	10	736
10280	9	1154	10780	9	1560	11290	10	392	11800	10	742
10290	9	1162	10790	9	1569	11300	10	399	11810	10	748
10300	9	1170	10800	9	1578	11310	10	406	11820	10	755
10310	9	1178				11320	10	413	11830	10	762
10320	9	1186	10800	10	060	11330	10	420	11840	10	769
10330	9	1194	10810	10	066	11340	10	427	11850	10	776
10340	9	1202	10820	10	072	11350	10	433			
10350	9	1211	10830	10	079	11360	10	440	11860	10	783
10360	9	1219	10840	10	086	11370	10	447	11870	10	790
10370	9	1227	10850	10	093	11380	10	454	11880	10	797
10380	9	1235	10860	10	100	11390	10	462	11890	10	803
10390	9	1243	10870	10	107	11400	10	469	11900	10	810
10400	9	1251	10880	10	114	11410	10	475	11910	10	817
10410	9	1259	10890	10	121	11420	10	482	11920	10	824
10420	9	1267	10900	10	127	11430	10	489	11930	10	831
10430	9	1275	10910	10	134	11440	10	495	11940	10	838
10440	9	1284	10920	10	141	11450	10	503	11950	10	845
10450	9	1292	10930	10	148	11460	10	510	11960	10	852
10460	9	1300	10940	10	155	11470	10	517	11970	10	859
10470	9	1308	10950	10	162				11980	10	866
10480	9	1316	10960	10	169	11480	10	524	11990	10	873
10490	9	1324	10970	10	176	11490	10	531	12000	10	879
10500	9	1333	10980	10	183	11500	10	538			
			10990	10	189	11700	10	674			
			11000	10	195						

Use nearest check point shown in heavy type.

Frequency 12000 to 14000 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.) (Cont.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
12000	11	100	12500	11	408	13000	11	719	13500	11	1027
12010	11	106	12510	11	415	13010	11	725	10510	11	1033
12020	11	112	12520	11	421	13020	11	732	13520	11	1039
12030	11	119	12530	11	427	13030	11	738	13530	11	1046
12040	11	125	12540	11	433	13040	11	744	13540	11	1052
12050	11	131	12550	11	439	13050	11	750	13550	11	1058
12060	11	138	12560	11	445	13060	11	756	13560	11	1064
12070	11	144	12570	11	452	13070	11	762	13570	11	1070
12080	11	150	12580	11	458	13080	11	769	13580	11	1076
12090	11	156	12590	11	464	13090	11	775	13590	11	1083
12100	11	162	12600	11	470	13100	11	781	13600	11	1089
12110	11	168	12610	11	476	13110	11	787	13610	11	1095
12120	11	174	12620	11	482	13120	11	793	13620	11	1101
12130	11	180	12630	11	489	13130	11	799	13630	11	1107
12140	11	187	12640	11	495	13140	11	806	13640	11	1113
12150	11	193	12650	11	501	13150	11	812	13650	11	1119
12160	11	199	12660	11	508	13160	11	818	13660	11	1125
12170	11	205	12670	11	514	13170	11	824	13670	11	1131
12180	11	211	12680	11	520	13180	11	830	13680	11	1138
12190	11	217	12690	11	526	13190	11	836	13690	11	1144
12200	11	223	12700	11	532	13200	11	843	13700	11	1150
12210	11	230	12710	11	538	13210	11	849	13710	11	1156
12220	11	236	12720	11	545	13220	11	855	13720	11	1162
12230	11	242	12730	11	551	13230	11	862	13730	11	1168
12240	11	248	12740	11	557	13240	11	868	13740	11	1174
12250	11	254	12750	11	564	13250	11	874	13750	11	1180
12260	11	260	12760	11	570	13260	11	880	13760	11	1186
12270	11	267	12770	11	576	13270	11	886	13770	11	1193
12280	11	273	12780	11	582	13280	11	892	13780	11	1199
12290	11	279	12790	11	590	13290	11	898	13790	11	1205
			12800	11	595	13300	11	904	13800	11	1211
12300	11	285	12810	11	601	13310	11	910	13810	11	1217
12310	11	291	12820	11	607	13320	11	917	13820	11	1223
12320	11	297	12830	11	613	13330	11	923	13830	11	1229
12330	11	303	12840	11	620	13340	11	929	13840	11	1235
12340	11	309	12850	11	626	13350	11	935	13850	11	1241
12350	11	315	12860	11	632	13360	11	941	13860	11	1247
12360	11	322	12870	11	638	13370	11	947	13870	11	1253
12370	11	328	12880	11	644	13380	11	954	13880	11	1259
12380	11	334	12890	11	650	13390	11	960	13890	11	1266
12390	11	340	12900	11	657	13400	11	966	13900	11	1272
12400	11	346							13910	11	1278
12410	11	352	12910	11	663	13410	11	972	13920	11	1284
12420	11	359	12920	11	669	13420	11	980	13930	11	1290
12430	11	365	12930	11	675	13430	11	986	13940	11	1296
12440	11	371	12940	11	681	13440	11	991	13950	11	1302
12450	11	377	12950	11	687	13450	11	997	13960	11	1308
12460	11	383	12960	11	693	13460	11	1003	13970	11	1314
12470	11	389	12970	11	699	13470	11	1009	13980	11	1321
12480	11	396	12980	11	706	13480	11	1015	13990	11	1327
12490	11	402	12990	11	713	13490	11	1021	14000	11	1333
12500	11	408	13000	11	719	13500	11	1027			
12600	11	470	13200	11	843						

Use nearest check point shown in heavy type.

Frequency 14000 to 16000 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.) (Cont.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
13800	11	1211	14400	12	060	15000	12	366	15500	12	623
14000	11	1333	14500	12	111	15010	12	371	15510	12	628
14010	11	1339	14510	12	116	15020	12	376	15520	12	633
14020	11	1345	14520	12	121	15030	12	381	15530	12	638
14030	11	1351	14530	12	126	15040	12	386	15540	12	644
14040	11	1357	14540	12	131	15050	12	391	15550	12	649
14050	11	1363	14550	12	137	15060	12	397	15560	12	654
14060	11	1369	14560	12	142	15070	12	402	15570	12	659
14070	11	1376	14570	12	147	15080	12	407	15580	12	664
14080	11	1382	14580	12	152	15090	12	412	15590	12	669
14090	11	1388	14590	12	157	15100	12	417	15600	12	674
14100	11	1394	14600	12	162				15610	12	679
			14610	12	168	15110	12	422	15620	12	684
14110	11	1400	14620	12	173	15120	12	427	15630	12	689
14120	11	1406	14630	12	178	15130	12	432	15640	12	694
14130	11	1412	14640	12	183	15140	12	437	15650	12	699
14140	11	1418	14650	12	188	15150	12	443	15660	12	705
14150	11	1424	14660	12	193	15160	12	448	15670	12	710
14160	11	1430	14670	12	198	15170	12	453	15680	12	715
14170	11	1436	14680	12	203	15180	12	458	15690	12	721
14180	11	1442	14690	12	208	15190	12	463	15700	12	726
14190	11	1449	14700	12	213	15200	12	469	15710	12	731
14200	11	1455				15210	12	474	15720	12	736
14210	11	1461	14710	12	218	15220	12	479	15730	12	741
14220	11	1468	14720	12	223	15230	12	484	15740	12	746
14230	11	1474	14730	12	228	15240	12	489	15750	12	752
14240	11	1480	14740	12	233	15250	12	494	15760	12	757
14250	11	1486	14750	12	238	15260	12	499	15770	12	762
14260	11	1492	14760	12	243	15270	12	505	15780	12	767
14270	11	1498	14770	12	248	15280	12	510	15790	12	772
14280	11	1504	14780	12	253	15290	12	515	15800	12	777
14290	11	1510	14790	12	259	15300	12	520			
14300	11	1516	14800	12	264				15810	12	782
14310	11	1523	14810	12	269	15310	12	525	15820	12	787
14320	11	1529	14820	12	274	15320	12	530	15830	12	792
14330	11	1535	14830	12	279	15330	12	535	15840	12	797
14340	11	1541	14840	12	284	15340	12	540	15850	12	802
14350	11	1547	14850	12	290	15350	12	545	15860	12	807
14360	11	1553	14860	12	295	15360	12	551	15870	12	813
14370	11	1560	14870	12	300	15370	12	556	15880	12	818
14380	11	1566	14880	12	305	15380	12	561	15890	12	823
14390	11	1572	14890	12	310	15390	12	567	15900	12	828
14400	11	1578	14900	12	315	15400	12	572			
			14910	12	320	15410	12	577	15910	12	833
14400	12	060	14920	12	325	15420	12	582	15920	12	838
14410	12	065	14930	12	330	15430	12	587	15930	12	844
14420	12	070	14940	12	335	15440	12	592	15940	12	849
14430	12	076	14950	12	340	15450	12	597	15950	12	854
14440	12	081	14960	12	345	15460	12	602	15960	12	859
14450	12	086	14970	12	351	15470	12	607	15970	12	864
14460	12	091	14980	12	356	15480	12	613	15980	12	869
14470	12	096	14990	12	361	15490	12	618	15990	12	874
14480	12	101	15000	12	366	15500	12	623	16000	12	879
14490	12	106				15600	12	674	16200	12	981
14500	12	111									


Use nearest check point shown in heavy type.

Frequency 16000 to 18100 kilocycles

TABLE 3-2 H-F OSCILLATOR CALIBRATION DATA (2000 Kc. to 18,100 Kc.) (Cont.)

Freq.	A	B	Freq.	A	B	Freq.	A	B	Freq.	A	B
16000	12	879	16500	12	1133	16800	12	1285	17400	12	1590
16010	12	884	16510	12	1138	17000	12	1386	17550	12	1668
16020	12	890	16520	12	1143	17010	12	1391	17560	12	1673
16030	12	895	16530	12	1148	17020	12	1396	17570	12	1678
16040	12	900	16540	12	1153	17030	12	1401	17580	12	1683
16050	12	905	16550	12	1158	17040	12	1406	17590	12	1688
16060	12	910	16560	12	1163	17050	12	1411	17600	12	1694
16070	12	915	16570	12	1168	17060	12	1416	17610	12	1699
16080	12	920	16580	12	1173	17070	12	1421	17620	12	1704
16090	12	925	16590	12	1179	17080	12	1426	17630	12	1709
16100	12	930	16600	12	1184	17090	12	1431	17640	12	1715
16110	12	935	16610	12	1189	17100	12	1436	17650	12	1720
16120	12	940	16620	12	1194				17660	12	1725
16130	12	945	16630	12	1199	17110	12	1441	17670	12	1731
16140	12	951	16640	12	1204	17120	12	1446	17680	12	1736
16150	12	956	16650	12	1209	17130	12	1452	17690	12	1742
16160	12	961	16660	12	1214	17140	12	1457	17700	12	1747
16170	12	966	16670	12	1219	17150	12	1462			
16180	12	971	16680	12	1224	17160	12	1467	17710	12	1752
16190	12	976	16690	12	1229	17170	12	1472	17720	12	1757
16200	12	981	16700	12	1234	17180	12	1477	17730	12	1763
16210	12	986	16710	12	1239	17190	12	1482	17740	12	1768
16220	12	991	16720	12	1244	17200	12	1487	17750	12	1773
16230	12	996	16730	12	1249	17210	12	1492	17760	12	1779
16240	12	1001	16740	12	1254	17220	12	1498	17770	12	1784
16250	12	1006	16750	12	1259	17230	12	1503	17780	12	1789
16260	12	1012	16760	12	1264	17240	12	1508	17790	12	1795
16270	12	1017	16770	12	1270	17250	12	1513	17800	12	1800
16280	12	1022	16780	12	1275	17260	12	1518	17810	12	1805
16290	12	1027	16790	12	1280	17270	12	1523	17820	12	1811
16300	12	1032	16800	12	1285	17280	12	1528	17830	12	1816
16310	12	1037	16810	12	1290	17290	12	1533	17840	12	1821
16320	12	1042	16820	12	1295	17300	12	1538	17850	12	1827
16330	12	1047	16830	12	1300	17310	12	1544	17860	12	1832
16340	12	1052	16840	12	1305	17320	12	1549	17870	12	1837
16350	12	1057	16850	12	1310	17330	12	1554	17880	12	1843
16360	12	1062	16860	12	1315	17340	12	1559	17890	12	1848
16370	12	1067	16870	12	1320	17350	12	1564	17900	12	1854
16380	12	1073	16880	12	1325	17360	12	1569	17910	12	1860
16390	12	1078	16890	12	1330	17370	12	1574	17920	12	1865
16400	12	1083	16900	12	1335	17380	12	1579	17930	12	1871
16410	12	1088	16910	12	1340	17390	12	1584	17940	12	1877
16420	12	1093	16920	12	1345	17400	12	1590	17950	12	1882
16430	12	1098	16930	12	1350	17410	12	1595	17960	12	1888
16440	12	1103	16940	12	1355	17420	12	1600	17970	12	1893
16450	12	1108	16950	12	1361	17430	12	1605	17980	12	1898
16460	12	1113	16960	12	1366	17440	12	1610	17990	12	1904
16470	12	1118	16970	12	1371	17450	12	1615	18000	12	1910
16480	12	1123	16980	12	1376	17460	12	1621	18010	12	1915
16490	12	1128	16990	12	1381	17470	12	1626	18020	12	1921
16500	12	1133	17000	12	1386	17480	12	1631	18030	12	1927
						17490	12	1636	18040	12	1933
						17500	12	1641	18050	12	1939
						17510	12	1647	18060	12	1944
						17520	12	1653	18070	12	1949
						17530	12	1658	18080	12	1955
						17540	12	1663	18090	12	1961
						17550	12	1668	18100	12	1966


Use nearest check point shown in heavy type.




CONTROL "G" SETTING

LOW FREQUENCY TUNING CHART


200KC TO 475KC




CONTROL "G" SETTING
 LOW FREQUENCY TUNING CHART
 475KC TO 1500 KC



HIGH FREQUENCY TUNING CHART
2000KC TO 4000KC



HIGH FREQUENCY TUNING CHART
4000 KC TO 9000 KC



HIGH FREQUENCY TUNING CHART
9000 KC TO 18,000 KC

TABLE 3-3 TYPICAL ANTENNA TUNING DATA (Without Capacitor) (Cont.)

DO NOT USE ANTENNA CAPACITOR

27.5 Ft. Antenna				30 Ft. Antenna				32.5 Ft. Antenna				35 Ft. Antenna			
KC	C	D	E	KC	C	D	E	KC	C	D	E	KC	C	D	E
2600	1	...	0	2500	1-2	...	20	2450	1-2	...	26	2400	1-2	...	0
3000	2	...	75	3000	3-4	...	70	3000	3	...	65	3000	3-4	...	70
3500	3-4	...	110	3500	4	...	95	3500	4-5	...	100	3500	4-5	...	100
4000	4-5	...	130	4000	4-5	...	120	4000	5	...	120	4000	5-6	...	120
5000	6	...	150	5000	5-6	...	145	5000	5-6	...	150	5000	6-7	...	145
6000	6-7	...	165	6000	6-7	...	165	6000	6-7	...	165	6000	7	...	160
8000	7	70	190	8000	7	95	180	8000	7	100	200	7000	7	...	180
9100	7	100	200	8500	7	100	200					7600	7	100	200
								7600	10	36	0				
9000	10	59	10	8200	10	48	0	8000	10	37	90	7500	8	70	0
9500	10	57	80	9000	10	48	130	9000	10	42	160	8000	8	75	40
10000	10	55	110	10000	10	50	170	10000	10	46	185	9000	8	85	62
11000	10	60	175	11000	10	55	200	11000	10	54	200	10000	8	100	100
12000	10	65	185	12000	10	63	200	12000	10	65	200	10400	8	100	126
14000	10	80	195	14000	10	82	200	13000	10	75	200				
15500	10	100	195	15000	10	92	200	14000	10	82	200	8700	11	0	175
				15600	10	98	200	14600	10	88	200	9000	11	8	180
9000	11	45	40									10000	11	28	200
10000	11	40	140	8000	11	62	110	8000	11	0	113	11000	11	52	200
12000	11	55	195	10000	11	32	180	9000	11	22	168	12000	11	62	200
14000	11	75	200	12000	11	45	200	10000	11	35	188	14000	11	77	200
16500	11	95	200	14000	11	65	200	11000	11	47	200	15000	11	86	200
				16000	11	90	200	12000	11	60	200	15700	11	100	190
16000	13	0	180	16600	11	98	200	14000	11	78	200				
17000	13	45	190					16000	11	100	188	15000	13	0	166
18000	13	60	195	16000	13	0	184	16200	11	100	200	16000	13	66	152
				17000	13	45	188					17000	13	84	142
				18000	13	70	188	16000	13	52	165	18000	13	100	154
								16500	13	69	160				
								17000	13	70	170				
								18000	13	75	180				

TABLE 3-3 TYPICAL ANTENNA TUNING DATA (Without Capacitor) (Cont.)

DO NOT USE ANTENNA CAPACITOR

35 Ft. Antenna				40 Ft. Antenna				45 Ft. Antenna				50 Ft. Antenna			
KC	C	D	E	KC	C	D	E	KC	C	D	E	KC	C	D	E
2400	1-2	...	0	2300	1-2	...	3	2200	1-2	...	0	2100	1-2	...	0
3000	3-4	...	70	2500	2-3	...	10	2500	2-3	...	20	2500	3-4	...	19
3500	4-5	...	100	3000	3-4	...	60	3000	4-5	...	62	3000	4-5	...	55
4000	5-6	...	120	3500	4-5	...	95	3500	5-6	...	90	3500	5-6	...	95
5000	6-7	...	145	4000	5-6	...	120	4000	6	...	120	4000	6-7	...	120
6000	7	...	160	5000	6-7	...	150	5000	7	...	155	5000	7	...	160
7000	7	...	180	6000	7	...	170	6000	7	100	175	5500	7	100	180
7600	7	100	200	6800	7	100	200	6100	7	100	185				
												5400	8	32	0
7500	8	70	0	6600	8	57	0	6000	8	49	0	6000	8	38	90
8000	8	75	40	7000	8	60	50	7000	8	59	106	7000	8	48	148
9000	8	85	62	8000	8	70	121	8000	8	69	129	8000	8	65	152
10000	8	100	100	9000	8	83	111	9000	8	85	106	9000	8	85	148
10400	8	100	126	10000	8	97	121	9800	8	100	90	10000	8	92	142
				10500	8	100	140								
8700	11	0	175					7500	10	0	171	9000	11	29	200
9000	11	8	180	8400	10	0	188	8000	10	0	185	10000	11	40	200
10000	11	28	200	9000	10	25	196	9000	10	38	193	11000	11	53	200
11000	11	52	200	10000	10	47	200	10000	10	53	200	12000	11	72	200
12000	11	62	200	11000	10	60	200	11000	10	64	200	13000	11	82	200
14000	11	77	200	12000	10	70	200	12000	10	73	200	14000	11	100	0
15000	11	86	200	14000	10	88	200	13000	10	83	200	15000	11	98	135
15700	11	100	190	14500	10	100	200	13740	10	100	182				
												13500	13	37	28
15000	13	0	166	14500	12	71	200	13500	12	66	200	14000	13	45	52
16000	13	66	152	15000	12	76	200	14000	12	70	200	15000	13	52	125
17000	13	84	142	16000	12	84	200	15000	12	82	92	16000	13	69	136
18000	13	100	154	17000	12	100	141	16000	12	85	125	17000	13	71	164
				18000	12	100	146	17000	12	87	164	18000	13	68	184
								18000	12	86	195				

TABLE 3-3 TYPICAL ANTENNA TUNING DATA (Without Capacitor) (Cont.)

DO NOT USE ANTENNA CAPACITOR

50 Ft. Antenna				55 Ft. Antenna				60 Ft. Antenna			
KC	C	D	E	KC	C	D	E	KC	C	D	E
2100	1-2	...	0	2000	1-2	...	0	2000	1-2	...	0
2500	3-4	...	19	2500	3-4	...	15	2500	3-4	...	15
3000	4-5	...	55	3000	4-5	...	45	3000	5-6	...	55
3500	5-6	...	95	3500	5-6	...	100	3500	6-7	...	90
4000	6-7	...	120	4000	6-7	...	130	4000	7	...	125
5000	7	...	160	5000	7	100	168	4800	7	100	178
5500	7	...	100	5170	7	100	181				
								4750	8	0	0
5400	8	32	0	5000	8	15	0	5000	8	4	60
6000	8	38	90	6000	8	35	126	6000	8	22	155
7000	8	48	148	7000	8	51	152	7000	8	44	170
8000	8	65	152	8000	8	64	160	8000	8	63	164
9000	8	85	143	9000	8	81	136	9000	8	80	150
10000	8	92	142	9700	8	100	106	9700	8	100	120
								8000	9	39	200
9000	11	29	200	9500	9	62	198	9000	9	58	200
10000	11	40	200	10000	9	68	195	10000	9	74	186
11000	11	53	200	11000	9	87	171	10880	9	100	123
12000	11	72	200	11500	9	100	165				
13000	11	82	200					10500	10	65	200
14000	11	100	0	11200	10	73	200	11000	10	78	181
15000	11	98	135	12000	10	90	161	11350	10	89	0
				12200	10	100	82				
13500	13	37	28					11290	11	74	200
14000	13	45	52	12100	12	60	200	12000	11	75	190
15000	13	52	125	13000	12	62	133				
16000	13	69	136	14000	12	63	183	11600	12	59	30
17000	13	71	164	15000	12	68	200	12000	12	50	141
18000	13	68	184					13000	12	49	197
				14800	13	0	155	15000	12	71	200
				15000	13	0	160	17000	12	85	200
				16000	13	45	169	18000	12	94	200
				17000	13	62	177				
				18000	13	72	185				

TABLE 3-4 TYPICAL ANTENNA TUNING DATA (With Capacitor)

20 Ft. Antenna				22.5 Ft. Antenna				25 Ft. Antenna				27.5 Ft. Antenna			
Use 75 mmfd capacitor (3 sections)				Use 75 mmfd capacitor (3 sections)				Use 75 mmfd capacitor (3 sections)				Use 75 mmfd capacitor (3 sections)			
Freq.	C	D	E	Freq.	C	D	E	Freq.	C	D	E	Freq.	C	D	E
2100	1	---	0	2100	1	---	0	2160	1-2	---	0	2130	1-2	---	0
2500	3-4	---	0	2500	2-3	---	20	2500	2-3	---	28	2500	2-3	---	20
3000	4-5	---	30	3000	4-5	---	45	3000	4-5	---	50	3000	4-5	---	44
3500	5-6	---	52	3500	5-6	---	62	3500	5-6	---	65	3500	5-6	---	65
4000	6	---	65	4000	6	---	80	4000	6-7	---	80	4000	6	---	85
5000	6-7	---	102	5000	6-7	---	108	5000	6-7	---	106	5000	6-7	---	116
6000	7	50	118	6000	7	48	120	6000	7	44	125	6000	7	52	138
8000	7	72	146	7000	7	65	132	7000	7	64	140	7000	7	65	154
10000	7	90	168	8000	7	76	149	9000	7	80	184	8000	7	75	174
10500	7	100	174	10000	7	94	184	9500	7	90	200	8800	7	86	200
				10400	7	100	200								
10000	10	75	200					9500	10	65	0	8800	10	58	0
10500	10	85	200	10000	10	81	200	10000	10	66	92	9000	10	59	40
11000	10	94	200	10450	10	100	200	11000	10	68	166	10000	10	62	156
11300	10	100	200	10450	10	73	0	12000	10	74	184	11000	10	63	191
				11000	10	76	75	13000	10	82	192	12000	10	75	200
11100	11	76	200	12000	10	82	160	14000	10	90	200	13000	10	84	200
11600	11	95	200	13000	19	88	178	14500	10	100	200	14000	10	92	200
11600	11	75	0	14000	10	96	195					14400	10	100	200
12000	11	75	80	14100	10	100	200	14400	13	0	162				
13000	11	80	142					14500	13	0	164	13000	11	76	200
14000	11	86	180	14000	13	0	140	15000	13	0	181	14000	11	85	200
15000	11	92	200	14500	13	0	175	16000	13	51	200	15000	11	94	200
				15000	13	30	200	17000	13	73	200	15600	11	100	200
14500	13	0	164	16000	13	67	200	18000	13	89	200				
15000	13	0	180	17000	13	85	200					14400	13	0	161
16000	13	66	185	17600	13	100	200					15000	13	0	186
17000	13	84	190									16000	13	56	200
17700	13	100	200									17000	13	76	200
												18000	13	90	200

USE THESE DATA ONLY IF ONE OR MORE CHANNELS IS BETWEEN 2000 AND 3000 KCS.

USE THESE DATA ONLY IF ONE OR MORE CHANNELS IS BETWEEN 2000 AND 2700 KCS.

TABLE 3-4 TYPICAL ANTENNA TUNING DATA (With Capacitor) (Cont.)

27.5 Ft. Antenna				30 Ft. Antenna				32.5 Ft. Antenna				35 Ft. Antenna			
Use 75 mmfd capacitor (3 sections)				Use 75 mmfd capacitor (3 sections)				Use 50 mmfd capacitor (2 sections)				Use 50 mmfd capacitor (2 sections)			
Freq.	C	D	E	Freq.	C	D	E	Freq.	C	D	E	Freq.	C	D	E
2130	1-2	---	0	2100	1	---	0	2100	1-2	---	0	2150	1	---	0
2500	2-3	---	20	2500	2-3	---	30	2500	3-4	---	10	2500	2-3	---	22
3000	4-5	---	44	3000	4-5	---	48	3000	4-5	---	44	3000	4-5	---	60
3500	5-6	---	65	3500	5-6	---	64	3500	5-6	---	70	3500	5-6	---	85
4000	6	---	85	4000	6	---	80	4000	6-7	---	90	4000	6-7	---	110
5000	6-7	---	116	5000	6-7	---	121	5000	7	---	124	5000	7	32	128
6000	7	52	138	6000	7	54	138	6000	7	55	144	6000	7	56	156
7000	7	65	154	7000	7	71	152	7000	7	70	173	7000	7	75	184
8000	7	75	174	8000	7	81	186	7790	7	90	200	7435	7	95	200
8800	7	86	200	8350	7	100	200	7650	9	60	0	7200	9	54	0
				8100	10	50	0	8000	9	64	60	7500	9	58	49
8800	10	58	0	8500	10	50	88	9000	9	69	112	8000	9	60	112
9000	10	59	40	9000	10	52	138	10000	9	74	169	9000	9	67	142
10000	10	62	156	10000	10	55	165	11000	9	81	179	10000	9	72	160
11000	10	63	191	11000	10	66	200	12000	9	90	179	11000	9	80	176
12000	10	75	200	12000	10	76	200	12500	9	100	180	12000	9	88	178
13000	10	84	200	13000	10	85	200	11000	10	69	200	13000	9	100	181
14000	10	92	200	13500	10	89	200	12000	10	78	200	10000	10	53	200
14400	10	100	200	14000	10	93	200	13000	10	86	200	11000	10	65	200
								14000	10	95	200	12000	10	74	200
13000	11	76	200	13500	11	81	200	14100	10	100	200	13000	10	82	200
14000	11	85	200	14000	11	85	200	13000	11	79	200	14000	10	90	200
15000	11	94	200	14500	11	89	200	14000	11	86	200	14600	10	100	200
15600	11	100	200	15000	11	93	200	15000	11	94	200	14500	13	0	160
								14800	13	0	180	15000	13	0	178
14400	13	0	161	15000	13	0	188	15000	13	5	200	16000	13	70	156
15000	13	0	186	15500	13	41	200	15000	13	60	200	17000	13	90	130
16000	13	56	200	16000	13	58	200	16000	13	86	164	17700	13	100	146
17000	13	76	200	17000	13	76	200	17000	13	100	185				
18000	13	90	200	18000	13	91	200								

USE THESE DATA ONLY IF ONE OR MORE CHANNELS IS BETWEEN 2000 AND 2600 KCS.

USE THESE DATA ONLY IF ONE OR MORE CHANNELS IS BETWEEN 2000 AND 2400 KCS.

TABLE 3-4 TYPICAL ANTENNA TUNING DATA (With Capacitor) (Cont.)

35 Ft. Antenna				40 Ft. Antenna				45 Ft. Antenna				50 Ft. Antenna			
Use 50 mmfd capacitor (2 sections)				Use 50 mmfd capacitor (2 sections)				Use 25 mmfd capacitor (1 section)				Use 25 mmfd capacitor (1 section)			
Freq.	C	D	E	Freq.	C	D	E	Freq.	C	D	E	Freq.	C	D	E
2150	1	---	0	2100	1-2	---	0	2050	1-2	---	0				
2500	2-3	---	22	2500	3-4	---	25	2500	3-4	---	33				
3000	4-5	---	60	3000	4-5	---	66	3000	4-5	---	70				
3500	5-6	---	85	3500	5-6	---	100	3500	5-6	---	111				
4000	6-7	---	110	4000	6-7	---	120	4000	6	---	132				
5000	7	32	128	5000	7	38	144	5000	7	43	160				
6000	7	56	156	6000	7	60	179	5500	7	54	180				
7000	7	75	184	6500	7	71	200	5900	7	60	200				
7435	7	95	200												
				6330	9	40	0	5800	9	27	0				
7200	9	54	0	7000	9	47	94	6000	9	30	42				
7500	9	58	49	8000	9	56	148	7000	9	42	138				
8000	9	60	112	9000	9	66	162	8000	9	55	158				
9000	9	67	142	10000	9	72	174	9000	9	67	165				
10000	9	72	160	11000	9	80	177	10000	9	74	170				
11000	9	80	176	12000	9	91	178	11000	9	83	173				
12000	9	88	178	12600	9	100	179	12000	9	100	150				
13000	9	100	181					12200	9	100	173				
				11000	10	68	200								
10000	10	53	200	12000	10	76	200	12000	11	70	200				
11000	10	65	200	13000	10	85	200	13000	11	80	200				
12000	10	74	200	14000	10	100	180	14000	11	91	158				
13000	10	82	200	14190	10	100	192	14400	11	100	110				
14000	10	90	200												
14600	10	100	200	14000	12	71	200	14000	12	75	200				
				14500	12	75	200	15000	12	82	75				
14500	13	0	160	15000	12	80	200	16000	12	85	143				
15000	13	0	178	16000	12	88	150	17000	12	89	174				
16000	13	70	156	17000	12	94	108	18000	12	92	200				
17000	13	90	130	18000	12	100	157								
17700	13	100	146												

USE THESE DATA ONLY IF ONE OR MORE CHANNELS IS BETWEEN 2000 AND 2400 KCS.

USE THESE DATA ONLY IF ONE OR MORE CHANNELS IS BETWEEN 2000 AND 2200 KCS.




Figure 4-1 Primary Power Circuits

SECTION LV

THEORY OF OPERATION

1. POWER CONTROL CIRCUITS - NAVY TYPE COL-211624 POWER UNIT.

The Navy Type COL-211624 Power Unit is a complete DC operated power unit capable of supplying all necessary power for operation of a Navy Type -52286-A Radio Transmitter Unit as well as power necessary for operation of Standard Navy Control and Telephone Circuits. The object of the power control circuits is to get the master start relay K-1901 operated which will apply primary power to the low voltage dynamotor. The 28 v output of the low voltage dynamotor supplies power to operate plate power relay K-1904; therefore, as soon as the low voltage dynamotor is up to full output the plate power relay can be operated applying primary power to the high voltage dynamotor.

a. PRIMARY POWER CIRCUITS. (See figures 4-1) - The primary power circuits are the circuits necessary for excitation of the two dynamotors which furnish all plate, filament and relay power for the Navy Type -52286-A Radio Transmitter Unit as well as 14 v DC for Standard Navy Telephone Circuits.

The power source is connected to the "L" terminals on terminal board J-1905. The circuit for exciting the low voltage dynamotor D-1901 is from the positive "L" terminal through LINE fuse F-1902, EMERGENCY switch S-1906, line filter choke L-1919, the contacts of master start relay K-1901, fuse F-1903, noise filter choke L-1909, LV dynamotor D-1901, noise filter choke L-1908, line filter choke L-1920, EMERGENCY switch S-1906, LINE fuse F-1901 to the negative "L" terminal on terminal board J-1905.

The circuit for exciting the high voltage dynamotor D-1902 is from the positive "L" terminal on terminal board J-1905 through LINE fuse F-1902, EMERGENCY switch S-1906, line filter choke L-1919, the contacts of plate power relay K-1904, fuse F-1904, noise filter choke L-1911, HV dynamotor D-1902, noise filter choke L-1910, line filter choke L-1920, EMERGENCY switch S-1906, LINE fuse F-1901 to the negative "L" terminal on terminal board J-1905. Plate power relay K-1904 cannot be operated unless the LV dynamotor is operating and generating 28 v DC operating voltage for the coil of plate power relay K-1904.

b. LOCAL POWER CONTROL - 6 WIRE NAVY CIRCUIT. (See figure 4-2) - For local power control using 6 WIRE Navy Control the 4 WIRE-6 WIRE selector switch S-1907 should be in the 6 WIRE position, the LOCAL-REMOTE switch S-1908 in the LOCAL position and the 4 WIRE POWER switch S-1902 in the OFF position. To operate the master start relay K-1901, the energizing current follows the path from the positive "L" terminal on terminal board J-1905 through LINE fuse F-1902, EMERGENCY switch, S-1906, line filter choke L-1919, limiting resistor R-1901, the coil of master start relay K-1901, the contacts of ON push button S-1909, contacts 1 and 4 of 4 WIRE-6 WIRE switch S-1907, line filter choke L-1920, EMERGENCY switch S-1906, LINE fuse F-1901 to the

negative "L" terminal on terminal board J-1905. A hold-in circuit is necessary to maintain master start relay K-1901 in the operated position, therefore, a set of normally open contacts on the master start relay are connected across the contacts of the ON push button S-1909 in such a manner as to hold the relay operated when the ON push button is released. The hold-in circuit is from one contact on the ON push button S-1909; through the hold-in contacts on master start relay K-1901 and to the other contact on the ON push button S-1909.

Operation of master start relay K-1901 completes the circuit necessary to start the low voltage dynamotor. Part of the 28 v output of the LV dynamotor is utilized for operation of plate power relay K-1904. Operation of plate power relay K-1904 completes the primary circuit of the HV dynamotor which generates plate voltage for the transmitter unit. See figure 4-6 for the circuits used in operating the plate power relay K-1904.

The master start relay is returned to the unoperated position by short circuiting the operating coil to the extent that the armature releases and opens the hold-in contacts. The operating coil is short circuited by the circuit from one terminal of the coil of master start relay K-1901 through contacts 5 and 2 on the 4 WIRE-6 WIRE selector switch S-1907, the contacts of the OFF push button S-1910 contacts 6 and 3 of 4 WIRE-6 WIRE selector switch S-1907 and to the other master start relay coil terminal. A current limiting resistor, R-1901, is connected in series with the short circuiting circuit to limit the amount of current that may flow when the master start relay coil is shorted by the OFF push button.

g. LOCAL POWER CONTROL - 4 WIRE NAVY CIRCUITS. (See figure 4-3) - In 4 WIRE local control operation, the master start relay is controlled by the 4 WIRE POWER switch S-1902. The LOCAL-REMOTE switch S-1908 must be in the LOCAL position, the 4 WIRE-6 WIRE selector switch S-1907 must be in the 4 WIRE position and the 4 WIRE POWER switch S-1902 in the ON position. The coil of the master start relay K-1901 is energized by the circuit from the positive "L" terminal on terminal board J-1905 through LINE fuse F-1902, EMERGENCY switch S-1906, line filter choke L-1919, limiting resistor R-1901, the coil of master start relay K-1901, the contacts of 4 WIRE POWER switch S-1902, contacts 6 and 9 on 4 WIRE-6 WIRE selector switch S-1907, contacts 20 and 21 on LOCAL-REMOTE switch S-1908, contacts 7 and 4 on 4 WIRE-6 WIRE selector switch S-1907, line filter choke L-1920, EMERGENCY switch S-1906, LINE fuse F-1901 to the negative "L" terminal on terminal board J-1905. Since 4 WIRE POWER switch S-1902 is a positive acting switch, no hold-in circuit is necessary, therefore, the master start relay may be returned to the unoperated position merely by opening the 4 WIRE POWER switch. As indicated in figure 4-3, operating 4 WIRE POWER switch S-1902 to the ON position actuates master start relay K-1901 which closes and allows the LV dynamotor to operate. A portion of the 28 v DC output of the LV dynamotor is utilized to operate plate power relay K-1904 which applies primary power to the HV dynamotor.

i. REMOTE POWER CONTROL - 6 WIRE NAVY CIRCUITS. (See figure 4-4) - A set of push buttons are used for ON-OFF power control in standard Navy 6 WIRE control circuits. The DC power unit is designed to operate from Navy 6 WIRE circuits by operating the LOCAL-REMOTE switch S-1908 to the REMOTE position, placing the 4 WIRE-6 WIRE selector switch S-1907 in the 6 WIRE position, and opening the 4 WIRE POWER switch S-1902. Terminals 1, 2 and 3 on terminal




Figure 4-2 Local Power Control - 6 Wire Navy Circuits




Figure 4-3 Local Power Control - 4 Wire Navy Circuits




Figure 4-4 Remote Power Control - 6 Wire Navy Circuits




Figure 4-5 Remote Power Control - 4 Wire Navy Circuits

board J-1905 are provided for connecting push button control of the power circuits. The circuit for energizing the master start relay K-1901 is from the positive "L" terminal on terminal board J-1905 through LINE fuse F-1902, EMERGENCY switch S-1906, line filter choke L-1919, limiting resistor R-1901, the coil of master start relay K-1901, contacts 3 and 6 on 4 WIRE-6 WIRE selector switch S-1907, contacts 19 and 20 on LOCAL-REMOTE switch S-1908, the Navy ON push button contacts 2 and 1 on LOCAL-REMOTE switch S-1908, line filter L-1920, EMERGENCY switch S-1906, LINE fuse F-1901 to the negative "L" terminal on terminal board J-1905. Since the Navy control circuit push button is of momentary contact construction, a hold-in circuit is necessary for master start relay K-1901. This hold-in circuit consists of a pair of contacts on the master start relay which parallel the Navy ON push button. Operation of master start relay K-1901 completes the circuit necessary to energize the LV dynamotor primary winding. A portion of the 28 v DC output from the LV dynamotor is employed to energize plate power relay K-1904. The circuits required to energize plate power relay K-1904 are described in paragraph 2 of this section.

Master start relay K-1901 is returned to the unoperated position by short circuiting the operating coil. As shown in figure 4-4, terminals 2 and 3 on terminal board J-1905 are connected across the coil of master start relay K-1901. When the Navy OFF push button is pressed, the coil of master start relay K-1901 is short circuited and the hold-in circuit opens allowing the master start relay to release. Current limiting resistor R-1901 is placed in series with the operating coil of master start relay K-1901 to limit the current that may flow while the coil is short circuited by the OFF push button. A pilot light connected between terminals 1 and 4 on terminal board J-1905 will be energized when the master start relay K-1901 is operated.

e. REMOTE POWER CONTROL - 4 WIRE NAVY CIRCUITS. (See figure 4-5) Power control of 4 WIRE Navy circuits requires the use of a SPST positive action ON-OFF switch connected across terminals 2 and 5 on terminal board J-1905. For this type of control the LOCAL-REMOTE switch S-1908 must be in the REMOTE position, the 4 WIRE-6 WIRE selector switch S-1907 in the 4 WIRE position and the 4 WIRE POWER switch S-1902 in the ON position.

To energize the coil of master start relay K-1901 the circuit employed is from the positive "L" terminal on terminal board J-1905, through LINE fuse F-1902, EMERGENCY switch S-1906, line filter choke L-1919, limiting resistor R-1901, the coil of master start relay K-1901, 4 WIRE POWER switch S-1902, contacts 6 and 9 on 4 WIRE-6 WIRE selector switch S-1907, contacts 19 and 20 on LOCAL-REMOTE switch S-1908, terminals 2 and 5 on terminal board J-1905, contacts 13 and 14 on LOCAL-REMOTE switch S-1908, line filter choke L-1920, EMERGENCY switch S-1906 and LINE fuse F-1901 to the negative "L" terminal on terminal board J-1905. Since the Navy ON-OFF switch is of the positive action type, no hold-in circuit is necessary and master start relay K-1901 is released upon opening the Navy ON-OFF switch. Operating the 4 WIRE POWER switch S-1902 on the power unit to the OFF position will also release the master start relay.

A pilot light connected across terminals 2 and 4 on terminal board J-1905 will be energized when the master start relay is operated.

Operation of master start relay K-1901 completes the primary circuit to LV dynamotor D-1901. Part of the 28 v DC output of the LV dynamotor is utilized in operating plate power relay K-1904 which controls the primary power to HV dynamotor D-1902. An explanation of the circuits involved in the operation of plate power relay K-1904 is given in the following paragraphs.

2. POWER CONTROL CIRCUITS - TRANSMITTER UNIT.

The circuits described thus far were for the purpose of operating the master start relay K-1901. As a result of operating master start relay K-1901 the low voltage dynamotor is started applying filament power to the transmitter tubes and making relay power available for the transmitter unit. Relay and microphone power is also made available for NAVY control circuits.

The circuits described in the following paragraphs are for the purpose of operating the plate power relay K-1904. The operation of this relay applies primary power to the high voltage dynamotor which supplies plate power for the transmitter tubes. See figure 4-1. Plate power relay K-1904 is energized from the 28 v DC output of the low voltage dynamotor by various methods as described in the following paragraphs. See figure 4-6. In this illustration, plate power relay K-1904 is located at the extreme right hand edge of the drawing. The following operations will energize the coil of K-1904:


- a. Rotation of EMISSION selection switch S-110 to MCW.
- b. Rotation of EMISSION selection switch S-110 to CW.
- c. Rotation of EMISSION selection switch S-110 to VOICE, providing a keying device (Push-to-Talk switch, Key, Test Key, etc.) is operated.
- d. Rotation of power level selector switch S-106 to the CALIBRATE position.

If the EMISSION selector switch, S-110, is operated to the MCW position, plate power relay K-1904 is energized by the circuit through contacts 1 and 3 of Autotune motor control relay K-101, contacts 1 and 2 of the Autotune limit switch, S-111, the contacts of interlock switch S-1905, the coil of plate power relay K-1904, the contacts of EMISSION selector switch S-110, and the contacts of LOCAL-REMOTE switch S-107. Operation of the plate power relay K-1904 applies primary power to the high voltage dynamotor.

If the EMISSION selector switch, S-110 is operated to the CW position, the circuit necessary for the operation of the plate power relay, K-1904, is completed and power is applied to the primary circuit of the high voltage dynamotor. Operating the EMISSION selector switch, S-110, to the CW position completes the circuit necessary for the operation of CW relay K-103 through the contacts of LOCAL-REMOTE switch, S-107, the contacts of EMISSION selector switch, S-110, and the coil of CW relay, K-103. When CW relay K-103 has operated, the coil of plate power relay K-1904 is energized through contacts 4 and 5 of CW relay K-103, the coil of plate power relay K-1904, the contacts of interlock switch S-1905, contacts 1 and 2 of the Autotune limit switch, S-111, and contacts 1 and 3 of the Autotune motor control relay K-101.

With the LOCAL-REMOTE switch, S-107, in the LOCAL position, the EMISSION selector switch, S-110, in the VOICE position, the circuit necessary for the

Figure 4-6 Power Control Circuits - Transmitter Unit



NOTE: UNLESS OTHERWISE INDICATED ALL RESISTANCE VALUES ARE IN OHMS & CAPACITY VALUES ARE IN MICROFARADS

operation of the "voice" relay, K-104 is completed through the coil of "voice" relay K-104, the contacts of EMISSION selection switch, S-110, and the contacts of LOCAL-REMOTE switch S-107. If power level switch, S-106, is in either the TUNE or OPERATE position, it is necessary to operate the TEST switch, S-104, or to complete the circuit through the throttle switch jack, J-101, the circuit through the MICROPHONE jack, J-102, or the circuit through the KEY jack, J-103, before the plate power relay, will operate.

If the power level switch S-106 is operated to the CALIBRATE position, CW relay K-103 is operated through the coil of CW relay K-103 and the contacts of power level switch S-106. The plate power relay, K-1904 will be operated by the circuit through contacts 1 and 3 of Autotune motor control relay K-101, contacts 1 and 2 of the Autotune limit switch, S-111, the contacts of interlock switch S-1905, the coil of plate power relay K-1904, and contacts 4 and 5 of CW relay K-103.

The transmitter panel pilot lamp, I-101, will be energized when the EMISSION selector switch, S-110, is in any position other than the OFF position. The pilot lamp will be energized through contacts 1 and 3 of Autotune motor control relay K-101, contacts 1 and 2 of the Autotune limit switch S-111, the resistor R-136, the contacts of LOCAL-REMOTE switch S-107, the contacts of EMISSION selector switch S-110, and the pilot lamp I-101.

When the LOCAL-REMOTE switch S-107 is placed in the REMOTE position, control of all power circuits is transferred from the transmitter panel controls to the controls located on the Navy Type COL-23410 remote control unit.

To complete the circuit necessary for operation of plate power relay K-1904, when the EMISSION switch S-903 is placed in the VOICE position, the telegraph key must be operated or the microphone jack J-903, circuit must be completed. The "voice" relay K-104 is operated by the circuit through the coil of "voice" relay K-104, the contacts of EMISSION selector switch S-903, and the contacts of LOCAL-REMOTE switch S-107. The plate power relay K-1904 is operated by the circuit through contacts 1 and 3 of Autotune motor control relay K-101, contacts 1 and 2 of Autotune limit switch, S-111, the contacts of interlock switch S-1905, the coil of plate power relay K-1904, contacts 1 and 2 of "voice" relay K-104 and the telegraph key or the microphone jack, J-903.

If the EMISSION selector switch S-903 is operated to the CW position, the CW relay K-103 is operated by the circuit through the coil of K-103, the contacts of EMISSION selector switch S-903 and the contacts of LOCAL-REMOTE switch S-107. The operation of CW relay K-103 completes the circuit necessary for the operation of the plate power relay, K-1904. Plate power relay K-1904 is operated by the circuit through contacts 1 and 3 of Autotune motor control relay K-101, contacts 1 and 2 of Autotune limit switch S-111, the contacts of interlock switch S-1905, the coil of plate power relay K-1904, and contacts 4 and 5 of CW relay K-103. The operation of plate power relay K-1904 applies power to the primary circuit of the high voltage dynamotor.

If the EMISSION selector switch S-903 is operated to the MCW position, plate power relay K-1904 is energized through contacts 1 and 3 of Autotune motor control relay K-101, contacts 1 and 2 of Autotune limit switch S-111,

the contacts of interlock switch S-1905, the coil of plate power relay K-1904, the contacts of EMISSION control switch S-903 and the contacts of LOCAL-REMOTE switch S-107.

The pilot lamp I-901 is energized when the EMISSION switch S-903 is in any position other than the OFF position. The pilot lamp I-901 is energized by the circuit through contacts 1 and 3 of Autotune motor control relay K-101, contacts 1 and 2 of Autotune limit switch S-111, resistor R-136, the contacts of LOCAL-REMOTE switch S-107, the contacts of EMISSION selector switch S-903 and the pilot lamp I-901.

3. KEYING CIRCUITS.

Three different relays are used in the Navy Model TCZ-2 equipment for keying purposes. Two relays, K-102 in the transmitter unit and K-1903 in the power supply unit are used during HF transmission while a third relay K-3001 in the LF load coil unit is added during LF operation. The transmitter may be keyed from the front panel, from the Navy Type COL-23410 Remote Control Unit, or from NAVY Control Circuits. When the LOCAL-REMOTE switch S-1908 is in the LOCAL position, keying can be accomplished from the front panel, or the Remote Control Unit. When the LOCAL-REMOTE switch S-1908 is in the REMOTE position, keying can be accomplished from the NAVY Control Circuits, the transmitter front panel and the Remote Control Unit; however, the receiver disabling circuits will be inoperative while keying from the transmitter front panel or the Remote Control Unit.

a. LOCAL KEYING CIRCUITS. (See figure 4-7) - For local keying the LOCAL-REMOTE switch S-1908 must be in the LOCAL position and a telegraph key must be connected to J-103 in the transmitter unit. Closing the circuit through KEY jack J-103 completes the circuit through the coil of keying relay K-102, interlock switch S-113D, Autotune limit switch S-111, and Autotune motor control switch K-101 to energize keying relay K-102. While keying relay K-1903 in the power unit is concerned mostly with remote keying, the receiver disabling contacts are located on this relay and must be operated at all times; therefore, K-1903 is operated by a circuit from the 115 v DC supply through contact numbers 14 and 15 on LOCAL-REMOTE switch S-1908, contacts 1 and 10 on keying relay K-102 back through contact numbers 17 and 18 on LOCAL-REMOTE switch S-1908, through the coil of keying relay K-1903 through a set of contacts on the master start relay K-1901 and to the 115 v DC supply.

b. REMOTE KEYING CIRCUITS.

(1) NAVY CIRCUITS. - The LOCAL-REMOTE switch S-1908 in the power unit must be in the REMOTE position for remote keying using the NAVY circuits. Terminals 5 and 6 on terminal board J-1905 are provided for keying connections. From figure 4-8 it can be seen that keying relay K-102 in the transmitter unit is operated by the action of keying relay K-1903 in the power unit. The circuit for energizing the coil of K-1903 is from terminal number 5 on terminal board J-1905 through contact numbers 13 and 14 on LOCAL-REMOTE switch S-1908, through the 115 v DC supply, a set of contacts on the master start relay K-1901, the coil of keying relay K-1903, contact numbers 16 and 17 on LOCAL-REMOTE switch S-1908, and to terminal number 6 on terminal board J-1905. Operation of K-1903 energizes the coil of keying relay K-102 in the transmitter unit by the circuit from ground through the contacts of keying relay K-1903, contact numbers 9




Figure 4-7 Local Keying Circuits






Figure 4-8 Remote Keying Circuits



NOTE: UNLESS OTHERWISE INDICATED, ALL RESISTANCE VALUES ARE IN OHMS, AND CAPACITY VALUES ARE IN MICROFARADS.

Figure 4-9 Microphone Circuits



NOTE: UNLESS OTHERWISE INDICATED, ALL RESISTANCE VALUES ARE IN OHMS, AND CAPACITY VALUES ARE IN MICROFARADS.

Figure 4-10 Filament Circuits

and 10 of LOCAL-REMOTE switch S-1908, the coil of keying relay K-102, interlock switch S-113D, motor limit switch S-111, and a set of contacts on motor control relay K-101 to the positive 28 v DC source.

(2) REMOTE CONTROL UNIT NAVY TYPE COL-23410. - The keying circuits for keying the equipment from the Navy Type COL-23410 Remote Control Unit are in parallel with the keying circuits for LOCAL keying from the transmitter panel, therefore, the keying circuits are essentially the same as described in Paragraph 3a of this section.

NOTE

While it is possible to key the transmitter from the front panel while the LOCAL-REMOTE switch S-1908 is in the REMOTE position, keying relay K-1903 will not be energized so the receiver disabling circuits will be inoperative.

4. MICROPHONE CIRCUITS.

A simplified circuit of the microphone circuits is shown in figure 4-9. The transmitter may be voice modulated from the front panel, the NAVY Type COL-23410 Remote Control Unit, or from NAVY telephone circuits. Terminals number 7 and 8 of terminal board J-1905 located in the base of the power unit furnish 14 v DC at 1.2 amp for microphone and relay operation.

A toggle switch S-201 located under the tuning chart is employed in the speech amplifier input circuit to transfer the speech amplifier input from carbon microphone to dynamic microphone input. When this toggle switch is in the CARBON position, button current is supplied to the microphone. If NAVY telephone circuits are used, microphone switch S-201 should be in the CARBON position. A connection between terminals 8 and 11 on terminal board J-1905 (such as a Push-to-Talk button on a microphone) will complete the circuit to energize carrier relay K-1902. The audio input to the transmitter is connected to terminal numbers 9 and 10 of terminal board J-1905. A line matching transformer, T-1901, is provided to match lines of 200, 400, or 600 ohms impedance. The secondary of T-1901 is tapped at 42, 60, 82, and 106 ohms impedance.

5. FILAMENT CIRCUITS.

The filament power circuits of the transmitter are a combination of series and parallel connections. The filaments are supplied with power from the 28 volt DC source. Figure 4-10 shows the filament connections in simplified form. Filament power is applied to the HF oscillator tube, V-101, the frequency multiplier tubes, V-102 and V-103, the audio amplifier tube, V-201, the audio driver tube, V-202, the sidetone amplifier tube, V-203, the calibration frequency oscillator tube, V-2201, the mixer tube, V-2202, the detector-audio tube, V-2203, the LF oscillator tube, V-401, the power amplifier tube, V-104, and the modulator tubes, V-105 and V-106, when the low voltage dynamotor is started. The overload fuse, F-1905 breaks the filament circuits when an overload occurs in the transmitter filament or associated circuits.

6. EMISSION, SELECTION AND CARRIER CONTROL.

See figure 4-11. The switch S-110 is a combination transmitter ON-OFF switch and EMISSION selector switch. Selecting VOICE emission by the operation of S-110 operates relay K-104. Contacts 5 and 6 on K-104 disconnect the output of the audio oscillator, from the input to the speech amplifier. Contacts 1 and 2 on K-104 connects the coil of relay K-1904 to the emission control circuits of J-101, J-102, J-103, the TEST switch, S-104, and the remote circuits, J-903, J-904, K-1902, and K-1903. Selecting CW emission completes the circuit necessary for the operation of relay K-103. Relay contacts 4 and 5 on K-103 complete the circuit necessary for the operation of K-1904 which, in turn, applies primary power to the high voltage dynamotor. Selecting MCW emission operates relay K-1904, the plate power relay.

The RF carrier is controlled by opening the cathode circuit of the oscillator and removing the screen voltage from the power amplifier. The carrier control relay, K-102, has six sets of contacts. Contacts 3 and 9 on K-102 complete the oscillator cathode circuit by grounding resistor R-131. Contacts 3 and 9 on K-102 and resistor R-131 serve as a cathode return for both the HF oscillator, V-101, and the LF oscillator, V-401. The desired oscillator circuit is selected by the operation of switch S-114. Switch S-114 operates in conjunction with control A. The audio oscillator, is in operation whenever relay K-102 is in the operated position. The voltage developed across the resistor, R-2201, is applied to the input of the speech amplifier through the relay contacts 5 and 6 on K-104, the power level switch, S-106, and the input transformer T-201. Relay contacts 5 and 13 on K-102 apply plate voltage to V-2203. During periods of CW transmission the output of the audio oscillator is fed through the speech amplifier to the sidetone amplifier and the keying may be monitored by listening to the output of the sidetone amplifier. When switch, S-106, is in the CALIBRATE position, the circuit from the output of the audio oscillator to the input of the speech amplifier is broken. The carrier control relay K-102 may be operated by closing the circuits of the Throttle Switch jack, J-101, the MICROPHONE jack J-102, the KEY jack J-103, the TEST switch S-104, the remote microphone jack J-903, the remote key jack J-904, or by operation of relays K-1902 and K-1903. Switch S-113D is operated in conjunction with the output network switch, S-113, and breaks the energizing circuit to the coil of relay K-102 whenever S-113 is operated, thus removing excitation from the RF circuits to prevent arcing at the switch contacts. The Autotune limit switch, S-111, and the Autotune motor relay, K-101, contacts 1 and 3 are also connected in series with K-102 relay coil so that when S-111 or K-101 operates, the holding circuit for K-102 will be broken and arcing at all switch contacts will be prevented.

7. APPLICABLE REMOTE CONTROL CIRCUITS.

Terminals 1 to 12 on J-1905 in the power units are intended for use with external or remote carrier control and microphone circuits. See figure 4-12. Terminals 1 to 5 inclusive are used for primary power control of the power units while terminals 5 to 12 are used for carrier control and microphone circuits.

Operation of relays K-1902 and K-1903 completes the circuits necessary to operate the carrier control relay K-102. The keying relay K-1903 is energized by closing the circuit between terminals 5 and 6 of J-1905. For phone operation utilizing the remote circuits connected to J-1905, the carrier control relay, K-102, is operated by the operation of K-1902. The coil of K-1902 is energized by a connection from terminal No. 8 to terminal No. 11 which is made




Figure 4-11 Emission Selection and Carrier Control Circuits




Figure 4-12 Applicable Remote Control Circuits




Figure 4-13 Speech Amplifier Circuits




Figure 4-14 Modulator Circuits

through suitable relays controlled by push-buttons on handsets or chestset microphones. Contacts on carrier relay K-1902 also connect the microphone circuit from the transmitter unit to terminals 9 and 10 of terminal board J-1905 through transformer T-1901. Carrier relay K-1902 gets energizing current from a winding on the low voltage dynamotor which supplies 14 volts at 1.2 amps of filtered DC for this purpose. This winding also furnishes button current for remote carbon button microphones and current for other control relays that may be involved.

8. AUDIO CIRCUITS.

The audio system consists of a two stage speech amplifier, push-pull modulators, a sidetone amplifier, and an MCW audio tone oscillator.

a. **SPEECH AMPLIFIER.** - See figure 4-13. Either of two types of microphone may be used with this equipment. The input to the speech amplifier has been designed so that by operating a switch, proper connections are made to the MICROPHONE jack, J-102, (figure 4-13) to match the output of either a carbon or dynamic type of microphone. The microphone circuit selector switch, S-201, is located beneath the tuning chart on the front panel of the transmitter. If S-201 is placed in the CARBON position, limiting resistors R-201 and R-202 are connected between the positive terminal of the 28 v DC power source and the MICROPHONE jack, J-102, to provide the voltage necessary for the operation of the carbon type of microphone. The operation of S-201 also connects resistor R-203 between J-102 and the input circuit of the speech amplifier to reduce the level of the output of the carbon microphone to the level of the output of a dynamic microphone. Thus, no audio gain control has been provided because the level of the input to the speech amplifier is the same when using a dynamic microphone as it is when using a carbon microphone. If S-201 is placed in the DYNAMIC position the voltage is removed from the input circuit and the MICROPHONE jack, J-102, is connected in series with resistor R-216 and the primary of the input transformer, T-201. The two stage speech amplifier employs a Type 12SJ7 tube, V-201, as first amplifier, and a Type 6V6GT tube, V-202, as second amplifier. The output of the microphone is coupled by the input transformer, T-201, to the grid of V-201. The output of V-201 is coupled to the grid of V-202 by the capacitor C-204. The output of the audio driver tube, V-202, is coupled to the grids of the modulator tubes V-105 and V-106 by transformer T-202.

b. **MODULATOR.** - The modulator employs two Type 811 high mu triodes connected in push-pull, and operating Class B. See figure 4-14. The modulators are capable of modulating the carrier (100 watts nominal) at least 90% with full voltage applied to the power amplifier. While the 811 is essentially a zero bias tube when used with plate voltages as high as 1150 volts DC, it becomes necessary to apply some bias to the grid of the tube to keep the static plate current at a safe value. In this application the bias is obtained from the 28 volt DC supply by utilizing the average voltage drop through the filaments of the tubes to obtain equal voltage for application to the grids of both modulator tubes. The output of the modulators is coupled to the RF circuits by modulation transformer T-101. Both the screen and plate of the power amplifier tube, V-104, are modulated. The full output voltage of 1150 volts DC, is applied to the plates of the modulator tubes, V-105 and V-106. Relay contacts 3 and 7 on K-103 remove plate voltage from the modulators when CW emission is selected.


c. SIDETONE AMPLIFIER. - A sidetone amplifier, figure 4-15 is incorporated in the same unit as the two stage speech amplifier. The amplifier employs a Type 6V6GT beam pentode tube V-203. The output of the audio driver V-202 in addition to being applied to the primary of coupling transformer T-202, is applied to a voltage dividing system consisting of C-206, R-211 and R-212. The grid of the sidetone amplifier V-203 is coupled to the junction of R-211 and R-212 and the voltage developed across resistor R-211 drives the grid of V-203 to provide sufficient output from the sidetone amplifier to operate headphones or speaker. The output of V-203 is coupled to the SIDETONE jack, J-104, by the transformer T-203 through the switch S-202 and relay contacts K-102C. The turns-ratio of transformer T-203 may be varied by operating the sidetone OUTPUT switch S-202. The output of the sidetone amplifier is keyed by the operation of the carrier control relay K-102. The SIDETONE jack, J-105, may be connected in parallel with J-104 by connecting a jumper between terminals 26 and 27 of cable connector J-106. The necessary plate and screen voltages for the sidetone amplifier are obtained by tapping the bleeder system of the low voltage output of the power unit.

9. CALIBRATION OSCILLATOR.

a. GENERAL. - The calibration oscillator employs a circuit known as a regenerative frequency divider. The circuit produces a 50 kc fundamental frequency and harmonic output voltages while using a 200 kc crystal as a controlling standard. The 200 kc quartz crystal unit is mounted in a sealed holder which plugs into the two prong receptacle in the rear right-hand corner of the transmitter. Both triode sections of a 12SL7GT tube, V-2201, a 12SA7 pentagrid converter tube, V-2202, and one section of an additional 12SL7GT tube, V-2203, are used in the calibration oscillator circuit. The crystal holder and vacuum tubes plug into sockets on top of the chassis in the order mentioned. The chassis is stamped with the crystal and vacuum tube type designations. The inductor tuning screws that protrude through the sides of the shield cans containing tank circuits Z-2201A, Z-2201B, Z-2202A, and Z-2202B should not be adjusted for any reason unless the alignment procedure is thoroughly understood. The CFI Unit is placed in operation by applying plate voltage to the CFI tubes. The voltage is obtained from the low voltage section of the dynamotor and is applied when power level switch S-106 is operated to the CALIBRATE position. Operating power level switch S-106 to either TUNE or OPERATE position removes high voltage from the CFI tubes thus disabling the oscillator circuit.


b. CIRCUIT FUNCTION. (Figure 4-16)

(1) The application of plate voltage to the oscillator section of 12SL7GT tube V-2201, starts the 200 kc crystal oscillator. This causes a frequency of 200 kc, plus random tube and circuit noises, to appear on the injection grid of 12SA7 mixer tube V-2202. This random noise appearing on the plate of 12SA7 excites the frequency tripler section of 12SL7GT tube V-2201. Since the plate circuit of this section of 12SL7GT tube V-2201 is tuned to 150 kc, only the 150 kc components of the random noise are amplified. This 150 kc component of the random noise is then impressed on the control grid of the 12SA7 mixer tube. Since the plate circuit of the 12SA7 is tuned to 50 kc; the 50 kc difference frequency, produced by the combination of a 200 kc voltage and a 150 kc voltage appearing in the 12SA7 tube, is the frequency amplified. This 50 kc voltage continues to excite the second triode section of the 12SL7GT, which because of its 150 kc plate circuit, triples the frequency and sustains the 150 kc




NOTE:
UNLESS OTHERWISE INDICATED ALL RESISTANCE
VALUES ARE IN OHMS AND CAPACITY VALUES ARE
IN MICROFARADS.

Figure 4-15 Sidetone Amplifier Circuits




NOTE: UNLESS OTHERWISE INDICATED ALL RESISTANCE VALUES ARE IN
OHMS, AND CAPACITY VALUES ARE IN MICROFARADS.

Figure 4-16 CFI Circuits



NOTE: UNLESS OTHERWISE INDICATED, ALL RESISTANCE VALUES ARE IN OHMS, AND CAPACITY VALUES ARE IN MICROFARADS.

Figure 4-17 MCW Oscillator Circuits



NOTE: UNLESS OTHERWISE INDICATED, ALL RESISTANCE VALUES ARE IN OHMS, AND CAPACITY VALUES ARE IN MICROFARADS.

Figure 4-18 Low Frequency Circuits

voltage on the 12SA7 control grid. The 50 kc voltage appearing on the 12SA7 plate becomes the calibration frequency.

(2) One triode section of the second 12SL7GT tube, V-2203, is employed as a signal detector. A portion of the 50 kc voltage appearing on the plate of 12SA7 tube V-2202 is coupled to the grid of V-2203 by capacitor C-2204. Depending upon the transmitting frequency that is selected, a portion of the output of the LF oscillator or the HF oscillator is coupled to the grid of V-2203 by capacitor C-2206 or capacitor C-2205. The beat note that is generated in the signal detector between the output of the HF of the LF oscillator and the 50 kc CFI standard is coupled to the input of the speech amplifier by capacitor C-2209. When power level switch S-106 is operated to the CALIBRATE position, the circuit is completed and the output of the signal detector is heard in the sidetone circuits of the transmitter. The second triode section of 12SL7GT tube V-2203 is connected as an audio oscillator which supplies a signal for sidetone keying and MCW operation of the transmitter. The 12SA7 CFI mixer tube V-2202 and the audio oscillator section of 12SL7GT tube V-2203 are provided with a common bias resistor, R-2217. When the CFI is turned off, the voltage drop across R-2217 is not sufficient to stop the audio oscillator. However, when the CFI is operating, 12SA7 CFI mixer tube V-2202 draws sufficient current to cause a sharp increase in the voltage drop across R-2217 increasing the bias voltage applied to the cathode of the audio oscillator section of 12SL7GT tube V-2203. This results in overbiasing and stopping the audio oscillator tube which prevents the CFI detector from accepting a portion of the 1000 cycle voltage, generated by the audio oscillator, through capacity coupling between the 12SL7GT tube elements.

10. MCW AUDIO OSCILLATOR. (Figure 4-17.)

Keying relay contacts 5 and 13 on K-102 apply voltage to the plate of the audio oscillator section of 12SL7GT tube V-2203 when keying relay K-102 is operated. The audio frequency output level of this oscillator and consequently the percentage of MCW modulation is controlled by varying resistor R-2201. The screwdriver slot for varying resistor R-2201 is accessible through a hole on the rear of the MCW-CFI Unit. The voltage developed across resistor R-2201 is coupled through "voice" relay contacts 5 and 6 on K-104 and power level switch S-106 to the speech amplifier input circuit, making the audio oscillator the MCW oscillator when MCW emission is selected. When VOICE emission has been selected, voice relay contacts 5 and 6 on K-104 disconnect the output of the audio oscillator section of vacuum tube V-2203 from the input circuit of the speech amplifier. During periods of CW transmission the audio oscillator is keyed and the output is fed to the input of the speech amplifier and the sidetone amplifier to provide a means of monitoring the keying.

11. RADIO-FREQUENCY CIRCUITS.

The Type COL-52286-A Transmitter employs two RF systems. One system covers the frequency range 200 kc to 1500 kc and the other system the frequency range 2000 kc to 18,100 kc. Separate oscillator tubes are employed for each frequency range. The same power amplifier tube serves both systems.

a. LOW-FREQUENCY CIRCUITS. (See figure 4-18.) - The LF oscillator, V-401, employs a Type 1625 beam pentode tube. This oscillator operates in the frequency range 200 kc to 1500 kc. This frequency range is covered in six bands.

Refer to the oscillator calibration curves, Section III for the frequency coverage of the individual bands. A combination of capacitive and inductive grid tuning is employed. The COARSE tuning switch S-401 varies the grid circuit capacity by increasing the number of padding capacitors connected in the circuit as S-401 is rotated toward the lowest frequency position. Switch S-401 also changes the tap on the grid inductor L-401 to vary the inductance in the grid circuit. Trimmer capacitors have been connected in parallel with the padding capacitors to provide means of fine adjustment of grid circuit capacity. These trimming capacitors are of the ceramic type and the capacity of each may be varied by rotating one plate with respect to the other. In spite of the small physical size, this type of capacitor provides a means of varying the capacity over a wide range. With the end-points of the frequency band set and the trimmer capacitors adjusted to give some overlap in each position of switch S-401, all fine frequency adjustments within the frequency range of each switch position are made by varying the inductance of the inductor L-401. The inductance of L-401 is altered by adjusting the position of the core, which is actuated by the tuning screw that is accessible through the coil shield. The position of the tuning core within the inductor is determined by Control G. When LF operation is desired and the LF position (13) of control "A" has been selected, the cathode circuit of the oscillator V-401 is coupled through the contacts of switch S-114 and resistor R-131 to relay contacts 3 and 9 of the carrier control relay K-102. Operation of K-102 completes the cathode circuit to ground. Screen voltage for V-401 is obtained by tapping the low voltage output bleeder. The output of the oscillator V-401 is coupled to the grid of the power amplifier tube V-104 by S-103 when Control "A" is operated to the LF position. Selecting LF operation operates relay K-105 which connects the plate circuit of V-104 to the external loading coil. The HF output network is completely removed from the circuit by the operation of K-105. Relay contacts K-105 remove the shorting connection across the plate choke, L-109. Screen voltage for V-104 is obtained from the low voltage output of the power unit. The full voltage of the high voltage section of the power unit is applied to the plate of V-104. The external loading coil in addition to being an antenna loading coil is also the power amplifier plate tank circuit. A tapped inductor and variometer provide means of adjusting the loading and the power amplifier plate tank tuning.

Antenna keying relay K-3001 in the low frequency load coil unit is connected to the keying circuit and is operated in synchronism with carrier relay K-102 when the telegraph key, test key, or microphone switch is operated.

b. HIGH FREQUENCY EXCITER CIRCUITS. - The HF oscillator, figure 4-19, employs a beam pentode Type 837 tube, V-101, in a variable frequency oscillator circuit. The oscillator operates within the frequency range 1000 kc to 1510 kc. This frequency range is covered in two bands, 1000 kc to 1200 kc, and 1200 kc to 1510 kc. The band of frequencies within which output is obtained, is dependent on the position of HF oscillator range switch S-101. Capacitors C-101 and C-135 are connected in the grid circuit of the HF oscillator tube, V-101, by HF oscillator range switch S-101 which is operated by Control "A". Alternate positions of Control "A" add or remove the padding capacitors C-101 and C-135. With Control "A" in the 2.0 mc to 2.4 mc position HF oscillator range switch S-101 is closed, giving the maximum grid circuit capacitance and consequently the lowest frequency output. Therefore, when Control "A" is in the 2.0 mc to 2.4 mc position, oscillator output is obtained in the frequency range 1000 kc to 1200 kc. When Control "A" is rotated to the 2.4 mc to 3.0 mc position, HF oscillator range switch S-101 is opened, removing capacitors C-101 and C-135 from the circuit, and oscillator output is obtained in the frequency range




Figure 4-19 High Frequency Exciter Circuits




Figure 4-20 Power Amplifier and Output Network




Figure 4-21 High Frequency RF Circuits - Block Diagram

1200 kc to 1510 kc. When Control "A" is operated to the 3.0 mc to 3.6 mc position, HF oscillator range switch S-101 is again operated to the closed position and oscillator output is obtained in the frequency range 1000 kc to 1200 kc. In the remaining nine HF positions of Control "A", HF oscillator range switch S-101 is alternately opened and closed to give oscillator output as indicated above. Trimming capacitors C-134 and C-135 have been provided to aid in setting the end-points of the two frequency bands. When setting the HF end of the 1000 kc to 1200 kc band, the grid capacity is trimmed using variable capacitor C-135. When the HF end of the 1200 kc to 1510 kc band is set, the grid tuning capacity is trimmed by using variable capacitor C-134. Fine frequency adjustment within each band is made by varying the inductance of grid tuning inductor L-101. The inductance of L-101 is varied by adjusting the position of the tuning slug within the coil. The position of the tuning slug is determined by Control "B". Approximately 20 revolutions of Control "B" will cover the entire frequency range of the band upon which the oscillator is operating, with some overlap on both ends of the band. A portion of the output of the HF oscillator V-101 is fed to the grid of the CFI tube, V-2203, to permit the calibration of HF oscillator tube V-101 against the crystal oscillator circuit of CFI unit. When HF operation has been selected, rotating Control "A" to any one of the twelve HF positions will close the cathode circuit of HF oscillator tube V-101 through cathode choke L-102, the contacts of oscillator selecting switch S-114 and the cathode resistor R-131, to keying relay contacts 3 and 9 on K-102. The operation of keying relay K-102 completes the cathode circuit to ground. Screen voltage for HF oscillator tube V-101 is obtained by tapping the bleeder across the low voltage output of the power unit. The full voltage of the low voltage section of the power unit is applied to the plate of HF oscillator tube V-101.

To obtain RF output in the frequency range 2000 kc to 18,100 kc, the output of the HF oscillator must be multiplied from two to twelve times. The frequency multiplier tubes, V-102 and V-103, are inoperative when LF operation has been selected. The frequency multiplier stages employ Type 1625 beam pentode tubes. The first multiplier tube may operate as a frequency doubler, tripler, or quadrupler. The number of times that the frequency of the output of the HF oscillator tube, V-101, is multiplied is dependent upon the position of first multiplier range switch S-102. The position of first multiplier range switch S-102 is determined by Control "A". Twelve HF positions and one LF position of Control "A" are available. The twelve HF positions permit the selection of any output frequency within the frequency range 2000 kc to 18,100 kc.

The 13 positions of Control "A" and the frequency range covered by each are tabulated below:

HIGH FREQUENCY TUNING - COARSE

<u>Control Position "A"</u>	<u>Frequency Range</u>
1	2.0 to 2.4 mc
2	2.4 to 3.0 mc
3	3.0 to 3.6 mc
4	3.6 to 4.0 mc
5	4.0 to 4.8 mc
6	4.8 to 6.0 mc
7	6.0 to 7.2 mc

HIGH FREQUENCY TUNING - COARSE (Cont)

<u>Control Position</u>	<u>Frequency Range</u>
8	7.2 to 9.0 mc
9	9.0 to 10.8 mc
10	10.8 to 12.0 mc
11	12.0 to 14.4 mc
12	14.4 to 18.1 mc
13	200 kc to 1500 kc

In the first six positions of Control "A", only the first frequency multiplier tube, V-102, is in operation. First multiplier range switch S-102 connects the output circuit of the first frequency multiplier tube V-102 to the input circuit of the final amplifier tube V-104. With Control "A" in Position 1 or 2, first multiplier tube V-102 is operating as a frequency doubler. With Control "A" in Position 3 or 4, first multiplier tube V-102 is operating as a frequency tripler. With Control "A" in Position 5 or 6, first multiplier tube V-102 is operating as a frequency quadrupler. First multiplier range switch S-102 is a twelve-position switch and connects padding capacitors across the first multiplier tube V-102 plate tuning inductor L-105. The capacity of the tank circuit is reduced as Control "A" is rotated in a clockwise direction, thus increasing the frequency of the output of first multiplier tube V-102 as Control "A" is rotated through Positions 1 through 6. When Control "A" is rotated to Position 7, the second multiplier tube, V-103 is placed in operation. First multiplier range switch S-102 acts to connect the output circuit of first multiplier tube V-102 to the grid circuit of second multiplier tube V-103 and breaks the circuit from the first multiplier tube V-102 output circuit to the grid circuit of final amplifier tube V-104. The second multiplier tube V-103 operates only as a frequency tripler. Control "A", when in Positions 7 to 12 inclusive, also operates second multiplier operating switch S-115 to connect the cathode of second multiplier tube V-103 through bias resistor R-129 to ground. The first multiplier tube, V-102, operates as a frequency doubler when Control "A" is in Position 7 or 8, as a frequency tripler when Control "A" is in Position 9 or 10, and as a frequency quadrupler when Control "A" is in Position 11 or 12. Second multiplier range switch section S-103 connects the sections of padding capacitor C-115 across the second multiplier tube V-103 plate inductor, L-106. Capacitors C-111 and C-115 are of the ceramic type and the capacity of each section may be adjusted by rotating one plate in respect to the other. The frequency multiplier stages are aligned by adjusting the capacity of C-111 and C-115 and the inductance of the plate tank inductors L-105 and L-106. The tuning slugs within inductors L-105 and L-106 are ganged with the tuning slug of L-101, but may be adjusted in respect to each other and with respect to the tuning slug of L-101, to obtain proper tracking within each frequency band. Plate and screen voltages for the frequency multiplier tubes, V-102 and V-103, are furnished by the low voltage section of the power unit. The voltage for application to the tube screens is dropped from the 400 volt output of the power unit to approximately 270 volts by dropping resistors R-105 and R-109.

c. POWER AMPLIFIER AND OUTPUT NETWORK. - The power amplifier stage, figure 4-20, employs a Type 813 beam pentode tube and operates as a straight amplifier at all frequencies. When the transmitter is operating in the frequency range 200 kc to 1500 kc, the output of the RF oscillator is capacitively coupled to

the grid of the power amplifier. When the transmitter is operating in the frequency range 2.0 mc to 6.0 mc the output of the first frequency multiplier tube, V-102, is coupled to the grid of the power amplifier tube through first multiplier range switch S-102 contacts and capacitor C-116. When the transmitter is operating in the frequency range 6.0 mc to 18.1 mc the output of the second frequency multiplier tube, V-103 is coupled to the grid of the final amplifier tube, V-104, through second multiplier range switch S-103 contacts and capacitor C-116. When LF operation has been selected, output circuit selecting relay K-105 operates to connect the plate circuit of the final amplifier tube, V-104, to external loading coil terminal J-117. With output circuit selecting relay K-105 in the normal unoperated position, the plate circuit of final amplifier tube V-104 is connected to the output network that is incorporated in the transmitter proper. Screen voltage for the power amplifier is supplied by the low voltage section of the power unit. Screen voltage is applied to final amplifier tube V-104 when the keying relay K-102 is operated through relay contacts 5 and 13 on K-102. The operation of output circuit selecting relay K-105 performs four functions, namely, (1) connects the output of the power amplifier to external loading coil terminal J-117, (2) disconnects the antenna tuning and power amplifier plate tank circuit, (3) adds an additional RF choke, L-109, in series with the power amplifier feed choke L-108, and (4) connects the positive 28 volt DC lead to external relay connector J-107. When output circuit selecting relay K-105 is in the normal or unoperated position, the output of the power amplifier tube is coupled to the plate tank and antenna coupling network in the transmitter proper through the capacitor C-118 and the RF choke, L-109, is shorted out. The full output voltage of the high voltage section of the power unit is applied to the plate of final amplifier tube V-104.

The output network is designed to operate as either a pi or L section. The multi-section output network switch S-113 connects the capacitors and inductors in the proper positions to permit matching the power amplifier plate circuit to most aircraft antennas at any frequency within the frequency range 2000 kc to 18,100 kc.

The following table will help the operator to better understand the operation of the output network switch S-113:

Control "C"	S-113A	S-113B	S-113C	S-113E	S-113F	S-113G	S-113H
Position							
1	Operated by the rotation of C-125. (Operated when dial E reads in 0-100 range.)	1	1	OPEN	OPEN	OPEN	OPEN
2		1	2	OPEN	OPEN	OPEN	OPEN
3		1	3	OPEN	OPEN	OPEN	OPEN
4		1	4	OPEN	OPEN	OPEN	OPEN
5		1	5	OPEN	OPEN	OPEN	OPEN
6		1	6	OPEN	OPEN	OPEN	OPEN
7		1	7	OPEN	OPEN	OPEN	OPEN
8		2	7	OPEN	CLOSED	CLOSED	CLOSED
9		2	7	OPEN	OPEN	OPEN	CLOSED
10		2	7	OPEN	OPEN	CLOSED	OPEN
11		2	7	OPEN	CLOSED	OPEN	OPEN
12		2	7	OPEN	OPEN	OPEN	OPEN
13		2	7	CLOSED	OPEN	CLOSED	OPEN

The variometer, L-112, is operated by Control "D". The variable capacitor C-125 is operated by Control "E". The above controls are connected to the Autotune system, but may be manually operated without disturbing the positions of the Autotune stop rings if the CHANNEL selector switch S-108 is placed in the MANUAL position and the Autotune system allowed to operate. The network will tune and deliver rated power to antennas 17 feet to 60 feet in length throughout the frequency range 3000 kc to 18,100 kc. If operation in the range 2000 kc to 3000 kc is desired, it may be necessary to connect the Type-481628 Antenna Shunt Capacitor (figure 1-8) across the network output.

12. AUTOTUNE SYSTEM.

The Collins Autotune System is an electrically controlled means of mechanically repositioning adjustable elements such as tap switches, variable inductors, variable capacitors, etc. Any combination of these items such as are used in transmitting equipment can be tuned to any one of eleven preselected frequencies in a period of twenty-five seconds at normal room temperature and with a normal supply voltage, by the use of the Autotune system. Provisions have also been made to permit manual tuning of the radio equipment.

The Autotune assembly consists of a group of positioning mechanisms, one of which is applied to each tuning element to perform the same function as a manual tuning knob. Each positioning mechanism provides precise angular setting of the tuning control to any one of eleven angular positions, each of which is readily adjustable. The settings for each frequency and for each control are entirely independent.

The positioning accuracy of the Autotune mechanism is of a very high order. Each setting is inherently independent of wear, backlash, alignment, supply voltage, etc. The accuracy of the settings is comparable to that of vernier manual controls. The parts are machined within close limits and although operation is most precise, there are no delicate adjustments or fragile mechanisms. Permanently lubricated bearings are used in many places and the assembly is enclosed and protected from dust and corrosion.

a. MECHANICAL DETAILS. (Refer to figure 4-22.)


(1) LINE SHAFT. - The line shaft extends the entire length of the Autotune casting and drives all the Autotune units. Power is applied to the shaft from the motor (47) by means of a chain drive (18).

(2) SINGLETURN WORM. - The singleturn unit is driven by one worm on the line shaft (1).

(3) CAM DRUM DRIVE SPUR GEAR. - This gear is fastened directly to the slip clutch worm gear (4) and drives the cam drum spur gear (10) through the idler gear (14).

(4) SLIP CLUTCH WORM GEAR. - This gear is fastened to the cam drum drive spur gear (3) and drives the stop ring drum (12) through the slip clutch (6). This gear is driven by the singleturn worm (2).

(5) SLIP CLUTCH BAND. - This band is driven directly from the slip clutch worm gear (4) and presses against the slip clutch drum (6).



KEY TO SYMBOLS

- 1-LINE SHAFT
- 2-SINGLETURN WORM
- 3-CAM DRUM DRIVE SPUR GEAR
- 4-SLIP CLUTCH WORM GEAR
- 5-SLIP CLUTCH BAND
- 6-SLIP CLUTCH DRUM
- 7-TUNED ELEMENT
- 8-CIRCUIT SEEKING TAP SWITCH
- 9-SINGLE TOOTH RATCHET
- 10-CAM DRUM SPUR GEAR
- 11-CAM DRUM
- 12-STOP RING DRUM
- 13-SINGLETURN DIAL
- 14-IDLER GEAR
- 15-PAWL (15A-PAWL HEEL)(15B-PAWL TOE)
- 16-SINGLETURN HOME STOP PAWL

- 17-PAWL SPRING
- 18-SINGLETURN HOME STOP RING
- 19-ANVIL
- 20-MULTITURN WORM #1
- 21-MULTITURN HOME STOP CAM
- 22-SLIP CLUTCH BAND
- 23-SLIP CLUTCH DRUM
- 24-TUNED ELEMENT
- 25-IDLER GEAR #1
- 26-IDLER GEAR #2
- 27-COUNTER DRUM SPUR GEAR
- 28-COUNTER DRUM
- 29-TURN COUNTER DIAL
- 30-REAR LIMIT SWITCH SECTION
- 31-FORWARD LIMIT SWITCH SECTION
- 32-LIMIT SWITCH DRIVE SHAFT

- 33-SWITCH OPERATING ARM
- 34-LIMIT SWITCH DRIVE SHAFT SPUR GEAR
- 35-MULTITURN DIAL
- 36-STOP RING DRUM
- 37-PAWL (37A-PAWL HEEL)
(37B-PAWL TAIL) (37C-PAWL TOE)
- 38-CAM DRUM
- 39-MULTITURN WORM #2
- 40-PAWL SPRING
- 41-STOP RING DRUM WORM GEAR
- 42-STOP RING DRUM SPUR GEAR
- 43-CAM DRUM WORM GEAR
- 44-COUNTER DRUM DRIVE GEAR
- 45-MULTITURN HOME STOP PAWL
- 46-MULTITURN HOME STOP RING
- 47-AUTOTUNE MOTOR
- 48-CHAIN DRIVE

Figure 4-22 Collins Autotune System - Mechanical Portion

(6) SLIP CLUTCH DRUM. - This slip clutch drum, driven by the slip clutch band (5), is fastened to the stop ring drum shaft.

(7) TUNED ELEMENT. - The tuned element, such as a tap switch, a variable capacitor, or a variometer, is driven directly from the stop ring drum shaft.

(8) CIRCUIT SEEKING TAP SWITCH. - This switch is driven by the cam drum shaft and is phased so that the contacts are in synchronization with the cams of the cam drums (11) and (38).

(9) SINGLE TOOTH RATCHET. - The single tooth ratchet, when engaged, drives the cam drum. These ratchets keep the cam drums of the various units synchronized.

(10) CAM DRUM SPUR GEAR. - The cam drum spur gear is driven from the line shaft through gears (2), (3), and (14). The spur gear drives the cam drum (11) through the single tooth ratchet (9).

(11) CAM DRUM. - The cam drum consists of twelve cams mounted on a shaft with adjacent cam slots staggered 30 degrees. These cams are rigidly fastened to the drum. The single tooth ratchet (9) mounts on the shaft behind the drum and drives the drum.

(12) STOP RING DRUM. - The stop ring drum assembly consists of twelve stop rings mounted on a shaft with spacers between the rings. The stop rings are free to rotate but the spacers are keyed to the shaft such that as one stop ring is rotated, movement of the ring will not affect the adjacent rings which may have been previously adjusted. A locking bar, on the dial, locks the stop rings when adjustment has been completed. The locking mechanism consists of a bar that drives a screw to apply pressure to the stack of stop rings and spacers, thereby, in effect, locking them.

(13) SINGLETURN DIAL. - The singleturn dial is fastened to the stop ring drum (12) and enables the operator to adjust the tuned element (7). The locking bar is located on the front of the dial.

(14) IDLER GEAR. - The idler gear transmits power from the cam drum drive spur gear (3) to the cam drum spur gear (10).

(15A) PAWL HEEL. - The pawl heel is held against the cam drum (11) by the pawl spring (17).

(15B) PAWL TOE. - The pawl toe serves to position the tuned element (7) by dropping into the stop ring slot and stopping the stop ring drum (12) after the motor (47) reverses and the pawl heel (15A) is in a cam drum slot.

(16) SINGLETURN HOME STOP PAW. - This pawl limits the rotation of the singleturn unit to one revolution. The pawl is located on the same shaft as the pawl (15) and is engaged by the singleturn home stop ring (19). Referring to the mechanical portion of the Autotune, the pawl as shown in solid lines limits the rotation of the stop ring drum (12) in the counterclockwise direction. The pawl cannot pivot further because it bears against the stop ring drum (12) at point "B". The pawl as shown in dotted lines limits the rotation of the cam drum (12) in a clockwise direction. The pawl cannot pivot further in this posi-

tion because it bears on the cam drum (11) at point "A".

(17) PAWL SPRING. - The pawl spring presses the pawl heel (15A) against the cam drum (11) and when the pawl heel (15A) drops into the cam drum slot, the pawl spring presses the pawl toe (15B) against the stop ring drum (12).

(18) SINGLETURN HOME STOP RING. - This ring, mounted with the other stop rings on the stop ring drum (12), is rigidly fastened to the drum. The home stop pawl (16) engages with this ring to limit the rotation of the stop ring drum (12) to one revolution.

(19) ANVIL. - The anvil prevents the multiturn pawl tails (37B) from becoming engaged in the counter drum (28) ring slots until after the motor (47) reverses.

(20) MULTITURN WORM #1. - This worm drives the stop ring drum worm gear (41).

(21) MULTITURN HOME STOP CAM. - This cam is mounted with the other cams on the counter drum (28). This cam actuates the home stop pawl (45) to limit the rotation of the stop ring drum (36) to twenty revolutions.

(22) SLIP CLUTCH BAND. - This band, driven by the worm gear (41), drives the stop ring drum (36) through the slip clutch drum (23).

(23) SLIP CLUTCH. - This clutch, similar to (6), is driven by the slip clutch band (22) and is fastened to the stop ring drum shaft.

(24) TUNED ELEMENT. - This frequency determining element is coupled directly to the stop ring drum (36).

(25) IDLER GEAR #1. - This gear and gear (26) link the counter drum (28) to the slip clutch spur gear (44) which is fastened to the stop ring drum (36).

(26) IDLER GEAR #2. - This gear and idler gear #1 (25) link the counter drum (28) to the slip clutch spur gear (44).

(27) COUNTER DRUM SPUR GEAR. - This gear drives the counter drum (28).

(28) COUNTER DRUM. - This drum consists of eleven cams with spacers between them. Like the stop ring drums (12) and (36), the spacers are keyed to the shaft so that movement of one cam will not disturb adjacent cams. A spring on the rear of the counter drum loads the stack of cams axially so that the rings will not turn too easily.

(29) TURN COUNTER DIAL. - This dial, numbered from 0 to 20, indicates the number of turns the Multiturn unit has made.

(30) REAR LIMIT SWITCH SECTION. - This switch, actuated by the operating arm (33), is normally held in the operated position. During the first part of the Autotune cycle, this switch opens, disabling the keying relay. As the Autotune cycle nears completion, the operating arm (33) recloses the switch, turning off the motor (47) and restoring the coil circuit of the keying relay.

(31) FORWARD LIMIT SWITCH SECTION. -- This switch, normally closed, provides a holding circuit for the motor control relay. When the operating arm (33) opens the switch, the circuit seeking tap switch reverses the motor, thereby returning the Autotune to the home position, completing the cycle.

(32) LIMIT SWITCH DRIVE SHAFT. -- This shaft is driven by the gear (34) from the line shaft (1). The screw thread on the shaft moves the switch operating arm forward or backward between the limit switch sections (30) and (31). On either end of the screw are cams which limit the travel of the switch operating arm (33).

(33) SWITCH OPERATING ARM. -- This arm is driven by the threaded drive shaft (32) and controls limit switches (30) and (31).

(34) LIMIT SWITCH DRIVE SHAFT SPUR GEAR. -- This gear, driven by the stop ring drum spur gear (42) drives the limit switch drive shaft (32).

(35) MULTITURN DIAL. -- This dial with locking bar enables the operator to adjust the stop ring drum (36) to any desired operating frequency within the range of the equipment.

(36) STOP RING DRUM. -- See (12).

(37A) PAWL HEEL. -- The pawl heel is held against the cam drum (38) by the pawl spring (40).

(37B) PAWL TAIL. -- The pawl tail, when allowed to engage the counter drum (28) ring slot by the movement of the anvil (19) selects the revolution in which the tuned element (24) will be positioned.

(37C) PAWL TOE. -- The pawl toe serves to position the tuned element (24) by dropping into the stop ring slot and stopping the stop ring drum (36).

(38) CAM DRUM. -- See (11).

(39) MULTITURN WORM #2. -- This worm drives the cam drum (38) through the singletooth ratchet (9).

(40) PAWL SPRING. -- This spring is similar to (16).

(41) STOP RING DRUM WORM GEAR. -- This gear, powered from the line shaft (1) by the worm (20), drives the stop ring drum (36) through the slip clutch (23).

(42) STOP RING DRUM SPUR GEAR. -- This gear is fastened to the stop ring drum worm gear (41) and drives the limit switch drive shaft (32) through the gear (34).

(43) CAM DRUM WORM GEAR. -- This gear, powered from the line shaft (1) by the worm (39), drives the cam drum (38) through the single tooth ratchet (9).

(44) COUNTER DRUM DRIVE GEAR. -- This gear, fastened to the slip clutch drum (23) drives the counter drum (28) through the idler gears (25) and (26) and gear (27).

(45) MULTITURN HOME STOP PAWL. - This pawl, actuated to either position shown by the home stop cam (21), engages the projection on the home stop ring (46) to limit the rotation of the stop ring drum (36) to 20 revolutions. This pawl is mounted on the same shaft as the pawl (37).

(46) MULTITURN HOME STOP RING. - This ring is engaged by the pawl (45) and is mounted on the stop ring drum (36). The dotted outlines of the home stop ring (46) and pawl (45) show the stop ring drum (36) in the limit of rotation in the counterclockwise direction. The other position shows limit in the clockwise direction.

(47) AUTOTUNE MOTOR. - The Autotune motor is a DC shunt wound reversible type and applies power to the line shaft (1) through the chain drive (48).

(48) CHAIN DRIVE. - The chain drive transmits the power from the Autotune motor (17) to the line shaft (1) and consists of a driving pinion coupled to a driven sprocket by a chain.

b. ELECTRICAL DETAILS. (See figure 4-23.)

(1) B-101 AUTOTUNE MOTOR. - The Autotune motor operates from the 28 volt direct current power source and is controlled by the limit switches, S-111 and S-112, and motor control relay, K-101.


(2) K-101 MOTOR CONTROL RELAY. - K-101 is energized through the contacts of the keying relay, K-102, the LOCAL-REMOTE switch, S-107, the channel selector switch, S-108, and the circuit seeking tap switch, S-109, to ground. The holding circuit for the relay is through contacts 5 and 6 of motor control relay K-101 and the contacts of front limit switch section, S-112. When operated, motor control relay K-101 disables keying relay K-102 and plate power relay K-1904 preparatory to the release of rear limit switch section S-111.

(3) K-102 KEYING RELAY. - K-102, when operated during periods of transmission, prevents false operation of the Autotune system. The energizing circuit is through the emission control circuits, that is the TEST switch, S-104, the Throttle Switch jack, J-101, the MICROPHONE jack, J-102, or the KEY jack, J-103.

(4) S-107 LOCAL-REMOTE SWITCH. - S-107 permits the selection of either the panel channel selecting circuit or the remote channel selecting circuit. This switch is located on the transmitter panel and is designed for manual operation only.

(5) S-108 CHANNEL SELECTING SWITCH. - S-108 permits the selection of any one of eleven Autotune frequency channels and "MANUAL" tuning of the transmitter. The selection of a new channel energizes motor control relay, K-101, by the circuit through CHANNEL selecting switch, S-108, and circuit seeking switch, S-109, to ground.

(6) S-109 CIRCUIT SEEKING TAP SWITCH. - S-109 is driven by the Autotune motor, B-101, through a worm and spur gear arrangement. The circuit seeking tap switch, S-109, completes the circuit necessary for the operation of the motor control relay, K-101. Of the twelve circuits connected to the circuit seeking tap switch, S-109, eleven are grounded at all times. The operation of



- | | | |
|----------------------------|---------------------------------------|-------------------------------------|
| B101 - AUTOTUNE MOTOR | R115 - MOTOR TORQUE RETAINER RESISTOR | S111 - REAR LIMIT SWITCH SECTION |
| K101 - MOTOR CONTROL RELAY | S107 - LOCAL-REMOTE SWITCH | S112 - FORWARD LIMIT SWITCH SECTION |
| K102 - KEYING RELAY | S108 - CHANNEL SELECTOR SWITCH | S113D - KEYING INTERLOCK SWITCH |
| K1904 - PLATE POWER RELAY | S109 - CIRCUIT SEEKING TAP SWITCH | S1905 - PANEL INTERLOCK SWITCH |

Figure 4-23 Collins Autotune System - Electrical Portion




Figure 4-24 Collins Autotune Operating Sequence

motor control relay, K-101, connects front limit switch section, S-112, in the circuit, preventing seeking switch, S-109, from finding the circuit selected by CHANNEL selecting switch, S-108, until after the limit switch operating arm reaches and operates front limit switch section, S-112.

(7) S-111 REAR LIMIT SWITCH SECTION. - S-111 is normally held in the position necessary to complete the circuit for the operation of keying relay, K-102, and plate power relay, K-1904. When released by the limit switch operating arm, contacts 2 and 3 of the rear limit switch section, S-111, short motor torque retainer resistor, R-115, out of the circuit preparatory to the release of motor control relay, K-101. The return of the limit switch operating arm to the original position opens contacts 2 and 3 of rear limit switch section, S-111, placing motor torque retainer resistor, R-115, again in the circuit, thereby stopping Autotune motor, B-101.

(8) S-112 FRONT LIMIT SWITCH SECTION. - The normally closed contacts of S-112 complete the holding circuit for motor control relay, K-101, through contacts 5 and 6 of K-101. When the front limit switch section, S-112, is operated by the switch operating arm, allowing circuit seeking tap switch, S-109, to find the circuit position selected by CHANNEL selecting switch, S-109, the operating circuit for motor control relay, K-101, is broken allowing K-101 to release. De-energizing motor control relay, K-101 reverses the direction of rotation of the Autotune motor, B-101.

(9) S-113D KEYING INTERLOCK SWITCH. - S-113D is operated by the "ANTENNA TUNING - COARSE", Control "C", and prevents the operation of the keying relay, K-102, between settings of Control "C".

c. AUTOTUNE OPERATION. - The Autotune system consists of one Multiturn unit and four Singleturn units (refer to figures 4-22, 5-7, 5-9) which are driven by a reversible motor through a line shaft. The Multiturn unit may be set up to select any dial setting in a continuous range of 7200 angular degrees (twenty turns or revolutions) of dial rotation.

NOTE

One revolution of the dial is equal to 360 angular degrees of rotation. The Singleturn units may be set up to select any dial setting from 0 to 360 degrees of rotation (a single turn or revolution). The drawings of the electrical and mechanical portions of the Autotune, figure 4-22 and figure 4-23, should be referred to in connection with the description of the following operational sequence. The drawings show the Autotune at the completion of the operation cycle

(1) The operator turns the CHANNEL selector switch, S-108, to the channel desired.

(2) This places a ground on the motor control relay, K-101, through the circuit seeking tap switch, S-109, the CHANNEL selector switch, S-108, the LOCAL-REMOTE switch, S-107, and the contacts of the keying relay, K-102. With the keying relay, K-102, in the normal or unenergized position, the motor control relay, K-101, will operate and energize the Autotune motor, B-101. The motor control relay, K-101, is then kept energized by the circuit through contacts 5 and 6 and the limit switch section, S-112. The operation of motor control relay, K-101, disables the keying relay, K-102.

(3) The motor, B-101, drives the line shaft (1) in a forward direction causing all the cam drums and stop-ring drums to rotate in a counterclockwise direction and the multiturn unit counter drum to rotate in a clockwise direction.

(4) The switch operating arm (33) moves out from the rear limit switch section, S-111, and moves toward the forward limit switch section, S-112. Contacts 1 and 2 of the rear limit switch section, S-111, open, keeping keying relay K-102 and plate power relay, K-1904, disabled when the motor control relay, K-101, opens. Contacts 2 and 3 of the rear limit switch section short motor torque resistor, R-115, out of the circuit preparatory to the release of motor control relay, K-101.

(5) The forward limit switch section, S-112, opens and the motor continues to run until the open segment of the circuit seeking tap switch, S-109, is positioned opposite the contact upon which the channel selector switch has been set by the operator.

(6) As the open segment of the circuit seeking tap switch, S-109, comes to the contact of the channel selected, the synchronized cam drums are at the position where the pawl heels (15A and 37A) of the channel selected have just dropped into their respective slots in the cam drums.

(7) Since the holding circuit has been removed, the motor control relay, K-101, opens, causing the polarity of the voltage on the armature to be reversed which reverses the direction of rotation of the motor.

(8) After the motor reverses, allowing the cam drums to fully engage their respective pawl heels, the switch operating arm moves toward the rear, allowing the forward limit switch section, S-112, to reclose.

(9) As the motor continues to run in the reverse direction, the stop-ring drum (12) of the singleturn unit rotates and when the slot on the stop ring of the channel selected is adjacent to pawl toe (15B) the pawl toe drops into the slot. The pawl toe stops the tuned element (7) at the predetermined position and the clutch slips until the Autotune cycle has been completed.

(10) The counter drum (28) of the multiturn unit reverses direction of rotation thereby rotating the anvil (19) out from under the pawl tail (37B) as the motor reverses, and when the slot of the cam on the counter drum, of the channel selected, is adjacent to the pawl tail (37B), the pawl tail drops into the slot and selects the revolution in which the tuned element (24) will be positioned.

(11) As soon as the slot in the proper stop ring of the stop-ring drum (36) is adjacent to the pawl toe (37C) the pawl toe drops into the slot. This stops the tuned element (24) at the preselected position and the clutch (23) slips until the Autotune cycle has been completed.

(12) As the motor continues in the reverse direction, the switch operating arm moves back against the rear limit switch section, S-111, opening contacts 2 and 3 of S-111.

(13) Contacts 2 and 3 of the rear limit switch section upon opening remove the short across the motor torque retainer resistor, R-115, which stops the motor by allowing just enough current to flow through the armature of motor B-101 to provide a position retaining torque to the Autotune units.

(14) The contacts 1 and 2 of the rear limit switch section, S-111, close, permitting the carrier to be turned on. The Autotune cycle is now complete. The carrier control circuits and Autotune control circuits are interlocked so that the Autotune can not operate when the carrier is on and the carrier cannot be turned on while the Autotune system is in operation.

13. UNIT FUNCTION.

a. The order of the Autotune units from left to right is as follows: "E", "C", "D", "A" and "B".

b. Proceeding in the order of unit function; the choice of oscillator, the high frequency oscillator range, the multiplier range and the Autotune seeking switch, S-109, are controlled by Autotune unit "A"; the high frequency oscillator tuning is controlled by Autotune unit "B"; the coarse selection of inductance and capacity in connection with a given antenna by Autotune unit "C"; the variometer, providing a fine control of inductance, serving as tuning resonator by Autotune unit "D"; and the large variable capacitor, providing a fine control of capacitance, serving as a loading control, by Autotune unit "E".

c. The high frequency oscillator, which is the unit at the extreme right of the transmitter is controlled by Autotune unit "B". The multiplier coil forms are mounted at the back of the casting. The slugs of multiplier coils are attached to the same shaft that controls the oscillator slug. Also mounted in the high frequency oscillator casting is the switch, actuated by a star cam in the adjacent multiplier chassis, which changes the frequency range of the high frequency oscillator.

d. The multiplier chassis, the operation of which is controlled by Autotune unit "A", contains the star cam mentioned above plus a cam operated multi-contact switch which controls the high and the low frequency oscillators. The wafer switch nearest the Autotune unit controls the range of the first multiplier stage, the wafer switch farthest from the Autotune unit controls the range of the second multiplier stage and the remaining cam operates a switch that closes the cathode circuit of the second multiplier stage at the proper time.

e. Autotune unit "D" controls the variometer.

f. The network switch, controlled by Autotune unit "C", varies the tap on the loading inductance and the capacity in the circuit. In the first position all of the inductance is in the circuit and in the seventh position this inductance is completely shorted out. Between ranges seven and eight switch S-113 operates to cut in the ceramic padding capacitor, various combinations of which are used from ranges eight to thirteen. In addition, a small inductance is connected across the variometer on range thirteen by the operation of one of the switch arms. A star cam on the same network switch shaft operates a switch, S-113D, that incapacitates the RF portion of the complete transmitter by preventing the operation of the keying relay, K-102, between the network switch settings.

g. Autotune unit "E" controls the setting of the large variable loading capacitor, plus the operation of a switch in the network switch assembly controlled by a cam attached to the variable capacitor rotor. This switch extends the range of the large variable loading capacitor by connecting three ceramic capacitors located in the network switch assembly as padders.

UNCLASSIFIED

... ..

... ..

... ..

... ..

... ..

... ..

SECTION V
MAINTENANCE

This radio equipment has been constructed of materials considered to be the best obtainable for the purpose and has been carefully inspected and adjusted at the factory to reduce maintenance to a minimum. However, a certain amount of checking and servicing is necessary to maintain efficient and dependable operation. The following procedures should aid in the checking and servicing of the equipment.

1. DAILY OPERATIONAL CHECK.

The operation of the transmitter should be checked daily or after any appreciable shut-down period. The following operational checks will indicate whether or not the transmitter is operating normally.

a. PROCEDURE.

(1) Turn the Power Supply on and after allowing the tubes sufficient time to warm up, rotate the EMISSION selector switch, S-110, to the CW position (applies 1150 volts DC plate potential) and operate the TEST switch, S-104, to the ON position.

(2) Check the PA PLATE meter reading.

(3) Release the TEST switch and operate S-110 to the VOICE position.

(4) Insert a microphone cord plug into the MICROPHONE jack, J-102, press the Push-to-Talk switch (applies 1150 volts plate potential) and while speaking into the microphone observe the PA PLATE meter needle "kick". Check the position of the microphone switch, S-201, to make certain that it is in the proper position for the type of microphone used.

(5) Check the keying on CW and MCW by listening to the output of the sidetone amplifier and to the keyed signal on an adjacent receiver.

(6) Check keying using LOCAL control and an external key. Also check keying with REMOTE control.

If the above checks indicate normal transmitter operation, no further tests will be necessary.

If transmitter operation does not appear to be normal, check the (1) position of the power level switch, S-106, (2) position of the EMISSION selector switch, S-110, (3) position of the LOCAL-REMOTE switch, S-107, (4) position of the metered circuit selector switch, S-105, (5) fuses, (6) power unit operation, (7) line voltage, (8) cable connector plugs, (9) antenna and ground connections, and (10) position of controls "A" and "B".

If the above checks fail to reveal the cause of erratic operation or transmitter failure, further trouble shooting will be necessary. The trouble shooting procedure together with the symptoms of and cures for some of the more common causes of erratic operation or transmitter failure is outlined in this section of this book under SERVICING.

2. ROUTINE CHECK.

To assure efficient and dependable service, periodic operational checks should be made. The inspection and check should be made at intervals of approximately one month or during the regular port inspection.

The following routine checks are recommended; others may suggest themselves to the maintenance personnel.

a. EQUIPMENT INSPECTION.

(1) Check all interconnecting wires. If necessary hand-tighten all plug locking rings. Inspect for broken and loose wires at the plugs.

(2) Check the connections to the receiver antenna, ground and loading coil, making certain that the spring connector terminals are making good contact with the wires.

(3) Remove the end bells from the dynamotors and, using compressed air, blow out all carbon and copper dust from the commutator and surrounding surfaces. Inspect the brushes for wear and replace them if the carbons are shorter than 1/4 inch.

(4) All relays should be carefully checked at regular intervals. Check the contacts for proper alignment, pitting and corrosion. Use a burnishing tool to clean the contacts - never use sandpaper or emery cloth.

b. OPERATIONAL CHECKS. - To check the operation of the Autotune system, proceed as follows:

(1) Place the power level switch, S-106, in the TUNE position and the EMISSION selector switch, S-110, in the VOICE position.

(2) Beginning with Channel 1 operate the CHANNEL selector switch, S-108, to each of the ten high-frequency channels. As each Autotune cycle is completed, check the positions of the controls against their original settings.

(3) Having checked the positioning of the ten high-frequency channels, operate CHANNEL selector switch, S-108, to the L. FREQ. position.

(4) When the Autotune cycle has been completed, Control "A" should come to rest in Position 13.

(5) After checking that the Autotune positions correctly for the eleven channel positions, operate S-108 to the MANUAL position.

(6) When the Autotune cycle has been completed, check the operation of all controls. Each control should move freely to permit transmitter tuning without

disturbing the positions of the Autotune stop rings.

NOTE

To check the operation of the power control, RF and audio circuits, proceed as follows:

(7) Operate the LOCAL-REMOTE switch, S-107, to the LOCAL position and the EMISSION selector switch, S-110, to the CW position. (Applies 1150 volts DC plate potential.)

(8) Rotate the metered circuit selector switch, S-105, to the PA PLATE position.

(9) Operate the TEST switch, S-104, to the ON position.

(10) Check the power amplifier plate reading on meter M-102. The meter should indicate current within the CW portion of the meter scale.

NOTE

If M-102 does not indicate a PA PLATE meter reading within the CW portion of the scale some adjustment of the output loading may be necessary. Before attempting to readjust the output circuit for proper loading for the particular channel upon which the transmitter is operating, check the operation on the other Autotune channels by operating the CHANNEL selector switch, S-108.

(11) If all meter readings are off in the same direction, that is, if all readings are too high or if all readings are too low, check the line voltage.

NOTE

If the line voltage is much higher or lower than the voltage was at the time that the tuning adjustments were made and the Autotune stop rings locked, the power amplifier plate meter reading will be somewhat different than the original reading. No adjustment of the output tuning controls should be attempted if the tuning adjustments were originally made with normal supply voltage.

(12) Release the TEST switch and insert a key cord plug into the KEY jack, J-103. Check the keying by operating the telegraph key and listening to the keyed signal in a receiver. The transmitter should key cleanly and without noticeable chirp at speeds up to thirty words per minute.

(13) Release the telegraph key and operate the EMISSION selector switch, S-110, to the MCW position. (Applies 1150 volts DC plate potential.)

(14) Operate the TEST switch, S-104, to the ON position.

(15) Check the PA PLATE meter reading on meter M-102. The meter should indicate within the MCW portion of the meter scale.

(16) Release the TEST switch and insert the earphones cord plug into the

SIDETONE jack, J-104.

(17) Insert the key cord plug into the KEY jack, J-103.

(18) With the earphones in position, operate the telegraph key and check the keying by listening first in the earphones and then in an adjacent receiver. The keying should be clean-cut and with little distortion of character at keying speeds up to thirty words per minute.

(19) Release the telegraph key and operate the EMISSION selector switch, S-110, to the VOICE position.

(20) Insert the microphone cord plug into the MICROPHONE jack, J-102.

(21) Press the Push-to-Talk button on the microphone (applies 1150 volts DC plate potential) and check the PA PLATE meter reading.

(22) Check the modulation by pressing the Push-to-Talk button on the microphone (applies 1150 volts DC plate potential) and speaking into the microphone at normal voice level and checking the swing of the needle of meter M-102. The needle should swing up to the MCW portion of the meter scale, or slightly beyond, on voice peaks.

(23) Check the operation of the speech amplifier by listening to the side-tone amplifier output while having someone speak into the microphone

NOTE

When operation from the LOCAL position has been checked, the procedure outlined below should be followed to check remote operation:

(24) Operate the LOCAL-REMOTE switch, S-107, to the REMOTE position.

(25) Operate the EMISSION selector switch, S-903, in the type COL-23410 Remote Control Unit, to the VOICE position.

(26) Following the procedure outlined for checking the Autotune system from the transmitter panel, check the operation and positioning of the dials when using the CHANNEL selector switch, S-902. The position of the controls for a given Autotune channel selected with S-902 should correspond to the position of the controls when the Autotune channel is selected with the panel switch, S-108.

(27) Insert a microphone cord plug into microphone jack J-903 and check the transmitter control by operating the Push-to-Talk button on the microphone (applies 1150 volts DC plate potential). Also check the condition of the audio lines from the Control Unit to the transmitter by speaking into the microphone and checking the kick of the needle of meter M-102. Voice peak readings should correspond to readings obtained when checking the modulation with panel or LOCAL transmitter control.

(28) Operate S-903 to the CW position (applies 1150 volts DC plate potential) and operate the key. Check the keying by listening to the signal on a receiver.

(29) Operate S-903 to the MCW position (applies 1150 volts DC plate potential) and check PA PLATE by observing M-102. Check the keying by listening to the keyed signal on a receiver.

3. SERVICING.

a. GENERAL. - If the above checks reveal erratic or abnormal operation, the tubes should be carefully checked. Tube failure is probably the most common cause of transmitter failure. The most dependable method of checking the tubes and finding the defective tube is to replace the tubes one at a time, with tubes known to be in good condition.

In case of trouble, look for simple causes first. Analyze and isolate the difficulty before attempting to remove or dismantle any part of the equipment.

A few moments of thought and study of the complete schematic circuit diagram, figure 7-45, together with a tabulation of the various possible causes of failure, may save hours of haphazard labor.

Radio equipments are often damaged by needless disassembly and removal of parts, when the real cause of trouble is merely a broken lead or a faulty connection.

In order to gain access to the tubes and other components the transmitter cover must be removed. This can be done by inserting a coin or a screwdriver in the holddown screw, making a half turn counterclockwise and lifting off the cover.

b. VACUUM TUBE REPLACEMENT. - After having made certain that the KEY, MICROPHONE and Throttle Switch circuits are open remove the transmitter cabinet cover.

CAUTION

In the interest of safety, and to protect other filaments and filament resistors that may be in the circuit, the equipment should be completely turned off when tubes are being replaced.

(1) The tube clamps used in this equipment are designed to prevent the tube from coming out of the socket under vibration incident to normal service. Refer to the tube placement diagram, figure 2-2, for the exact location of the various tube clamps. The clamp on tube V-101 is readily accessible through the side cover plate. The clamps on V-105 and V-106 are accessible through the rear cover plate. The clamps on V-102 and V-103 can best be reached from the top of the transmitter.

(2) To open or close a clamp in removing or replacing tubes insert a screw driver as shown in the lower left corner illustration of figure 2-2. Gently press the clamp open or closed as required. No undue exertion is necessary in operating this type of clamp. Removal of 813 power amplifier tube, V-104, is facilitated by inserting a screwdriver through a ventilating hole in the rear cover plate so that the screwdriver may be used as a lever between the tube base and the socket.

(3) The 813 tube should be inserted by orienting the base pin with the slot in hole above the socket and pressing down firmly until the tube snaps solidly in the socket.

(4) Study the tube-heater circuits (see figure 4-10) to become familiar with the series-parallel arrangement used. This is important to prevent the needless replacement of tubes.

(5) In most instances, an open filament in a tube will break the filament circuit of another tube. An open filament circuit in the low frequency oscillator will cause an abnormally low voltage on the high frequency oscillator tube, V-101. Occasionally, the metal tubes contain foreign matter which may be "weld-flash" loosened under prolonged vibration. This causes inter-electrode short circuits which are sometimes difficult to find because of their temporary nature.

(6) The RF ammeter, M-101, is calibrated on 2000 kc at the factory using a "dummy" antenna load comprising 10 ohms and 100 micromicrofarads (mmf). The calibration will hold approximately throughout the range of the transmitter. However, since the reading of this meter is dependent upon the impedance of the antenna being used and the operating frequency, the reading will be high when the antenna presents a low impedance and low when the antenna presents a high impedance.

c. VACUUM TUBE FAILURE SYMPTOMS. - Some of the more common symptoms of tube failure together with the tubes that may need replacement are given in the paragraphs that follow:

(1) NO RF OUTPUT IN THE FREQUENCY RANGE 2.0 mc TO 6.0 mc. - Three RF tubes are in use when the transmitter is operating in the frequency range 2.0 mc to 6.0 mc, namely V-101, V-102, and V-104. To find the particular tube that is defective replace each tube with another tube of the same type that is known to be in good condition, that is, replace one tube at a time. After each tube replacement check transmitter operation. If, after having replaced all three tubes the transmitter is still inoperative or low in output, further trouble shooting will be necessary.

(2) NO RF OUTPUT IN THE FREQUENCY RANGE 6.0 mc TO 18.1 mc. - When operating in the frequency range 6.0 mc to 18.1 mc a fourth RF tube, V-103, is brought into operation. If after having found satisfactory transmitter operation in the frequency range 2.0 mc to 6.0 mc, the output is discovered to be low or nil in the frequency range 6.0 mc to 18.1 mc, the trouble is likely in the 2nd multiplier stage. Replace the type 1625 tube, V-103, with a tube of the same type known to be in good condition and check the operation. If the transmitter is still inoperative or the output low, the trouble is something other than a defective tube.

(3) NO RF OUTPUT L. FREQ. CHANNEL (200 kc TO 1500 kc). - When the transmitter is operating in the low frequency range only two RF tubes are used, the LF oscillator tube, V-401, and the PA tube, V-104. If output in the frequency range 2.0 mc to 18.1 mc is satisfactory but no output is obtained when the low frequency channel is selected, the trouble is probably in the low frequency oscillator stage. Replace V-401 with a tube of the same type known to be in good condition and check transmitter operation. If the stage is still inoperative further tests will be necessary.

(4) SATISFACTORY VOICE OPERATION - NO MODULATION ON MCW. - The same audio amplifier and modulator stages are employed for both VOICE and MCW operation, therefore, if no modulation is obtained on MCW, the MCW Oscillator tube, V-2203, must be inoperative. Replace V-2203 and while listening to the output of the sidetone amplifier or to the signal in a receiver, operate the TEST key and check the modulation. If the signal is still unmodulated it will be necessary to check the oscillator circuit.

(5) SATISFACTORY RF OUTPUT AND SIDETONE AMPLIFIER OUTPUT - NO MODULATION ON EITHER VOICE OR MCW. - The output of the audio driver tube, V-202, is coupled to the input of the sidetone amplifier. Therefore, satisfactory output from the sidetone amplifier indicates that the audio amplifier and audio driver stages are operating satisfactorily. The output of the audio driver is also coupled through a transformer to the grids of the modulator tubes, V-105 and V-106. Replace the modulator tubes with tubes known to be in good condition, one at a time, and check the transmitter output for modulation. If the RF signal is still unmodulated the trouble is other than defective tubes and further trouble shooting will be necessary.

(6) SATISFACTORY RF OUTPUT - NO MODULATION VOICE OR MCW - NO OUTPUT FROM SIDETONE AMPLIFIER. - There being no output from the sidetone amplifier, it is evident that one or more of the following three stages is inoperative, audio amplifier, V-201, audio driver, V-202, or the sidetone amplifier, V-203. Replace V-201, V-202, and V-203 with a tube of the proper type that is known to be in good condition, one at a time, and while listening to the SIDETONE output, operate the TEST switch after each tube is replaced.

(7) SATISFACTORY RF OUTPUT - SATISFACTORY VOICE AND MCW OPERATION WHEN OPERATING IN CALIBRATE POSITION NO BEAT NOTE OBTAINABLE BETWEEN RF OSCILLATOR OUTPUT AND CALIBRATION OSCILLATOR OUTPUT. - Satisfactory VOICE and MCW operation indicates that the RF, audio and MCW oscillator stages are operating properly, therefore, the trouble must be in the calibration oscillator circuit. Remove calibration oscillator tubes, V-2201, V-2202, V-2203, and crystal, Y-2201, one at a time, and replace with others known to be in good condition. If it is still impossible to obtain a beat note between the two signals, the trouble is still likely in the calibration oscillator circuit but is something other than a defective tube.

(8) LOW RF OUTPUT. - If the grid meter reading is satisfactory and the transmitter is otherwise apparently operating satisfactorily, note the extent to which the PA PLATE meter reading soars off resonance with power level switch, S-106, in the OPERATE position. Failure of the PA PLATE meter reading to soar more than 10% usually indicates low emission of the 813 final amplifier tube, V-104. Normal off resonance PA PLATE meter reading will be found to be about 200. If it appears that the off resonance reading is considerably more than 200 the 813 tube will usually be found to be "soft" or "gassy".

(9) HIGH DISTORTION ON VOICE. - Replace the 813 tube if after checking the speech amplifier tubes, the unit itself and the modulator tubes, V-105 and V-106, high distortion exists at full modulation. Since both the screen and the plate of the tube have separate modulation transformer windings it is possible for a condition to exist where the proportion of current drawn by the 813 screen and plate is not normal. This condition can cause a mismatch to

occur in the modulation transformer at high audio levels.

d. TROUBLE SHOOTING. - If replacing vacuum tubes has failed to remedy the trouble and the transmitter is still inoperative or not operating properly, further trouble shooting will be necessary.

A few tools and an indicating instrument are absolutely essential. In addition to the tools ordinarily available (screwdriver, pliers, soldering iron, etc.) a volt-ohmmeter capable of measuring DC voltages up to 1500 volts is necessary. Any voltmeter having high internal resistance (1000 ohms or more per volt) will suffice but a meter of the vacuum tube type is recommended. High voltage circuits should not be checked with a voltmeter unless other means cannot be used. This practice is advocated in the interest of safety.

The following table of typical servicing problems should prove useful in locating common sources of trouble:

(1) TYPICAL SERVICING PROBLEMS OTHER THAN THOSE COMMONLY CAUSED BY VACUUM TUBE, CAPACITOR OR RESISTOR FAILURES.

SYMPTOM	PROBABLE CAUSE
28 volt short	Autotune cover touching a lug on Autotune limit switch section S-111. Autotune limit switch contact arms touching multiturn unit. Terminals of motor control relay K-101 shorted due to cable pressure against relay. Autotune motor B-101 defective. Lug on R-116 touching chassis. Lug on keying interlock switch S-113D touching chassis.
Fuse F-1907 blown.	400 volt short.
400 volt short in Multiplier Unit.	Cable wire caught on an arm of range switch S-103. Cable shield touching lug of C-115. L-105 slug shorting on pin of L-105 internally. L-106 slug shorting on pin of L-106 internally. S-101 cam follower arm not centered on star cam resulting in the arm contacting a mounting screw of a contact spring of range switch S-102.
400 volt short not in multiplier	Ground bus on X-104 socket touching 813 tube V-104 series screen resistor R-112 tie point. Lug on R-113 touching chassis. Lug on R-105 touching chassis. Short in connections to J-111 Wires pinched underneath Modulation transformer, T-101.

High voltage short.	Center grounding lead of CW relay K-103 touching contact springs.
No output from High Frequency Oscillator.	Improper contact on oscillator selecting switch, S-114. Improper contact on keying relay, K-102.
Absence of beat notes at sidetone output.	Cable connections on J-111 broken or shorted. Cable connections on J-114 broken or shorted.
No output from first multiplier stage.	First multiplier plate choke, L-115 open. Incorrect adjustment of, or foreign matter on, the contacts of range switch, S-102. A section of padding capacitor, C-111, open or shorted. A broken slug or a shorted or open turn on inductor L-105. Improper contact on oscillator selecting switch, S-114. Control grid or screen suppressor resistors R-103 or R-104 grounded. Dial "A" out of alignment with shaft.
No output from second multiplier stage.	Improper contact on second multiplier cathode switch S-115. Incorrect adjustment of, or foreign matter on, the contacts of range switches, S-102 and/or S-103. A section of padding capacitor C-115 open or shorted. A broken slug or a shorted or open turn on inductor L-106. Control grid or screen suppressor resistors R-106 or R-108 grounded. Dial "A" out of alignment with shaft.
Insufficient or absence of grid current reading on meter M-102.	813 tube V-104 not in the socket properly. 813 tube filament not at full brilliance due to open shunt resistor R-123 or defective filament. Multiplier padding capacitors C-111 and C-115 in need of readjustment due to excessive vibration, humidity or corrosion. Grid choke L-107 open or turns shorted. Defective contact on meter circuit selector switch S-105.
Erratic operation or frequency instability of High Frequency Oscillator.	Incorrect adjustment of oscillator range switch S-101 cam follower. Dial "A" out of alignment with shaft.

Section V
 Paragraphs 3

RESTRICTED

813 tube draws plate current with key up.
 Erratic multiplier operation. Inability to adjust unit properly.
 Erratic final amplifier operation. Inability to resonate amplifier properly.

Loose nut on oscillator lead screw at multiplier slug cross-bar (will necessitate recalibration of oscillator).
 Multiturn unit loose on casting.
 Backlash in lead screw bushing.
 Capacity change of capacitors C-101, C-102, C-103, C-104, or C-105.

Erratic multiplier operation. Inability to adjust unit properly.

Leads connecting multiplier padding capacitors C-111 and C-115 touching each other.

Erratic final amplifier operation. Inability to resonate amplifier properly.

Turns shorting on inductance L-113 (aggravated at operating temperatures).
 Failure of S-113 network switches to make contact due to foreign matter on contacts or binding of switch arm shafts.
 Mechanism for the operation of S-113A (operated by Dial "F") out of adjustment.
 Improper adjustment of vacuum contact S-116.
 Improper contact adjustment of output circuit selecting relay K-105.
 Static drain choke L-110 or choke L-116 open (changes tuning characteristics).
 Misplaced bus wiring in network switch causing shorts or arcing.
 Open thermocouple in antenna ammeter.
 Poor contact of rotor contacts of variometer L-112.
 Dial "C" out of alignment with shaft.
 Wrong antenna or incorrect use of antenna shunt capacitor.

813 tube draws plate current with key up.

Cathodes of exciter stages grounded regardless of the operation of keying relay K-102.
 813 tube V-104 screen contact on keying relay K-102 not grounding the screen when the key is up.

Spurious RF and AF oscillations.

813 tube V-104 beam forming plates not grounded causing self oscillation of the tube.
 Shield of first audio amplifier tube V-201 not grounded.
 Defective audio amplifier unit.
 Shield on wires to voice relay K-104 or J-112 disconnected.

	Defective contact on power level switch S-106. Open capacitor C-209 or C-210.
Abnormal or no modulation	Defective contact on microphone jack J-102. Microphone selecting switch S-201 in wrong position for type of microphone being used. Defective contact jacks in J-112 (a jack pushed up in the housing). Open, shorted or partially shorted winding on modulation transformer T-101. CW relay contact arm in contact with a lug of capacitor C-120A. Lead of R-134 grounded on the frame of power level switch S-106.
Abnormal or no modulation only on MCW	Lead of R-135 grounded on the frame of power level switch S-106. Voice relay K-104 not making contact. Broken wire on J-111 or J-112. Shield on wires to voice relay K-104 touching contact arm terminals of K-104.
Keying relay K-102 energized when key is up.	Shield on wires to voice relay K-104 touching contact arm terminals of this relay.
Sidetone output low or absent entirely. Volume increased by turning sidetone output control S-202 counterclockwise.	A ground in the sidetone circuit (especially in remote control cabling or connections).
Sidetone pitch varied by adjustment of sidetone output control S-202.	Remote connections 23, 24 and 25 shorted in either position of keying relay K-102 (key up or down).
Abnormal operation of output circuit selecting relay K-105.	Faulty operation, or shorting terminals on oscillator selecting switch S-114.
Autotune hesitates at moment of reversal accompanied by clicking of keying relay K-102.	Improper contact or shorting terminals on limit switch section S-111.
Unusual clicking noise during Autotune operation.	Probably a stiffened joint in chain drive.
An Autotune Unit locks when the Autotune system is in the MANUAL position.	Unit is probably out of synchronization.
Autotune channel is selected, but motor does not start.	Foreign matter on contacts of motor control relay K-101.

Autotune system will not reverse.

Improper contact on limit switch section S-112, CHANNEL selector switch S-108 or Seeking switch S-109.

An Autotune unit will not reposition.

Broken pawl spring.
Foreign matter in the Autotune system.
Anvil inoperative (on multiturn unit).

Erratic channeling of Autotune system.

Probably an intermittent contact on the circuit from CHANNEL selector switch S-108 to J-106 seeking switch S-109.

NOTES

Look for open, shorted or partially shorted chokes and other inductances.

Inspect capacitors for shorts, intermittent shorts or opens.

Inspect resistors for opens or wrong values.

Look for faulty connections or pieces of solder or wire which might cause short circuits.

If the foregoing tests do not reveal the source of trouble, refer to the table of voltages and resistances in this Section of this book.

(2) REMOTE CONTROL UNIT. - To gain access to the components in the Remote Control Unit, remove the mounting plate by removing the four thumb-nuts from the front panel. The contacts on the ganged switch sections may require cleaning or, if the unit has been exposed to an extreme shock, the switch pies may require replacement.

(3) ANTENNA LOADING COIL. - The Antenna Loading Coil should require very little maintenance but components such as switches, capacitors and inductors may require adjustment or replacement if the equipment has been subject to overload or extreme mechanical shock.

To gain access to the components in the Antenna Loading Coil remove the two sides and the top. The bottom and back are permanently attached. The top and sides are removed as a unit by taking out all the screws that are observed on their surface. The switch contacts may require attention due to corrosion. Plug connectors should also be inspected for corrosion and dirt. Capacitors may become shorted or open. The static drain choke may become open. These components can be checked with standard test instruments through the openings at the sides and top.

(4) POWER UNIT

(a) GENERAL. - The circuits and components employed in the power unit are straightforward and can be serviced by ordinary means and methods. Access to most components can be had by removing the two side plates. All screws observed on the two side plates should be removed and the side plates set aside. If necessary, the back plate can be removed also. Refer to the illustration.

section of this book to become familiar with the parts locations. Check the operation of switches, relays and interlocks. Check all connections including plug connectors and receptacles for effects of corrosion and for loose contact springs.

(b) DYNAMOTORS. - Low filament or relay voltage may be due to a dirty commutator, worn brushes in the low voltage dynamotor or an accumulation of copper dust between some of the commutator bars. Low plate voltage may be due to the same conditions in the high voltage dynamotor. To remove the copper dust use a stream of compressed air. Replace the brushes when they have reached a length of one quarter inch or less. Examine the mica between the commutator segments. If the mica is even with the surface of the commutator, it is likely that arcing and fouling of the commutator surface will occur. No amount of polishing the commutator surface or replacing brushes will cure this condition. The armature must be removed from the dynamotor and the mica undercut. This would be a good time to true up the commutator with a cutting tool. Some common faults of dynamotors are as follows:

1. SPARKING AT THE BRUSHES.

- a. Rough or dirty commutator surface.
- b. Poor brush fit.
- c. Incorrect brush pressure.
- d. Overload on the machine.
- e. Short-circuited armature coil.
- f. Open-circuited armature coil.

2. DYNAMOTOR FAILING TO START.

- a. No voltage on the line.
- b. Fuses out.
- c. Failure of relays to operate.

To clean a dirty commutator use a silken rag that has been dipped in kerosene and thoroughly wrung out. If the commutator is rough or pitted it may be smoothed up by moving a block of wood covered with fine sandpaper (do not use emery cloth or paper) back and forth axially by hand over the surface. After this operation the commutator should be blown out with air and wiped clean with a rag. If the spaces between the commutator bars become clogged with carbon, the remedy is to clean out the spaces with an old hack saw blade taking care not to scratch the commutator surface.

WARNING

The terminal board at the bottom of the power unit carries in excess of 1100 volts DC. If possible, remove the dynamotors from the cabinet for servicing.

Each dynamotor is mounted on a chassis which slides out of the front of the cabinet. Rotate the two thumb-nuts in a counterclockwise direction as far as they will go and then pull the dynamotor forward out of the cabinet.

(c) RELAYS. - Relay failures have become one of the most common sources of equipment trouble. Reports indicate that many of these failures occur as a result of the rough handling of relays or the improper treatment of contacts.

A Relay is a delicate piece of equipment and its adjustments are usually made with great precision. Handle it as you would an expensive watch or a fine meter.

When it is necessary to clean and readjust relays, do it carefully. To clean flat surface contacts, use only a crocus cloth or a burnishing tool. Make sure all pits and burns are removed from contact points and that contact surfaces are parallel. Extreme care must be exercised when cleaning telephone type relays. Abrasives will flatten the points and lead to further trouble. Use only a crocus cloth and apply this gently. On both telephone type relays and flat surface contact relays be sure that the contact arms have not been bent or their movements jammed in any way.

If new adjustments are to be made, make them carefully and correctly. Check and recheck until spacings are exactly what they are supposed to be. After the relay has been in operation again for a short time, check the spacings once more and readjust if necessary.

Some extra care will go a long way towards eliminating this frequent source of trouble.

Failure of the power unit to deliver power might be traced directly to the relays employed.

(5) TRANSMITTER UNIT. - Three of the sub-units in the Navy Type -52286-A Transmitter Unit, the LF unit, the MCW-CFI Unit and the Audio Amplifier Unit, may be readily removed for checking and the replacement of parts. The three units have been equipped with multi-terminal connector plugs to permit the removal of the sub-units from the transmitter without the use of a soldering iron. The following procedure is recommended for the removal of the above named units:

(a) LF OSCILLATOR UNIT.

1. Remove the connector wire from the right-hand side of the unit.
2. Remove the seven screws that hold the low-frequency panel in place.
3. Loosen all screws along the top edge of the Autotune front cover plate.
4. Remove the plate lead from the 813 power amplifier tube, V-104, and remove the tube from the socket by inserting a screwdriver through a ventilating hole in the back of the transmitter, using it as a lever between the tube base and the socket. Lift the tube out.

5. Insert a screwdriver through the ventilating holes at the back of the transmitter and remove the screws that hold the back of the unit.

6. The unit is now free of all retaining screws and wires and may be removed from the transmitter by raising the rear edge of the oscillator unit to free the front panel from the Autotune cover plate and then raising the unit until the connector plug is free.

(b) MCW-CFI UNIT.

1. Loosen the two large screws that hold the unit to the main transmitter chassis.

2. Raise the unit until the connector plug is disengaged.

3. Tip the unit toward the frequency multiplier tubes, V-102 and V-103, until the transformer clears the cabinet cover clamping bracket.

4. Remove the screws holding the sides of the MCW-CFI Unit chassis and pull the sides out as far as the connecting wires will permit.

5. All circuit components are accessible from the bottom of the unit.

(c) AUDIO AMPLIFIER UNIT.

1. Loosen the two large screws that hold the unit to the main transmitter chassis.

2. Remove the plate cap from the high-frequency oscillator, V-101, and remove the tube from the socket.

3. Raise the unit until the multi-terminal plug becomes disengaged from the receptacle.

4. Slide the unit backward until the cabinet studs are cleared and raise the audio amplifier unit upward.

(d) HIGH-FREQUENCY OSCILLATOR. - The frequency multiplier plate tank inductors are readily accessible if the cabinet wrap-around plate is removed from the right-hand end of the transmitter cabinet. Four screws in the rear and ten screws on the side hold the plate in position. An additional shield covers the section of the casting that houses the high-frequency oscillator circuit components. If this inner shield is removed all oscillator circuit components will be exposed and available for checking and replacement.

NOTICE

Removal of this inner shield will necessitate oscillator recalibration.

Do not remove this inner shield or make any adjustments of the HF oscillator condensers or slug unless the calibration of this oscillator is thoroughly understood.

(e) FREQUENCY MULTIPLIER. - Some of the frequency multiplier circuit

components are accessible from the bottom of the transmitter when the bottom cover plate is removed. To gain access to the remaining frequency multiplier circuit components, the multiplier unit must be removed from the assembly. The following procedure is recommended for the removal of the multiplier unit from the transmitter:

1. Remove the plate caps from the frequency multiplier tubes, V-102 and V-103, unlock the tube base clamps and remove the tubes from the sockets. Disconnect the low-frequency oscillator plate lead at the oscillator end.
2. Remove the transmitter bottom cover plate and the Autotune cover plate.
3. Remove Autotune Unit "A" in the following manner: Turn the dial locking bar to the unlocked position and loosen the two #10 Bristo set screws in the dial. Turn the dial and locking bar counterclockwise together until the bar comes free. Remove both the dial and the locking bar. Remove the dial back plate, loosen the two long screws on the top end of the unit and the short screw on the bottom end of the unit. Carefully lift the unit out.

CAUTION

Care must be exercised not to move any of the Autotune mechanisms from the time the unit is loosened until the unit is again securely in place, otherwise the unit may be thrown out of synchronization.

4. When the Autotune Singleturn Unit has been removed, remove the screws holding the seeking switch, S-109, to the Autotune casting and swing the switch out.
5. Unsolder and remove the wires leading to the multiplier coils at the rear of the high-frequency oscillator unit. Unsolder and remove the bus wire connected to coupling capacitor C-116.
6. The cam follower arm of high-frequency oscillator range switch S-101 must be removed from the oscillator casting if the multiplier unit is removed. Two Phillips head screws hold this arm on the oscillator casting. Removal of these screws will allow the arm to drop away from the star cam upon which it operates, after which it can be removed from the transmitter.
7. Remove the two screws just behind the second multiplier tube clamp shell and the two screws just in front of the first multiplier tube clamp shell.
8. The multiplier unit can now be pulled out sufficiently to remove the nut holding the ground wire lug on the side of the unit adjacent to the fire wall assembly. Remove cable connector J-115 from P-101 in the multiplier unit.

9. The multiplier unit may now be lifted out of the transmitter.

10. In reassembling the transmitter it is essential that the shaft of seeking switch S-109 be carefully centered with the cam drum shaft that drives it. This may be checked by referring to Paragraph V-7d except that the position of the switch and not the driving arm should be adjusted.

11. In replacing the cam follower arm of high-frequency oscillator range switch S-101, care must be exercised to make certain the end of the arm is centered in the hole provided in the contact arm of the switch. The cam follower arm mounting screws may then be inserted, but not tightened. Because of the fine thread in the aluminum casting, care must be exercised not to cross-thread these screws. The arm should then be centered on the star cam mounted on the multiplier switch shaft and the arm mounting screws tightened just enough to hold the arm in place.

12. In order to time the operation of oscillator range switch S-101, the following procedure should be followed:

a. Remove the warning plate covering the adjustment holes for C-134 and C-135. (Figure 5-3.)

b. Connect a continuity indicator from the shaft of C-135 (nearest the multiturn unit) to the oscillator casting.

c. Adjust the cam follower until switch S-101 indicates continuity on the odd numbered contacts of multiplier range switches S-102 and S-103 (check with Dial "A"). This should be done in such a manner that continuity is maintained during the fraction of a revolution necessary for the contact arms of multiplier range switches S-102 and S-103 to travel completely across the flat portion of every odd numbered contact, but not to extend more than the dividing line between the even and the odd numbered contacts.

d. Tighten the cam follower arm mounting screws securely enough to hold the arm in permanent adjustment.

e. If the above conditions cannot be met, the multiplier mounting screws should be loosened and the multiplier moved enough to make the adjustment outlined possible. Retighten the multiplier mounting screws.

NOTE

Care should be exercised to replace the dial exactly as it was before disassembly. Range No. 1 on the dial should correspond exactly with the centering of the contact arms of range switches S-102 and S-103 on contact 1. In addition, the dial must clear the dial back plate throughout the rotation range of Control "A".

(f) OSCILLATOR CASTING. - The following procedure is recommended for the removal of the oscillator casting from the transmitter:

NOTICE

The removal of the high-frequency oscillator is not recommended unless it is absolutely necessary.

1. Remove the plate cap from the high-frequency oscillator tube, V-101, unlock the tube base clamp and remove the tube from the socket.

2. Remove the MCW-CFI and the Audio Amplifier Units as outlined in the preceding section.

3. Remove the two screws that hold J-111, the MCW-CFI Unit Connector plug receptacle, to the standoffs and unsolder the single wire that connects the high-frequency oscillator tube V-101 cathode to terminal 1 on J-111.

4. Remove the Autotune cover plate and wrap-around section of the transmitter cabinet.

5. Remove the locking bar and dial from Control "A" by turning the dial locking bar to the unlocked position, loosening the two number 10 Bristo set screws in the dial, and turning both locking bar and dial counterclockwise until free. Remove the dial back plate.

6. The Autotune Singleturn Unit adjacent to the high-frequency oscillator Multiturn Unit must be removed so that the screws holding the oscillator casting to the Autotune casting may be loosened. To remove this unit loosen the short screw that holds the lower edge of the unit to the Autotune casting and the two long screws that hold the upper edge of the unit to the casting and lift the unit carefully out of position.

CAUTION

Care must be exercised not to move any of the Autotune mechanisms from the time the unit is loosened until the unit is again securely in place, otherwise the unit may be thrown out of synchronization.

7. When the Autotune Singleturn Unit has been removed, loosen the screws that hold the castings together in the front and top of the chassis.

8. To complete disconnecting the HF oscillator, move the casting slightly to the right and unsolder the connections to the terminal strip on the inner side of the casting and the wires leading to the frequency multiplier plate tank inductors.

9. The HF oscillator casting assembly may now be removed from the transmitter.

CAUTION

Care must be exercised not to damage the cam follower arm of S-101. This arm is attached to the left side of the oscillator casting.

NOTE

All components not included in units that may not be removed from the main assembly of the transmitter have been mounted in positions so as to be as accessible as possible in the limited space available. The cabinet cover, bottom plate and Autotune cover plate are all removable from the main assembly. The location of the part to be checked or replaced will determine the section of the cabinet that is to be removed.

4. RADIO-FREQUENCY CIRCUIT ALIGNMENT.

a. LOW-FREQUENCY OSCILLATOR ALIGNMENT.

(1) If low-frequency oscillator circuit components have been damaged or replaced, the grid circuit may require realignment. For realignment of the circuit the following procedure should be followed:

(a) Operate Control "F" to Position 6 (1035 kc to 1500 kc).

(b) Rotate the CHANNEL selector switch, S-108, to the L.-FREQ. position.

(c) Operate the EMISSION selector switch, S-110, to the VOICE position.

(d) When the Autotune cycle has been completed check the position of Control "A".

The control should stop in Position 13. If the control stops in any position other than number 13, loosen the locking bar and manually operate Control "A" to Position 13.

(e) Refer to Table 3-1 in Section III of this book and select a dial setting under column G that is near the middle of the tuning range. If there is a dial setting listed on each side of the midpoint of the tuning range, select the dial setting on the high-frequency side.

For example 1079 in the column under G is very near the midpoint of the tuning range of the control. (The exact midpoint is 1000.)

(f) Rotate Control "G" to the dial setting that has been chosen from the calibration table.

(g) Operate the power level switch, S-106, to the CALIBRATE position. (Applies 1150 volts DC to plates of V-104, V-105, and V-106.)

(h) Insert an earphones cord plug into the SIDETONE output jack, J-104.

(i) While listening to the SIDETONE amplifier output, rotate Control "G" about the setting obtained from the calibration table until exact zero beats is obtained between the output of the low-frequency oscillator and the output of the calibration oscillator.

(j) Check the dial setting and lock the dial.

(k) Loosen the two set screws that hold the knob to the shaft of Control "G" and without detuning the circuit, rotate the knob on the shaft until the dial setting corresponds to the setting given in the calibration table and tighten the set screws.

(l) Rotate Control "G" to home stop position near zero. Loosen the two set screws on the counter dial mechanism collar attached to the main oscillator shaft and holding the mechanism at zero, rotate Control "G" to zero. Tighten the set screws.

(m) Operate Control "F" to Position 5.

(n) As explained in steps (e) and (f), select a dial setting from Table 3-1 near the middle of the tuning range.

(o) Note the numbered slots on the oscillator shield cover exposing the trimming capacitor, C-411. Also refer to figure 5-1.

(p) While listening to the SIDETONE output, adjust capacitor section E (5) of C-411 with any narrow tool until zero beat is obtained between the low-frequency oscillator output and the output of the calibration oscillator.

(q) Operate Control "F" to Position 4 and repeat steps (n) and (p) adjusting section D (4) of C-411 instead of section E.

(r) Repeat steps (n) and (p) adjusting capacitor trimmer sections C (3), B (2) and A (1), for Control "F" Positions 3, 2 and 1, respectively.

(s) Check the excitation over the entire range of each position of Control "F" by rotating Control "G" through twenty revolutions for each position of Control "F".

b. HIGH-FREQUENCY OSCILLATOR ALIGNMENT USING CFI.

(1) If the high-frequency RF circuits are to be realigned in the field, where no frequency measuring equipment is available, the calibration oscillator may be used to check the band end-point frequencies. However, if coils, transformer cores, capacitors, etc., in the oscillator circuit require replacement, an accurate means of measuring frequency must be used together with a portable frequency meter to check the harmonic output of the frequency multiplier.

(2) For realignment when a frequency standard is not available, the following procedure should be followed:

(a) With the EMISSION selector switch, S-110, in the OFF position, remove the cover plate from the right-hand end of the transmitter cabinet. Remove the small plate on the bottom of the oscillator casting. This plate covers the holes provided for the adjustment of trimmer capacitors C-134 and C-135. The HF oscillator grid trimmer capacitors, C-134 and C-135, the HF oscillator grid inductor, L-101, tuning slug adjustment and the frequency multiplier plate inductor, L-105 and L-106, tuning slug adjustments are thus exposed.

(b) Rotate the CHANNEL selector switch, S-108, to the MANUAL position.

(c) Operate the EMISSION selector switch, S-110 to the VOICE position.

(d) When the Autotune cycle has been completed, operate Control "A" to Position 2.

(e) Set the indicator mark, over Control "B", to mid-scale using the CORRECTOR knob.

(f) Refer to Table 3-2 in Section III of this book and obtain the dial setting of Control "B" for output on 2400 kc with Control "A" in position 2.




Figure 5-1 Low Frequency Oscillator





Figure 5-2 Low Frequency Oscillator Adjustment



ADJUSTMENT WARNING PLATE

Figure 5-3 High Frequency Oscillator




Figure 5-4 High Frequency Oscillator Adjustment

(Oscillator output on 1200 kc.)

(g) Rotate Control "B" to the setting obtained from the table. Approach the setting in a clockwise direction.

(h) Loosen the nut on the rear of the lead screw that holds the multiplier tuning slug yoke to the screw.

(i) Insert an earphones cord plug into the SIDETONE output jack, J-104.

(j) Operate the power level switch, S-106, to the CALIBRATE position. (Applies 1150 volts DC to plate of V-104.)

(k) While listening to the SIDETONE output in the earphones, and keeping Control "B" set at the position obtained from the table, adjust the position of the HF oscillator grid inductor tuning slug by rotating the tuning slug screw with pliers, the jaws of which are padded to prevent marring the shaft, until zero beat is obtained between the output of the calibration oscillator and the output of the high-frequency oscillator.

NOTE

Caution should be exercised in the adjustment of the position of the tuning slug when no frequency standard is available. A fraction of a revolution in one direction or the other should realign the circuit.

(l) When zero beat has been obtained, carefully tighten the nut on the end of the slug screw to prevent further displacement of tuning slug.

(m) Refer to Table 3-2 in Section III and obtain the correct position of Control "B" for output on 3000 kc with Control "A" in Position 2. (Oscillator output on 1500 kc)

(n) Rotate Control "B" to the setting obtained from the table. Approach the setting in a clockwise direction.

(o) Adjust trimming capacitor C-134, (figure 5-3) until zero beat is obtained between the output of the HF oscillator and the output of the calibration oscillator.

(p) Check several points in the band by obtaining Control "B" settings from Table 3-2 and listening to the beat note output of the SIDETONE amplifier.

(q) If the setting of Control "B" necessary to obtain exact zero beat deviates more than 4 or 5 dial divisions from the setting given in the calibration table, repeat steps (f) through (p) of the above procedure until the dial settings necessary to obtain a given frequency correspond very closely to those given in the calibration table.

(r) When alignment adjustments have been completed with Control "A" in Position 2, operate the control to Position 1.

(s) Refer to Table 3-2 opposite 2000 kc (Control "A" in Position 1) and obtain the dial setting for Control "B". (Oscillator output on 1000 kc.)

(t) While listening to the SIDETONE output, adjust trimming capacitor C-135 (figure 5-3) until zero beat between the high-frequency oscillator output and the calibration oscillator output is obtained.

NOTE

Do not make any further adjustments of trimmer C-134.

(u) Check several points within the frequency range 2000 kc to 2400 kc by obtaining the dial setting of Control "B" from the table, listening to the SIDETONE output and operating Control "B" about the setting obtained from the calibration table. The settings should check with those given in the table within 4 or 5 dial divisions.

NOTE

No adjustment of the high-frequency oscillator grid inductor slug should be made with Control "A" in Position 1.

(v) Return the EMISSION selector switch, S-110, to the OFF position.

c. HIGH-FREQUENCY OSCILLATOR ALIGNMENT USING EXTERNAL FREQUENCY STANDARD (NAVY TYPE 1M).

(1) If oscillator circuit components have been replaced and an accurate frequency standard is available the following procedure should be followed for the alignment of the high-frequency oscillator circuit:

(a) With the EMISSION selector switch, S-110, in the OFF position remove the cover plates from the right-hand end and bottom of the transmitter cabinet. The HF oscillator grid trimmer capacitors, C-134 and C-135, the HF oscillator grid inductor, L-101, tuning slug adjustment and the frequency multiplier plate inductor, L-105 and L-106, tuning slug adjustments are exposed.

(b) Rotate the CHANNEL selector switch, S-108, to the MANUAL position.

(c) Operate the EMISSION selector switch, S-110, to the VOICE position.

(d) When the Autotune cycle has been completed, operate Control "A" to Position 2.

(e) Set the indicator mark, over Control "B", to mid-scale using the CORRECTOR knob.

(f) Refer to Table 3-2 and obtain the dial setting for an output frequency of 2400 kc with Control "A" in Position 2. (Oscillator output on 1200 kc.)

(g) Rotate Control "B" to the setting obtained from the table.

(h) Loosen the nut on the rear of the lead screw that holds the multiplier tuning slug yoke to the screw.

(i) Operate the power level switch, S-106, to the CALIBRATE position. (Applies 1150 volts DC to plate of V-104.)

(j) Measure the output frequency of the oscillator and adjust the position of the tuning slug in L-101 until the oscillator frequency is exactly 1200 kc.

(k) When the correct position of the tuning slug has been found tighten the locking nut to prevent any further displacement of the slug.

(l) Refer to Table 3-2 and obtain the setting of Control "B" necessary to obtain an output frequency of 3000 kc with Control "A" in Position 2. (Oscillator output on 1500 kc.)

(m) Rotate Control "B" to the setting obtained from the table.

(n) Measure the output frequency of the oscillator and adjust capacitor trimmer C-134 (figure 5-3) until the frequency of the oscillator output is exactly 1500 kc.

(o) Check several points within the band by obtaining dial settings from the calibration tables, rotating Control "B" to these settings and measuring the frequencies.

NOTE

Always keep in mind that with Control "A" in Positions 1 or 2 the frequencies given in the calibration tables are always twice the output frequency of the oscillator. With the power level switch in the CALIBRATE position only the oscillator is operating, therefore, the output frequency to be measured will always be one-half the frequency that is given in the calibration tables.

(p) If the dial setting of Control "B" which is necessary to obtain output on a selected frequency deviates more than 4 or 5 dial divisions from the dial setting given in the calibration tables, repeat steps (f) through (o) until the actual dial setting of Control "B" corresponds very closely to the setting given in the table.

(q) When alignment has been completed with Control "A" in Position 2, operate the control to Position 1.

(r) Refer to Table 3-2 and obtain the dial setting of Control "B" to obtain an output frequency of 2000 kc with Control "A" in Position 1. (Oscillator output on 1000 kc.)

(s) Adjust trimming capacitor C-135 (figure 5-3) until the oscillator output frequency is exactly 1200 kc.

NOTE

Do not make any adjustment of C-134 or the core in inductor L-101 with Control "A" in Position 1.

(t) Check several points within the band by comparing the actual dial settings necessary to obtain a given frequency with the dial settings given in the calibration tables for the same frequency. The settings should check within 4 or 5 dial divisions.

(u) Return the EMISSION selector switch, S-110, to the OFF position.

d. FREQUENCY MULTIPLIER ALIGNMENT.

(1) Having completed the alignment of the high-frequency oscillator circuit, complete the RF circuit alignment by following the procedure outlined below for the adjustment of the frequency multiplier circuits:

(a) With the transmitter tipped up on the rear edge and the bottom cover removed, the frequency multiplier plate tank capacitors are exposed.

NOTE

The multiplier plate tank capacitors are located beneath the multiplier chassis. (Stacks of ceramic capacitor sections.) Capacitor section A of each capacitor, C-111 and C-115, is located nearest the right-hand side of the transmitter, as the transmitter is viewed from the bottom, with sections B, C, D, E and F in order in the stack. (Figure 5-5.)

(b) Operate Control "A" to Position 6.

(c) Rotate the metered circuit selector switch, S-105, to the PA GRID position.

(d) Rotate Control "B" until the dial reading is 1100.

(e) Operate the power level switch to the TUNE position.

(f) Operate the EMISSION selector switch, S-110, to the CW position. (Applies 1150 volts DC plate potential.)

CAUTION

Use an insulated tool to adjust the capacitors. When the key is operated the capacitor is at a potential of 400 volts above ground.

(g) Insert a shorted plug in KEY jack J-103 and adjust section F (bottom of stack) of first multiplier padding capacitor C-111 to the position that will give the maximum PA GRID meter reading on M-102.

NOTE

To vary the capacity of sections of C-111 or C-115 rotate the metal lip that protrudes between capacitor section.

(h) Using a portable frequency meter check the output frequency of the first frequency multiplier stage to be sure that the plate circuit is tuned to the correct harmonic. The output should be on approximately 5400 kc with Control "A" in Position 6 and Control "B" tuned to a dial reading of 1100.

(i) When it has been ascertained that the multiplier output is on the correct harmonic rotate Control "B" over the entire range, observe the grid reading on meter M-102.




Figure 5-5 Frequency Multiplier




Figure 5-6 Frequency Multiplier Adjustment

CAUTION

When the key is operated the inductors L-105 and L-106 are at a potential of 400 volts above ground.

(j) Take out dips in the meter reading by adjusting section F of first multiplier padding capacitor C-111 for an average reading of the meter.

CAUTION

When the key is operated the inductors L-105 and L-106 are at a potential of 400 volts above ground.

(k) A drop at the extreme ends of the range is permissible but if the meter needle still dips sharply at any other point, rotate Control "B" to a dial reading of 1100, loosen the first multiplier inductance L-105 tuning slug locking nut and change slightly the position of the tuning slug. Tighten the slug locking nut.

(l) Rotate Control "B" over the entire range and check the PA GRID current. Meter M-102 should indicate a consistent value of grid current over the entire range. If the meter needle dips sharply at any point repeat steps (j) and (k).

(m) Having completed the adjustment of the inductor slug and section F of C-111, remove the key shorting plug and rotate Control "A" to Position 5.

(n) Rotate Control "B" to a dial reading of 1100.

(o) Replace the key shorting plug, adjust section E of capacitor C-111 to give a maximum PA GRID meter reading and check with a frequency meter for the correct harmonic.

NOTE

Do not make any further adjustments of the position of the tuning slug in L-105.

(p) Rotate Control "B" through the entire range and check the excitation. If dips occur in the meter reading readjust padding capacitor C-111E.

(q) Remove the key shorting plug and operate Control "A" to Position 4.

(r) Replace the key shorting plug and adjust section D of C-111 for maximum PA GRID meter reading.

(s) Check the excitation over the band by operating Control "B" over the entire range. If dips in the meter reading occur repeat step (j).

(t) Repeat steps (r) and (s) for Positions 4, 3, 2 and 1 of Control "A". Adjust capacitor sections D, C, B and A, for Control "A" Positions 4, 3, 2 and 1 respectively.

(u) Having completed the alignment of the 1st frequency multiplier stage, remove the key shorting plug and operate Control "A" to Position 12.

(v) Rotate Control "B" to a dial reading of 1100.

(w) Replace the key shorting plug and adjust section F of second multiplier padding capacitor C-115 for maximum PA-GRID meter reading.

(x) Using an insulated screwdriver to reduce body capacity adjust trimmer capacitor C-136 for maximum PA GRID meter reading.

(y) Check the output frequency of the second multiplier with a frequency meter. With Control "A" in Position 12 and Control "B" tuned to a dial reading of 1100 the frequency meter should indicate approximately 16,430 kc. A materially different reading indicates that a wrong harmonic has been chosen necessitating a readjustment of padding capacitor C-115F and trimmer capacitor C-136.

(z) Take out dips in the meter reading by adjusting section F of padding capacitor C-115.

(aa) A drop at the extreme ends of the range is permissible but if the meter needle still dips sharply at any other point, rotate Control "B" to a dial reading of 1100, loosen the second multiplier inductance L-106 tuning slug locking nut and change the position of the tuning slug slightly. Tighten the slug locking nut.

(bb) Again rotate Control "B" over the entire range and check the excitation. If the meter dips sharply at any point repeat steps (x) through (bb)

(cc) Having completed the adjustment of the inductor slug and section F of C-115, remove the key shorting plug and rotate Control "A" to Position 11.

(dd) Rotate Control "B" to a dial reading of 1100.

(ee) Replace the key shorting plug, adjust section E of capacitor C-115 to the capacity which gives the maximum PA GRID meter reading and check with a frequency meter for the correct harmonic.

NOTE

Do not make any further adjustment of the tuning slug in L-106 or trimmer capacitor C-136.

(ff) Rotate Control "B" through the entire range and check the excitation. If dips occur in the meter reading readjust padding capacitor C-115E.

(gg) Repeat steps (ee) and (ff) with Control "A" in positions 10, 9, 8 and 7. Adjust capacitor sections D, C, B and A for Control "A" Positions 10, 9, 8 and 7 respectively.

The above procedure completes the alignment of the high-frequency RF circuits of the transmitter.

5. MCW-CFI ADJUSTMENT

NOTE

If at any time erratic or abnormal operation is observed, or the unit fails to function entirely, the tubes and crystal should be carefully checked. Tube failure is probably the most common cause of the failure of any electronic device. The most dependable method of checking and finding the defective tube or crystal is to replace each tube one at a time with tubes known to be in good condition and to insert another crystal known to be active and correct in frequency.

IMPORTANT

Realignment or servicing other than tube or crystal replacement should not be attempted until the tubes and crystal have been carefully checked and unless the alignment procedure of the unit is thoroughly understood.

WARNING

Because the inductor tuning adjustment screws are in a difficult position to reach when the unit is in place in the transmitter, and because of the proximity of exposed leads carrying potentials of more than 400 volts, a short extension cable allowing the MCW-CFI Unit to be on the bench beside the transmitter is recommended.

NOTE

Because of the small space, adjustment of the unit is most conveniently made with a very small "jewelers" type screwdriver having a shank at least 1-1/4 inches long. Such a screwdriver is included in the equipment spares.

a. CFI ALIGNMENT USING TRANSMITTER SIDETONE CIRCUITS.

- (1) Make sure that EMISSION selector switch S-110 is in the OFF position.
- (2) Insert a coin or a screwdriver in the slot of the transmitter cover hold-down screws, rotate the screws one-half revolution counterclockwise and lift off the cover.
- (3) Loosen the two large screws that hold the unit to the main transmitter chassis.
- (4) Raise the unit until the connector plug is disengaged and lift the unit out.
- (5) Connect an extension cable to MCW-CFI jack J-111 in the transmitter and to unit plug P-2201.
- (6) Turn LOCAL-REMOTE switch S-107 to the LOCAL position.
- (7) Connect earphones to the sidetone circuits by inserting the earphones cord plug into SIDETONE jack J-104.

- (8) Rotate CHANNEL selector switch S-108 to the MANUAL position.
- (9) Turn EMISSION selector switch S-110 to the VOICE position.
- (10) When the Autotune cycle has been completed, rotate Control "C" to any dial reading, taking care to approach the chosen setting clockwise through at least one eight turn and to set the dial accurately.
- (11) Rotate Control "A" to Position 1.
- (12) Turn power level switch S-106 to the CALIBRATE position. (Applies 1150 volts DC to plates of V-104, V-105 and V-106.)
- (13) Adjust SIDETONE gain control switch S-202 to Position 2 and search for calibration beat signals by rotating Control "B".
- (14) If beat signals are not found, insert a small screwdriver in the slot of inductor Z-2201A tuning adjustment screw, adjacent to which is stamped the number "200". Rotate this screw, while continuing to rotate Control "B", until a beat signal is heard, indicating operation of the crystal oscillator.
- (15) If a loud squeaking rush noise appears as soon as the crystal oscillator functions, adjust inductor Z-2202A tuning adjustment screw, adjacent to which is stamped the number "150", until this noise disappears. Absence of such noises is one indication of correct unit operation.
- (16) Vary the pitch of the beat signal arrived at, by adjusting Control "B" to a pitch easy to listen to. Adjust SIDETONE gain control switch S-202 to a position giving comfortable volume level.
- (17) Adjust inductor Z-2201A tuning adjustment screw for the midpoint of the maximum volume range.
- (18) Tune the HF oscillator by rotating Control "B" until two loud signals of approximately equal volume are heard.
- (19) Compare the zero beat signal dial settings of the two selected beat points with the calibration table check points to determine if the interval between the points is 100 kc (oscillator frequency is doubled on range 1 causing 50 kc interval with oscillator to be recorded as 100 kc.)
- (20) If the interval is correct and the dial readings correspond reasonably (within 25 dial divisions) with the calibration table tune Z-2201B (farthest from crystal) marked "50", tune Z-2202B (nearest crystal) marked "50", and tune Z-2202A (marked "150") for maximum sidetone output. Recheck tuning in the same order.
- (21) Turn the transmitter on and off several times, noting whether the crystal oscillates positively as soon as the transmitter is turned on. Detune Z-2201A (marked "200") slightly to improve crystal starting if necessary.
- (22) If less than a 50 kc interval (recorded 100 kc on Band 1) is obtained, rotate mixer tank Z-2202B adjustment screw clockwise three turns, then rotate

tripler tank Z-2202A adjustment screw counterclockwise until harsh noises occur and disappear. Repeat Steps 18 to 20 inclusive.

(23) If more than a 50 kc interval (recorded 100 kc on Band 1) is obtained, rotate mixer tank Z-2202B adjustment screw counterclockwise three turns, then rotate tripler tank Z-2202A adjustment screw clockwise until harsh noises occur and disappear. Repeat Steps 18 to 20 inclusive.

(24) The unit can now be considered to be aligned and the calibration frequency accurate to within very close limits. Replacement in the transmitter completes the operation.

NOTE

It is possible for the unit to be adjusted in the transmitter by removing the multiplier tubes, since the 400 volt plate potential is removed from the multiplier tube plate cap leads by the operation of power level switch S-106 to the CALIBRATE position. However, in the interests of safety, this procedure is not recommended, since the exposed plate cap lead of the HF oscillator and the exposed LF oscillator plate lead terminals are at a potential of more than 400 volts above ground.

b. MCW ADJUSTMENT. - The frequency of the audio tone oscillator is fixed at approximately 1000 cps but the output level may be varied by means of a variable resistor R-2201.

To adjust the audio tone oscillator follow the procedure outlined in Steps (1) to (5) inclusive in the section devoted to CFI adjustment preparations and then proceed as follows:

(1) Adjust the transmitter for MCW operation on any frequency and place it in operation.

(2) By means of an oscilloscope or other modulation level measuring device measure the percentage of modulation.

(3) Insert a screwdriver through the hole provided in the back side of the MCW-CFI Unit and engage the exposed slot.

(4) Rotate the screwdriver until the desired percentage of modulation is attained. An adjustment providing 70% modulation at full power is recommended.

c. CFI ALIGNMENT USING VACUUM TUBE VOLTMETERS. - If multi-scale reversible polarity DC vacuum tube voltmeters are available, the following alignment procedure should be followed. Although it is possible to follow this procedure using only one such meter, it is recommended that wherever possible three meters be employed as described.

(1) Follow steps 1 to 8 inclusive in the preceding adjustment procedure.

(2) Connect the normally negative or grounded lead of meter number 1 to a ground in the unit. Connect the normally positive or above ground lead through a 1 megohm resistor to terminal No. 4 of X-2201 (V-2201 oscillator control grid). Adjust meter to read 0 to -30 volts.

(3) Connect and adjust meter number 2 in the same manner as in step (2) except to select terminal number 1 of X-2201 (V-2201 tripler control grid).

(4) Connect meter number 3 in the same manner as in step (2) except to select terminal number 8 of X-2202 (V-2202 mixer control grid). Adjust meter to read 0 to -10 volts.

(5) Follow steps (9) to (12) inclusive outlined in the preceding adjustment procedure.

(6) Insert a small screwdriver in the slot of inductor Z-2201A tuning adjustment screw, adjacent to which is stamped the number "200". Rotate this screw for maximum voltage as indicated on meter number 1 (step 2).

(7) Rotate inductor Z-2202A, tuning adjustment screw, adjacent to which is stamped the number "150" until maximum negative voltage is indicated on meter number 2. (Several voltage peaks may be found, possibly even a positive one. The correct position of the adjustment screw is that which gives the highest negative meter reading.)

(8) Rotate inductor Z-2202B tuning adjustment screw adjacent to which is stamped the number "50" (nearest crystal) until the maximum voltage peak is indicated on meter number 3.

(9) Repeat steps (7) and (8) until meter number 2 and meter number 3 indicate maximum reading simultaneously.

(10) Turn power level switch S-106 to the TUNE position.

(11) Disconnect meters and reconnect a meter to terminal number 1 of X-2203 (detector section of V-2203 control grid).

(12) Adjust SIDETONE gain control switch S-202 to Position 2 and turn power level switch S-106 to the CALIBRATE position. (Applies 1150 volts DC to plate of V-104.)

(13) Using headphones, adjust Control "B" until a beat signal is heard on an HF oscillator frequency ending in 50 (consult calibration tables in data section). Vary the pitch of the beat signal arrived at by adjusting Control "B" to a pitch easy to listen to. Adjust SIDETONE gain control switch S-202 to a position giving comfortable volume level.

(14) Rotate inductor Z-2201A tuning adjustment screw, adjacent to which is stamped the number "50" (farthest from crystal) until the meter indicates minimum voltage. The beat note heard in the headphones varies in volume as this point is approached. The adjustment screw should be adjusted in the vicinity of minimum voltage meter reading at the point which produces a maximum audio level beat note located between two weaker points.

6. PRECISION CALIBRATION OF MCW-CFI UNIT CRYSTAL OSCILLATOR. -- The 200 kc crystal used in the MCW-CFI Unit is accurate to within $\pm .01\%$ 32-158°F (0-70°C). Variations in the tuning of the crystal tank circuit through the range in which the crystal will stay in oscillation averages about 25 cycles off crystal frequency. It can be seen therefore that the CFI can be considered accurate for all practical purposes.

The alignment procedure previously outlined presupposes a Navy Type -52286-A Transmitter oscillator in good working condition and reference to the oscillator calibration tables for determining the 50 kc interval CFI output.

The remote possibility of obtaining other than a 50 kc interval during alignment can be checked by listening on a nearby calibrated receiver, especially if the receiver is provided with a beat frequency oscillator, and observing that a 50 kc interval exists between harmonics of the CFI output as the receiver is tuned over a range of about 300 kc. For this purpose, a well shielded receiver should be used.

a. PROCEDURE.

- (1) Obtain a length of stranded, insulated wire about 6 feet long. Connect one end of the wire to the antenna terminal on the receiver and the other end to the ground terminal on the receiver. Twist the two leads together and make a loop in the extreme end of the "twisted pair".
- (2) Place the loop over the detector and audio oscillator tube V-2203 which is located farthest from the crystal unit in the MCW-CFI Unit.
- (3) Place transmitter LOCAL-REMOTE switch S-107 in the LOCAL position.
- (4) Place EMISSION selector switch S-110 in the VOICE position.
- (5) Operate power level switch S-106 to the CALIBRATE position. (Applies 1150 volts DC to plates of V-104, V-105 and V-106.)
- (6) Place the receiver in operation and turn on the receiver beat frequency oscillator.
- (7) Listen to the receiver as it is tuned over a range of about 300 kc and observe whether a 50 kc interval exists between the beat notes observed. If other than a 50 kc interval is observed, refer to the CFI alignment procedure outlined in Paragraph V-5a, step (1) to (8) inclusive, and step (22) or (23).
- (8) Again tune the receiver repeating the procedure outlined until the interval is correctly 50 kc.

Since a slight variation in the output frequency of the crystal oscillator is possible by detuning the crystal oscillator tank circuit, this factor can be used to adjust the CFI output frequency to exact zero beat with another highly accurate frequency standard by feeding the output of such a standard into the receiver while it is connected in the manner described in Paragraph V-6 except that the receiver beat frequency oscillator must be turned off. Any such standard of value must be constantly checked against the U.S. Bureau of Standards or similar transmissions. If such a transmission can be received directly, the ultimate in accurate adjustment of CFI frequency can be obtained by attaching the antenna to the receiver, in addition to the "twisted pair" connection to the receiver, and obtaining a zero beat between the standard transmission and the CFI output. Any standard used in the manner outlined must be a multiple of 50 kc.

7. MAINTENANCE OF AUTOTUNE MECHANISM.

a. LUBRICATION.

(1) The four types of lubricants required are: (1) Texaco Capella A lubricating oil manufactured by the Texas Company, 135 E. 42 St., New York City, (2) Socony-Vacuum PD-535A lubricating grease manufactured by the Socony Vacuum Oil Co., 26 Broadway, New York City, (3) Cities Service North Star 000 oil manufactured by The Cities Service Oil Company, 500 Roberts St., Saint Paul, Minnesota. The replaceable Autotune lubrication wicks (see Parts List, Section VI) are obtainable from Collins Radio Company, Cedar Rapids, Iowa. In locations where severe dust is encountered, it may be necessary to thoroughly clean all parts before application of any lubricants. A soft brush and a jet of compressed air will be suitable for cleaning the Autotune mechanism.

(2) The Texaco Capella A oil is to be used for all lubrication points except the open gears and pawls. The points to be lubricated with this oil include:

- (a) All line shaft bearings.
- (b) Autotune motor bearings.
- (c) Front and rear cam drum bearings on each of the Autotune units.
- (d) All idler gear bearings.
- (e) Counter drum bearings.
- (f) Limit switch drive shaft bearings.

(3) The Socony-Vacuum PD-535A grease should be used on all gears. These gears include:

- (a) Spur and idler gears on all Autotune units.
- (b) The screw on the limit switch drive shaft.

(4) Cities Service North Star 000 oil should be used for lubricating the pawl stacks on each of the Autotune units.

(5) Replaceable wick lubricators are used in the following positions:

- (a) All line shaft worms.
- (b) Autotune chain drive.

(6) The Autotune lubrication chart, figure 5-11, shows the proper points for the application of each type of lubricant. The letters inside the dotted circles denote the type of lubricant to be used at each point. The letters A, B, and C are identified with the lubricants they represent at the bottom of figure 5-11.




Figure 5-7 Autotune Singleturn Unit - Left Side




Figure 5-8 Autotune Singleturn Unit - Right Side




Figure 5-9 Autotune Multiturn Unit - Left Side







Figure 5-10 Autotune Multiturn Unit - Right Side



SINGLETURN UNIT



MULTITURN UNIT



AUTOTUNE CASTING

HFO CASTING

SEMI-ANNUALLY

EACH ARROW INDICATES A POINT OF LUBRICATION. LETTERS WITHIN BALLOONS CORRESPOND TO LUBRICANTS LISTED BELOW. APPLY SPARINGLY WITH CAMEL HAIR BRUSH. REMOVE EXCESS LUBRICANT.

- (A) TEXACO CAPELLA A OIL (OR EQUAL)
- (B) SOCONY VACUUM PD5 35A GREASE (OR EQUAL)
- (C) CITIES SERVICE NORTH STAR 000 (OR EQUAL)

BALL BEARINGS SHOWN ABOVE DO NOT REQUIRE LUBRICATION.

ANNUALLY

REPLACE 7 WICKS WITH A COMPLETE NEW SET. DO NOT RE-USE WICKS.

Figure 5-11 Autotune Lubrication Chart

(7) Each of the three lubricants may be applied with a camel's hair brush to the various lubrication points. Only very small amounts of oil or grease are required at most points. Be sure to remove any excess oil or grease after lubricating the Autotune system.

(8) It will not be necessary to remove the individual Autotune units in order to lubricate the mechanism properly. The transmitter should be turned on the back and the Autotune front panel removed for maximum access to the lubrication points.

(9) The wick lubricator on the singleturn Autotune units can be most easily replaced by loosening the screws clamping the wick holder to the unit and sliding the holder forward. The wick lubricator holders on the multiturn Autotune unit and the Autotune chain drive must be removed in order to replace the wicks.

b. SYNCHRONIZATION CHECK.

(1) In order for the Autotune system to function properly, the five individual units must be carefully synchronized. If there is any reason to doubt the accuracy of the synchronization, it should be immediately checked. This may be done as follows:

(2) Turn the equipment on the back so as to have maximum access to the units and remove the Autotune front panel.

NOTE

If the counter drum rings in the multiturn unit "B" have been moved for any reason so that a pawl cannot fall in the slot of a given ring within the range of the counter drum rotation, the ring must be moved manually a quarter turn in either direction.

(3) Place the crank (which is included in the spare parts) on the right end of the Autotune line shaft, orient the crank hub in the slot and fasten it with a 4-40 x 1/2" screw.

(4) By means of the crank turn the line shaft counterclockwise until all the cam drums are being driven. Continue to turn the crank counterclockwise until the stop-ring drum on the Multiturn unit has reached home stop and has ceased to turn.

(5) After the stop-ring drum on the Multiturn unit has ceased to turn and only the cam drums are turning, pull the fork of the anvil (figure 4-22) in a counterclockwise direction away from under the tails of the pawls so that they are free to fall to the surface of the counter drum. If at any time the line shaft should be turned clockwise, it will first be necessary to turn the line shaft again in the counterclockwise direction far enough to reach home stop before pulling the anvil out from under the tails of the pawls; otherwise, as soon as the line shaft is turned counterclockwise, the anvil will be rotated up **under** the tails of the pawls.

(6) Continue to rotate the crank slowly until the No. 5 pawl on one of the units, just drops into its cam slot.

NOTE

Count from the front of the Autotune unit to the back, omitting the first or manual pawl, to arrive at pawl No. 5.

(7) Note the position of the crank arm by marking a line on the casting and then slowly turn the crank, noting the points at which the No. 5 pawls on all of the other units drop into the cam slots. All of the pawls should drop into place within a quarter turn ahead or behind the point where the number 5 pawl or unit "A" engaged with its cam. All pawls should drop sharply with a "click".

(8) Continue to rotate the crank counterclockwise until the number 6 pawl on one of the units, just drops into its cam slot.

(9) Note the position of the crank arm by marking a line on the casting and then slowly turn the crank, noting the points at which the number 6 pawls on all of the other units drop into the cam slots and repeat the procedure outlined in Step (7).

(10) Repeat Steps (8) and (9) checking the operation in turn of pawls number 7, 8, 9, 10, 11, 12 (LF), manual, 1, 2, 3, and 4.

g. SYNCHRONIZATION.

(1) If the Autotune system is found to be out of synchronism, the following procedure should be used to restore it:

(2) Determine which units are not in synchronism with the multiturn unit by use of the foregoing procedure. No adjustment is possible on the multiturn unit, therefore all other units should be synchronized with this unit.

(3) Repeat the procedure outlined in paragraph V-7b, (4) and (5).

(4) If it has been found by means of the Synchronization Check that Autotune unit "A" is not synchronized with Autotune unit "B", it may be synchronized as follows:

(a) Turn the line shaft counterclockwise until pawl number 5 on unit "B" just drops into its slot in the cam drum. At this point the cam drum on unit "A" should be in a position so that the set screws in the collar below the gear are accessible. In case one of the set screws is inaccessible, tighten the accessible set screw with a number 6 Bristo wrench and continue to turn the line shaft counterclockwise until the inaccessible set screw can be reached and loosened with the number 6 Bristo wrench, after which it will be necessary to continue to turn the line shaft in a counterclockwise direction until pawl number 5 on unit "B" again just drops into its slot in the cam drum. When this point is reached the remaining set screw in the collar on the cam drum shaft in unit "A" should be loosened. In case the above conditions cannot be met, it will be necessary to choose some other pawl that will allow these conditions.

(b) The cam drum in unit "A" is now free to be turned with the fingers until number 5 pawl just drops into its slot in the cam drum.

(c) Insert a 0.005 inch feeler gauge between the cam drum washer, which is adjacent to the cam drum and the gear on the cam drum shaft in unit "A".

Now insert a number 6 wrench in the accessible set screw, force the collar tight against the gear and around clockwise so that all play is taken up before tightening the screw. Care must be used not to move the cam drum during this step.

(d) Turn the line shaft counterclockwise noting the sequence in which the pawls on unit "A" fall with respect to the corresponding pawls on unit "B". If all the corresponding pawls on the two units fall within one-quarter turn of the line shaft, the two units are synchronized. The second set screw in the collar on unit "A" cam drum shaft should now be tightened.

(5) It is entirely possible, due to slight irregularities in the structure of the cam drums, that one or more corresponding pairs of pawls on the two units will not fall within the prescribed one-quarter turn tolerance or that the synchronizing was not done with sufficient care, causing even number 5 pawl on unit "A" to drop ahead or behind number 5 pawl on unit "B" by more than one-quarter turn.

(a) If it is found necessary to correct the synchronization, turn the line shaft counterclockwise noting the sequence in which the pawls fall. If some or all of the corresponding pawls fall farther apart from each other than the prescribed tolerance, pick out the pair that drops farthest apart and note which pawl drops first.

(b) If the pawl on unit "A" drops first, note what part of a revolution the line shaft must be turned through before the corresponding pawl on unit "B" falls. Continue to crank the line shaft counterclockwise until the two set screws on the collar below the cam drum on unit "A" are easily accessible. After loosening the set screws, turn the line shaft counterclockwise through the required part of a turn deemed necessary to correct the error and tighten the set screws. Repeat with more care if the pawls upon rechecking do not yet fall within the prescribed limits.

(c) If the pawl on unit "B" drops first, note what part of a revolution the line shaft must be turned through before the corresponding pawl on unit "A" falls. Continue to crank the line shaft counterclockwise until the two set screws on the collar below the cam drum on unit "A" are easily accessible. After loosening the set screws, rest the hand on the frame of unit "A" and, placing the thumb firmly on the cam drum, rotate the cam drum slightly counterclockwise by the amount judged necessary to correct the error, then tighten the set screws. Repeat with more care if the pawls upon rechecking do not yet fall within the prescribed limits.

(d) Check to make sure that both set screws in the collar on unit "A" cam drum shaft are tight.

(6) If it has been found by means of the Synchronization Check that Auto-tune unit "D", "C" or "E" is not synchronized with unit "A", causing corresponding pawls on units "A", "D", "C" and "E" to drop more than one-quarter turn of the line shaft apart, it will be necessary to re-synchronize the unit or units with unit "A" which are not within the one-quarter turn tolerance by the same procedure given for synchronizing unit "A" with unit "B" as outlined in Steps (4) and (5).

(7) It should be noted that when the Autotune System has been synchronized correctly, corresponding pawls on units "A" and "B" drop within one-quarter turn of each other and the corresponding pawls on units "C", "D" and "E" drop within one-quarter turn of those on unit "A".

d. AUTOTUNE POSITIONING MECHANISM.

(1) The Autotune positioning control mechanism consists of the Autotune seeking switch, S-109, which is of the open segment type, driven by an arm attached to the shaft of the cam drum on the singleturn Autotune unit "A", and the CHANNEL selector switch, S-108.

(2) The seeking switch driving arm must be so adjusted that when, for instance position number 5 is selected by the CHANNEL selector switch S-108, the number 5 pawl will drop on all Autotune units and be in this position at the end of the Autotune cycle. In addition, the driving arm pin must engage the driven arm completely, but the pin must not touch the frame of the seeking switch, S-109, at any point of the 360 degree rotation. Finally, a "back-up" distance of roughly from $5/64"$ $\pm 1/64"$ must be maintained between the pin of the driving arm and its place of contact on the driven arm after the cam drum, to which the driving arm is attached, is rotated by hand clockwise as far as it will go.

(3) If there is reason to believe that the seeking switch driving arm is out of adjustment, the following procedure should be followed to check it:

- (a) Turn the CHANNEL selector switch, S-108, to any position.
- (b) Turn the EMISSION selector switch, S-110, to the VOICE position. If the Autotune motor starts running allow it to run until the Autotune cycle is complete and the motor stops.

NOTE

If the motor continues to run more than 30 seconds without coming to a stop, observe whether, due to misalignment of the seeking switch driving arm, the seeking switch, S-109, is not being driven before turning the EMISSION selector switch, S-110, to the OFF position. If the adjustment of the seeking switch driving arm appears to be correct, the trouble is probably misalignment of or foreign matter in the motor control relay, K-101, or limit switch, S-111 and S-112. A short in the seeking switch itself can cause this trouble as can a short in the wiring.

(c) Turn the EMISSION selector switch, S-110, to the OFF position.

(d) Connect a continuity indicator from the number 1 contact of remote cable jack J-106 to the gnd connector on the transmitter. Operate the LOCAL-REMOTE switch, S-107, to the REMOTE position.

(e) Repeat Steps V-7b (2) to V-7b (4) inclusive.

(f) Continue to rotate the crank slowly until the last pawl corresponding to the contact selected has just dropped into its cam slot.

(g) Note the position of the crank arm by marking a line on the casting and then slowly turn the crank until the continuity is broken.

(h) Observe the fraction of a revolution that the crank has turned. It should be within the limits of one-eighth to one full turn of the crank.

(i) If the continuity is not broken within the limits of one-eighth to one full turn of the crank, the seeking switch driving arm must be adjusted.

(j) Repeat Steps (f), (g), and (h) for each contact of remote cable jack J-106 up to and including number 11.

(4) If it is determined in checking by the procedure outlined in paragraph V-7c (3) that the driving arm of the seeking switch, S-109, is out of adjustment, it may be readjusted as follows:

(a) If the switch shaft is not centered exactly with the cam drum shaft in front of it or if the mounting screws are loose, correct these conditions by re-centering the switch shaft and tightening the screws.

(b) Select a position by turning the line shaft crank counterclockwise that will place the set screws in the hub of the seeking switch driving arm in an accessible position.

(c) Loosen the set screws with a number 6 Bristo wrench.

(d) Turn the seeking switch driving arm clockwise if the switch as checked in Step (3) opened early, and counterclockwise if it opened late. The amount to turn the arm must be determined by trial and error, but will be very slight unless it has become loose enough to cause an entirely different pawl number to drop on the Autotune units.

(e) Tighten the set screws, taking care that the pin completely engages the driven arm but does not come so close to the frame of the seeking switch as to permit it to touch at any point of the 360 degree rotation.

(f) Recheck as outlined in Steps (3), (f), (g), (h) and repeat procedure until the Autotune seeking switch, S-109, is correctly adjusted.

e. AUTOTUNE LIMIT SWITCH.

(1) The limit switch is composed of a front section, S-112, and a rear section, S-111, and is located on the right side of the Multiturn or "B" Autotune unit.

(2) The rear limit switch section, S-111, should be adjusted so that it snaps between the limits of 3-1/4 to 9-1/4 turns of the line shaft crank counting clockwise from the time the switch snaps until the collar pin on the switch operating arm is engaged by the rear lead screw collar.

(3) Add or remove shims from the rear end of the front switch section, S-112, insulator stack until the foregoing conditions Step V-7e (2) can be met.

NOTE

Do not attempt to bend the arms of the rear switch sections as such a procedure may destroy the snap action of the switch.

(4) The front limit switch section should be adjusted so that it closes between the limits of 3-1/4 to 9-1/4 turns of the line shaft crank in a clockwise direction from the reference point. This reference point is arrived at by turning the line shaft crank counterclockwise, until the collar pin on the switch operating arm is engaged by the front lead screw collar. A continuity indicator connected across the switch contacts will facilitate noting the exact moment the switch makes the contact.

(5) The main arm of the front switch section should follow the short arm for slightly less than 1/32 inch as the short arm is bent back until contact is broken. This assures adequate contact pressure necessary for reliable operation of the switch.

(6) Using an ordinary telephone relay spring bender, bend the head of the long switch contact arm and the heel end of the short contact leaf until the foregoing conditions Steps (4) and (5) are met.

(7) Make sure that the leaves of the front and rear switch sections are in the clear and are not in danger of shorting on any part of the mechanism.

8. REPLACEMENT OF PARTS.

The following Autotune parts may be replaced in the field if adequate shop facilities are available. Since the Autotune mechanism is necessarily complicated, it is recommended that only skilled and experienced personnel be permitted to repair it.

REPLACEABLE AUTOTUNE PARTS

<u>Item</u>	<u>Quan.</u>	<u>Part Description</u>	<u>Used With</u>	<u>Part Number</u>
1	1	Multiturn Autotune Unit "B" Includes Wick Lubricator		520 0361 40 or 96K-1 500 4644 001
2	1	Singleturn Autotune Unit "A" Includes Wick Lubricator		571 0738 30 or 96J-4 500 4630 001
3	1	Singleturn Autotune Unit "C" Includes Wick Lubricator		572 0737 30 or 96J-2 500 4630 001
4	1	Singleturn Autotune Unit "D" Includes Wick Lubricator		571 0737 30 or 96J-1 500 4630 001

<u>Item</u>	<u>Quan.</u>	<u>Part Description</u>	<u>Used With</u>	<u>Part Number</u>
5	1	Singleturn Autotune Unit "E" Includes Wick Lubricator		573 0737 30 or 96J-3 500 4630 001
6	1	Dial for Unit A	2	508 1069 20 or NY-1069B
7	1	Dial for Unit B	1	507 5524 00 or X-5524
8	1	Dial for Unit C	3	508 1072 20 or NY-1072B
9	1	Dial for Unit D	4	507 5586 00 or NX-5586
10	1	Dial for Unit E	5	507 5796 00 or NX-5796
11	5	Dial Locking Bar	6,7,8, 9,10	507 5525 00 or NX-5525
12	5	Bar Stop Disc	11	507 5620 00 or X-5620
13	1	Main Line Shaft	17	507 5512 00 or NX-5512
14	4	Singleturn Worm	13	507 5513 00 or NX-5513
15	1	Small Multiturn Worm	17	Same as (14)
16	1	Large Multiturn Worm	17	507 5519 00 or NX-5519
17	1	Multiturn Line Shaft	13	507 5517 00 or NX-5517
18	1	Main Line Shaft Thrust Bearing	13	309 1320 00 or 309N132
19	1	Multiturn Line Shaft Thrust Bearing	17	309 1360 00 or 309N136
20	6	Line Shaft Bearing	13,17	507 5724 00 or NX-5724
21	1	Line Shaft Crank	17	571 1149 10 or GA-1149A
22	1	Counter Drum Dial	1	507 5527 00 or X-5527

<u>Item</u>	<u>Quan.</u>	<u>Part Description</u>	<u>Used With</u>	<u>Part Number</u>
23	1	Positioning Switch Drive Arm	2	571 0881 10 or 881A
24	1	Chain Drive Includes Wick Lubricator	13,25, 26	507 5603 00 or NX-5603 500 4635 001
25	1	Motor Sprocket	24	507 5602 00 or NX-5602
26	1	Line Shaft Sprocket	13,25, 26	507 5514 00 or NX-5514

a. REMOVING COMPONENT PARTS.

(1) COVER. - Remove 16 screws and lift off. (Cover must be removed before any other units or parts are removed.)

(2) MOTOR. - Remove 3 mounting screws and unsolder four wires to motor. Pivot motor as it is lifted out so as to free it from chain drive.

(3) AUTOTUNE UNIT "A". - Turn dial locking bar to unlocked position and loosen the two number 10 Bristo set screws in the dial. Turn dial and locking bar counterclockwise together until bar comes free. Remove both dial and locking bar. Remove the dial back plate, loosen the two long screws on the top end of the unit and the short screw on the bottom end of the unit. Lift the unit out.

(4) AUTOTUNE UNIT "C", "D", OR "E". - Remove 4 screws, one on each of Autotune units "C", "D", and "E" and one on the end of the jack strip. Pull the strip out as far as the wires will permit. Turn locking screw on Autotune unit "C", "D", or "E" to unlocked position and loosen the two number 10 Bristo set screws in the dial. Remove dial, remove dial back plate, loosen the two long screws on the top end of the unit and the short screw on the bottom of the rear plate. Lift the unit out.

NOTE

Autotune units "C", "D", and "E" differ only in that the clutches are designed to exert a different torque on each of these units. Each unit is stamped at the bottom of the front plate with the control letter "C", "D" or "E". Care must be exercised not to interchange these units. Note that the control dials are not interchangeable because of the dial engraving.

(5) AUTOTUNE UNIT "B". - Remove the right end cover plate and the dial and back plate from Unit "A". Next remove the number 10 nut on the back end of the main tuning slug leadscrew which is attached to the multiplier slug coupling yoke. Then remove the two mounting screws along the upper edge of the backplate of the multiturn unit; also remove the single screw along the lower edge. Remove the two screws which hold the limit switch and carefully

pull the switch away from the assembly. Pull the assembly out of the casting carefully so as not to damage the tuning slug on the leadscrew.

NOTE

If the leadscrew is turned even slightly the high frequency oscillator must be recalibrated and realigned.

(6) LINE SHAFT. - Remove all Autotune singleturn units and four screws of the thrust bearing on left end of shaft. Remove taper Groov-pins on worms for heads A, C, and D and on sprocket. Pull shaft assembly out of the left end of Autotune casting.

CAUTION

Be very careful not to spring the line shaft when driving out the taper Groov-pins. Support the shaft adjacent to the gears when removing or replacing the taper Groov-pins. Keep the gears separate and in order so each may be replaced in the same location from which it was removed.

(7) REPLACING CONTROL DIALS "A", "B", "C", "D" AND "E". - Care must be exercised to replace the dials exactly as they were before disassembly. Each dial must clear the dial back plate throughout the range of the Autotune unit to which it is attached.

(a) Dial "A" should indicate range number 1 when the contact arm of range switch S-102 is centered on contact number 1. The setting must be approached clockwise from the counterclockwise rotation limit.

(b) Dial "B" should indicate "0" when the multiturn unit is at the counterclockwise home stop position when the reference marker is in a vertical position.

(c) Dial "C" should read between 1 and 13 when the unit is rotated against the counterclockwise rotation limit. Rotating the dial to position number 1 should cause a tooth of the star cam to seat squarely on the roller of Autotune interlock switch S-113D during the interval that the contact arm of S-113C rests squarely on contact number 1. Contact number 1 is located farthest from the transmitter front panel.

(d) Dial "D" should indicate "0" when the crosswise half-turn in the rotor winding of variometer L-112 is at the top of the unit and the windings of the unit are in alignment. This setting must be approached clockwise from the counterclockwise limit of rotation.

(e) Dial "E" should be adjusted so that switch S-113A is completely closed when the dial reads 100 and completely open when the dial reads 200. The switch must operate in the blank space between the dial reading of 100 and 200.

b. SERVICING THE MAIN LINE SHAFT ASSEMBLY.

(1) The following replaceable parts are associated with the main line shaft assembly:

<u>Item</u>	<u>Description</u>
13	Main Line Shaft
14	Singleturn Worm (4)
18	Main Line Shaft Thrust Bearing
20	Line Shaft Bearing (4)
24	Chain Drive
25	Line Shaft Sprocket

(2) In order to replace these parts it will be necessary to remove the entire line shaft assembly. Care must be exercised to keep each gear in the proper order when disassembling the line shaft. None of the gears are interchangeable.

(3) The following procedure is recommended for removing the line shaft assembly.

CAUTION

When driving out the taper Groov-pins be very careful not to spring the line shaft.

(a) Remove all singleturn Autotune heads (Heads A, C, D and E).

(b) Remove the taper Groov-pin from each of the worms and the sprocket. Before driving out a taper Groov-pin, be sure that the line shaft is well supported adjacent to the taper Groov-pin.

(c) Remove the four screws from the thrust bearing retainer plate on the left end of the casting.

(d) Slowly work the shaft off the left end of the casting removing each worm or the sprocket as it nears the end of the shaft. Be sure each gear is properly identified so as to be replaced in its original position. These gears are not interchangeable because each gear is drilled while on the line shaft.

c. REPLACING A SINGLETURN WORM.-- The replacement singleturn worm is furnished undrilled. The following procedure is recommended for replacing a singleturn worm:

(1) Center-punch the sleeve of the worm in the spot corresponding to the center of the hole on the old worm.


(2) Using a 1/16" drill, drill through one side of the worm sleeve.

(3) Slide the worm on the shaft with the sleeve end away from the thrust bearing assembly.

(4) Drill through to the other side of the worm sleeve with the 1/16" drill.

(5) Proceed to reassemble the line shaft in the reverse order of the foregoing disassembling procedure using new 1/16" x 3/8" taper Groov-pins on the worms and a new 5/64" x 1/2" taper Groov-pin on the sprocket.

Figure 5-12 Autotune Casting



d. REPLACING A LINE SHAFT SPROCKET. - Follow the same procedure as used for replacing the singleturn worm except use a number 47 drill.

e. REPLACING THE CHAIN DRIVE. - As the line shaft is being pulled out the left end of the casting, slip off the old chain and sprocket. Put the new chain on the sprocket and push the line shaft back into place, slipping the shaft through the sprocket. Slip the singleturn worm on the end of the shaft and then replace with new taper Groov-pins.

f. REPLACING A LINE SHAFT BEARING. - The oilite type line shaft bearings are held in place by means of a press fit. A thin steel sleeve fits over these bearings. After removing the line shaft the defective bearing should be driven out gently by using a mallet and a rod or blunt end punch. The new bearing should then be gently driven into place. Be careful not to deform the bearing.

g. REPLACING THE MAIN LINE SHAFT THRUST BEARING. - In replacing this bearing, it will not be necessary to remove the entire line shaft assembly. The following procedure is recommended:

- (1) Remove the four screws from the bearing retainer plate on the left end of the casting.
- (2) Remove the taper Groov-pin from the line shaft sprocket.
- (3) Work the shaft end bearing out about an inch or more from the end of the casting.
- (4) Carefully block up the outside bearing collar and drive out the taper Groov-pin from the inside bearing collar.

CAUTION

Be careful not to spring the line shaft when driving the taper Groov-pin out.

(5) Replace the inside collar on the shaft, slide the new bearing on the shaft and then slide the outside collar through the bearing into the inside collar.

(6) Insert a taper Groov-pin and gently drive it home.

CAUTION

Be sure the outside collar is blocked up properly so that the line shaft will not be sprung.

(7) Slide the shaft back to its original position and replace the bearing plate. Use a new taper Groov-pin in the line shaft sprocket.

h. REPLACING THE MAIN LINE SHAFT. - The task of installing a new line shaft is difficult and lengthy and should only be attempted by an experienced mechanic who has adequate tools available. The following procedure is recommended for replacing the main line shaft:

- (1) Remove the line shaft as previously prescribed.
- (2) Reassemble the gears on the shaft and drive the taper Groov-pins in lightly.
- (3) Carefully measure the distance from the milled end of the shaft to one end of each worm, the sprocket and the thrust bearing.
- (4) Completely disassemble the line shaft.
- (5) Centerpunch each gear and the sprocket at a point which is at a right angle to the previously used taper Groov-pin hole and the same distance from the end.
- (6) Drill each gear with a 1/16" drill and the sprocket with a number 47 drill through on one side only.
- (7) Put one of the worms on the shaft, in its predetermined position, block the shaft well, and, using a 1/16" drill, drill through the new hole in the gear into the line shaft through the other side of the gear.
- (8) Suitably mark the new hole on the sleeve of the gear.
- (9) Repeat Steps (7) and (8) for the remaining worms and sprocket. Use a number 47 drill for the sprocket.
- (10) Assemble the bearing and slide it on the end of the shaft.
- (11) Clamp the bearing, block the shaft and drill through the two sleeves and the shaft at a point at right angles to the old hole. Use a 1/16" drill.
- (12) Suitably mark the new hole on both sleeves.
- (13) Using new taper Groov-pins (five 1/16" x 3/8" and one 5/64" x 1/2") assemble the shaft in the casting as previously described.

NOTE

Be sure to place the gears in their proper order on the shaft.

i. SERVICING THE MULTITURN LINE SHAFT ASSEMBLY.

(1) The following replaceable parts are associated with the Multiturn line shaft assembly:

<u>Item</u>	<u>Description</u>
15	Small Multiturn Worm
16	Large Multiturn Worm
17	Multiturn Line Shaft
19	Multiturn Line Shaft Thrust Bearing
20	Line Shaft Bearing

(2) This shaft assembly may be serviced in the same general way as the main line shaft. The multiturn head must be removed before any work may be done on the shaft. The large worm requires a 5/64" x 1/2" taper Groov-pin and the small worm and thrust bearing require 1/16" x 3/8" taper Groov-pins.

9. PERFORMANCE STANDARDS.

Table 5-1 POWER INPUT REQUIREMENTS

<u>Type of Emission</u>	<u>Power Input</u>
CW	
CW (Stand-by)	
MCW	
MCW (Stand-by)	
VOICE (No Modulation)	
VOICE (90% Modulation)	
VOICE (Stand-by)	

NOTE

All of the above power input measurements were made with 115 volts input to the power unit and with power amplifier loaded to rated PA PLATE meter reading.

Table 5-2 TYPICAL AUDIO-FREQUENCY DATA

a. OVERALL AUDIO-FREQUENCY RESPONSE (EITHER CARBON OR DYNAMIC INPUT).

<u>Frequency</u>	<u>50% Mod.</u>	<u>90% Mod.</u>
100 cps	-7.6 db	-7.0 db
200 cps	-3.4 db	-2.8 db
300 cps	-2.2 db	-1.7 db
500 cps	-0.7 db	-0.4 db
1000 cps	0.0 db	0.0 db
2000 cps	-0.2 db	-0.3 db
3000 cps	-0.7 db	-0.9 db
4000 cps	-1.6 db	-1.8 db
5000 cps	-2.7 db	-3.2 db

NOTE

All of the above measurements made with input to microphone jack J-102.

b. AUDIO INPUT. - Input required for 90% Modulation at 1000 cps.

CARBON Input - 1.52 v required.

DYNAMIC Input - 16.0 mv required.

Ø Inclusion of this sign indicates information not available for the Preliminary Instruction Book. This information will be included in the Final Instruction Book.

c. NOISE LEVEL, - Below 100% Modulation with input at 1000 cps.

CARBON Input - -44 db.

DYNAMIC Input - -45 db.

d. AUDIO DISTORTION, - Distortion with 90% Modulation at 1000 cps.

CARBON Input - 4.5% Distortion.

DYNAMIC Input - -4.7% Distortion.

e. SIDETONE DISTORTION, - Distortion measured on output of SIDETONE at Position 5 with 90% Modulation at 1000 cps.

CARBON Input - -8.8% Distortion.

DYNAMIC Input - -8.9% Distortion.

f. SIDETONE OUTPUT.

Switch Position	Output		Load Impedance
	CW	MCW	
1	0.6 volt	0.75 volt	125 ohms
2	1.3 volt	1.6 volt	125 ohms
3	2.5 volts	3.0 volts	125 ohms
4	5.0 volts	6.0 volts	125 ohms
5	8.8 volts	10.5 volts	125 ohms
6	19.5 volts	23.5 volts	2000 ohms

NOTE

All of the above audio-frequency measurements were made with Control "A" in Position 2 at an RF output frequency of 3.0 mc, with 115 v input to the power unit and with power amplifier loaded to rated PA PLATE meter reading.

Table 5-3 MCW-CFI UNIT OUTPUT LEVEL

DB at SIDETONE jack J-104 of -52286-A Transmitter with MCW-CFI UNIT installed using 500 ohm 6 MW

"Zero" Ref. Type Meter across 125 ohms.

Sidetone OUTPUT Level switch on Position 5.

Freq.	Dial "G"	db	Freq.	Dial "G"	db	Freq.	Dial "G"	db
kc	Band 1		kc	Band 2 (Cont.)		kc	Band 3 (Cont.)	
200	393	+9.5	325	1557	+1	450	1732	+15
	936	Usable		1690	Usable	466-2/3	1909	Usable
225	1159	Usable	350	1941	+16	Band 4		
	1363	Usable	Band 3			450	00	+15
250	1729	+14	350	160	+16	475	272.5	
	1959	Usable		532	Usable	500	522	+16
Band 2			375	688	+3	525	742	
275	559	+0		832	Usable	550	942	+13.5
	762	Usable	400	1091	+15	575	1127	
300	1114	+15		1322	Usable	600	1305	+11
	1418	Usable	433-1/3	1534	Usable	625	1479	

10402

RESTRICTED

5-47

RESTRICTED

Section V
Paragraphs 9

Table 5-3 (Cont.)

Freq.	Dial "G"	db	Freq.	Dial "G"	db	Freq.	Dial "G"	db
ke	Band 4 (Cont.)		ke	Band 5 (Cont.)		ke	Band 6 (Cont.)	
650	1656	+11	950	1550	+4.5	1275	1097	+17
675	1848		975	1670	-10	1300	1179	+6-1/2
700	2084	+10	1000	1757	+7	1325	1259	+12
Band 5			1025	1939	-3	1350	1339	+6
675	1000		Band 6			1375	1417	+10
700	199	+15	1025	095	-10	1400	1494	+6
725	376		1050	222	+10-1/2	1450	1658	+12
750	537	+11	1075	340		1500	1832	+3-1/2
775	685		1100	450	+9			
800	823	+9	1125	555	+7			
825	954		1150	654	+9			
850	1079	+9	1175	749				
875	1199		1200	841	+9			
900	1316	+6	1225	929				
925	1433		1250	1014	+8			

Table 5-3 (Cont.)

Freq. kc	Dial "B"	db	Freq. kc	Dial "B"	db	Freq. kc	Dial "B"	db
2000	100	+10	2366-2/3	1455	Usable	2633-1/3	775	Usable
2023	223	Usable	2400	1578	+9	2650	826	Usable
2050	284			1704	Usable	2666-2/3	878	Usable
2066-2/3	346	Usable		1767	Usable	2700	979	+6.5
2100	469	+10.5		1832	Usable	2733-1/3	1081	Usable
2133-1/3	591	Usable	2500	1967	+8	2750	1132	Usable
2150	655	Usable	2400	60	+10	2766-2/3	1183	Not Good
2166-2/3	717	Usable	2433-1/3	162	Usable	2800	1284	+6.5
2200	841	+9	2450	213	Usable	2833-1/3	1385	Usable
2233-1/3	965	Usable	2466-2/3	263	Usable	2850	1436	Usable
2250	1026	Usable	2500	365.5	+9.5	2900	1589	+5.5
2267	1087	Usable	2533-1/3	468	Usable	2933-1/3	1694	Usable
2300	1209	+8.5	2550	518	Usable	2950	1746	Usable
2333-1/3	1332	Usable	2566-2/3	570	Usable	3000	1910	+4
2350	1393	Usable	2600	673	+7.0			

RESTRICTED

RESTRICTED

Section V
Paragraphs 9

Table 5-4

RESISTANCE MEASUREMENTS FROM VACUUM TUBE TERMINALS TO

GROUND AND

TYPICAL OPERATING VOLTAGES AND CURRENTS

All voltage readings taken at full power level with a supply voltage of 115 volts.


All voltage and resistance measured to ground.

Voltage readings in Column A taken with a 1000 ohm per volt voltmeter. Voltage readings in Column B taken with a 20,000 ohm per volt voltmeter.

For voltage measurements, unless otherwise noted, transmitter is adjusted for VOICE operation in the range 6000 kc to 7200 kc, key closed, no modulation.


For resistance measurements, allow one half hour to elapse with transmitter turned off. Keying relay, Audio, LFO, MCW-CFI, Remote Control and Power Unit disconnected. Tubes in place. EMISSION selector switch is in the MCW position, Control "A" on Position 7 and power level switch on OPERATE, unless otherwise noted. Key closed.

V-101 837




	PIN	VOLTAGE		MA	RESISTANCE
		A	B		
Filament	1	12	12		5.5
Filament	7	24	24		3
Cathode	6	14	14		inf
Grid 1	4	6.5**	8**		22,000
Grid 2	3	190	190	10	5000
Grid 3	5	0	0		0
Plate	C	395	400	30	6750
Shield	2	0	0		0

V-102 1625




Filament	1	12	12		4.5
Filament	7	24	24		3
Cathode	6	42	43		1000
Grid 1	4	-55**	-65**		100,050
Grid 2	3	300	320	6	26,750
Plate	C	395	400	35	6750
-----	2	0	0		inf
-----	5	-55**	-65**		100,000

V-103 1625




Filament	1	0	0		0
Filament	7	12	12		4.5
Cathode	6	63	65		1000
Grid 1	4	-165**	-175**		100,050
Grid 2	3	300	320	3.2	26,750
Plate	C	395	400	40	6750
-----	2	0	0		inf
-----	5	-165**	-175**		100,000

V-104 813




Filament	1	10	10		.5
Filament	7	0	0		0
Grid 1	4	-180**	-185**		20,300
Grid 2	3	395	400	40	inf
Grid 3	5	0	0		0
Plate	C	1285	1285	150	inf
-----	2	395	400		inf
-----	6	0	0		0

V-105 811



	PIN	VOLTAGE		MA	RESISTANCE
		A	B		
Filament	1	10	10		.5
Filament	4	16	16		1
Grid	3	10*	10*		inf
Plate	C	1285	1285	16.5	inf
-----	2	0	0		inf

V-106 811




Filament	1	22	22		1.5
Filament	4	16	16		1
Grid	3	16*	16*		inf
Plate	C	1285	1285	16.5	inf
-----	2	0	0		inf

V-201 12SJ7 #




Filament	2	0	0		0
Filament	7	12	12		5
Cathode	5	7	9		2200
Grid 1	4	0**	0**		4000
Grid 2	6	35	35	.2	inf
Grid 3	3	0	0		0
Plate	8	70	115	.6	inf
-----	1	0	0		0

V-202 6V6GT




Filament	2	18	18		5.5
Filament	7	12	12		5
Cathode	8	9.5	9.5		250
Grid 1	5	0**	0**		500,000
Grid 2	4	200	210	3	inf
Plate	3	190	195	30	inf

V-203 6V6GT




Filament	2	24	24		5.5
Filament	7	18	18		6
Cathode	8	10	10.5		250
Grid 1	5	0**	0**		100,000
Grid 2	4	200	210	3.5	inf
Plate	3	190	195	30	inf

V-401 1625 ##



	PIN	VOLTAGE		MA	RESISTANCE
		A	B		
Filament	1	0	0		0
Filament	7	12	12		inf
Cathode	6	19	19		inf
Grid 1	4	-15	-16		15,000
Grid 2	3	190	190	2	inf
Plate	C	395	400	50	inf
-----	2	0	0		inf
-----	5	19	19		inf

V-2201 12SL7GT




Filament	7	0	0		0
Filament	8	12	12		15
CFI CRYSTAL OSCILLATOR SECTION					
Cathode	6	0	0		0
Grid	4	-6**	-6**		150,000
Plate	5	90	115	2.5	inf
CFI TRIPLER SECTION					
Cathode	3	0	0		0
Grid	1	-10**	-17**		50,000
Plate	2	80	90	1.3	inf

V-2202 12SA7



Filament	2	12	12		15
Filament	7	0	0		0
Cathode	6	2	2		220
Grid 1	5	-2**	-4**		50,000
Grid 2 & 4	4	90	95	9	0
Grid 3	8	-6**	-10**		50,000
Grid 5	1	2	2		0
Plate	3	90	90	2.5	0

V-2203 12SL7GT



Filament	7	12	12		15
Filament	8	20	24		27
CFI DETECTOR SECTION					
Cathode	3	0	0		28
Grid	1	-1.5**	-2**		500,000
Plate	2	55	75	.25	inf
AUDIO OSCILLATOR SECTION					
Cathode	6	.1**	.1**		220
Grid	4	-1**	-1.5**		150,000
Plate	5	65	75	.5	67,000

Place power level switch in the CALIBRATE position and microphone selecting switch in the CARBON position.

* Since modulator Grid bias is obtained by utilizing the average voltage drop through the filaments of the modulator tubes, it is impractical to measure this value directly. Value shown is actually a filament voltage measurement. The effective value may be considered to be half the filament voltage actually supplied the filament of the tube.

Voltage and current measurements made with transmitter adjusted for 1000 kc with final amplifier at resonance under load. Resistance measurements made with Control "A" on 13 (LF).

** 100 mh RF choke used to isolate meter.

Table 5-5 VOLTAGE AND RESISTANCE TO GROUND FROM CONNECTOR TERMINALS

All voltage readings taken at full power level with a supply voltage of 115 volts.

Voltage readings in Column A taken with a 1000 ohm per volt voltmeter. Voltage readings in Column B taken with a 20,000 ohm per volt voltmeter.

For voltage measurements, unless otherwise noted, transmitter is adjusted for MCW operation, LOCAL control, in the range 6000 kc to 7200 kc, key closed.

For resistance measurements, allow one half hour to elapse with transmitter turned off. Keying relay, Audio, LFO, MCW-CFI, Remote Control and Power units disconnected. Tubes in place. EMISSION selector switch is in the MCW position, Control "A" on Position 1, Autotune positioned on CHANNEL 1, LOCAL-REMOTE switch on LOCAL position and power level switch on OPERATE unless otherwise noted. Microphone circuit selecting switch S-20P in the CARBON position. Key Closed.

<u>Connector</u>	<u>Term</u>	<u>Voltage</u>		<u>Meter Scale</u>	<u>Resistance</u>	
		A	B		Local	Remote #

HFO TERM STRIP

1	190	190	250	5000
2	24	24	50	3
3	12	12	50	5.5
4	14	14	50	inf

<u>Connector</u>	<u>Term</u>	<u>Voltage</u>		<u>Meter Scale</u>	<u>Resistance</u>	
		A	B		Local	Remote #
J-106	1	0	0		180	inf
	2	0	0		0	0
	3	0	0		0	0
	4	0	0		0	0
	5	0	0		0	0
	6	0	0		0	0
	7	0	0		0	0
	8	0	0		0	0
	9	0	0		0	0
	10	0	0		0	0
	11	0	0		0	0
	12	0	0		inf	180
	13	0	0		inf	0
	14	28	28		150	150
	15	0	0		inf	inf
	16				120	120
	17	0	0		inf	150
	18	0	0		0	0
	19	0	0		0	0
	20	23.5	23.5		inf	inf
	21	0	0		0	inf
	22	0	0		inf	0

Connector	Term	Voltage		Meter Scale	Resistance	
		A	B		Local	Remote #
	23	0	0		inf	inf
	24	0	0		inf	inf
	25	0	0		inf	inf
	26	0##			inf	inf
	27	10.5##			inf	inf

Connector	Term	Voltage		Meter Scale	Resistance	
		A	B			
J-107	1	0	0		0	
	2	0	0		0	
	3	0	0		inf	
J-108	1	395	400		6750	
	2	395	400		inf	
	3	28	28		3	
	4	28	28		3	
	5	0	0		0	
	6	28	28		1.5	
	7	0	0		0	
	8	0	0		0	
	9	395	400		inf	
	10	1285	1285		inf	

Connector	Term	Voltage		Meter Scale	Resistance		
		A	B				
J-111	1	13.5	13.5	50	0	T*	C**
		15**	15**	50	inf	inf	inf
	2	0	0		inf	inf	inf
	3	-.1	-.5	5	inf	inf	inf
		400**	415**	1000			
	4	0	0		inf	inf	inf
	5	390	400	1000	inf	inf	inf
		400**	415**	1000			
	6	0	0		0	0	0
	7	0	0		inf	4	inf
	8				3	3	3

Connector	Term	Voltage		Meter Scale	Resistance	
		A	B			
J-112	1	10	10	50	inf	
	2	10	10	50	.5	
	3	16	16	50	.5	
	4	16	16	50	inf	
	5	10.5##			inf	
	6	190	195	250	5000	
	7	24	24		3	
	8	0	0		0	
	9	0	0		0	
	10	23.5	23.5		inf	
	11	0	0		0	
	12	0	0		inf	

Connector	Term	Voltage		Meter Scale	Resistance
		A	B		
J-114	1	0	0		0
	2	12	12		5.5
	3	395	400		6750
	4	190	190		5000
	5	19	19		inf
	6	0	0		inf
J-115	1	300	320		26,750
	2	395	400		6750
	3	0	0		---
	4	28	28		3
	5	0	0		inf
	6	14	14		inf
	7	0	0		125
	8	14	14		inf
	9	24	24		3
	10	0	0		---
	11	395	400		6750
	12	300	320		26,750
J-116	1	0	0		inf
	2	28	28		153
	3	0	0		0
	4	0	0		0
	5	395	400		inf
	6	10.5##			inf
	7	0	0		inf
	8	10.5##			inf
	9	0	0		inf
	10	0	0		inf
	11	0	0		inf
	12	0	0		inf
	13	395	400		6750
	14	0	0		0
	15	28	28		3
P-101	1	300	320		inf
	2	395	400		inf
	3	0	0		---
	4	28	28		inf
	5	0	0		inf
	6	14	14		inf
	7	0	0		inf
	8	14	14		inf
	9	24	24		inf
	10	0	0		---
	11	395	400		inf
	12	300	320		inf

Connector	Term	Voltage		Meter Scale	Resistance
		A	B		
P-102					
	1	0	0		inf
	2	28	28		inf
	3	0	0		inf
	4	0	0		inf
	5	395	400		inf
	6	10.5###			inf
	7	0	0		inf
	8	10.5###			inf
	9	0	0		inf
	10	0	0		
	11	0	0		inf
	12	0	0		inf
	13	395	400		inf
	14	0	0		inf
	15	28	28		inf
P-201					
	1	10	10	50	inf
	2	10	10	50	inf
	3	16	16	50	inf
	4	16	16	50	inf
	5	10.5###			2 to 16
	6	190	195	250	inf
	7	24	24		24
	8	0	0		0
	9	0	0		0
	10	23.5	23.5		325
	11	0	0		0
	12	0	0		6.5
P-401					
	1	0	0		0
	2	12	12		28
	3	395	400		inf
	4	190	190		inf
	5	19	19		inf
	6	0	0		inf

LOCAL-REMOTE switch on REMOTE position for these readings.

Use 1,000 ohm per volt AC voltmeter sidetone switch on #5 (output of audio sidetone).

If receiver disabling circuit is used terminals 26 and 27 are equal.

* Turn power level switch to TUNE position for these readings.

** Turn power level switch to CALIBRATE position for these readings.

Table 5-6 RESISTANCE MEASUREMENTS ON ROTATING MACHINES

All resistance readings were made with all brushes removed from the machines.

a. AUTOTUNE MOTOR. - Fractional Type NY-818C-C direct current shunt wound motor 3.1 amps, 28 volts, 1/20 hp, 3900 rpm. Part No. 508 0818 33.

Resistance between commutator segments diametrically opposed = .83 ohms.

Resistance between adjacent commutator segments = .16 ohms (24 commutator segments).

Field resistance, F1 to F2 = 27.0 ohm (F1 grounded to motor frame).

b. LOW VOLTAGE DYNAMOTOR PART NO. 231 0028 00

(1) Resistance from any of the commutators to the dynamotor frame = infinite ohms.

Ø(2) Average resistance between adjacent segments on the 115 v commutator =

Ø(3) Average resistance between adjacent segments on the 28 v commutator =

Ø(4) Average resistance between adjacent segments on the 14 v commutator =

Ø(5) Field winding resistance =

c. HIGH VOLTAGE DYNAMOTOR PART NO. 231 0029 00

(1) Resistance from any of the commutators to the dynamotor frame = infinite ohms.

Ø(2) Average resistance between adjacent segments on the 115 v commutator =

Ø(3) Average resistance between adjacent segments on the 400 v commutator =

Ø(4) Average resistance between adjacent segments on the 750 v commutator =

Ø(5) Resistance of the field winding =

NOTE

A short or low resistance to ground from either terminal A1 or A2, with brushes removed and external wires disconnected, indicates a defective capacitor or brush holder.

A variation in resistance between adjacent commutator segments, with brushes removed indicates a defective armature.

Ø Inclusion of this sign indicates information not available for the Preliminary Book. This information will be included in the Final Instruction Book.

A low resistance or short to ground from the commutator, indicates a defective armature.

A large discrepancy in field resistance or a short from F2 to ground indicates a defective field winding.

A low resistance or short to ground from the input or output wires, with brushes removed, indicates a defective capacitor or brush holder.

A variation in resistance between adjacent segments on any commutator, with brushes removed, indicates a defective armature.

A low resistance or short to ground from any commutator, with brushes removed, indicates a defective armature.

A large discrepancy in shunt field resistance indicates a defective or shorted field winding.

10. TUBE COMPLEMENT.

Table 5-7 TUBE COMPLEMENT

<u>Tube Type</u>	<u>Quan.</u>	<u>Function</u>
837	1	HF Oscillator
1625	1	1st Frequency Multiplier
1625	1	2nd Frequency Multiplier
813	1	Power Amplifier
811	2	Modulators
12SJ7	1	Audio Amplifier
6V6GT	1	Audio Driver
6V6GT	1	Sidetone Amplifier
12SL7GT	1	Crystal Oscillator-Tripler
12SA7	1	Mixer
12SL7GT	1	Detector-Audio Osc.

NOTE:

Tube pin connections and typical operating voltages and currents may be found in Table 5-4.

WARNING

In order to obtain satisfactory tube life the following precautions must be taken:

Operate all tube filaments within $\pm 5\%$ of rated voltage.

Do not exceed rated plate current in any of the tubes during normal operation of the equipment.

When tuning, do not exceed rated plate current except for periods of short duration.

Failure to observe the above precautions may result in the destruction of the tubes.

ALL TUBES SUPPLIED WITH THE EQUIPMENT OR AS SPARES ON THE EQUIPMENT CONTRACT SHALL BE USED IN THE EQUIPMENT PRIOR TO EMPLOYMENT OF TUBES FROM GENERAL STOCK.

11. THE ADJUSTMENT AND THE REPLACEMENT OF PARTS OF COMMERCIAL ASSEMBLIES.

The following drawings and parts lists cover standard commercial assemblies for which replacement parts are obtainable. Ordering information is given such as to permit identification of any part which is subject to failure as a result of normal wear in service.

Because of special design the manufacturers of relays other than those listed below, consider it impractical to replace parts of these assemblies. If any of these units fail, a complete assembly should be ordered.

Adjustment data on the following items is included:

<u>Part Number (Symbol Desig.)</u>	<u>Function</u>
405 0009 00 (K-101) (Alternate) 405 2201 10	Autotune Motor Control Relay
410 0008 00 (K-102)	Keying Relay
410 1700 00 (K-103)	CW Emission Control Relay
410 1600 00 (K-104)	Voice Emission Control Relay
410 0010 00 (K-105)	Output Circuit Selecting Relay

a. GENERAL REQUIREMENTS FOR SATISFACTORY OPERATION.

- (1) All screws and nuts should be tight.
- (2) All relay assemblies should be securely mounted.
- (3) When replacing parts such as coils or contacts, the wires should have a little slack, but not enough to interfere with moving parts. All unnecessary solder should be removed and bare wire should be bent in such a manner that it will not touch adjacent metal parts.
- (4) When replacing armatures or contacts, the bushings and springs should be carefully aligned and checked for free operation.
- (5) When adjusting contact springs, the bends in the springs should be gradual rather than sharp bends or kinks.
- (6) Contacts should be carefully aligned and under no condition should the contacts be more than one-fourth of the diameter of the contacts out of alignment with respect to each other as gauged by eye.
- (7) The coils should measure within $\pm 5\%$ of the specified DC resistance.





Figure 5-13 NY-818C-C Autotune Motor Schematic



NOTE:
 ALTERNATE CONTACT ARRANGEMENT
 NORMALLY CLOSED STATIONARY CONTACT 4 MAY BE
 FOUND LOCATED IN POSITION (5) IN WHICH CASE
 IT WILL BE CONNECTED TO PI02 TERMINAL NO. 5.

Figure 5-14 Keying Relay (K-102) Contact Arrangement

NOTE

The resistance values of the windings are based upon a normal temperature of +20°C (+68°F). If the resistance is measured at a temperature other than this, corrections should be made for the difference in temperature.

(8) It is important that the relay contacts be kept free from corrosion and pits. The relays should be inspected regularly and if the contacts have become corroded a burnishing tool should be used to remove the corrosion.

(9) The armature should not make contact with the core.

b. RELAY ADJUSTMENT.

(1) 405 2201 00 (Alternate) (K-101)

The contact should be adjusted so that when the relay is in the unoperated position the spacing between the movable contact and the stationary contact is between .040 inch and .050 inch. The armature should be adjusted so that the spacing between the armature and the top edge of the field pole is .040 inch. The tension of the armature spring should be adjusted so that the armature back tension is 7 ounces. This relay should operate with a minimum of 18 volts DC and a maximum of 32 volts DC. The DC resistance of the coil, measured at +20°C (+68°F), should be 150 ohms.

(2) 410 0008 00 (K-102)

This relay has been provided with three adjusting screws. The two adjusting screws located on the side of the relay opposite the multi-terminal connector plugs, Item 20, figure 5-15 control the position and tension of the relay armature when the relay is unoperated. The lower adjusting screw determines the position of the armature and the upper screw determines the tension of the armature return spring. The tension of the armature return spring, as measured at the top of the bakelite strip should be between 23 ounces and 24 ounces.

To set the armature position, leave the relay in the unoperated condition and rotate the lower adjusting screw in a clockwise direction until the movable contacts just begin to lift from the fixed contacts. Then rotate the adjusting screw approximately one-half revolution in a counterclockwise direction. The movable contacts should rest firmly against the fixed contacts. The position of each fixed contact is adjustable and may be set by loosening the locking nut and rotating the contact. Contacts are numbered according to the terminal number of the plug to which they are connected. See figure 5-14. The contacts operate in the following sequence when the coil is energized: 2 and 12 open, 5 and 4 (or 3 and 5) open, vacuum contact S-116 open, Vacuum contact S-116 close, 4 and 7 close, 6 and 8 close, 3 and 9 close, and 5 and 13 close. The contacts operate in a reverse order when the coil is deenergized. Check the adjustment of the remaining fixed contacts by applying between 22 volts DC and 28 volts DC to the relay coil (terminals 14 and 15 on the multi-terminal connector plug, Item 20, figure 5-15) and observing the position of the movable contacts. The movable contacts should rest firmly against the corresponding fixed contact.

The contacts of the relay should be adjusted so that the gap between the movable contacts and the fixed contacts, when the relay is unoperated, is .035 inch. The relay will operate with a minimum of 18 volts DC applied to the coil but will only follow keying of eight impulses per second with this voltage. With 24 volts DC applied to the relay coil the armature will follow keying at 16 impulses per second. With 28 volts DC applied to the relay coil, the armature will follow keying of 35 words per minute. The maximum voltage that should be applied to the relay coil is 28 volts DC.

(3) 260 6010 00 (S-116)

This vacuum contact is mounted on relay 410 0008 00. The vacuum contact must be adjusted to operate properly when the relay 410 0008 00 is adjusted as described in the preceding paragraphs. A single adjusting screw near the multi-terminal connector plug permits the adjustment of the mounting yoke so that the movable contact operating arm will operate the arm to close the contact but will not apply enough pressure to damage the vacuum tube. To adjust the mounting yoke, loosen the studs, Item 17, figure 5-15, and with relay unoperated, rotate the adjusting screw, Item 16, in a direction that allows the movable contact within the vacuum tube to rest firmly against the fixed contact that is ordinarily connected to the RECEIVER terminal of the transmitter, that is, Item 10 on the relay drawing. When this adjustment has been completed, tighten the studs, Item 17, and apply voltage to the relay coil (Terminals 14 and 15 on the multi-terminal connector plug, Item 20) and, with the relay operated, check the position of the movable contact within the vacuum tube. The movable contact arm should rest firmly against the fixed contact that is ordinarily connected to the COND. terminal on the transmitter. The contact should be firm but the movable arm should not apply enough pressure to the fixed arm to endanger the vacuum seal. The contact pressure must not exceed 665 grams (23.4 oz.) measured at a point 3/4" from the diaphragm. If the movable contact is applying too much pressure to the fixed contact when the relay is operated, readjust the lower adjusting screw on the side of relay 410 0008 00, opposite the connector plug, to reduce the pressure.

(4) 410 1700 00 (K-103)

The contacts of this relay should be adjusted so that when the relay is unoperated the gap between the fixed contact and the movable contact, Item 17, figure 5-17, is between .045 inch and .050 inch. The gap between the armature and the front edge of the field piece should be 3/32 inch. The armature return spring, Item 8, should be adjusted so that the pressure against the top contacts when the relay is unoperated is between 75 and 80 grams. The pressure between the movable contacts and the fixed contacts when the relay is operated should be between 50 and 55 grams. The DC resistance of the coil is 125 ohms. The minimum voltage required for satisfactory operation is 18 volts DC. The voltage applied to the coil should never exceed 32 volts DC.

(5) 410 1600 00 (K-104)

The contacts should be adjusted so that the air gap between the movable contacts, Item 3, figure 5-16, and the fixed contacts, Item 9, is .030 inch. The armature return spring, Item 6, should be adjusted so that the pressure between the movable contacts and the upper fixed contacts is 50 grams. When the relay is operated the pressure between the movable contacts and the lower fixed contacts should be 70 grams. The air gap between the

field piece and the armature, as measured at the front edge of the field piece, should be .035 inch. The DC resistance of the coil measured at 68 degrees F. is 150 ohms. The relay should operate with a minimum of 18 volts DC and the voltage applied to the coil should never exceed 32 volts DC.





(6) 410 0010 (K-105)

The air gap between the armature contacts and the fixed contacts should be adjusted to .110 inch. The DC resistance of the coil is 60 ohms. The minimum voltage necessary for satisfactory operation is 22 volts DC. The maximum voltage that should be applied to the relay coil is 30 volts DC continuous operation.

PARTS LIST FOR 410 0008 00 KEYING RELAY (K-102)



(Guardian Type G-36427)

<u>Item</u>	<u>Qty.</u>	<u>Guardian Part No.</u>	<u>Description</u>
1	1	BR-599-A	Contact Mounting Bracket
2	1	2522-4	Solder Lug
3	1	SW-57-A	Adj. Contact Screw
4	2		#4 Split Lock Washers
5	2		4-40 x 3/8 Binder Head Mch. Screw
6	1		4-48 x 3/16 Hex. Nuts
7	2		4-40 x 3/16 Hex. Nuts
8	1	BU-110	Vacuum Tube Terminal
9	1	BM-161	Mounting Plate
10	1	BU-102	Vacuum Tube Terminal
11	1	CS-142	Adjusting Bracket Spring
12	1	CV-81	Tube End Cover
13	1	CV-94	Cover (Top)
14	1	N-19	Hex. Cap Nut
15	1	ST-157	Lever Rearing Stud
16	1	SW-54	Tube Adjusting Screw
17	2	SW-56	Adjustment Screw
18	2	SW-60	Insert Screw
19	1	X-380	Rubber Cushion
20	1	X-382	Contact Plug
21	1	X-399	Vacuum Switch
22	6		4-40 x 3/8 Flat Head Mach. Screw
23	6		4-48 x 1/16 Bristol Head
24	1		#8 External Shakeproof Washer
25	1	CVA-20	Side Cover Assembly
26	1	CVL-21	Side Cover Assembly
27	1	X-386	Terminal Block Assembly
28	1	X-381	Collar & Arm Assembly
29	1	BRA-97	Stop Bracket Assembly
30	1	BRA-98	Tube Adjusting Bracket Assembly
31	1	FIA-85	Coil & Armature Assembly
32	2		6-32 x 1/4" Binder Head Mach. Screw
33	1		8-32 x 5/8" Binder Head Mach. Screw
34	6		4-40 x 5/16" Binder Head Mach. Screw
35	6		4-40 x 3/16" Binder Head Mach. Screw
36	2		4-40 x 3/16" Flat Head Mach. Screw
37	1		2-56 x 3/8" Round Head Mach. Screw



GUARDIAN ELECTRIC MFG. CO. CHICAGO ILLINOIS	COLLINS RADIO COMPANY CEDAR RAPIDS IOWA
GUARDIAN ELEC.CO. PART NUMBER: G-32877	COLLINS PART NO: 410N19A

Figure 5-15 Keying Relay (K-102) Assembly



GUARDIAN ELECTRIC COMPANY CHICAGO, ILLINOIS	COLLINS RADIO COMPANY CEDAR RAPIDS, IOWA
GUARDIAN ELECT. NUMBER: G-32734	COLLINS PART NO: 410N16

Figure 5-16 Voice Relay (K-104) Assembly



PARTS LIST FOR 410 1600 OO VOICE EMISSION CONTROL RELAY (K-104)

(Guardian Type G-32734)

<u>Item</u>	<u>Qty.</u>	<u>Guardian Part No.</u>	<u>Description</u>
1	1	BR-611-B	Relay Mounting Bracket
2	1	FI-48	Field Piece
3	1	ARM-319	Armature Assembly
4	1	X-241	Counterweight
5	1	BR-487	Armature Retainer Bracket
6	1	CS-120	Armature Spring
7	1	US-128-C	Armature Stop Bracket
8	1	BB1-74	Contact Block & Spring Assem
9	1	BB1-61	Contact Bracket & Block Assem
10	1	BB-141	Spacer Block
11	1	FP-23	Coil Insulator
12	1	SP-220-W	Coil Assembly
13	1		8-32 x 3/8 Binder Head Screw
14	1		8-32 x 3/16 Binder Head Screw
15	2		6-32 x 3/8 Binder Head Screw
16	2		6-32 x 7/16 Binder Head Screw
17	1		2-56 x 3/16 Round Head Screw
18	2		2-56 x 5/8 Round Head Screw
19	2		2-56 x 3/16 Hex Nuts




PARTS LIST FOR 410 1700 00 CW EMISSION CONTROL RELAY (K-103)
(Guardian Type G-32811)

<u>Item</u>	<u>Qty.</u>	<u>Guardian Part No.</u>	<u>Description</u>
1	1	BRA-101	Mounting Bracket Assembly
2	1	FI-64	Field Piece
3	1	BR-487A	Armature Retainer Bracket
4	2	SPA-85	Spacers
5	1	CXA-829	A-2 Contact Assembly
6	1	B-179	Contact Spring Mounting Bar
7	1	X-389	Counterweight
8	1	CS-122	Armature Spring
9	1	BBA-76	Contact Bracket & Block Assem
10	1	FW-16	Bakelite Washer
11	1	MW-47-D	Plain Brass Washer
12	2	FW-90	Cushion Washers
13	4	FW-91	Cushion Washers
14	1	CS-18-J	Separator Plate
15	1	CS-21	Lug Adapter
16	1	ARA-424	Armature Assembly
17	2	CX-350	Contact Spring Assembly
18	1	BRA-99-A	Armature Bracket Assembly
19	1	SP-222-W	Coil Assembly
20	1		8-32 x 1/2 Binder Head Screw
21	1		8-32 x 3/16 Binder Head Screw
22	2		#8 Shakeproof
23	2		5-40 x 5/8 Fillister Head Screw
24	2		#5 Split Lock Washers
25	2		2-56 x 7/8 Round Head Screw
26	2		2-56 x 3/8 Round Head Screw
27	2		2-56 x 7/16 Round Head Screw
28	6		#2 Split Lock Washers
29	4		2-56 x 3/16 Hex. Nuts
30	2		2-56 x 1/4 Special Mach. Screw
31	2		2-56 x 1/4 Round Head Screw



GUARDIAN ELECTRIC COMPANY CHICAGO, ILLINOIS	COLLINS RADIO COMPANY CEDAR RAPIDS, IOWA
GUARDIAN ELECT. NUMBER: G-32811	COLLINS PART NO: 410 1700 00

Figure 5-17 CW Relay (K-103) Assembly



FRACTIONAL MOTORS COMPANY CHICAGO, ILLINOIS	COLLINS RADIO COMPANY CEDAR RAPIDS, IOWA
FRACTIONAL NUMBER: F-800	COLLINS PART NO. NY-818C-C

Figure 5-18 Autotune Motor Assembly

NY-818 C-C MOTOR 1/20 H.P. 28 VOLT DC. 3900 RPM.
 MANUFACTURED BY
 THE FRACTIONAL MOTORS CO CHICAGO, ILLINOIS




Figure 5-19 Autotune Motor Photograph

PARTS LIST FOR 508 0818 33 AUTOTUNE MOTOR (E-101)

(Fractional Type NY-818C-C)

<u>Item</u>	<u>Quantity</u>	<u>Fractional Part Number</u>	<u>Description</u>
1	1	F-860	Armature Assembly (without bearing)
2	1	F-875	Field Coil
3	1	F-801	Brush Holder End Bracket
4	1	F-803	Motor Yoke
5	1	F-802	End Bracket
6	2	N.D.77037	Ball Bearing
7	1	S-102	Bearing Load Spring
8	2	F-840	Capacitor
9	2	F-812	Capacitor Bracket
10	2	F-815	Motor Stud
11	2	F-811	Brush Assembly
12	2	F-830	Brush Holder
13	2	F-825	Brush Holder Cap
14	2	SCR-209	Brush Holder Screw
15	4	SCR-206	Pole Screw
16	2	SCR-210	Terminal Screws
17	2	F-805	Pole Key
18	2	F-870	Pole Piece Assembly
19	2	SCR-208	Capacitor Bracket Screw
20	1	F-821	Terminal Base
	4	F-820	Terminals

SECTION VI

PARTS AND SPARE PARTS LISTS

1. INTRODUCTION.

Component parts of the equipment are identified by means of symbol designations. Wherever it is required to reference a component, the same symbol designation is used. Thus, a part appearing on a simplified schematic, a complete circuit diagram, a wiring diagram, photograph or layout drawing, will always be identified by means of the same symbol designation. In addition, each component part is stamped with its corresponding symbol designation. These symbol designations identify the various component parts which appear in the following parts lists.

Only one Symbol Designation is assigned to cover component parts with multiple electrical or mechanical characteristics. However, since at times it is desirable to identify certain electrical or mechanical sections of these component parts, suffix letters are added when necessary. Thus, C-121A, C-121B, and C-121C identify each section of triple capacitor C-121.)

The alphabetical portion of symbol designations have been selected from the following list in accordance with the classification of the component parts concerned.

- (A) Structural parts, panels, frames, castings, etc.
- (B) Motors and other prime movers, self-synchronous motors, etc.
- (C) Capacitors of all types.
- (CR) Dry disc rectifiers.
- (D) Dynamotors.
- (E) Miscellaneous electrical parts: Insulators, knobs, brushes, etc.
- (F) Fuses.
- (G) Generators, exciters, etc.
- (H) Hardware, screws, bolts, studs, pins, snapslides, etc.
- (I) Indicating devices (except meters and thermometers), pilot lamps, etc.
- (J) Jacks and receptacles (stationary).
- (K) Contactors, relays, circuit breakers, etc.
- (L) Inductors, RF, and AF.

- (M) Meters of all types, gauges, thermometers, etc.
- (N) Nameplates, dials, charts, etc.
- (O) Mechanical parts, bearings, shafts, couplings, gears, ferrules, flexible shafts, housings, etc.
- (P) Plugs.
- (Q) Diaphragms, (microphone, telephone, projector, etc.).
- (R) Resistors, fixed and variable, potentiometers, etc.
- (S) Switches, interlocks, thermostats.
- (T) Transformers, RF, and AF, and power.
- (U) Hydraulic parts.
- (V) Vacuum and gaseous discharge tubes.
- (W) Wires, interconnecting cables, without plugs.
- (X) Sockets.
- (Y) Mechanical oscillators, crystals, magnetstriction tubes, etc.
- (Z) Filters, IF transformers, compound tuned circuit assemblies, etc., in a common container.

The numerical portion of the symbol designation has been assigned to identify the component part with a particular major unit assembly. The numerical portion of symbol designations begin with 101 for the first component part in each class (i.e., component part in each alphabetical class as described above) and run consecutively for the remaining component parts in a particular class. A different numerical series of numbers is used for each major unit of the equipment. The series 101 to 199 is reserved for the first major unit. The series 201 to 299 is reserved for the second major unit. The series 301 to 399 is reserved for the third major unit. In this manner, each major unit of the entire equipment is identified with a series of numerals to be used for the designation of component parts.

The List of Major Units, Table 6-1, gives a complete list of symbol designation numbers in correlation with the major units.

Table 6-1 LIST OF MAJOR UNITS

<u>Quan.</u>	<u>Symbol Group</u>	<u>Navy Type Designation</u>	<u>Collins Type Number</u>	<u>Name of Major Unit</u>	<u>Assembly Dwg. No.</u>
1	101-199 201-299 401-499 2201-2299	-52286-A	17H-2	Radio Transmitter	K351E
1	901-999	COL-23410	314N-2	Remote Control Unit	K1104C
1	Y-2201	CR-2-B/U (200 KC)	-----	200 KC Quartz Crystal	-----
1	3001-3099	COL-47505	180H-4	Antenna Load Coil	
1	1101-1199	COL-481628	195D-1	Antenna Shunt Capacitor	1370B
1	1501-1599	-----	65X-7	Control Cable (Power Unit to Transmitter)	500 1496 OOD
1	1601-1699	-----	65X-8	Power Cable (Power Unit Transmitter)	500 1497 OOD
1	1701-1799	-----	65X-9	Power Cable (Transmitter to Load Coil)	500 1498 OOD
1	1901-1999	COL-211624	413D-4	Dynamotor Assembly Power Unit	502 3869 005
1	2301-2399	-----	65X-10	Control Cable (Power Unit to Control Box)	500 4474 OOD

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

RADIO TRANSMITTER ASSEMBLY

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
101-199 201-299 401-499 2201-2299		NAVY MODEL -52286-A RADIO TRANSMITTER, Includes one complete set of tubes; Low Frequency Oscillator, Audio Unit and MCW-CFI Unit.			830	17H-2		500 9366 00E
<u>MOTORS</u>								
B-101	Autotune Motor	MOTOR, 1/20 hp 28 v DC Nominal 20 v Min 32 v Max			1740	NY-818C-C		508 0818 33
B-101	Brush for Autotune motor B-101	BRUSH, + & - Motor Brush			1740	F-811		234 1302 00
B-101	Brush holder for Autotune motor B-101	HOLDER, brush			1740			234 0066 00
B-101	Brush holder cap for Autotune motor B-101	CAP, brush holder			1740	F-825		234 0060 00
B-101	Bearing for Autotune motor B-101	BEARING			3330	77037		309 1220 00
<u>CAPACITORS</u>								
C-101	HFO Grid Padding	CAPACITOR, .000185 mf $\pm 1\%$ 1000 TV	-481677-1		700	841-001)
C-102)	Temperature	CAPACITOR, Set of three matched ceramic capacitors packaged as a set. To be connected in the equipment in accordance with the circuit at the left to provide 413 mmf $\pm 1\%$ 1000 TV, Temperature Coefficient minus 48 Parts per Million per $^{\circ}\text{C}$ $\pm 5\%$	-481678-1		700	Type 841)
C-103)	Compensating)
C-104))
10424)

TABLE 6-2

PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>CAPACITORS (Cont.)</u>								
C-105	HFO Cathode Bypass	CAPACITOR, .005 mf $\pm 5\%$ 2500 TV	-482938-B5		911 4030	4LST HLST		925 2502 10
*C-106	HFO Filament Bypass	CAPACITOR, .006 mf $\pm 20\%$ 1000 TV	-48410-B20		911 4030	4LS HLS-10		910 2603 40
*C-107	HFO Screen Bypass	CAPACITOR, .002 mf $\pm 20\%$ 1000 TV	-48789-B20		911 4030	4LS HLS-10		910 2203 40
C-108	1st Mult Grid	CAPACITOR, .0005 mf $\pm 10\%$ 1500 TV	-481409-B10		4030	BE-15		915 3505 20
C-109	1st Mult Cathode Bypass	CAPACITOR, .002 mf $\pm 20\%$ 1500 TV	-482111-B20		4030	BE-15		915 2205 40
C-110	1st Mult Screen Supply Filter	CAPACITOR, .002 mf $\pm 20\%$ 1500 TV	-482111-B20		4030	BE-15		915 2205 40
C-111	1st Mult Pl Tuning	CAPACITOR, 6 Section Variable Ceramic	-481679		700	828-003		917 6130 00
C-112	2nd Mult Grid Coupling	CAPACITOR, .00025 mf $\pm 10\%$ 1500 TV	-482947-10		4030	BE-15		915 3255 20
C-113	2nd Mult Cathode Bypass	CAPACITOR, .002 mf $\pm 20\%$ 1500 TV	-482111-B20		4030	BE-15		915 2205 40
C-114	2nd Mult Scr. Supply Filt	CAPACITOR, .002 mf $\pm 20\%$ 1500 TV	-482111-B20		4030	BE-15		915 2205 40
C-115	2nd Mult Pl Tuning	CAPACITOR, 6 Section Variable Ceramic	-481679		700	828-003		917 6130 00
C-116	Power Amplr Grid Coupling	CAPACITOR, .0005 mf $\pm 10\%$ 1500 TV	-481409-B10		4030	BE-15		915 3505 20
*C-117	Power Amplr Filament Bypass	CAPACITOR, .006 mf $\pm 20\%$ 1000 TV	-48410-B20		911 4030	4LS HLS-10		910 2603 40
C-118	Power Amplr Pl Blocking	CAPACITOR, .002 mf $\pm 20\%$ 7500 TV			911 4030			975 2201 40
*C-119	Power Amplr Screen Supply Filter	CAPACITOR, .002 mf $\pm 20\%$ 2500 TV	-48789-B20		911 4030	4LS HLS-25		925 2203 40
C-120A	Power Amplr Pl Supply Filter	CAPACITOR, .002 mf $\pm 20\%$ 5000 TV	-48789-B20		911 4030	4LS HLS-50		950 2203 40
C-120B	Power Amplr Pl Supply Filter	CAPACITOR, .002 mf $\pm 20\%$ 5000 TV	-48789-B20		911 4030	4LS HLS-50		950 2203 40

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>CAPACITORS (Cont.)</u>							
C-121	C121A,C121B,C121C	CAPACITOR, 3-0.1 mf $\pm 20\%$ 600 WV	-48713-B20		911 4210	DYRT-6111 3XDRTW6-.1	956 0001 00
C-121A	Transient Suppressing	CAPACITOR, Section of C-121					
C-121B	Transient Suppressing	CAPACITOR, Section of C-121					
C-121C	Transient Suppressing	CAPACITOR, Section of C-121					
C-122	C-122A, C-122B						
C-122A	Power Amplr Pl Tank Padding	CAPACITOR, .00005 mf $\pm 10\%$ Ceramic	-481690-10		700	850-002	913 4503 20
C-122B	Power Amplr Pl Tank Padding	CAPACITOR, .00005 mf $\pm 10\%$ Ceramic	-481690-10		700	850-002	913 4503 20
C-124	C-124A, C-124B, C-124C						
C-124A	PA Pl Tank Padding	CAPACITOR, .000067 mf $\pm 5\%$ Ceramic	-481691-5		700	850-003	913 4673 10
C-124B	PA Pl Tank Padding	CAPACITOR, .000067 mf $\pm 5\%$ Ceramic	-481691-5		700	850-003	913 4673 10
C-124C	PA Pl Tank Padding	CAPACITOR, .000067 mf $\pm 5\%$ Ceramic	-481691-5		700	850-003	913 4673 10
C-125	PA Pl Tuning	CAPACITOR, Rotor Assembly Stator Assembly			830 830	GA-1342B GA-1308A	571 1342 20 571 1308 10
C-126	Low Voltage Supply Filter	CAPACITOR, 2.0 mf $\pm 20\%$ 600 WV	-48777-20		911 1640 1881	KG-3020 A7649 67X2	930 7824 00
C-127	2nd Mult Pl Supply Filter	CAPACITOR, .006 mf $\pm 20\%$ 1500 TV	-481411-B20		4030	BE-15	915 2605 40
C-128	Pl Filter	CAPACITOR, .002 mf $\pm 20\%$ 7500 TV			911		975 2201 40
C-129	PA Pl Tank Padding	CAPACITOR, .00005 mf $\pm 10\%$ Ceramic	-481690-10		700	850-002	913 4503 20
C-130	PA Pl Tank Padding	CAPACITOR, .000025 mf $\pm 10\%$ Ceramic	-481689-10		700	850-001	913 4253 20
C-131	1st Mult Pl Supply Filter	CAPACITOR, .0008 mf $\pm 5\%$ 1000 TV	-482948-5		4030	BE-10	910 3805 10
C-132 10426	Motor B-101 Spark Suppr	CAPACITOR, .004 mf $\pm 20\%$ 1200 TV	-482939-B20		911	3WS	909 2406 40

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Designation Code	Mfr's Designation	Spec. Tol. or Mod.	Contractor's Drawing and Part Number
<u>JACKS AND RECEPTACLES (Cont.)</u>								
J-115	Multiplier Unit Conn Plug Receptacle	RECEPTACLE, 12 Terminal Octal Style Cable Plug Connector	-49935		200	70-12		369 1700 00
J-116	K-102 & S-116 Connector Strip	RECEPTACLE, 15 Terminal Chassis Mtg Connector	-49936		2580	300		366 2150 00
J-117	LOAD COIL Connector	RECEPTACLE, 1/2" Push Type			1320			372 2110 00
J-118	ANT CAPACITOR Connector	RECEPTACLE, 5/8" Push Type Binding Post			1320			372 2210 00
<u>RELAYS</u>								
K-101	Relay, Autotune Motor Control	RELAY, 3 Pole Double Throw Circuit Control Relay	-29513		2050	G-33177		405 2201 10
	Alternate		-29604		1820			405 0009 00
K-102	Relay, Keying	RELAY, DT Multi-contact	-29605		2050			410 0008 00
	Alternate		-29606		4310			410 0011 00
K-103	Relay, CW Emission	RELAY, 2 PDT 1 PST Circuit Control Relay	-29607		2050	G-32811		410 1700 00
K-104	Relay, VOICE emission	RELAY, 2 PDT Circuit Control Relay	-29609		2050	G-32734		410 1600 00
K-104	Alternate		-29610		284	R-22-B		410 0013 00
K-105	Relay, Output Circuit Selecting	RELAY, 1 PDT, 1 PNO & 1 PNC with Mycalex Insulation 18-32 v DC	-29519		2050	G-36427		410 0010 00
<u>INDUCTORS AND REACTORS</u>								
L-101	HFO Tuning Ind	INDUCTOR, Special precision wound Ind			830	GA-671D		571 0671 40
L-102	HFO Cathode RF Choke	CHOKE, Multi-section 2.5 uh 0.125 amp 50 ohm	-47903		3220	R100-U		240 5300 00
L-103	HFO Screen RF Choke	CHOKE, Multi-section 2.5 uh 0.125 amp 50 ohm	-47903		3220	R100-U		240 5300 00
L-104	HFO P1 Feed Choke	CHOKE, 2 Section 208 mh \pm 1% 2 ohm duo-lateral wound	-47904		4335			240 6000 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

<u>Symbol Designation</u>	<u>Function</u>	<u>Description</u>	<u>Navy or JAN Type Number</u>	<u>Navy Drawing or Spec.</u>	<u>Mfr's Mfr. Designation Code</u>	<u>Spcl. Tol or Mod.</u>	<u>Contractor's Drawing and Part Number</u>
<u>SWITCHES (Cont.)</u>							
S-105	Metered Circuit Selector	SWITCH, 2 circuit 3 position non-shorting			3410		259 1391 00
S-106	Power Level Selector	SWITCH, 5 circuit 3 position shorting			3410		259 0004 00
S-107	LOCAL-REMOTE	SWITCH, 4 circuit 2 position shorting			3410		259 1411 00
S-108	Autotune CHANNEL Selecting	SWITCH, 1 circuit 12 position non-shorting			3410		259 1401 00
S-109	Autotune Circuit Seeking	SWITCH, 1 circuit 12 position shorting			3410	25851 DH-1	259 1371 00
S-110	EMISSION SELECTOR	SWITCH, 3 circuit 4 position shorting			3410		259 1362 00
S-111	Rear Limit section	SWITCH, SP 1 NC 1 NO Contact Leaf	-24573		830	GA-1557B	571 1557 20
S-112	Forward Limit section	SWITCH, SP 1 NC Contact Leaf	-24569		830	Y-983A	508 0983 10
S-113	S-113A, S-113B, S-113C, S-113D, S-113E, S-113F, S-113G, S-113H	SWITCH, Mult Section sw Assembly			830	186P-1	571 0085 30
S-113A	PA Tank Padding Cap Connector	SWITCH, Single Contact sw Arm Assembly			830	GA-1105A	571 1105 10
S-113B	PA Tuning Cap Connector	SWITCH, Double Contact sw Arm Assembly			830	GI-1083A	571 1083 10
S-113C	PA Tank Ind Tap Selecting	SWITCH, Single Contact sw Arm Assembly			830	GA-1109A	571 1074 10
S-113D	Keying Interlock	SWITCH, Single Pole, 1 NO Contact Leaf	-24571		830	Y-1048A	508 1048 10
S-113E	Padding Ind Connector	SWITCH, Single Contact sw Arm Assembly			830	GA-1082A	571 1082 10
S-113F	Padding Cap Connector	SWITCH, Single Contact Arm Assembly			830	GA-1079A	571 1079 10
S-113G	Padding Cap Connector	SWITCH, Single Contact Arm Assembly			830	GA-1079A	571 1079 10

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Code	Mfr's Designation	Spcl. Tol or Mod.	Contractor's Drawing and Part Number
<u>SOCKETS</u>								
X-101	For V-101	SOCKET, 7 terminal base Iso	-49366		2570	227		220 5730 00
X-102	For V-102	SOCKET, 7 terminal base Iso	-49366		2570	227		220 5730 00
X-103	For V-103	SOCKET, 7 terminal base Iso	-49366		2570	227		220 5730 00
X-104	For V-104	SOCKET, 7 terminal "Jumbo" Wafer	-49384		2570	237		220 5711 00
X-105	Alternate For V-105	SOCKET, 4 prong low loss Ceramic	-49362		2570	224		220 5450 00
X-106	For V-106	SOCKET, 4 prong low loss Ceramic	-49362		2570	224		220 5450 00

PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

AUDIO AMPLIFIER UNIT

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation	Contractor's Drawing and Part Number
<u>CAPACITORS</u>						
C-201	Microphone Supply Filter	CAPACITOR, 20 mf +100% -10% 100 WV	-482956		911 RVL-10051-1 3030 SPO-38482	183 3310 00
C-202	Audio Amplr Cathode Bypass	CAPACITOR, 20 mf +100% -10% 100 WV	-482956		911 RVL-10051-1 3030 SPO-38482	183 3310 00
*C-203	Audio Amplr Screen Bypass	CAPACITOR, .05 mf +20% -10% 600 WV	-482936-10		1640 3030	930 0010 00
C-204	Audio Driver Grid Coupling	CAPACITOR, .006 mf ±10% 1500 TV	-481411-B10		4030 BE-15	915 2605 20
C-205	Audio Amplr Pl Decoupling	CAPACITOR, .001 mf ±10% 1500 TV	-481410-B10		4030 BE-15	915 2105 20
C-206	Audio Driver Output Coupling	CAPACITOR, .003 mf ±10% 1500 TV	-482949-10		4030 BE-15	915 2305 20
C-207	Audio Driver Cathode Bypass	CAPACITOR, 20 mf +100% -10% 100 WV	-482956		911 RVL-10051-1 3030 SPO-38482	183 3310 00
C-208	Sidetone Amplr Cathode Coupling	CAPACITOR, 20 mf +100% -10% 100 WV	-482956		911 RVL-10051-1 3030 SPO-38482	183 3310 00
C-209	Mod Grid RF Bypass	CAPACITOR, .01 mf +60% -20% 400 WV			ASA: CN35A103	934 0003 00
	Alternate		-481506-B20 or CM-35B-103M		911 IWL	909 0002 00
C-210	Mod Grid RF Bypass	CAPACITOR, .01 mf +60% -20% 400 WV			ASA: CN35A103	934 0003 00
	Alternate		-481506-B20 or CM-35B-103M		911 IWL	909 0002 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN JAN Type Number	Navy Drawing or Spec.	Mfr's Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>PLUGS</u>								
P-201	Audio Amplr Unit Connector	PLUG, 12 terminal Connector Chassis Mtg.	-49662		2580	P-312-AB		365 2120 00
<u>RESISTORS</u>								
R-201	Microphone Current Limiting	RESISTOR, 220 ohm $\pm 5\%$ 1 w	-63291-221		90			703 1220 10
R-202	Microphone Current Limiting	RESISTOR, 100 ohm $\pm 5\%$ 1 w	-63291-101		90			703 1100 10
R-203	Microphone Output Coupl Alternate	RESISTOR, 15,000 ohm $\pm 5\%$ $\frac{1}{2}$ w	-63355-153		2360	BT1/2-Navy		729 5154 10 745 1134 00
R-204	T-201 Pri Terminating	RESISTOR, 220 ohm $\pm 5\%$ 1 w	-63291-221		90			703 1220 10
R-205	Audio Amplr Grid	RESISTOR, 470,000 ohm $\pm 10\%$ $\frac{1}{2}$ w	-63360-474		2360	BT1/2-Navy		729 5470 42
R-206	Audio Amplr Filament Current Dividing	RESISTOR, 42 ohm $\pm 10\%$ 10 w	-633225-10		3450	BD		710 1422 20
R-207	Audio Amplr Cath	RESISTOR, 2200 ohm $\pm 10\%$ 1 w	-63288-222		2360	BW1-Navy		708 0002 00
R-208	Audio Amplr Screen Decoupling	RESISTOR, 1 meg $\pm 10\%$ $\frac{1}{2}$ w	-63360-105		2360	BT1/2-Navy		729 0008 00
R-209	Audio Amplr Pl Decoupling	RESISTOR, 220,000 ohm $\pm 10\%$ $\frac{1}{2}$ w	-63360-224		2360	BT1/2-Navy		729 5220 42
R-210	Audio Driver Grid	RESISTOR, 470,000 ohm $\pm 10\%$ $\frac{1}{2}$ w	-63360-474		2360	BT1/2-Navy		729 5470 42
R-211	Sidetone Amplr Grid	RESISTOR, 100,000 ohm $\pm 5\%$ $\frac{1}{2}$ w	-63355-104		2360	BT1/2-Navy		729 5100 41
R-212	Sidetone Amplr Grid Coupling	RESISTOR, 470,000 ohm $\pm 5\%$ $\frac{1}{2}$ w	-63355-474		2360	BT1/2-Navy		729 5470 41
R-213	Audio Driver Pl Decoupling	RESISTOR, 750,000 ohm $\pm 5\%$ $\frac{1}{2}$ w	-63355-754		2360	BT1/2-Navy		729 5750 41
R-214	Audio Driver Cathode	RESISTOR, 250 ohm $\pm 10\%$ 1 w	-63703-251		2360	BW1-Navy		708 2505 12
R-215	Sidetone Amplr Cathode	RESISTOR, 250 ohm $\pm 10\%$ 1 w	-63703-251		2360	BW1-Navy		708 2505-12
R-216	T-201 Primary Terminal	RESISTOR, 220 ohm $\pm 10\%$ $\frac{1}{2}$ w	-63678-221		2360	BW1/2		707 2205 20

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Contractor's Drawing and Part Number
<u>SWITCHES</u>						
S-201	Microphone Circuit Selector Switch	SWITCH, DPDT Toggle 1 amp 250 v DC or 3 amp 125 v DC	-24003-A		2160 24003	266 0004 00
S-202	Sidetone Amplr Output Control switch	SWITCH, 1 P 6 Position 1 Section Shorting			3030	259 1490 00
<u>TRANSFORMERS</u>						
T-201	Audio Amplr Input Coupling	TRANSFORMER, Pri: 75 ohm Secd: 125,000 ohm 100-5000 cps 1000 TV	-302036		780 7823	677 2590 00
T-202	Audio Driver Output Coupling	TRANSFORMER, Pri: 5000 ohm 30 ma 300-4000 cps Secd: 2000 ohm 1500 TV	-302037		780 7821	677 2530 00
T-203	Sidetone Amplr Output Coupling	TRANSFORMER, Pri: 4000 ohm 30 ma 1500 TV 300-4000 cps Secd: Tapped 200 ohm 50 ohm 12.5 ohm 3.12 ohm 0.78 ohm 0.195 ohm 1500 TV	-302038		780 10082	677 2540 00
<u>VACUUM TUBES</u>						
V-201	Audio Amplr	TUBE, Triple-Grid Amplr	12SJ7		* * 12SJ7	254 0254 00
V-202	Audio Driver	TUBE, Beam Pentode	6V6GT		* * 6V6GT	254 0200 00
V-203	Sidetone Amplr	TUBE, Beam Pentode	6V6GT		* * 6V6GT	254 0200 00
<u>SOCKETS</u>						
X-201	For V-201	SOCKET, 8 terminal octal tube	-49423		200 88-8	220 1850 00
X-202	For V-202	SOCKET, 8 terminal octal tube	-49423		200 88-8	220 1850 00
X-203	For V-203	SOCKET, 8 terminal octal tube	-49423		200 88-8	220 1850 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

LOW FREQUENCY OSCILLATOR UNIT

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Code	Mfr's Designation	Spcl. Tol or Mod.	Contractor's Drawing and Part Number
401-499		LOW FREQUENCY OSCILLATOR: Includes tube. Frequency range 200 kc to 1500 kc.			830	33W-1		520 0219 00
<u>CAPACITORS</u>								
C-401	LFO Screen Bypass	CAPACITOR, .002 mf $\pm 20\%$ 1500 TV	-482111-B20		4030	BE-15		915 2205 40
C-402	LFO Cathode Coupling	CAPACITOR, .00005 mf $\pm 20\%$ 900 TV	-481279-B20		4030	Type "C"		909 4503 40
C-403	LFO Feedback Coupling	CAPACITOR, .0003 mf $\pm 2\%$ 1000 TV	-481685-2		911	1 WL		
C-404	LFO Feedback Coupling	CAPACITOR, Set of three matched ceramic capacitors packaged as a set. To be connected in parallel to provide 0.00083 mf $\pm 1/2\%$ temp compensation neg., 150 parts per million per degree C $+15 -87$ PPM/ $^{\circ}$ C 500 WV	-481688-1/2		700	816-035		913 3307 00
					700	816-044		913 1100 00
C-405A	LFO Cathode Bypass	CAPACITOR, .002 mf $\pm 1\%$ 500 TV	-482951-F10		4170			912 2208 60
C-405B	LFO Cathode Bypass	CAPACITOR, .002 mf $\pm 1\%$ 500 TV	-482951-F10		4170			912 2208 60
*C-405C	LFO Cathode Bypass	CAPACITOR, .01 mf $\pm 1\%$ 500 TV	-481385-F1		4170			912 2108 60
C-406	LFO Cathode Coupling	CAPACITOR, .000125 mf $\pm 2\%$ 1000 TV	-481684-2		700	814-106		913 0001 00
C-407	LFO Grid Padding	CAPACITOR, Set of three matched capacitors packaged as a set. To be connected in parallel to provide 0.00088 mf $\pm 1\%$ temp compensation neg., 32 parts per million per degrees C $+15 -61$ PPM/ $^{\circ}$ C 500 WV	-481687-1		700	816-043		913 1200 00
C-408A	LFO Grid Padding	CAPACITOR, .0015 mf $\pm 1\%$ 1000 TV	-482952-F1		4170			912 2158 60

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Design- Code nation	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>CAPACITORS (Cont.)</u>							
C-408B	LFO Grid Padding	CAPACITOR, .00015 mf $\pm 2\%$ 1000 TV	-481682		700 810-250		913 0017 00
C-408C	LFO Grid Padding	CAPACITOR, .0003 mf $\pm 2\%$ 1000 TV	-481685-2		700 816-035		913 3307 00
C-409A	LFO Grid Padding	CAPACITOR, .002 mf $\pm 1\%$ 500 TV	-482951-F10		4170		912 2208 60
*C-409B	LFO Grid Padding	CAPACITOR, .0004 mf $\pm 1\%$ 500 TV	-481319-F1		4170		912 3408 60
C-409C	LFO Grid Padding	CAPACITOR, .00035 mf $\pm 2\%$ 1000 TV	-481686-2		700 816-041		913 0014 00
C-410A	LFO Grid Padding	CAPACITOR, .00025 mf $\pm 2\%$ 1000 TV	-481683-2		700 810-290		913 0024 00
C-410B	LFO Grid Padding	CAPACITOR, .002 mf $\pm 1\%$ 500 TV	-482951-F10		4170		912 2208 60
C-410C	LFO Grid Padding	CAPACITOR, .002 mf $\pm 1\%$ 500 TV	-482951-F10		4170		912 2208 60
C-410D	LFO Grid Padding	CAPACITOR, .0015 mf $\pm 1\%$ 1000 TV	-482952-F1		4170		912 2158 60
C-411	C-411A, C-411B, C-411C, C-411D, C-411E	CAPACITOR, 5 Section Variable Ceramic	-481680		700 826-003		917 5110 00
C-411A	C-410 Trimmer	CAPACITOR, Section of C-411					
C-411B	C-406 Trimmer	CAPACITOR, Section of C-411					
C-411C	C-409 Trimmer	CAPACITOR, Section of C-411					
C-411D	C-408 Trimmer	CAPACITOR, Section of C-411					
C-411E	C-407 Trimmer	CAPACITOR, Section of C-411					
C-412	LFO Grid Coupling	CAPACITOR, .0003 mf $\pm 2\%$ 1000 TV	-481685-2		700 816-035		913 3307 00

MISCELLANEOUS ELECTRICAL PARTS

E-401	LFO HV Feedthru	BUSHING INSERT, 3/16" x 5/8"	-61152		700		190 2932 00
E-402	LFO P1 Lead Standoff	CYL STANDOFF, 3/8" x 1/2"	-61415		2410	395-L-1/2	190 2329 00

INDUCTORS AND REACTORS

L-401	LFO Grid Tuning Inductor	INDUCTOR, 45 turns close wound 48-38 litz wire			830	GA-1259C	571 1259 30
L-402	LFO P1 Feed Choke	CHOKE, 8 mh 0.125 amp 70 ohm	-47908		3090		240 4100 00
L-403	LFO Cathode Choke	CHOKE, Multi-section 2.5 uh 0.125 amp 50 ohm	-47903		3220	R100-U	240 5300 00
10440					70		

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Code	Mfr's Designation	Spec. Tol. or Mod.	Contractor's Drawing and Part Number
<u>PLUGS</u>								
P-401	LFO Connector Plug	PLUG, 6 Terminal Connector Chassis Mtg.			2580	Type 300		365 2060 00
<u>RESISTORS</u>								
R-401	LFO Grid	RESISTOR, 15,000 ohm $\pm 10\%$ 1 w			2360	BT1-Navy		729 7154 20
<u>SWITCHES</u>								
S-401	LFO Freq Range SW	SWITCH, Rotor Assembly			830	GA-1021A		571 1021 10
S-401		SWITCH, Stator Assembly			830	GA-1544B		571 1544 20
<u>VACUUM TUBES</u>								
V-401	LFO	TUBE, Type 1625 Beam Pentode	1625		* *	1625		254 0458 00
<u>SOCKETS</u>								
X-401	For V-401	SOCKET, 7 Term base Iso	CEJ-49366		2570	227		220 5730 00

* * Standard Vacuum Tubes are supplied by numerous well known manufacturers.

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spec. Tol or Mod.	Contractor's Drawing and Part Number
<u>CAPACITORS</u>							
C-2201	Calibration Oscillator Tripler Pl Coupling	CAPACITOR, .006 mf +60% -20% 600 WV			911 ASA: CN35A602		934 0002 00
C-2202	Calibration Oscillator Tripler Grid Coupling	CAPACITOR, .006 mf +60% -20% 600 WV			911 ASA: CN35A602		934 0002 00
C-2203	Calibration Oscillator Mixer Grid Coupling	CAPACITOR, .006 mf +60% -20% 600 WV			911 ASA: CN35A602		934 0002 00
C-2204	Calibration Oscillator Detector Grid Coupling	CAPACITOR, 200 mmf +5% 1000 TV			4170 ASA: CM20B201-J		935 0118 00
C-2205	Calibration Oscillator Input HFO	CAPACITOR, 10 mmf +10% 1000 TV	-48710-B10		911 5WS 4030 KS 4210 MO 30 1468		909 4107 52
C-2206	Calibration Oscillator Input LFO	CAPACITOR, 10 mmf +10% 1000 TV	-48710-B10		911 5WS 4030 KS 4210 MO 30 1468		909 4107 52
*C-2207	Calibration Oscillator Pl Decoupling	CAPACITOR, .05 mf +10% -10% 600 WV	-482936-10		1640		930 0010 00
*C-2208	Calibration Oscillator Mixer Screen Decoupling	CAPACITOR, .05 mf +10% -10% 600 WV	-482936-10		1640		930 0010 00
*C-2209	Calibration Oscillator Output Coupling	CAPACITOR, .05 mf +10% -10% 600 WV	-482936-10		1640		930 0010 00
*C-2210	Audio Oscillator Grid Tank	CAPACITOR, .05 mf +10% -10% 600 WV	-482936-10		1640		930 0010 00
C-2211	HV Supply Filter	CAPACITOR, .5 mf +20% 600 WV	-481223-20		911 DYN-6050 4210 XDR6-.5 1640 A7178		956 0006 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

<u>Symbol Designation</u>	<u>Function</u>	<u>Description</u>	<u>Navy or JAN Type Number</u>	<u>Navy Drawing or Spec.</u>	<u>Mfr's Mfr. Code</u>	<u>Designation</u>	<u>Contractor's Drawing and Part Number</u>
<u>CAPACITORS (Cont.)</u>							
C-2212	C-2212A,C-2212B	CAPACITOR, 2-.1 mf $\pm 20\%$ 600 WV	-48312-B		911	DYRT	956 4016 40
C-2212A	Audio Oscillator Blocking	CAPACITOR, Section of C-2212	*CP50B1-F104KK				
C-2212B	Audio Oscillator Tank Tuning	CAPACITOR, Section of C-2212					
C-2212	Alternate						961 5036 40
C-2213	Oscillator Feedback	CAPACITOR, 30 mmf $\pm 5\%$ 500 WV	CM 20C300-M			ASA: CM20C300	935 0144 00
C-2213	Alternate		-481327-C5 *CM20C300J		911	5R	912 4303 10
C-2214	RF Bypass	CAPACITOR, .005 mf $\pm 5\%$ 1000 TV				ASA: CM35B512	935 2105 00
	Alternate					ASA: CM40B512	935 3035 00
<u>INDUCTORS</u>							
L-2201	Audio Oscillator Grid Tank Inductor	INDUCTOR, .25 hy 1000 cps & .1 mf cap	-302095		780	7822	678 2470 00
<u>PLUGS</u>							
P-2201	MCW-CFI Unit Connector Plug	PLUG, 8 term connector			2580	300	365 0002 00
<u>RESISTORS</u>							
R-2201	Audio Oscillator Output Control	RESISTOR, 2-15 ohm WW Rheostat	-633249		4975		381 9010 00
R-2202	Calibration Oscillator P1 Decoupling	RESISTOR, 100,000 ohm $\pm 10\%$ 1/2 w	-63360-104		2360	BT1/2-Navy	729 5100 42
10443							

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>RESISTORS (Cont.)</u>							
R-2203	Calibration Oscillator Tripler Grid	RESISTOR, 47,000 ohm $\pm 10\%$ 1/2 w	-63360-473		2360 BT1/2-Navy		729 5474 20
R-2203	Alternate						745 1156 00
R-2204	Audio Oscillator Grid Coupling	RESISTOR, 150,000 ohm $\pm 10\%$ 1/2 w	-63360-154		2360 BT1/2-Navy		729 5150 42
R-2204	Alternate						745 1171 00
R-2205	Calibration Oscillator Mixer Injection Grid	RESISTOR, 47,000 ohm $\pm 10\%$ 1/2 w	-63360-473		2360 BT1/2-Navy		729 5474 20
R-2205	Alternate						745 1156 00
R-2206	Calibration Oscillator Mixer Control Grid	RESISTOR, 47,000 ohm $\pm 10\%$ 1/2 w	-63360-473		2360 BT1/2-Navy		729 5474 20
R-2206	Alternate						745 1156 00
R-2207	Calibration Oscillator Mixer Filament Dropping	RESISTOR, 85 ohm $\pm 2-1/2\%$ 10 w	-632958-2-1/2		3450		710 0003 00
R-2208	Calibration Oscillator Pl Decoupling	RESISTOR, 33,000 ohm $\pm 10\%$ 1/2 w	-63360-333		2360 BT1/2-Navy		729 5334 20
R-2208	Alternate						745 1149 00
R-2209	Calibration Oscillator Screen Dropping	RESISTOR, 15,000 ohm $\pm 10\%$ 1 w	-63288-153		2360 BT1-Navy		729 7154 20
R-2209	Alternate						745 3135 00
R-2210	Calibration Oscillator HV Dropping	RESISTOR, 15,000 ohm $\pm 10\%$ 10 w	-633182-10		3450		710 0010 00
R-2211	Audio Oscillator HV Dropping	RESISTOR, 220,000 ohm $\pm 10\%$ 1 w	-63288-224		2360 BT1-Navy		729 7220 42
R-2211	Alternate						745 3184 00
R-2212A	Audio Oscillator HV Bleeder	RESISTOR, 100,000 ohm $\pm 10\%$ 1/2 w	-63360-104		2360 BT1/2-Navy		729 5100 42
R-2212A	Alternate						745 1170 00
R-2212B	Audio Oscillator HV Bleeder	RESISTOR, 220,000 ohm $\pm 10\%$ 1/2 w	-63360-224		2360 BT1/2-Navy		729 5220 42
R-2212B	Alternate						745 1184 00

10444

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>RESISTORS (Cont.)</u>							
R-2213	Calibration Oscillator Detector Grid	RESISTOR, 470,000 ohm $\pm 10\%$ 1/2 w	-63360-474		2360 BT1/2-Navy		729 5470 42
R-2213	Alternate						745 1198 00
R-2214	Calibration Oscillator Detector P1 Decoupling	RESISTOR, 470,000 ohm $\pm 10\%$ 1/2 w	-63360-474		2360 BT1/2-Navy		729 5470 42
R-2214	Alternate						745 1198 00
R-2215	Audio Oscillator Output Loading	RESISTOR, 2200 ohm $\pm 5\%$ 1/2 w	-63355-222		2360 BT1/2-Navy		729 5220 01
R-2215	Alternate						745 1099 00
R-2216	Calibration Oscillator Grid	RESISTOR, 150,000 ohm $\pm 10\%$ 1/2 w	-63360-154		2360 BT1/2-Navy		729 5150 42
*R-2217	Calibration Oscillator Mixer Cathode	RESISTOR, 220 ohm $\pm 20\%$ 1/2 w	-63678-221		2360 BW1/2		707 2205 40
	Alternate		-63288-221				729 0001 00
	Alternate						708 2205 40
<u>VACUUM TUBES</u>							
V-2201	Calibration Oscillator Crystal Oscillator- Tripler	TUBE, Dual Triode 12SL7GT			* * 12SL7GT		254 0258 00
V-2202	Calibration Oscillator Mixer	TUBE, Pent Convert 12SA7, 12SA7GT/G			* * 12SA7 12SA7GT/G		254 0248 00
V-2203	Calibration Oscillator Detector-Audio Osc.	TUBE, Dual Triode 12SL7GT			* * 12SL7GT		254 0258 00
<u>SOCKETS</u>							
X-2201	For V-2201	SOCKET, 8 Terminal Octal Tube	-49423		200 88-8		220 1850 00
X-2202	For V-2202	SOCKET, 8 Terminal Octal Tube	-49423		200 88-8		220 1850 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>SOCKETS (Cont.)</u>							
X-2203	For V-2203	SOCKET, 8 Terminal Octal Tube	-49423		200 88-8		220 1850 00
X-2204	For Y-2201	SOCKET, 2 Terminal Crystal	-49951		9816		292 0012 00
<u>QUARTZ CRYSTALS</u>							
Y-2201	Calibration Oscillator Quartz Crystal	QUARTZ CRYSTAL, Mounted in Holder	CR-2-B/U (200 kc)		4870		291 0002 00
<u>TUNED CIRCUIT ASSEMBLIES</u>							
Z-2201	Z-2201A, Z-2201B	TUNED CIRCUIT, Coil Assembly	-47923		70		278 0001 00
Z-2201A	Calibration Oscillator Crystal Oscillator	TUNED CIRCUIT, Section of Z-2201					
Z-2201B	Calibration Oscillator Detector Cathode Tank	TUNED CIRCUIT, Section of Z-2201					
Z-2202	Z-2202A, Z-2202B	TUNED CIRCUIT, Assembly Coil	-47911		70		278 0002 00
Z-2202A	Calibration Oscillator Tripler Pl Tank	TUNED CIRCUIT, Section of Z-2202					
Z-2202B	Calibration Oscillator Mixer Tank	TUNED CIRCUIT, Section of Z-2202					

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

<u>Symbol Designation</u>	<u>Function</u>	<u>Description</u>	<u>Navy or JAN Type Number</u>	<u>Navy Drawing or Spec.</u>	<u>Mfr's Mfr. Designation Code</u>	<u>Spcl. Tol or Mod.</u>	<u>Contractor's Drawing and Part Number</u>
<u>COMPLETE UNIT ASSEMBLIES</u>							
		ASSEMBLY, MCW-CFI Unit			830	8Q-2	500 4587 005
		ASSEMBLY, Audio Unit			830	26S-1	500 7620 005
		ASSEMBLY, Multiplier Unit			830	318E-1	500 3149 004
		ASSEMBLY, HFO Unit ***			830	33X-1	500 4473 005
		ASSEMBLY, Singleturn Autotune Unit "D" (Includes Wick Lubricator Assem)			830	96J-1	571 0737 30
		ASSEMBLY, Singleturn Autotune Unit "C" (Includes Wick Lubricator Assem)			830	96J-2	572 0737 30
		ASSEMBLY, Singleturn Autotune Unit "E" (Includes Wick Lubricator Assem)			830	96J-3	573 0737 30
		ASSEMBLY, Singleturn Autotune Unit "A" (Includes Wick Lubricator Assem.)			830	96J-4	571 0738 30
<u>MISCELLANEOUS</u>							
		MANUAL, Operating (Calibration Book)			830		520 9111 00
		FERRULE, Conduit			200		019 2034 00
		COUPLING, Conduit			630		019 2050 00
		CAP, Protective			630	RWK-59A1	371 1069 00
		KNOB, HFO Dial			830		507 5524 00
		DIAL, HFO Counter			830		507 5527 00
		KNOB, Dial Lock and Fiducial			830		507 5531 00
		KNOB, Variometer Dial			830		507 5586 00
		SLUG, HFO Tuning			830		507 5719 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>MISCELLANEOUS (Cont.)</u>								
		KNOB, Capacitor Dial			830			507 5796 00
		SLUG, Multiplier Tuning			830			507 6192 00
		KNOBS, Bar			830			571 1765 20
		KNOB, Multiplier Dial			830			508 1069 20
		KNOB, Network Switch Dial			830			508 1072 20
		SCREW, 6-40 x 1/8 set			500			328 0019 00
Alternate								328 0002 00
		SCREW, 4-48 x 1/8 set			500			328 0001 00
		SCREW, 8-36 x 1/8 set			500			328 0020 00
Alternate								328 0003 00
		SCREW, 8-36 x 1/4 set			500			328 0022 00
Alternate								328 0004 00
		SCREW, 4-40 x 1/2" Long			3580			343 0137 00
		SPACER, 3/4" x 3/8" Switch			830			500 0019 00A
		SPACER, 3/4" x 3/8" Switch			830			500 0020 00A
		SPACER, 3/4" x 3/8" Switch			830			500 0021 00A
		SCREW, Special			830			507 5762 00
		SCREW, Special			830			500 2704 001
		SCREW, 8-32 thd 2-3/8" Special			3580			330 4210 00
		SCREW, 8-32 thd 2-1/2" Special						344 0105 00
		COUPLER, 1/2" Spline			830			500 2729 001
		COUPLER, 1-1/32" Spline			830			500 2730 001
		GROMMET, 1-9/16" Neoprene			880	4757		201 1250 00
		GROMMET, 3/8" Neoprene			2850	905		201 1060 00
		GROMMET, 9/16" Neoprene			2850	913		201 1090 00
		GROMMET, 1/4" Neoprene			2850	901		201 1040 00
		CLIP, Grid			3220	12		301 1001 00
		CLIP, Grid			3220	24		301 6000 00
		KNOB, SIDETONE SW			830			507 5866 00
		WRENCH, External Spanner			830			507 5733 00
		WRENCH, Internal Spanner			830			507 5734 00

PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Designation Code	Spec. Tol or Mod.	Contractor's Drawing and Part Number
<u>MISCELLANEOUS (Cont.)</u>							
		WRENCH, #10 Bristo					024 9710 00
		WRENCH, #8 Bristo					024 0019 00
		WRENCH, #6 Bristo					024 9730 00
		WRENCH, #4 Bristo					024 2900 00
		SCREW DRIVER, #1 Phillips					024 3000 00
		SCREW DRIVER, #2 Phillips					024 3100 00
		SCREW DRIVER, .070" shank Jewelers			4296	5550	024 0015 00
		GAUGE, FEELER .005"			830		500 9135 001
		RIGHT TRACK, Shock Mounting					500 4279 00B
		LEFT TRACK, Shock Mounting					500 4278 00B
<u>MISCELLANEOUS AUTOTUNE PARTS</u>							
		CRANK, Autotune			830		571 1149 10
		SHAFT, Main Line			830		507 5512 00
		WORM, Small			830		500 6679 001
		WORM, Large			830		507 5519 00
		BEARING, Line Shaft			830		507 5724 00
		ARM, Positioning Switch Drive			830		571 0881 10
		CHAIN, Autotune Drive (Includes Wick Lubricator Assem)			830		507 5603 00
		SPROCKET, Motor			830		507 5602 00
		SPROCKET, Line Shaft			830		507 5514 00
		WICK LUBRICATOR, Autotune Singleturn Unit			830		500 4630 001
		WICK LUBRICATOR Autotune Multiturn Unit			830		500 4644 001
		WICK LUBRICATOR, Autotune Chain Drive			830		500 4635 001

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

NAVY TYPE COL-23410 REMOTE CONTROL UNIT

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Mfr's Mfr. Designation Code	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
--------------------	----------	-------------	-------------------------	-----------------------	-----------------------------	-----------------------------	--------------------	--------------------------------------

MISCELLANEOUS ELECTRICAL PARTS

E-901	Pilot Light Mounting	MOUNTING, pilot light, polarized ruby jewel		AN-QQ-S-91	1200	80		262 1270 00
-------	----------------------	---	--	------------	------	----	--	-------------

PILOT LAMPS

I-901	Pilot Lamp	LAMP, 28 v 0.17 amp T3-1/4 bulb, bayonet base			1888	Mazda #313		262 3270 00
-------	------------	---	--	--	------	------------	--	-------------

JACKS AND RECEPTACLES

J-901	Headphone Jack	JACK, Single circuit, for 1/4" plug	-49025A		3030	SC1A		358 1040 00
J-902	Audio Input Connector	TERMINAL STRIP, 2 terminal			2040			
J-903	Microphone Jack	JACK, three circuit for 3/16" plug	-49039		830	SC2AB		500 2218 002
J-904	Telegraph Key Jack	JACK, single circuit, for 1/4" plug	-49025A		3030	SC1A		358 1040 00
					2040			

PLUGS

P-901	Control Cable Connector	CONNECTOR, 27 terminal wall mounting, 10 amp contacts	-49946		630	NK-27-32SL		371 4050 00
-------	-------------------------	---	--------	--	-----	------------	--	-------------

RESISTORS

*R-901 10450	Headphone Series Resist- or	RESISTOR, 1800 ohm $\pm 20\%$ 1 watt	-63288-182		2360	BT1-Navy		729 7180 04
-----------------	--------------------------------	--------------------------------------	------------	--	------	----------	--	-------------

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

<u>Symbol Designation</u>	<u>Function</u>	<u>Description</u>	<u>Navy or JAN Type Number</u>	<u>Navy Drawing or Spec.</u>	<u>Mfr's Designation Code</u>	<u>Spcl. Tol. or Mod.</u>	<u>Contractor's Drawing and Part Number</u>
<u>RESISTORS (Cont.)</u>							
R-902	Volume Control	ATTENUATOR, Bridged T pad, 500 ohm, metalized	-631874 pot plus two -RC21BE511M Resistors		2360 9680-8791		380 2010 00
<u>SWITCHES</u>							
S-901	Phones-Speaker Switch	SWITCH, Toggle, DPDT, 3 amp " 125 v	-24003		2160 20905-GH		266 1030 00
S-901	Alternate Channel Selector Switch	SWITCH, Single circuit, non-shorting, 11 position one deck			3410		266 0002 00 259 1421 00
S-903	Emission Selector Switch	SWITCH, three circuit, shorting, four position, two deck			3410		259 1361 00
<u>TRANSFORMERS</u> (See figure 7-75 for Winding Data)							
T-901	Speaker Coupling Transformer	TRANSFORMER, 500 ohm Line to six ohm voice coil			2525		667 7051 00
<u>LOUD SPEAKER</u>							
LS-901	Loud Speaker	SPEAKER, 5" PM, 6 ohm voice coil	-49437		2525 S2482		271 2200 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

NAVY TYPE -481628 ANTENNA SHUNT CAPACITOR

<u>Symbol Designation</u>	<u>Function</u>	<u>Description</u>	<u>Navy or JAN Type Number</u>	<u>Navy Drawing or Spec.</u>	<u>Mfr's Mfr. Designation Code</u>	<u>Spec. Tol. or Mod.</u>	<u>Contractor's Drawing and Part Number</u>
---------------------------	-----------------	--------------------	--------------------------------	------------------------------	------------------------------------	---------------------------	---

CAPACITORS

C-1101	Antenna Shunt Capacitor	CAPACITOR, 25 mmf $\pm 10\%$ 10 kv test	-482977-10		30 1860-201 4210 XYA-10-425		914 1762 00
C-1102	Antenna Shunt Capacitor	CAPACITOR, 25 mmf $\pm 10\%$ 10 kv test	-482977-10		30 1860-201 4210 XYA-10-425		914 1762 00
C-1103	Antenna Shunt Capacitor	CAPACITOR, 25 mmf $\pm 10\%$ 10 kv test	-482977-10		30 1860-201 4210 XYA-10-425		914 1762 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

65X-7 CONTROL CABLE (500 1496 OOD)
(Power Unit to transmitter)

<u>Symbol Designation</u>	<u>Function</u>	<u>Description</u>	<u>Navy or JAN Type Number</u>	<u>Navy Drawing or Spec.</u>	<u>Mfr's Mfr. Designation Code</u>	<u>Spcl. Tol. or Mod.</u>	<u>Contractor's Drawing and Part Number</u>
<u>PLUGS</u>							
P-1501	Cable Connector Plug	CONNECTOR, 27 terminal 90° plug female			630 NK-27-23-11/16		371 4060 00
P-1502	Cable Connector Plug	CONNECTOR, 27 terminal straight plug male			630 FNK-27-22C-11/16		371 4049 00
<u>CABLES</u>							
W-1501	Connecting Cable	MULTI-CONDUCTOR CABLE, 27 conductors all #22 ga			360		424 2710 00

TABLE 6-2
 PARTS LIST BY SYMBOL DESIGNATION
 FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

65X-8 POWER CABLE (500 1497 OGD)
 (Power Unit to Transmitter)

<u>Symbol Designation</u>	<u>Function</u>	<u>Description</u>	<u>Navy or JAN Type Number</u>	<u>Navy Drawing or Spec.</u>	<u>Mfr's Code</u>	<u>Mfr's Designation</u>	<u>Spcl. Tol. or Mod.</u>	<u>Contractor's Drawing and Part Number</u>
<u>PLUGS</u>								
P-1601	Cable Connector Plug	CONNECTOR, 10 terminal straight	U-7/U		630	FK10-21-9/16		371 5140 00
P-1602	Cable Connector Plug	CONNECTOR, 10 terminal 90° plug	U-9/U		630	RFK-10-24C-9/16		371 5129 00
<u>CABLES</u>								
W-1601	Connecting Cable	MULTI-CONDUCTOR CABLE, two #14, one #18 and seven #22 ga			360			424 1010 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

65X-9 POWER CABLE (500 1498 00C)
(Transmitter to Load Coil)

<u>Symbol Designation</u>	<u>Function</u>	<u>Description</u>	<u>Navy or JAN Type Number</u>	<u>Navy Drawing or Spec.</u>	<u>Mfr's Mfr. Designation Code</u>	<u>Spcl. Tol. or Mod.</u>	<u>Contractor's Drawing and Part Number</u>
<u>MISCELLANEOUS ELECTRICAL PARTS</u>							
E-1701	Reducer Bushing	BUSHING, clamp reducer from 7/16" to .280"			630 P		371 1110 00
E-1702	Reducer Bushing	BUSHING, clamp reducer from 7/16" to .280"			630 P		371 1110 00
<u>PLUGS</u>							
P-1701	Cable Connector Plug	CONNECTOR, 3 terminal 90° plug			630 FNK-27-22C-11/16		371 1090 00
P-1702	Cable Connector Plug	CONNECTOR, 3 terminal straight plug			630 RWK-C3-22C 7/16		371 1109 00
<u>CABLES</u>							
W-1701	Connecting Cable	Two Conductor shielded CABLE, #20 AWG			#8422		425 0250 00

PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

NAVY TYPE COL-211624 POWER UNIT

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>CAPACITORS</u>							
C-1901	Audio Coupling Capacitor	CAPACITOR, paper, 2.0 mf $\pm 20\%$ 400 WV	-48403-B20		911		954 2484 00
C-1901	Alternate	CAPACITOR, paper, 2.0 mf +40 -15%, 600 WV	CP53BLFF205				961 4062 00
C-1901	Alternate	CAPACITOR, paper, 2.0 mf +40 -15%, 600 WV	CP50BLFF205				961 4070 00
C-1901	Alternate	CAPACITOR, paper, 2.0 mf $\pm 20\%$, 400 WV	-48403-B20		911		954 2444 00
C-1902	Spark Suppressor	CAPACITOR, paper, 2.0 mf $\pm 20\%$, 400 WV	-48403-B20		911		954 2484 00
C-1902	Alternate	CAPACITOR, paper, 2.0 mf +40 -15%, 600 WV	CP53BLFF205				961 4062 00
C-1902	Alternate	CAPACITOR, paper, 2.0 mf +40 -15%, 600 WV	CP50BLFF205				961 4070 00
C-1902	Alternate	CAPACITOR, paper, 2.0 mf $\pm 20\%$, 400 WV	-48403-B20		911		954 2444 00
C-1903	LV Filter	CAPACITOR, paper, 8 mf $\pm 20\%$, 800 WV	-482935-20		911	KG-U- 4080	930 1940 00
C-1904	LV Filter	CAPACITOR, paper, 8 mf $\pm 20\%$, 800 WV	-482935-20		911	KG-U- 4080	930 1940 00
C-1905	HV Filter	CAPACITOR, paper, 4 mf $\pm 20\%$, 2000 WV	-481417-20		911	TJU- 20040	930 4040 00
C-1905	Alternate	CAPACITOR, paper, 4 mf +20% -10%, 2000 WV	CP70ELFJ405V				962 4013 00
C-1906	HV Filter	CAPACITOR, paper, 4 mf $\pm 20\%$, 2000 WV	-481417-20		911	TJU- 20040	930 4040 00
C-1906	Alternate	CAPACITOR, paper, 4 mf +20% -10%, 2000 WV	CP70ELFJ405V				962 4013 00

PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Designation Code	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>CAPACITORS (Cont.)</u>							
C-1907	C-1907A,C-1907B	DUAL CAPACITOR, paper 0.1/0.1 mf $\pm 20\%$, 600 WV	-48312-B20		911 4250	DYRT 2527-9	956 4016 40
C-1907A	LV Noise Filter	Part of C-1907					
C-1907B	LV Noise Filter	Part of C-1907					
C-1907	Alternate	DUAL CAPACITOR, 0.1/0.1 mf +40 -15%, 600 WV	CP51B4FF104				961 5038 00
C-1908	C-1908A, C-1908B	DUAL CAPACITOR, paper 0.1/0.1 mf $\pm 20\%$, 600 WV	-48312-B20		911 4250	DYRT 2527-9	956 4016 40
C-1908A	HV Noise Filter	Part of C-1908					
C-1908B	HV Noise Filter	Part of C-1908					
C-1908	Alternate	DUAL CAPACITOR, 0.1/0.1 mf +40 -15%, 600 WV	CP51B4FF104				961 5038 00
C-1909	Spark Filter	CAPACITOR, paper, 2.0 mf $\pm 20\%$, 400 WV	-48403-B20		911		954 2484 00
C-1909	Alternate	CAPACITOR, paper, 2.0 mf +40 -15%, 600 WV	CP53B1FF205				961 4062 00
C-1909	Alternate	CAPACITOR, paper, 2.0 mf +40 -15%, 600 WV	CP50B1FF205				961 4070 00
C-1909	Alternate	CAPACITOR, paper, 2.0 mf $\pm 20\%$, 400 WV	-48403-B20		911		954 2444 00
C-1910	Dynamotor Input Noise Filter	CAPACITOR, mica, 0.01 mf $\pm 20\%$, 500 WV	-48643-A20		911 4030	4L H-10	910 1107 40
C-1911	LV Noise Filter	CAPACITOR, paper, 0.1 mf $\pm 20\%$, 600 WV	-48197-C20		4250 911 4210		956 2018 40
C-1911	Alternate	CAPACITOR, paper, 0.1 mf $\pm 10\%$, 600 WV	CP50B1FF104K				961 4018 00
C-1912	HV Output Noise Filter	CAPACITOR, paper, 0.1 mf $\pm 20\%$, 1500 WV			911 4250	DYR- 15010	930 0012 00
C-1913	Dynamotor Input Noise Filter	CAPACITOR, Mica, 0.01 mf $\pm 20\%$, 500 WV	-48643-A20		911 4030	4L H-10	910 1107 40
10457							

PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spcl. Tol or Mod.	Contractor's Drawing and Part Number
CAPACITORS (Cont.)							
C-1914	28 v Output Noise Filter	CAPACITOR, mica, 0.01 mf $\pm 20\%$ 500 WV	-48643-A20		911 4L 4030 H-10		910 1107 40
C-1915	28 v Output Noise Filter	CAPACITOR, paper, 2.0 mf $\pm 20\%$, 400 WV	-48403-B20		911		954 2484 00
C-1915	Alternate	CAPACITOR, paper, 2.0 mf +40 -15%, 600 WV	CP53B1FF205				961 4062 00
C-1915	Alternate	CAPACITOR, paper, 2.0 mf +40 -15%, 600 WV	CP50B1FF205				961 4070 00
C-1915	Alternate	CAPACITOR, paper, 2.0 mf $\pm 20\%$, 400 WV	-48403-B20		911		954 2444 00
C-1916	HV Output Noise Filter	CAPACITOR, paper, 0.1 mf $\pm 20\%$, 1500 WV			911 DYR- 4250 15010		930 0012 00
C-1917	28 v Output Ripple Filter	CAPACITOR, paper, 4 mf $\pm 20\%$, 50 WV	-482934-20		911 PC9B36 4250		930 0013 00
C-1918	14 v Output Noise Filter	CAPACITOR, mica, 0.01 mf $\pm 20\%$, 500 WV	-48643-A20		911 4L 4030 H-10		910 1107 40
C-1919	14 v Ripple Filter	CAPACITOR, Electrolytic, 20 mf +100 -10%, 100 WV	-482956		911 RVL-10051-1 3030 SPO 38482		183 3310 00
C-1919	Alternate	CAPACITOR, Electrolytic, 20 mf +150 -10%, 150 WV	CE630200J				184 6527 00
C-1920	Line Filter	CAPACITOR, paper, 2 mf $\pm 10\%$, 600 WV	-48777-10		911 KG-3020 1640 A7649		930 7822 00
C-1920	Alternate	CAPACITOR, paper, 2 mf +20 -10%, 600 WV	CP70B1FF205V				962 4010 00
C-1921	Line Filter	CAPACITOR, paper, 2 mf $\pm 10\%$, 600 WV	-48777-10		911 KG-3020 1640 A7649		930 7822 00
C-1921	Alternate	CAPACITOR, paper, 2 mf +20 -10%, 600 WV	CP70B1FF205V				962 4010 00
C-1922	C-1922A, C-1922B	DUAL CAPACITOR, 0.1/0.1 mf +20 -10%, 600 WV	CP51B4FF104V				961 5037 00
C-1922A	Line Filter	Part of C-1922					
C-1922B	Line Filter	Part of C-1922					

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spcl. Tol or Mod.	Contractor's Drawing and Part Number
<u>CAPACITORS (Cont.)</u>							
C-1922	Alternate	DUAL CAPACITOR, paper 0.1/0.1 mf +10%, 600 WV	-48312-B10		911 DYRT 4250 2527-9		956 4016 20
C-1923	14 v Output Ripple Filter	CAPACITOR, Electrolytic, 20 mf +100-10%, 100 WV	-482956		911 RVL-10051-1 3030 SPØ 38482		183 3310 00
C-1923	Alternate	CAPACITOR, Electrolytic, 20 mf +150-10% 150 WV	CE630200J				184 6527 00
<u>DYNAMOTORS</u>							
D-1901	Low Voltage Dynamotor	DYNAMOTOR, Input: 115 v DC Output #1: 28 v DC 15 amp Output #2: 14 v DC 1.2 amp	CAEN-211623		4960		231 0028 00
D-1902	High Voltage dynamotor	DYNAMOTOR, Inptu: 115 V DC Output #1: 400 v DC 750 ma Output #2: 750 v DC 350 ma	CAEN-211622		4960		231 0029 00
<u>MISCELLANEOUS ELECTRICAL PARTS</u>							
E-1901	Feedthru Bushing	BUSHING 3/8" x 5/8" Ceramic	NS4W4202				190 0006 00
E-1901	Alternate	BUSHING 3/8" x 5/8" Ceramic	-61511		2410 9791		190 2919 00
E-1902	Feedthru Bushing	BUSHING PLUG, 5/8" x 5/8" Ceramic	NS4W4102				190 0002 00
E-1902	Alternate	BUSHING PLUG, 5/8" x 5/8" Ceramic	NS3W4102		2410		190 2920 00
E-1904	Resistor Mounting Block	BLACK PORCELAIN 1" x 1-5/8"			60		193 1000 00
E-1907	Pilot Light Bracket	Mounting for miniature bayonet base bulb			1200 30		262 1230 00
E-1908	Pilot Light Bracket	Mounting for miniature bayonet base bulb			1200 30		262 1230 00
10459							

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spcl. Tol or Mod.	Contractor's Drawing and Part Number
<u>JACKS AND RECEPTACLES (Cont.)</u>							
J-1903	Remote Control Terminal Board	TERMINAL BOARD, 27 terminals			830		571 1545 20
J-1904	Remote Transmitter Power Terminal Board	Part of J-1903, 10 terminals					
J-1905	Navy RADIOPHONE Terminal Board	TERMINAL BOARD, 21 terminals			830		500 3964 002
J-1906	HV Dynamotor Connector Socket	CONNECTOR, 6 contact, wall mounting, female	-49942		830		500 2072 001
J-1907	LW Dynamotor Connector Socket	CONNECTOR, 6 contact, wall mounting, female	-49942		830		500 2072 001
J-1908	Relay Mounting Plate	Bakelite plate drilled to mount K-1901 and K-1903			830		502 3879 002
J-1909	Relay Mounting Plate	Bakelite plate drilled to mount K-1902 and K-1904			830		502 3880 002
J-1910	Filter Box Terminal Board	TERMINAL BOARD, 10 terminals			830		571 2121 10
<u>RELAYS</u>							
K-1901	Master Start Relay	RELAY, Contacts 3 PNO, coil 115 v DC			287		405 0019 00
K-1901	Alternate	RELAY, Contacts 3 PNO, coil 115 v DC	-29533		2050	G-33549	405 2203 10
K-1902	Carrier Relay	RELAY, Contacts 2 PNO, coil 7.2-14 v DC	-29523		287	R-30	405 0013 00
K-1902	Alternate	RELAY, Contacts 2 PNO, coil 7.2-14 v DC	-29524		2050	G-33402	405 2205 10
K-1903	Keying Relay	RELAY, Contacts 2 PDT, coil 115 v DC	-29525		287	R-39D	405 0015 00
K-1903	Alternate	RELAY, Contacts 2 PDT, coil 115 v DC	-29526		1820	JD115RR	405 2208 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>RELAYS (Cont.)</u>								
K-1904	Plate Power Relay	RELAY, Contacts 2 PNO, coil 25-28 v DC	-29531		287	R-39D		405 0014 00
K-1904	Alternate	RELAY, Contacts 2 PNO, coil 28 v DC nom	-29532		1820	JD28AA		405 2206 00
<u>INDUCTORS AND REACTORS</u>								
L-1901	14 v Output Filter	REACTOR, 0.15 hy 1.0 amp 2500 v	-302062		780			678 2600 00
L-1902	400 v Output Filter	REACTOR, 6 hy 0.3 amp, 2500 v	-302061		780			678 2390 00
L-1903	1150 v Output Filter	REACTOR, 6 hy 0.4 amp, 10,000 v	-302063		780			678 1510 00
L-1904	14 v Output Noise Filter	CHOKE, 22 microh	-47902		1384			240 5400 00
L-1905	14 v Output Noise Filter	CHOKE, 22 microh	-47902		3030	RF-583		240 5400 00
L-1906	28 v Output Noise Filter	CHOKE, 22 microh	-47902		1384			240 5400 00
L-1907	28 v Output Noise Filter	CHOKE, 22 microh	-47902		3030	RF-583		240 5400 00
L-1908	LV Dynamotor Input Filter	CHOKE, 22 microh	-47902		1384			240 5400 00
L-1909	LV Dynamotor Input Filter	CHOKE, 22 microh	-47902		3030	RF-583		240 5400 00
L-1910	HV Dynamotor Input Filter	CHOKE, 22 microh	-47902		1384			240 5400 00
L-1911	HV Dynamotor Input Filter	CHOKE, 22 microh	-47902		3030	RF-583		240 5400 00
L-1912	400 v Output Noise Filter	CHOKE, 1.0 mh 300 ma Pie wound	-47895		3220	R-300U		240 5800 00
L-1913	400 v Output Noise Filter	CHOKE, 1.0 mh 300 ma Pie wound	-47895		3090			240 5800 00
					3220	R-300U		240 5800 00
					3090			

10462

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>INDUCTORS AND REACTORS (Cont.)</u>							
L-1914	400 v Output Noise Filter	CHOKE, 1.0 mh 300 ma	-47895		3220 R-300U 3090		240 5800 00
L-1915	1150 v Output Noise Filter	CHOKE, 1.0 mh 300 ma	-47895		3220 R-300U 3090		240 5800 00
L-1916	1150 v Output Noise Filter	CHOKE, 1.0 mh 300 ma	-47895		3220 R-300U 3090		240 5800 00
L-1917	1150 v Output Noise Filter	CHOKE, 1.0 mh 300 ma	-47895		3220 R-300U 3090		240 5800 00
L-1918	1150 v Output Noise Filter	CHOKE, 1.0 mh 300 ma	-47895		3220 R-300U 3090		240 5800 00
L-1919	Line Filter	CHOKE, 22 microh	-47902		1384 3030 RF-583		240 5400 00
L-1920	Line Filter	CHOKE, 22 microh	-47902		1384 3030 RF-583		240 5400 00
<u>PLUGS</u>							
P-1901	HV Dynamotor Connector Plug	CONNECTOR, chassis mount, 6 contact, male	CJC-49251		2580 P-406-ABL/16		363 2060 00
P-1902	LV Dynamotor Connector Plug	CONNECTOR, chassis mount, 6 contact, male	CJC-49251		2580 P-406-ABL/16		363 2060 00
<u>RESISTORS</u>							
R-1901	Relay Current Limiting Resistor	RESISTOR, 63 ohms $\pm 5\%$ 120 w	63881-F		4250		733 0169 00
R-1902	Spark Filter Resistor	RESISTOR, 200 ohm $\pm 20\%$ 2 w	63705-201		2360	133-0200-7	709 2005 40
R-1902	Alternate	RESISTOR, 200 ohms $\pm 5\%$ 2 w	RW55E201				747 7533 00
R-1903	Meter Shunt	RESISTOR, Section #1: 13.4 ohms $\pm 5\%$ Section #2: 6.7 ohms $\pm 5\%$	COM-633920		3450		717 4100 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spec. Tol. or Mod.	Contractor's Drawing and Part Number
<u>RESISTORS (Cont.)</u>							
R-1904	Spark Suppressor Resistor	RESISTOR, 200 ohms $\pm 20\%$ 2 w	63705-201		2360 133-0200-7		709 2005 40
R-1904	Alternate	RESISTOR, 200 ohm $\pm 5\%$ 2 w	RW55E201				747 7533 00
R-1905	Pilot Light Dropping Resistor	RESISTOR, 1000 ohms $\pm 5\%$ 20 w	63011F		4250		733 1661 00
R-1905	Alternate	RESISTOR, 1000 ohms $\pm 5\%$ 20 w	RW15F102				746 2540 00
R-1906	Line Voltage Bleeder	RESISTOR, 100,000 ohms $\pm 20\%$ 1/2 w	RC21BF104				745 2171 00
R-1906	Alternate	RESISTOR, 100,000 ohms $\pm 20\%$ 1/2 w	RC20BF104				745 1171 00
<u>SWITCHES</u>							
S-1902	4 Wire Power Switch	TOGGLE SWITCH, SPST 1 amp 250 v	-24567		2160 20994-ET		266 1010 00
S-1905	Panel Interlock Switch	SWITCH, push toggle, SPNO, 3 amp 250 v			2160 3592-N		266 1050 00
S-1905	Alternate	SWITCH, push toggle, SPNO, 0.5 amp 125 v DC	-24195		1881		266 0001 00
S-1905	Alternate	SWITCH, push toggle, SPNO, 0.5 amp 125 v DC	-24563		1883 1GA19A44		266 0003 00
S-1906	EMERGENCY Switch	SWITCH DPST, 20 amp 250 v AC	-24458		1010 7402		260 0007 00
S-1907	4 WIRE - 6 WIRE Selector Switch	SWITCH, toggle, 3 PDT, 10 amp 250 v AC	-24565		1010 8660		260 0008 00
S-1908	LOCAL-REMOTE Switch	SWITCH, lever multi contact	-24566		830		502 0210 004
S-1909	ON Push Button	PUSH BUTTON, Black, normally open and closed contacts			2160 B-2		260 2020 00
S-1910	OFF Push Button	PUSH BUTTON, Red, normally open and closed contacts			2160 B-2		260 2030 00
<u>TRANSFORMERS</u>							
T-1901	Audio Coupling	TRANSFORMER, audio Pri: tapped at 200, 400, 600 ohms. Sec: tapped at 42, 60, 82, and 106 ohms	-302040		780		677 2610 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION
FOR NAVY MODEL TCZ-2 TRANSMITTING EQUIPMENT

65X-10 CONTROL CABLE (500 4474 00D)
(From Remote Unit to Power Unit)

<u>Symbol Designation</u>	<u>Function</u>	<u>Description</u>	<u>Navy or JAN Type Number</u>	<u>Navy Drawing or Spec.</u>	<u>Mfr's Code</u>	<u>Mfr's Designation</u>	<u>Spcl. Tol. or Mod.</u>	<u>Contractor's Drawing and Part Number</u>
<u>PLUGS</u>								
P-2301	Cable Connector Plug	CONNECTOR, 27 terminal	-49950		630	NK-27-21C- 11/16		371 4020 00
<u>CABLES</u>								
S-2301	Connecting Cable	CABLE, 27 conductor						424 2710 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr. Code	Mfr's Designations	Spcl. Tol. or Mod.	Contractor's Drawing and Part Number
<u>JACKS AND RECEPTACLES (Cont.)</u>								
J-3004	Connection to Antenna Terminal on Transmitter	BINDING POST, 5/8" push type			1320			372 2110 00
J-3005	ANT Connector Terminal	BINDING POST, 5/8" push type			4217	10000 series		
J-3006	Relay Power Connector	CONNECTOR, 3 terminal chassis mounting type	-49937		1320	10000 series		372 2110 00
					4217	10000 series		372 2110 00
					630	WK-C3-32S		371 1040 00
<u>RELAYS</u>								
K-3001	Antenna Keying Relay	RELAY, SPDT with vacuum contactor	-29520		2050	G32881		410 2100 00
<u>INDUCTORS AND REACTORS</u>								
L-3001	200 to 575 kc Load Coil Assembly	INDUCTOR, loading coil assem			830			502 1708 003
L-3002	200 to 575 kc Variometer Assembly	VARIOMETER ASSEMBLY			830			502 1709 004
L-3003	Variometer and Load Coil Assembly 575 to 1500 kc	INDUCTOR, variometer and load coil assembly			830			502 1710 004
L-3005	Static Drain Choke	CHOKE, 6 mh multi-section dual lateral wound	-47907		950			240 5900 00
<u>METERS</u>								
M-3001	Antenna Meter	THERMOAMMETER, 0-3 amp $\pm 2\%$ 30 scale divisions	-22438		4910	507		457 1140 00

TABLE 6-2
PARTS LIST BY SYMBOL DESIGNATION (Cont.)

Page 45 of 45 Pages

Symbol Designation	Function	Description	Navy or JAN Type Number	Navy Drawing or Spec.	Mfr's Mfr. Designation Code	Spcl. Tol or Mod.	Contractor's Drawing and Part Number
<u>PLUGS</u>							
P-3001	Relay Connector	SOCKET CONNECTOR, chassis mounting 2 terminal	-49866		2580 S-302-1B		366 2020 00
<u>SWITCHES</u>							
S-3001	Load Coil Selector Switch Assembly	TAP SWITCH, 2 position, DPDT			830		502 5300 004
S-3002	575 to 1500 kc Selector Switch	TAP SWITCH, ceramic insulation			830		502 1712 003
S-3003	200 to 575 kc Selector Switch	TAP SWITCH, ceramic insulation			830		502 5118 004
S-3004	K-3001 Relay Vacuum Contact	SWITCH, SPDT 8 amp 250 v vacuum sealed	-24163		1881 GL-34		260 6010 00

* Navy Type Number is for a suitable replacement part.

** Standard vacuum tubes are supplied by numerous well known manufacturers

*** The High Frequency Oscillator Unit assembly includes the 96K-1 Multiturn Autotune Unit "B" (Multiturn Unit includes Wick Lubricator Assen).

RESTRICTED

TABLE 6-3

PARTS LIST BY NAVY TYPE NUMBERS

<u>Quan</u>	<u>Navy Type Number</u>	<u>All Symbol Designations Involved</u>
<u>MOTOR</u>		
1	-211476	B-101
<u>CAPACITORS</u>		
1	-48197-C20	C-1911
1	-48312-B10	C-1922 Alternate
2	-48312-E20	C-1907, C-1908
4	-48403-P20	C-1901, C-1902, C-1909, C-1915
2	-48410-E20	C-106, C-117
6	-48643-A20	C-1910, C-1913, C-1914, C-1918, C-3002, C-3003
2	-48710-B10	C-2205, C-2206
1	-48713-B20	C-121
2	-48777-10	C-1920, C-1921
1	-48777-20	C-126
4	-48789-E20	C-107, C-119, C-120A, C-120B
1	-481033-B20	C-3001
1	-481223-20	C-2211
1	-481279-B20	C-402
1	-481319-F1	C-409B
1	-481327-C5	C-2213 Alternate
1	-481385-F1	C-405C
2	-481409-B10	C-108, C-116
1	-481410-F10	C-205
1	-481411-B10	C-204
1	-481411-B20	C-127
2	-481417-20	C-1905, C-1906
2	-481506-E20	C-209 Alternate, C-210 Alternate
1	-481677-1	C-101
1	-481678-1	C-102-C-103-C-104
2	-481679	C-111, C-115
1	-481680	C-411
1	-481681	C-136
1	-481682	C-408B
1	-481683-2	C-410A
1	-481684-2	C-406
3	-481685-2	C-403, C-408C, C-412
1	-481686-2	C-409C
1	-481687-1	C-407
1	-481688-1/2	C-404
1	-481689-10	C-130
3	-481690-10	C-122A, C-122B, C-129
3	-481691-5	C-124A, C-124B, C-124C

RESTRICTED

TABLE 6-3

PARTS LIST BY NAVY TYPE NUMBERS

<u>Quan.</u>	<u>Navy Type Number</u>	<u>All Symbol Designations Involved</u>
<u>CAPACITORS (Cont.)</u>		
5	-482111-B20	C-109, C-110, C-113, C-114, C-401
1	-482934-20	C-1917
2	-482935-20	C-1903, C-1904
5	-482936-10	C-203, C-2207, C-2208, C-2209, C-2210
1	-482937-20	C-138
1	-482938-B5	C-105
2	-482939-B20	C-132, C-133
1	-482940-B10	C-137
2	-482942-B20	C-118, C-128
1	-482947-10	C-112
1	-482948-5	C-131
1	-482949-10	C-206
5	-482951-F10	C-405A, C-405B, C-409A, C-410B, C-410C
2	-482952-F1	C408A, C-410D
6	-482956	C-201, C-202, C-207, C-208, C-1919, C-1923
2	-482959	C-134, C-135
3	-482977-10	C-1101, C-1102, C-1103
2	CE630200J	C-1919 Alternate, C-1923 Alternate
1	-CM 20C 300M	C-2213
2	-CM 35B 103M	C-209 Alternate, C-210 Alternate
1	CP50B1FF104K	C-1911 Alternate,
4	CP50B1FF205X	C-1901 Alternate, C-1902 Alternate, C-1909 Alternate, C-1915 Alternate
1	CP51B4FF104V	C-1922
2	CP51B4FF104X	C-1907 Alternate, C-1908 Alternate
4	CP53B1FF205X	C-1901 Alternate, C-1902 Alternate, C-1909 Alternate, C-1915 Alternate
2	CP70B1FF205V	C-1920 Alternate, C-1921 Alternate
2	CP70E1FJ405V	C-1905 Alternate, C-1906 Alternate
1		C-125
2		C-209, C-210
2		C-1912, C-1916
3		C-2201, C-2202, C-2203

RESTRICTED

TABLE 6-3

PARTS LIST BY NAVY TYPE NUMBERS

<u>Quan.</u>	<u>Navy Type</u>	<u>All Symbol</u>
	<u>Number</u>	<u>Designations Involved</u>

CAPACITORS (Cont.)

1		C-2204
1		C-2212
1		C-2214
1		C-3004

DYNAMOTORS

1	CAEN-211622	D-1902
1	CAEN-211623	D-1901

MISCELLANEOUS ELECTRICAL PARTS

1	-61152	E-401
1	-61170	E-105
1	-61415	E-402
1	-61503	E-104
2	-61511	E-103A, E-1911 Alternate
1	-61512	E-106A
1	-61513	E-107
2	NS 3W 4102	E-109B, E-1902 Alternate
1	NS 4W 4102	E-1902
1	NS 4W 4204	E-1901
2		E-102, E-901
1		E-103B
1		E-106B
1		E-108
2		E-1701, E-1702
1		E-1904
2		E-1907, E-1908
1		E-3001
1		E-3002
1		E-3003

FUSES

2		F-1901, F-1902
3		F-1903, F-1904, F-1905
1		F-1906
1		F-1907
1		F-1908

PILOT LAMPS

2		I-101, I-901
2		I-1901, I-1902

TABLE 6-3

PARTS LIST BY NAVY TYPE NUMBERS

<u>Quan.</u>	<u>Navy Type</u> <u>Number</u>	<u>All Symbol</u> <u>Designations Involved</u>
--------------	-----------------------------------	---

JACKS AND RECEPTACLES

6	-49025A	J-101, J-103, J-104, J-105, J-901, J-904
2	-49039	J-102, J-903
1	-49566	J-111
1	-49663	J-112
1	-49932	J-106
1	-49933	J-107
1	-49934	J-108
1	-49935	J-115
1	-49936	J-116
1	-49937	J-3006
1	-49938	J-1901
1	-49939	J-1902
2	-49942	J-1906, J-1907
1		J-109
1		J-110
2		J-113, J-3003
1		J-114
3		J-117, J-3004, J-3005
1		J-118
1		J-902
1		J-1903
1		J-1904
1		J-1905
1		J-1908
1		J-1909
1		J-1910
1		J-3001
1		J-3002

RELAYS

1	-29513	K-101
1	-29519	K-105
1	-29520	K-3001
1	-29523	K-1902
1	-29524	K-1902 Alternate
1	-29525	K-1903
1	-29526	K-1903 Alternate
1	-29531	K-1904
1	-29532	K-1904 Alternate
1	-29533	K-1901 Alternate
1	-29604	K-101 Alternate
1	-29605	K-102
1	-29606	K-102 Alternate
1	-29607	K-103
1	-29609	K-104

RESTRICTED

TABLE 6-3

PARTS LIST BY NAVY TYPE NUMBERS

<u>Quan.</u>	<u>Navy Type Number</u>	<u>All Symbol Designations Involved</u>
<u>RELAYS (Cont.)</u>		
1	-29610	K-104 Alternate
1		K-1901
<u>INDUCTORS AND REACTORS</u>		
9	-47895	L-116, L-117, L-1912, L-1913, L-1914, L-1915, L-1916, L-1917, L-1918
10	-47902	L-1904, L-1905, L-1906, L-1907, L-1908, L-1909, L-1910, L-1911, L-1919, L-1920
4	-47903	L-102, L-103, L-115, L-403
1	-47904	L-104
1	-47905	L-107
1	-47906	L-108
2	-47907	L-109, L-3005
1	-47908	L-402
1	-47909	L-110
1	-302061	L-1902
1	-302062	L-1901
1	-302063	L-1903
1	-302095	L-2201
1		L-101
1		L-105
1		L-106
1		L-112
1		L-113
1		L-114
1		L-401
1		L-3001
1		L-3002
1		L-3003
<u>LOUD SPEAKERS</u>		
1	-49437	LS-901
<u>METERS</u>		
1	-22438	M-3001
1	-22499	M-101
1	-22500	M-101
1	-22501	M-102
1	-22502	M-102

RESTRICTED

TABLE 6-3

PARTS LIST BY NAVY TYPE NUMBERS

<u>Quan.</u>	<u>Navy Type Number</u>	<u>All Symbol Designations Involved</u>
<u>PLUGS</u>		
1	-49661	P-401
1	-49662	P-201
1	-49866	F-3001
1	-49944	P-101
1	-49946	P-901
1	-49947	P-1501
1	-49948	P-1701
1	-49949	P-1702
1	-49950	P-2301
2	CJC-49251	P-1901, P-1902
1	U-7/U	P-1601
1	U-8/U	P-1502
1	U-9/U	P-1602
1		P-102
1		P-2201
<u>RESISTORS</u>		
1	-63011F	R-1905
2	-63288-104	R-102, R-107
2	-63288-153	R-401, R-2209
1	-63288-182	R-901
1	-63288-221	R-2217 Alternate
1	-63288-222	R-207
1	-63288-223	R-101
1	-63288-224	R-2211
5	-63288-470	R-103, R-104, R-106, R-108, R-112
1	-63291-101	R-202
2	-63291-221	R-201, R-204
1	-63355-104	R-211
1	-63355-153	R-203
1	-63355-222	R-2215
1	-63355-474	R-212
1	-63355-754	R-213
2	-63360-104	R-2202, R-2212A
1	-63360-105	R-208
2	-63360-154	R-2204, R-2216
2	-63360-224	R-209, R-2212B
1	-63360-333	R-2208
3	-63360-473	R-2203, R-2205, R-2206
4	-63360-474	R-205, R-210, R-2213, R-2214
1	-63535-10	R-133
1	-63678-100	R-135
2	-63678-221	R-216, R-2217

RESTRICTED

RESTRICTED

TABLE 6-3

PARTS LIST BY NAVY TYPE NUMBERS

<u>Quan.</u>	<u>Navy Type Number</u>	<u>All Symbol Designations Involved</u>
<u>RESISTORS (Cont.)</u>		
1	-63678-750	R-134
2	-63703-251	R-214, R-215
2	-63705-201	R-1902, R-1904
1	-63881-F	R-1901
1	-631874-20 Pot plus two	R-902
RC21BE511M resistors		
1	-632958-2-1/2	R-2207
2	-633157-10	R-129, R-130
1	-633182-10	R-2210
1	-633225-10	R-206
1	-633226-10	R-131
1	-633227-10	R-116
1	-633229-10	R-123
1	-633230-10	R-115
1	-633239-10	R-121
3	-633240-10	R-105, R-109, R-110
1	-633241-10	R-124
4	-633242-10	R-117, R-118, R-119, R-120
1	-633243-2	R-128
1	-633244-2	R-132
1	-633245-2	R-111
1	-633249	R-2201
1	COM-633920	R-1903
1	RC20BF104	R-1906 Alternate
1	RC21BF104	R-1906
1	RW15F102	R-1905 Alternate
2	RW55E201	R-1902, Alternate R-1904 Alternate
3		R-113, R-114, R-136
1		R-137
<u>SWITCHES</u>		
2	-24003-A	S-201, S-901
1	-24195	S-1905 Alternate
1	-24458	S-1906
1	-24560	S-104
1	-24563	S-1905 Alternate
1	-24565	S-1907
1	-24566	S-1908
1	-24567	S-1902
1	-24569	S-112
1	-24570	S-115
1	-24571	S-113D
1	-24572	S-114

RESTRICTED

TABLE 6-3

PARTS LIST BY NAVY TYPE NUMBERS

<u>Quan.</u>	<u>Navy Type Number</u>	<u>All Symbol Designations Involved</u>
<u>SWITCHES</u>		
1	-24573	S-111
2	CG 24163	S-116, S-3004
1		S-101
1		S-102
1		S-103
1		S-105
1		S-106
1		S-107
1		S-108
1		S-109
1		S-110
1		S-113
1		S-202
1		S-401
1		S-1905
1		S-1909
1		S-1910
1		S-3002
1		S-3003
<u>TRANSFORMERS</u>		
1	-47912	T-102
1	-302035	T-101
1	-302036	T-201
1	-302037	T-202
1	-302038	T-203
1	-302039	T-901
1	-302040	T-1901
<u>VACUUM TUBES</u>		
2	6V6GT	V-202, V-203
1	12SA7	V-2202
1	12SJ7	V-201
2	12SL7GT	V-2201, V-2203
2	811	V-105, V-106
1	813	V-104
1	837	V-101
3	1625	V-102, V-103, V-401
<u>CABLES</u>		
1		W-1501
1		W-1601
1		W-1701
1		W-2301

RESTRICTED

RESTRICTED

TABLE 6-3

PARTS LIST BY NAVY TYPE NUMBERS

<u>Quan.</u>	<u>Navy Type Number</u>	<u>All Symbol Designations Involved</u>
<u>SOCKETS</u>		
2	-49362	X-105, X-106
4	-49366	X-101, X-102, X-103, X-401
1	-49384	X-104
6	-49423	X-201, X-202, X-203, X-2201, X-2202, X-2203
1	-49951	X-2204
<u>CRYSTALS</u>		
1	CR-2-B/U (200 kc)	Y-2201
<u>TUNED CIRCUIT ASSEMBLIES</u>		
1	-47911	Z-2202
1	-47923	Z-2201

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>CAPACITORS (Cont.)</u>								
2	-48403-B20	C-1901,C-1902, C-1909,C-1915	Capacitor, Paper 2 mf ±20% 400 WV		911			954 2484 00
	-48403-B20	Alternate C-1901,C-1902, C-1909,C-1915	Capacitor, Paper 2 mf ±20% 400 WV		911			954 2444 00
1	-48410-B20	C-106,C-117	Capacitor, Mica .006 mf ±20% 1000 TV		911	4LS		910 2603 40
2	-48643-A20	C-1910,C-1913, C-1914,C-1918, C-3002,C-3003	Capacitor, Mica .01 mf ±20% 1000 TV		4030 911 4030	HLS-10 4L H-10		or 910N260C-M 910 1107 40 or 910N110G-M
1	-48710-B10	C-2205,C-2206	Capacitor, Mica .00001 mf ±10% 1000 TV		911 4030	5WS KS		909 4107 52 or 909N410GN-K
1	-48713-B20	C-121A,C-121B, C-121C	Capacitor, Paper, triple sect 0.1 mf ±20% 600 WV		911 4210	DYRT-6111 3XDMRT6.1		956 0001 00
1	-48777-10	C-1920,C-1921	Capacitor, Paper 2 mf ±10% 600 WV		911 1640 1880	KG-3020 A7649 67X2		930 7822 00
	-48777-20	Alternate C-126	Capacitor, Paper, oil filled 2.0 mf ±20% 600 WV		911	KG-3020		930 7824 00 or 930N78B-M
1	-48789-B20	C-107	Capacitor, Mica .002 mf ±20% 1000 TV		911 4030	4LS HLS-10		910 2203 40 or 910N220C-M
1	-48789-B20	C-119	Capacitor, Mica .002 mf ±20% 2500 TV		911 4030	4LS HLS-25		925 2203 40 or 925N220C-M
1	-48789-B20	C-120A,C-120B	Capacitor, Mica .002 mf ±20% 5000 TV		911 4030	4LS HLS-50		950 2203 40 or 950N220C-M
	-48847-B20	Alternate C-2201,C-2202, C-2203	Capacitor, Mica .006 mf ±20% 900 TV		4030 911	CLS 1WLS		909 2603 54

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>CAPACITORS (Cont.)</u>								
1	-481033-B20	C-3001	Capacitor, Mica .0007 mf +20% 5000 WV		911 4030	6LS F2		906 3701 40 or 906N370A-M
1	-481279-B20	C-402	Capacitor, Mica .00005 mf +20% 900 TV		4030 911	Type "C" 1WL		909 4503 40 or 909N450C-M
1	-481319-F1	C-409B	Capacitor, Mica .0004 mf +1% 500 TV		4170			912 3408 60 or 912N340H-F
	-481327-C5	Alternate C-2213	Capacitor, Mica 30 mmf +5% 500 WV		911	5R		912 4303 10 or 912N430C-J
1	-481385-F1	C-405C	Capacitor, Mica .001 mf +1% 500 TV		4170			912 2108 60 or 912N210H-F
1	-481409-B10	C-108, C-116	Capacitor, Mica .0005 mf +10% 1500 TV		4030	BE-15		915 3505 20
1	-481410-B	C-205	Capacitor, Mica .001 mf +10% 1500 TV		4030	BE-15		915 2105 20 or 915N210E-K
1	-481411-B	C-204	Capacitor, Mica .006 mf +10% 1500 TV		4030	BE-15		915 2605 20 or 915N260E-K
1	-481411-B20	C-127	Capacitor, Mica .006 mf +20% 1500 TV		4030	BE-15		915 2605 40 or 915N260E-M
1	-481417-20	C-1905, C-1906	Capacitor, Paper 4 mf +20% 2000 WV		911	TJU-20040		930 4040 00
	-481425-B20	Alternate C-2214	Capacitor, Mica .005 mf +20% 600 TV		911 4030 4210	3WISC JLS MKBW		909 2506 40
	-481506-B20	Alternate C-209, C-210	Capacitor, Mica 10,000 mmf +20% 600 TV DC		911	1WL		909 0002 00
1	(481677-1)	C-101	Capacitor, Ceramic .000185 +1% 1000 TV		4210			571 1433 30 or GA-1433C

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
			<u>CAPACITORS (Cont.)</u>					
	(Refer to C-101)	C-102,C-103, C-104	Set of 3 matched ceramic) capacitors total 413 mmf) ±1% 1000 TV					
1	481679	C-111,C-115	Capacitor, Ceramic 6 section, variable, 1000 TV		700	828-003		917 6130 00
1	481680	C-411	Capacitor, Ceramic 5 sect variable 1000 TV		700	826-003		917 5110 00 or 917N5A1
1	481681	C-136	Capacitor, Ceramic 13 mmf variable		700	822-009		917 1010 00 or 917N101
1	481682-2	C-408B	Capacitor, Mica .00015 mf ±2% 1000 TV		700	810-250		913 0017 00
1	481683-2	C-410A	Capacitor, Mica .00025 mf ±2% 1000 TV		700	810-290		913 0024 00 or 913N325N7-G
1	481684-2	C-406A	Capacitor, Mica .000125 mf ±2% 1000 TV		700	814-106		913 0001 00
1	481685-2	C-403,C-408C, C-412	Capacitor, Ceramic .0003 mf ±2% 1000 TV		700	816-035		913 3307 00 or 913N330-G
1	481686-2	C-409C	Capacitor, Mica .00035 mf ±2% 1000 TV		700	816-041		913 0014 00
1	481687-1	C-407	Capacitor, Ceramic Set of 3 matched capacitors total .00088 mf ±1% temp coef: Neg 32 PPM/°C +15 -61 PPM/°C		700	816-043		913 1200 00
1	481688-1	C-404	Capacitor, Ceramic Set of 3 matched capacitors total .00083 mf ±1% 500 WV		700	816-044		913 1100 00 or 913N1A1
1	481689-10	C-130	Capacitor, Ceramic 25 mmf ±10% 1500 TV		700	850-001		913 4253 20 or 913N425C-K
1	481690	C-122A,C-122B, C-129	Capacitor, Ceramic 50 mmf ±10% 1500 TV		700	850-002		913 4503 20 or 913N450C-K

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>CAPACITORS (Cont.)</u>								
1	-481691	C-124A,C-124B, C-124C	Capacitor, Ceramic 67 mmf +5% 1500 TV		700	850-003		913 4673 10 or 913N467C-J
1	-482111-B20	C-109,C-110, C-113,C-114, C-401	Capacitor, Mica .002 mf +20% 1500 TV		4030	BE-15		915 2205 40
1	-482410-20	C-2211	Capacitor, Paper .5 mf +20% 600 WV		911 4210	DYR-6050 X-DMR6-.5		956 0006 00 or 956NSOBYX1-M
1	-482934-20	C-1917	Capacitor, Paper 4 mf +20% 50 WV		911	PC9B36		930 0013 00
1	-482935-20	C-1903,C-1904	Capacitor, Paper 8 mf +20% 800 WV		911	KG-U-4080		930 1940 00
3	-482936-10	C-203,C-2207, C-2208,C-2209, C-2210	Capacitor, Paper oil filled .05 mf +20% -10% 600 WV		3030			930 0010 00
1	-482937-20	C-138	Capacitor, Paper .1 mf +20% 600 WV		1640 3030			930 0006 00
1	-482938-B5	C-105	Capacitor, Mica .005 mf +5% 2500 TV		911 4030	4LST HLST		925 2502 10 or 925N250K-J
1	-482939-B20	C-132,C-133	Capacitor, Mica .004 mf +20% 600 TV		911 4030	3WS JS		909 2406 40 or 909N240F
	-482940-B10	Alternate C-137	Capacitor, Mica .0015 mf +10% 900 TV		4210 4030			909 2156 20 or 909N215F-K
1	-482941-B10	C-3004	Capacitor, Mica 200 mmf +10% 5000 TV		911 4030	6L F		906 3202 00
1	-482942-B20	C-118,C-128	Capacitor, Mica .002 mf +20% 7500 TV		4030	A2LS		975 2201 40 or 975N220A-M
1	-482947-10	C-112	Capacitor, Mica .00025 mf +10% 1500 TV		4030	BE-15		915 3255 20
1 10674	-482948	C-131	Capacitor, Mica .0008 mf +5% 1000 TV		4030	BE-10		910 3805 10 or 910N380E-J

TABLE 6-4

EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>CAPACITORS (Cont.)</u>								
1	-482949-10	C-206	Capacitor, Mica .003 mf +10% 1500 TV		4030	BE-15		915 2305 20 or 915N230E-K
1	-482951-F10	C-405A,C-405B, C-409A,C-410B C-410C	Capacitor, Mica .002 mf ±1% 500 TV		4170			912 2208 60 or 912N220H-F
1	-482952-F1	C-408A,C-410D	Capacitor, Mica .0015 mf ±1% 500 TV		4170			912 2158 60
6	-482956	C-201,C-202, C-207,C-208, C-1919,C-1923	Capacitor, Electrolytic 20 mf +100% -10% 100 v		911 3030	RVL-10051-1 SPO 38482		183 3310 00 or 183N33A
1	-482959	C-134,C-135	Capacitor, Midget variable 28 mmf 1000 TV		3410			922 5100 00 or 922N51
	-482959	Alternate C-134, C-135	Capacitor, Midget variable 28 mmf 1000 TV		230			922 0007 00
1	-482977-10	C-1101, C-1102, C-1103	Capacitor, Mica 25 mmf +10% 10,000 TV		30	1860-201		914 1762 00 or 914N1X6-K
1	CM20B201	C-2204	Capacitor, Mica .0002 mf +5% 1000 TV		4170			935 0118 00
1	CM20C300	C-2213	Capacitor, Mica 30 mmf +5% 500 WV					935 0144 00
	CM30C152	Alternate C-137	Capacitor, Mica .0015 mf +2% 1000 TV					935 4109 00
1	CM35B103	C-209,C-210	Capacitor, Mica .01 mf +20% 600 TV					935 2118 00
1	CM35B152	C-137	Capacitor, Mica .0015 mf +5% 1000 TV					935 2081 00
1	CM35B512	C-2214	Capacitor, Mica 5100 mmf +5% 1000 TV					935 2105 00

10675

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>CAPACITORS (Cont.)</u>								
1	CM35B622	C-2201, C-2202, C-2203	Capacitor, Mica 6200 mmf ±5% 1000 TV					935 2108 00
	CM40B512	Alternate C-2214	Capacitor, Mica 5100 mmf ±5% 1000 TV					935 3035 00
	CM45B202	Alternate C-107	Capacitor, Mica .002 mf ±5% 1200 WV					936 0268 00
	CM45B202	Alternate C-119	Capacitor, Mica .002 mf ±5% 2000 TV					936 0268 00
	CM70B201	Alternate C-3004	Capacitor, Mica 200 mmf ±5% 5000 TV					938 2032 00
	CM70B751	Alternate C-3001	Capacitor, Mica 750 mmf ±5% 5000 WV					938 2060 00
	CN35A103	Alternate C-209, C-210	Capacitor, Paper .01 mf +60% -20% 400 WV					934 0003 00
	CN35A602	Alternate C-2201, C-2202, C-2203	Capacitor, Paper .006 mf +60% -20% 600 WV		911	ASA: CN 35A602		934 0002 00
	CP50B1FF-104K	Alternate C-1911	Capacitor, Paper .1 mf ±10% 600 WV					961 4018 00
	CP50B1FF-205X	Alternate C-1901, C-1902, C-1909, C-1915	Capacitor, Paper 2 mf +40% -15% 600 WV					961 4070 00

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>DYNAMOTOR PARTS (Cont.)</u>								
6		D-1902	Holder, Brush, Pos LV Output for 231 0029 00, 2-3/8" x 2-9/16" x .6"		4960	A-6487		234 0074 00
6		D-1902	Holder, Brush, Neg LV Output for 231 0029 00, 2-3/16" x 2-9/16" x 7/16"		4960	A-6673		234 0072 00
6		D-1902	Holder, Brush, Pos HV Output for 231 0029 00, 2-3/4" x 1" x 1-3/16"		4960	A-6489		234 0070 00
6		D-1902	Holder, Brush, Neg HV Output for 231 0029 00, 2-3/4" x 1" x 1-3/16"		4960	A-6489-1		234 0071 00
24		D-1901, D-1902	Cap, Brush Holder, Pos and Neg Input for 231 0028 00 and 231 0029 00, 15/16 - 27 thd, .46" thk		4960	A-6588		234 0056 00
24		D-1901, D-1902	Cap, Brush Holder, Pos and Neg LV for 231 0028 00 and 231 0029 00, 7/16 - 27 thd, 9/32" thk		4960	A-5065		234 4090 00
12		D-1901	Cap, Brush Holder, Pos or Neg HV, for 231 0028 00, 5/8 - 27 thd, 11/32" thk		4960	5635		234 4120 00
12		D-1902	Cap, Brush Holder, Pos or Neg HV, for 231 0029 00, 3/8 - 27 thd, 11/32" thk		4960	A-5125		234 0057 00
2		D-1901, D-1902	Field Coil, Replacement for 231 0028 00, 231 0029 00		4960	B-8568 (F-510)		234 0143 00
1		D-1901	Armature, Replacement for 231 0028 00		4960	C-8564 (A-513)		234 0141 00

10679

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>DYNAMOTOR PARTS (Cont.)</u>								
1		D-1902	Armature, Replacement for 231 0029 00		4960	C-8483 (A-512)		234 0142 00
2		D-1901, D-1902	Bearing, Replacement for 231 0028 00, 231 0029 00		4960	6211		234 0075 00
<u>MISCELLANEOUS ELECTRICAL PARTS</u>								
2	-61152	E-401	Insulator, Feedthru, button ceramic 3/16 x 5/8		2410			190 2932 00
1	-61415	E-402	Insulator, Standoff, ceramic 3/8 x 1/2		2410	395L-1/2		190 2329 00 or 19ONSL5
1	-61488	E-105	Insulator, Standoff, cyl ceramic 1/2 x 1		2410	397-L1		190 2327 00 or 19ONSL3
4	-61503	E-104	Insulator, Standoff, ceramic 3/8-1/2 x 3/4		2410	GS-10		190 2570 00 or 19ONSN7
	-61511	Alternate E-103A,E-1901	Insulator, Feedthru, ceramic 1/2-5/8 x 3/8		2410			190 2919 00
1	-61512	E-106A	Insulator, Feedthru, conical ceramic 3/4 to 7/8 OD x 7/8		2410			190 2921 00 or 19ONBI21
3	-61513	E-107	Insulator, Bushing insert 3/16 x 5/8		2410			190 2929 00
	NS3W4102	Alternate E-109B,E-1902	Insulator, Feedthru, conical ceramic 1/2 to 5/8 OD x 5/8		2410			190 2920 00
3	NS4W4102	E-109B,E-1902	Insulator, Ceramic bushing, 1/2-5/8 x 5/8					190 0002 00
4	NS4W4202	E-103A,E-1901	Insulator, Feedthru, ceramic 1/2-5/8 x 3/8					190 0006 00

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>MISCELLANEOUS ELECTRICAL PARTS (Cont.)</u>								
1	REL3A317	E-103B	Insulator, Feedthru, ceramic 1/2-5/8 x 5/8		2410			190 2925 00 or 190NBI25
1	REL3A317	E-106B	Insulator, Feedthru, conical ceramic 3/4 to 7/8 OD x 7/8		2410			190 2926 00 or 190NBI26
1		E-102,E-901	Pilot light bracket for miniature base bulb		1200	Cat. 80		262 1270 00 or 262N127
1		E-108	Insulator, Feedthru, bowl type		2410	YA-1685B		581 1685 20 or 1685B
3		E-401	Insulator, Bushing receptacle 1-1/8, 1-3/4 x 2-1/2					190 2917 00
1		E-1701,E-1702	Bushing, Rubber cable clamp reducer 7/16 OD .28 ID x 5/8		630	P		371 1110 00
2		E-1904	Ceramic Block for resistor clip		60			193 1000 00 or 193N1
1		E-1907,E-1908	Pilot lamp receptacle		1200	30		262 1230 00
1			Jewel, green		1200			262 2180 00
1			Jewel, red		1200			262 2160 00
2		E-3001	Feedthru, Ceramic		830			507 7007 00
1		(E-3001, J-3002)	Feedthru, xmtr to loading coil term		830			571 1746 20
1		E-3002	Feedthru, Antenna lead in and xmtr ant to load coil terminals		830			507 7009 00
1		E-3003	Shockmount, Meter M-3001 3/16" x 4" OD		4640			200 5360 00 or 200N536
1			Clip, for choke L-107		2920			265 3010 00
2			Clip, 3/8" ferrule		2920 2049			265 4010 00 or 265 1005 00
1			Clip, 9/16" ferrule					265 5010 00
1			Clip, 1-1/8" ferrule		2520	388-208		265 9020 00

10681

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>MISCELLANEOUS ELECTRICAL PARTS (Cont.)</u>								
1			Tube, Hold down, for V-101 V-102, V-103		830			571 1208 20
1			Tube, Hold down, for V-105 V-106		830			572 1208 20
<u>FUSES</u>								
4		F-1901,F-1902	Fuse, Renewable cartridge 30 amp		2520	380-030		264 2301 00
20		F-1901,F-1902	Fuse, Renewable link for 264 2301 00, 30 amp		2520			264 2302 00
30		F-1903,F-1904 F-1905	Fuse, Non-renewable, 15 amp					264 6009 00
10		F-1906	Fuse, Non-renewable, 3 amp 1-1/2" long, 13/32" diam ends					264 6002 00
20		F-1907	Fuse, 1 amp 1000 v 3" long, 3/8" diam ends		2920	2104		264 7040 00
20		F-1908	Fuse, 1 amp 2500 v 4 1/2" long, 3/8" diam ends		2920	2109		264 7090 00
<u>PILOT LAMPS</u>								
4		I-101,I-901	Lamp, 28 v .17 amp miniature bayonet base		1881	T3-1/4		262 3270 00
4		I-1901,I-1902	Lamp, 12-16 v, .1 amp miniature bayonet base		1881	T3-1/4		262 3260 00
		Alternate	Lamp, 12-16 v, .1 amp miniature bayonet base					262 0019 00

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>JACKS AND RECEPTACLES</u>								
3	-49025A	J-101, J-103, J-104, J-105, J-901, J-904	Jack, 1 circuit for plugs with 1/4" barrel		3040 3240	SC1A		358 1040 00
1	-49039	J-102, J-903	Jack, 3 circuit		3030 3240	SCA2B		358 1050 00
1	-49566	J-111	Connector, 8 term female socket		2580	300		366 2080 00 or 366N208
1	-49572	J-114	Connector, 6 term female chassis mtg		2580	300		366 2060 00
1	-49663	J-112	Connector, 12 term female chassis mtg		2580	300		366 2120 00
1	-49932	J-106	Connector, 27 term female wall mtg		630	RNK-27-31SL		371 4039 00 or 371N403R
1	-49933	J-107	Connector, 3 term female wall mtg		630	RWK-C3-31SL		371 1059 00 or 371N105R
1	-49934	J-108	Connector, 10 term male wall mtg		630	FK-10-32S		371 5130 00 or 371N513
1	-49935	J-115	Connector, 12 term male octal style cable		200	70-12		369 1700 00
1	-49936	J-116	Connector, 15 term male chassis mtg		2580	300		366 2150 00 or 366N215
1	-49937	J-3006	Connector, 3 term chassis mtg type		630			371 1040 00
1	-49938	J-1901	Connector, 27 term, wall mtg type		630	NK-27-32S-2		371 4010 00
1	-49939	J-1902	Connector, 10 term wall mtg type		630	RFK-10-31SL-2		371 5119 00
1	-49942	J-1906, J-1907	Connector, 6 term wall mtg		830			500 2072 001
1		J-109, J-118	Binding Post, 5/8" push type		1320 4217	10,000 Series		372 2210 00 or 372N22A

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

<u>Quantity</u>	<u>Navy or JAN Type Number</u>	<u>All Symbol Designations Involved</u>	<u>Description</u>	<u>Navy Spec. or Dwg. No.</u>	<u>Mfr. Code</u>	<u>Mfr's Designation</u>	<u>Spcl. Tol. or Mod.</u>	<u>Contractor's Drawing or Part Number</u>
<u>JACKS AND RECEPTACLES (Cont.)</u>								
1		J-110	Binding Post, 5/8" push type		1320 4217	10,000 Series		372 2410 00 or 372N24A
1		J-113, J-3003	Binding Post, 5/8" push type		1320 4217	10,000 Series		372 1410 00 or 372N14A
1		J-117	Binding Post, 5/8" push type		1320			372 2110 00
1		J-3004, J-3005	Binding Post, 5/8" push type					372 2410 00
1			Connector, 6 term socket chassis mtg type		2580	SS-6-AB1/16		364 2060 00
<u>RELAYS</u>								
1	-29513	K-101	Relay, 3PDT, coil: 28 v DC		284	R-30-F		405 0012 00
	-29513	Alternate K-101	Relay, 3PDT, coil: 28 v DC		2050	G-33177		405 2201 10 or 405NB201A
	-29514-A	Alternate K-102	Relay, Multi-contact DT coil: 28 v DC		4310			410 0011 00
1	-29515	K-103	Relay, DPDT and SPST coil: 28 v DC		284	R22A		410 0012 00
	-29515	Alternate K-103	Relay, DPDT and SPST coil: 28 v DC		2050	G32811-A		410 0015 00
	-29515	Alternate K-103	Relay, DPDT and SPST coil: 28 v DC		2050	G32811		410 1700 00
1	-29516	K-104	Relay, DPDT, coil: 28 v DC		284	R-22-B		410 0013 00

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>RELAYS (Cont.)</u>								
1	-29516 -29519	Alternate K-104 K-105	Relay, SPDT, SPNC & SPNO, coil: 18-32 v DC		2050 2050	G-33304		410 0014 00 410 0010 00
1	-29520	K-3001	Relay, SPDT coil: 28 v DC		2050	G-32881		410 2100 00 or 410N21
1	-29523	K-1902 - Alternate	Relay, 2PNO coil: 12 v DC		287	R-30		405 0013 00
1	-29524 -29525	K-1902 K-1903	Relay, 2PNO coil: 12 v DC Relay, DPDT coil: 115 v DC		2050 287	G-33402 R-39D		405 2205 10 405 0015 00
1	-29526 -29531	Alternate K-1903 K-1904	Relay, DPDT coil: 115 v DC Relay, 2PNO coil: 28 v DC		1820 287	JD 115RR R39D		405 2208 00 405 0014 00
1	-29532 -29533	Alternate K-1904 K-1901	Relay, 2PNO coil: 28 v DC Relay, 3PNO coil: 115 v DC		1820 2050	JD28AA G-33549		405 2206 00 405 2203 10
1	-29604 -29605	Alternate K-1901 Alternate K-101 K-102	Relay, 3PDT, coil: 28 v DC Relay, Keying type with vacuum switch, 3PNO, 1PNC, 2PDT coil, 28 v DC		1820 2050	27D G-32877A		405 0009 00 410 0008 00
<u>INDUCTORS AND REACTORS</u>								
9 10684	-47895	L-116,L-117, L-1912,L-1913, L-1914,L-1915, L-1916,L-1917, L-1918	Choke, 1 mh .3 amp duo- lateral wound		3090	R-300U		240 5800 00 or 240N58

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>INDUCTORS AND REACTORS (Cont.)</u>								
10	-47902	L-1904,L-1905, L-1906,L-1907, L-1908,L-1909, L-1910,L-1911, L-1919,L-1920	Choke, 22 uh 55T #12 E		3030	RF583		240 5400 00
4	-47903	L-102,L-103, L-115,L-403	Choke, 2.5 mh .125 amp		3220 3090	R-100U		240 5300 00 or 240N53
1	-47904	L-104	Choke, 208 uh $\pm 1\%$ duo-lateral wound		4335			240 6000 00 or 240N60
1	-47905	L-107	Choke, 2.5 mh .125 amp		3220	R100		240 2100 00 or 240N2A
1	-47906	L-108	Choke, 100 uh $\pm 10\%$		830	GA-1404C		571 1404 30 or GA-1404C
2	-47907	L-109,L-3005	Choke, 6 mh, multi section duo-lateral wound		950			240 5900 00 or 240N59
1	-47908	L-402	Choke, 8 mh, .125 amp		2140	CH-8		240 4100 00 or 240N4A
1	-47909	L-110	Choke, 190 mh $\pm 10\%$		830	GA-1395C		571 1395 30
1	-302061	L-1902	Reactor, Filter, 6 hy .3 amp		780			678 2390 00
1	-302062	L-1901	Reactor, Filter .15 hy, 1 amp		780			678 2600 00
1	-302063	L-1903	Reactor, 6 hy $+20\%$ -0% .4 amp		780			678 1510 00
1	-302095	L-2201	Inductor, .25 hy to oscillate at 1000 cps with .1 mf capacitor		780	7822		678 2470 00
1		L-101	Inductor, HF osc tuning		830	GA-671D		571 0671 40
1		L-105	Inductor, 1st multiplier		830			571 1687 20 or GA-1687B
1		L-106	Inductor, 2nd multiplier plate 9-1/2 turns #24 wire		830			571 1686 20 or GA-1686B

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>INDUCTORS AND REACTORS (Cont.)</u>								
1		L-114	Inductor, Plate tank padding 2.1 uh $\pm 5\%$		830	GA-1114A		571 1114 10
1		L-401	Inductor, LF ose grid 19.956 uh $\pm 1\%$		830	GA-1259C		571 1259 30
1		L-3001	Inductor, load coil assem		830			502 1708 003
<u>PLUGS</u>								
1	-49565	P-2201	Connector, 8 term chassis mtg plug					365 2080 00
1	-49661	P-401	Connector, 6 term male chassis mounting		2580	300		365 2060 00 or 365N206
1	-49662	P-201	Connector, 12 term male chassis mtg		2580	P-312-AB		365 2120 00 or 365N212
1	-49866	P-3001	Connector, 2 term chassis mtg socket		2580	S-302-AB		366 2020 00 or 366N202
1	-49944	P-101	Connector, 12 term octal style female chassis mtg		200	M1P		369 1600 00 or 369N16
1	-49946	P-901	Connector, 27 term wall mtg receptacle		630	K		371 4050 00 or 371N405
1	-49947	P-1501	Connector, 27 term 90 degree plug female		630	NK-27-23-11/16		371 4060 00 or 371N406
1	-49948	P-1701	Connector, 3 term 90 degree angle plug		630	WK-C3-23C7/16		371 1090 00 or 371N109
1	-49949	P-1702	Connector, 3 term straight plug		630	RWK-C3-22C7/16		371 1109 00 or 371N1109
1	-49950	P-2301	Connector, 27 term straight plug female		630	NK-27-21C-11/16		371 4020 00 or 371N402
1	U-7/U	P-1601	Connector, 10 term straight plug		630	FK10-21-9/16		371 5140 00 or 371N514

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>PLUGS (Cont.)</u>								
1	U-8/U	P-1502	Connector, 27 term straight plug male		630	RNK-27 22C11/16		371 4049 00 or 371N404R
1	U-9/U	P-1602	Connector, 10 term 90 degree angle plug		630	RFK10- 24C9/16		371 5129 00 or 371N512R
1		P-1901,P-1902	Connector, 6 term chassis mtg plug		2580	P-406- AB1/16		363 2060 00
<u>RESISTORS</u>								
1	-63011F	R-1905	Resistor, 1000 ohm +5% 20 w		4250			733 1661 00
	-63288-104	Alternate R-102,R-107	Resistor, 100,000 ohm +10% 1 w		2360	BT1- Navy		729 7100 42 or 729NG100M-K
	-63288-153	Alternate R-401,R-2209	Resistor, 15,000 ohm +10% 1 w		2360	BT1-Navy		729 7154 20 or 729NG15M-K
1	-63288-182	R-901	Resistor, 1800 ohm +20% 1 w		2360	BT1-Navy		729 7180 04 or 729NG1800-M
	-63288-203	Alternate R-137	Resistor, 20,000 ohm +20% 1 w		2360	BT1-Navy		729 7204 40
	-63288-221	Alternate R-2217	Resistor, 220 ohm +10% 1 w		2360			729 0001 00
	-63288-222	Alternate R-207	Resistor, 2200 ohm +10% 1 w		2360	BW1-Navy		708 0002 00 or 708N2200NA-K
	-63288-223	Alternate R-101	Resistor, 22,000 ohm +10% 1 w		2360	BT1-Navy		729 7224 20 or 729NG22M-K

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>RESISTORS (Cont.)</u>								
	-63288-224	Alternate R-2211	Resistor, .22 meg $\pm 10\%$ 1 w					729 7220 42
	-63288-470	Alternate R-103, R-104, R-106, R-108, R-112	Resistor, 47 ohm $\pm 20\%$ 1 w		4220			729 7474 00 or 729NG47-M
1	-63291-101	R-202	Resistor, 100 ohm $\pm 5\%$ 1/2 w		90			703 1100 10 or 703NA100-J
1	-63291-221	R-201, R-204	Resistor, 220 ohm $\pm 5\%$ 1 w		90			703 1220 10 or 703NA220-J
1	-63355-104	R-211	Resistor, 100,000 ohm $\pm 5\%$ 1/2 w		2360	BT1/2-Navy		729 5100 41 or 729NE100M-J
	-63355-153	Alternate R-203	Resistor, 15,000 ohm $\pm 5\%$ 1/2 w		2360	BT1/2-Navy		729 5154 10 or 729NE15M-J
	-63355-222	Alternate R-2215	Resistor, 2200 ohm $\pm 5\%$ 1/2 w		2360	BT1/2-Navy		729 5220 01 or 729NE2200-J
	-63355-474	Alternate R-212	Resistor, 470,000 ohm $\pm 5\%$ 1/2 w		2360	BT1/2-Navy		729 5470 41 or 729NE470M-J
	-63355-754	Alternate R-213	Resistor, 750,000 ohm $\pm 5\%$ 1/2 w		2360	BT1/2-Navy		729 5750 41 or 729NE750M-J
1	-63360-104	R-2202, R-2212A	Resistor, 100,000 ohm $\pm 10\%$ 1/2 w		2360	BT1/2-Navy		729 5100 42 or 729NE100M-K
	-63360-105	Alternate R-208	Resistor, 1 meg $\pm 10\%$ 1/2 w		2360	BW1-Navy		729 0008 00 or 729NELMeg-K

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>RESISTORS (Cont.)</u>								
	-63360-154	Alternate R-2204, R-2216	Resistor, 150,000 ohm $\pm 10\%$ 1/2 w		2360	BT1/2- Navy		729 5150 42 or 729NE150M-K
	-63360-224	Alternate R-209, R-2212B	Resistor, 220,000 ohm $\pm 10\%$ 1/2 w		2360	BT1/2- Navy		729 5220 42 or 729NE220M-K
	-63360-473	Alternate R-2203, R-2205, R-2206	Resistor, 47,000 ohm $\pm 10\%$ 1/2 w		2360	BT1/2- Navy		729 5474 20 or 729NE47M-K
	-63360-474	Alternate R-205, R-210, R-2213, R-2214	Resistor, 470,000 ohm $\pm 10\%$ 1/2 w		2350	BT1/2- Navy		729 5470 42 or 729NE470M-K
1	-63535-10	R-133	Resistor, 50 ohm $\pm 10\%$ 10 w		3450			710 1501 20 or 710NA50A-K
	-63678-100	Alternate R-135	Resistor, 10 ohm $\pm 10\%$ 1/2 w		2360	BW1/2		707 1052 00 or 707N10N-K
	-63678-221	Alternate R-216	Resistor, 220 ohm $\pm 10\%$ 1/2 w					707 2205 20
	-63678-221	Alternate R-2217	Resistor, 220 ohm $\pm 20\%$ 1/2 w		2360	BW1/2		707 2205 40
	-63678-750	Alternate R-134	Resistor, 75 ohm $\pm 10\%$ 1/2 w		2360	BW1/2		707 7552 00 or 707N75N-K
	-63703	Alternate R-2217	Resistor, 220 ohm $\pm 20\%$ 1 w		2360	BW1-Navy		708 2205 40
	-63703-251	Alternate R-214, R-215	Resistor, 250 ohm $\pm 10\%$ 1 w		2360	BW1-Navy		708 2505 12 or 708N250NA-K
1 10689	-63705-201	R-1902, R-1904	Resistor, 200 ohm $\pm 20\%$ 2 w		2360	133-0200-7		709 2005 40

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>RESISTORS (Cont.)</u>								
1	-63881F	R-1901	Resistor, 63 ohm $\pm 5\%$ 1/20 w ferrule type		4250			733 0169 00
1	-632958-2 $\frac{1}{2}$	R-2207	Resistor, 85 ohm $\pm 2-1/2\%$ 10 w		3450			710 0003 00
1	-633157-10	R-129, R-130	Resistor, 1000 ohm $\pm 10\%$ 10 w		3450	BD		710 1141 20 or 710NA1MA-K
1	-633182-10	R-2210	Resistor, 15,000 ohm $\pm 10\%$ 10 w		3450			710 0010 00
1	-633225-10	R-206	Resistor, 42 ohm $\pm 10\%$ 10 w		3450	BD		710 1422 20 or 710NA42B-K
1	-633226-10	R-131	Resistor, 350 ohm $\pm 10\%$ 10 w		3450	BD		710 0021 00
1	-633227-10	R-116	Resistor, 1 ohm $\pm 10\%$ 25 w		3450	BD		710 1112 00 or 710NALA-K
2	-633228-20	R-113, R-114, R-136	Resistor, 150 ohm $\pm 20\%$ 10 w		3450	BD		710 0019 00 or 710NA150B-M
1	-633229-10	R-123	Resistor, 12.6 ohm $\pm 10\%$ 25 w		3450			710 0045 00 or 710NC12.6A-K
1	-633230-10	R-115	Resistor, 100 ohm $\pm 10\%$ 25 w		3450			710 0048 00
1	-633239-10	R-121	Resistor, 0.8 ohm $\pm 10\%$ 50 w		3450			710 0013 00 or 710NDO.8A-K
2	-633240-10	R-105, R-109, R-110	Resistor, 20,000 ohm $\pm 10\%$ 25 w		3450	0218		710 0078 00 or 710NC20MA-K
1	-633241-10	R-124	Resistor, 25,000 ohm $\pm 10\%$ 25 w		3450	0219		710 0081 00 or 710NC25MA-K
2	-633242-10	R-117, R-118, R-119, R-120	Resistor, 5000 ohm $\pm 10\%$ 25 w		3450	0212		710 3541 20 or 710NC5MA-K
1	-633243-2	R-128	Resistor, 4000 ohm $\pm 2\%$ 1 w		2360	WW3		721 3447 00 or 721NL4M-G
1	-633244-2	R-132	Resistor, 50,000 ohm $\pm 2\%$ 0.8 w		2360	WW3		721 3504 70 or 721NL50M-G
1	-633245-2	R-111	Resistor, 235 ohm $\pm 2\%$ 1 w		2360	WW3		721 3235 70 or 721NL235-G
1	-633249	R-2201	Resistor, 2-15 ohm rheostat		4975			381 9010 00 or 381N901

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
		<u>RESISTORS (Cont.)</u>						
	RC20BF104	Alternate R-211	Resistor, 100,000 ohm +5% 1/2 w					745 1169 00
	RC20BF104	Alternate R-1906	Resistor, 100,000 ohm +20% 1/2 w					745 1171 00
1	RC20BF105	R-208	Resistor, 1 meg +10% 1/2 w					745 1212 00
1	RC20BF153	R-203	Resistor, 15,000 ohm +5% 1/2 w					745 1134 00
1	RC20BF154	R-2204, R-2216	Resistor, 150,000 ohm +5% 1/2 w					745 1176 00
1	RC20BF221	R-216	Resistor, 220 ohm +10% 1/2 w					745 1058 00
1	RC20BF221	R-2217	Resistor, 220 ohm +20% 1/2 w					745 1059 00
1	RC20BF222	R-2215	Resistor, 2200 ohm +5% 1/2 w					745 1099 00
1	RC20BF224	R-209, R-2212B	Resistor, 220,000 ohm +10% 1/2 w					745 1183 00
1	RC20BF333	R-2208	Resistor, 33,000 ohm +5% 1/2 w					745 1148 00
2	RC20BF473	R-2203, R-2205, R-2206	Resistor, 47,000 ohm +10% 1/2 w					745 1156 00
2	RC20BF474	R-205, R-210, R-2213, R-2214	Resistor, 470,000 ohm +10% 1/2 w					745 1198 00
1	RC20BF474	R-212	Resistor, 470,000 ohm +5% 1/2 w					745 1197 00
1	RC20BF750	R-134	Resistor, 75 ohm +5% 1/2 w					745 1039 00
1	RC20BF754	R-213	Resistor, 750,000 ohm +5% 1/2 w		2360	BT1/2- Navy		745 1207 00
1	RC21BF100K	R-135	Resistor, 10 ohm +10% 1/2 w					745 2002 00
1	RC21BF104	R-1906	Resistor, 100,000 ohm +20% 1/2 w					745 2171 00
1	RC30BF104	R-102, R-107	Resistor, 100,000 ohm +10% 1 w					745 3170 00
1	RC30BF153	R-401, R-2209	Resistor, 15,000 ohm +10% 1 w					745 3135 00
1	RC30BF222	R-207	Resistor, 2200 ohm +10% 1 w					745 3100 00
1	RC30BF223	R-101	Resistor, 22,000 ohm +10% 1 w					745 3142 00
1	RC30BF223	R-137	Resistor, 22,000 ohm +20% 1 w					745 3143 00
1	RC30BF224	R-2211	Resistor, .22 meg +10% 1 w					745 3184 00

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>RESISTORS (Cont.)</u>								
1	RC30BF241	R-214, R-215	Resistor, 240 ohm $\pm 5\%$ 1 w					745 3060 00
3	RC30BF470	R-103, R-104, R-106, R-108, R-112	Resistor, 47 ohm $\pm 20\%$ 1 w					745 3031 00
	RE13A372G	Alternate R-137	Resistor, 22,000 ohm $\pm 20\%$ 1 w					729 7224 40
	RW15F102	Alternate R-1905	Resistor, 1000 ohm $\pm 5\%$ 20 w					746 2540 00
1	RW55E201	Alternate R-1902, R-1904 R-902	Resistor, 200 ohm $\pm 5\%$ 2 w Resistor, 500 ohm "T" pad attenuator		2360	CSMPD		747 7533 00 380 2010 00 or 380N201
1		R-1903	Resistor, Two section, 13.4 ohm $\pm 5\%$, 6.7 ohm $\pm 5\%$, max current .5 amp		3450			717 4100 00
		Alternate R-2208	Resistor, 33,000 ohm $\pm 10\%$ 1/2 w		2360	BT1/2- Navy		729 5334 20 or 729NE33M-1
<u>SWITCHES</u>								
1	-24003 -24003-A	Alternate S-901 S-201	Switch, Toggle, DPDT Switch, Toggle, DPDT 1 amp 250 v		1883	IGA4C56		266 0002 00 266 0004 00
	-24195	Alternate S-1905	Switch, Push toggle, normally open, interlock					266 0001 00
1	-24458	S-1906	Switch, Toggle, DPST 20 amp 250 v					260 0007 00

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

<u>Quantity</u>	<u>Navy or JAN Type Number</u>	<u>All Symbol Designations Involved</u>	<u>Description</u>	<u>Navy Spec. or Dwg. No.</u>	<u>Mfr. Code</u>	<u>Mfr's Designation</u>	<u>Spcl. Tol. or Mod.</u>	<u>Contractor's Drawing or Part Number</u>
<u>SWITCHES (Cont.)</u>								
1	-24560	S-104	Switch, Toggle, SPST #20 amp 24 v		1010	8817		260 1100 00 or 260N110
	-24563	Alternate S-1905	Switch, Push toggle, normally open, interlock					266 0003 00
1	-24565	S-1907	Switch, Toggle, 3PDT 10 amp 250 v					260 0008 00
1	-24566	S-1908	Switch, Lever, multi-contact					502 0210 004
1	-24567	S-1902	Switch, Toggle, SPST					266 1010 00
1	-24569	S-112	Switch, Leaf, SPST		830	Y983A		508 0983 10
1	-24570	S-115	Switch, Leaf, SPST		830	Y-981A		508 0981 10 or Y-981A
1	-24571	S-113D	Switch, Leaf, SPST		830	Y-1048A		508 1048 10 or Y-1048A
1	-24572	S-114	Switch, Leaf, 1 SPDT 2 SPST		830	Y-1136B		508 1136 20 or Y-1136B
1		S-101A	Switch, Special moving arm		830	GA-1445A		571 1445 10 or GA-1445A
1		S-101B	Stationary arm		830	GA-2002A		571 2002 10 or GA-2002A
1		S-102	Switch, Rotary, 18 contact		830			500 0085 00B
1		S-103	Switch, Rotary, 7 contact		830			500 0206 00B
1		S-105	Switch, Rotary 3 pos 2 circuit non-shorting		3410			259 1391 00 or 259N139A
1		S-106	Switch, Rotary, 5 circuit 3 position 2 pi		3410			259 0004 00
1		S-107	Switch, Rotary, 2 pos 4 circuit shorting		3410			259 1411 00 or 259N141A
1		S-108	Switch, Rotary, 12 contact non-shorting		3410			259 1401 00 or 259N140A

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
1	S-109	S-110	Switch, Rotary, 12 contact shorting		3410	25851-DH-L		259 1371 00 or 259N137A 259 1362 00 or 259N136B 571 1557 20
1	S-111	S-111	Switch, leaf, SPDT circuit shorting		830	GA-1557B		502 4170 002 571 0885 30
1	Alternate S-111	S-113	Switch, leaf, SPDT		830	186P-1		
1	S-113C	S-113	Switch, Multi-Element S-113A complete with ceramic capacitors		830	GA-1074A		571 1074 10 or GA-1074A
1	Alternate S-114	S-116, S-3004	Switch, Special SPDT 8 amp 250 v vacuum sealed		1881	GI-34		500 0247 002 260 6010 004 or 260N601 259 1490 00 or 259N149
1	S-202	S-202	Switch, Rotary, 1 sect 6 cont, shorting type		3030	GA-1021A		571 1021 10 or GA-1021A
1	S-401	S-401	Switch, Rotary assem, LF osc		830	GA-1544B		571 1544 20 or GA-1544B
1	S-401	S-401	Switch, Stator assem, LF osc		830	GA-1544B		571 1544 20 or GA-1544B
1	S-901	S-901	Switch, Toggle, DPT 1 amp 250 v		2160	20905-GH		266 1030 00 or 266N103 259 1421 00 or 259N142A
1	S-902	S-902	Switch, Rotary, 11 cont non-shorting		3410			259 1361 00 or 259N1361
1	S-903	S-903	Switch, Rotary, 3 circuit 4 pos, 2 deck					266 1050 00
1	S-1905	S-1905	Switch, Push toggle, normally open, interlock					

SWITCHES (Cont.)

10694

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>SWITCHES (Cont.)</u>								
1		S-1909	Switch, Start, black normally open and normally closed					260 2020 00
1		S-1910	Switch, Stop, red normally opened and normally closed					260 2030 00
1		S-3001	Switch, 2 sections SPDT (DPDT)					502 5300 004
1		S-3002	Switch Shaft, assem		830			502 1747 003
1		S-3002	Switch Stator, assem		830			502 1748 002
3		S-3002,S-3003	Standoff, 3/8" x 2" ceramic		830			507 6158 00
1		S-3003	Switch Shaft, assem		830			502 5116 002
1		S-3003	Switch Stator, assem		830			502 5117 002
<u>TRANSFORMERS</u>								
1	-47912	T-102	Transformer, RF					571 1716 20
1	-302035	T-101	Transformer, Modulation Pri: 15,000 ohm CT 150 ma Secd #1: 7300 ohm Secd #2: 970 ohm 300 to 4000 cps ±2 db		780	7950		677 0002 00
1	-302036	T-201	Transformer, Audio coupling Pri: 75 ohm Secd: 125,000 ohm 100 - 5000 cps		780	7823		677 2590 00 or 677N259
1	-302037	T-202	Transformer, Audio coupling Pri: 5000 ohm 30 ma Secd: 2000 ohm 300 - 4000 cps		780	7821		677 2530 00 or 677N253
1	-302038	T-203	Transformer, Sidetone					677 2540 00
1	-302039	T-901	Transformer, Speaker Input: 500 ohm to 6 ohm voice coil					667 7051 00

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>TRANSFORMERS (Cont.)</u>								
1	-302040	T-1901	Transformer, Coupling Pri: 200,400,600 ohms Secd: 42,60,82,106 ohms		780			677 2610 00
<u>VACUUM TUBES</u>								
4	6V6	Alternate V-202,V-203	Tube, Vacuum, beam pentode		**	6V6		254 0198 00
2	6V6GT/G	V-202,V-203	Tube, Vacuum, beam pentode		**	6V6GT		254 0200 00
2	12SA7	V-2202	Tube, Vacuum, pentode converter		**	12SA7		254 0247 00
2	12SA7GT/G	Alternate V-2202	Pentagrid Converter		**	12SA7/GT		254 0248 00
2	12SJ7	V-201	Tube, Vacuum, triple grid amplifier		**	12SJ7		254 0254 00
1	12SJ7/GT	Alternate V-201	Tube, Vacuum, triple grid amplifier		**	12SJ7/GT		254 0255 00
4	12SL7GT	V-2201,V-2203	Dual Triode		**	12SL7GT		254 0258 00
4	811	V-105,V-106	Tube, Vacuum, triode		**	811		254 0395 00
2	813	V-104	Tube, Vacuum, beam pentode		**	813		254 0397 00
2	837	V-101	Tube, Vacuum, beam pentode		**	837		254 0406 00
6	1625	V-102,V-103, V-401	Tube, Vacuum, beam pentode		**	1625		254 0458 00
<u>CABLES</u>								
1			Cable, 27 conductor, control					500 1496 00D
1			Cable, 10 conductor, power					or 65X-7 500 1497 00D

** Standard vacuum tubes are supplied by numerous well-known manufacturers.
10696

or 65X-8

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

<u>Quantity</u>	<u>Navy or JAN Type Number</u>	<u>All Symbol Designations Involved</u>	<u>Description</u>	<u>Navy Spec. or Dwg. No.</u>	<u>Mfr. Code</u>	<u>Mfr's Designation</u>	<u>Spcl. Tol. or Mod.</u>	<u>Contractor's Drawing or Part Number</u>
<u>CABLES (Cont.)</u>								
1			Cable, 2 conductor, relay power					500 1498 00C or 65X-9
1			Cable, 27 conductor, remote					500 4474 004 or 65X-10
<u>SOCKETS</u>								
2	-49366	X-101,X-102, X-103,X-401 Alternate X-101,X-102, X-103,X-401	Socket, Tube, 7 prong, ceramic		2570	227		220 5730 00 or 220N573
1	-49951	X-2204	Crystal Socket		810	9816		220 1006 00 292 0012 00
1		X-104	Socket, Tube, 7 prong, wafer ceramic		2570	237		220 5711 00 or 220N571A
1		X-105,X-106	Socket, Tube, 4 prong, ceramic		2570	224		220 5450 00 or 220N545
3		X-201,X-202, X-203,X-2201, X-2202,X-2203	Socket, Tube, octal ceramic		200	88-8		220 1850 00 or 220N185
<u>CRYSTAL</u>								
1		Y-2201	Crystal, Quartz, mounted freq 200 kc		830			291 0002 00
<u>TUNED CIRCUIT ASSEMBLIES</u>								
1	-47911	Z-2202A, Z-2202B	Inductor assembly		70			278 0002 00
1 10697	-47923	Z-2201A, Z-2201B	Inductor assembly		70			278 0001 00

TABLE 6-4
EQUIPMENT SPARE PARTS LIST BY NAVY TYPE NUMBERS

Quantity	Navy or JAN Type Number	All Symbol Designations Involved	Description	Navy Spec. or Dwg. No.	Mfr. Code	Mfr's Designation	Spcl. Tol. or Mod.	Contractor's Drawing or Part Number
<u>MISCELLANEOUS (Cont.)</u>								
1			Screwdriver, Phillips #1		4707			024 3000 00
1			Screwdriver, Phillips #2		4707			024 3100 00
1			Screwdriver, .070" shank		4296	555C		024 0015 00
1			Crank, Autotune		830	GA-1149A		571 1149 10 or 1149-A
1			Wrench, External spanner		830			507 5733 00 or X-5733
1			Wrench, Internal spanner		830			507 5734 00 or X-5734
2			Track Channel, assem		830			571 0821 30
1			L Track channel		830			500 4278 002
1			R Track channel		830			500 4279 002
1			Feeler Gauge .005"		830			500 9135 001
2			Spare Parts boxes		830			500 6656 004 or 502 7025 004
1			Spare Parts box		830			500 3535 004 or 502 7026 004
3			Spare Parts box seal		830			004 7490 00

2. APPLICABLE COLOR CODES.

a. HOOKUP WIRE CODE. - This wire code is the standard code for all unit wiring in connection with the Model TCZ-2 Radio Transmitting Equipment.

(1) Two classes of wire are employed, consisting of flame resistance and bus bar.

(2) Flame resistant wire is supplied in two degrees of insulation rated at 1000 volts and 3000 volts. The voltage rating of the wire is indicated by an identification thread in the strands of the conductor. A blue thread indicates 1000 volts insulation while a white thread indicates 3000 volts insulation. Two other threads of different colors serve to indicate the manufacturer of the wire and the year in which it was made.

(3) Standard RMA Color Code Numerals are used for designating the body color and the color of the tracers. This code is as follows:

0 - Black	5 - Green
1 - Brown	6 - Blue
2 - Red	7 - Violet
3 - Orange	8 - Gray
4 - Yellow	9 - White

NOTE

Wires employing code numbers 7 and 8, also 4, are not used.

(4) The wire color code is made up of a letter designating the wire size and voltage rating of insulation followed by numerals designating the body color and the colors of up to three tracers.

(5) A shielded flame resistant wire is indicated by inserting the letter S after the first letter of the code. Example: AS956 indicates a white wire with green and blue tracers in a tinned shielding braid.

(6) The wire code used in the NAVY MODEL TCZ-2 Equipment is as follows:

CABLE WIRE CODE

Color Code	Body Color	First Tracer Color	Second Tracer Color	Third Tracer Color	Wire Specifications
*A9	White				No. 22 A.W.G Flameproof Insulation Lacquered Glass Braid 1000 volt rating
*A90	White	Black			
*A92	White	Red			
*A93	White	Orange			
*A95	White	Green			
*A96	White	Blue			
A902	White	Black	Red		
A9020	White	Black	Red	Black	
A9023	White	Black	Red	Orange	
A9025	White	Black	Red	Green	
A9026	White	Black	Red	Blue	
A903	White	Black	Orange		
A9030	White	Black	Orange	Black	
A9035	White	Black	Orange	Green	
A9036	White	Black	Orange	Blue	
A905	White	Black	Green		
A9050	White	Black	Green	Black	
A906	White	Black	Blue		
A9060	White	Black	Blue	Black	
A9202	White	Red	Black	Red	
A923	White	Red	Orange		
A925	White	Red	Green		
A9252	White	Red	Green	Red	
A9256	White	Red	Green	Blue	
A926	White	Red	Blue		
A9262	White	Red	Blue	Red	
A9303	White	Orange	Black	Orange	
A935	White	Orange	Green		
A9353	White	Orange	Green	Orange	
A9356	White	Orange	Green	Blue	
A936	White	Orange	Blue		
A9363	White	Orange	Blue	Orange	
A9505	White	Green	Black	Green	
A9525	White	Green	Red	Green	
A9535	White	Green	Orange	Green	
A956	White	Green	Blue		
A9606	White	Blue	Black	Blue	
A9626	White	Blue	Red	Blue	
A9636	White	Blue	Orange	Blue	

Color Code	Body Color	First Tracer Color	Second Tracer Color	Third Tracer Color	Wire Specifications
B9 *B90 B91 B92 B93 B94 B95 B96 B902 B925	White White White White White White White White White White	Black Brown Red Orange Yellow Green Blue Black Red		Red Green	No. 20 A.W.G. Flameproof Insulation Lacquered Glass Braid 1000 volt rating
C9 C90 C92 C95 C96 C902 C903 C925 C935 *CS93	White White White White White White White White White White	Black Red Green Blue Black Black Red Orange Orange		Red Orange Green Green	No. 18 A.W.G. Flameproof Insulation Lacquered Glass Braid 1000 volt rating
D9 D90 D91 D92 D93 D95 D96 D902 D903 D925 D935 D936	White White White White White White White White White White White White White	Black Brown Red Orange Green Blue Black Black Red Orange Orange		Red Orange Green Green Blue	No. 16 A.W.G. Flameproof Insulation Lacquered Glass Braid 1000 volt rating
E9 E90 E92 E93 E95 E96 E902 E903 E920 E925	White White White White White White White White White White	Black Red Orange Green Blue Black Black Red Red		Red Orange Black Green	No. 14 A.W.G. Flameproof Insulation Lacquered Glass Braid 1000 volt rating

Section VI
Paragraph 2

RESTRICTED

Color Code	Body Color	First Tracer Color	Second Tracer Color	Third Tracer Color	Wire Specifications
F9 F91 F96 F906	White White White White	Brown Blue Black	Orange		No. 12 A.W.G. Flameproof Insulation Lacquered Glass Braid 1000 volt rating
J9 J90	White White	Black			No. 6 A.W.G. Flameproof Insulation Lacquered Glass Braid 1000 volt rating
L92 L96	White White	Red Blue			No. 20 A.W.G. Flameproof Insulation Lacquered Glass Braid 3000 volt rating
N90 N92 N95 N96 N902 N906	White White White White White White	Black Red Green Blue Black Black	Red Blue		No. 16 A.W.G. Flameproof Insulation Lacquered Glass Braid 3000 volt rating

RESTRICTED


10481

b. CODE FOR BUS-BAR. - The code for bus-bar is made up of the letter designation BB followed by the wire size as shown below:


#20 - BB20
#18 - BB18
#16 - BB16

#14 - BB14
#12 - BB12

COLOR CODE FOR FIXED RESISTORS—VALUES IN OHMS



Resistor with axial wire leads.



Resistor with radial wire leads.

BODY		END		DOT OR BAND		END	
1st Band		2nd Band		3rd Band		End Band	
Color	Value	Color	Value	Color	Value	Color	Tolerance
Black.....	0	Black.....	0	Gold.....	0.1	Gold.....	(J) ± 5%
Brown.....	1	Brown.....	1	Silver.....	0.01	Silver.....	(K) ± 10%
Red.....	2	Red.....	2	Black.....	None	None.....	(M) ± 20%
Orange.....	3	Orange.....	3	Brown.....	0		
Yellow.....	4	Yellow.....	4	Red.....	00		
Green.....	5	Green.....	5	Orange.....	000		
Blue.....	6	Blue.....	6	Yellow.....	0000		
Violet.....	7	Violet.....	7	Green.....	00000		
Gray.....	8	Gray.....	8	Blue.....	000000		
White.....	9	White.....	9	Violet.....	0000000		
				Gray.....	00000000		
				White.....	000000000		

EXAMPLE FOR AXIAL-LEAD RESISTOR

Band	Color	Significant Figures		Number of Zeros	Tolerance
		1st	2nd		
1	Red	2
2	Orange	...	3
3	Yellow	0000	...
4	Gold	±5%

The resistance of this resistor is 230,000 ohms ±5%

EXAMPLE FOR RADIAL-LEAD RESISTOR


Position	Color	Significant Figures		Number of Zeros	Tolerance
		1st	2nd		
Body	Orange	3
End	Blue	...	6
Dot	Green	00000	...
End	Silver	±10%

The resistance of this resistor is 3,600,000 ohms ±10%

COLOR CODE FOR FIXED MICA CAPACITORS

Color	CAPACITANCE *		Tolerance	Characteristic
	Significant Figure	Decimal Multiplier		
Black	0	1	20 per cent (M)	A
Brown	1	10	1 per cent	B
Red	2	100	2 per cent (G)	C
Orange	3	1,000	3 per cent	D
Yellow	4	...	4 per cent	E
Green	5	...	5 per cent	F
Blue	6	...	6 per cent	G
Violet	7	...	7 per cent	...
Gray	8	...	8 per cent	...
White	9	...	9 per cent	...
Gold	...	0.1	5 per cent (J)	...
Silver	...	0.01	10 per cent (K)	...

* Capacitance in micromicrofarads.



Color code scheme for JAN standard fixed mica capacitors. The significance of the letters denoting "characteristic" will be found in the Joint Army-Navy Specification JAN-C-5.

3. MANUFACTURERS OF REPLACEABLE PARTS.

TABLE 6-5 - LIST OF MANUFACTURERS

30	Aerovox Corporation 740 Belleville Avenue New Bedford, Mass.	780	Chicago Transformer Corp. 3501 Addison Street Chicago, 18, Illinois
60	The Akron Porcelain Co. Akron, Ohio	810	Cinch Manufacturing Corp. 2335-2347 W. Van Buren St. Chicago, 12, Illinois
70	Aladdin Radio Industries, Inc. 223 West Jackson Boulevard Chicago, Illinois	830	Collins Radio Company 855 35th Street N.E. Cedar Rapids, Iowa
90	Allen-Bradley Company 136 West Greenfield Avenue Milwaukee, 4, Wisconsin	880	Continental Rubber Works Erie, Pennsylvania
200	American Phenolic Corporation 1830 South 54th Avenue Chicago, Illinois	911	Cornell-Dubilier Corporation 333 Hamilton Blvd. South Plainfield, 6, New Jersey
230	American Steel Package Co. Defiance, Ohio	950	Coto-Coil Company, Inc. 65 Pavilion Ave. Providence, 5, Rhode Island
284	Automatic Electric Sales Corp. 1033 W. Van Buren St. Chicago, 7, Illinois	1010	Cutler-Hammer, Inc. 315 N. 12th St. Milwaukee, Wisconsin
287	Automatic Electric Mfg. Co. Mankato, Minnesota	1200	Drake Manufacturing Company 1713 West Hubbard Street Chicago, Illinois
360	Belden Manufacturing Company P.O. Box 507A Chicago, 80, Illinois	1320	Hugh H. Eby, Inc. 18 W. Chelton Avenue Philadelphia, 44, Pa.
500	Bristol Company 66 Bride Street Waterbury, 91, Conn.	1384	Electronic Laboratories, Inc. 122 West New York Street Indianapolis, Indiana
630	Cannon Electric Development Co. 3209 Humboldt Street Los Angeles, 31, California	1390	Emerson Electric Mfg. Co., Inc. 1824 Washington Ave. St. Louis, 3, Missouri
700	Centralab 900 E. Keefe Avenue Milwaukee, 1, Wisconsin		

Section VI
Paragraph 3

RESTRICTED

- | | | | |
|------|--|------|--|
| 1640 | John E. Fast and Co.
3123 N. Pulaski Road
Chicago, 41, Illinois | 2410 | Isolantite Incorporated
Belleville, New Jersey |
| 1740 | Fractional Motors
1501 North Halsted
Chicago, Illinois | 2520 | Jefferson Electric Co.
Bellwood, Illinois |
| 1820 | G. M. Laboratories, Inc.
4314-26 North Knox Ave.
Chicago, Illinois | 2525 | Jensen Radio Manufacturing Co.
6601 S. Laramie Avenue
Chicago, 38, Illinois |
| 1880 | General Electric Co.
1 Plastics Ave.
Pittsfield, Mass. | 2570 | E. F. Johnson Company
Waseca, Minnesota |
| 1881 | General Electric Co.
840 S. Canal Street
Chicago, Illinois | 2580 | Howard B. Jones
2460 W. George St.
Chicago, 18, Illinois |
| 1883 | General Electric Co.
Appliance and Mdse. Dept
1285 Boston Ave.
Bridgeport, Conn. | 2850 | Layelle Rubber Company
424 North Wood Street
Chicago, Illinois |
| 1888 | General Electric Co.
Electronics Dept,
754 State Street
Schenectady, 7, N. Y. | 2920 | Littelfuse Incorporated
4757 Ravenswood Ave.
Chicago, 40, Illinois |
| 2040 | Groove Pin Corporation
2017 Kerrigan Ave.
Union City, New Jersey | 3030 | P. R. Mallory and Co., Inc.
3029 East Washington St.
Indianapolis, 6, Indiana |
| 2050 | Guardian Electric Mfg. Co.
1400 West Washington Blvd.
Chicago, 7, Illinois | 3040 | Maresh Sheet Metal Works
905 17th St., N. E.
Cedar Rapids, Iowa |
| 2140 | Hammarlund Mfg. Co., Inc.
460 West 34th Street
New York, 1, N. Y. | 3090 | Meissner Mfg. Co.
Mt. Carmel, Illinois |
| 2160 | Hart and Hegeman Division
Arrow Hart and Hegeman Elec. Co.
103 Hawthorne Street
Hartford, Connecticut | 3220 | National Company, Inc.
61 Sherman Street
Malden, 48, Massachusetts |
| 2350 | Insuline Corp. of America
The Insuline Building
3602 35th Ave
Long Island City, New York | 3240 | National Fabricated Products Co.
2650 West Belden Avenue
Chicago, 47, Illinois |
| 2360 | International Resistance Co.
401 North Broad Street
Philadelphia, 8, Pennsylvania | 3330 | New Departure
Div. General Motors Corp.
Bristol, Conn. |
| | | 3410 | Oak Manufacturing Company
1260 Clybourn Avenue
Chicago, 10, Illinois |
| | | 3450 | Ohmite Manufacturing Company
4835 West Flournoy Street
Chicago, 44, Illinois |

RESTRICTED

10484

3580	Pheoll Manufacturing Co. 5700 Roosevelt Road Chicago, 50, Illinois	4704	Vaco Products, Co. 317 East Ontario Chicago, Illinois
3846	Raytheon Production Corp. 55 Chapel Street Newton, Massachusetts	4870	Western Electric Co., Inc. 300 Central Kearny, New Jersey
4030	Sangamo Electric Company 1935 Funk Street Springfield, Illinois	4900	Westinghouse Elec. & Mfg. Co. East Pittsburgh, Pennsylvania
4170	F. W. Sickles Company Box 920 Springfield, 2, Massachusetts	4910	Weston Elec. Instrument Corp. Newark, New Jersey
4210	Solar Manufacturing Corp 285 Madison Ave. New York, 17, New York	4960	Wincharger Corporation East 7th at Division St. Sioux City, 6, Iowa
4217	Soreng Manegold Company 1901 Clybourn Avenue Chicago, Illinois	4975	Wirt Company 5221-27 Green Street Germantown, Philadelphia, Pa.
4220	Walter Speck 225 N. Pine St. Langhorne, Pa.		
4230	Speer Resistor Corp. St. Mary's, Pennsylvania		
4240	Sperti Inc. Beech and Kenilworth Aves. Norwood Station Cincinnati, Ohio		
4250	Sprague Specialties Company North Adams, Massachusetts		
4296	The L. S. Starrett Co. Athol, Mass.		
4310	Struthers Dunn Incorporated 1321 Arch St. Philadelphia, 7, Pa.		
4335	S. W. Inductor Company 1056-58 North Wood Street Chicago, 22, Illinois		
4640	United States Rubber Co. 440 W. Washington Street Chicago, 6, Illinois		




Figure 7-1 Navy Type COL-52286-A Transmitter Unit - Front Open View





Figure 7-2 Navy Type COL-52286-A Transmitter Unit - Top Open View

Figure 7-3 Navy Type COL-52286-A Transmitter - Bottom View






Figure 7-4 High Frequency Oscillator - Side Open View




Figure 7-5 Frequency Multiplier - Side Open View




Figure 7-6 Fire Wall Assembly - Top View




Figure 7-7 Fire Wall Assembly - Bottom View



Figure 7-8 Low Frequency Oscillator Unit - Front View




Figure 7-9 Low Frequency Oscillator Unit - Top Open View




Figure 7-10 Low Frequency Oscillator Unit - Bottom Open View




Figure 7-11 MCW-CFI Unit - Top View




Figure 7-12 MCW-CFI Unit - Bottom View




Figure 7-13 Audio Amplifier Unit - Top View




Figure 7-14 Audio Amplifier Unit - Bottom View




Figure 7-15 Multi-Element Switch - Right Side View




Figure 7-16 Multi-Element Switch - Left Side View




Figure 7-24 Navy Type COL-23410 Remote Control Unit - Top View




Figure 7-25 Navy Type COL-23410 Remote Control Unit - Bottom View




Figure 7-26 Navy Type COL-47505 Antenna Loading Coil Unit - Front View




Figure 7-27 Navy Type COL-47505 Antenna Loading Coil Unit - Top Open View




Figure 7-28 Navy Type COL-47505 Antenna Loading Coil Unit -
Right Side Open View




Figure 7-29 Navy Type COL-47505 Antenna Loading Coil Unit -
Left Side Open View




Figure 7-30 Navy Type COL-481628 Antenna Shunt Capacitor -
Top View




Figure 7-31 96J Autotune Singleturn Unit - Left Side View




Figure 7-32 96J Autotune Singleturn Unit - Right Side View




Figure 7-33 96K Autotune Multiturn Unit - Left Side View





Figure 7-34 96K Autotune Multiturn Unit - Right Side View

Figure 7-35 Autotune Casting



NOTE: ALL FRACTIONAL DIMENSIONS
 $\pm 1/32$ UNLESS OTHERWISE NOTED.

WEIGHT: 66 POUNDS










Figure 7-36 Navy Type COL-52286-A Radio Transmitter Installation Diagram

Figure 7-36 Navy Type COL-52286-A Radio Transmitter Installation Diagram



WEIGHT - 210 LBS. UNCRATED
376 LBS. CRATED

CONTENTS OF CRATED UNIT - 22 CU. FT.

DIMENSIONS OF CRATED UNIT
31 ¹/₂" x 37 ¹/₂" x 27"

HEAT DISSIPATION - 300 WATTS

VENTILATION - THROUGH LOUVERS ON REAR, LEFT, & RIGHT SIDES.

CABLE ENTRANCES - VIA OPEN UNDERSIDE OF UNIT.

Figure 7-37 Navy Type COL-211624 Dynamotor Assembly Power Unit Installation Diagram

Figure 7-37 Navy Type COL-211624 Dynamotor Assembly Power Unit Installation Diagram





Figure 7-38 Navy Type COL-23410 Remote Control Unit Installation Diagram



UNIT WEIGHT 48 LBS.

SIZE OF MOUNTING HOLES $\frac{.257}{.262}$





Figure 7-39 Navy Type COL-47505 Antenna Loading Coil Unit Installation Diagram

WEIGHT: 1 POUND 9.5 OZ.







Figure 7-40 Navy Type COL-481628 Antenna Shunt Capacitor Installation Diagram






QTY.	ITEM NO.	DESCRIPTION	COLLINS PART NO.	MFG. PART NO.	MFG.
1	P1501	CONNECTOR PLUG - FEMALE	371 4060 00	NK-27-21-C11/16	10C
1	P1502	CONNECTOR PLUG - MALE	371 4049 00	RNK-27-22-C11/16	10C
.9	W1501	CABLE	424 2710 00		24B
1.2		.118 INSULATING SLEEVING	152 1226 00		
0.3		#22 HOOKUP WIRE -A90-	440 0902 00		
0.1		.166 INSULATING SLEEVING	152 1223 00		



NOTE: ALL WIRES ARE OF THE SAME GAUGE. CONNECT PINS IN P1501 TO LIKE NUMBERED PINS IN P1502.

- CUT THE CABLE TO THE PROPER LENGTH FOR THE INSTALLATION INVOLVED. ALLOW ENOUGH ADDITIONAL LENGTH SO THAT THE RADIUS OF ANY BEND IN THE CABLE IS NEVER LESS THAN 8 INCHES, AND THE CABLE IS NOT TIGHT ENOUGH TO INTERFERE WITH THE ACTION OF THE SHOCKMOUNTS, OR TO DAMAGE THE CONNECTIONS.
- CHECK DRAWING FOR PROPER CABLE LAY.
- FOR PLUG P1502, CUT THE LACQUERED COTTON BRAID AND RESIN TAPE 1-3/16 INCH FROM THE END OF THE CABLE. (A)
- SOLDER A 3/16 INCH LENGTH OF THE BRAIDED COPPER SHIELD MEASURED FROM THE LACQUERED COTTON BRAID; UNBRAID THE SHIELD AND CUT OFF THE LOOSE WIRES AND COTTON BRAID EVEN WITH THE SOLDERED PORTION OF THE BRAIDED COPPER SHIELD. (B)
- UNBRAID THE SHIELD ON #20 WIRE, TURN BACK AND SOLDER TO MAIN SHIELD. (C)
- STRIP INSULATION 1/4 INCH BACK FROM ENDS OF WIRES.
- ON WIRE #19 TWIST AND SOLDER A PIECE OF #22 WIRE, BRING BACK AND SOLDER TO MAIN SHIELD. (D)
- TIN ENDS OF WIRES
- SLIP THE PLUG CAP AND LOCKING RING OVER CABLE.
- SLIP A 1/2 INCH PIECE OF VARNISHED TUBING OVER EACH WIRE. USE VARNISHED TUBING WHICH GIVES A SNUG FIT.
- SOLDER WIRES TO PLUG TERMINALS AND SLIP VARNISHED TUBING OVER THE CONNECTION.
- INSTRUCTIONS APPLY TO PLUG P1501 EXCEPT INSTRUCTIONS #3 SUBSTITUTE 1 3/4 INCHES IN #3
- USE RESIN CORE SOLDER FOR ALL SOLDERED CONNECTIONS.
- SYMBOL DESIGNATIONS AS SHOWN TO BE STAMPED ON PARTS, (NONE ON CABLE).



TOOLS RECOMMENDED FOR ASSEMBLY OF CABLE
 WIRE STRIPPER
 LONG NOSE PLIERS
 SIDE CUTTING PLIERS
 SCREW DRIVER
 SOLDERING IRON








Figure 7-41 65X-7 Control Cable Assembly Diagram



QTY.	ITEM NO.	DESCRIPTION	COLLINS PART NO.	MFG. PART NO.	MFG.
1	PI601	CONNECTOR PLUG-FEMALE	371 5140 00	FK-10-21-C 9/16	10C
1	PI602	CONNECTOR PLUG-MALE	371 5129 00	RFK-10-24-C 9/16	10C
1.2	W1601	CABLE-10 CONDUCTOR FT.	424 1010 00		24B
0.7'	E	.118 INSULATING SLEEVING, FT.	152 1226 00		
0.3'	D	#22 HOOK-UP WIRE -A9-, FT.	440 0901 2901 00		
0.2'	F	166 INSULATING SLEEVING, FT.	152 1223 7440 00		



- CUT THE CABLE TO THE PROPER LENGTH FOR THE INSTALLATION INVOLVED. ALLOW ENOUGH ADDITIONAL LENGTH SO THAT THE RADIUS OF ANY BEND IN THE CABLE IS NEVER LESS THAN 8 INCHES AND THE CABLE IS NOT TIGHT ENOUGH TO INTERFERE WITH THE ACTION OF THE SHOCKMOUNTS OR TO DAMAGE THE CONNECTORS.
- CHECK DRAWING FOR PROPER CABLE LAY.
- FOR PLUG PI601 CUT THE LACQUERED COTTON BRAID AND RESIN TAPE $1\frac{3}{16}$ INCH FROM THE END OF THE CABLE. (A)
- SOLDER A $\frac{3}{16}$ INCH LENGTH OF THE BRAIDED COPPER SHIELD MEASURED FROM THE LACQUERED COTTON BRAID, UNBRAID THE SHIELD AND CUT OFF THE LOOSE WIRES AND THE COTTON BRAID EVEN WITH THE SOLDERED PORTION OF THE BRAIDED COPPER SHIELD. (B)
- STRIP INSULATION BACK $\frac{1}{4}$ INCH FROM ENDS OF THE WIRES.
- TWIST AND SOLDER A PIECE OF #22 WIRE TO #5 WIRE, BRING BACK AND SOLDER TO SHIELD. (C)
- TIN ENDS OF WIRES, & SLIP SLEEVING (E) AND (F) OVER CONDUCTORS.
- SLIP THE PLUG CAP AND LOCKING RING OVER CABLE.
- SLIP A $\frac{1}{2}$ INCH PIECE OF VARNISHED TUBING OVER EACH WIRE. USE VARNISHED TUBING WHICH GIVES A SNUG FIT.
- SOLDER WIRES TO PLUG TERMINALS AND SLIP VARNISHED TUBING OVER THE CONNECTIONS.
- WHEN ALL WIRES HAVE BEEN SOLDERED TO THE PLUG TERMINALS FASTEN THE PLUG CAP AND LOCKING RING OVER THE PLUG TERMINALS AND TIGHTEN THE CABLE CLAMP.
- INSTRUCTIONS APPLY TO PLUG PI602 EXCEPT INSTRUCTION #3. SUBSTITUTE $1\frac{3}{4}$ INCH IN THIS INSTRUCTION.
- USE RESIN CORE SOLDER ON ALL SOLDERED CONNECTIONS.
- SYMBOL DESIGNATIONS AS SHOWN TO BE STAMPED ON PARTS (NONE ON CABLE).



TOOLS RECOMMENDED FOR ASSEMBLY OF CABLE

WIRE STRIPPER
LONG NOSE PLIERS
SIDE-CUTTING PLIERS
SCREWDRIVER
SOLDERING IRON







Figure 7-42 65X-8 Power Cable Assembly Diagram



REQ'D	ITEM NO.	DESCRIPTION	COLLINS PART NUMBER	MFG. PART NUMBER	MFG.
1	PI701	CONNECTOR PLUG - FEMALE	371 1090 00	WK-C3-23C 1/16	10C
1	PI702	CONNECTOR PLUG - MALE	371 1109 00	RWK-C3-22C 1/16	10C
2	E1701-2	SPLIT REDUCER BUSHING	371 1110 00		10C
10.5	WI701	CABLE 2 CONDUCTOR FT.	425 0350 00	*8422	24B
0.1	E	.118 INSULATING SLEEVING FT.	152 1226 00		
0.2	F	.168 INSULATING SLEEVING FT.	152 1223 00		

- CUT THE CABLE TO THE PROPER LENGTH. ALLOW ENOUGH ADDITIONAL LENGTH FOR STRIPPING BOTH ENDS OF WIRES.
- CHECK DRAWING FOR PROPER CABLE LAY.
- FOR PLUG PI702 CUT THE RUBBER COVERING $15/16$ INCHES FROM THE END OF THE CABLE (A).
- TURN BACK APPROXIMATELY $1/4$ INCH OF THE RUBBER COVERING. SOLDER A $3/16$ INCH LENGTH OF THE BRAIDED COPPER SHIELD MEASURED FROM THE RUBBER COVERING: UNBRAID THE SHIELD AND TWIST. CUT OFF THE COTTON WRAP EVEN WITH THE SOLDERED PORTION OF THE BRAIDED COPPER SHIELD (B).
- STRIP INSULATION BACK $1/4$ INCH FROM ENDS OF WIRES.
- TIN ENDS OF WIRES, & SLIP SLEEVING (E) & (F) OVER CONDUCTORS.
- TIN THE TWISTED SHIELD (C) $5/8$ INCH FROM END AND SOLDER TO #1 PIN ON THE CONDUCTOR PLUG.
- PUSH RUBBER COVERING BACK OVER SHIELDING.
- SLIP THE PLUG CAP AND LOCKING RING OVER CABLE.
- SOLDER WIRES TO PLUG TERMINALS.
- FASTEN THE PLUG CAP AND LOCKING RING OVER THE PLUG TERMINALS AND TIGHTEN CABLE CLAMP.
- INSTRUCTIONS APPLY TO PI701, EXCEPT INSTRUCTIONS #4, #7 & #8 SUBSTITUTE $1/4$ INCHES IN #3.
- USE ROSIN CORE SOLDER FOR ALL SOLDERED CONNECTIONS.
- SYMBOL DESIGNATIONS AS SHOWN TO BE STAMPED ON PARTS (NONE ON CABLE).



TOOLS RECOMMENDED FOR ASSEMBLY OF CABLE

WIRE STRIPPER
LONG NOSE PLIERS
SIDE-CUTTING PLIERS
SCREWDRIVER
SOLDERING IRON










Figure 7-43 65X-9 Antenna Loading Coil Cable Assembly Diagram



REQ'D	ITEM NO	PART NAME	COLLINS PART NO.	MFG. PART NO.	MFG.
1	P2301	FEMALE CONNECTOR	371 4020 00	NK-27-2IC 11/16	IOC
10.5	W2301	CABLE	424 8868 00		24B
27	A	SOLDER LUG	304 4900 00	WE134	2030
1.1	B	SLEEVING	152 1226 00		
.3	C	WIRE-22 A.W.G.	440 8988 00		
.8	H	FRICTION TAPE	004 0175 00		
.1	J	SLEEVING	152 1223 00		

TERM. NO.	CABLE DATA		CABLE DATA	
	CONDUCTOR COLOR	NUMBER OF RIDGES	CONDUCTOR BODY COLOR	FIRST TRACER SECOND TRACER
1	GRAY	0	GREEN	WHITE
2	BROWN	0	RED	WHITE
3	BROWN	1	ORANGE	WHITE BLACK
4	GRAY	1	BLUE	WHITE
5	WHITE	1	BLACK	
6	WHITE	2	GREEN	BLACK
7	BROWN	2	RED	BLACK
8	GREEN	2	WHITE	
9	WHITE	2	ORANGE	BLACK
10	BLACK	0	BLACK	WHITE
11	YELLOW	0	WHITE	BLACK
12	YELLOW	1	GREEN	BLACK
13	GREEN	1	BLACK	RED
14	RED	0	RED	
15	RED	1	BLUE	BLACK
16	BLACK	2	BLUE	
17	BLACK	1	WHITE	RED
18	YELLOW	2	RED	WHITE
19	ORANGE	2	WHITE	RED
20	White Black in Shield	0	BLUE (SHIELDED)	WHITE BLACK
21	GREEN	0	GREEN	
22	RED	2	ORANGE	
23	BLUE	0	BLACK	WHITE
24	ORANGE	1	ORANGE	RED
25	ORANGE	0	BLUE	RED
26	BLUE	2	RED	GREEN
27	BLUE	1	ORANGE	GREEN



- TOOLS RECOMMENDED FOR ASSEMBLY OF CABLE**
- WIRE STRIPPER
 - LONG NOSE PLIERS
 - SIDE CUTTING PLIERS
 - SCREW DRIVER
 - SOLDERING IRON

- NOTES:-**
- CUT CABLE TO PROPER LENGTH, ALLOWING ENOUGH ADDITIONAL LENGTH FOR STRIPPING BOTH ENDS OF WIRES.
 - CHECK DRAWING TO INSURE PROPER ASSEMBLY OF WIRES WITH THE TERMINALS ON THE PLUG.
 - FOR PLUG P2301:
 - CUT THE LACQUERED COTTON BRAID & RESIN TAPE 1 3/16 INCHES FROM THE END OF THE CABLE (D)
 - SOLDER A 3/16 INCH LENGTH OF THE BRAIDED COPPER SHIELD MEASURED FROM THE LACQUERED COTTON BRAID UNBRAID THE SHIELD AND CUT OFF THE LOOSE WIRES & COTTON BRAID EVEN WITH THE SOLDERED PORTION OF THE BRAIDED COPPER SHIELD (E)
 - UNBRAID THE SHIELD (F) ON CONDUCTOR 20. TURN BACK AND SOLDER TO MAIN SHIELD (E)
 - STRIP INSULATION 1/4 INCH BACK FROM THE ENDS OF THE CONDUCTORS
 - ON CONDUCTOR 19 TWIST & SOLDER ONE END OF WIRE (C) BRING BACK AND SOLDER TO MAIN SHIELD.
 - TIN ENDS OF CONDUCTORS
 - SLIP THE PLUG CAP & LOCKING RING OVER CABLE
 - SLIP SLEEVING (B) 1/2 IN LG. OVER EACH CONDUCTOR
 - SOLDER CONDUCTORS TO PLUG TERMINALS AND SLIP SLEEVING OVER CONNECTION
 - WRAP APPROXIMATELY 2 TURNS OF FRICTION TAPE (H) AROUND THE END OF THE LACQUERED COTTON BRAID & COPPER SHIELDING
 - FASTEN THE PLUG CAP & LOCKING RING OVER PLUG TERMINALS AND TIGHTEN CABLE CLAMP
 - FOR LUG END OF CABLE:
 - CUT THE LACQUERED COTTON BRAID & RESIN TAPE AS SHOWN FROM END OF CABLE
 - SOLDER A 3/16 INCH LENGTH OF THE BRAIDED COPPER SHIELD MEASURED FROM THE LACQUERED COTTON BRAID UNBRAID THE SHIELD AND CUT OFF LOOSE WIRES & COTTON BRAID EVEN WITH THE SOLDERED PORTION OF THE BRAIDED COPPER SHIELD
 - CABLE & CUT WIRES TO LENGTH PER TERMINAL BOARD 1545B AS SHOWN
 - CLAMP THE SOLDER LUGS (A) OVER THE ENDS OF THE CONDUCTORS & INSULATION AND SOLDER
 - WRAP APPROXIMATELY 2 TURNS OF FRICTION TAPE (H) AROUND THE END OF LACQUERED COTTON BRAID & COPPER SHIELDING
- 5- ALL DIMENSIONS IN INCHES UNLESS OTHERWISE SPECIFIED.
6- SYMBOL DESIGNATION AS SHOWN TO BE STAMPED ON PLUG, (NONE ON CABLE).

Figure 7-44 65X-10 Remote Control Cable Assembly Diagram




Figure 7-45 Navy Model TCZ-2 Complete Schematic

Figure 7-45 Navy Model TCZ-2 Complete Schematic




Figure 7-46 Navy Type COL-52286-A Transmitter Schematic




Figure 7-47 Navy Type COL-211624 Dynamotor Assembly Power Unit Schematic





Figure 7-48 Navy Type COL-23410 Remote Control Unit Schematic



NOTE: UNLESS OTHERWISE INDICATED, ALL RESISTANCE VALUES ARE IN OHMS, AND CAPACITY VALUES ARE IN MICROFARADS.

Figure 7-49 Navy Type COL-47505 Antenna Loading Coil Schematic




Figure 7-51 High Frequency Oscillator Practical Wiring Diagram




Figure 7-52 Multiplier Practical Wiring Diagram




Figure 7-53 Low Frequency Oscillator Practical Wiring Diagram







Figure 7-54 MCW-CFI Unit Practical Wiring Diagram

NOTE: C207 & C208 ARE MOUNTED ABOVE C201 & C202 ON TOP SIDE OF CHASSIS.



THIS LEAD TO GO BETWEEN CABLE AND CHASSIS AND SHORT AS POSSIBLE.

Figure 7-55 Audio Amplifier Practical Wiring Diagram



ITEM NO.	QTY.	COLLING PART NUMBER	QUANTITIES ARE FOR ONE ASSEMBLY	
			AMOUNT OF TYPE PART NUMBER	PART NAME
1	1	152 1610 00		INSULATED SLEEVINGS, FEET
2	1	152 1640 00		INSULATED SLEEVINGS, FEET
3	5	152 1970 00		INSULATED SLEEVINGS, FEET
4	3	304 1100 00		BRASS WASHERS
5	2	304 1500 00		1/4" SOLDER LUGS
6	40	304 1800 00		3/16" SOLDER LUGS
7	40	304 2000 00		3/16" SOLDER LUGS
8	45	304 5200 00		SPADE SOLDER LUG
9	8	313 0002 00		6-32 NUT
10	8	343 0169 00		4-32 x 5/16 PH. HEAD SCREW
11	1	11901 371 5118 00		27 TERMINAL CONNECTOR
12	1	11902 371 5118 00		10 TERMINAL CONNECTOR
13	8	373 0001 00		88 INTERNAL SHAKE WASHER
14	7	440 0401 00		WIRE, FEET
15	9	440 0403 00		WIRE, FEET
16	5	440 0408 00		WIRE, FEET
17	5	440 0409 00		WIRE, FEET
18	1	440 0410 00		WIRE, FEET
19	1	440 0411 00		WIRE, FEET
20	2	440 0413 00		WIRE, FEET
21	1	440 0414 00		WIRE, FEET
22	8	440 0502 00		WIRE, FEET
23	1	440 0504 00		WIRE, FEET
24	1	440 0505 00		WIRE, FEET
25	3	440 0507 00		WIRE, FEET
26	8	440 0508 00		WIRE, FEET
27	1	440 0509 00		WIRE, FEET
28	1	440 0510 00		WIRE, FEET
29	3	440 0702 00		WIRE, FEET
30	1	440 0704 00		WIRE, FEET
31	10	440 0705 00		WIRE, FEET
32	10	440 0707 00		WIRE, FEET
33	8	440 0708 00		WIRE, FEET
34	5	440 0709 00		WIRE, FEET
35	9	440 0710 00		WIRE, FEET
36	1	440 0711 00		WIRE, FEET
37	1	440 0712 00		WIRE, FEET
38	7	440 0902 00		WIRE, FEET
39	1	440 0903 00		WIRE, FEET
40	1	440 0904 00		WIRE, FEET
41	2	440 0905 00		WIRE, FEET
42	1	440 0906 00		WIRE, FEET
43	1	440 0907 00		WIRE, FEET
44	2	440 0912 00		WIRE, FEET
45	1	440 0918 00		WIRE, FEET
46	1	440 0921 00		WIRE, FEET
47	1	440 0922 00		WIRE, FEET
48	1	440 0923 00		WIRE, FEET
49	1	440 0925 00		WIRE, FEET
50	1	440 0926 00		WIRE, FEET
51	1	440 0927 00		WIRE, FEET
52	1	440 0932 00		WIRE, FEET
53	1	440 0933 00		WIRE, FEET
54	1	440 0934 00		WIRE, FEET
55	1	440 0935 00		WIRE, FEET
56	1	440 0936 00		WIRE, FEET
57	1	440 0937 00		WIRE, FEET
58	1	440 0938 00		WIRE, FEET
59	1	440 0939 00		WIRE, FEET
60	1	440 0940 00		WIRE, FEET
61	1	447 1652 00		WIRE, FEET
62	1	447 1653 00		WIRE, FEET
63	1	500 1963 00		27 TERMINAL STRIP
64	1	507 6308 00		RECEPTACLE MOUNTING PLATE
65	1	571 1545 20		37 TERMINAL STRIP

Figure 7-56 Navy Type COL-211624 Dynamotor Assembly Power Unit Practical Wiring Diagram

Figure 7-56 Navy Type COL-211624 Dynamotor Assembly Power Unit Practical Wiring Diagram




Figure 7-57 Navy Type COL-23410 Remote Control Unit
Practical Wiring Diagram






Figure 7-58 Navy Type COL-47505 Antenna Loading Coil
Practical Wiring Diagram

QTY	PART NO.	DESCRIPTION	MAT'L	FIN.
1	A 307.5718 00	COIL FORM		
15	B 420.2440 00	#24 D.E. WIRE FT		
2	C 312.3480 00	4-40 X 3/8 BRASS STUD		


Figure 7-59 HF Oscillator Grid Inductor L-101




- ASSEMBLY NOTES:
1. CEMENT STUDS (C) INTO COIL FORM (A) WITH SAUERISEN CEMENT
 2. WIND COIL AS PER WINDING DATA.
 3. APPLY WITH BRUSH OR SPRAY GUN ONE COAT OF POLYSTYRENE CEMENT #912 AFTER WINDING.

WINDING DATA			
WINDINGS	NUMBER OF TURNS	PITCH	TURNS PER INCH
A	9	.02255	44.346
B	11	.0255	39.215
C	1	.0332	30
D	6	.04758	21.017
E	4	.04962	20.154
F	5	.0500	20
G	5	.0488	20.576
H	6 1/4	.0332	30

Figure 7-60 First Multiplier Plate Inductor L-105



GA	ITEM	DESCRIPTION	PART NO.	MAT'L	FIN.
	2	C #2-56X 1/16 BRASS STUD	312 3390 00		
	7	D #24 D.E. WIRE FT	421 2440 00		
	1	E DOUBLER COIL FORM	507 5716 00		




WINDING DATA

WINDING		NO. OF TURNS	PITCH	TURNS PER INCH
A	A	14	.0215	46.51
B	B	2	.1515	6.61
C	C	1	.165	6.06
D	D	11	.0215	46.51

ASSEMBLY NOTES

1. CEMENT STUDS (C) INTO COIL FORM (E) WITH DUCO WATERPROOF HOUSEHOLD CEMENT.
2. WIND COIL AS PER WINDING DATA.
3. APPLY WITH BRUSH OR SPRAY GUN ONE COAT OF #1202 CLEAR GLYPTAL CEMENT AFTER WINDING.


Figure 7-61 Second Multiplier Plate Inductor L-106



FLOW SOLDER AFTER WINDING WIRE ABOUT STUDS.

- ASSEMBLY NOTES:**
1. CEMENT STUDS (D) INTO COIL FROM (C) WITH DUCO WATERPROOF HOUSEHOLD CEMENT.
 2. WIND COIL AS PER WINDING DATA.
 3. APPLY WITH BRUSH OR SPRAY GUN ONE COAT OF #1202 CLEAR GLYPTAL CEMENT AFTER WINDING.

GA	ITEM	DESCRIPTION	PART NO.	MAT'L	FIN.
1	C	COIL FORM	507 5717 00		
2	D	#2-56 X7/16 BRASS STUD	312 3390 00		
3	E	#24 DE. WIRE, FT.	421 2440 00		



WINDING DATA

	TURNS	PITCH	TOTAL
START	2-3/4	.022	.0605
	1/4	.218	.115
	1/2	.252	.241
	1/2	.178	.330
	1/2	.170	.415
	1/2	.168	.499
	1/2	.212	.605
	1/2	.174	.692
	1/4	.188	.739
	1/2	.230	.854
FINISH	2-1/4	.023	.906

A	IT.	DESCRIPTION	PART NO.	MAT'L	FIN.
1	A	COIL FORM	507 5739 10		
X	B	#27 CHROME OXIDE WIRE 3 1/2 FT. L.	421 2730 00		
2	C	#2-56 X 3/8 FILL. HD. SCR.	321 0022 00		
1	D	#2-56 HEX. NUTS	313 0006 00		
1	X	ASSEMBLY PER QUANT. "A."	571 1448 10		
1	E	SOLDERING SLEEVE	507 6842 00		





Figure 7-62 PA Plate Feed Choke L-108

571-1404-30

A	IT.	DESCRIPTION	PART NO.	MAT'L	FIN.
2	A	CLAMP	139 4600 00		
2	B	.087 x .167 EYELETS	307 2800 00		
1	C	40 FEET #35 SSE. COPPER WIRE	421 3530 00		
1	D	COIL FORM	507 5742 00		
1	X	ASS'Y OF PARTS PER GROUP A.	571 2103 10		



CLOSE WIND * TURNS ITEM (C)
 FOR 190MH ± 10MH INDUCTANCE
 SOLDER ENDS TO ITEM (B)
 * APPROXIMATELY 340 TURNS

Figure 7-63 Output Network Static Drain Choke L-110

A	ITEM	DESCRIPTION	PART NO.	MAT'L	FIN.
1	A	ROTOR COIL 5 FT. WIRE	421 0006 00	NOTE	
2	B	ROTOR MTG. BAR # 2	507 6092 00		
2	C	ROTOR MTG. BAR # 1	507 8093 00		
2	D	ROTOR ATTACHMENT PLATE	507 6098 00		
4	E	6-32 X 5/16 PH. BRASS SCREW	343 0112 00		
4	F	#6 PHOS. BR. INT. SHAKE WASHER	373 3020 00		
1	X	ASS'Y. OF PARTS PER. QUANT. A	571 1246 20		

COIL #10 (.100) MEDIUM HARD DRAWN
SILVER PLATED COPPER WIRE







Figure 7-64 PA Plate Inductor - Rotor for L-112


Figure 7-65 PA Plate Inductor - Stator for L-112



A	ITEM	DESCRIPTION	PART NO.	MAT'L	FIN.
1	A	STATDR COIL. 5FT. OF WIRE	421 000600	NOTE	
2	B	MOUNTING BAR #2	507 6100 00		
2	C	MOUNTING BAR #1	507 6099 00		
1	D	ROTOR BEARING BAR #1	507 6090 00		
1	E	ROTOR BEARING BAR #2	507 6091 00		
	F				
4	G	6-32 x 5/16 PH. BIND. HD. SCREW. BRASS	343 0112 00		
4	H	#8 PHOS. BR. INT. SHAKE. WASHER	373 3020 00		
1	X	ASSY OF PARTS PER QT. "A"	571 1245 20		



COIL: #10 (.100) MEDIUM HARD DRAWN
SILVER PLATED COPPER WIRE.

NOTE: ENDS OF COILS TO BE ROUND
AND FREE FROM SHARP EDGES.



GA	IT.	PART NO.	DESCRIPTION	MAT'L	FIN.
1	A	571 1100 20	COIL FORM		
1	B	421 1421 00	28 FT. #14 LEAD COVERED COPPER WIRE		
1	C	507 7350 00	CORONA RING		

SOLDER ITEM (C) TO ITEM (B) AT 4 POSITIONS INCLUDING BOTH ENDS. USE HARD SOLDER 90-10



ENLARGED DETAIL OF TAP LOOPS


WINDING DATA

WIRE	GAUGE	PART NO.	APPROXIMATE NUMBER OF TURNS	TYPE OF WINDING	L.	DIST. C.	Q.	FREQ.	CAP.
LEAD COVERED COPPER WIRE	14	421 1421 00	43	SINGLE LAYER	42μH		325	2.0M C.	150μμFD.

Figure 7-66 Antenna Loading Inductor L-113

Figure 7-67 PA Plate Tank Padding Inductor L-114

A	IT.	DESCRIPTION	PART NO.	MAT'L	FIN.
1	A	COIL FORM	5075922 00		
4	B	#16 LEADED COPPER WIRE, <i>ft</i>	421 1621 00		



END "A" IS THREE INCHES LONG


END "B" IS ONE INCH LONG

WINDING & TEST DATA (WITH Q METER)

WIRE	GUAGE	PART NUMBER	NO. OF TURNS	TYPE OF WINDING	L. <i>μh</i> (MIN)	Q.	FREQ. (<i>mc</i>)	CAP. (<i>μmf</i>)
LEADED COPPER WIRE	16	421 1621 00	15	SINGLE LAYER	2.1 ± 5%	270. MIN.	18.	37.

GA	IT	PART NO.	DESCRIPTION	MAT'L	FIN.
1	A	571 1868 20	L. F. OSCILLATOR COIL FORM		
3	B	312 3380 00	2-56 X 5/8 STUD		
0.2	C	014 4000 00	TAPE 1/4 X .005 FT.		
130	D	422 5100 00	48-38 LITZ WIRE, FT.		

Figure 7-68 LF Oscillator Grid Inductor L-401




ASSEMBLY NOTES:


1. IMPREGNATE WITH CERESSE AA OR EQUIVALENT AT TEMPERATURE OF 121°-126°C. (250°-260°F.) UNTIL AIR BUBBLES CEASE. LET COOL, THEN FLASH DIP IN HALOWAX NO 2141 AT TEMPERATURE OF 176°-182°C. (350°-360°F.)

NOTE: THE COAT OF WAX MUST BE FREE FROM BUBBLES & BLOW HOLES & NOT MORE THAN 1/32 IN. THICK.

2. CEMENT ITEM (B) TO ITEM (A) WITH DUCO CEMENT 4N457



DETAIL NO. 2
TAPE AT END OF WINDING.



DETAIL NO. 1
TAPE AT START OF WINDING.

WINDING DATA NOTE: INDUCTANCE AT 1000 C.P.S. 20.0MH.



WIRE	GUAGE	PART NO.	NO. OF TURNS	TYPE OF WINDING	L.	DIST. C.	Q.	FREQ.	CAP.
48-38 LITZ	19	422 5100 00	45	SINGLE LAYER	19,956 μ H $\pm 1\%$	3,166 MMF.	104 $\pm 8\%$	2000 KC.	320 MMF.

NOTES:
 1. LENGTH OF TAPS TO BE $3\frac{1}{2}$ "
 2. RIGHT HAND WINDING.

TAP NO. FROM TOP	TOTAL TURNS FROM TOP	INDUCTANCE BETWEEN TOP & TAP (ON Q METER WITH CQ AT 400 MMF)	Q BETWEEN TOP & TAP	FREQUENCY AT WHICH Q IS MEAS.
1	47.5	622	193	334
2	82.5	1490	235	206
3	107.5	2380	228	163
4	129.5	3270	180	139
5	142.5	3985	96	126
6 (END)	145.75	5040	165	112


QUANTITIES LISTED ARE FOR ONE ASSEMBLY				ITEM NO.	PART NUMBER	PART NAME
500	500	500	500			
				18 A	288 1002 00	MOLDED IRON CORE
				6 B	323 0072 00	8-32X $\frac{1}{2}$ SL. B.H. SCR.
				6 C	323 0097 00	10-32X $1\frac{1}{8}$ SL. B.H. SCR.
				3 D	330 4240 00	6-32X $\frac{3}{8}$ FIBRE SCREEN
				203 E	422 0064 001	60-38 LITZ WIRE, FT.
				3 F	500 2700 001	COIL WINDING TERMINAL
				1 G	502 1717 003	LOAD COIL FORM
				1 H	502 1718 003	IRON CORE SUPPORT
				1 J	502 1719 003	LOAD COIL BASE
				1 K	502 1720 003	LOAD COIL SUB-BASE
				1 L	502 1721 002	LOAD COIL SPACER
				6 M	502 1722 002	IRON CORE SUPPORT ROD
				20 N	014 4000 00	ARMATURE TAPE, FT.
				15 P	421 1020 00	#10 TINNED CU BUS, FT.
				2 Q	310 6210 00	#10 BR. FLAT WASHER
				2 R	323 0096 00	10-32X1" S.B.H. SCREW
				2 S	373 7040 00	#10 EXT. P.B. SHAKE
				2 T	322 0081 00	10-32X $1\frac{1}{4}$ S.F.H. SCREW

DETAIL SHOWING METHOD OF TAPING AT TAPS.
 SCALE 10=1



DETAIL SHOWING METHOD OF TAPING START & END OF WINDING & SEQUENCE OF 2 LAYER BANK WINDING.
 SCALE 10=1

SOLDER START OF WINDING TO BUS WIRE AT TERMINAL.



ENDS OF WINDING, $3\frac{1}{4}$ " TURNS AFTER TAP #5 (BASE END OF COIL)






Figure 7-69 Antenna Loading Coil L-3001

Figure 7-70 Antenna Loading Coil - Stator for L-3002





QUANTITIES LISTED ARE FOR ONE UNIT				PART NUMBER	PART NAME
500	500	502 1723 002	ITEM NO.		
			1 A	502 1730 003	STATOR COIL FORM
			2 P	304 6100 00	6 SOLDER LUG
			78 C	422 0064 00	60-38 LITZ WIRE, FT.
			0.4 D	014 4000 00	ARMATURE TAPE, FT.




DETAIL SHOWING METHOD OF TAPING START & END OF WINDING AND SEQUENCE OF DOUBLE BANK WINDING.

SCALE 10:1

Figure 7-71 Antenna Loading Coil - Rotor for L-3002





QUANTITIES LISTED ARE FOR ONE ASSEMBLY						PART NAME
500	500	500	ITEM NO.	PART NUMBER		
	2	A	304 5000 00	#10 SOLDER LUG		
	4	B	330 4240 00	6-32X 3/8 FIBRE HEX HD SCREW		
	65	C	422 0064 00	WIRE 60-38 LITZ, FT.		
	1	D	502 1731 00	COIL FORM		
	2	E	502 1732 002	ROTOR SHAFT SURPORT		
	0.4	F	014 4000 00	ARMATURE TAPE, FT.		



DETAIL SHOWING METHOD OF TAPING
START OF WINDING AND SEQUENCE
OF DOUBLE BANK WINDING.
SCALE 10:1


Figure 7-72 Antenna Loading Coil - Stator for L-3003

QUANTITIES LISTED ARE FOR ONE ASSEMBLY				PART NUMBER	PART NAME
5000	500	502 17 34 008	ITEM NO.		
	1	A	502 174 003	STATOR COIL FORM	
94	B	422	0064 00	60-38 LIT Z WIRE, FT.	
	2	C	304 6100 00	6 SOLDER LUG	
	8'	D	014 4000 00	ARMATURE TAPE	




DETAIL SHOWING METHOD OF TAPING START OF WINDING AND SEQUENCE OF DOUBLE BANK WINDING.

SCALE 10:1




ALL TAPS BROUGHT OUT FROM COIL TO BE 3 1/2" LONG.




DETAIL SHOWING METHOD OF TAPING AT TAPS
SCALE 4:1


Figure 7-73 Antenna Loading Coil - Rotor for L-3003



QUANTITIES LISTED ARE FOR ONE ASSEMBLY				PART NUMBER	PART NAME
500	500	502 1739002	ITEM NO.		
		1	A	502 1744 002	COIL FORM
		2	B	502 1743 002	ROTOR SHAFT SUPPORT
		4	C	330 42 40 00	6-32X $\frac{3}{8}$ FIBRE HEX. HD. SCR.
		2	D	304 5000 00	SOLDER LUG
		23	E	422 0064 00	60-38 LITZ WIRE, FT.
		0.4	F	014 4000 00	ARMATURE TAPE, FT.



DETAIL SHOWING METHOD OF TAPING START & END OF WINDING AND SEQUENCE OF DOUBLE BANK WINDING
SCALE 10:1



SIG. CORP FT-241-A
AN TYPE CR-2-B/U (200 KC)

Figure 7-74 Type CR-2-B/U (200 kc) Crystal Unit