

# TELETYPE

## PRINTING TELEGRAPH SYSTEMS

BULLETIN 226B

INSTALLATION  
ADJUSTMENTS AND LUBRICATION  
MODEL 28 PRINTER SET  
(STUNT BOX C.A.A)

CHANGE 1



COPYRIGHT 1955 BY TELETYPE CORPORATION IN UNITED STATES.  
COPYRIGHT IN ALL COUNTRIES PARTICIPATING IN INTERNATIONAL  
CONVENTION AND PAN AMERICAN CONVENTIONS. ALL RIGHTS  
RESERVED INCLUDING RIGHTS OF TRANSLATIONS INTO ALL LANGUAGES.

CHANGE 1



## LIST OF EFFECTIVE PAGES

APRIL 1955

PAGE NUMBERS	CHANGE IN EFFECT
TITLE PAGE	CHANGE I
EFFECTIVE PAGE	CHANGE I
A TO D	ORIGINAL
1-0 TO 2-18	ORIGINAL
2-19	CHANGE I
2-20 TO 2-23	ORIGINAL
2-24	CHANGE I
2-25 TO 3-30	ORIGINAL

THIS PAGE LISTS THE EFFECTIVE PAGES IN THE BULLETIN  
AND MUST BE REPLACED WHEN CHANGES ARE MADE.

## TABLE OF CONTENTS

## SECTION I

INSTALLATION	Page
General .....	1-0
Procedure .....	1-1

## SECTION II

ADJUSTMENTS	
1. General .....	2-0
2. Adjustments	
a. General .....	2-1
b. Manual Selection of Characters or Functions .....	2-1
c. Instructions	
Mounting Typing Unit .....	2-65
Removing Code Bar Assembly .....	2-38
Removing Code Bar Shift Mechanism .....	2-16
Removing Front Plate Assembly .....	2-35
Removing Main Shaft .....	2-58
Removing Platen .....	2-58
Removing Print Carriage .....	2-14
Removing Selector Magnet .....	2-6
Removing Selector Cam Assembly with Clutch .....	2-14
Removing Selector Mechanism .....	2-12
Removing Type Box .....	2-10
Removing Type Box Carriage .....	2-15
Replacing Spacing Cables .....	2-40
d. Requirements - Base	
Intermediate Gear Bracket .....	2-3
Synchronous Motor Positioning .....	2-4
e. Spring Tensions - Base	
Local Line Feed Trip Link .....	2-5
Local Carriage Return Bail Spring .....	2-5
Margin Indicator .....	2-4
f. Requirements - Typewriter	
Automatic Carriage Return Arm .....	2-60
Carriage Return Latch Bail .....	2-38
Carriage Return Lever .....	2-39
Carriage Wire Rope .....	2-36
Code Bar Detent .....	2-63
Code Bar Clutch Trip Lever .....	2-17
Code Bar Shift Lever Drive Arm .....	2-15
Code Bar Shift Lever Link Guide .....	2-16
Condition Code (Zero), Code Bar Shift Mechanism .....	2-24
Copyholder .....	2-69
Copy Lamps .....	2-69
Clutch Drum Position (Except Selector) .....	2-23
Clutch Shoe Lever .....	2-22
Clutch Trip Shaft Set Collars .....	2-19
Cradle .....	2-66
Dashpot Vent Screws .....	2-40
Dome .....	2-67
Dome Catch .....	2-67
Figures and Letters Code Bar Shift Mechanism .....	2-54

## TABLE OF CONTENTS

## SECTION II

	Page
f. Requirements – Typer (Cont'd)	
Function Clutch Trip Lever .....	2-18
Function Reset Bail Blade .....	2-34
Horizontal Positioning Drive Linkage .....	2-33
Indicator Lamp .....	2-69
Intermediate Arm Backstop Bracket .....	2-14
Left Hand Margin .....	2-41
Left Vertical Positioning Lever Eccentric Stud .....	2-29
Line Feed Clutch Trip Lever Adjusting Screw .....	2-21
Line Feed Clutch Trip Lever Eccentric Post .....	2-21
Line Feed Clutch Phasing .....	2-26
Line Feed Spur Gear Detent Eccentric .....	2-57
Margin Indicating Lamp .....	2-64
Off Line Stunt Shift Bracket Assembly .....	2-24
Oscillating Rail Slide Position .....	2-30
Paper Finger Adjustment .....	2-62
Paper Straightener Collar .....	2-61
Printing Arm .....	2-46
Printing Carriage Lower Roller .....	2-43
Printing Carriage Position .....	2-43
Printing Hammer Bearing Stud .....	2-44
Printing Hammer Stop Bracket .....	2-46
Printing Track .....	2-45
Rocker Shaft Bracket Eccentric Stud .....	2-27
Range Finder Knob Phasing .....	2-11
Remote Signal Bell .....	2-66
Reversing Slide Adjusting Stud .....	2-32
Reversing Slide Brackets .....	2-32
Ribbon Feed Lever Bracket .....	2-48
Ribbon Reverse Detent .....	2-47
Ribbon Reverse Spur Gear .....	2-47
Right Margin .....	2-42
Ratchet Shaft Left Bracket .....	2-26
Right Vertical Positioning Lever Eccentric Stud .....	2-28
Selector Armature .....	2-6
Selector Magnet Bracket .....	2-7
Selector Cutch Stop Arm .....	2-11
Shift Linkage .....	2-44
Small Door .....	2-68
Small Door Catch .....	2-68
Small Door Stop Arm .....	2-68
Spacing Clutch Trip Lever .....	2-20
Spacing Gear Clearance .....	2-25
Spacing Gear Phasing .....	2-25
Spacing Trip Lever Bail Cam Plate .....	2-31
Stop Arm Bail Guide .....	2-12
Stripper Blade Cam Position .....	2-55
Stunt Case Code Bar Shift Mechanism .....	2-24
Transfer Lever Eccentric .....	2-13
Type Box Clutch Suppression Arm .....	2-24
Type Box Clutch Trip Lever .....	2-22
Type Box Clutch Trip Lever Eccentric Post .....	2-21
Vertical Positioning Lock Lever .....	2-35
Window and Paper Guide .....	2-69

## TABLE OF CONTENTS

## SECTION II

	Page
g. Spring Tensions – Typer	
Automatic Carriage Return – Line Feed Bell Crank .....	2-41
Automatic Carriage Return – Line Feed Blocking Slide .....	2-53
Breaker Slide Bail .....	2-27
Carriage Return Latch Bail .....	2-38
Clutch Latch Lever (Except Selector) .....	2-17
Clutch Shoe .....	2-23
Clutch Shoe Lever .....	2-23
Clutch Trip Lever .....	2-20
Code Bar Clutch Cam Follower .....	2-18
Code Bar Detent .....	2-63
Code Bar Yield Spring .....	2-63
Common Transfer Lever .....	2-13
Condition Code Shift Fork .....	2-53
Decelerating Slide Bell Crank .....	2-42
Function Bar .....	2-52
Function Contact .....	2-56
Function Lever .....	2-52
Function Pawl .....	2-52
Horizontal Positioning Drive Linkage .....	2-33
Horizontal Positioning Lock Lever .....	2-27
Horizontal Stop Slide .....	2-60
Line Feed Bar Bell Crank .....	2-57
Line Feed Bar Release Lever .....	2-57
Lower Wire Rope Pulley Bail .....	2-36
Marking Lock Lever .....	2-8
Off Line Stunt Shift Solenoid .....	2-24
Paper Finger .....	2-62
Paper Pressure Bail .....	2-62
Paper Straightener Lever .....	2-61
Platen Detent Bail .....	2-57
Printing Hammer Operating Bail .....	2-45
Printing Hammer Operating Bail Latch .....	2-45
Printing Hammer Yield .....	2-45
Printing Hammer Plunger .....	2-45
Pressure Roller Lever .....	2-62
Push Lever Reset Bail .....	2-10
Reset Bail .....	2-34
Reversing Slide Detent .....	2-32
Ribbon Feed Lever .....	2-48
Ribbon Ratchet Wheel Friction .....	2-48
Ribbon Reverse .....	2-49
Ribbon Reverse Detent Lever .....	2-47
Ribbon Tension .....	2-49
Selector Arm .....	2-8
Selector Clutch Drum .....	2-9
Selector Clutch Latch Lever .....	2-10
Selector Lever .....	2-9
Selector Push Lever .....	2-9
Single – Double Line Feed Stripper Bail .....	2-59
Shift Linkage .....	2-44
Signal Bell Armature .....	2-66
Spacing Cutout Transfer Bail .....	2-42
Spacing Feed Pawl Release Link .....	2-37
Spacing Feed Pawl .....	2-30

## TABLE OF CONTENTS

## SECTION II

	Page
g. Spring Tensions – Typer (Cont'd)	
Spacing Lock Lever .....	2-10
Spacing Trip Lever .....	2-31
Spacing Trip Lever Bail .....	2-31
Spacing Suppression Bail .....	2-58
Start Lever .....	2-12
Suppressor Code Bar .....	2-24
Transfer Slide .....	2-40
Trip Shaft Lever .....	2-17
Type Box Carriage Roller Arm .....	2-43
Type Pallet .....	2-46
Vertical Positioning Lever .....	2-28
Vertical Positioning Lock Lever .....	2-29
3. Selector Receiving Margin Adjustment .....	2-70

## SECTION III

LUBRICATION	
1. General .....	3-1
2. Procedure .....	3-2; 3-31

## SECTION I INSTALLATION

### 1. INSTALLATION


#### a. GENERAL DESCRIPTION

The Model 28 printer set with Station Selecting Mechanism ( Stunt Case) consists of the following basic units: Apparatus Cabinet; Receiving only Base; Motor Unit; Set of Gears; and an Electrical Service Assembly.

The Typing Units may be provided with various accessory groups for different service requirements.

#### b. PROCEDURE

Unpack all component units and parts with care. Observe all caution labels and instructions. Muslin bags and small parts should be kept with their associated pieces of apparatus until used in the installation.



**CABINET** - Remove the insulating covers for access to terminal screws when installing the AC power cable and the signal line cable. Refer to the wiring diagram associated with each unit for the terminal connections.



## CAUTION

A good ground is important for satisfactory operation of the equipment. The ground screw is located at the extreme right of the cabinet above the terminal board.

**ELECTRICAL SERVICE UNIT** The unit is wired for 0.060 ampere operation at the factory. If 0.020 ampere operation is desired, change the wiring as shown in the associated wiring diagram. Install the rectifier in accordance with the instructions accompanying the unit.

With the cabinet dome raised, place the Electrical Service Unit in the rear of the cabinet with the legs extending upward and the name plates facing the front. Drop the two studs through the holes located at each end of the panel and fasten the unit to the cabinet shelf. Untie the power switch extension shaft from the hinge bar and remove the knob. Insert the shaft through the hole near the right front corner of the cabinet from the back side. Place the opposite end of the shaft in the hole near the corner and engage the slotted extension with the toggle switch Hook one end of the spring (furnished) around the shaft and attach the other end to the cradle. Replace the knob with the arrow to the right.

**AC MOTOR** Place the pinion on the motor shaft the gear toward the motor. Mount the intermediate driven gear on the shaft with the flat side of the gear toward the right. Place motor on the base and secure it with the four Mounting screws and lockwashers. See that the gears mesh properly.

Remove the insulating cover from the terminal block on the base. Attach the motor leads to terminals 1 and 2. Replace the cover with the No. 1 stamp toward the rear.

**TYPING UNIT** The Stunt Box may be furnished without certain stunt case and common function bars in order that the assigned code for the Station, Area, or Relay Call may be inserted in the field. DO NOT OPERATE THE TYPER WITHOUT THE FUNCTION BARS FOR WHICH THE FUNCTION PAWLS HAVE BEEN FURNISHED. HOWEVER, THREE SPECIAL SPRINGS MAYBE PLACED UNDER THE LOOSE PAWLS WITH THE ENDS OF THE SPRING CLIPPED TO THE TIE BAR FOR SUPPORT. Refer to the chart (P. 2-51) for the function bars corresponding to the Station Calls to be set up.

Remove the four 1/4 - 32 (hex head) screws with lockwashers from the base. Engage the front feet on the locating studs. Rotate the motor by hand to insure proper meshing of the gears. Secure the Typing Unit with the four screws.

## PAPER AND RIBBON

a. To replenish the supply of paper, open the dome of the cabinet, move the paper release lever on the Typing Unit toward the rear, slide one of the spindle retainers toward the rear and remove the paper spindle. Insert the spindle in a fresh roll of paper and remount it so that the paper unwinds from underneath. Feed the paper over the paper straightener shaft (Figure 61) and fold the end of the paper backward to square it off. With the paper release lever toward the rear, start the paper feeding around the platen and then restore the release lever to its forward position. Depress the line feed wheel and continue to feed the paper upward. Do not disturb the ribbon. Make certain that the paper passes under the paper fingers which may be raised temporarily to facilitate the operation. It may be necessary to operate the release lever momentarily when finally straightening the paper.

b. To replace the ribbon, open the glass door in the dome, raise the toggles on the ribbon spool shafts (Figure 48) to the vertical position and remove both spools. Engage the hook that is on the end of the new ribbon in the hub of the empty spool. Wind a few turns of the ribbon onto the empty spool to make sure that the reversing eyelet has been wound upon the spool. Place the spools on the ribbon spool shafts in such a manner that the ribbon feeds from the rear of each spool without twisting. Turn each spool shaft slightly until the driving pins on the spool shafts engage the holes in the spools. Thread the ribbon forward around both ribbon rollers, through the slots in the ribbon reverse levers, and through the ribbon guide on the type box carriage. Make certain that the ribbon remains in the guide slots and that both reversing eyelet are between the ribbon spools and the reverse levers. Eliminate any slack in the ribbon.


## SECTION II ADJUSTMENTS

### 1. GENERAL

a. The model 28 receiving only printer with station selection (Stunt Case) feature is arranged for operation in a country wide communication system which is divided into a number of area Networks. The printers in each area are operating in a stand-by condition (Motor Running) with printing suppressed until the assigned call code or codes is received. Printers in one area network may be individually or collectively selected to receive a message. The printers in an adjacent area may be selected in a similar manner by routing station calls codes through a relay station where facilities are available for entering the adjacent network.

b. A code sequence composed of functions and character combinations, precede each message. The sequence (CONDITION CODE CR-CR-LTRS followed by the SELECT CODE consisting of three characters) serves as an address. All printers in the area respond to the condition code which momentarily opens a "gate". The call letters following the condition code determines the printer or printers in the group that respond to the call and type the message to follow. Upon the completion of the text the end of message sequence (Consisting of Fig-CR-LTRS) is transmitted to shift the typer out of the printing position.

The remote - local feature is provided to manually shift the typer in printing position when desired.



STUNT BOX

## 2. ADJUSTMENTS

### a. GENERAL

The sequence in which the following adjustments are arranged takes into consideration the normal approach to the mechanism and the fact that a change in one adjustment may affect others. Adjustments should not be disturbed unnecessarily. Tools required to perform the adjustments are listed in 1124B but are not supplied as part of the equipment. After performing an adjustment, tighten any screws or nuts that have been loosened and check related adjustments.

In the figures of this bulletin, fixed pivot points are designated by solid black circles and the floating pivot points are crosshatched. The terms right, left, front, rear, upper, and lower, refer to the normal position of the Typing Unit when installed in the cabinet.


### NOTES

- (1) When rotating the main shaft of the Typing Unit by hand, the clutches do not fully disengage upon reaching their stop positions. In order to relieve the drag on the clutches and permit the main shaft to rotate fully, apply pressure on the lug of each clutch disc (Figure 16) with a screwdriver to cause it to engage its latch lever. This procedure should always be followed prior to placing the Typing Unit on the base and switching on the power.
- (2) The Typing Units are furnished without certain function bars in the Stunt Box which pertain to the area, Station or Relay Call Codes. CAUTION - - - DO NOT OPERATE THE TYPING UNIT UNTIL ALL FUNCTION BARS HAVE BEEN INSTALLED FOR WHICH THE ASSOCIATED FUNCTION LEVERS AND FUNCTION PAWLS HAVE BEEN FURNISHED. Refer to page-50 and page 51 for the field installation procedure for the assigned call codes.
- (3) Adjustments that call for rotation of the type box clutch must be made with the unit in a printing case. The Typing Unit may be shifted into a printing case by latching the function lever associated with a Stunt Case Shift mechanism.
- (4) When making a complete adjustment of the Typing Unit, the following conditioning operations should be performed to prevent damage to the unit:
  - (a) Loosen the shift lever drive arm clamp screw (Figure 14)
  - (b) Move the right and left vertical positioning lever eccentric stud (Figure 28 and 29) and the rocker shaft bracket to their lowest position.
  - (c) Loosen the two bearing stud mounting screws and the horizontal positioning drive linkage (FIGURE 27)
  - (d) Loosen the clamp screws and move the reversing slide brackets to their uppermost position (Figure 32)
  - (e) Loosen the function reset bail blade mounting screws (FIGURE 34)
  - (f) Disconnect the stripper blade driving link (P. 2-59).
  - (g) Loosen the carriage return lever clamp screw.

### b. MANUAL SELECTION OF CHARACTERS OR FUNCTIONS.

To manually operate the Typing Unit while removed from the base, hold the selector magnet armature (Figure 5) operated by means of a spring clip and rotate the main shaft in counterclockwise direction (by means of the handwheel listed in Table 1124B) to bring all clutches to their positions. Fully disengage all clutches as described in the preceding note. Release the armature momentarily to permit the selector clutch to engage. Turn the main shaft slowly until No. 5 selector lever has just moved to the peak of its cam. Strip the push levers from the selector levers which are spacing in the code combination of the character or function that is being selected. It should be noted that the selector levers (Figure 12) move in succession starting with the inner lever (Number one). Continue to rotate the main shaft until all operations initiated by selector action clears through the unit.

226B



TYPING UNIT

## D. BASE

INSTRUCTIONS FOR REMOVING TYPING UNIT FROM CABINET  
REFER TO P. 3-2 FOR DISASSEMBLY PROCEDURE


INTERMEDIATE GEAR BRACKET

## (1) REQUIREMENT

THERE SHOULD BE A BARELY PERCEPTIBLE AMOUNT OF BACKLASH BETWEEN THE TYPER DRIVEN GEAR AND THE TYPER DRIVING GEAR AT THE POINT WHERE BACKLASH IS THE LEAST.

## TO ADJUST

POSITION THE COMPLETE INTERMEDIATE GEAR MECHANISM BRACKET BY UTILIZING THE ADJUSTING SLOTS WITH THE THREE HEXAGON HEAD SCREWS LOSSENEED. ALIGN GEARS AT THIS TIME.



## (2) REQUIREMENT

THERE SHOULD BE A BARELY PERCEPTIBLE AMOUNT OF BACKLASH BETWEEN THE INTERMEDIATE DRIVING GEAR AND THE INTERMEDIATE DRIVEN GEAR AT THE POINT WHERE THE BACKLASH IS THE LEAST.

## TO ADJUST

RAISE OR LOWER THE FRONT END OF THE INTERMEDIATE GEAR BRACKET BY MEANS OF THE FILISTER HEAD ADJUSTING AND CLAMPING SCREWS LOCATED AT THE FRONT END OF THE BRACKET. REFINE REQUIREMENT (1) IF NECESSARY.

FIGURE 1 BASE AND MOTOR GEARING




FIGURE 2 SYNCHRONOUS MOTOR




FIGURE 3 BASE, MARGIN INDICATING MECHANISM, FRONT VIEW





FIGURE 4 BASE, LOCAL LINE FEED MECHANISM

## F. TYPING UNIT

## NOTE

TO FACILITATE MAKING THE FOLLOWING ADJUSTMENTS, REMOVE THE SELECTOR MAGNET ASSEMBLY AND THE RANGE FINDER ASSEMBLY. TO INSURE BETTER OPERATION, PULL A PIECE OF PAPER BETWEEN THE ARMATURE AND THE POLE PIECES TO REMOVE ANY OIL OR FOREIGN MATTER THAT MAY BE PRESENT. MAKE CERTAIN THAT NO LINT OR PIECES OF PAPER REMAIN BETWEEN THE POLE PIECES AND ARMATURE. BEFORE REMOUNTING THE RANGE FINDER, CHECK AND ADJUST THE RANGE FINDER KNOB PHASING.

A. SELECTOR ARMATURE

## NOTE

THIS REQUIREMENT NEED NOT BE MADE NOR CHECKED IF SELECTOR MAGNET BRACKET (FIG. 6) AND RECEIVING MARGIN (TABLE 1) REQUIREMENTS ARE MET.

- (1) REQUIREMENT (ARMATURE CLAMP STRIP) CLEARANCE  
MIN. 0.010 INCH  
MAX. 0.030 INCH  
BETWEEN ARMATURE CLAMP STRIP AND CASTING.
  - (2) REQUIREMENT (ARMATURE ALIGNMENT) OUTER EDGE OF ARMATURE SHOULD BE FLUSH (WITHIN 0.015 INCH) WITH OUTER EDGE OF POLE PIECES.
  - (3) REQUIREMENT (ARMATURE BACKSTOP ALIGNMENT)  
SOME CLEARANCE  
MIN. 0.010 INCH  
BETWEEN THE SIDES OF THE BACKSTOP AND THE SIDES OF THE ARMATURE EXTENSION
- TO ADJUST  
FIRST, POSITION ARMATURE SPRING ADJUSTING NUT TO HOLD ARMATURE FIRMLY AGAINST PIVOT EDGE OF CASTING, THEN POSITION ARMATURE AND BACKSTOP WITH MOUNTING SCREWS LOOSENED.

INSTRUCTIONS FOR REMOVING SELECTOR MAGNET ASSEMBLY

NOTE - - - REMOVE ONLY FOR SERVICING

REMOVE THE RANGE FINDER BY REMOVING THE TWO SCREWS AND THE NUT WHICH MOUNT IT TO THE SELECTOR.

REMOVE THE CABLE FROM THE COIL TERMINAL SCREWS.

REMOVE THE TWO MAGNET ASSEMBLY MOUNTING SCREWS AND LIFT THE ASSEMBLY OUT OF THE HOLE IN LOCATING PLATE.

FIGURE 5 TYPER, SELECTOR MAGNET







FIGURE 6 TYPER, SELECTOR MAGNET, RIGHT SIDE VIEW.

SELECTOR ARMATURE SPRING TENSION

## (1) REQUIREMENT (WHEN NO DISTORTION TEST SET IS AVAILABLE)


WITH THE MARKING LOCK LEVER, SPACING LOCK LEVER, AND START LEVER ON HIGH PART OF THEIR CAMS. SCALE APPLIED AS NEARLY VERTICAL AS POSSIBLE AT END OF ARMATURE EXTENSION. IT SHOULD REQUIRE APPROXIMATELY 3 OZS. TO PULL ARMATURE TO MARKING POSITION.

TO ADJUST  
ROTATE THE ADJUSTING NUT.



(2) REQUIREMENT (USING A DISTORTION TEST SET)  
THE SELECTOR SHOULD BE RELATIVELY FREE OF INTERNAL BIAS WHEN CHECKED AS SPECIFIED IN THE INSTRUCTIONS FURNISHED WITH THE SET.

TO ADJUST  
VARY THE TENSION OF THE ARMATURE SPRING BY ROTATING ITS ADJUSTING NUT.

MARKING LOCK LEVER SPRING TENSION REQUIREMENT

LETTERS COMBINATION SELECTED, MAIN SHAFT ROTATED UNTIL SELECTOR CLUTCH IS DISENGAGED. PUSH SCALE APPLIED HORIZONTALLY TO LOWER HORIZONTAL EXTENSION OF THE LOCK LEVER  
MIN. 1-1/2 OZS.  
MAX. 3 OZS.  
TO START LEVER MOVING

FIGURE 7 TYPER, SELECTOR MECHANISM, RIGHT SIDE VIEW





FIGURE 8 TYPWR, SELECTOR MECHANISM



#### INSTRUCTIONS FOR REMOVING THE TYPE BOX

NOTE - - - REMOVE ONLY FOR SERVICING

MOVE TYPE BOX LATCH TOGGLE TO THE RIGHT. LIFT THE RIGHT END OF THE TYPE BOX (APPROX.) 45° AND PULL TO THE RIGHT TO DISENGAGE TYPE BOX FROM ITS LEFT BEARING STUD.  
REINSTALL IN REVERSE ORDER. MAKE SURE THAT THE TYPE BOX IS FIRMLY SEATED ON ITS BEARING STUDS AND THE POINT OF LATCH TOGGLE IS PLACED IN THE NOTCH OF THE TYPE BOX PLATE BEFORE LATCHING THE TOGGLE.

FIGURE 9 TYPWR, SELECTOR CLUTCH MECHANISM, RIGHT SIDE VIEW

RANGE FINDER KNOB PHASING

## REQUIREMENT

WITH RANGE FINDER KNOB TURNED TO EITHER END OF RACK, ZERO MARK ON SCALE SHOULD BE IN LINE WITH SCRIBED LINE ON RANGE FINDER PLATE - 3 POINTS.

## TO PHASE

REMOVE PLATE AND POSITION KNOB WITH MOUNTING NUT LOOSENED

SELECTOR CLUTCH STOP ARM

## REQUIREMENT

RANGE SCALE SET AT 60. SELECTOR CLUTCH DISENGAGED. ARMATURE IN MARKING POSITION. CLUTCH STOP ARM SHOULD ENGAGE THE CLUTCH SHOE LEVER BY APPROXIMATELY THE FULL THICKNESS OF THE SHOE LEVER.

## TO ADJUST

POSITION THE STOP ARM ON THE STOP ARM BAIL WITH ITS CLAMP SCREW LOOSENED.




FIGURE 10 TYPYR RANGE FINDER MECHANISM. RIGHT SIDE VIEW




FIGURE 11 TYPER, SELECTOR CLUTCH MECHANISM, RIGHT SIDE VIEW

INSTRUCTIONS FOR REMOVING SELECTOR MECHANISM

NOTE - - - REMOVE ONLY FOR SERVICING

REMOVE SELECTOR MAGNET (SEE P.2-6) REMOVE FELT WICK FROM ITS HOLDER THEN REMOVE HOLDER. UNHOOK COMMON TRANSFER LEVER SPRING FROM PUSH LEVER GUIDE. REMOVE REMAINING THREE SELECTOR MOUNTING SCREWS (ONE IS INSIDE THE SIDE FRAME) AND LIFT SELECTOR FROM SIDE FRAME REPLACE IN REVERSE ORDER.





FIGURE 12 TYPWR, CODE BAR SHIFT MECHANISM



INTERMEDIATE ARM BACKSTOP BRACKET

REQUIREMENT

SELECTOR PUSH LEVERS STRIPPED. CLEARANCE BETWEEN FRONT EDGE OF INNER STEP OF SHIFT BAR AND THE FRONT CODE BAR SHIFT LEVER WHEN THE PLAY IN THE PARTS IS TAKEN UP TO MAKE THE CLEARANCE MAXIMUM  
 MIN. 0.010 INCH  
 MAX. 0.025 INCH

TO ADJUST

POSITION THE BACKSTOP BRACKET WITH ITS TWO CLAMP SCREWS LOOSENED.

INSTRUCTIONS FOR REMOVING PRINT CARRIAGE

NOTE . . . REMOVE ONLY FOR SERVICING  
 LOOSEN TWO SCREWS IN PRINT CARRIAGE CABLE CLAMP AND DISENGAGE THE CABLE FROM THE CLAMP. MOVE CARRIAGE TO LEFT END OF ITS TRACK AND TILT LOWER PART OF THE CARRIAGE FORWARD TO DISENGAGE ROLLER FROM TRACK. REINSTALL IN REVERSE ORDER, MAKE SURE THAT PRINTING LEVER ARM IS RE-ENGAGED CORRECTLY WITH THE PRINTING BAIL. POSITION CARRIAGE CLAMP ON CABLE FOR CORRECT PRINTING. SEE FIGURE 43

FIGURE 13 TYPER, CODE BAR SHIFT MECHANISM

INSTRUCTION FOR REMOVING SELECTOR CAM ASSEMBLY WITH CLUTCH

NOTE - - - REMOVE ONLY FOR SERVICING

LIFT THE PUSH LEVER BAIL CAM FOLLOWER FROM THE CAM AND LATCH IT IN THE RAISED POSITION ON THE LEDGE OF THE PUSH LEVER GUIDE BY SLIDING IT TO THE LEFT. LIFT SELECTOR LEVERS AND MARKING LOCK LEVER FROM THEIR CAMS BY MOVING THE MARKING LOCK LEVER FORWARD UNTIL THE ARMATURE DROPS BEHIND IT.  
 REMOVE NUT AND SCREW WHICH MOUNT SELECTOR CLUTCH DRUM AND POSITION THE SELECTOR CLUTCH SO THAT THE STOP LUG IS IN THE UPPERMOST POSITION.  
 HOLD START LEVER AND SPACING LOCKLEVER AWAY FROM THEIR CAMS WITH FOREFINGER OF LEFT HAND AND WITH DRAW THE CAM ASSEMBLY BY SLIDING IT TO THE RIGHT WHILE ROCKING IT BACK AND FORTH SLIGHTLY.  
 REPLACE THE ASSEMBLY IN THE REVERSE ORDER EXCEPT FOR THE FOLLOWING. AS THE CAM ASSEMBLY APPROACHES ITS FULLY INSTALLED POSITION, IT WILL BE NECESSARY TO POSITION THE CODE BAR CLUTCH TRIP CAM FOLLOWER AND THE SELECTOR CLUTCH LATCH SO THEY RIDE ON THEIR RESPECTIVE CAM SURFACES.  
 RESTORE PUSH LEVER BAIL AND THE ARMATURE TO THEIR NORMAL OPERATING POSITIONS.



INSTRUCTIONS FOR REMOVING TYPE BOX CARRIAGE

NOTE - - - REMOVE ONLY FOR SERVICING

MOVE TYPE BOX CARRIAGE TO EXTREME RIGHT. HOLD CODE BARS IN MARKING POSITION AND ROTATE MAIN SHAFT SO THAT TYPE BOX IS IN ITS UPPERMOST POSITION. REMOVE RETAINER RING FROM STUD AT RIGHT END OF TYPE BOX CARRIAGE LINK AND DISENGAGE LINK FROM CARRIAGE. ROTATE PRINTER SHAFT SO THAT TYPE BOX IS IN ITS LOWEST POSITION. HOLD RIBBON GUIDE FORWARD AND RIBBON REVERSE LEVER BACK AND PULL CARRIAGE TOWARD THE RIGHT TO DISENGAGE IT FROM CARRIAGE RACK. REINSTALL CARRIAGE IN REVERSE ORDER.




FIGURE 14 TYPWR, CODE BAR SHIFT MECHANISM

INSTRUCTIONS FOR REMOVING CODE BAR SHIFT MECHANISM

NOTE - - - REMOVE ONLY FOR SERVICING

REMOVE THE SPRING ATTACHED TO COMMON TRANSFER LEVER AND RESTORE ANY OPERATED PUSH BARS TO THE SPACING POSITION BY RAISING THE RESET BAIL.

LOOSEN THE CLAMP SCREW ON THE SHIFT LEVER, AND REMOVE THE TWO SCREWS WHICH MOUNT THE MECHANISM - ONE TO SIDE FRAME, OTHER TO SELECTOR MECHANISM MANIPULATE THE TRANSFER LEVERS AND CODE BAR EXTENSIONS WHILE GENTLY TWISTING THE MECHANISM SO AS TO SLIDE THE MECHANISM OFF THE CODE BAR EXTENSIONS. ↓

TO REPLACE THE MECHANISM ON THE TYPING UNIT, REVERSE THE PROCEDURE USED IN REMOVING IT, EXCEPT FOR THE FOLLOWING:

WITH THE MAIN SHAFT IN THE STOP POSITION, PUSH THE CODE BAR EXTENSIONS TO THE MARKING POSITION (LEFT, OR IN). MANIPULATE THE CODE BAR EXTENSIONS AND TRANSFER LEVERS SO THAT THE EXTENSIONS LINE UP WITH THEIR RESPECTIVE SLOTS, AND SLIDE THE EXTENSIONS THROUGH THE SLOTS, ONE AT A TIME (BOTTOM SLOT VACANT.)




FIGURE 15 TYPWR, CODE BAR SHIFT MECHANISM




FIGURE 16 TYPYER, CODE BAR CLUTCH TRIP SHAFT MECHANISM





FIGURE 17 TYPER, FUNCTION CLUTCH MECHANISM



CLUTCH TRIP SHAFT SET COLLARS

(1) REQUIREMENT

THE SPACING CLUTCH LATCH LEVER SHOULD HAVE SOME SIDE PLAY.  
MAX. 0.008 INCH

TO ADJUST

POSITION THE SPACING CLUTCH LATCH LEVER SET COLLAR.

(2) REQUIREMENT

APPROXIMATE ALIGNMENT OF RIGHT END OF STOP EXTENSIONS  
ON TRIP LEVER AND SHOE LEVER

TO ADJUST

POSITION THE LINE FEED CLUTCH TRIP LEVER SET COLLAR

(3) REQUIREMENT

THE LINE FEED CLUTCH LATCH LEVER SHOULD  
HAVE SOME SIDE PLAY  
MAX. 0.008 INCH

TO ADJUST

POSITION THE LINE FEED CLUTCH LATCH LEVER  
SET COLLAR.

ANTI-DEFLECTION PLATE

REQUIREMENT

WITH THE TYPING UNIT UPSIDE DOWN  
MIN. 1 LB.  
MAX. 5 LBS.

TO PULL TRIP SHAFT AWAY FROM ANTI-DEFLECTION PLATE

TO ADJUST

POSITION THE PLATE WITH ITS MOUNTING SCREWS LOOSENED.





FIGURE 18 TYPER , TRIP LATCH MECHANISM




SPACING CLUTCH TRIP LEVER

REQUIREMENT

SPACING AND TYPE BOX CLUTCHES DISENGAGED.  
TRIP LEVER ARM IN ITS UPWARD POSITION  
TRIP LEVER SHOULD BE APPROXIMATELY  
FLUSH WITH OUTER SURFACE OF THE SHOE  
LEVER OR UNDER FLUSH BY NOT MORE  
THAN 1/2 THE THICKNESS OF THE SHOE LEVER.  
CHECK THE STOP LUG WITH THE LEAST ENGAGEMENT  
TO ADJUST  
POSITION THE TRIP LEVER ADJUSTING SCREW.

SPACING CLUTCH TRIP LEVER SPRING



CLUTCH TRIP LEVER SPRING TENSION

1. SPACING
2. LINE FEED
3. TYPE BOX

REQUIREMENT

CLUTCH ENGAGED AND ROTATED UNTIL  
TRIP LEVER RESTS ON STOP LUG.  
MIN. 5 OZS.  
MAX. 7 1/4 OZ.  
TO MOVE TRIP LEVER AWAY FROM STOP LUG

FIGURE 19 TYPER, SPACING CLUTCH MECHANISM

**A. TYPE BOX CLUTCH TRIP LEVER  
ECCENTRIC POST**

**REQUIREMENT**

TYPE BOX CLUTCH DISENGAGED.  
TRIP LEVER SHOULD ENGAGE THE CLUTCH  
SHOE LEVER BY THE FULL THICKNESS OF  
THE SHOE LEVER

**TO ADJUST**  
POSITION THE TRIP LEVER ECCENTRIC  
POST.

TYPE-BOX CLUTCH

TRIP ARM

CLUTCH SHOE LEVER

TRIP LEVER

TRIP LEVER ECCENTRIC POST

**C. LINE FEED CLUTCH TRIP LEVER**

**ADJUSTING SCREW**

**REQUIREMENT**

LINE FEED FUNCTION SLIDE ARM  
IN REAR POSITION.  
CLUTCH TRIP LEVER AGAINST ITS  
ECCENTRIC POST.  
TRIP ARM HELD AGAINST ITS  
FUNCTION SLIDE ARM.  
SOME CLEARANCE BETWEEN THE  
END OF THE TRIP LEVER ADJUST-  
ING SCREW AND THE TRIP ARM.  
MAX. 0.006 INCH

**TO ADJUST**  
POSITION THE ADJUSTING SCREW.

LINE FEED FUNCTION SLIDE ARM

TRIP ARM

ADJUSTING SCREW

**B. LINE FEED CLUTCH TRIP LEVER  
ECCENTRIC POST**

**REQUIREMENT**

TRIP LEVER ADJUSTING SCREW  
BACKED OFF.  
LINE FEED CLUTCH IN ITS STOP  
POSITION.  
TRIP LEVER SHOULD ENGAGE THE  
CLUTCH SHOE LEVER BY THE FULL  
THICKNESS OF THE SHOE LEVER.  
CHECK AT STOP LUG WITH LEAST  
ENGAGEMENT.

**TO ADJUST**  
POSITION THE TRIP LEVER  
ECCENTRIC POST.


LINE FEED CLUTCH

CLUTCH SHOE LEVER

LINE FEED CLUTCH TRIP LEVER

TRIP LEVER  
ECCENTRIC POST

FIGURE 20 TYPER, TYPE BOX CLUTCH AND LINE FEED CLUTCH MECHANISM

TYPE BOX CLUTCH TRIP LEVER

(1) REQUIREMENT (See Note 3 Page 2-1)  
CLUTCH TRIP SHAFT CAM FOLLOWER ROLLER  
(SEE FIG. 17 ) ON THE LOWEST SUR-  
FACE OF CAM (LOCATED ON CODE BAR  
CLUTCH). CLEARANCE BETWEEN INNER  
FACE OF TYPE BOX CLUTCH TRIP LEVER  
AND THE CLUTCH DISK STOP LUG.

MIN. 0.040 INCH  
MAX. 0.050 INCH

TO ADJUST

LOOSEN CLAMP SCREW AND POSITION STOP.

(2) REQUIREMENT


WHEN POSITIONING THE TRIP ARM  
DETERMINE THAT THE LATCH LEVER  
HAS SOME SIDE PLAY.

MAX. 0.008 INCH

TO ADJUST

POSITION THE CLUTCH TRIP  
ARM ON ITS SHAFT WITH THE  
CLAMP SCREW LOOSENED.

FIGURE 21 TYPER, TYPE BOX CLUTCH MECHANISM

CLUTCH SHOE LEVER

## REQUIREMENT

GAP BETWEEN CLUTCH SHOE LEVER AND ITS  
STOP LUG SHOULD BE 0.055 INCH TO 0.075  
INCH GREATER WHEN CLUTCH IS ENGAGED  
THAN WHEN THE CLUTCH IS DISENGAGED.

TO CHECK

DISENGAGE THE CLUTCH AND MEASURE THE  
GAP. TRIP THE CLUTCH AND ROTATE IT UNTIL  
THE CLUTCH SHOE LEVER IS TOWARD THE BOTTOM  
OF THE UNIT. ALIGN THE HEAD OF THE CLUTCH  
DRUM MOUNTING SCREW WITH THE STOP LUG.  
MANUALLY COMPRESS THE SHOE LEVER AGAINST  
THE STOP LUG AND ALLOW THEM TO SNAP APART.  
AGAIN MEASURE THE GAP WITH THE CLUTCH THUS  
ENGAGED.

## NOTE

ON MULTIPLE STOP CLUTCHES CHECK THE CLEARANCE  
AT THE STOP LUG THAT IS ADJACENT TO THE NOTCH  
IN THE CLUTCH ADJUSTING DISK.

TO ADJUST


LOOSEN THE TWO CLAMP SCREWS ON THE CLUTCH DISK. ENGAGE A WRENCH ON THE LUG OF THE  
ADJUSTING DISK AND ROTATE THE DISK.

## NOTE

AFTER THE ABOVE ADJUSTMENT IS MADE, DISENGAGE THE CLUTCH, REMOVE THE DRUM MOUNTING  
SCREW AND ROTATE THE DRUM IN ITS NORMAL DIRECTION OF ROTATION TO MAKE CERTAIN THAT  
IT DOES NOT DRAG ON THE SHOE IF THE DRUM DRAGS, REFINE THE ABOVE ADJUSTMENT.

FIGURE 22 TYPER, CLUTCH SHOE MECHANISM (ALL CLUTCHES)





CLUTCH DRUM POSITION (EXCEPT SELECTOR)

REQUIREMENT  
 CLUTCH SHOE LEVER HELD DISENGAGED. CLUTCH SHOULD HAVE SOME END PLAY  
 MAX. 0.020 INCH

TO ADJUST  
 POSITION EACH DRUM AND SPACING CLUTCH SET COLLAR WITH MOUNTING SCREWS LOOSENED.





FIGURE 23 TYPER, CLUTCH MECHANISM, LEFT SIDE VIEW



**A STUNT CASE CODE BAR SHIFT MECHANISM REQUIREMENT**

WITH LATCH FUNCTION LEVER ON ITS LOWER RELEASING LATCH, NOTCH IN SUPPRESSION CODE BAR SHOULD ALIGN WITH NOTCHES, IN OTHER CODE BARS

**TO ADJUST**

POSITION PROPER GUIDE PLATE WITH ITS CLAMP NUTS LOOSENED. (Similar parts Figure 53 and 54). REPEAT FOR EACH STUNT CASE CODE BAR SHIFT MECHANISM.

**B CONDITION CODE ( ZERO ) CODE BAR SHIFT MECHANISM REQUIREMENT**

NOTCH IN CONDITION CODE BAR SHOULD ALIGN WITH NOTCHES IN OTHER CODE BARS

**TO ADJUST**

POSITION GUIDE PLATE ( FIG.53. WITH CLAMP NUTS LOOSENED.

**C TYPE BOX CLUTCH SUPPRESSION ARM REQUIREMENT**

WITH SUPPRESSION ARMS IN BLOCKED POSITION. SOME TO 0.005 INCH CLEARANCE BETWEEN TRIP ARM EXTENSION AND CLUTCH TRIP LEVER.

**TO ADJUST**


POSITION SUPPRESSION ARM WITH ITS MOUNTING SCREWS LOOSENED.

**D OFF LINE STUNT SHIFT BRACKET ASSEMBLY REQUIREMENT**

NOTCH IN SUPPRESSION CODE BAR SHOULD ALIGN WITH NOTCHES IN OTHER CODE BARS WHEN SOLENOID IS HELD IN OPERATED POSITION

**TO ADJUST**

POSITION SOLENOID BRACKET ASSEMBLY WITH ITS MOUNTING SCREWS LOOSENED.






FIGURE 25 TYPWR, SPACING MECHANISM




FIGURE 26 TYPEWRITER, LINE FEED AND ROCKER SHAFT MECHANISM

ROCKER SHAFT BRACKET ECCENTRIC STUD

REQUIREMENT


TYPE BOX CLUTCH DISENGAGED. PLAY IN ROLLER ARM TAKEN TOWARD FRONT. DISTANCE BETWEEN THE LOWER SIDE OF THE LOCK LEVER ROLLER AND THE TOP EDGE OF THE SHOULDER ON THE HORIZONTAL POSITIONING LOCK LEVER SHOULD BE  
 MIN. 0.065 INCH  
 MAX. 0.080 INCH

TO ADJUST

POSITION THE ECCENTRIC STUD IN THE LOWER END OF THE ROCKER SHAFT LEFT BRACKET. KEEP HIGH PART OF ECCENTRIC (MARKED WITH DOT) BELOW CENTER LINE OF DRIVE LINK.

NOTE

AFTER MAKING RELATED ADJUSTMENTS ANY CHANGE IN THIS ADJUSTMENT WILL REQUIRE A RECHECKING OF THE FOLLOWING ADJUSTMENTS: HORIZONTAL POSITIONING DRIVE LINKAGE (FIGURE -32), RIGHT VERTICAL POSITIONING LEVER ECCENTRIC STUD (FIGURE 28), LEFT VERTICAL POSITIONING LEVER ECCENTRIC STUD (FIGURE 29), VERTICAL POSITIONING LOCK LEVER (FIGURE -35), RIBBON FEED LEVER STOP BRACKET (FIGURE -47), FUNCTION STRIPPER BLADE ARMS (FIGURE -55), SPACING TRIP-LEVER BAIL CAM PLATE (FIGURE -31), PRINTING TRACK (FIGURE -44), PRINTING ARM (FIGURE -45), REVERSING SLIDE BRACKETS (FIGURE -60).



REQUIREMENT

LOCK LEVER IN ITS UPPER POSITION.  
 MIN. 28 OZS.  
 MAX. 43 OZS.  
 TO START LEVER MOVING UPWARD.

BREAKER SLIDE BAIL SPRING TENSION

REQUIREMENT

BREAK SLIDE BAILS IN THEIR LOWER POSITION.  
 MIN. ½ OZ.  
 MAX. 1¼ OZS.  
 TO START BAIL MOVING

FIGURE 27 TYPER, SHIFT AND POSITIONING MECHANISMS




FIGURE 28 TYPER, VERTICAL POSITIONING MECHANISM, RIGHT






FIGURE 29 TYPER, VERTICAL POSITIONING MECHANISM, LEFT SIDE



OSCILLATING RAIL SLIDE POSITION

REQUIREMENT (See Note 3 Page 2-1)  
 SPACING CUTOUT LEVER AND AUTOMATIC C.R. L.F. ARM IN MAXIMUM COUNTER-CLOCKWISE POSITION ON THE SPACING DRUM. SPACING CLUTCH DISENGAGED. SPACING PAWL WHICH IS FARTHEST ADVANCED ENGAGED WITH THE TOOTH THAT IS JUST ABOVE CUT-AWAY SECTION IN THE RATCHET WHEEL. THE RIGHT END OF THE OSCILLATING RAIL SLIDE SHOULD CLEAR THE PULLEY BY  
 MIN. 0.025 INCH  
 MAX. 0.050 INCH

TO ADJUST  
 POSITION THE SLIDE ON THE WIRE ROPE WITH ITS CLAMP SCREWS LOOSENED.



SPACING FEED PAWL SPRING TENSION

REQUIREMENT  
 EACH SPACING PAWL IN LEAST ADVANCED POSITION AND RESTING AGAINST RATCHET WHEEL, EACH SPRING UNHOOKED FROM SPRING BRACKET  
 MIN. 2 1/2 OZ.  
 MAX. 4 OZS.  
 TO PULL SPRINGS TO INSTALLED LENGTH

FIGURE 30. TYPER, SPACING MECHANISM






FIGURE 31 TYPYER, SPACING MECHANISM

226B





FIGURE 32 TYPER, HORIZONTAL MOTION REVERSING MECHANISM

HORIZONTAL POSITIONING DRIVE LINKAGE

## REQUIREMENT

TYPE BOX CLUTCH DISENGAGED.

CODE BARS 5 AND 5 TO SPACING (RIGHT)


CLEARANCE BETWEEN EACH SIDE OF CENTER HORIZONTAL STOP SLIDE AND DECELERATING SLIDES, ON SIDE WHERE KNEE LINK IS STRAIGHT, SHOULD BE EQUAL (WITHIN 0.005 INCH)

MIN. 0.015 INCH

MAX. 0.040 INCH

## TO ADJUST

LOOSEN TWO MOUNTING SCREWS OF BOTH BEARING STUDS (INNER TWO FRICTION TIGHT). POSITION ONE OR BOTH BEARING STUDS ON THE CONNECTING STRIP TO PROVIDE 0.025 INCH TO 0.035 INCH BETWEEN THE CENTER HORIZONTAL SLIDE AND THE DECELERATING SLIDE ON THE SIDE WHERE THE LINKAGE IS NOT BUCKLED. TIGHTEN THE TWO INNER MOUNTING SCREWS. CHANGE POSITION OF REVERSING SLIDE AND CHECK OPPOSITE CLEARANCE. EQUALIZE BY SHIFTING BOTH STUDS AND CONNECTING STRIP AS A UNIT. HOLD THE DRIVE LINKAGE HUB AGAINST THE LOWER VERTICAL LINK OF THE DRIVE LINKAGE. TIGHTEN THE TWO OUTER BEARING STUD MOUNTING SCREWS. CHECK THE LINKAGE FOR FREENESS THROUGHOUT A COMPLETE CYCLE.

HORIZONTAL POSITIONING DRIVE LINKAGE  
SPRING TENSION

## REQUIREMENT


WITH THE LINKAGE IN ITS STRAIGHT POSITION AND A 32 OZ. PUSH SCALE APPLIED NEAR THE END OF THE UPPER EXTENSION

MIN. 7 OZS.

MAX. 12 OZS.

TO START THE LINK BUCKLING

FIGURE 33 TYPWR, SHIFT SLIDE DRIVE MECHANISM



FUNCTION RESET BAIL BLADE

(See Note 3 Page 2-1)

(1) REQUIREMENT

CLEARANCE BETWEEN FRONT EDGE OF CARRIAGE RETURN AND INNER LINE FEED FUNCTION BARS AND EDGE OF RESET BAIL WHEN FUNCTION BARS ARE HELD IN THEIR EXTREME REAR POSITION  
MIN. 0.018 — MAX. 0.030 INCH

NOTE - - - ANY UNIT WITH FUNCTION BARS LOCATED BETWEEN THE NO. 10 AND NO. 30 SLOT, MEASURE CLEARANCE ON FUNCTION BARS CLOSEST TO EACH OF THE BLADE INNER MOUNTING SCREWS.

TO CHECK

DISENGAGE FUNCTION AND TYPE BOX CLUTCHES AND UNLATCH FUNCTION PAWLS FROM THEIR RESPECTIVE FUNCTION BARS. LOOSEN CARRIAGE RETURN LEVER CLAMP SCREWS.

TO ADJUST

POSITION BLADE ON FUNCTION BAIL WITH ITS MOUNTING SCREWS FRICTION TIGHT.

(2) REQUIREMENT

TYPE BOX CLUTCH ROTATED 1/2 REVOLUTION. EACH FUNCTION LEVER IN TURN HELD IN ITS EXTREME REAR POSITION. LATCH ASSOCIATED FUNCTION PAWL ONE AT A TIME. HOOK SCALE OVER END OF FUNCTION PAWL. WITH NOT MORE THAN 16 OZS. APPLIED, THE CLEARANCE BETWEEN FUNCTION PAWL AND ITS BAR SHOULD NOT BE LESS THAN 0.006 INCH.

NOTE - - - DO NOT LATCH MORE THAN ONE FUNCTION PAWL AT A TIME. THE SHIFT CODE BAR SHOULD HAVE SOME END PLAY WHEN LETTERS AND FIGURES FUNCTION PAWLS ARE ALTERNATELY LATCHED ON THEIR BARS

TO ADJUST

REFINE ABOVE ADJUSTMENT AND /OR SHIFT CODE BAR OPERATING MECHANISM, ADJUSTMENT. ALSO STUNT SHIFT MECHANISM ADJUSTMENT AND ZERO CODE BAR MECHANISM ADJUSTMENT.




FIGURE 34 TYPER, RESET BAIL MECHANISM

INSTRUCTIONS FOR REMOVING FRONT PLATE ASSEMBLY

NOTE - - - REMOVE ONLY FOR SERVICING

REMOVE TYPING UNIT FROM BASE (SEE P.3-2). REMOVE RETAINING RING FROM TYPE BOX CARRIAGE LINK RIGHT STUD AND DISENGAGE LINK FROM CARRIAGE (SEE FIG. 43). REMOVE TWO SCREWS WHICH SECURE HORIZONTAL MECHANISM ROCKER BRACKET TO ROCKER SHAFT. REMOVE SPACING SHAFT GEAR. REMOVE FOUR SCREWS WHICH SECURE FRONT PLATE ASSEMBLY TO TYPER FRAME AND PULL FRONT PLATE FORWARD TO DISENGAGE IT FROM CONNECTING PARTS OF THE UNIT. REINSTALL IN REVERSE ORDER. MAKE SURE THAT HORIZONTAL STOP BELL CRANKS, SHIFT SLIDE LEVER, REVERSING SLIDE LEVER, AUTOMATIC C.R.-L.F. BELL CRANK, AND CARRIAGE RETURN LEVER EXTENSION ARE PROPERLY ENGAGED WITH MATING PARTS BEFORE TIGHTENING PLATE MOUNTING SCREWS. REPLACE SPACING SHAFT GEAR (SEE P. 2-25 FOR PHASING)




FIGURE 35 TYPER, VERTICAL POSITIONING MECHANISM




FIGURE 36 TYPER, SPACING MECHANISM

CARRIAGE WIRE ROPE

REQUIREMENT (See Note 3 Page 2-1)

CLEARANCE BETWEEN LOWER WIRE ROPE AND CARRIAGE RETURN LATCH BAIL POST SHOULD BE AT LEAST 0.006 INCH. WITH THE HORIZONTAL POSITIONING MECHANISM IN ITS LOWEST POSITION, CLEARANCE BETWEEN THE LOWER WIRE ROPE AND THE LEFT HORIZONTAL POSITIONING DRIVE LINKAGE SHOULD BE:  
MIN. 0.030 INCH  
TO ADJUST

RETURN THE PRINTING CARRIAGE TO ITS LEFT HAND POSITION. LOOSEN THE ROPE CLAMP SCREW ONE TURN ONLY. POSITION THE PULLEY BEARING STUDS WITH THEIR MOUNTING SCREWS LOOSENED TO MEET THE REQUIREMENT. MAKE CERTAIN THAT THE ROPE MOVES AROUND ITS CLAMP SCREW TO AN EQUALIZED POSITION TIGHTEN THE CLAMP SCREW AND MOUNTING SCREWS.

LOWER WIRE ROPE PULLEY BAIL SPRING

REQUIREMENT

SPRING UNHOOKED FROM PULLEY BAIL, BAIL EXTENSION RESTING ON OPENING IN FRONT PLATE.

MIN. 18 OZS.

MAX. 22 OZS.

TO PULL SPRING TO POSITION LENGTH




FIGURE 37 TYPWR, CARRIAGE RETURN MECHANISM

INSTRUCTIONS FOR REMOVING CODE BAR ASSEMBLY

NOTE - - - REMOVE ONLY FOR SERVICING

REMOVE TYPING UNIT FROM BASE. (SEE P.3-2.) REMOVE STUNT BOX ASSEMBLY (P 2-50) AND FRONT PLATE ASSEMBLY (P2-35) REMOVE CODE BAR ASSEMBLY MOUNTING SCREWS- 2 EACH SIDE. REMOVE CODE BAR SHIFT BAR RETAINER PLATE AND THE SHIFT BARS. PULL THE CODE BAR ASSEMBLY FORWARD AND TO THE LEFT. REINSTALL CODE BAR ASSEMBLY IN REVERSE ORDER. LOOSEN TIE BAR SCREWS AND PRESS THE ASSEMBLY TOWARD THE REAR AND DOWNWARD AGAINST THE LOCATING SURFACES.





FIGURE 38 TYPER, CARRIAGE RETURN MECHANISM






CARRIAGE RETURN LEVER

REQUIREMENT

CARRIAGE RETURN FUNCTION SET UP ON SELECTOR. MAIN SHAFT ROTATED UNTIL FUNCTION CLUTCH IS DISENGAGED IN STOP POSITION THAT RESULTS IN LEAST CLEARANCE. CARRIAGE RETURN FUNCTION PAWL HOOKED ONTO ITS FUNCTION BAR. SPACING DRUM HELD SO THAT THE CARRIAGE RETURN LATCH BAIL IS IN ITS LATCHED POSITION. CLEARANCE BETWEEN LATCHING FACE OF CARRIAGE LATCH BAIL AND TOP OF CARRIAGE RETURN LEVER  
 MIN. 0.006 INCH  
 MAX. 0.025 INCH  
 POSITION THE CARRIAGE RETURN LEVER ON THE CARRIAGE RETURN BAIL WITH ITS CLAMP SCREW LOOSENED

FIGURE 39 TYPWR, CARRIAGE RETURN MECHANISM

**DASH POT VENT SCREW**

REQUIREMENT (See Note 3 Page 2-1)

TYPE BOX CARRIAGE SHOULD RETURN FROM ANY LENGTH OF LINE WITHOUT BOUNCING WHEN THE PRINTER IS OPERATED UNDER POWER FROM AUTOMATIC TRANSMISSION OF ONE CR AND ONE LF SIGNAL BETWEEN LINES AT ANY SPEED. THE FIRST CHARACTER OF EACH LINE SHOULD BE PRINTED IN THE SAME LOCATION (GAUGED BY EYE) AS IT WOULD IF THE UNIT WERE OPERATED SLOWLY IN MANUAL OPERATION TO ADJUST

BACK OFF THE VENT SCREW UNTIL A MECHANICAL BOUNCE IS PERCEPTIBLE THEN ADVANCE THE SCREW UNTIL A SLIGHT PNEUMATIC BOUNCE IS PERCEPTIBLE. LOCK THE SCREW HALF WAY BETWEEN THE TWO POSITIONS.

FIGURE 40. TYPWR, DASHPOT MECHANISM

**INSTRUCTIONS FOR REPLACING THE SPACING CABLES**

NOTE - - - DO NOT REMOVE UNLESS THERE IS REASON TO BELIEVE THAT THE ADJUSTMENTS CAN NOT BE MADE.

**CARRIAGE CABLE**

RETURN THE CARRIAGE TO THE LEFT POSITION. UNWIND CARRIAGE RETURN SPRING BY LOOSENING NUT ON FRONT OF SPRING DRUM BEARING POST AND OPERATING RATCHET ESCAPEMENT LEVER. REMOVE CABLE FROM CLAMP ON PRINTING CARRIAGE, AND THE CLAMP ON TYPE BOX DRIVING DRIVING SLIDE. LOOSEN CLAMP SCREW WHICH SECURES CABLE TO SPRING DRUM, AND REMOVE SCREW IN SPACING DRUM WHICH SECURES THE ENDS OF THE CABLE, AND REMOVE CABLE FROM DRUM. REPLACE IN REVERSE ORDER.

**LOWER TIE CABLE**

REMOVE SCREW WHICH SECURES CABLE TO SPACING DRUM AND REMOVE END OF CABLE FROM THE DRUM. LOOSEN SCREWS WHICH SECURE MARGIN BELL CONTACT CAM PLATE ON SPACING DRUM AND POSITION THE PLATE TO EXPOSE CABLE MOUNTING SCREW. REMOVE CABLE SCREW AND REMOVE CABLE FROM SPRING DRUM. LOOSEN SCREWS IN BEARING STUDS ON PRINTING CARRIAGE CABLE ROLLERS AND MOVE STUDS TOWARD CENTER OF TYPING UNIT. REPLACE IN REVERSE ORDER. WHEN INSTALLING CABLE OBSERVE THAT EACH CABLE IS IN ITS CORRECT TRACK AROUND DRUMS. (LOWER CABLE SHOULD BE TOWARD FRONT OF DRUM) ADJUST POSITION OF TYPE BOX, PRINTING CARRIAGE, MARGIN CONTACT CAM PLATE AND CABLE TENSION AS SPECIFIED IN ADJUSTING REQUIREMENTS.




FIGURE 41 TYPWR, CARRIAGE RETURN MECHANISM




FIGURE 42 TYPER, RIGHT MARGIN AND DECELERATING SLIDE MECHANISM





FIGURE 43 TYPER, PRINTING AND TYPE BOX CARRIAGE



**SHIFT LINKAGE REQUIREMENT** (See Note 3 Page 2-1)  
 CARRIAGE NEAR MIDPOINT OF PLATEN.  
 TYPE BOX IN POSITION TO PRINT "M".  
 MANUALLY BUCKLE RIGHT SHIFT LINKAGE  
 AND SHIFT TYPE BOX TO LEFT. THE  
 PERIOD TYPE PALLET SHOULD BE APPROXIMATELY  
 IN THE CENTER OF THE PRINT HAMMER WHEN  
 THE PRINT HAMMER IS JUST TOUCHING THE  
 PERIOD TYPE PALLET.  
 TO ADJUST  
 POSITION THE LEFT SHIFT LINKAGE ON  
 THE OSCILLATOR RAIL WITH ITS TWO  
 CLAMP SCREWS LOOSENED.  
 RECHECK THE ADJUSTMENT BY SHIFTING  
 ALTERNATELY FROM M TO PERIOD. TAKE  
 UP PLAY IN EACH DIRECTION AND REFINE  
 THE ADJUSTMENT IF NECESSARY.

**SHIFT LINKAGE SPRING TENSION REQUIREMENT**  
 LINK IN STRAIGHT POSITION.  
 MIN. 9 OZS.  
 MAX. 14 OZS.  
 TO START EACH LINK MOVING.

**PRINTING HAMMER BEARING STUD REQUIREMENT**  
 TYPE BOX AT MIDPOINT OF PLATEN AND IN POSITION  
 TO PRINT PERIOD..PRINTING HAMMER  
 IN CONTACT WITH TYPE PALLET AND PRESSED  
 DOWNWARD AT ITS BEARING POST. FACE  
 OF THE HAMMER SHOULD BE FULLY ON THE  
 END OF THE TYPE PALLET.  
 TO ADJUST  
 ADD OR REMOVE SHIMS BETWEEN THE SHOULDER  
 ON THE BEARING POST AND THE STOP BRACKET.

FIGURE 44 TYPWR, SHIFT MECHANISM




FIGURE 45 TYPER, PRINTING MECHANISM

PRINTING HAMMER STOP BRACKET


REQUIREMENT

TYPE BOX, IN BLANK POSITION AND NEAR CENTER OF PLATEN. PRINTING BAIL IN ITS DOWNWARD POSITION. PRINTING HAMMER HELD AGAINST ITS STOP WITH 8 OZS. OF PRESSURE, CLEARANCE BETWEEN PRINTING HAMMER AND DUMMY TYPE PALLET  
 MIN. 0.015 INCH  
 MAX. 0.030 INCH

TO ADJUST

POSITION THE STOP BRACKET WITH ITS MOUNTING SCREWS AND THE PRINTING HAMMER BAIL PIVOT STUD LOOSENED.

(See Note 3 Page 2-1)



TYPE PALLET SPRING TENSION

REQUIREMENT

TYPE BOX REMOVED FROM THE UNIT. 8 OZ. SCALE APPLIED VERTICALLY TO THE END OF THE PALLET SHANK.  
 MIN. 1/4 OZS.  
 MAX. 3/4 OZ.  
 TO START PALLET MOVING

PRINTING ARM

(1) REQUIREMENT

PRINTING TRACK IN MAXIMUM DOWNWARD POSITION. PRINTING HAMMER OPERATING BAIL AGAINST ITS STOP. SOME CLEARANCE BETWEEN SECONDARY PRINTING ARM AND FORWARD EXTENSION OF HAMMER OPERATING BAIL.  
 MAX. 0.012 INCH  
 WHEN PRINTING ARM SLIDE IS HELD DOWNWARD OVER EACH PRINTING TRACK MOUNTING SCREW FOR MAXIMUM CLEARANCE.

(2) REQUIREMENT

PRINTING TRACK IN UPPERMOST POSITION. LATCHING EXTENSION OF PRINTING HAMMER OPERATING BAIL SHOULD OVERTRAVEL LATCHING SURFACE OF OPERATING BAIL LATCH BY MIN. 0.006 INCH  
 CHECK RIGHT AND LEFT POSITIONS


TO ADJUST

POSITION SECONDARY PRINTING ARM WITH CLAMP SCREWS LOOSENED.

NOTE

THE PRINTING ARM ADJUSTMENT SHOULD ALWAYS BE MADE WITH THE PRINTING HAMMER OPERATING BAIL SPRING BRACKET (FIGURE -37) IN THE NO 1 POSITION. POSITIONS NO. 2 AND NO. 3 ARE TO BE USED ONLY FOR MAKING MULTIPLE COPIES.






RIBBON REVERSE SPUR GEAR

**REQUIREMENT**

WHEN RIGHT REVERSING LEVER IS IN MAXIMUM DOWNWARD POSITION, THE LEFT REVERSING LEVER SHOULD BE IN ITS MAXIMUM UPWARD POSITION.

**TO ADJUST**


LOOSEN THE SET SCREWS IN THE DETENT CAM. LOOSEN THE LEFT SPUR GEAR NUT. SECURELY TIGHTEN THE RIGHT SPUR GEAR NUT. MOVE THE RIGHT REVERSING LEVER TO ITS MAXIMUM DOWNWARD POSITION AND HOLD THE LEFT REVERSING LEVER IN ITS MAXIMUM UPWARD POSITION. THEN TIGHTEN THE LEFT SPUR GEAR NUT.



RIBBON REVERSE DETENT LEVER SPRING TENSION

**REQUIREMENT**

DETENT SEATED IN NOTCH OF CAM. RIGHT RIBBON REVERSING LEVER HELD DOWNWARD.  
 MIN. 6½ OZS.  
 MAX. 9 OZS.  
 TO START THE DETENT LEVER MOVING.




RIBBON REVERSE DETENT

**REQUIREMENT**

DETENT SHOULD BE SEATED APPROXIMATELY EQUAL IN EACH NOTCH OF CAM. FREE END OF THE DETENT FLUSH WITH CAM.  
**TO ADJUST**  
 POSITION THE CAM ON ITS SHAFT WITH ITS SET SCREWS LOOSENED.

FIGURE 47 TYPER, RIBBON REVERSE MECHANISM

(See Note 3 Page 2-1)



RIBBON FEED LEVER BRACKET

(1) REQUIREMENT (LEFT-HAND MECHANISM)  
 LEFT REVERSING LEVER IN UPWARD POSITION.  
 RIBBON MECHANISM IN UPPER POSITION  
 RATCHET WHEEL HELD AGAINST THE DETENT LEVER.  
 CLEARANCE BETWEEN THE FRONT FACE OF THE  
 FEED LEVER AND THE SHOULDER OF A TOOTH  
 ON THE RATCHET WHEEL  
 MIN. 0.020 INCH  
 MAX. 0.030 INCH

TO ADJUST  
 POSITION THE FEED LEVER BRACKET WITH ITS  
 MOUNTING SCREWS LOOSENED.

(2) REQUIREMENT (RIGHT-HAND MECHANISM)  
 RIGHT REVERSING LEVER AND RIBBON  
 MECHANISM IN UPWARD POSITION.  
 ADJUST FEED LEVER BRACKET IN THE  
 SAME MANNER.

NOTE  
 ROTATE THE MAIN SHAFT. THE  
 RATCHET WHEEL SHOULD STEP ONE  
 TOOTH ONLY WITH EACH OPERATION.

RIBBON FEED LEVER SPRING TENSION

REQUIREMENT

FEED LEVER AND DETENT LEVER IN RATCHET  
 WHEEL TOOTH. SCALE APPLIED VERTICALLY TO EACH  
 LEVER NEAR FEED LEVER SPRING

MIN. 3/4 OZ.

MAX. 2 OZS.

TO START EACH LEVER MOVING DOWNWARD. CHECK  
 LEFT AND RIGHT. IF NECESSARY ADJUST TORSION  
 SPRING BY PULLING LOWER END TOWARD REAR.

RIBBON RATCHET WHEEL FRICTION  
 SPRING TENSION

REQUIREMENT

FEED LEVERS DISENGAGED.

MIN. 3 OZS.

MAX. 7 1/2 OZS.

TO START THE RATCHET WHEEL MOVING

FIGURE 48 TYPYR, RIBBON FEED MECHANISM





FIGURE 49 TYPER, RIBBON REVERSE MECHANISM

INSTRUCTIONS FOR REMOVING STUNT BOX ASSEMBLY

NOTE - - - REMOVE ONLY FOR SERVICING

REMOVE TYPING UNIT FROM BASE (SEE P.3-2). REMOVE THE STUNT BOX MOUNTING SCREWS AND DISCONNECT STRIPPER BAIL ARM (FIG. 55).

SLIDE UPPER END OF STRIPPER DRIVING LINK TO THE RIGHT (REAR VIEW) TO DISENGAGE LINK FROM STRIPPER BLADE DRIVING ARM. LIFT STUNT BOX ASSEMBLY UPWARD AND PULL TOWARD THE REAR TO DISENGAGE SHIFT FORKS AND PILOT PINS FROM CODE BAR ASSEMBLY. REMOVE CONTACT ASSEMBLY. REINSTALL STUNT ASSEMBLY IN REVERSE ORDER. PUSH THE ASSEMBLY FORWARD IN ITS GUIDE RAILS TO WITHIN 1/8" OF ITS FINAL POSITION, THEN MANUALLY DISENGAGE FUNCTION PAWLS FROM THEIR FUNCTION LEVERS AND PUSH FUNCTION ASSEMBLY FORWARD AND DOWN TO LATCH IN PLACE.

INSTRUCTIONS FOR INSTALLING FUNCTION BARS IN STUNT BOX

NOTE - - - TYPING UNITS ARE FURNISHED WITHOUT THE FUNCTION BARS ASSOCIATED WITH THE AREA CALL, STATION CALL, OR RELAY CALL (IF REQUIRED). REFER TO P.51 FOR LOCATION AND P. 51 FOR IDENTIFICATION OF FUNCTION BARS CORRESPONDING TO ASSIGNED CALL. OBSERVE POSITION OF EACH STUNT CASE FUNCTION BAR.

CAUTION - - - DO NOT OPERATE TYPER UNTIL ALL FUNCTION BARS HAVE BEEN INSTALLED FOR WHICH CORRESPONDING FUNCTION PAWLS AND FUNCTION LEVERS HAVE BEEN SUPPLIED.

INSERT THE ASSIGNED FUNCTION BAR INTO THE SPECIFIED SLOT OF THE STUNT BOX FROM THE FRONT. GUIDE REAR PROJECTIONS OF THE BAR INTO ENGAGEMENT WITH ITS SHAFT AND THE FUNCTION PAWL. INSTALL THE FUNCTION BAR SPRING. REMOVE THE FUNCTION BAR IN THE REVERSE ORDER.

FIGURE 50 TYPER, STUNT BOX MECHANISM

## FUNCTION BAR POSITION FOR SEQUENTIAL SELECTION

SLOT NO.	TYPING UNIT RESPONDS TO	ARRANGEMENT		
		AJ.	AK.	AL.
9	153409 - 153438	153409 - 153438	153409 - 153438	153409 - 153438
10	STATION SELECT CODE	152676 - 152703	152676 - 152703	152676 - 152703
11	STATION SELECT CODE	152676 - 152703	152676 - 152703	152676 - 152703
15	#1 RELAY SELECT CODE	NONE	153409 - 153438	153409 - 153438
16	#1 RELAY SELECT CODE	"	152676 - 152703	152676 - 152703
17	#1 RELAY SELECT CODE	"	152676 - 152703	152676 - 152703
18	#2 RELAY SELECT CODE	NONE	NONE	153409 - 153703
19	#2 RELAY SELECT CODE	"	"	152676 - 152703
20	#2 RELAY SELECT CODE	"	"	152676 - 152703
21	#1 RELAY SELECT CODE	NONE	153409 - 153438	153409 - 153438
22	#1 RELAY SELECT CODE	"	152676 - 152703	152676 - 152703
23	#1 RELAY SELECT CODE	"	152676 - 152703	152676 - 152703
24	#2 RELAY SELECT CODE	NONE	NONE	153409 - 153438
25	#2 RELAY SELECT CODE	"	"	152676 - 152703
26	#2 RELAY SELECT CODE	"	"	152676 - 152703
27	AREA SELECT CODE	NONE	153432	153432
28	AREA SELECT CODE	"	152676 - 152703	152676 - 152703
29	AREA SELECT CODE	"	152676 - 152703	152676 - 152703
30	AREA SELECT CODE	153432	153432	153432
31	AREA SELECT CODE	152676 - 152703	152676 - 152703	152676 - 152703
32	AREA SELECT CODE	152676 - 152703	152676 - 152703	152676 - 152703

WARNING - - - DO NOT OPERATE TYPING UNIT WITHOUT INSTALLING ALL THE FUNCTION BARS

## STUNT CASE FUNCTION BARS

(INITIAL FUNCTION BAR FOR AREA, STATION OR RELAY CALL CODE)

CHARACTER	PART NO.	CHARACTER	PART NO.	CHARACTER	PART NO.
A	SC 153409	J	SC 153418	S	SC 153427
B	SC 153410	K	SC 153419	T	SC 153428
C	SC 153411	L	SC 153420	U	SC 153429
D	SC 153412	M	SC 153421	V	SC 153430
E	SC 153413	N	SC 153422	W	SC 153431
F	SC 153414	O	SC 153423	X	SC 153432
G	SC 153415	P	SC 153424	Y	SC 153433
H	SC 153416	Q	SC 153425	Z	SC 153434
I	SC 153417	R	SC 153426		

## COMMON FUNCTION BARS

(SUCCESSIVE FUNCTION BARS FOR AREA, STATION OR RELAY CALL CODE)

CHARACTER	PART NO.	CHARACTER	PART NO.	CHARACTER	PART NO.
A	152676	J	152685	S	152696
B	152677	K	152686	T	152697
C	152678	L	152687	U	152698
D	152679	M	152688	V	152699
E	152680	N	152689	W	152700
F	152681	O	152690	X	152701
G	152682	P	152691	Y	152702
H	152683	Q	152692	Z	152703
I	152684	R	152695		

FIGURE 51 TYPER, STUNT BOX MECHANISM






FIGURE 52 TYPWR, STUNT BOX MECHANISM



CONDITION CODE SHIFT FORK SPRING  
REQUIREMENT

WITH CONDITION CODE SHIFT FORK IN ITS UNOPERATED POSITION.  
MIN. 1 OZ.  
MAX. 3 OZS.  
TO PULL SPRING TO ITS INSTALLED POSITION



AUTOMATIC CARRIAGE RETURN - LINE FEED BLOCKING SLIDE SPRING  
REQUIREMENT

WITH CONDITION CODE SHIFT FORK IN ITS UNOPERATED POSITION.  
MIN. 1 OZ.  
MAX. 3 OZS.  
TO PULL SPRING TO ITS INSTALLED LENGTH.

FIGURE 53 TYPER, STUNT BOX MECHANISM

FIGURES AND LETTERS CODE BAR SHIFT MECHANISM

NOTE --- ROTATE FUNCTION CLUTCH UNTIL FUNCTION BARS ARE IN THEIR EXTREME REAR POSITION.

(1) REQUIREMENT

HOOK LETTERS FUNCTION PAWL OVER END OF FUNCTION BAR (FIGS. PAWL DISENGAGED).  
CLEARANCE BETWEEN LOWER GUIDE PLATE EXTENSION AND LETTERS SHIFT SLIDE.

MIN. 0.005 INCH                      MAX. 0.015 INCH

(2) REQUIREMENT

HOOK FIGURES FUNCTION PAWL OVER END OF FUNCTION BAR (LTRS. PAWL DISENGAGED).  
CLEARANCE BETWEEN LOWER GUIDE PLATE EXTENSION AND FIGURES SHIFT SLIDE

MIN. 0.005 INCH                      MAX. 0.015 INCH

TO ADJUST

POSITION UPPER AND/OR LOWER GUIDE PLATE BY ITS ADJUSTING SLOT WITH THE CLAMP NUTS  
LOOSENED.




FIGURE 54 TYPWR, SHIFT MECHANISM



STRIPPER BLADE CAM POSITION

## REQUIREMENT

STRIPPER BLADE CAM SHOULD MOVE EACH STRIPPER BLADE ARM AN EQUAL DISTANCE ABOVE AND BELOW CENTER LINE OF ITS PIVOT. (GAUGE BY EYE).

- A. UPWARD DIRECTION
- B. DOWNWARD DIRECTION

## TO CHECK

WITH FUNCTION CLUTCH IN ITS STOP POSITION, OBSERVE ENGAGEMENT OF STRIPPER BLADE CAM (UPPER PEAK) WITH STRIPPER BLADE ARM. THEN ROTATE CLUTCH TO TURN CAM TO ITS EXTREME DOWNWARD POSITION AND OBSERVE ENGAGEMENT OF LOWER CAM PEAK.

## TO ADJUST

WITH STRIPPER BLADE DRIVING LINK MOUNTING SCREWS LOOSENED, EQUALIZE THE OVER TRAVEL OF EACH CAM PEAK BY USING SCREW DRIVER ADJUSTMENT ON LINK.




FIGURE 55 TYPWR, FUNCTION PAWL STRIPPER,




FIGURE 56 TYPWR, FUNCTION CONTACTS




FIGURE 57 TYPWR, LINE FEED MECHANISM

INSTRUCTIONS FOR REMOVING THE MAIN SHAFT ASSEMBLY

NOTE - - - REMOVE ONLY FOR SERVICING

REMOVE PRINTER FROM BASE (SEE P.3-2). REMOVE SELECTOR CAM ASSEMBLY (SEE 2-14) ,REMOVE CLAMP COLLAR (WITH OILER) FROM RIGHT END OF SHAFT. PLACE CARRIAGE IN ITS LEFT POSITION. REMOVE SCREW WHICH SECURES SPACING SHAFT (FIG. 25) IN SPACING PAWL ASSEMBLY AND REMOVE SPACING SHAFT WITH GEAR. REMOVE MAIN SHAFT RIGHT HAND BEARING RETAINER PLATE. REMOVE TYPE BOX CLUTCH CONNECTING LINK RETAINER PLATE AT THE CLUTCH STUD AND REMOVE STUD. REMOVE LEFT BEARING RETAINER MOUNTING SCREWS. SLIDE UPPER END OF STRIPPER DRIVING LINK TO THE RIGHT (REAR VIEW) TO DISENGAGE LINK FROM STRIPPER BLADE DRIVING ARM. UNHOOK SPRINGS FROM STOP LEVERS AND LATCH LEVERS ON ALL CLUTCHES AND THE CLUTCH TRIP SHAFT CAM FOLLOWER SPRINGS POSITION CODE BAR CLUTCH SO THAT LOW PART OF TRIP CAM CLEARS CAM FOLLOWER. MOVE MAIN SHAFT ASSEMBLY TOWARD THE LEFT TO DISENGAGE THE CODE BAR CLUTCH AND FUNCTION CLUTCH LINKS FROM THEIR CONNECTING PINS. LIFT LEFT END OF SHAFT OUT OF THE SIDE FRAME AND POSITION THE SHAFT SO THAT THE FUNCTION

INSTRUCTIONS FOR REMOVING THE PLATEN

NOTE - - - REMOVE ONLY FOR SERVICING

REMOVE PLATEN, GEAR, PLATEN BEARING RETAINERS AND PAPER FINGER SHAFT. HOLD OFF DETENT AND LIFT PLATEN OUT OF SIDE FRAME. REPLACE IN THE REVERSE ORDER. WHEN REPLACING THE PLATEN BEARING RETAINERS, PUT THE RETAINER UPPER SCREW IN FIRST. LEAVE SCREW SLIGHTLY LOOSE. PRESS LOWER END OF RETAINER DOWN AND HOOK IT INTO ELONGATED HOLE IN SIDE FRAME. REPLACE LOWER SCREW. TIGHTEN BOTH SCREW.




FIGURE 58 TYPWR, SPACING SUPPRESSION MECHANISM





FIGURE 59 TYPER, SINGLE - DOUBLE LINE FEED MECHANISM



**HORIZONTAL STOP SLIDE SPRING TENSION REQUIREMENT**

(See Note 3 Page 2-1)

CODE BARS IN MARKING POSITION (LEFT).  
 TYPE BOX CLUTCH ROTATED  $\frac{1}{4}$  TURN FROM ITS STOP POSITION.  
 HORIZONTAL MOTION DECELERATING SLIDES (FIG. 33) HELD AWAY  
 FROM HORIZONTAL STOP SLIDES.  
 MIN.  $\frac{1}{2}$  OZ. MAX.  $1\frac{1}{2}$  OZS. FOR UPPER AND LOWER SLIDES  
 MIN.  $1\frac{1}{4}$  OZS.: MAX. 3 OZS. FOR MIDDLE SLIDE  
 TO START SLIDE MOVING.  
 NOTE: WHEN CHECKING UPPER AND LOWER SLIDES, HOLD MIDDLE  
 SLIDE  $\frac{1}{32}$  INCH FORWARD.




FIGURE 60 TYPER, HORIZONTAL MOTION STOP AND AUTOMATIC CARRIAGE RETURN MECHANISM





FIGURE 61 TYPWR, PAPER MECHANISM



PAPER FINGER ADJUSTMENT REQUIREMENT

THE PRESSURE END OF THE PAPER FINGERS SHOULD OVERLAP THE PAPER FROM 3/8 INCH TO 1/2 INCH.

TO ADJUST POSITION THE PAPER FINGERS BY SLIDING THEM ON THEIR SHAFT.

PAPER FINGER SPRING TENSION REQUIREMENT

PULL UPWARD ON RIGHT PAPER FINGER TO START LEFT PAPER FINGER MOVING FROM PLATEN.

MIN. 3 OZS.  
MAX. 5 OZS.

PRESSURE ROLLER LEVER SPRING REQUIREMENT

MIN. 26 OZS.  
MAX. 32 OZS.  
TO START EACH CENTER LEVER MOVING

PAPER PRESSURE BAIL SPRING TENSION REQUIREMENT

SCALE HOOKED OVER PRESSURE BAIL AT EACH END OF PLATEN.  
MIN. 10 OZS.  
MAX. 20 OZS.  
TO MOVE PRESSURE BAIL FROM PLATEN.

FIGURE 62 TYPWR, PAPER MECHANISM



**CODE BAR DETENT REQUIREMENT**

FRONT PLATE REMOVED. ALL CLUTCHES DISENGAGED. SHIFT CODE BAR SHOULD DETENT EQUALLY (Gauge By Eye).

**TO ADJUST**

EQUALIZE THE DETENTING OF THE CODE BARS BY ADDING OR REMOVING SHIMS BETWEEN THE CASTING AND THE CODE BAR BRACKET.

**CODE BAR DETENT SPRING TENSION**

**NOTE**

UNLESS THERE IS REASON TO BELIEVE THAT THESE SPRINGS ARE CAUSING OPERATING FAILURE DO NOT CHECK THIS REQUIREMENT.


**REQUIREMENT (EXCEPT SUPPRESSOR)**

CODE BAR DETENT BRACKET CAREFULLY REMOVED AND CODE BARS REMOVED FROM DETENT BRACKET. SCALE APPLIED TO DETENT BALL AND PULLED IN DIRECTION OF BALL TRAVEL.

MIN. 1 1/2 OZS.

MAX. 3 1/2 OZS.

TO START BALL MOVING AGAINST COMPRESSION OF SPRING. CHECK EACH BAIL



**CODE BAR YIELD SPRING REQUIREMENT**


SELECTOR CLUTCH, CODE BAR CLUTCH, AND TYPE BOX CLUTCH DISENGAGED. NO. 1. CODE BAR IN SPACING POSITION

MIN. 17 OZS.

MAX. 23 OZS.

TO START CODE BAR SHIFT BAR PIVOT MOVING AWAY FROM CODE BAR. CHECK NO. 2 AND COMMON CODE BAR SHIFT BAR IN THE SAME MANNER.

FIGURE 63 TYPWR, CODE BAR DETENT MECHANISM



MARGIN INDICATOR LAMP  
REQUIREMENT

OPERATING UNDER POWER, THE LAMP  
SHOULD ILLUMINATE ON THE DESIRED  
CHARACTER


TO ADJUST

SET THE TYPE BOX CARRIAGE TO PRINT THE  
DESIRED CHARACTER AND POSITION THE CAM DISK  
COUNTERCLOCKWISE ON THE SPRING DRUM WITH ITS THREE  
MOUNTING SCREWS LOOSENED.

NOTE

THE RANGE OF ADJUSTMENT IS FROM THE 5TH TO  
85TH CHARACTER.

FIGURE 64 TYPER, MARGIN INDICATING MECHANISM



#### MOUNTING TYPING UNIT ON KEYBOARD OR BASE

##### REQUIREMENT

WHEN PLACING THE TYPING UNIT ON THE BASE HOLD IT TILTED SLIGHTLY TO THE RIGHT AND LOWER THE RIGHT END INTO ENGAGEMENT WITH THE RIGHT LOCATING STUD. WHILE EASING THE LEFT END DOWNWARD ROTATE THE MOTOR BY HAND TO PROPERLY MESH THE GEARS. SECURE BY FOUR MOUNTING SCREWS


FIGURE 65 MOUNTING TYPING UNIT

ARMATURE SPRING TENSION  
REQUIREMENT

MIN. 1/2 OZ.  
MAX. 1 OZ.  
TO PUSH THE ARMATURE AGAINST THE  
CORE (VERTICALLY).

REMOTE SIGNAL BELL  
REQUIREMENT

ARMATURE HELD AGAINST THE MAGNET  
CORE.  
CLEARANCE BETWEEN THE ARMATURE BALL  
AND THE BELL  
MIN. 0.020 INCH  
MAX. 0.035 INCH  
TO ADJUST  
BEND THE ARMATURE EXTENSION JUST  
BELOW THE ARMATURE SPRING.



CRADLE  
REQUIREMENT

TOP OF HINGE BRACKET PARALLEL TO TOP OF HINGE BAR.  
TO ADJUST  
TURN STOP SCREW WITH LOCK NUT LOOSENED.






FIGURE 66 REMOTE SIGNAL BELL AND CRADLE

NOTE

THE FOLLOWING ADJUSTMENTS ARE MADE AT THE FACTORY AND SHOULD NOT BE DISTURBED UNLESS THERE IS REASON TO BELIEVE THAT THE PARTS ARE OUT OF ADJUSTMENT OR HAVE BEEN DISASSEMBLED.



DOMe

(1) REQUIREMENT

DOMe SHOULD BE CENTERED (RIGHT TO LEFT) ON CABINET AND PLACED MIN. 1/4 INCH MAX. 5/16 INCH FROM FRONT EDGE OF CABINET.

TO ADJUST

POSITION DOMe WITH THE (6) NUTS, WHICH FASTEN THE DOMe TO ITS HINGES, LOOSENED. THEN TIGHTEN NUTS.

(2) REQUIREMENT

THERE SHOULD BE A LIGHT-PROOF SEAL AT THE REAR OF THE DOMe BETWEEN THE RUBBER GASKET AND TOP EDGE OF THE CABINET.

TO ADJUST

POSITION THE DOMe IN THE DOWNWARD DIRECTION WITH THE (6) NUTS WHICH FASTEN THE DOMe TO ITS HINGES, LOOSENED. TIGHTEN NUTS.

DOMe CATCH

(1) REQUIREMENT

DOMe SHOULD LATCH SECURELY WITH A LIGHT-PROOF SEAL AT THE FRONT OF THE DOMe BETWEEN RUBBER GASKET AND TOP EDGE OF THE CABINET.

(2) REQUIREMENT

DOMe CATCH SHOULD UNLATCH WHEN THE CATCH BUTTON IS DEPRESSED NO DEEPER THAN THE OUTER SURFACE OF THE DOMe.

TO ADJUST

BEND THE TWO DOMe LATCH CATCHES.

(CABINET ADJUSTMENT CONTINUED)

SMALL DOOR CATCH

## (1) REQUIREMENT

WITH SMALL DOOR LATCHED, THE RUBBER GASKET SHOULD PRESS AGAINST THE LEDGE OF THE DOME AT ALL POINTS. THE DOOR SHOULD BE FLUSH WITHIN 1/16 INCH WITH TOP SURFACE OF DOME.

## (2) REQUIREMENT

WHEN DOOR IS RELEASED FROM ITS CATCH IT SHOULD SPRING OPEN AT LEAST 1/2 INCH.

## TO ADJUST

BEND THE SMALL DOOR CATCH. RECHECK REAR OF DOOR TO MAKE CERTAIN IT IS FLUSH WITH OR SLIGHTLY ABOVE THE DOME.


SMALL DOOR

## REQUIREMENT

SMALL DOOR SHOULD BE CENTERED (LEFT TO RIGHT) AND SHOULD BE POSITIONED SO AS TO PROVIDE A LIGHT-TIGHT SEAL BETWEEN RUBBER GASKET AND LEDGE OF THE DOME AT ALL POINTS.

## TO ADJUST

LOOSEN THE (4) NUTS WHICH SECURE THE DOME TO THE DOME BRACKET. PUSH THE HINGES AGAINST THE DOME BRACKET AND TIGHTEN THE (4) NUTS. LOOSEN THE (3) NUTS WHICH SECURE THE HINGE EXTENSION TO THE DOOR. SLIDE THE DOOR TO ITS EXTREME FORWARD POSITION AND POSITION CENTRALLY (SIDE TO SIDE). TIGHTEN THE (3) NUTS WHICH SECURE THE HINGE EXTENSION TO THE HINGES. POSITION THE DOOR SO THAT IT IS FLUSH WITH OR SLIGHTLY ABOVE THE DOME AND TIGHTEN THE (4) NUTS. LOOSEN THE (3) NUTS WHICH SECURE THE HINGE EXTENSION TO THE DOOR. CLOSE THE DOOR AND SLIDE IT TOWARD THE REAR TO PROVIDE A LIGHT-TIGHT SEAL AT THE FRONT CORNERS OF THE DOOR. TIGHTEN THE (4) NUTS.

SMALL DOOR STOP ARM


## REQUIREMENT

STOP ARM SHOULD BE FREE OF BINDS WHEN DOOR IS OPENED OR CLOSED.

## TO ADJUST

LOOSEN THE STOP ARM BRACKET MOUNTING SCREWS. CLOSE THE DOOR. DISCONNECT THE TORSION SPRING. ALIGN STOP ARM FOR FREENESS AND TIGHTEN MOUNTING SCREWS WITH DOOR CLOSED. REPLACE TORSION SPRING.

g. COVER




COPYHOLDER

REQUIREMENT

THERE SHOULD BE SUFFICIENT TENSION ON THE LINE GUIDE TO PREVENT IT FROM SLIPPING DOWN ITS SHAFT. IT SHOULD ALSO HOLD THE COPY IN PLACE.

TO ADJUST

REMOVE THE NUTS FROM SHAFT MOUNTING POST, AND TURN THE SHAFT. REPLACE THE SHAFT MOUNTING POST.



WINDOW AND PAPER GUIDE

(1) REQUIREMENT

THE BOTTOM EDGE OF THE PAPER GUIDE SHOULD BE FLUSH WITH THE BOTTOM EDGE OF THE WINDOW.

TO ADJUST


POSITION THE PAPER GUIDE WITH ITS MOUNTING SCREWS LOOSENED.

(2) REQUIREMENT

THE EDGE OF WINDOW SHOULD BARELY CLEAR THE PAPER GUIDE WHEN THE WINDOW IS OPENED OR CLOSED.

TO ADJUST

POSITION WINDOW WITH ITS RETAINER SCREWS LOOSENED.




INDICATOR LAMP

REQUIREMENT

CLEARANCE BETWEEN INDICATOR LAMP AND TRANSLUCENT BUTTON APPROXIMATELY 1/16 INCH.

TO ADJUST

POSITION LAMP HOLDER ON ITS BRACKET WITH ITS MOUNTING NUT LOOSENED.



COPY LAMP

REQUIREMENT

CLEARANCE BETWEEN COPY LAMP AND COVER APPROXIMATELY 1/16 INCH.

TO ADJUST

POSITION LAMP HOLDER ON ITS BRACKET WITH ITS MOUNTING NUT LOOSENED.

## 3. SELECTOR RECEIVING MARGIN ADJUSTMENT ( FINAL)

When a signal distortion test set is used for determining the receiving margins of the selector, and where the condition of the components is equivalent to that of new equipment, the range and distortion tolerance tabulated in Table 1 should be met.

TABLE 1 SELECTOR RECEIVING MARGIN MINIMUM REQUIREMENTS

Current	Speed in W.P.M.	Points Range with Zero Distortion	Percentage of Marking and Spacing Bias Tolerated	End Distortion With Scale At Bias Optimum Setting
0.060 Amp. (Windings Parallel)	60	72	40	35
	75	72	40	35
	100	72	40	35
0.020 Amp. (Windings Series)	60	72	40	35 <sub>r</sub>
	75	72	40	35
	100	72	35	35



### SECTION III LUBRICATION

#### 1. GENERAL

1.01 The printer set should be lubricated as directed in this section. Their figures indicate points to be lubricated and the kind and quantity of lubricant to be used. Lubricate the printer just prior to placing it in service. After a few weeks in service, relubricate to make certain that all points receive lubrication. The following lubrication schedule should be followed thereafter.

Operating Speed (Words per minute)	Lubricating Interval (Typing Unit)
60 . . . . .	3000 hrs. or 1 yr.)
75 . . . . .	2400 hrs. or 9 mo.)
100 . . . . .	1500 hrs. or 6 mo.)

whichever occurs  
first

1.02 Use Teletype KS-7470 oil at all locations where the use of oil is indicated. Use KS-7471 grease on all surfaces where grease is indicated except the motor bearings. Apply two drops of KS-7470 oil to motor bearings every four months (depress oiler with metal object). If the motor is disassembled at any time, repack the bearings with KS-7471 grease.

1.03 All spring wicks and felt oilers should be saturated. The friction surfaces of all moving parts should be thoroughly lubricated. However, over lubrication which will permit oil or grease to drip or to be thrown on other parts should be avoided. Take special care to prevent any oil or grease from getting between the selector armature and its magnet pole faces or between electrical contacts.

1.04 Apply a thin film of grease to all gears and the spacing clutch reset cam plate.

1.05 Apply oil to all cams, including the camming surfaces of each clutch disk.


1.06 The photographs show the paragraph numbers referring to particular line drawings of mechanisms and where these mechanisms are located on the unit. Parts in the line drawings are shown in an upright position unless otherwise specified.

1.07 The illustration symbols indicate the following lubrication directions:

- 0 Apply 1 drop of oil.
- 02 Apply 2 drops of oil.
- 03 Apply 3 drops of oil.
- 020 Apply 20 drops of oil, etc.
- G Apply thin film of grease.
- GF Fill in (spaces between cams) with grease.
- SAT Saturate (Felt oilers, washers, wicks) with oil.

## 2. DISASSEMBLY

## 2.01 CABINET DISASSEMBLY




PERFORM OPERATIONS IN NUMERICAL SEQUENCE

① DISCONNECT THE PLUG ON THE CABLE FROM THE RECEPTACLE ON THE RIGHT SIDE OF THE TYPING UNIT.

② DISCONNECT THE PLUG ON THE CABLE FROM THE RECEPTACLE ON THE LEFT SIDE OF THE BASE.

③ REMOVE THE CROSS BAR FROM THE FRONT OF THE CABINET BY LOOSENING THE TWO KNURLED THUMB SCREWS.


## 2.02 BASE DISASSEMBLY



④ REMOVE THE FOUR SCREWS HOLDING THE BASE TO THE CRADLE ASSEMBLY AND REMOVE THE BASE WITH AUTOMATIC TYPER.


⑤ REMOVE THE FOUR SCREWS HOLDING THE AUTOMATIC TYPER TO THE BASE AND REMOVE TYPING UNIT.

## 3. CABINET




4. BASE

4.01 REST BASE BOTTOM SIDE UP




(BOTTOM VIEW)

4.02 LOCAL CARRIAGE-RETURN MECHANISM




4.03 LOCAL LINE-FEED MECHANISM




4.04 BASE GEARS AND MARGIN INDICATOR


REST BASE IN UPRIGHT POSITION



4.05 MARGIN-INDICATING MECHANISM




4.06 BASE GEARS




5. TYPING UNIT  
 5.01 TYPE BOX CARRIAGE AND PRINTING MECHANISM


REST TYPING UNIT IN UPRIGHT POSITION




5.02 PRINTING MECHANISM



5.03 PRINTING MECHANISM (Continued)




5.04 TYPE BOX CARRIAGE MECHANISM




5.05 CODE BAR AND PAPER FEED MECHANISM

REST TYPING UNIT IN UPRIGHT POSITION



(FRONT VIEW)


5.06 CODE BAR MECHANISM (Continued)





5.07 CODE BAR MECHANISM (Continued)


REST TYPING UNIT IN UPRIGHT POSITION




5.08

(LEFT SIDE VIEW)


5.08 TYPE BOX CLUTCH SUPPRESSION MECHANISM



5.09 PAPER FEED MECHANISM




5.10 REST TYPING UNIT IN UPRIGHT POSITION




(LEFT SIDE VIEW)


5.11 REST TYPING UNIT IN UPRIGHT POSITION




5.12 RIBBON FEED MECHANISM (RIGHT SIDE)




5.13 RIBBON FEED MECHANISM (Continued)





5.14 RIBBON FEED MECHANISM (Continued)




5.15 VERTICAL POSITIONING MECHANISM ( RIGHT SIDE)




5.16 RIBBON FEED MECHANISM (LEFT SIDE)




5.17 RIBBON FEED MECHANISM (Continued)




5.18 VERTICAL POSITIONING MECHANISM (LEFT SIDE)




5.19 REST TYPING UNIT IN UPRIGHT POSITION




5.20 CODE BAR MECHANISM




5.21 SELECTOR MECHANISM



5.22 SELECTOR MECHANISM (Continued)




5.23 REST TYPING UNIT IN UPRIGHT POSITION



( REAR VIEW )




5.24 REMOVE STUNT BOX  
(REFER TO ADJUSTMENT SECTION  
FOR REMOVAL INSTRUCTIONS)




(REAR VIEW)


5.25 STUNT BOX MECHANISM




5.26 STUNT BOX MECHANISM (Continued)




5.27 SINGLE-DOUBLE LINE FEED MECHANISM




5.28 RIBBON-REVERSE MECHANISM




5.29 FUNCTION BAR RESET MECHANISM




5.30 REST TYPING UNIT ON ITS BACK




5.31 SPACING DRUM DRIVE MECHANISM




5.32 CARRIAGE RETURN MECHANISM



5.33 CARRIAGE RETURN MECHANISM (Continued)




5.34 PRINTING TRACK GUIDE





5.35 POSITIONING MECHANISM

REST TYPING UNIT ON ITS BACK




(FRONT VIEW)


5.36 HORIZONTAL POSITIONING MECHANISM




5.37 HORIZONTAL POSITIONING MECHANISM ( Continued )




5.38 HORIZONTAL POSITIONING MECHANISM ( Continued )



5.39 HORIZONTAL POSITIONING MECHANISM ( Continued )




5.40 REST TYPING UNIT IN UPRIGHT POSITION





(FRONT VIEW)

5.41 LETTERS-FIGURES SHIFT MECHANISM







5.42 LETTERS-FIGURES SHIFT MECHANISM (Continued)




5.43 OSCILLATING MECHANISM



5.44 OSCILLATING MECHANISM (Continued)




5.45 REST TYPING UNIT IN BOTTOM UPWARD POSITION




(BOTTOM VIEW)


5.46 MAIN SHAFT (CLUTCHES, GEARS, ETC.)




5.47 MAIN SHAFT (CLUTCHES, GEARS, ETC.) (Continued)




5.48 MAIN SHAFT (CLUTCHES, GEARS, ETC.) (Continued)



5.49 MAIN SHAFT (CLUTCHES, GEARS, ETC.) (Continued)




5.50 REST TYPING UNIT IN BOTTOM UPWARD POSITION




(BOTTOM VIEW)


5.51 SPACING MECHANISM




5.52 SPACING MECHANISM (Continued)



5.53 SPACING MECHANISM (Continued)



5.54 REST TYPING UNIT IN BOTTOM UPWARD POSITION



(REAR VIEW)

5.55 LINE-FEED MECHANISM

