

**BULLETIN 312B
NAVSHIPS 0967-173-6020
VOLUME 2
(of 3 Volumes)**

**TECHNICAL MANUAL
28 AUTOMATIC SEND-RECEIVE (ASR)
TELETYPEWRITER SETS**



**TELETYPE[®]
CORPORATION**
5555 TOUHY AVENUE, SKOKIE, ILLINOIS



INTRODUCTION

This manual contains three (3) volumes of literature for the 28 Automatic Send-Receive Teletypewriter Sets as follows:

Volume 1, NAVSHIPS 0967-173-6010, provides cross reference material, description and principles of operation, installation, operating test, disassembly and reassembly of the set, and component wiring diagrams.

Volume 2, NAVSHIPS 0967-173-6020, provides adjusting information, lubrication, and disassembly and reassembly of components.

Volume 3, NAVSHIPS 0967-173-6030, provides parts ordering information.

Each volume is made up of a group of appropriate independent sections. The sections are complete within themselves; they are separately identified by title and section number and the pages of each section are numbered consecutively, independent of other sections.

The identifying number of a section, a 9-digit number, appears at the top of each page of the section, in the left corner of left-hand pages and the right corner of right-hand pages.

To locate specific information, refer to the table of contents. The name of the involved component, the title of the section, and the 9-digit section number may then be found. The sections are arranged in the order shown in the table of contents. Turn to page one of the section indicated where the contents of the section will be found (except where a section is small and does not require a listing of contents).



VOLUME 2

TABLE OF CONTENTS

<u>Title</u>	<u>Contents</u>	<u>Section</u>	<u>Issue</u>
28 Cabinet for ASR Teletypewriter Sets	Adjustments	573-134-703TC	1
28 Electrical Service Unit	"	573-133-700TC	2
28 Perforator-Transmitter Base	"	573-117-700TC	4
28 Typing Unit	"	573-115-700TC	7
28 Typing and Nontyping Perforator	"	573-139-700TC	1, Add 1
28 Typing Reperforator and Tape Printer	"	573-118-700TC	7
28 Reperforator and Tape Printer Bases	"	573-121-700TC	6
28 Transmitter Distributor Unit (LXD)	"	573-127-703TC	1
Motor Units	"	570-220-700TC	4
28 Cabinet for ASR Teletypewriter Sets	Lubrication	573-134-704TC	1
28 Electrical Service Units	"	573-133-701TC	2
28 Perforator-Transmitter Base	"	573-117-701TC	3
28 Typing Unit	"	573-115-701TC	3
28 Typing and Nontyping Tape Perforator	"	573-139-701TC	1
28 Typing Reperforator and Tape Printer	"	573-118-701TC	4
28 Transmitter Distributor Unit (LXD)	"	573-127-704TC	1
Motor Units	"	570-220-701TC	4
28 Cabinet for ASR Teletypewriter Sets	Disassembly & Reassembly	573-134-705TC	1
28 Electrical Service Unit	" " "	573-133-702TC	2
28 Perforator-Transmitter Base	" " "	573-117-702TC	2
28 Typing Unit	" " "	573-115-702TC	3
28 Typing and Nontyping Perforator	" " "	573-139-702TC	1
28 Typing Reperforator and Tape Printer	" " "	573-118-702TC	2
28 Transmitter Distributor Unit (LXD)	" " "	573-127-705TC	1



28 CABINET FOR AUTOMATIC SEND-RECEIVE

TELETYPEWRITER SETS

ADJUSTMENTS

CONTENTS	PAGE
1. GENERAL	1-2
2. BASIC UNIT	3
Cabinet	
Armature spring tension	11
Chad chute and chad bin assemblies	11
Cradle	9
Dome	3
Dome latch	4
Lamp position	8
Left front cross bar	10
Left front door	7
Message tray position	12
Paper guide	8
Remote signal bell	11
Right front door	6
Top doors (right and left)	6
Top middle door	6
Torsion bar	5
Window	8

1. GENERAL

1.01 This section has been revised to include recent engineering changes and additions, and to rearrange the text so as to bring the section generally up-to-date. Since this is an ex-

tensive revision, marginal arrows ordinarily used to indicate changes have been omitted.

1.02 This section contains the specific requirements and adjustments for the 28 cabinet for automatic send-receive teletypewriter sets.

1.03 Maintenance procedures apply only to mechanisms of a particular design, or to certain models of 28 cabinets for automatic send-receive teletypewriter sets.

1.04 The adjustments of each unit are arranged in a sequence that should be followed if a complete readjustment of the unit were undertaken. The tools and spring scales required to perform these adjustments are listed in the applicable section. After an adjustment is completed, be sure to tighten any nuts or screws that are loosened. The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions and the angles at which scales should be applied when measuring spring tensions. If a part mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same number is replaced when the part is remounted.

1.05 References made to left or right, up or down, front or rear, etc apply to the unit in its normal operating position as viewed from the front.





Figure 1 - Model 25 Teletype Machine Transmitter-Receiver Set

2. BASIC UNIT

2.01 Cabinet




DOME
REQUIREMENT

THE DOME SHOULD BE CENTERED ON THE CABINET FROM RIGHT TO LEFT AND PLACED APPROXIMATELY 0.050 INCH FROM THE FRONT EDGE OF CABINET OR SO THE EXTRUDED PORTIONS OF THE LEFT FRONT DOOR AND RIGHT FRONT CROSS BAR LINE UP.

TO ADJUST

- (1) DISCONNECT THE UPSTOP LATCH ARM ON RIGHT SIDE OF DOME. THEN PIVOTING DOME REARWARDLY OVER THE BACK, PRY END OF TORSION BARS OUT OF HOLE AND SLIP OUT FROM REAR BRACKET IN DOME.
- (2) POSITION THE DOME WITH THE SCREWS THAT SECURE THE DOME HINGE TO THE CABINET LOOSENED. THE DOME WHEN CLOSED SHOULD BE RESTING ALONG THE TOP FRONT EDGE ON THE CABINET BODY, THE RIGHT FRONT CROSS BAR AND LEFT FRONT CROSS BAR, WITH SOME DAYLIGHT SHOWING REARWARDLY ALONG THE TOP FLANGE OF THE SIDES TOWARD THE REAR HINGE.

2.02 Cabinet (continued)



NOTE: IF NECESSARY TO CHECK REQUIREMENT, REMOVE BLANK CONTROL PANEL.

DOMELATCH
(1) REQUIREMENT

WITH THE DOME LATCHED THERE SHOULD BE A SLIGHT PRESSURE ON THE RUBBER BUMPER. TO ADJUST LOOSEN PIVOT SCREWS ON BOTH RIGHT AND LEFT LATCHES. POSITION LATCHES TO PROVIDE SOME TO 0.032 INCH BETWEEN EACH LATCH AND ITS LATCHING SURFACE AND LOCK THE SCREWS. POSITION RUBBER BUMPER TO PROVIDE 0.030 TO 0.045 INCH BETWEEN DOME AND CABINET AND SECURE THE BUMPERS. A SLIGHT PRESSURE SHOULD LATCH THE DOME.


(2) REQUIREMENT

IT SHOULD NOT BE POSSIBLE TO DEPRESS THE DOME LATCH BUTTON COMPLETELY INTO THE DOME.

TO ADJUST

POSITION THE LATCH TOWARD THE OUTSIDE SURFACE OF DOME WITH MOUNTING SCREWS LOOSENED. PIVOT DOME OPEN REARWARDLY OVER BACK OF CABINET. REPLACE ENDS OF TORSION RODS BY SLIDING THE STRAIGHT PORTION OF RODS UNDER BRACKET ON THE GUSSET IN CORNERS OF THE DOME, UNTIL BENT END OF ROD SLIPS INTO RETAINING HOLE IN FRONT OF BRACKET. PIVOT DOME FORWARD, AND REPLACE UPSTOP LATCH ARM ON RIGHT SIDE OF DOME AND SECURE IN PLACE WITH SCREW AS BEFORE.

2.03 Cabinet (continued)

**TORSION BAR**

- (1) REQUIREMENT-WHEN THE CLOSED DOME IS RELEASED FROM ITS LATCHES THE TORSION BARS SHOULD LIFT THE DOME ABOVE THE FRONT EDGE OF CABINET
MIN. 7 INCHES---MAX. 9 INCHES
- (2) REQUIREMENT-WHEN DOME IS STARTED DOWN BY SLIGHT PUSH FROM ITS FULLY OPENED POSITION IT SHOULD NOT CLOSE OR LATCH. NOTE: READJUST DOME IF MORE APPARATUS IS ADDED.
- TO ADJUST
TURN THE SHOULDER NUTS ON THE EYE BOLTS CLOCKWISE TO INCREASE THE SPRING TORQUE, AND COUNTERCLOCKWISE TO DECREASE THE SPRING TORQUE.


2.04 Cabinet (continued)

TOP DOORS (RIGHT AND LEFT)

REQUIREMENT

THE DOORS SHOULD SET SQUARELY AND UNIFORMLY ON THE CONTOUR OF THE DOME.
TO ADJUST

POSITION EACH DOOR WITH ITS HINGE MOUNTING SCREWS LOOSENED.



TOP MIDDLE DOOR

REQUIREMENT

THE DOOR SHOULD REST FLAT AND SQUARELY ON THE DOME. THE REINFORCEMENT CHANNEL SHOULD FIT OVER ITS GUIDE BRACKET IN THE DOME.

TO ADJUST

REMOVE THE SPRING DETENT FROM CENTER OF DOME AND POSITION THE DOOR WITH ITS HINGE MOUNTING SCREWS AND BRACKET MOUNTING SCREWS LOOSENED.

RIGHT FRONT DOOR


REQUIREMENT

THE RIGHT AND LEFT EDGES OF THE RIGHT FRONT DOOR SHOULD BE EVEN WITH THE RIGHT TOP DOOR. WITH THE DOOR CLOSED IT SHOULD REST FLAT ON THE HORIZONTAL SURFACE OF THE DOME.

TO ADJUST

REMOVE THE THUMB SCREWS, LATCHES, AND SPRINGS FROM THE DOOR, AND POSITION THE DOOR WITH ITS MOUNTING SCREWS LOOSENED.

2.05 Cabinet (continued)



LEFT FRONT DOOR

(1) REQUIREMENT

THE DOOR SHOULD SET SQUARELY ON ITS OPENING IN THE DOME AND FLAT ON THE DOME.

TO ADJUST

REMOVE LATCH THUMB SCREW AND LATCH. REMOVE TORSION SPRING ANCHOR POST. POSITION THE DOOR WITH ITS HINGE MOUNTING SCREWS LOOSENED.

(2) REQUIREMENT

THE TORSION SPRING SHOULD RAISE THE DOOR UPWARD UNTIL STOPPED BY ITS STOP GUIDE BEFORE IT REACHES A VERTICAL POSITION.

TO ADJUST

ROTATE THE TORSION SPRING POST TO ACQUIRE SUFFICIENT LIFTING POWER. POSITION THE GUIDE STOP WITH ITS MOUNTING SCREW LOOSENED.

(3) REQUIREMENT



THE DOOR LATCH SHOULD HAVE SUFFICIENT LATCHING SURFACE ON ITS BRACKET AND SHOULD HOLD THE DOOR CLOSED REASONABLY TIGHT.

TO ADJUST

POSITION ITS ADJUSTING BRACKET HORIZONTALLY WITH ITS MOUNTING SCREWS LOOSENED. MODIFY UP OR DOWN POSITION OF BRACKET IF NECESSARY.

2.06 Cabinet (continued)

NOTE: THE REQUIREMENTS FOR PAPER GUIDE AND WINDOW GIVEN HEREIN ALSO APPLY WHERE THE CABINET IS EQUIPPED WITH A FORM GUIDE INSTEAD OF A PAPER GUIDE.



2.07 Cabinet (continued)

CRADLE

(1) REQUIREMENT

UNDER NORMAL LOAD, THE TOP OF THE CRADLE RAILING SHOULD BE 2 INCHES \pm 1/32 INCH FROM THE SHELF ON THE CABINET.

TO ADJUST


LOOSEN THE LOCK NUTS ON VIBRATION DAMPENER NO. 1, 2, AND 3 ON TOP OF THE LEFT AND RIGHT RAILS. LOOSEN THE NUT ON THE LOWER END OF STUD IN MOUNT NO. 4. ROTATE THE ADJUSTING STUDS UNTIL THE RAILS HAVE REACHED THE DESIRED HEIGHT. TIGHTEN ALL NUTS PREVIOUSLY LOOSENED.

(2) REQUIREMENT

THE FRONT RAIL SHOULD BE POSITIONED APPROXIMATELY 3-11/32 INCH \pm 1/32 INCH FROM AND PARALLEL TO THE FRONT OF THE CABINET.

TO ADJUST

POSITION THE BASE RAIL ASSEMBLY WITH ITS FOUR MOUNTING SCREWS AND TWO LOCATING ECCENTRICS LOOSENED AFTER POSITIONING THE RAIL ASSEMBLY TO DESIRED POSITION, ROTATE THE ECCENTRICS AGAINST THE REAR RAIL AND LOCK IN POSITION.



2.08 Cabinet (continued)

LEFT FRONT CROSS BAR

NOTE:

THE FRONT CROSS BAR BRACKETS ARE LOCATED AT THE FACTORY AND SHOULD NOT BE DISTURBED UNLESS IT IS NECESSARY TO REMOVE FOR REPLACEMENT. SHOULD THEY HOWEVER BE REMOVED REPLACE AS FOLLOWS:

REQUIREMENT

THE ADJUSTABLE CROSS BAR BRACKETS SHOULD BE POSITIONED 0.050 FROM THE FRONT EDGE OF THE CABINET BODY CROSS BAR

TRANSMITTER HOUSING

REQUIREMENT


THE HOUSING MOUNTING BRACKET ON THE LEFT FRONT CROSS BAR SHOULD BE POSITIONED TO PROVIDE A MINIMUM OF 0.020 INCH BETWEEN THE HOUSING AND THE TRANSMITTER UNIT.

COPYHOLDER
REQUIREMENT


THERE SHOULD BE SUFFICIENT TENSION ON THE LINE GUIDE TO PREVENT IT FROM SLIPPING DOWN ITS SHAFT. IT SHOULD ALSO HOLD THE COPY IN PLACE.

TO ADJUST

REMOVE THE MOUNTING SCREWS OR NUTS FROM THE SHAFT AND TURN THE SHAFT SO AS TO INCREASE THE SPRING TENSION. REPLACE THE SHAFT MOUNTING POST.



2.09 Cabinet (continued)



ARMATURE SPRING TENSION

REQUIREMENT

MIN. 1/2 OZ. ---- MAX. 1 OZ.

TO PUSH THE ARMATURE AGAINST THE CORE (VERTICALLY)

REMOTE SIGNAL BELL

REQUIREMENT

ARMATURE HELD AGAINST THE
MAGNET CORE. CLEARANCE
BETWEEN THE ARMATURE BALL
AND THE BELL

MIN. 0.020 INCH

MAX. 0.035 INCH


TO ADJUST

BEND THE ARMATURE EXTENSION,
BELOW THE ARMATURE SPRING

ARMATURE

BELL

ARMATURE BALL




CHAD CHUTE AND CHAD BIN ASSEMBLIES -
(AUTOMATIC SEND-RECEIVE SET)

REQUIREMENT

WHEN CHAD BIN IS INSERTED ON
SLIDE PLATES, THE CABINET DOOR SHOULD
CLOSE WITHOUT INTERFERING WITH CHAD BIN.

TO ADJUST


USING THE SLACK IN THE MOUNTING SCREW
BODY HOLES, POSITION THE CHAD CHUTE AND
THE CHAD BIN LEFT AND RIGHT SIDE PLATES.



2.10 Cabinet (continued)

MESSAGE TRAY POSITION
REQUIREMENT

THE THREE-SHELF MESSAGE TRAY SHOULD
BE POSITIONED SO AS NOT TO INTERFERE
WITH THE CABINET DOME TORSION BARS.
TO ADJUST
POSITION THE SHELVES WITH THEIR MOUNTING
SCREWS LOOSENED.



28 ELECTRICAL SERVICE UNITS
 ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1	Remote signal bell	5
2. REQUIREMENTS AND ADJUSTMENTS	2	28G and 28G-1 Electrical Service Units	
Electrical Motor-Control Mechanism		Slow release relay	2
Intermediate lever spring	3	28LB Electrical Service Unit	6
Start armature spring	3		
Start magnet core	3	1. GENERAL	
Stop armature spring	3	1.01 This section provides mechanical adjust- ing information for the 28 electrical service units and most of the various components that may be assembled onto it. It is reissued to include a signal bell assembly and to arrange the material in a standardized format.	
Line Test Key Assembly	5	<u>Note:</u> Remove power from units, before making adjustments.	
Relay Motor-Control Mechanism		1.02 Since this is a general revision, margi- nal arrows normally used to indicate changes and additions have been omitted.	
Inner contact spring gap	4		
Middle contact spring	4		
Outer contact spring	4		
Switch position	4		
Signal Bell			
Armature spring	5		

2. REQUIREMENTS AND ADJUSTMENTS


2.01 28G and 28G-1 Electrical Service Unit

SLOW RELEASE RELAY

Requirement

The relay should not de-energize while receiving a series of BLANK code combinations. The time required to stop an associated transmitter after receipt of line break signal should not exceed

Max 800 milliseconds.



To Adjust

Insert a 5-foot strip of BLANK tape into the transmitter. Turn the keyboard control knob to the K-T position. Turn the line-test key to the TEST position. Depress the SEND key. Loosen the residual screw locknut on the armature of the slow release relay and turn the screw counterclockwise until no gap exists between the armature and pole piece. Press the slow release relay test button and turn on the transmitter. With the tape running through the transmitter turn the residual screw clockwise until the slow release relay armature begins to vibrate. Then turn the residual screw counterclockwise slowly until the armature stops vibrating. Tighten the locknut. Rerun the entire 5-foot strip of tape through the transmitter, while the slow release relay test key is held depressed; the slow release relay armature must not drop out.

Insert a 5-foot strip of LETTERS tape into the transmitter. Plainly mark a row of perforations approximately three inches back from the sensing pins on the transmitter. Hold the slow release relay test button depressed, and start the transmitter. When the previously marked row of perforations reach the sensing pins, depress the line-break key and hold depressed until the transmitter stops. Mark the row of perforations immediately over the sensing pins, remove the tape from the transmitter and count the number of perforations between the two marked lines. The number of perforations between these lines should be no greater than,

- (1) Eight for 100 wpm operation.
- (2) Six for 75 wpm operation.
- (3) Five for 60 wpm operation.

Should the number of perforations be greater than that specified above, turn the residual screw clockwise approximately 1/8 turn and repeat the above test. The number of perforations may be fewer than that specified above provided the requirement is met.

2.02 Electrical Motor-Control Mechanism (if Equipped)

(A) STOP ARMATURE SPRING

Requirement

Stop armature latched on start armature. Stop armature spring unhooked.

Min 4-1/2 oz---Max 6 oz
to pull spring to installed length.

(B) INTERMEDIATE LEVER SPRING

Requirement

With the stop and start armatures held against their cores, apply a gram scale to the under side of the intermediate lever just to the right of its downward extension and push upward.

Min 10 grams
Max 20 grams
to start the lever moving upward.

(D) START MAGNET CORE

Requirement


Stop armature in unattracted position. Clearance between the start magnet core and anti-freeze rivet on the start armature

Armature TP151409 TP152849

Min	0.003 inch	0.010 inch
Max	0.010 inch	0.015 inch


To Adjust

Advance or retard the start magnet cores with screwdriver (locknut loosened).




Requirement

Stop armature in attracted position. Intermediate lever held upward. 8 oz scale applied to start armature at right of intermediate lever lower extension
Min 2-1/2 oz
Max 4 oz
to hold start armature against cores.



TP151409 ARMATURE



TP152849 ARMATURE

2.03 Relay Motor-Control Mechanism (if Equipped)

SWITCH POSITION (IF UNIT IS SO EQUIPPED)


Requirement

When the solenoid plunger is depressed slowly, the switch should operate when the plunger is within
 Max 0.005 inch
 from the end of its travel (gauge by eye).
 Check by the audible click or by test lamp.

To Adjust

Loosen the switch mounting screws.
 Hold the plunger downward and move the switch toward the plunger until it operates. Tighten the screws.

**EARLIER DESIGN
 (CONTACT PILE-UP TYPE)**




(A) MIDDLE CONTACT SPRING

Requirement

With solenoid plunger unoperated
 Min 2 oz---Max 3 oz
 to break contact with inner contact.

To Adjust

Form middle contact spring with suitable spring bender.



(B) OUTER CONTACT SPRING

Requirement

Hold solenoid plunger operated.
 Min 12 oz---Max 16 oz
 to break contact with the middle contact spring.

To Adjust

Form outer contact spring with suitable spring bender.

(C) INNER CONTACT SPRING GAP

Requirement

Hold solenoid plunger operated.
 Clearance between inner and middle contact spring contact surface
 Min 0.025 inch---Max 0.030 inch

To Adjust

Form inner contact spring with suitable spring bender.

2.04 Signal Bell

(A) ARMATURE SPRING TENSION

Requirement

Min 1/2 oz---Max 1 oz
to push the armature against the core
(vertically).


Requirement

Armature held against the magnet
core. Clearance between the
armature ball and the bell

Min 0.020 inch---Max 0.035 inch

To Adjust




Bend the armature extension just
below the armature spring.



2.05 Line Test Key Assembly (if Equipped)

LINE TEST KEY

Note: This key is carefully adjusted at the
factory and should not need readjusting un-
less it has been disassembled or mutilated.



Requirement

When knob is moved to downward position
contacts 9-10 should close before contacts
8-10 and 5-6 open.

To Adjust (if necessary)

Form contact leaf springs with a suitable
spring bender to meet requirements.

2.06 28 LB Electrical Service Unit


(A) Requirement for circuit assurance detector: The circuit assurance detector should accept incoming spacing signals from a receive set without setting off an alarm. If the spacing signals fall within the limits of 32.6 to 73.0 ms in length, and are received at least once each 500 ms, the alarm does not operate. The alarm contacts in the dry-reed relay pack (a part of the circuit assurance detector) close to initiate an alarm if the signal to the send set does not comply.

(B) To adjust: The timers on the circuit assurance card are adjusted with off-line signals by using the TP146439 adapter. The character T or V (32.6 ms marking pulse and 73.0 ms marking pulse respectively) is sent from the 28 LA or 28 LB transmitter distributor to the MLR relay. Using the TP146439 adapter, a 32.6 ms spacing pulse, and a 73.0 ms spacing pulse are taken from the normally closed contacts of the MLR relay and fed into the card. The operating point of the lower limit timer is set by using the 32.6 ms spacing

pulse and the operating point of the upper limit timer is set by using the 73.0 ms spacing pulse.

(C) Preliminary preparation:

- (1) Prepare four test tapes as follows:
 - (a) Three feet punched with BLANKS only.
 - (b) Three feet punched with T only.
 - (c) Three feet punched with M only.
 - (d) Three feet punched with V only.
- (2) Lower the message processing panel of the send set.
 - (a) Block relay CFR operated.
 - (b) Block relay PBRB operated.
 - (c) Set the timer disable switch to its NORMAL position.



- (3) Lower the alarm panel of the send set.
 - (a) Block relay TCFR in the unoperated position.
 - (4) Remove the following from their sockets in the electrical service unit.
 - (a) Relay REC.
 - (b) Relay LFR.
 - (c) Relay MLR.
 - (d) Wave shaping assembly (TP-146652).
 - (5) Plug relay MLR into the socket provided in the adapter.
 - (6) Plug the adapter, with the MLR relay, into the MLR socket of the electrical service unit.
 - (7) Plug the adapter test plug into the REC socket of the electrical service unit.
- (D) Upper limit timer adjustment (73 ms):
- (1) Set the switch on the adapter to its ADJUST position.
 - (2) Place the beginning of the V test tape in the reading head of the TD.
 - (3) Set the TD STOP-RUN lever in the STOP position.
 - (4) Press the RESET key on the key and lamp assembly to clear all alarms.
 - (5) Set the TRANSMITTER selector switch on the key and lamp assembly to its NORMAL position.
 - (6) Start the test tape through the TD by operating the STOP-RUN lever to the RUN position.
 - (7) With the TD reading the V test tape, rotate the adjusting screw of the 200K potentiometer (rear potentiometer) on the card counterclockwise until CONNECTION LOST alarm operates. Then rotate the adjusting screw clockwise until the CONNECTION LOST alarm fails to operate.

Note: Everytime the alarm operates, the circuit must be reset by pressing the RESET key with the TD lever in the STOP position.

- (8) Very slowly rotate the adjusting screw counterclockwise until the CONNECTION LOST alarm just operates as V test tape is read by TD.
- (E) Lower limit timer adjustment (32.6 ms):
- (1) Set the switch on the adapter to ADJUST position.
 - (2) Place the beginning of the T test tape in the reading head of the TD.
 - (3) Set the TD STOP-RUN lever in the STOP position.
 - (4) Press the RESET key on the key and lamp assembly to clear all alarms.
 - (5) Set the TRANSMITTER selector switch on the key and lamp assembly to its NORMAL position.
 - (6) Start the test tape through the TD by setting the STOP-RUN lever on RUN.
 - (7) With the TD reading the T test tape, rotate the adjusting screw of the 100K potentiometer (forward potentiometer) on the card clockwise until the CONNECTION LOST alarm operates. Then rotate the screw counterclockwise until the alarm fails to operate.

Note: Every time the alarm operates, the circuit must be reset by pressing the RESET key with the TD lever in the STOP position.

- (8) Very slowly rotate the adjusting screw clockwise until the CONNECTION LOST alarm just operates as T test tape is read by TD.

(F) Final tests:

- (1) Set the adapter switch in its TEST position. Press the RESET key on the key and lamp assembly with the TD lever in the STOP position to clear any alarms.
- (2) Place the beginning of the BLANK test tape in the reading head of the TD and start the TD reading. CONNECTION LOST alarm should operate. If not, readjust the upper limit timer. To clear an alarm condition depress the RESET key on the key and lamp assembly with the TD lever in the STOP position

(3) Replace the BLANK test tape with the T test tape and start the TD. The CONNECTION LOST alarm should fail to operate. If the alarm operates, readjust the upper limit timer as described in (D).

(4) Replace the T test tape with the M test tape and start the TD. The CONNECTION LOST alarm should fail to operate. If the alarm operates, readjust the lower limit timer as described in (E).

(5) Replace the M test tape with the V test tape and start the TD. The CONNECTION LOST alarm should operate. If the alarm fails to operate, readjust the lower limit timer as described in (E). Clear the alarm as previously described.

(6) Restore the equipment to normal by reversing the order of (C), Preliminary preparation. The timer disable switch should be in NORMAL position.

28 PERFORATOR-TRANSMITTER BASE

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1-3	Synchronous motor positioning	26
2. BASIC UNIT	4	Keyboard Mechanism	
Codebar Assembly		Ball wedgelock, ball endplay, and universal bail latch (final)	14
Clutch tripbar spring	8	Ball wedgelock and ball track clearance (preliminary).	12
Clutch tripbar spring (used for synchronous pulse transmission).	9	Codelever spring	18
Codebar bail	11	Lockball channel	10
Codebar bail and nonrepeat lever clearance	11	Lockball endplay	12
Codebar and codelever clearance	8	Local carriage return function bail spring	18
Codebar bail latch spring.	11	Local line feed trip link spring.	17
Codebar bail spring	13	Plunger spring.	17
Codebar extension spring.	19	Signal Generator Mechanism	
Codebar guide clearance	4	Clutch latchlever spring	5
Codebar spring	9	Clutch shoe lever	5
Codelever universal bail spring	4	Clutch shoe lever spring	6
Function bail levers and codelever clearance.	10	Clutch shoe spring	6
Lockbar spring	9	Clutch stop lever	5
Nonrepeat lever spring	11	Clutch stop lever spring	5
Spacebar bail pivot.	4	Signal contact clearance	7
Universal bail extension	13	Signal contact clearance (strobing)	15
Universal bail latchlever.	13	Signal contact clearance - polar operation (strobing)	16
Universal bail latch spring.	13	Signal contact drive link	7
Universal codebar	9	Signal contact spring.	7
Interrelated Features		Transfer bail detent latch spring.	7
Cam follower spring.	25	Transfer bail detent plate	7
Clutch tripbar link return spring.	23	Transfer lever locking bail spring.	19
Codebar bail	21	Transfer lever spring.	19
Codebar extension and punch slide latch	22	3. VARIABLE FEATURES	
Codebar extension bail spring.	24	Answer-Back Mechanism	
Codebar extension blocking assembly.	24	Armature latch spring.	54
Detent lever spring.	24	Blocking lever spring	54
Follower lever spring.	21	Character generator mounting plate.	50
Intermediate gear bracket	27	Coding the message drum	55
Keyboard control switch	25	Detent lever spring.	50
Margin indicator spring.	19	Drive link.	51
Mounting typing unit on keyboard.	28	Drive link spring	51
Perforator alignment	20	Latch operating lever adjusting screw.	53
Perforator clutch release trip	23	Latch operating lever spring	53
Punch slide latch spring	22	Magnet yoke	48
Reset lever spring	25	Motor control relay switch.	54
Signal generator frame	28	Sensing lever springs	50

CONTENTS	PAGE
Stepping pawl	52
Stepping pawl spring	53
Stop lever latch	49
Answer-Back Mechanism ("Figs D")	
Keyboard lockbail eccentric	56
Auxiliary Contacts	
Auxiliary contacts	58
Character Counter Mechanism	
Antibounce spring	32
Character counter scale	32
Character counter stroke	34
Cord assembly	31
End-of-line switch	33
Ratchet drum assembly return spring	33
Reset latchlever and drive lever spring	34
Reset lever extension spring	34
Stop lever	32
Clutch Trip Delay Mechanism	
Clutch trip delay	57
Trip delay torsion spring	57
Code Reading Contacts (Transmitting)	
Code reading contacts (transmitting)	60
Electrical Line Break Mechanism	
Line break lever spring	29
Keyboard Lockbar Switch Mechanism	
Keyboard lockbar switch	30
Keyboard lockbar switch spring	30
Letters and Figures Contact	
Letters and figures contact	59
Local Paper Feed-Out Mechanism	
Switch lever spring	29
Perforator Motor	
Perforator motor pinion and driven gear mesh	46
Power Backspace Switch	
Power backspace switch position	43
Remote Control Gear Shift Mechanism	
Armature stop	45
Clutch stop lever	45
Gear shift magnet	45

CONTENTS	PAGE
Gear shift magnet armature spring	44
Gear shift mechanism	44
Repeat on Space Mechanism	
Spacebar	35
Space repeat lever spring	35
Stop	35
Travel screw	35
Synchronous Pulse Mechanism	
Armature clamp	42
Armature hinge	40
Contact gap	41
Magnet armature	40
Mounting bracket	40
Universal codebar contact	41
Tape-Out Switch Mechanism	
Low tape switch	30
Switch lever spring	30
Tape-out lever spring	30
Time Delay Mechanism	
Contact latch pawl spring	37
Contact pawl spring	37
Eccentric follower pawl spring	39
Time delay mechanism position	38
Time delay ratchet wheel tension	36
Time delay switch position	36
Time delay disabling device	39
Universal Keyboard Switch	
Keyboard universal switch	47
Keyboard universal switch - horizontal	47
Keyboard universal switch - vertical	47

1. GENERAL

1.01 This section has been revised to include recent engineering changes and additions, and to rearrange the text, so as to bring the section generally up-to-date. Since this is an extensive revision, marginal arrows ordinarily used to indicate changes have been omitted.

1.02 This section contains the specific requirements and adjustments for the 28 perforator-transmitter base.

1.03 Maintenance procedures which apply only to mechanisms of a particular design, or to certain models of 28 perforator-transmitter bases are so indicated in the titles of the paragraphs which contain these particular adjustment requirements.




Figure 1 - 28 Perforator-Transmitter Base

1.04 The adjustments of each unit are arranged in a sequence that should be followed if a complete readjustment of the unit were undertaken. The tools and spring scales required to perform these adjustments are listed in the applicable section. After an adjustment is completed, be sure to tighten any nuts or screws that are loosened. The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions and the angles at which scales should be applied when measuring spring tensions. If a part mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same number is replaced when the part is re-mounted.

1.05 References made to left or right, up or down, front or rear, etc apply to the unit in its normal operating position as viewed from the front.

1.06 The letters K (Keyboard), K-T (Keyboard - Tape), and T (Tape) are used in this section to refer to corresponding positions of the keyboard-control knob. Unless otherwise specified adjustments should be made in the K-T position.

1.07 When a requirement calls for a clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latch-lever so that the clutch shoes release their tension on the clutch drum. When engaged, the clutch shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum.

Note: When the signal generator shaft is rotated by hand, the clutch does not fully disengage upon reaching its stop position. In order to relieve drag and permit the main shaft to rotate freely, apply pressure on the lug of the clutch disc with a screwdriver to cause it to engage its latchlever and fully disengage the clutch.


1.08 All electrical contact points should meet squarely. Contacts with the same diameter should not be out of alignment more than 25 per cent of the contact diameter. Check contacts for pitting and corrosion and clean or burnish them before making specified adjustment or tolerance measurement. Avoid sharp kinks or bends in the contact springs.

CAUTION: KEEP ALL ELECTRICAL CONTACTS FREE OF OIL AND GREASE.


2. BASIC UNIT

2.01 Code Bar Assembly

NOTE: REMOVE PERFORATOR TRANSMITTER FROM CABINET BEFORE ADJUSTING CODE BARS.



(A) CODE BAR GUIDE CLEARANCE REQUIREMENT
 ALL CODE BARS SHOULD MOVE FREELY WITHOUT BINDS INCLUDING THE CLUTCH TRIP BAR AND KEYBOARD LOCK BAR.
 MIN. SOME
 MAX. 0.010 INCH
 TO ADJUST
 LOOSEN MOUNTING SCREWS AND POSITION CODE BAR GUIDES.




NOTE: KEYLEVER COVER MUST BE REMOVED. SEE DISASSEMBLY AND REASSEMBLY.

(C) SPACE BAR BAIL PIVOT REQUIREMENT
 MIN. SOME END PLAY.
 MAX. 0.010 INCH.
 SPACE BAR FREE FROM BIND.
 TO ADJUST
 POSITION SPACE BAR WITH PILOT SCREWS LOOSENED.

NOTE: THE BAIL SHOULD BE SO ADJUSTED THAT THE SPACE BAR CAN BE OPERATED WITHOUT BINDING IN THE HOLES IN THE GUIDE PLATE AND THE FRAME.

2.02 Signal Generator Mechanism



(A)
CLUTCH SHOE LEVER REQUIREMENT
 CLEARANCE WHEN CLUTCH IS DISENGAGED SHOULD BE 0.055 INCH TO 0.085 INCH LESS THAN WHEN CLUTCH IS ENGAGED.

TO CHECK
 LATCH CLUTCH IN DISENGAGED POSITION AND MEASURE CLEARANCE. ROTATE GEAR UNTIL OIL HOLE IS UPWARD. ENGAGE CLUTCH AND MEASURE CLEARANCE.

TO ADJUST
 LOOSEN THE TWO ADJUSTING DISK CLAMP SCREWS TO POSITION DISK.

CLUTCH SHOE LEVER

CLUTCH DRUM

(B)
CLUTCH STOP LEVER REQUIREMENT
 SHOULD FULLY ENGAGED CLUTCH SHOE LEVER. DURING ROTATION, THE LEVER SHOULD NOT TOUCH THE CLUTCH DRUM AT ANY POINT.

TO ADJUST
 POSITION STOP LEVER WITH ITS CLAMP SCREW LOOSENED.

CLUTCH CAM DISK

(C)
CLUTCH STOP LEVER SPRING TENSION REQUIREMENT

CLUTCH ENGAGED AND ROTATED 1/4 TURN.

MIN. 2 OZS.

MAX. 3 OZS.

TO START LEVER MOVING.

STOP LEVER CLAMP SCREW

CLUTCH STOP LEVER SPRING

CLUTCH TRIP BAIL EXTENSION

(D)
CLUTCH LATCH LEVER SPRING TENSION REQUIREMENT

CLUTCH LATCH LEVER RESTING ON THE HIGHEST POINT OF CLUTCH DISK.

MIN. 2 OZS.

MAX. 3 OZS.

TO START LATCH LEVER MOVING.



CLUTCH LATCH LEVER

CLUTCH LATCH LEVER SPRING

2.03 Signal Generator Mechanism continued

(A) CLUTCH SHOE LEVER SPRING TENSION
REQUIREMENT

CLUTCH ENGAGED.
CAM DISK HELD TO PREVENT TURNING.
MIN. 15 OZS.
MAX. 20 OZS.
TO MOVE SHOE LEVER IN CONTACT WITH STOP LUG.




(B) CLUTCH SHOE SPRING TENSION
NOTE

IN ORDER TO CHECK THIS SPRING TENSION, IT IS NECESSARY TO REMOVE THE CLUTCH FROM THE MAIN SIGNAL GENERATOR DRIVE SHAFT. THEREFORE, IT SHOULD NOT BE CHECKED UNLESS THERE IS GOOD REASON TO BELIEVE THAT IT DOES NOT MEET ITS REQUIREMENT.

REQUIREMENT

CLUTCH DRUM REMOVED.
MIN. 3 OZS.
MAX. 5 OZS.
TO START PRIMARY SHOE MOVING AWAY FROM SECONDARY SHOE AT POINT OF CONTACT.

2.04 Signal Generator Mechanism continued



TO ADJUST
 ROTATE DETENT PLATE RIGHT OR LEFT BY MEANS OF SCREWDRIVER
 WITH DETENT PLATE MOUNTING SCREWS LOOSENED.

(C) SIGNAL CONTACT CLEARANCE REQUIREMENT

MARKING AND SPACING GAPS SHOULD BE EQUAL WITHIN 0.001 INCH.


TO CHECK

DEPRESS Y KEYLEVER AND ROTATE SIGNAL GENERATOR CAM SLEEVE UNTIL EACH CONTACT HAS FULLY OPENED.

TO ADJUST

LOOSEN MOUNTING SCREWS AND MOVE CONTACT BOX BY MEANS OF ECCENTRIC.

NOTE: CHECK BY MEANS OF SIGNAL CHECKING DEVICE WHERE POSSIBLE, AND CAREFULLY RE-FINE THE ADJUSTMENT TO ELIMINATE ALL BIAS FROM THE SIGNALS BY EQUALIZING THE CURRENT-ON AND CURRENT-OFF INTERVALS




(D) SIGNAL CONTACT DRIVE LINK REQUIREMENT

WITH MAINSHAFT IN STOP POSITION AND TRANSFER BAIL DETENT LATCH SPRING UNHOOKED (SEE FIG ABOVE), MOVE LATCHES AWAY FROM TRANSFER BAIL EXTENSION. HOLD THE TOGGLE FIRMLY AGAINST CONTACTS.


MIN 6 OZS --- MAX 9 OZS

TO START TRANSFER BAIL EXTENSION MOVING.

2.05 Codebar Assembly continued



NOTE: IF NECESSARY REMOVE CHARACTER COUNTER ASSEMBLY. SEE DISASSEMBLY AND REASSEMBLY.



(A) CODE BAR AND CODE LEVER CLEARANCE REQUIREMENT

CARRIAGE RETURN KEY DEPRESSED BUT NOT ENOUGH TO TRIP OFF UNIVERSAL BAIL LATCH OR CLUTCH BAR.

MIN. 0.006 INCH --- MAX. 0.017 INCH
MEASURE AT CODE BAR #3

TO ADJUST

POSITION GUIDE BY ADJUSTING SLOT WITH FOUR MOUNTING SCREWS LOOSENED.

(B) CLUTCH TRIP BAR SPRING TENSION REQUIREMENT

BLANK KEY DEPRESSED TO ALLOW THE CLUTCH TRIP BAR TO FALL TO RIGHT.
SPRING UNHOOKED FROM BRACKET

MIN. 8 OZS. --- MAX. 12 OZS.

TO PULL SPRING TO INSTALLED LENGTH.

NOTE: SEE FOLLOWING PAGE FOR ADJUSTMENTS (C), (D), (E) AND (F).

Codebar Assembly continued

NOTE: ADJUSTMENTS CONTINUED FROM
PRECEDING PAGE.

(C) CLUTCH TRIP BAR (USED FOR SYNCHRONOUS PULSED TRANSMISSION)
REQUIREMENT

WITH THE CLUTCH DISENGAGED AND LATCHED, POWER OFF AND ARMATURE OF THE
MAGNET ASSEMBLY HELD AWAY FROM THE CLUTCH TRIP BAR. PUSH AT THE RIGHT
HAND END OF CLUTCH TRIP BAR.
MIN. 9 OZS. --- MAX. 12 OZS.
TO START CLUTCH TRIP BAR MOVING.

NOTE: HOLD THE SWINGER OF THE CONTACT ASSEMBLY AWAY FROM THE UNIVERSAL CODE BAR
WHEN MEASURING THE CLUTCH TRIP SPRING TENSION.

(D) UNIVERSAL CODE BAR (USED FOR SYNCHRONOUS PULSED TRANSMISSION)
REQUIREMENT

WITH THE CLUTCH DISENGAGED AND LATCHED, DEPRESS THE BLANK KEY TO
ALLOW THE UNIVERSAL CODE BAR TO FALL TO THE RIGHT. SPRING UNHOOKED FROM
THE BRACKET.
MIN. 8 OZS. --- MAX. 12 OZS.
TO PULL SPRING TO INSTALLED LENGTH.

(E) CODE BAR SPRING TENSION
REQUIREMENT

KEYBOARD IN K POSITION, LETTERS KEYLEVER DEPRESSED (POWER OFF) HOLD
TRANSFER LEVERS (REF. FIGURE 1-15) TO THE RIGHT SO THEY DO NOT AFFECT
THE CODE BARS.
MIN. 3 OZS. --- MAX. 5 OZS.
TO START CODE BAR MOVING.


(F) LOCK BAR SPRING TENSION
REQUIREMENT

CLUTCH DISENGAGED, KEYBOARD LOCK KEYLEVER DEPRESSED. APPLY PUSH END
OF SCALE AGAINST R.H. END OF LOCK BAR.
MIN. 2-1/2 OZS. --- MAX. 6 OZS.
TO START LOCK BAR MOVING.

2.06 Codebar Assembly continued

(A) FUNCTION BAIL AND CODE LEVER CLEARANCE REQUIREMENT

MIN. 0.015 INCH BETWEEN ANY FUNCTION BAIL AND ITS ADJACENT CODE LEVER.
 TO ADJUST POSITION FUNCTION BAIL ASSEMBLY WITH MOUNTING SCREWS AND TYPING UNIT LOCATING STUDS LOOSENED.




NOTE: THIS ADJUSTMENT SHOULD NOT BE MADE UNLESS THE LOCK BALL CHANNEL HAS BEEN DISASSEMBLED.

2.07 Keyboard Mechanism

(B) LOCK BALL CHANNEL REQUIREMENT


THERE SHOULD BE SOME TO 0.006 INCH CLEARANCE BETWEEN END OF LOCK BALL CHANNEL AND ADJUSTING SCREW WHEN MOST OF THE CODE LEVERS ARE CENTRALLY LOCATED IN THE LOCK BALL CHANNEL SLOTS.
 TO CHECK REMOVE THE LOCK BALL RETAINER. REMOVE A WEDGE FROM EACH END AND ONE FROM THE CENTER IN ORDER TO VIEW THE POSITION OF THE CODE LEVER.



TO ADJUST


LOOSEN THE LOCK BALL CHANNEL MOUNTING SCREWS. BACK OFF LATERAL ADJUSTING SCREWS AND POSITION CHANNEL. TURN ONE ADJUSTING SCREW IN AGAINST THE END OF THE CHANNEL AND LOCK IT. TURN THE OTHER ADJUSTING SCREW IN TO THE END OF THE CHANNEL AND BACK IT OFF 1/4 TURN. LOCK THE SCREW. REPLACE THE WEDGES AND CHECK THEIR POSITION WITH RESPECT TO THE BALLS. PULL CHANNEL ASSEMBLY DOWNWARD UNTIL ALL CODE LEVERS STRIKE THEIR UPSTOP WITHOUT WEDGES JUMPING OUT OF POSITION. REPLACE LOCK BALL RETAINER. BACK OFF BALL ENDPLAY ADJUSTING SCREW.

2.08 Code Bar Assembly continued



(B) CODE BAR BAIL REQUIREMENT
 CAM ECCENTRIC AND ARM WHICH HOLD THE BAIL IN EXTREME RESET POSITION TO THE LEFT.
 MIN. SOME
 MAX. 0.006 INCH
 BETWEEN CODE BAR BAIL ROLLER AND CODE BAR BAIL LATCH
 TO ADJUST
 WITH LOCK NUT LOOSENED, ADJUST ECCENTRIC STUD SO THAT HIGH POINT IS IN UPPER HALF OF ARC.

(C) NON-REPEAT LEVER SPRING TENSION REQUIREMENT
 ANY KEYLEVER DEPRESSED
 MIN. 2 OZS.
 MAX. 3-1/4 OZS.
 TO START NON-REPEAT LEVER MOVING DOWNWARD.



(D) CODE BAR BAIL AND NON-REPEAT LEVER CLEARANCE REQUIREMENT
 MECHANISM IN INITIAL TRIP-OFF POSITION, ANY KEY DEPRESSED, NO POWER.
 MIN. 0.010 INCH
 MAX. 0.020 INCH
 BETWEEN ROLLER OF CODE BAR BAIL AND NON-REPEAT LEVER PICK-UP STEP.
 TO ADJUST
 LOOSEN LOCK NUT AND SHOULDER SCREW AND MOVE MECHANISM LEFT OR RIGHT.



2.09 Keyboard Mechanism continued

(A) BALL WEDGELOCK AND BALL TRACK CLEARANCE
REQUIREMENT (PRELIMINARY)


ADJUSTMENT SCREW BACKED OUT TO PERMIT MAXIMUM BALL MOVEMENT WITHOUT THE BALLS ROLLING OUT OF TRACK. (FROM PREVIOUS LATERAL ADJUSTMENT)
APPLY 32 OZS. OF PRESSURE TO THE "Q" OR THE "P" KEYLEVER
MIN. 0.005 INCH
MAX. 0.015 INCH
EQUAL WITHIN 0.005 INCH BETWEEN THE TIP OF THE WEDGE-LOCK AND THE BALL TRACK.

TO ADJUST

LOOSEN MOUNTING SCREWS AT EACH END OF THE BALL TRACK AND ADJUST TRACK UP OR DOWN.

NOTE: REMOVE KEYBOARD HOOD IN ORDER TO MAKE THIS ADJUSTMENT. SEE DISASSEMBLY AND REASSEMBLY

NOTE: WHEN GAUGING THESE CLEARANCES MAKE SURE THERE IS NO CLEARANCE BETWEEN THE LOWER EDGE OF CODE LEVER EXTENSIONS AND THE BOTTOM OF THE SLOTS IN THE WEDGES. A TOTAL OF 43 BALLS ARE REQUIRED IN THE BALL TRACK ASSEMBLY.




(B) LOCK BALL-END PLAY

REQUIREMENT (PRELIMINARY)


WITH A 32 OZS. PRESSURE APPLIED TO THE CAR. RET. KEY, THE BALLS SHALL HAVE A MIN. CLEARANCE

TO ADJUST

TURN IN BALL END-PLAY ADJUSTMENT SCREW WITH FINGERS UNTIL A RESISTANCE IS FELT, TIGHTEN THE NUT.



2.10 Codebar Assembly continued



2.11 Keyboard Mechanism continued

BALL WEDGELOCK, BALL END-PLAY AND UNIVERSAL BAIL LATCH ADJUSTMENTS - (FINAL)

CHECK UNDER POWER:


- (1) REQUIREMENT
MIN. 2 OZS.
MAX. 5 OZS.
TO TRIP ANY CENTER ROW KEY.
- (2) REQUIREMENT
WITH 5-1/2 OZS. PRESSURE APPLIED PERPENDICULAR TO THE "A" KEY, DEPRESS EACH KEY IN THE THIRD ROW. THE "A" KEY SHALL TRIP EACH TIME A KEY IS RELEASED. REPEAT THIS CHECK WITH THE 5-1/2 OZS. PRESSURE ON THE "CAR. RET." KEY.
- (3) REQUIREMENT
THE CLUTCH SHALL NOT TRIP WHEN ANY TWO KEYS ARE DEPRESSED SIMULTANEOUSLY.
- (4) REQUIREMENT
WITH $4\frac{1}{4} \pm \frac{1}{4}$ OZ. APPLIED TO THE "SPACE BAR," DEPRESS "CAR. RET." KEY. THE "SPACE BAR" SHALL TRIP EACH TIME THE "CAR. RET." KEY IS RELEASED BY MOVING THE FINGER OFF THE KEY IN A HORIZONTAL DIRECTION.

NOTE

DISREGARD MULTIPLE SPACE OPERATION IF UNIT IS EQUIPPED WITH 163775 MODIFICATION KIT FOR REPEAT-SPACE OPERATION.

TO ADJUST

IF NECESSARY, REFINE PRELIMINARY BALL WEDGELOCK, PRELIMINARY BALL END-PLAY, PRELIMINARY UNIVERSAL BAIL LATCH, AND UNIVERSAL BAIL EXTENSION ADJUSTMENTS.




2.12 Signal Generator Mechanism continued

SIGNAL CONTACT CLEARANCE (USING SIGNAL TEST SET --- SUCH AS DXD/LSS)
PRELIMINARY --- WITH ELECTRICAL NOISE SUPPRESSOR DISCONNECTED FROM CIRCUIT, CONNECT SIGNAL CONTACTS SO AS TO INTERRUPT (KEY) CURRENT TO "STROBE" LAMP OF DXD OR LSS. TEST SET AND KEYBOARD MUST OPERATE AT SAME SPEED. (SEE TABLE 1-1).

REQUIREMENTS

- (1) WITH BLANKS COMBINATION SELECTED, ORIENT SCALE OF TEST SET TO ALIGN ZERO MARK OF STOP SEGMENT WITH BEGINNING OF STOP PULSE IMAGE. LENGTH OF TRACE SHALL BE FROM THE ZERO MARK (NOTE 1.) TO (MIN. 141-1/2 DIVISIONS ----- MAX. 142-1/2 DIVISIONS) TO ADJUST - IF VARIATIONS OCCUR, POSITION SCALE SO THAT VARIATIONS EXTEND EQUALLY ON RIGHT & LEFT OF 142 MARK.
- (2) NOMINAL LENGTH OF PULSES NO. 1, 2, 3, 4, & 5 IS 100 DIVISIONS. TO ADJUST - RECHECK CONTACT CLEARANCE REQUIREMENT FIG. 1-4. REFINE CLEARANCE, WHERE NECESSARY, TO FAVOR PULSES 1 THRU. 5 BY ORIENTING BEGINNING OF STOP PULSE TRACE UP TO ± 5 DIVS. FROM ZERO MARK OF SEGMENT (REFER TO REQUIREMENTS "A" AND "B" BELOW)
- (3) EACH PULSE TRACE (SEE "C" BELOW) TO BE FREE OF UNDERSIRABLE BREAKS. TO ADJUST - RECHECK TRANSFER BAIL DETENT PLATE REQUIREMENT. (FIG. 1-4) AND WHERE NECESSARY, REFINE ADJUSTMENT. NOTE --- DETENT PLATE MAY BE ROTATED EITHER LEFT OR RIGHT AS LONG AS DETENT TOGGLE LATCH CONTINUES TO CAM OFF PROJECTION OF TRANSFER BAIL.



- A. BEGINNING OF EACH TRACE SHOULD FALL BETWEEN
 1. ZERO MARK AND 5TH DIV. OF SCALE SEGMENT
 2. 95TH DIV. (PREVIOUS SEGMENT) AND ZERO MARK.
- B. END OF EACH TRACE (EXCEPT STOP PULSE)
 1. 95TH DIV. (PREVIOUS SEGMENT) & ZERO MARK
 2. ZERO MARK AND 5TH DIV. OF SCALE SEGMENT.
- C. EACH TRACE OF THE MARKING CODE PULSES MAY HAVE A BREAK WITHIN TOLERANCE LIMITS --- THE BREAK SHOULD NOT OCCUR PRIOR TO 95TH DIVISION OF OBSERVED PULSE (1 THROUGH 5) OR 137TH DIVISION OF STOP PULSE. SEE TABLE 1-1 FOR PERMISSIBLE WIDTH OF BREAK AT SPEED OF OPERATION.


SEE "R" & "Y" COMBINATION FIGURE 1-16D

TABLE 1-1 SIGNALING PULSE SPEED AND PERMISSIBLE WIDTH OF BREAK

SPEED	OPERATIONS PER MINUTE	WIDTH OF BREAK NOT TO EXCEED	REMARKS
60 W.P.M.	368.182	1 DIVISION	MARKING PULSES (1 THROUGH 5 & STOP)
75 W.P.M.	460.00	1-1/2 DIVISION	MARKING PULSES (1 THROUGH 5 & STOP)
100 W.P.M.	600.00	2 DIVISION	MARKING PULSES (1 THROUGH 5 & STOP)

2.13 Signal Generator Mechanism continued

"R" AND "Y" COMBINATION




FOR UNITS WITH SPACING CONTACTS OF SIGNAL GENERATOR WIRED FOR POLAR OPERATION REQUIREMENTS ---

- (1) SPACING PULSES SHALL START NO EARLIER THAN 94TH DIV. OF PREVIOUS SEGMENT AND NO LATER THAN 6TH DIV. OF PULSE UNDER OBSERVATION.
- (2) TRACE OF SPACING PULSE SHALL END NO EARLIER THAN 94TH DIV. OF PULSE UNDER OBSERVATION AND END NO LATER THAN 6TH DIV. OF FOLLOWING PULSE.
- (3) TRACE OF START PULSE SHALL BEGIN NO EARLIER THAN 136TH DIV. OF STOP SEGMENT AND NO LATER THAN 6TH DIV. OF START SEGMENT. START PULSE SHALL END NO EARLIER THAN 94TH DIV. OF START SEGMENT AND END NO LATER THAN 6TH DIV. OF NO. 1. SEGMENT.
- (4) SPACING PULSE MAY HAVE A BREAK PROVIDED THE BREAK IS NOT OVER ONE DIVISION WIDE AND IT DOES NOT OCCUR PRIOR TO 95TH DIV. OF PULSE UNDER OBSERVATION.

SEE TABLE 1-1 FOR PERMISSIBLE WIDTH OF BREAK AT SPEED OF OPERATION.

2.14 Keyboard Mechanism continued




2. 15 Keyboard Mechanism continued

(A) CODE LEVER SPRING TENSION


(1) REQUIREMENT
MIN. 1 OZ.
MAX. 2 OZS.
TO START CODE LEVER MOVING DOWNWARD.

(2) REQUIREMENT
POWER ON.
GENERATOR CLUTCH DISENGAGED.
MIN. 3 OZS.
MAX. 5 OZS.
TO OPERATE KEYLEVER OR SPACE BAR.



(B) LOCAL CARRIAGE RETURN FUNCTION BAIL SPRING TENSION
(COMBINED CODE LEVER AND BAIL SPRING)

REQUIREMENT
MIN. 1 OZ.
MAX. 3 OZS.
TO MOVE KEYLEVER DOWNWARD.





2.16 Codebar Assembly and Signal Generator Mechanism continued

(B) TRANSFER LEVER LOCKING BAIL SPRING TENSION REQUIREMENT

SPRING UNHOOKED FROM POST, CLUTCH DISENGAGED.
 MIN. 5 OZS.
 MAX. 6 OZS.
 TO PULL TO INSTALLED LENGTH.

(A) TRANSFER LEVER SPRING TENSION REQUIREMENT


CLUTCH DISENGAGED.
 MIN. 1 1/2 OZS.
 MAX. 2 1/2 OZS.
 TO START EACH OF SEVEN LEVERS MOVING.



(C) CODE BAR EXTENSION SPRING REQUIREMENT

MIN. 5 OZS.
 MAX. 7 OZS.
 TO START EACH EXTENSION MOVING.

2.17 Interrelated Features




(D) MARGIN INDICATOR SPRING TENSION REQUIREMENT

MIN. 7 OZS.
 MAX. 11 OZS.
 TO START LEVER MOVING.

Note: Paragraph 2.18 through 2.23 apply to both typing and non-typing perforators.

2.18 Interrelated Features continued



PERFORATOR ALIGNMENT

(1) REQUIREMENT

PUNCH SLIDE LATCHES SHOULD ALIGN WITH CODE BAR EXTENSIONS
MIN. 0.010 -- MAX. 0.020 INCH TO RIGHT OF CODE BAR EXTENSION.

(2) REQUIREMENT

RESET CAM SHOULD ALIGN WITH ITS CAM FOLLOWER ROLLER
APPROXIMATELY 0.030 INCH FORWARD OF THE REAR EDGE OF THE ROLLER.


CONTINUED ON FOLLOWING PAGE.

CONTINUED FROM PRECEDING PAGE.

TO ADJUST

LOOSEN SET SCREWS AND DISENGAGE FLEXIBLE COUPLINGS. LOOSEN TWO ALIGNMENT BRACKET SCREWS AND THREE PERFORATOR MOUNTING SCREWS. SET EXTENSION GUIDE PIN IN MIDDLE OF GUIDE BRACKET SLOT AND ALIGN PERFORATOR AND RESET CAM. TIGHTEN PERFORATOR MOUNTING SCREWS. POSITION ALIGNMENT BRACKET SO THAT IT CONTACTS PERFORATOR CASTING FOR ITS FULL LENGTH, AND TIGHTEN SCREWS. POSITION REAR BEARING BRACKET UNTIL PERFORATOR DRIVE SHAFT LINES UP WITH BEARING BRACKET SHAFT. A STRAIGHT-EDGE RULE APPLIED TO THE CENTER OF THE BEARING BRACKET SHAFT SHOULD ALSO EXTEND THROUGH THE CENTER OF THE PERFORATOR DRIVE SHAFT. TIGHTEN SCREWS, AND ENGAGE THE COUPLING, IF NECESSARY, REFINE LINE UP OF PUNCH SLIDE LATCHES AND CODE BAR EXTENSIONS BY ADJUSTING THE CODE BAR EXTENSION GUIDE BRACKET IN ITS MOUNTING HOLES.

2.19 Interrelated Features continued



(B) CODE BAR BAIL REQUIREMENT

CONTROL KNOB IN T POSITION. CODE BAR BAIL AT EXTREME LEFT. CLEARANCE BETWEEN CODE BAR BAIL LATCH LEVER AND ROLLER.

MIN. SOME --- MAX. 0.006 INCH


TO ADJUST

POSITION ECCENTRIC STUD WITH LOCK SCREW LOOSENED TO MEET REQUIREMENT. RECHECK AFTER TIGHTENING LOCK SCREW.

TO CHECK

WITH ALL CLUTCHES LATCHED, DEPRESS LTRS KEY. AFTER CODE BARS HAVE MOVED TO RIGHT, THERE MUST BE SOME CLEARANCE BETWEEN FOLLOWER RESET LEVER AND CLUTCH TRIP BAR PIN.

2.20 Interrelated Features continued



(1) REQUIREMENT

CONTROL KNOB IN T POSITION, BLANK KEYLEVER DEPRESSED. PUNCH SLIDE LATCHED. PLAY BETWEEN CODE BAR EXTENSIONS AND CODE BARS TAKEN UP BY MOVING AND HOLDING EXTENSIONS AT ENGAGEMENT WITH CODE BARS. CLEARANCE SHOULD BE MIN. SOME --- MAX. 0.010 INCH BETWEEN CODE BAR EXTENSIONS AND CLOSEST PUNCH SLIDE LATCH.

(2) REQUIREMENT

LTRS KEYLEVER DEPRESSED. CODE BAR EXTENSIONS SHOULD ROTATE PUNCH SLIDE LATCHES TO RELEASE ALL PUNCH SLIDES. CHECK DYNAMIC OPERATION BY DEPRESSING THE "REPEAT" AND "BLANK" KEY SIMULTANEOUSLY.

(3) ON KEYBOARD PERFORATORS NOT HAVING THE "BLANK" KEY, OPERATE THE "BLANK" CODE BAR LEVER BY LIFTING WITH A SPRING HOOK. TO ADJUST

POSITION GUIDE VERTICALLY WITH GUIDE LOCK NUT LOOSENED TO OBTAIN REQUIRED CLEARANCE. TIGHTEN LOCK NUT.

2.21 Interrelated Features continued

PERFORATOR CLUTCH RELEASE TRIP REQUIREMENT

PERFORATOR CLUTCH SHOULD TRIP CONSISTENTLY IN K-T POSITIONS WHEN BLANK AND REPEAT KEYLEVERS ARE DEPRESSED SIMULTANEOUSLY. WHEN THE CONTROL KNOB IS TURNED FROM K POSITION TO K-T POSITION, THE PERFORATOR CLUTCH SHOULD TRIP WHEN THE FIRST KEYLEVER IS DEPRESSED. CLEARANCE BETWEEN MAIN TRIP LEVER AND CLUTCH RELEASE

MIN. 0.015 INCH
MAX. 0.025 INCH

TO ADJUST

PLACE CONTROL KNOB IN T POSITION. LOOSEN MAIN TRIP LEVER LATCH CLAMP SCREWS AND MOVE LATCH TO EXTREME LEFT. STRIKE BLANK KEYLEVER. MOVE THE STOP BRACKET TO THE RIGHT UNTIL IT IS OUT OF ENGAGEMENT WITH THE LATCH. MOVE THE CLUTCH TRIP BAR EXTENSION TO THE RIGHT UNTIL IT LATCHES. POSITION MAIN TRIP LEVER LATCH TO RIGHT TO OBTAIN REQUIRED CLEARANCE. TIGHTEN SCREWS.

NOTE: CHECK FOR CLEARANCE BETWEEN RESET BAIL AND SLIDES WHEN THE RESET LEVER IS TRIPPED. REFINE ADJUSTMENT IF NECESSARY TO OBTAIN OPERATIONAL CLEARANCE.


TO CHECK

WITH THE STOP BRACKET SCREWS FRICTION TIGHT, MOVE THE STOP BRACKET SLOWLY TO THE LEFT UNTIL THE LATCH JUST TRIPS. TIGHTEN CLAMP SCREWS. TURN ON MOTOR. DEPRESS BLANK AND REPEAT KEYLEVERS SIMULTANEOUSLY. IF OPERATION IS SATISFACTORY, TURN TO K-T POSITION AND REPEAT. TURN TO K POSITION AND BACK TO K-T POSITION. DEPRESS A KEYLEVER. PERFORATOR CLUTCH SHOULD TRIP. IF IT DOES NOT, MOVE STOP BRACKET SLIGHTLY TO THE RIGHT AND REPEAT THE ABOVE ADJUSTMENT.

NOTE: IF KEYBOARD DOES NOT HAVE BLANK KEYLEVER USE "T" KEYLEVER INSTEAD OF BLANK.

CLUTCH TRIP BAR LINK RETURN SPRING REQUIREMENT

CLUTCH DISENGAGED AND IN K-T POSITION.
MIN. 4 OZS.
MAX. 6 OZS.
TO START MAIN TRIP LEVER LATCH MOVING.



2.22 Interrelated Features continued

CODE BAR EXTENSION BLOCKING ASSEMBLY
REQUIREMENT

SELECTOR SWITCH IN K POSITION. CODE BAR EXTENSIONS AND CHARACTER COUNTER BARS SHOULD NOT OPERATE.

(1) CLEARANCE BETWEEN RIGHT END AT CODE BAR EXTENSIONS AND CODE BARS.


MIN. SOME
MAX. 0.015 INCH

(2) CLEARANCE BETWEEN BLOCKING LEVER AND SIDE OF NOTCH IN CHARACTER COUNTER CODE BARS. BAR WITH CLOSEST GAP


MIN. SOME
MAX. 0.010 INCH

TO ADJUST

WITH CLUTCH LATCHED, TURN CONTROL KNOB TO THE K POSITION. STRIKE LTRS KEYLEVER AND ROTATE SIGNAL GENERATOR SHAFT TO RETURN CODE BARS TO EXTREME LEFT. WITH ADJUSTING SCREW FRICTION TIGHT, POSITION EXTENSION BAIL TO OBTAIN REQUIREMENT (1) AND POSITION BLOCKING LEVER TO OBTAIN REQUIREMENT (2) MAKE CERTAIN THAT THE CODE BAR EXTENSION BAIL IS FREE ON ITS GUIDE POST. TEST OPERATION IN K, K-T AND T POSITIONS.




CODE BAR EXTENSION BAIL SPRING
REQUIREMENT
CONTROL KNOB IN K-T POSITION.
MIN. 7 OZS.
TO START EXTENSION BAIL MOVING.



DETENT LEVER SPRING
REQUIREMENT
MIN. 4 LBS.
MAX. 5 LBS.
TO START LEVER MOVING.

2.23 Interrelated Features continued




2.24 Interrelated Features continued

CAUTION

IF THE MOTOR SHOULD BECOME BLOCKED FOR SEVERAL SECONDS, THE THERMAL CUT-OUT SWITCH WILL BREAK THE CIRCUIT. SHOULD THIS HAPPEN, ALLOW THE MOTOR TO COOL AT LEAST 5 MINUTES BEFORE MANUALLY DEPRESSING THE RED BUTTON. AVOID REPEATED DEPRESSION.

SYNCHRONOUS MOTOR POSITIONING REQUIREMENT

TWO OILERS SHOULD BE UPWARD AND APPROXIMATELY EQUIDISTANT FROM A VERTICAL LINE THROUGH THE MOTOR SHAFT.
TO ADJUST POSITION THE MOTOR WITH BOTH CLAMP SCREWS LOOSENED.



2.25 Interrelated Features continued

(2) REQUIREMENT
 BARELY PERCEPTIBLE BACKLASH BETWEEN THE INTERMEDIATE DRIVING GEAR AND THE INTERMEDIATE DRIVEN GEAR AT THE CLOSEST POINT.

TO ADJUST
 RAISE OR LOWER THE FRONT END OF THE INTERMEDIATE GEAR BRACKET BY MEANS OF THE FILLISTER HEAD ADJUSTING AND CLAMPING SCREWS LOCATED AT THE FRONT END OF THE BRACKET. REFINE REQUIREMENTS IF NECESSARY.


INTERMEDIATE GEAR BRACKET

(1) REQUIREMENT


BARELY PERCEPTIBLE BACKLASH BETWEEN THE TYPING UNIT DRIVEN GEAR AND THE TYPING UNIT DRIVING GEAR AT THE CLOSEST POINT.

TO ADJUST

POSITION THE COMPLETE INTERMEDIATE GEAR MECHANISM BRACKET BY UTILIZING THE ADJUSTING SLOTS WITH THE THREE HEXAGON HEAD SCREWS LOOSENED. ALIGN THE GEARS AT THIS TIME.




2.26 Interrelated Features continued



(B) SIGNAL GENERATOR FRAME REQUIREMENT


WITH TYPING UNIT MOUNTED IN POSITION, THERE SHOULD BE A PERCEPTIBLE AMOUNT OF BACKLASH BETWEEN THE SIGNAL GENERATOR DRIVEN GEAR AND THE SIGNAL GENERATOR DRIVING GEAR AT THE POINT WHERE BACKLASH IS THE LEAST. TO ADJUST REMOVE THE SIGNAL GENERATOR FRAME REAR MOUNTING SCREW AND LOOSEN THE SHIM SCREW. ADD OR SUBTRACT SHIMS AS REQUIRED.

WHEN PLACING THE TYPING UNIT ON THE BASE HOLD IT TILTED SLIGHTLY TO THE RIGHT AND LOWER THE RIGHT END INTO ENGAGEMENT WITH THE RIGHT LOCATING STUD. WHILE EASING THE LEFT END DOWNWARD ROTATE THE MOTOR BY HAND TO PROPERLY MESH THE GEARS. SECURE BY FOUR MOUNTING SCREWS. ROTATE THE MOTOR BY HAND TO INSURE PROPER MESHING OF GEARS.




3. VARIABLE FEATURES

3.01 Electrical Line Break Mechanism




3.02 Local Paper Feed-Out Mechanism

SWITCH LEVER SPRING TENSION REQUIREMENT
 MIN. 11 OZS.
 MAX. 14 OZS.
 TO PULL SWITCH LEVER FREE OF SWITCH ACTUATING PIN.



3.03 Tape Out Switch Mechanism



(A) LOW TAPE SWITCH REQUIREMENT

SWITCH SHOULD OPERATE WHEN DIAMETER OF TAPE ROLL IS BETWEEN 2-3/4 INCHES AND 2-3/8 INCHES.

TO ADJUST

POSITION SWITCH ASSEMBLY WITH MOUNTING SCREWS LOOSENED. CHECK WITH TEST LAMP.

(C) SWITCH LEVER SPRING REQUIREMENT

MIN. 6 OZS. --- MAX. 7 OZS.
TO PULL SPRING TO LENGTH OF 1-1/4 INCHES


(B) TAPE-OUT LEVER SPRING REQUIREMENT

MIN. 6 OZS. --- MAX. 8 OZS.
TO PULL SPRING TO LENGTH OF 1-17/32 INCHES.

3.04 Keyboard Lockbar Switch Mechanism

(D) KEYBOARD LOCK BAR SWITCH SPRING REQUIREMENT

LOCK BAR LATCHED (SEND KEYLEVER DEPRESSED IF EQUIPPED WITH ELECTRICAL LOCK-OUT)
MIN. 8 OZS.
MAX. 15 OZS.
TO START SWITCH SPRING MOVING.



(E) KEYBOARD LOCK-BAR SWITCH (1) REQUIREMENT

WITH THE RECEIVE KEY DEPRESSED THE CONTACT GAP OF THE NORMALLY OPEN CONTACT (NO'S 1,2,3) SHOULD BE MIN. 0.008 INCH


(2) REQUIREMENT

WITH THE SEND KEY DEPRESSED CONTACT GAP OF THE NORMALLY CLOSED CONTACT NO. 4 SHOULD BE MIN. 0.008 INCH



(3) REQUIREMENT

ALL CONTACTS SHOULD CLOSE WITH SOME OVER-TRAVEL
TO ADJUST BEND CONTACT SPRINGS

3.05 Character Counter Mechanism



3.06 Character Counter Mechanism continued



CHARACTER COUNTER SCALE

- (1) REQUIREMENT
WHEN INDICATOR IS AT EXTREME LEFT OF SCALE, IT SHOULD POINT TO ZERO.
TO ADJUST
SET INDICATOR TO LEFT. LOOSEN LOCK SCREWS AND POSITION SCALE.
- (2) REQUIREMENT
POINT OF INDICATOR SHOULD NOT TOUCH THROUGHOUT ITS ENTIRE TRAVEL.
TO ADJUST
FORM THE INDICATOR.



STOP LEVER

- (1) REQUIREMENT
WITH THE COUNTER RATCHET FULLY RETURNED AND RESTING AGAINST ITS STOP LEVER, THE CLEARANCE BETWEEN THE LATCH LEVER AND THE FACE OF THE 4TH RATCHET TOOTH SHOULD BE
MIN. 0.002 INCH
MAX. 0.010 INCH
- (2) REQUIREMENT
THE ANTI-BOUNCE LATCH SHOULD NOT INTERFERE WITH THE ROTATION OF THE RATCHET.
TO ADJUST
HOLD THE DRIVE LEVER OUT OF ENGAGEMENT WITH THE RATCHET AND ROTATE THE STOP LEVER ECCENTRIC.

3.07 Character Counter Mechanism continued

RATCHET DRUM ASSEMBLY RETURN SPRING REQUIREMENT

1/2 TO 1 1/2 OZS. WHEN INDICATOR POINTS TO 35 ON THE SCALE.
 1 1/2 TO 2 1/2 OZS. WHEN INDICATOR POINTS TO 70 ON THE SCALE.

CHARACTER COUNTER END-OF-LINE SWITCH

(1) REQUIREMENT

THE SWITCH SHOULD CLOSE AT A PRESET NUMBER OF CHARACTERS.

(2) REQUIREMENT

BEFORE INSTALLING THE COUNTER ON THE KEYBOARD PERFORATOR, TIGHTEN THE CLAMP SCREWS AND SWITCH BRACKET MOUNTING SCREWS FRICTION TIGHT. WITH THE SWITCH LEAF SPRINGS APPROXIMATELY PARALLEL TO THE SWITCH MOUNTING BRACKET (GAGE BY EYE) AND WITH

MIN. 0.005 INCH --- MAX. 0.020 INCH

CLEARANCE BETWEEN THE LEAF SPRING SWITCH CONTACTS (BEND LOWER LEAF SPRING).

TO ADJUST

POSITION SWITCH BRACKET UNTIL THE UPPER SWITCH LEAF SPRING CLEARS THE LOW OF THE CAM

MIN. SOME --- MAX. 0.025 INCH

CHECK CLOSEST POINT AND TIGHTEN BRACKET SCREWS. SET INDICATOR TO COUNT DESIRED AND ADJUST CAM UNTIL THE SWITCH JUST CLOSSES. TIGHTEN CLAMP SCREWS.

TO CHECK OPERATION

MOVE RATCHET DRUM UNTIL THE INDICATOR TRAVERSES THE ENTIRE SCALE. THE SWITCH SHOULD CLOSE ON THE DESIRED COUNT, WITH A SMALL AMOUNT OF OVER-TRAVEL OF BOTH BLADES. IT MAY BE NECESSARY TO REFINE THE ABOVE ADJUSTMENTS WHEN OPERATING ON THE EXTREME ENDS OF THE 65 TO 80 CHARACTER RANGE.

3.08 Character Counter Mechanism continued

CHARACTER COUNTER STROKE

REQUIREMENT

WHEN CHARACTER AND REPEAT KEYS ARE DEPRESSED, THE COUNTER SHOULD OPERATE CONSISTENTLY IN T OR K-T POSITION. WHEN CARRIAGE RETURN KEY IS DEPRESSED, THE COUNTER SHOULD RESET WITHOUT BINDING. THE MECHANISM SHOULD COUNT THE FIRST CHARACTER ON A RESTART AFTER RESET CONDITION.

MIN. 0.006---MAX. 0.015 INCH

BETWEEN DRIVE LEVER AND RATCHET TOOTH, WHEN COUNTER IS SET NEAR MID-POINT OF ITS RANGE.

TO ADJUST

LOOSEN MOUNTING SCREWS. WITH KEYBOARD IN T POSTION, START MOTOR AND STRIKE CARRIAGE RETURN KEY, AND THEN E KEY. TURN OFF MOTOR. DEPRESS E KEY. POSITION CHARACTER COUNTER FRAME FOR CLEARANCE. TURN CONTROL KNOB TO K-T POSITION AND RECHECK. REFINE IF NECESSARY.


RESET LATCH LEVER AND DRIVE LEVER SPRING

REQUIREMENT

MIN. 1/2 OZ.

MAX. 1 OZ.

TO MOVE EITHER LEVER.



RESET LEVER EXTENSION SPRING


REQUIREMENT

WITH THE CODE BARS LATCHED


MIN. 1/2 OZ.

MAX. 1-1/4 OZ.

TO START LEVER MOVING.



3.09 Repeat On Space Mechanism



(A) TRAVEL SCREW REQUIREMENT
 WITH SPACE BAR FULLY DEPRESSED:
 MIN. 0.035 INCH --- MAX. 0.080 INCH
 BETWEEN RESET BAIL ROLLER AND
 NON-REPEAT LEVER.

TO ADJUST
 WITH SPACE BAR FULLY DEPRESSED,
 POSITION TRAVEL SCREW WITH ITS
 LOCK NUT LOOSENED. RECHECK
 CLEARANCE AFTER TIGHTENING
 LOCK NUT.

(B) STOP REQUIREMENT
 MIN. 0.002 INCH --- MAX. 0.020 INCH
 BETWEEN TRAVEL SCREW AND NON-
 REPEAT LEVER.


TO ADJUST
 DEPRESS G KEYLEVER TO TRIP KEY-
 BOARD CLUTCH. POSITION STOP
 SCREW WITH ITS LOCK NUT
 LOOSENED. RECHECK GAP AFTER
 TIGHTENING LOCK NUT.

(C) SPACE-REPEAT LEVER SPRING REQUIREMENT
 WITH SPRING UNHOOKED
 MIN. 13-1/2 OZS. --- MAX.
 16-1/2 OZS. TO POSITION
 LENGTH.




NOTE: SPACE BAR TOUCH TO OBTAIN A
 REPEAT IS AFFECTED BY THIS ADJUST-
 MENT. TO GET A LIGHTER TOUCH,
 ADJUST TO MAXIMUM LIMIT. TO
 OBTAIN A HEAVIER TOUCH ADJUST
 TO THE MINIMUM LIMIT.

3.10 Time Delay Mechanism



3.11 Time Delay Mechanism continued



CONTACT PAWL SPRING TENSION

REQUIREMENT

CONTACT PAWL LATCHED ON END OF LATCH LEVER.

MIN. 8 OZS.

MAX. 12 OZS.

TO START THE PAWL MOVING.

CONTACT LATCH PAWL SPRING TENSION

REQUIREMENT


LATCH PAWL SPRING UNHOOKED AT ANCHOR

MIN. 12 OZS.

MAX. 15 OZS.

TO STRETCH SPRING TO INSTALLED LENGTH AS SHOWN.


3.12 Time Delay Mechanism continued



3.13 Time Delay Mechanism continued

ECCENTRIC FOLLOWER PAWL SPRINGREQUIREMENT

ECCENTRIC FOLLOWER PAWL IN EXTREME FORWARD POSITION. 8 OZ. SCALE APPLIED TO PAWL NEAR RATCHET WHEEL AND PULLED UPWARD
 MIN. 1-1/2 OZS.
 MAX. 4 OZS.
 TO START PAWL MOVING.

TIME DELAY DISABLING DEVICEREQUIREMENT

DISABLE THE TIME DELAY MECHANISM WHEN NOT REQUIRED.
 TO ADJUST
 LOOSEN THE ADJUSTING LEVER MOUNTING SCREW AND PRESS DOWNWARD ON THE LEVER TO RAISE ECCENTRIC FOLLOWER OUT OF ENGAGEMENT WITH ITS RATCHET WHEEL.

3.14 Synchronous Pulse Mechanism

MOUNTING BRACKET (A)

TO CHECK

WITH MAGNET NOT ATTRACTED AND CLUTCH TRIP BAR IN FURTHEST LEFT POSITION.

REQUIREMENT

MIN. 0.005 INCH --- MAX. 0.015 INCH BETWEEN CLUTCH TRIP BAR AND ARMATURE LEVER.

TO ADJUST


POSITION MOUNTING BRACKET WITH THREE MOUNTING SCREWS LOOSE BY MEANS OF PRY POINT.

NOTE

TIGHTEN REAR LEFT MOUNTING SCREW AND MAKE MOUNTING BRACKET ADJUSTMENT (B).

REAR LEFT MOUNTING SCREW

PRY POINT



MAGNET ARMATURE (D)

TO CHECK

CLUTCH TRIP BAR IN EXTREME LEFT POSITION. HOOK 32 OZ. SCALE TO ARMATURE LEVER AS SHOWN. MEASURE AT RIGHT ANGLE TO ARMATURE LEVER AS INDICATED.

REQUIREMENT

MIN. 3 OZS. --- MAX. 5 OZS. TO PULL ARMATURE LEVER FROM CLUTCH TRIP BAR.

ARMATURE HINGE (C)

REQUIREMENT

WITH ARMATURE IN ATTRACTED POSITION ARMATURE FLUSH WITH POLE FACE AND MAGNET BRACKET EXTENSION.

TO ADJUST

POSITION ARMATURE WITH HINGE BRACKET MOUNTING SCREW AND SPRING POST LOOSE.

MOUNTING BRACKET (B)

TO CHECK

WITH ARMATURE LEVER HELD AGAINST MAGNET POLE FACE AND CLUTCH TRIP BAR IN FURTHEST RIGHT POSITION.

REQUIREMENT

MIN. 0.005 INCH --- MAX. 0.015 INCH BETWEEN CLUTCH TRIP BAR AND ARMATURE LEVER.

TO ADJUST

WITH RIGHT REAR AND LEFT FRONT MOUNTING BRACKET SCREWS LOOSE POSITION MOUNTING BRACKET BY MEANS OF PRY POINT.


MOUNTING SCREWS

PRY POINT


CLUTCH TRIP BAR

ARMATURE LEVER

SPRING POST




3.15 Synchronous Pulse Mechanism continued




CONTACT GAP
 REQUIREMENT
 WITH UNIVERSAL CODE BAR IN STOP POSITION
 (TO RIGHT AS VIEWED FROM REAR) CONTACT
 GAP SHOULD BE
 MIN. 0.020 INCH --- MAX. 0.035 INCH
 TO ADJUST
 POSITION CONTACT MOUNTING BRACKET
 WITH MOUNTING SCREWS LOOSE.

UNIVERSAL CODE BAR CONTACT
 REQUIREMENT
 WITH UNIVERSAL CODE BAR IN OPERATED
 POSITION (TO THE LEFT AS VIEWED FROM REAR)
 MIN. 3-1/2 OZS. --- MAX. 4-1/2 OZS.
 TO OPEN CONTACTS.
 TO ADJUST
 BEND CONTACT SWINGER.



3.16 Synchronous Pulse Mechanism continued




NOTE: TO MAKE KEYBOARD OPERABLE WITHOUT ELECTRICAL PULSE TO OPERATE STEPPING MAGNET LOOSEN CLAMP MOUNTING SCREW AND ROTATE CLAMP COUNTERCLOCKWISE TO HOLD THE ARMATURE IN THE OPERATING POSITION. MAINTAIN 0.005 INCH TO 0.015 INCH CLEARANCE BETWEEN CLUTCH TRIP BAR AND ARMATURE LEVER.

ARMATURE CLAMP REQUIREMENT

WITH ARMATURE OPERATED, CLEARANCE BETWEEN ARMATURE CLAMP AND ARMATURE APPROX. 3/8 INCH
TO ADJUST POSITION CLAMP WITH ITS MOUNTING SCREW LOOSENED.

3.17 Power Backspace Switch



3.18 Remote Control Gear Shift Mechanism


GEAR SHIFT MECHANISM

REQUIREMENT


THE BACKLASH BETWEEN THE MOTOR PINION AND ITS DRIVEN GEAR AND BETWEEN THE TYPING UNIT DRIVEN GEAR AND ITS DRIVING GEAR SHOULD BE SOME --- MAX. 0.005 INCH

TO ADJUST

LOOSEN THE FOUR SCREWS WHICH MOUNT THE ASSEMBLY BRACKET TO BASE. LOOSEN THE NUT-PLATE MOUNTING SCREW AT FRONT OF ASSEMBLY BRACKET. LOOSEN LOCK NUTS ON ADJUSTING BUSHINGS. POSITION GEAR SHIFT BRACKET ASSEMBLY FRONT TO REAR. RAISE OR LOWER REAR OF ASSEMBLY BY ROTATING ADJUSTING BUSHING NEAREST THE MOTOR. POSITION OTHER BUSHING AGAINST BASE PLATE AND TIGHTEN ALL SCREWS AND LOCK NUT.



3.19 Remote Control Gear Shift Mechanism continued




ARMATURE STOP

REQUIREMENT

WITH ARMATURE IN ITS OPEN POSITION AND THE ARMATURE STOP AGAINST THE CASTING, CLEARANCE BETWEEN GEAR SHIFT LEVER AND STUD ON SLEEVE
 MIN. 0.010 INCH
 MAX. 0.020 INCH

TO ADJUST

HOLD GEAR SHIFT LEVER IN POSITION AND POSITION ARMATURE STOP WITH ITS CLAMP SCREW LOOSENED UNTIL REQUIREMENT IS MET.



GEAR SHIFT MAGNET

REQUIREMENT

THE POLE FACE OF THE ARMATURE SHOULD MEET THE POLE FACE OF THE MAGNET SQUARELY
 TO ADJUST

POSITION ARMATURE WITH GEAR SHIFT LEVER CLAMP SCREW LOOSENED AND POSITION MAGNET BRACKET WITH ITS MOUNTING SCREWS LOOSENED.

CLUTCH STOP LEVER

REQUIREMENT

ARMATURE RESTING AGAINST MAGNET POLE FACE, CLEARANCE BETWEEN GEAR SHIFT LEVER AND THE SLEEVE
 MIN. 0.002 INCH
 MAX. 0.010 INCH

TO ADJUST

POSITION GEAR SHIFT LEVER WITH ITS CLAMP SCREW LOOSENED.

3.20 Perforator Motor

PERFORATOR MOTOR PINION AND DRIVEN GEAR MESH

REQUIREMENT

MIN. 0.004 INCH

MAX. 0.008 INCH


BACKLASH BETWEEN MOTOR PINION AND DRIVEN GEAR AT POINT OF MINIMUM BACKLASH.

TO CHECK

- (1) LOOSEN THE FOUR MOTOR MOUNTING SCREWS.
- (2) LOOSEN THE TWO NUTS WHICH LOCK THE ADJUSTING BUSHINGS AT THE RIGHT END OF THE MOTOR (REAR VIEW)

TO ADJUST

- (1) BACK OFF A FEW TURNS ON THE REAR ADJUSTING BUSHING TO PROVIDE ENOUGH CLEARANCE TO MAKE THE ADJUSTMENT.
- (2) BY MEANS OF THE FRONT ADJUSTING BUSHING, ADJUST THE MOTOR HEIGHT TO MEET REQUIREMENT AT THE PINION AND DRIVEN GEARS. TIGHTEN THE LOCK NUT.
- (3) TURN THE REAR ADJUSTING BUSHING UNTIL IT TOUCHES THE MOUNTING PLATE. TIGHTEN THE LOCK NUT.



3.21 Universal Keyboard Switch

(A) KEYBOARD UNIVERSAL SWITCH

PRELIMINARY REQUIREMENT

CENTERLINE OF INSULATED PORTION OF UNIVERSAL SWITCH ASSEMBLY SHOULD ALIGN WITH CENTERLINE OF CODE BAR LEVER.

TO ADJUST

POSITION UNIVERSAL SWITCH ASSEMBLY LATERALLY ON RETAINER BAR WITH ITS MOUNTING SCREW LOOSENED.

BRACKET MOUNTING SCREW

RETAINER BAR BRACKET

RETAINER BAR

FRONT VIEW

BAR MOUNTING SCREW

CODE BAR LEVER

SWITCH ASSEMBLY

ASSEMBLY MOUNTING SCREW

(B) KEYBOARD UNIVERSAL SWITCH - HORIZONTAL REQUIREMENT

CENTERLINE OF INSULATED PORTION OF UNIVERSAL SWITCH ASSEMBLY SHOULD ALIGN WITH CENTERLINE OF LOWERMOST PORTION OF CODE BAR LEVER.

TO ADJUST

POSITION RETAINER BAR FORWARD OR REARWARD ON ITS BRACKETS WITH ITS MOUNTING SCREWS LOOSENED.

(C) KEYBOARD UNIVERSAL SWITCH - VERTICAL REQUIREMENT

1. CLEARANCE BETWEEN CENTER AND LOWER CONTACT POINTS SHOULD BE MIN. 0.015 INCH --- MAX. 0.025 INCH

TO CHECK

PULL CONTACT FUNCTION LEVER DOWN AGAINST CODE BAR BASKET AT REAR OF BASKET AND FRONT OF CONTACT LEVER TOUCHING CENTER OF CONTACT INSULATOR

TO ADJUST

BEND UPPER CONTACT SPRING

2. CLEARANCE BETWEEN CENTER AND LOWER CONTACT POINTS SHOULD BE AT LEAST 0.010 INCH

TO CHECK

DEPRESS CONTACT OPERATING KEY WITH 16 OZS. PRESSURE.


3. CENTER AND LOWER CONTACTS SHOULD CLOSE WITH SOME OVER-TRAVEL

TO CHECK

FULLY DEPRESS CONTACT OPERATING KEY

TO ADJUST


POSITION COMPLETE ASSEMBLY WITH RIGHT AND LEFT BRACKET MOUNTING SCREWS LOOSENED.



3.22 Answer-Back Mechanism

NOTE 1: ADJUSTMENTS ON THIS PAGE SHOULD BE MADE WITH THE ANSWER-BACK MECHANISM REMOVED FROM THE KEYBOARD.

NOTE 2: FOR "HERE IS" KEYLEVER SWITCH REQUIREMENTS SEE UNIVERSAL KEYBOARD SWITCH ADJUSTMENTS, PAGE 47.



MAGNET YOKE
REQUIREMENT

CLEARANCE BETWEEN LATCHING SURFACES OF
STOP LEVER EXTENSION AND STOP LEVER
LATCH SHOULD BE
MIN. 0.005 INCH
MAX. 0.015 INCH

TO CHECK

HOLD TIP OF STOP LEVER AGAINST STOP BLADE.

TO ADJUST

POSITION MAGNET YOKE WITH ITS TWO
MOUNTING SCREWS LOOSENED.





Figure 2-28 — Answer-Back Mechanism

3.23 Answer-Back Mechanism continued

**STOP LEVER LATCH****(1) REQUIREMENT**

CLEARANCE BETWEEN STOP LEVER AND STOP LEVER LATCH SHOULD BE
 MIN. 0.002 INCH
 MAX. 0.007 INCH

TO CHECK

HOLD ARMATURE AGAINST THE MAGNET CORE AND THE STOP LEVER IN ITS MAXIMUM COUNTER-CLOCKWISE POSITION.

(2) REQUIREMENT

CLEARANCE BETWEEN STOP LEVER AND STOP LEVER LATCH THROUGHOUT A COMPLETE TRAVEL OF THE STOP LEVER
 MIN. 0.002 INCH

TO CHECK

HOLD ARMATURE AGAINST MAGNET CORE.

TO ADJUST

POSITION STOP LEVER LATCH WITH ITS TWO MOUNTING SCREWS LOOSENED.

3.24 Answer-Back Mechanism continued


NOTE: TO FACILITATE MAKING THIS ADJUSTMENT, REMOVE MESSAGE DRUM AND DRIVE PLATE ASSEMBLY FROM MECHANISM.

(B) SENSING LEVER SPRINGS

REQUIREMENT

WITH THE SIGNAL GENERATOR CLUTCH IN STOP POSITION AND THE MESSAGE DRUM REMOVED IT SHOULD REQUIRE MIN. 1/4 OUNCE MAX. 1-1/4 OUNCES TO START EACH SENSING LEVER MOVING.

SENSING LEVERS RESTING ON MOUNTING PLATE




(C) DETENT LEVER SPRING

REQUIREMENT

WITH THE SIGNAL GENERATOR CLUTCH IN STOP POSITION AND THE MESSAGE DRUM REMOVED, IT SHOULD REQUIRE MIN. 22 OUNCES MAX. 26 OUNCES TO START THE DETENT LEVER MOVING.

DETENT LEVER RESTING ON MOUNTING PLATE



(A) CHARACTER GENERATOR MOUNTING PLATE

(1) REQUIREMENT

SENSING LEVERS SHOULD BE CENTERED ON THE FULL WIDTH OF THEIR ASSOCIATED CODE BAR.

(2) REQUIREMENT


CLEARANCE BETWEEN SHOULDERS OF CODE BARS #1 AND #5 AND THEIR ASSOCIATED SENSING LEVERS SHOULD BE MIN. 0.002 INCH MAX. 0.012 INCH

TO ADJUST

POSITION THE MOUNTING PLATE WITH THE THREE MOUNTING SCREWS LOOSENED.

3.25 Answer-Back Mechanism continued

PERFORM THIS ADJUSTMENT BEFORE FINAL INSTALLATION OF MESSAGE DRUM AND DRIVE PLATE ASSEMBLY.



**DRIVE LINK SPRING
REQUIREMENT**

WITH THE SIGNAL GENERATOR CLUTCH IN STOP POSITION, IT SHOULD REQUIRE
MIN. 10 OUNCES
MAX. 15 OUNCES
TO PULL SPRING TO INSTALLED LENGTH.

**DRIVE LINK
REQUIREMENT**

CLEARANCE BETWEEN DRIVE PLATE EXTENSION AND BLOCKING LEVER SHOULD BE
MIN. 0.002 INCH
MAX. 0.007 INCH

TO CHECK

SIGNAL GENERATOR CAM ECCENTRIC AND ARM HOLDING CODE BAR BAIL IN EXTREME RESET POSITION TO THE LEFT.

TO ADJUST

LOOSEN THE TWO ADJUSTING SCREWS AND POSITION THE TWO DRIVE LINKS BY MEANS OF THE ADJUSTING SLOTS.

NOTE: THE STANDARD KEYBOARD ADJUSTMENTS LISTED BELOW SHOULD BE CHECKED DURING INSTALLATION OF THE ANSWER-BACK MECHANISM.

- A. CODE BAR AND CODE LEVER CLEARANCE, PAGE 4.
- B. CODE BAR BAIL, PAGE 11.
- C. CODE BAR BAIL AND NON-REPEAT LEVER CLEARANCE, PAGE 11.
- D. UNIVERSAL BAIL LATCH LEVER, PAGE 13.
- E. UNIVERSAL BAIL EXTENSION, PAGE 13.

3. 26 Answer-Back Mechanism continued

THE FOLLOWING FINAL ADJUSTMENTS FOR THE ANSWER-BACK MECHANISM SHOULD BE MADE AFTER INSTALLATION OF THE MECHANISM ON THE KEYBOARD.

STEPPING PAWL

REQUIREMENT


CLEARANCE BETWEEN STEPPING PAWL AND ANY CODE BLADE SHOULD BE
MIN. 0.018 INCH
MAX. 0.030 INCH

TO CHECK


MESSAGE DRUM IN FULLY DETENTED POSITION.
SIGNAL GENERATOR CAM AND ARM HOLDING CODE BAR BAIL IN EXTREME RESET POSITION TO THE LEFT.

TO ADJUST


LOOSEN LOCK NUT AND POSITION ECCENTRIC STUD SO THAT ITS HIGH POINT IS TOWARD THE TOP.




3.27 Answer-Back Mechanism continued




3. 28 Answer-Back Mechanism continued



(A) BLOCKING LEVER SPRING
 REQUIREMENT
 WITH SIGNAL GENERATOR CLUTCH IN STOP POSITION, UNHOOK BLOCKING LEVER SPRING FROM STOP LEVER.
 MIN. 1 OUNCE
 MAX. 2 OUNCES
 TO PULL SPRING TO INSTALLED LENGTH.




(B) ARMATURE LATCH SPRING
 REQUIREMENT
 WITH SIGNAL GENERATOR CLUTCH IN STOP POSITION, UNHOOK ARMATURE LATCH SPRING FROM SPRING POST ON MAGNET YOKE.
 MIN. 2 OUNCES
 MAX. 4 OUNCES
 TO PULL SPRING TO INSTALLED LENGTH.



(C) MOTOR CONTROL RELAY SWITCH
 REQUIREMENT
 THE SWITCH SHOULD BE IN ITS OPERATED POSITION WHEN THE ARMATURE IS HELD AGAINST THE MAGNET CORE.
 TO ADJUST POSITION SWITCH WITH ITS MOUNTING SCREWS LOOSENED.

3. 29 Answer-Back Mechanism continued
CODING THE MESSAGE DRUM




1. REMOVE MESSAGE DRUM FROM ANSWER BACK ASSEMBLY AND TAKE OUT CODE BLADES AS FOLLOWS: REMOVE DRIVE LINK SPRING ALLOWING DRIVE LINK TO DROP OUT OF ENGAGEMENT WITH STUD ON DRIVE PLATE. LIFT MESSAGE DRUM FROM NOTCHES. DEPRESS STEPPING PAWL EXTENSION AND PULL DRUM OFF SHAFT. REMOVE "O" RING FROM ONE END OF DRUM AND TAKE OUT TWENTY CODE BLADES. IT IS NOT NECESSARY TO TAKE OUT STOP BLADE.

LETTERS	TYPICAL FIG. ARRGT	CODE				
		1	2	3	4	5
A	—	■	■	■	■	■
B	2	■	■	■	■	■
C	3	■	■	■	■	■
D	4	■	■	■	■	■
E	5	■	■	■	■	■
F	6	■	■	■	■	■
G	7	■	■	■	■	■
H	8	■	■	■	■	■
I	9	■	■	■	■	■
J	0	■	■	■	■	■
K	1	■	■	■	■	■
L	2	■	■	■	■	■
M	3	■	■	■	■	■
N	4	■	■	■	■	■
O	5	■	■	■	■	■
P	6	■	■	■	■	■
Q	7	■	■	■	■	■
R	8	■	■	■	■	■
S	BELL	■	■	■	■	■
T	9	■	■	■	■	■
U	0	■	■	■	■	■
V	1	■	■	■	■	■
W	2	■	■	■	■	■
X	3	■	■	■	■	■
Y	4	■	■	■	■	■
Z	5	■	■	■	■	■
CARRIAGE RETURN		■	■	■	■	■
LINE FEED		■	■	■	■	■
LETTERS SHIFT		■	■	■	■	■
FIGURES SHIFT		■	■	■	■	■
SPACE		■	■	■	■	■
BLANK		■	■	■	■	■

2. CODE A BLADE BY BREAKING OFF UNWANTED TINES AT SCORED LINE AT BASE OF EACH TINE. THE FIGURE BELOW INDICATES TINES TO BE REMOVED FOR A PARTICULAR CHARACTER. HOLD EACH BLADE SECURELY NEAR SCORE MARK OF TINE TO BE REMOVED. IN STANDARD 5 LEVEL OPERATION, THE 0 CODE LEVEL TINE IS DISREGARDED.
3. CODE THE DRUM IN A COUNTER-CLOCKWISE DIRECTION STARTING WITH NO. 2 CODE BLADE (ADJACENT TO STOP BLADE). BEGIN MESSAGE WITH "LETTERS" (STOP BLADE) FOLLOWED BY "CARRIAGE RETURN" AND "LINE FEED". END MESSAGE WITH "CARRIAGE RETURN" AND "LINE FEED". THIS LEAVES 16 CHARACTERS AVAILABLE FOR MESSAGE PROPER. CODE ANY UNUSED CHARACTERS WITH "LETTERS" OR "BLANKS", SINCE EACH SLOT POSITION IN DRUM MUST BE OCCUPIED BY A CODE BLADE.
4. INSTALL CODED BLADES IN PROPER SLOTS IN DRUM - INSERT END OF BLADE UNDER REMAINING "O" RING AND ROTATE THE BLADE TOWARD CENTER OF DRUM UNTIL IT IS FULLY SEATED. WHEN ALL THE SLOTS ARE FILLED REPLACE "O" RING REMOVED IN 1. ABOVE
5. APPLY GREASE TO SHAFT OF MESSAGE DRUM. REASSEMBLE MECHANISM REVERSING PROCEDURE OF STEP 1. BE SURE PARTS ARE PROPERLY SEATED. LUBRICATE PER INSTRUCTION IN SECTION 3.


■ — LEAVE TINE
□ — REMOVE TINE



3.30 Answer-Back Mechanism ("Figs D")

NOTE

ADJUSTMENT REQUIREMENTS FOR "FIGS D" ANSWER-BACK OPERATION ARE IDENTICAL TO REQUIREMENTS FOR "FIGS C" OPERATION (SEE PAGES 48 THROUGH 55) EXCEPT FOR THE ADDITIONAL REQUIREMENT GIVEN BELOW.



KEYBOARD LOCK BAIL ECCENTRIC REQUIREMENT

CLEARANCE BETWEEN KEYBOARD LOCK LEVER W/HUB AND KEYBOARD LOCK FUNCTION LEVER SHOULD BE
MIN. SOME --- MAX. 0.006 INCH

TO CHECK

FULLY DEPRESS BOTH "KYBD LOCK" AND "HERE IS" KEYS (HOLD LIGHTLY).

TO ADJUST

LOOSEN LOCK NUT AND POSITION ECCENTRIC WITH ITS HIGH POINT TOWARD FRONT OF KEYBOARD.

3.31 Clutch Trip Delay Mechanism

CLUTCH TRIP DELAY
REQUIREMENT

PLACE KEYBOARD IN K-T POSITION. WITH KEYBOARD IN ITS TRIPPED POSITION AND SIGNAL GENERATOR SHAFT ROTATED SO THAT CLUTCH IS APPROXIMATELY 180 DEGREES FROM ITS LATCHED POSITION, DEPRESS LTRS KEYLEVER. SLOWLY CONTINUE ROTATION OF SIGNAL GENERATOR SHAFT IN CLOCKWISE DIRECTION NOTING GAP BETWEEN NEAREST EDGE OF CLUTCH SHOE LEVER AND CLUTCH STOP LEVER. CODEBAR BAIL SHALL NOT TRIP UNTIL GAP MEASURES


MIN. 3/8 INCH

MAX. 1/2 INCH

TO ADJUST

POSITION BLOCKING LEVER WITH CLAMPING SCREW FRICTION TIGHT, UTILIZING PRY POINTS PROVIDED.

NOTE: IF SIGNAL DISTORTION TEST SET IS AVAILABLE, MINIMUM GAP REQUIREMENT SHALL BE CONSIDERED MET IF 100 WPM SIGNAL GENERATOR STROBE REQUIREMENTS CAN BE MET.


TRIP DELAY TORSION SPRING
REQUIREMENT

WITH KEYBOARD CLUTCH DISENGAGED, APPLY PUSH END OF 8 OZ. SCALE VERTICALLY TO EDGE OF FORMED END OF BLOCKING LEVER.

MIN. 4-1/2 OZS.


MAX. 8 OZS.

TO START BLOCKING LEVER MOVING.




3.32 Auxiliary Contacts

AUXILIARY CONTACTS




(1) REQUIREMENT
 CLUTCH DISENGAGED AND LATCHED, CAM FOLLOWER OFF ITS CAM. CLEARANCE BETWEEN CONTACT POINTS
 MIN. 0.015 INCH
 MAX. 0.025 INCH
 TO ADJUST POSITION SET SCREW WITH LOCK NUT LOOSENED.


(2) REQUIREMENT
 CLUTCH DISENGAGED. CLEARANCE BETWEEN CAM FOLLOWER AND CAM
 MIN. SOME
 MAX. 0.005
 TO ADJUST POSITION MOUNTING BRACKET WITH ITS MOUNTING SCREWS LOOSENED. THIS ADJUSTMENT IS TO BE REFINED WHEN STROBING IS DONE.



(3) REQUIREMENT
 CAM FOLLOWER ON HIGH PART OF CAM
 MIN. 3-1/2 OZS.
 MAX. 4-1/2 OZS.
 TO SEPARATE THE CONTACTS TO ADJUST BEND UPPER CONTACT SPRING




(4) REQUIREMENT
 MIN. 0.010 INCH BETWEEN THE CONTACT GUARD AND THE CONTACT SPRINGS.



(5) REQUIREMENT
 WITH THE CLUTCH DISENGAGED AND LATCHED CLEARANCE BETWEEN THE LOWER EXTENSION OF THE CAM FOLLOWER AND THE INSIDE SURFACE OF THE CLUTCH DISK
 MIN. SOME
 TO ADJUST POSITION THE CONTACT SPRINGS CONTACT GUARD AND CAM FOLLOWER HINGE WITH THEIR MOUNTING SCREWS LOOSENED.

3.33 Letters and Figures Contacts



LETTERS-FIGURES CONTACT

REQUIREMENT

CLUTCH DISENGAGED AND LATCHED THEN LETTERS OR FIGURES KEYLEVER DEPRESSED. LEFT HAND CONTACT GAP

MIN. 0.012 INCH
MAX. 0.018 INCH

TO ADJUST

BEND CONTACT STIFFENER. CHECK BOTH CONTACT ASSEMBLIES.

REQUIREMENT

CLUTCH DISENGAGED AND LATCHED, THEN LETTERS OR FIGURES KEYLEVER DEPRESSED

MIN. 4-1/2 OZS.
MAX. 5-1/2 OZS.


TO SEPARATE CONTACTS

TO ADJUST

BEND SWINGER. RECHECK CONTACT GAPS.

LETTERS OR FIGURES CONTACT ASSEMBLY

RIGHT HAND CONTACT POINTS



(3) REQUIREMENT

CLUTCH DISENGAGED AND LATCHED. THEN ANY KEYLEVER OTHER THAN LETTERS OR FIGURES DEPRESSED. RIGHT CONTACT GAP


MIN. 0.012 INCH
MAX. 0.018 INCH

CHECK BOTH LETTERS OR FIGURES CONTACTS

TO ADJUST

POSITION CONTACT ASSEMBLY WITH ITS BRACKET MOUNTING SCREWS LOOSENED.

CODE BAR EXTENSIONS



(5) REQUIREMENT

CLUTCH DISENGAGED AND LATCHED, THEN ANY KEYLEVER OTHER THAN LETTERS OR FIGURES DEPRESSED.

MIN. 4-1/2 OZS.
MAX. 5-1/2 OZS.

TO SEPARATE LEFT HAND CONTACT POINTS

TO ADJUST

BEND LEFT CONTACT SPRING. CHECK BOTH CONTACT ASSEMBLIES. RECHECK CONTACT GAP.

LEFT CONTACT SPRING

(4) REQUIREMENT

CLUTCH DISENGAGED AND LATCHED, THEN WITH ANY KEYLEVER OTHER THAN LETTERS OR FIGURES DEPRESSED CLEARANCE BETWEEN LEFT CONTACT SPRING AND ITS STIFFENER

MIN. 0.003 INCH

TO ADJUST


REFINE POSITION OF CONTACT ASSEMBLY BRACKET.

LEFT SIDE CONTACT POINTS

SECTION 573-117-700

3.34 Code Reading Contacts (Transmitting)

NOTE: REFER TO SECTION 573-139-700 FOR OTHER ADJUSTMENTS OF CODE READING CONTACTS.



CODE READING CONTACTS

- (1) REQUIREMENT
CLUTCH DISENGAGED AND LATCHED. CLEARANCE
BEWTEEN LEFT SIDE CONTACT POINTS
MIN. 0.030 INCH
MAX. 0.035 INCH
- (2) REQUIREMENT
CLEARANCE BETWEEN THE LOWER SURFACE OF
BELLCRANK AND THE CODE BAR (CHECK NO. 1 AND NO. 5 ONLY)
MIN. 0.050 INCH
MAX. 0.065 INCH
- (3) REQUIREMENT
LOWER SURFACE OF BELLCRANK SHOULD BE
PARALLEL TO THE CODE BAR
TO ADJUST
POSITION THE MOUNTING BRACKET WITH ITS
MOUNTING NUTS LOOSENED.

28 TYPING UNIT

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL.	5	Line Feed and Platen Mechanism	
UNMOUNTED POSITIONS OF TYPING UNIT	6	Left margin (sprocket feed)	73
OPERATING CONDITIONS OF CLUTCHES.	6	Line feed bar bell crank spring.	61, 76
MANUAL SELECTION OF CHARACTERS OR FUNCTIONS.	6	Line feed bar release lever spring	61
VARIABLE FEATURES.	7	Line feed clutch phasing	31
EARLIER DESIGN MECHANISMS	7	Line feed spur gear detent eccentric	61
COMPLETE ADJUSTMENT OF TYPING UNIT	7	Line feed stripper bail spring.	63
2. BASIC UNITS.	8	Paper finger (friction feed)	67
Code Bar Mechanism		Paper finger locking arm spring (sprocket feed).	77
Code bar detent	70	Paper finger or guide bracket (sprocket feed).	75
Code bar detent spring	70	Paper finger or guide bracket latch spring (sprocket feed)	77
Code bar shift lever link bracket.	22	Paper finger or guide bracket shaft spring (sprocket feed).	77
Code bar shift lever drive arm.	21	Paper finger spring (friction feed).	67
Code bar yield spring	70	Paper guide (sprocket feed)	76
Common transfer lever spring	19	Paper pressure bail spring (friction feed)	67
Intermediate arm backstop bracket	20	Paper straightener collar (friction feed)	66
Transfer lever eccentric.	19	Paper straightener lever spring (friction feed)	66
Transfer lever spring.	19	Platen detent bail spring	61
Function Mechanism		Platen end play (sprocket feed).	74
Figs - ltrs shift code bar operating mechanism	38	Pressure roller lever spring (friction feed)	67
Function bar spring	59	Printing hammer stop bracket (sprocket feed).	73
Function contact spring.	68	Printed line (sprocket feed)	74
Function lever spring	59	Right margin (sprocket feed)	73
Function pawl spring.	59	Single-double line feed stripper bail assembly springs.	64
Function reset bail blade.	37	Sprocket pin separation (sprocket feed).	74
Function reset bail spring	37	Sprocket pin spring (sprocket feed)	76
Keyboard lock lever spring	46	Main Shaft and Trip Shaft Mechanisms	
Stripper blade drive cam position	62	Clutch drum position (except selector).	29
Stunt box clip.	60	Clutch latch lever spring (except selector).	23
Unshift-on-space function pawl.	69	Clutch shoe lever.	28

SECTION 573-115-700

CONTENTS	PAGE
Clutch shoe lever spring	29
Clutch shoe spring	29
Clutch trip lever spring.	26
Clutch trip shaft set collars.	25
Code bar clutch cam follower spring .	24
Code bar clutch trip lever	23
Function clutch trip lever	24
Line feed clutch trip lever adjusting screw	27
Line feed clutch trip lever eccentric post	27
Spacing clutch trip lever	26
Trip shaft lever spring	23
Type box clutch trip lever	28
Type box clutch trip lever eccentric post	27

Positioning Mechanism

Breaker slide bail spring.	32
Decelerating slide spring.	49
Horizontal positioning drive linkage. .	40
Horizontal positioning drive linkage spring	40
Horizontal positioning lock lever spring	32
Horizontal stop slide spring.	66
Left vertical positioning lever eccentric stud	34
Reversing slide adjusting stud	39
Reversing slide brackets.	39
Reversing slide detent spring.	39
Right vertical positioning lever eccentric stud	33
Rocker shaft bracket eccentric stud. .	32
Rocker shaft left bracket.	31
Shift linkage	52
Shift linkage spring.	52
Type box position (sprocket feed) . . .	72
Vertical positioning lever spring. . . .	33
Vertical positioning lock lever	41
Vertical positioning lock lever spring	34

Printing Mechanism

Printing arm	54
Printing carriage lower roller	50
Printing carriage position	51
Printing hammer bearing stud	51
Printing hammer operating bail latch spring.	53
Printing hammer operating bail spring	53
Printing hammer plunger spring.	53
Printing hammer stop bracket	54

CONTENTS	PAGE
Printing hammer yield spring.	53
Printing track	53
Ribbon feed lever bracket	57
Ribbon feed lever spring	57
Ribbon lever spring	58
Ribbon ratchet wheel friction spring	57
Ribbon reverse detent.	56
Ribbon reverse detent lever spring . .	56
Ribbon reverse spur gear	56
Ribbon tension spring	58
Type box alignment	55
Type box carriage roller arm spring	50
Type pallet spring	54

Selector Mechanism

Marking lock lever spring	14
Push lever reset bail spring.	16
Range finder knob phasing	17
Receiving margin for dual speed operation (60 and 100 wpm)	18
Selector armature	8, 13
Selector armature downstop bracket .	13
Selector armature spring (500 ma selector coils).	11
Selector armature spring (double button)	11, 12
Selector armature spring (single button)	11, 12
Selector cam lubricator.	20
Selector clutch drum.	15
Selector clutch latch lever spring . . .	16
Selector clutch stop arm	17
Selector lever spring	15
Selector magnet bracket (magnets energized)	9
Selector magnet bracket - vertical adjustment.	10
Selector push lever spring.	15
Selector receiving margin	18
Spacing lock lever spring.	16
Start lever spring.	14

Spacing Mechanism

Automatic CR-LF bell crank spring. .	47
Carriage draw wire rope.	42
Carriage return latch bail	44
Carriage return latch bail spring . . .	44
Carriage return lever	45
Carriage return spring	43
Dashpot vent screw.	46
Left margin.	47
Lower draw wire rope pulley bail spring	42

CONTENTS	PAGE	CONTENTS	PAGE
Margin indicator lamp	71	Intermediate bail spring	80
Oscillating rail slide position	35	Latch bail adjusting plate	80
Right margin	48	Operating lever adjusting plate	79
Right margin with automatic carriage return-line feed ring	65	Operating lever cam arm spring	81
Spacing cutout transfer bail spring	48	Operating lever slide arm	79
Spacing feed pawl release link spring	43	Operating lever slide arm spring	79
Spacing feed pawl spring	35	Right margin	82
Spacing gear clearance	30	Space suppression by-pass spring	82
Spacing gear phasing	30	Spacing clutch trip lever	78
Spacing suppression bail spring	63	Spacing cut-out transfer bail set collar	81
Spacing trip lever bail cam plate	36	Tabulator pawl (preliminary)	83
Spacing trip lever bail spring	36	Tabulator pawl-horizontal (final)	85
Spacing trip lever spring	36	Tabulator pawl-vertical (final)	84
Transfer slide spring	46	Tabulator pawl spring	84
3. VARIABLE FEATURES	78	Tabulator stop settings	86
Answer-Back Mechanism		Transmitter control contact gap	87
"Figures" stunt box contact	98	Transmitter control contact spring	87
Continuous Spacing Mechanism		Trip lever arm latch bail	80
Carriage return lever	101	Trip lever arm latch bail spring	80
Function clutch trip lever	100	Letters-Figures Code Bar Shift Magnet Mechanism	
Reset bail operating spring	101	Shift magnet armature	118
Solenoid plunger spring	100	Shift magnet armature return spring	118
Suppression bail adjusting bracket	101	Shift magnet yoke	118
Dc Magnet Operated Print Suppression Mechanism		Shift code bar return spring	118
Armature extension clearance	116	Local Back Space Mechanism	
Armature extension overtravel	116	Camming bail spring	93
Blocking bail	91	Camming bail stop arm	93
Blocking bail extension clearance	116	Page Feed-Out Mechanism	
Type box clutch suppression arm	91	Blocking arm	89
Type box clutch trip lever	116	Blocking arm spring	89
Form Alignment Switch Mechanism		Indexing disk	88
Form alignment switch	115	Mounting bracket	88
Form alignment switch spring	115	Page feed-out gear play	88
Form feed-out adjustment	115	Pointer	89
Form Feed-Out Mechanism		Switch operating arm (transmitter control)	88
Form feed-out torsion spring	119	Paper-Out Alarm Mechanism	
Horizontal Tabulator Mechanism		Switch bracket spring	102
Blocking lever spring	84	Switch operating lever	102
Cam arm stripper bail	81	Switch position	102
Clutch trip lever spring	78	Print Suppression Mechanism	
Horizontal tabulator slide arm spring	81	Suppression code bar mechanism	99
		Zero code bar shift mechanism	99

SECTION 573-115-700

CONTENTS	PAGE
Print Suppression and Off-Line Stunt Shift Control Mechanism	
Blocking bail	91
Print suppression magnet armature return spring	117
Suppression code bar position	117
Type box clutch suppression arm	91
Type box clutch trip lever	117
Reverse Line Feed Mechanism	
Line feed bar bell crank spring	98
Line feed bar release lever spring	96
Line feed bar springs	97
Line feed clutch spur gear	95
Line feed spur gear detent eccentric	96
Platen detent bail spring	96
Reverse line feed slide link spring	94
Reverse line feed slide link stop bracket	94
Selective Calling Mechanism	
Automatic carriage return-line feed blocking slide spring 92	
Blocking bail	91
Code bar shift mechanism	90
Condition code (zero) code bar shift mechanism	90
Condition code shift fork spring	92
Off line shift solenoid bracket assembly	90
Off line stunt shift solenoid spring	91
Print suppressor code bar spring	90
Type box clutch suppression arm	91
Type box clutch trip lever	90
Two Color Ribbon Mechanism	
Armature spring (left and right)	120
Operational requirement - ribbon magnet bracket (final)	121
Ribbon guide lever spring (left and right)	121
Ribbon magnet bracket (left and right) (preliminary)	120
Ribbon magnet hinge bracket (left and right) (final)	120
Ribbon magnet hinge bracket (left and right) (preliminary)	120
Ribbon reversing lever spring (left and right)	121
Ribbon roller bail spring (left and right)	121

CONTENTS	PAGE
Universal Contact (Selector) Mechanism	
Contact arm spring	109
Contact block	109
Contact drive arm position	109
Contact mounting bracket	109
Universal Contact (Stunt Box) Mechanism	
Contact	110
Contact bracket and drive cam	112
Contact bracket and drive cam position	113
Contact bracket and drive cam position (100 wpm)	113
Contact spring (two springs)	110
General application timing - final (using DXD or similar equipment)	113
General requirements after timing adjustments	114
Latch lever spring	111
Normally closed contacts (100 wpm for 83B2 switching system)	113
Normally closed contacts (100 wpm used in Delta and United Airlines System)	114
Normally open contact gap	110
Normally open contact gap (100 wpm)	113
Special adjustments (for 100 wpm)	113
Swinger spring	110
Trip cam	111, 113
Vertical Tabulation and Transmitter-Distributor Control Mechanism	
Blocking lever	104
Blocking lever spring	106
Form-out pawl spring	108
Indexing disk	103
Line feed clutch trip lever spring	108
Mounting bracket	103
Page feed-out gear play	103
Page feed-out index plate position	107
Pointer	104
Stunt box switch spring	108
Switch contact pressure	104
Switch contacts for transfer type control switch (transmitter control only)	107
Tabulation index plate position	106
Tabulator bail spring	108
Transmitter control switch for single-contact type control (transmitter control only)	106

CONTENTS	PAGE
Transmitter control switch - transfer type contacts (transmitter control only)	105
Vertical tabulator slide retainer	103
4. EARLIER DESIGN MECHANISMS	122
BASIC UNITS.	122
Code Bar Mechanism	
Code bar shift lever drive arm	124
Code bar shift lever link guide bracket	125
Function Mechanism	
Bell or motor stop function contact	140
Figs-ltrs shift code bar operating mechanism	129
Function contact spring	141
Function reset bail blade	130
Function stripper blade arms	138
Line Feed Mechanism and Platen Mechanism	
Single-double line feed lever	139
Main Shaft and Trip Shaft Mechanisms	
Anti-deflection plate	126
Clutch trip lever spring	127
Clutch trip shaft set collars	126
Spacing clutch trip lever	127
Positioning Mechanism	
Horizontal positioning drive linkage	131, 132
Horizontal positioning drive linkage spring	131, 132
Shift linkage spring	135
Printing Mechanism	
Printing arm	136
Printing hammer stop bracket	136
Ribbon reverse detent	137
Ribbon reverse detent lever spring	137
Ribbon reverse spur gear	137
Type box carriage roller	135
Type pallet spring	136
Selector Mechanism	
Bail lever guide	122
Selector armature	123
Start lever spring	122

CONTENTS	PAGE
Spacing Mechanism	
Automatic CR-LF bell crank spring	133
Automatic carriage return and line feed arm	138
Decelerating slide bell crank spring	134
Left margin	133
Margin indicator lamp	142
Oscillating rail slide position	128
Printing carriage position	133
Right margin	134
Spacing cutout transfer bail spring	134
Spacing feed pawl spring	128
VARIABLE FEATURES	143
Horizontal Tabulator Mechanism	
Cam plate stripper bail	145
Columnar tabulator stops	148
Horizontal tabulator slide arm spring	145
Operating lever adjusting plate	143
Operating lever cam plate spring	145
Operating lever extension link spring	143
Operating lever slide arm	143
Pawl mounting arm operating range (final)	148
Pawl mounting arm operating range (preliminary)	147
Right margin	146
Spacing cut-out transfer bail set collar	145
Space suppression by-pass spring	146
Tabulator pawl spring	146
Tabulator shaft mounting brackets	146
Tabulator shaft spring	143
Tabulator stop setting (not illustrated)	148
Trip arm latch bail	144
Trip arm latch bail adjusting plate	144
Trip arm latch bail spring	144
Paper-Out Alarm Mechanism	
Bell crank follower	149
Bell crank follower spring	149

1. GENERAL

1.01 This section is reissued: to incorporate adjusting information for the Selector Armature Downstop, and the Selector Armature Vertical Adjustment; to rearrange the text matter and assembly grouping to conform to the new

standard format. Since this is a general revision, marginal arrows are omitted.

1.02 The adjustments in this section are divided into basic units, variable features, and earlier design mechanisms. The basic units consist of the friction feed and sprocket feed typing units; the adjustments are sub-divided into major mechanisms most of which are common to both units. All other mechanisms which are of an optional nature to create variations of the 28 typing unit, appear under variable features. When applicable, earlier design mechanisms for the basic units and variable features are cross referenced in their adjustment text.

Note: Remove power from unit before making adjustments.

1.03 The adjustments for the basic units are arranged in a sequence that would be followed if a complete readjustment were undertaken. After an adjustment has been completed, be sure to tighten any nuts or screws that may have been loosened to facilitate the adjustment. If a part that is mounted on shims is to be removed, the number of shims used at each mounting screw should be noted so that the same shim pile up can be replaced when the part is re-mounted.

1.04 The spring tensions given in this section are indicated values and should be checked with proper spring scales in the position indicated. The adjusting illustrations, in addition to indicating the adjusting tolerances, positions of moving parts, and spring tensions, also show the angle at which the scale should be applied when measuring spring tensions.

1.05 Tools and spring scales required to perform the adjustments are not supplied as part of the equipment but are listed separately in Teletype Bulletin 1124B.

1.06 References made to left or right, up or down, and front or rear apply to the typing unit in its normal operating position as viewed by the operator facing the unit.

1.07 Where instructions call for the removal of parts or subassemblies, refer to appropriate section, covering Disassembly and Reassembly.

UNMOUNTED POSITIONS OF TYPING UNIT

1.08 The typing unit may be safely placed in any one of three positions for servicing:

- (1) In an upright position, and resting on all four feet.
- (2) Tilted backward, and resting on the two rear feet and rear points of side frames.
- (3) Bottom upwards, and resting on two upper points on each side frame.

In addition, the typing unit may be placed on either end by using the TP159358 modification kit (not supplied with the unit).

OPERATING CONDITIONS OF CLUTCHES

1.09 When a requirement calls for a clutch to be disengaged, the clutch shoe lever must be fully latched so that the clutch shoes are disengaged from the clutch drum. To become fully latched the trip lever must engage the clutch shoe lever, and the clutch disc must rotate far enough to permit the latch lever to fall into the notch on the clutch disc. The disengaged condition is illustrated in the upper figure of Par. 2.21. When engaged, the clutch shoe lever is unlatched and the clutch shoes are wedged against the clutch drum.

Note: When rotating the main shaft of the typing unit by hand, the clutches do not fully disengage upon reaching their stop positions. In order to relieve the drag on the clutches and permit the main shaft to rotate freely, apply pressure to the stop lug on each clutch disc with a screwdriver until each latch lever falls into its notch on its clutch disc. Thus each internal expansion clutch becomes fully disengaged. This procedure should be followed before placing the typing unit on the base and switching on the power.

MANUAL SELECTION OF CHARACTERS OR FUNCTIONS

1.10 To manually operate the typing unit while removed from the keyboard or base, hold the selector magnet armature (Par. 2.01) against the pole pieces with an armature clip. Rotate the main shaft in a counterclockwise direction (handwheel listed in Bulletin 1124B) to bring all clutches to their disengaged position.

Note: The armature clip is attached to the armature by carefully inserting the flat formed end of the clip over the top of the armature and between the pole pieces, and hooking the extruded projection under the edge of the armature. The top end of the clip

should then be hooked over the top of the selector coil terminal (bakelite) guard. The spring tension of the clip will hold the armature in the marking (attracted) position.

1.11 Fully disengage all clutches as described in the note following Par. 1.09. Release the armature momentarily to permit the selector clutch to engage. Turn the main shaft slowly until the no. 5 selector lever has just moved to the peak of its cam. Strip from the selector levers all push levers which are spacing in the code combination that is being selected. It should be noted that selector levers (Par. 2.12) move in succession, starting with the inner (no. 1). Continue to rotate the main shaft until all operations initiated by the selector mechanism clear the typing unit.

VARIABLE FEATURES

1.12 In addition to the basic unit adjustments, covered in Part 2, adjustments for a number of variable features appear in Part 3. Where adjustments of these variable features affect the adjustment sequence, cross reference information has been included in Part 2. Variable feature adjustments which do not affect the adjusting sequence, may be done at any time during the adjusting procedure.

EARLIER DESIGN MECHANISMS

1.13 Parts 2 and 3 contain illustrations and adjusting procedures for mechanisms currently being manufactured. Illustrations and adjusting procedures for mechanisms of earlier design are located in Part 4. Where a new mechanism has replaced a mechanism of earlier design, reference has been made in Parts 2 and 3 to the corresponding mechanism in Part 4.

COMPLETE ADJUSTMENT OF TYPING UNIT

1.14 When making a complete adjustment of the typing unit, the following conditioning operations should be performed to prevent damage:


- (a) Loosen the clamp screw on the code bar shift lever drive arm (Par. 2.15).
- (b) Move the right and left vertical positioning lever eccentric studs (Par. 2.28 and 2.29) in the rocker shaft brackets to their lowest position.
- (c) Loosen the two bearing stud mounting screws and two connecting strip clamp screws in the horizontal positioning drive linkage (Par. 2.35).
- (d) Loosen the clamp screws and move the reversing slide brackets to their uppermost position (Par. 2.34).
- (e) Loosen the function reset bail blade mounting screws (Par. 2.32).
- (f) For units equipped with two-stop function clutches: Loosen the shoulder bushings on each function stripper blade arm and move stripper blade and arms to their lowest positions (Par. 4.18).
- (g) Loosen the carriage return lever clamp screw (Par. 2.40).
- (h) Loosen the clamp screws in the oscillating rail slide (Par. 2.30).
- (i) Loosen the reversing slide adjusting stud (Par. 2.34).
- (j) Loosen the clamp nuts on the shift code bar guide plates (Par. 2.33).

2. BASIC UNITS

2.01 Selector Mechanism


NOTE

TO FACILITATE MAKING THE FOLLOWING ADJUSTMENTS, REMOVE THE RANGE FINDER AND SELECTOR MAGNET ASSEMBLIES. TO INSURE BETTER OPERATION, PULL A PIECE OF KS BOND PAPER BETWEEN THE ARMATURE AND THE POLE PIECES TO REMOVE ANY OIL OR FOREIGN MATTER THAT MAY BE PRESENT. MAKE CERTAIN THAT NO LINT OR PIECES OF PAPER REMAIN BETWEEN THE POLE PIECES AND ARMATURE.



2.02 Selector Mechanism (Cont.)

NOTE
THE APPROPRIATE PRELIMINARY SELECTOR
ARMATURE SPRING TENSION ADJUSTMENT MUST
BE MADE PRIOR TO THE SELECTOR MAGNET BRACKET
ADJUSTMENT.



SELECTOR MAGNET BRACKET (MAGNETS ENERGIZED)

(1) REQUIREMENT --- SPACING LOCK LEVER ON EACH HIGH PART OF CAM. ARMATURE IN CONTACT WITH POLE PIECE. CLEARANCE BETWEEN END OF ARMATURE EXTENSION AND SHOULDER ON SPACING LOCK LEVER.

MIN. 0.020 INCH ----- MAX. 0.035 INCH

TO ADJUST --- LOOSEN TWO MAGNET BRACKET MOUNTING SCREWS AND ADJUSTING LINK CLAMP SCREW. POSITION MAGNET BRACKET BY MEANS OF ADJUSTING LINK AND TIGHTEN LINK CLAMP SCREW ONLY.

(2) REQUIREMENT --- SPACING LOCK LEVER ON EACH HIGH PART OF CAM. ARMATURE IN CONTACT WITH POLE PIECE. SOME CLEARANCE BETWEEN UPPER SURFACE OF ARMATURE EXTENSION AND LOWER SURFACE OF SPACING LOCK LEVER WHEN LOCK LEVER IS HELD DOWNWARD.

MAX. 0.003 INCH

TO ADJUST --- POSITION UPPER END OF MAGNET BRACKET. TIGHTEN TWO MAGNET BRACKET MOUNTING SCREWS. RECHECK REQUIREMENT (1).

2.03 Selector Mechanism (Cont.)

CAUTION

BEFORE PROCEEDING WITH THE SELECTOR ARMATURE SPRING ADJUSTMENT, THE TYPE OF ARMATURE (ONE ANTIFREEZE BUTTON OR TWO ANTIFREEZE BUTTONS) MUST BE KNOWN. EXCESSIVE TENSION ON, OR THE MISHANDLING OF A TWO BUTTON ARMATURE CAN DAMAGE THE THIN LEAF SPRING ATTACHED TO THE PIVOT END. IF REMOVAL FOR EXAMINATION IS NECESSARY, DISASSEMBLE AS FOLLOWS:

- (1) DISCONNECT ARMATURE SPRING.
- (2) REMOVE ARMATURE MOUNTING SCREWS.
- (3) WITHDRAW ARMATURE FROM SELECTOR.


REASSEMBLE AND RECHECK THE FOLLOWING ADJUSTMENTS:

- SELECTOR ARMATURE
- SELECTOR ARMATURE DOWNSTOP BRACKET
- SELECTOR MAGNET BRACKET

SELECTOR MAGNET BRACKET - VERTICAL ADJUSTMENT

(3) REQUIREMENT

MARKING LOCK LEVER ON LOW PART OF CAM. ARM - ATURE IN CONTACT WITH FRONT POLE PIECE (MAGNET ENERGIZED). THERE SHOULD BE SOME CLEARANCE BETWEEN LOWER SURFACE OF ARM- ATURE EXTENSION AND UPPER SURFACE OF MARKING LOCK LEVER. GAUGE BY EYE.



TO ADJUST WITH MOUNTING SCREW LOOSENED POSITION UPPER END OF MAGNET BRACKET BY MEANS OF PRY POINT. RECHECK REQUIREMENTS (1) AND (2).

2.04 Selector Mechanism (Cont.)

SELECTOR ARMATURE SPRING (500 MA SELECTOR COILS
REFER TO PAR. 2.05 USING THE FOLLOWING:

SINGLE BUTTON ARMATURE

500 MA; MIN 4-1/2 OZS --- MAX 5-1/2 OZS

DOUBLE BUTTON ARMATURE

500 MA; APPROXIMATELY --- 1-1/8 OZ
TO PULL REAR BUTTON AGAINST ITS POLE PIECE

SECTION 573-115-700


2.05 Selector Mechanism (Cont.)

SELECTOR ARMATURE SPRING (FOR UNITS WITH SINGLE ANTI-FREEZE BUTTON ON SELECTOR ARMATURE)
 REQUIREMENT --- (PRELIMINARY) WITH START LEVER, MARKING AND SPACING LOCK LEVERS ON HIGH PART OF THEIR CAMS, HOOK SCALE UNDER END OF ARMATURE EXTENSION (HOLD AS NEARLY VERTICAL AS POSSIBLE). IT SHOULD REQUIRE

- (a) MIN. 1-1/2 OZS. ----- MAX. 2 OZS. FOR 20 MA OPERATION.
- (b) MIN. 2-1/2 OZS. ----- MAX. 3 OZS. FOR 60 MA OPERATION.

TO PULL ARMATURE TO MARKING POSITION.
 TO ADJUST --- POSITION ADJUSTING NUT.

REQUIREMENT --- (FINAL) REFER TO SELECTOR RECEIVING MARGIN PAR. 2.11




SELECTOR ARMATURE SPRING (FOR UNITS WITH TWO ANTI-FREEZE BUTTONS ON SELECTOR ARMATURE)
 REQUIREMENT --- (PRELIMINARY) WITH START LEVER, MARKING AND SPACING LOCK LEVERS ON HIGH PART OF THEIR CAMS, HOOK SCALE UNDER END OF ARMATURE EXTENSION (HOLD AS NEARLY VERTICAL AS POSSIBLE). IT SHOULD REQUIRE

<u>0.020 AMPERES</u>	<u>0.030 AMPERES</u>	<u>0.060 AMPERES</u>
14 GRAMS	18 GRAMS	21 GRAMS

TO PULL REAR BUTTON AGAINST ITS POLE PIECE
 TO ADJUST --- POSITION ADJUSTING NUT.


REQUIREMENT --- (FINAL) WHEN A DISTORTION TEST SET IS AVAILABLE, REFINE SELECTOR ARMATURE SPRING ADJUSTMENT TO MEET SELECTOR RECEIVING MARGIN PAR. 2.11. NOTE --- WITH SELECTOR MAGNETS ENERGIZED, FRONT ANTI-FREEZE BUTTON MUST BE IN CONTACT WITH ITS MAGNET CORE.



2.06 Selector Mechanism (Cont.)

NOTE

TO FACILITATE MAKING THE FOLLOWING ADJUSTMENTS, REMOVE THE RANGE FINDER ASSEMBLY AND SELECTOR MAGNET ASSEMBLY. TO INSURE BETTER OPERATION, PULL A PIECE OF BOND PAPER BETWEEN THE ARMATURE AND THE POLE PIECES TO REMOVE ANY OIL OR FOREIGN MATTER THAT MAY BE PRESENT. MAKE CERTAIN THAT NO LINT OR PIECES OF PAPER REMAIN BETWEEN THE POLE PIECES AND THE ARMATURE.



SELECTOR ARMATURE


NOTE

THESE REQUIREMENTS NEED NOT BE MADE NOR CHECKED IF THE SELECTOR MAGNET BRACKET AND RECEIVING MARGIN REQUIREMENTS ARE MET.

- (1) REQUIREMENT
CLEARANCE
MIN. 0.025 INCH
MAX. 0.045 INCH
BETWEEN ARMATURE CLAMP STRIP AND
MAGNET BRACKET CASTING.
- (2) REQUIREMENT
OUTER EDGE OF ARMATURE SHOULD BE FLUSH WITHIN 0.015 INCH
WITH OUTER EDGE OF POLE PIECES.
- (3) REQUIREMENT
START LEVER SHALL DROP FREELY INTO ARMATURE EXTENSION SLOT.

TO ADJUST

POSITION ARMATURE SPRING ADJUSTING NUT TO HOLD ARMATURE FIRMLY AGAINST PIVOT EDGE OF CASTING. POSITION ARMATURE WITH MOUNTING SCREWS LOOSENED.



REQUIREMENT

REMOVE OIL SHIELD. WITH MAGNET DE-ENERGIZED, LOCK LEVERS ON HIGH PART OF THEIR CAM, AND ARMATURE RESTING AGAINST ITS DOWNSTOP, CLEARANCE BETWEEN END OF ARMATURE AND LEFT EDGE OF LEFT POLE PIECE
MIN. 0.025 INCH MAX. 0.030 INCH.

TO ADJUST


POSITION DOWNSTOP BRACKET WITH MOUNTING SCREW LOOSENED. REPLACE OIL SHIELD AND CHECK OIL SHIELD ADJUSTMENT.

2.07 Selector Mechanism (Cont.)

MARKING LOCK LEVER SPRING

REQUIREMENT --- LETTERS COMBINATION SELECTED, ROTATE MAIN SHAFT UNTIL SELECTOR CLUTCH IS DISENGAGED. SCALE APPLIED TO LOWER EXTENSION OF LOCK LEVER MIN. 1-1/2 OZS. ----- MAX. 3 OZS. TO START MARKING LOCK LEVER MOVING.


NOTE FOR BELL SERVICE ONLY
WHEN CHECKING UNITS WITH SINGLE BUTTON ARMATURE, SIGNAL LINE SHALL BE SHUNTED BY A TWX SWITCHBOARD SIMULATOR. SIMULATOR SHALL NOT BE USED WITH UNITS EMPLOYING THE TWO BUTTON ARMATURE





START LEVER SPRING

REQUIREMENT --- WITH LATCH LEVER SPRING UNHOOKED, STOP ARM BAIL IN THE INDENT OF ITS CAM AND RANGE SCALE SET AT 60, IT SHOULD REQUIRE MIN. 2-1/2 OZS. ----- MAX. 4-1/2 OZS. TO START STOP ARM MOVING.

NOTE FOR EARLIER DESIGN SEE PAR. 4.01




2.08 Selector Mechanism (Cont.)



TO ADJUST POSITION CLUTCH DRUM WITH MOUNTING SCREW LOOSENED.

2.09 Selector Mechanism (Cont.)



2.10 Selector Mechanism (Cont.)


NOTE: REPLACE RANGE FINDER AND SELECTOR MAGNET ASSEMBLY

(A) RANGE FINDER KNOB PHASING
REQUIREMENT

WITH RANGE FINDER KNOB TURNED TO EITHER END OF RACK, ZERO MARK ON SCALE SHOULD BE WITHIN 3 POINTS OF SCRIBED LINE ON RANGE FINDER PLATE.

TO ADJUST

REMOVE MOUNTING NUT, DISENGAGE KNOB FROM RACK AND POSITION KNOB. RE-ENGAGE KNOB WITH RACK AND REPLACE MOUNTING NUT.


(B) SELECTOR CLUTCH STOP ARM
REQUIREMENT

RANGE SCALE SET AT 60. SELECTOR CLUTCH DISENGAGED. ARMATURE IN MARKING POSITION. CLUTCH STOP ARM SHOULD ENGAGE CLUTCH SHOE LEVER BY APPROXIMATELY FULL THICKNESS OF SHOE LEVER.

TO ADJUST

POSITION STOP ARM ON STOP ARM BAIL WITH CLAMP SCREW LOOSENED.

2.11 Selector Mechanism (Cont.)



SELECTOR RECEIVING MARGIN

REQUIREMENT (FOR UNITS EMPLOYING ARMATURE WITH ONE ANTI-FREEZE BUTTON) WHEN A SIGNAL DISTORTION TEST SET IS USED FOR DETERMINING THE RECEIVING MARGINS OF THE SELECTOR, AND WHERE THE CONDITION OF THE COMPONENTS IS EQUIVALENT TO THAT OF NEW EQUIPMENT, THE RANGE AND DISTORTION TOLERANCES BELOW SHOULD BE MET.

REQUIREMENT (FOR UNITS EMPLOYING ARMATURE WITH TWO ANTI-FREEZE BUTTONS) WHEN A DISTORTION TEST SET IS AVAILABLE, THE SELECTOR ARMATURE SPRING TENSION SHOULD BE REFINED, IF NECESSARY, TO MEET THE SELECTOR RECEIVING MARGINS. THE FRONT ANTI-FREEZE BUTTON MUST CONTACT THE MAGNET CORE WHEN THE MAGNET COILS ARE ENERGIZED.

SELECTOR RECEIVING MARGIN MINIMUM REQUIREMENTS

CURRENT	SPEED WPM	POINTS RANGE (ZERO DISTORTION)	PERCENT MARKING AND SPACING BIAS TOLERATED	END DISTORTION TOLERATED (SCALE SET AT BIAS OPTIMUM)
0.060 AMP. (WINDINGS PARALLEL)	60 75 100	72	40	35
0.020 AMP. (WINDINGS SERIES)	60 75	72	40	35

TO ADJUST: REFINE THE SELECTOR ARMATURE SPRING (SEE PAR. 2.04 and 2.05).

RECEIVING MARGIN FOR DUAL SPEED OPERATION (60 AND 100 WPM)

REQUIREMENT

WITH RANGE SCALE SET AT COMMON OPTIMUM SETTING FOR DUAL SPEED OPERATION, THE PAGE PRINTER SHOULD ACCEPT SIGNALS WITH 35% BIAS AND END DISTORTION WHEN OPERATED AT 60 OR 100 WPM.

TO ADJUST

1. BIAS SELECTOR BETWEEN LIMITS OF 0% TO -7% INTERNAL BIAS AT 100 WPM. (DO NOT READJUST FOR 60 WPM).

2. OBTAIN RECEIVING MARGINS AT 60 AND 100 WPM.


3. CALCULATE COMMON OPTIMUM BIAS SETTING AS FOLLOWS: $O_c = \frac{UMB_{100} + LSB_{60}}{2}$ WHERE

O_c = COMMON OPTIMUM BIAS SETTING

UMB_{100} = UPPER ORIENT LIMIT MARKING BIAS AT 100 WPM



LSB_{60} = LOWER ORIENT LIMIT SPACING BIAS AT 60 WPM

2.12 Codebar Mechanism



SECTION 573-115-700

2.13 Codebar Mechanism (Cont.)




REQUIREMENT

PUSH LEVERS NOT SELECTED. ALL CODE BAR SHIFT BARS TO THE RIGHT. SELECTOR CLUTCH DISENGAGED. CODE BAR SHIFT LEVER LINK IN LOWERMOST POSITION. CLEARANCE BETWEEN FRONT CODE BAR SHIFT LEVER AND INNER STEP OF CODE BAR SHIFT BAR FARTHEST FROM FRONT CODE BAR SHIFT LEVER

MIN. 0.010 INCH
MAX. 0.025 INCH
WHEN PLAY IN PARTS IS TAKEN UP FOR MAXIMUM CLEARANCE.

TO ADJUST

POSITION BACKSTOP BRACKET WITH ITS TWO CLAMP SCREWS LOOSENED.



2.14 Selector Mechanism (Cont.)

(B)
SELECTOR CAM LUBRICATOR

REQUIREMENT

THE LUBRICATOR TUBE SHOULD CLEAR THE HIGH PART OF THE LOCK LEVER CAM

MIN. 0.020 INCH


THE HIGH PART OF THE SELECTOR LEVER CAMS SHOULD TOUCH THE LUBRICATOR WICK, BUT SHOULD NOT RAISE IT MORE THAN 1/32 INCH.

NOTE: THERE SHOULD BE SOME CLEARANCE BETWEEN THE MARKING LOCK LEVER SPRING AND THE RESERVOIR.

TO ADJUST

POSITION THE LUBRICATOR BRACKET WITH ITS MOUNTING SCREWS LOOSENED.

2.15 Codebar Mechanism (Cont.)



NOTE: FOR EARLIER DESIGN SEE PAR. 4.03

2.16 Codebar Mechanism (Cont.)

CODE BAR SHIFT LEVER LINK BRACKET

REQUIREMENT

MOTION OF FRONT AND REAR CODE BAR SHIFT LEVERS SHOULD BE EQUALIZED WITH RESPECT TO CODE BAR TRAVEL.

TO CHECK (FRONT)



SELECT BLANK COMBINATION AND ROTATE MAINSHAFT UNTIL CODE BAR SHIFT LEVER LINK REACHES HIGHEST TRAVEL. TAKE UP PLAY FOR MAXIMUM CLEARANCE. CLEARANCE BETWEEN FRONT CODE BAR SHIFT LEVER AND SHOULDER ON NEAREST CODE BAR SHIFT BAR
 MIN. 0.002 INCH
 MAX. 0.025 INCH

TO CHECK (REAR)

SELECT LETTERS COMBINATION. CHECK CLEARANCE BETWEEN REAR CODE BAR SHIFT LEVER AND SHOULDER ON NEAREST CODE BAR SHIFT BAR IN SAME WAY.
 MIN. 0.002 INCH
 MAX. 0.025 INCH


TO ADJUST

POSITION ADJUSTING PLATES (FRONT AND REAR) WITH CLAMP SCREWS LOOSENED.




NOTE: FOR EARLIER DESIGN SEE PAR. 4.04

2.17 Main Shaft and Trip Shaft Mechanisms





REQUIREMENT
 CLUTCH TURNED TO STOP POSITION BUT WITH LATCH LEVER NOT LATCHED.
 MIN. 5 OZS.
 MAX. 7-1/4 OZS.
 TO MOVE LATCH LEVER FROM LUG. THIS REQUIREMENT APPLIES TO CODE BAR CLUTCH, FUNCTION CLUTCH, SPACING CLUTCH, LINE FEED CLUTCH, AND TYPE BOX CLUTCH.

REQUIREMENT
 SELECTOR CLUTCH AND CODE BAR CLUTCH DISENGAGED. CODE BAR CLUTCH TRIP LEVER SHOULD ENGAGE CLUTCH SHOE LEVER BY FULL THICKNESS OF SHOE LEVER AND HAVE SOME END PLAY
 MAX. 0.006 INCH
 TO ADJUST POSITION TRIP LEVER ON ITS SHAFT WITH CLAMP SCREW LOOSENED.



REQUIREMENT
 TRIP SHAFT LEVER ON LOW PART OF CAM. CODE BAR CLUTCH ENGAGED. ROTATE 1/4 TURN.
 MIN. 1 OZ.
 MAX. 2 OZS.
 TO START LEVER MOVING.

2. 18 Main Shaft and Trip Shaft Mechanisms (Cont.)



REQUIREMENT
 CODE BAR CLUTCH AND FUNCTION
 CLUTCH DISENGAGED. FUNCTION
 CLUTCH TRIP LEVER SHOULD
 ENGAGE CLUTCH SHOE LEVER
 BY FULL THICKNESS OF SHOE
 LEVER. (CHECK AT LUG WITH
 LEAST BITE ON TWO STOP
 CLUTCHES)

TO ADJUST
 POSITION TRIP LEVER ON ITS
 SHAFT WITH CLAMP SCREW
 LOOSENED, LETTING SHAFT
 HAVE END PLAY
 MIN. SOME
 MAX. 0.006 INCH

REQUIREMENT
 CAM FOLLOWER ROLLER ON THE LOW
 PART OF CAM.
 THE SPRING UNHOOKED FROM SPRING
 BRACKET.
 MIN. 20 OZS.
 MAX. 24 OZS.
 TO PULL SPRING TO INSTALLED LENGTH.

2. 19 Main Shaft and Trip Shaft Mechanisms (Cont.)

(A) CLUTCH TRIP SHAFT SET COLLARS


(1) REQUIREMENT

SPACING CUT-OUT LEVER SHOULD HAVE SIDE PLAY

MIN. SOME
MAX. 0.008 INCH

TO ADJUST
POSITION SPACING CUT-OUT LEVER
SET COLLAR

NOTE: FOR EARLIER DESIGN
SEE PAR. 4.05.



(2) REQUIREMENT

APPROXIMATE ALIGNMENT OF
RIGHT END OF STOP EXTENSIONS
ON TRIP LEVER AND SHOE LEVER.

TO ADJUST

POSITION LINE FEED CLUTCH
TRIP LEVER SET COLLAR.


(3) REQUIREMENT

LINE FEED CLUTCH LATCH LEVER
SHOULD HAVE SIDE PLAY.

MIN. SOME
MAX. 0.008 INCH


TO ADJUST

POSITION LINE FEED CLUTCH
LATCH LEVER SET COLLAR.



SECTION 573-115-700

2.20 Main Shaft and Trip Shaft Mechanisms (Cont.)



SPACING CLUTCH TRIP LEVER

REQUIREMENT

CLEARANCE BETWEEN TRIP LEVER AND CLUTCH DRUM SHOULD BE 0.018 TO 0.035 INCH LESS THAN CLEARANCE BETWEEN SHOE LEVER AND DRUM AT STOP SHOWING GREATEST CLEARANCE. THERE SHOULD BE SOME OVERBITE ON ALL STOP LUGS. GAUGE BY EYE.

TO CHECK

DISENGAGE THE CLUTCH. TRIP CLUTCH TRIP LEVER AND ROTATE MAIN SHAFT UNTIL TRIP LEVER IS OVER THE SHOE LEVER. TAKE UP PLAY OF SHOE LEVER INWARD BY SNAPPING THE TRIP LEVER OVER THE SHOE LEVER. CHECK CLEARANCE BETWEEN SHOE LEVER AND DRUM AT EACH STOP POSITION. WITH THE TRIP LEVER AT THE STOP POSITION WHICH YIELDS GREATEST CLEARANCE, ROTATE MAIN SHAFT SLOWLY UNTIL THE TRIP LEVER JUST FALLS OFF THE STOP LUG. CHECK CLEARANCE BETWEEN TRIP LEVER AND DRUM.

(RIGHT SIDE VIEW)

TO ADJUST

POSITION THE TRIP LEVER BY MEANS OF ITS CLAMP SCREW.

NOTE: FOR EARLIER DESIGN
SEE PAR. 4.06.


CLUTCH TRIP LEVER SPRING

REQUIREMENT

CLUTCH ENGAGED AND ROTATED UNTIL TRIP LEVER RESTS ON STOP LUG

CLUTCH	MIN.	MAX.
SPACING	11 OZS.	16 OZS.
LINE FEED	9 OZS.	12 OZS.
TYPE BOX	5 OZS.	7-1/4 OZS.

TO MOVE LEVER AWAY FROM STOP LUG.



(REAR VIEW)


2.21 Main Shaft and Trip Shaft Mechanisms (Cont.)

(A) TYPE BOX CLUTCH TRIP LEVER ECCENTRIC POST
REQUIREMENT

TYPE BOX CLUTCH DISENGAGED. TRIP LEVER SHOULD ENGAGE THE CLUTCH SHOE LEVER BY THE FULL THICKNESS OF THE SHOE LEVER. TO ADJUST POSITION THE TRIP LEVER ECCENTRIC POST.

(C) LINE FEED CLUTCH TRIP LEVER ADJUSTING SCREW
REQUIREMENT

LINE FEED FUNCTION SLIDE ARM IN REAR POSITION. CLUTCH TRIP LEVER AGAINST ITS ECCENTRIC POST. TRIP ARM HELD AGAINST ITS FUNCTION SLIDE ARM. SOME CLEARANCE BETWEEN THE END OF THE TRIP LEVER ADJUSTING SCREW AND THE TRIP ARM. MAX. 0.006 INCH. TO ADJUST POSITION THE ADJUSTING SCREW.



(B) LINE FEED CLUTCH TRIP LEVER ECCENTRIC POST
REQUIREMENT


CLEARANCE BETWEEN TRIP LEVER AND CLUTCH DRUM SHOULD BE 0.018 TO 0.035 INCH LESS THAN CLEARANCE BETWEEN SHOE LEVER AND DRUM AT STOP WHICH SHOWS GREATEST CLEARANCE. THERE SHOULD BE SOME OVERBITE ON ALL THREE STOP LUGS AS GAUGED BY EYE.

TO CHECK


DISENGAGE THE CLUTCH. TRIP CLUTCH TRIP LEVER AND ROTATE MAIN SHAFT UNTIL TRIP LEVER IS OVER THE SHOE LEVER. TAKE UP PLAY OF SHOE LEVER INWARD BY SNAPPING THE TRIP LEVER OVER THE SHOE LEVER. CHECK CLEARANCE BETWEEN SHOE LEVER AND DRUM AT EACH STOP POSITION. WITH TRIP LEVER AT THE STOP POSITION WHICH YIELDS GREATEST CLEARANCE, ROTATE MAIN SHAFT SLOWLY UNTIL THE TRIP LEVER JUST FALLS OFF THE STOP LUG. CHECK CLEARANCE BETWEEN TRIP LEVER AND DRUM.

TO ADJUST

BACK OFF TRIP LEVER ADJUSTING SCREW AND POSITION TRIP LEVER ECCENTRIC STOP POST.



2.22 Main Shaft and Trip Shaft Mechanisms (Cont.)



TYPE BOX CLUTCH TRIP LEVER

(1) REQUIREMENT
 CLUTCH TRIP SHAFT CAM FOLLOWER ROLLER
 (SEE PAR. 2.18) ON LOWEST SURFACE OF
 CAM (LOCATED ON CODE BAR CLUTCH).
 CLEARANCE BETWEEN INNER FACE OF
 TYPE BOX CLUTCH TRIP LEVER AND THE
 CLUTCH DISK STOP LUG.
 MIN. 0.025
 MAX. 0.045

TO ADJUST
 LOOSEN CLAMP SCREW AND POSITION STOP.

(2) REQUIREMENT
 WHEN POSITIONING THE TRIP ARM
 DETERMINE THAT THE LATCH LEVER
 HAS SOME SIDE PLAY
 MAX. 0.008 INCH

TO ADJUST
 POSITION THE CLUTCH TRIP
 ARM ON ITS SHAFT WITH THE
 CLAMP SCREW LOOSENED.


CLUTCH SHOE LEVER
REQUIREMENT

GAP BETWEEN CLUTCH SHOE LEVER AND ITS STOP
 LUG SHOULD BE 0.055 INCH TO 0.085 INCH GREATER
 WHEN CLUTCH IS ENGAGED THAN WHEN THE CLUTCH
 IS DISENGAGED.

TO CHECK
 DISENGAGE THE CLUTCH AND MEASURE THE GAP.
 TRIP THE CLUTCH AND ROTATE IT UNTIL THE CLUTCH
 SHOE LEVER IS TOWARD THE BOTTOM OF THE UNIT.
 AGAIN MEASURE THE GAP WITH THE CLUTCH THUS
 ENGAGED.


NOTE

ON MULTIPLE STOP CLUTCHES CHECK THE CLEARANCE
 AT THE STOP LUG THAT IS ADJACENT TO THE FORM IN
 THE CLUTCH ADJUSTING DISK.



TO ADJUST
 LOOSEN THE TWO CLAMP SCREWS ON THE CLUTCH DISK. ENGAGE A WRENCH OR SCREWDRIVER
 ON THE LUG OF THE ADJUSTING DISK AND ROTATE THE DISK.

2.23 Main Shaft and Trip Shaft Mechanisms (Cont.)




CLUTCH SHOE LEVER SPRING REQUIREMENT

CLUTCH ENGAGED. HOLD CAM DISK TO PREVENT TURNING. SPRING SCALE PULLED AT TANGENT TO CLUTCH.
 MIN. 15 OZS. ONE-STOP CLUTCHES
 MAX. 20 OZS.

MIN. 16 OZS. MULTIPLE-STOP CLUTCHES
 MAX. 22 OZS.
 TO MOVE THE SHOE LEVER IN CONTACT WITH THE STOP LUG.

CLUTCH DRUM POSITION (EXCEPT SELECTOR) REQUIREMENT

CLUTCH SHOE LEVER HELD DISENGAGED. CLUTCH SHOULD HAVE SOME END PLAY
 MAX. 0.015 INCH
 TO ADJUST POSITION EACH DRUM AND SPACING CLUTCH SET COLLAR WITH MOUNTING SCREWS LOOSENED.




CLUTCH SHOE SPRING NOTE

IN ORDER TO CHECK THIS SPRING TENSION, IT IS NECESSARY TO REMOVE THE CLUTCH FROM THE MAIN SHAFT. THEREFORE, IT SHOULD NOT BE CHECKED UNLESS THERE IS GOOD REASON TO BELIEVE THAT IT DOES NOT MEET ITS REQUIREMENT.

REQUIREMENT

CLUTCH DRUM REMOVED. SPRING SCALE APPLIED TO PRIMARY SHOE AT A TANGENT TO THE FRICTION SURFACE.
 MIN. 3 OZS.
 MAX. 5 OZS.
 TO START THE PRIMARY SHOE MOVING AWAY FROM SECONDARY SHOE AT POINT OF CONTACT

2.24 Spacing Mechanism



SPACING CLUTCH DISENGAGED. INDEX LINE ON THE SPACING PAWL SHOULD BE AS NEAR AS POSSIBLE TO THE CENTER OF THE TWO LINES ON THE PAWL RETAINING WASHER.

TO ADJUST


REMOVE THE MOUNTING SCREW FROM THE SPACING SHAFT GEAR. HOLD THE PAWLS IN ALIGNMENT AND ENGAGE THE SPACING SHAFT GEAR WITH THE CLUTCH GEAR AT A POINT WHERE THE SPACING SHAFT GEAR MOUNTING SCREW HOLE IS IN LINE WITH THE TAPPED HOLE IN THE SPACING SHAFT AND INSERT THE MOUNTING SCREW

CARRIAGE FULLY RETURNED. MINIMUM BACKLASH OF SPACING GEARS WITHOUT BIND.


TO ADJUST

INSERT SHIMS BETWEEN THE SPACING SHAFT BEARING AND FRONT PLATE AT UPPER MOUNTING SCREW TO INCREASE CLEARANCE AND AT LOWER MOUNTING SCREW TO DECREASE BACKLASH.

2.25 Line Feed and Platen Mechanism



2.26 Positioning Mechanism




2.27 Positioning Mechanism (Cont.)

ROCKER SHAFT BRACKET ECCENTRIC STUD


- (1) REQUIREMENT --- WITH TYPE BOX CLUTCH DISENGAGED AND PLAY IN LOCKING ARM TAKEN UP TOWARD FRONT, GAP BETWEEN LOWER SIDE OF LOCK LEVER ROLLER AND TOP EDGE OF SHOULDER ON HORIZONTAL POSITIONING LOCK LEVER SHOULD BE:
MIN. 0.055 INCH ----- MAX. 0.090 INCH
- (2) REQUIREMENT --- MAKE SURE THAT ROCKER SHAFT DRIVE LINK IS FREE IN ITS BEARINGS (NOT UNDER LOAD) WHEN CLUTCH IS IN (a) ITS STOP POSITION; (b) WHEN IT IS ROTATED 180 DEGREES FROM STOP POSITION.

TO ADJUST --- (1) POSITION ECCENTRIC STUD IN LOWER END OF ROCKER-SHAFT LEFT BRACKET. KEEP HIGH PART OF ECCENTRIC (MARKED WITH DOT) BELOW CENTER LINE OF DRIVE LINK. (2) MAKE SURE THAT STUD IS FREE IN TYPE BOX CLUTCH BEARING AT POSITIONS (a) AND (b) ABOVE (NO PUSHING OR PULLING FORCE ON DRIVE LINK). CHECK MANUALLY BY MOVING LINK TOWARD LEFT SIDE FRAME AND THEN IN REVERSE DIRECTION.

NOTE --- ANY CHANGE IN THIS ADJUSTMENT WILL REQUIRE THAT THE FOLLOWING RELATED ADJUSTMENTS BE RECHECKED: HORIZONTAL POSITIONING DRIVE LINKAGE (PAR. 2.35) RIGHT VERTICAL POSITIONING LEVER ECCENTRIC STUD (PAR. 2.28), LEFT VERTICAL POSITIONING LEVER ECCENTRIC STUD (PAR. 2.29) VERTICAL POSITIONING LOCK LEVER (PAR. 2.36), RIBBON FEED LEVER BRACKET (PAR. 2.53), FUNCTION STRIPPER BLADE ARMS (PAR. 4.18), SPACING TRIP LEVER BAIL CAM PLATE (PAR. 2.31), REVERSING SLIDE BRACKETS (PAR. 2.34) AND RIBBON REVERSE SPUR GEAR (PAR. 2.52) PRINTING TRACK (PAR. 2.49) AND PRINTING ARM (PAR. 2.50).



2.28 Positioning Mechanism (Cont.)



(A) RIGHT VERTICAL POSITIONING LEVER
ECCENTRIC STUD

REQUIREMENT

TYPE BOX CLUTCH DISENGAGED, COMMON CODE BAR IN SPACING POSITION. PLAY TAKEN UP BY PRESSING DOWNWARD ON COMMON CODE BAR AT GUIDE BLOCK.

MIN. 0.030 INCH

MAX. 0.050 INCH

CLEARANCE BETWEEN THE TOE OF VERTICAL POSITIONING LEVER AND THE BOTTOM OF THE COMMON CODE BAR WHEN PLAY IS TAKEN UP TO MAKE CLEARANCE A MINIMUM

TO ADJUST

POSITION THE ECCENTRIC STUD IN THE RIGHT ROCKER SHAFT BRACKET. POSITION HIGH PART OF ECCENTRIC (MARKED WITH DOT TOWARD THE REAR. THE HIGH PART OF THE ECCENTRIC CAN ALSO BE IDENTIFIED BY THE EXPOSED PORTION OF THE FLAT SURFACE OF THE VERTICAL POSITIONING LINK.

(B) VERTICAL POSITIONING LEVER SPRING

REQUIREMENT

VERTICAL POSITIONING LEVER TOES (RIGHT AND LEFT) IN CONTACT WITH THE SUPPRESSION CODE BAR, LEVERS NOT BUCKLED.


MIN. 4 OZS.

MAX. 12 OZS.

TO MOVE THE LINK EXTENSION AWAY FROM THE VERTICAL POSITIONING LEVER.

CHECK BOTH RIGHT AND LEFT SPRINGS.

2.29 Positioning Mechanism (Cont.)




2.30 Spacing Mechanism (Cont.)

NOTE: CHECK RELATED ADJUSTMENTS, PARS. 2.43, 2.44, AND 2.47, IF THE FOLLOWING ADJUSTMENTS ARE REMADE.

OSCILLATING RAIL SLIDE POSITION REQUIREMENT

CARRIAGE RETURN RING AND AUTOMATIC CARRIAGE RETURN-LINE FEED RING FREE TO ROTATE ON SPACING DRUM (FIVE MOUNTING SCREWS LOOSENED). SPACING CLUTCH DISENGAGED. FEED PAWL, WHICH IS FARTHEST ADVANCED, ENGAGING TOOTH IMMEDIATELY ABOVE CUT-AWAY SECTION OF RATCHET. CLEARANCE BETWEEN SLIDE AND PULLEY

MIN. 0.025 INCH---MAX. 0.050 INCH
TO ADJUST POSITION SLIDE ON WIRE ROPE WITH CLAMP SCREWS LOOSENED.



NOTE: FOR EARLIER DESIGN SEE PAR. 4.07.

SPACING FEED PAWL SPRING REQUIREMENT

EACH SPACING PAWL IN LEAST ADVANCED POSITION RESTING AGAINST RATCHET WHEEL. EACH SPRING UNHOOKED FROM BRACKET
MIN. 2-1/2 OZS.
MAX. 4 OZS.
TO PULL SPRINGS TO INSTALLED LENGTH.

NOTE: ON UNITS EQUIPPED FOR 6 SPACES PER INCH THIS TENSION SHOULD BE
MIN. 8 OZS.
MAX. 10 OZS.
TO PULL SPRINGS TO INSTALLED LENGTH.

SPACING FEED PAWL SPRING BRACKET

2.31 Spacing Mechanism (Cont.)

(A) SPACING TRIP LEVER BAIL CAM PLATE REQUIREMENT


SPACING TRIP LEVER ARM IN UPWARD POSITION. TYPE BOX CLUTCH ROTATED THROUGH APPROXIMATELY ONE-HALF OF ITS CYCLE. ALL FUNCTION PAWLS DISENGAGED FROM FUNCTION BAR. CLEARANCE BETWEEN TOP SURFACE OF TRIP LEVER ARM EXTENSION AND SPACING TRIP LEVER SHOULDER.

MIN. 0.010 INCH

MAX. 0.040 INCH

TO ADJUST

POSITION CAM PLATE ON ROCKER SHAFT WITH MOUNTING SCREWS LOOSENED. POSITION FORWARD EDGE OF CAM PLATE PARALLEL TO SHAFT.



(B) SPACING TRIP LEVER SPRING REQUIREMENT

TYPE BOX CLUTCH DISENGAGED.

MIN. 2-1/2 OZS.

MAX. 5 OZS.

TO START LEVER MOVING.

(C) SPACING TRIP LEVER BAIL SPRING REQUIREMENT

SPACING TRIP LEVER BAIL AGAINST STOP.


SPACING TRIP LEVER BAIL SPRING UNHOOKED.

MIN. 8 OZS.


MAX. 12 OZS.

TO PULL SPRING TO INSTALLED LENGTH.

2.32 Function Mechanism



(B) **FUNCTION RESET BAIL SPRING** --- WITH TYPING UNIT INVERTED, HOLD #1 CODE BAR IN ITS MARKING POSITION SO THAT NO FUNCTION BAR IS SELECTED. ROTATE MAIN SHAFT UNTIL FUNCTION RESET BAIL SPRINGS ARE IN THEIR MINIMUM LENGTH POSITION. HOOK A 32 OZ. SCALE (BETWEEN CLUTCH TRIP SHAFT AND SPACE SUPPRESSOR BAIL) ON FRONT EDGE OF RESET BAIL (AT MIDDLE OF BAIL) AND PULL REARWARD. MIN. 10 OZS. ----- MAX. 22 OZS. (TO START BAIL MOVING).



(A) **FUNCTION RESET BAIL BLADE (FOR UNITS WITH 2-STOP FUNCTION CLUTCH SEE PAR. 4.09)**

- (1) **REQUIREMENT** --- WITH ALL CLUTCHES DISENGAGED, TRIP CODE BAR CLUTCH AND TURN MAIN SHAFT UNTIL CODE-BAR CLUTCH SHOE-RELEASE LEVER JUST TOUCHES ITS STOP LEVER. UNLATCH ALL FUNCTION PAWLS FROM THEIR FUNCTION BARS. HOLD RESPECTIVE FUNCTION BAR IN ITS EXTREME REARWARD POSITION WITH SPRING HOOK; CLEARANCE BETWEEN FUNCTION BAR AND RESET BAIL BLADE SHOULD BE MIN. 0.018 INCH ----- MAX. 0.035 INCH
- TO CHECK** --- MEASURE CLEARANCE AT BARS IN STUNT BOX SLOTS, NO'S 1, 4, 11, 18, 23, 33, 38 AND 41. IF A DESIGNATED SLOT IS VACANT, USE NEAREST BAR OR SELECT BAR WITH HIGHEST NUMBERED SLOT WHEN A BAR IS LOCATED ON BOTH SIDES OF VACANT SLOT. (VIEW SLOTS FROM REAR, NUMBERING FROM LEFT TO RIGHT).
- TO ADJUST** --- POSITION BLADE ON RESET BAIL WITH ITS MOUNTING SCREWS FRICTION TIGHT.
- (2) **REQUIREMENT** --- EACH FUNCTION PAWL SHOULD OVER TRAVEL ITS FUNCTION BAR BY AT LEAST 0.002 INCH WITH INDICATED TENSIONS APPLIED. CHECK PAWLS ONE AT-A-TIME AT SLOT NO'S. USED ABOVE.
- TO CHECK** --- IF CARRIAGE RETURN LEVER ADJUSTMENT HAS NOT BEEN MADE, LOOSEN ITS CLAMP SCREW. LATCH FUNCTION PAWLS BY LOWERING STRIPPER BLADE; TRIP CODE BAR CLUTCH AND POSITION ITS RELEASE LEVER AS IN (1) ABOVE. STRIP OFF ANY FUNCTIONS WHICH MAY HAVE BEEN SELECTED.
- TO ADJUST** --- REFINE REQUIREMENT (1) ABOVE, HOLDING THE READJUSTMENT WITHIN LIMITS MIN. 0.018 INCH ----- MAX. 0.035 INCH

NOTE: IF THE FUNCTION RESET BAIL BLADE IS REPOSITIONED, CHECK THE ADJUSTMENT OF THE FIGS-LTRS SHIFT CODE BAR OPERATING MECHANISM FOLLOWING.

2.33 Function Mechanism (Cont.)

- NOTE 1. FOR UNITS WITH ADJUSTABLE GUIDE PLATES AND ONE-STOP FUNCTION CLUTCHES, PROCEED AS SPECIFIED.
- NOTE 2. FOR UNITS WITH ADJUSTABLE GUIDE PLATES AND TWO-STOP FUNCTION CLUTCHES, CHANGE FIRST SENTENCE IN REQUIREMENT (1) TO "DISENGAGE FUNCTION CLUTCH AT STOP GIVING LEAST CLEARANCE." THEN PROCEED AS SPECIFIED.

FIGS - LTRS SHIFT CODE BAR OPERATING MECHANISM

(1) REQUIREMENT

WITH FUNCTION CLUTCH ROTATED UNTIL CLUTCH DISK STOP LUG IS TOWARD BOTTOM OF UNIT, HOOK FIGURES FUNCTION PAWL OVER THE END OF THE FUNCTION BAR. CLEARANCE BETWEEN UPPER GUIDE PLATE EXTENSION AND SHIFT SLIDE. MAX. 0.020 WHEN PLAY IS TAKEN UP FOR MAXIMUM.

(2) REQUIREMENT


WITH 32 OZ. PULL APPLIED TO FUNCTION PAWL THERE SHOULD BE MIN. 0.002 INCH BETWEEN SHOULDER OF FIGURES FUNCTION PAWL AND FACE OF FUNCTION BAR.

(3) REQUIREMENT

REPEAT REQUIREMENT (1) & (2) FOR THE LETTERS FUNCTION PAWL. CHECK MAX. CLEARANCE BETWEEN LOWER GUIDE PLATE EXTENSION AND SHIFT SLIDE. CHECK MIN. CLEARANCE BETWEEN SHOULDER OF LETTER FUNCTION PAWL AND FACE OF FUNCTION BAR.


NOTE: THERE SHOULD BE SOME CLEARANCE BETWEEN THE UNOPERATED SHIFT SLIDE AND ITS GUIDE PLATE, WHEN THE SHIFT SLIDE HAS REACHED ITS POSITION OF MAXIMUM TRAVEL.

TO ADJUST POSITION UPPER AND/OR LOWER GUIDE PLATE BY THE ADJUSTING SLOT WITH THE CLAMP NUTS LOOSENED.



NOTE: FOR EARLIER DESIGN SEE PAR. 4.08

2.34 Positioning Mechanism (Cont.)




(A) REVERSING SLIDE
DETENT SPRING
REQUIREMENT

SLIDE IN LEFT HAND POSITION. SCALE
HOOKED IN UPPER RIGHT HAND DETENT NOTCH
MIN. 2 OZS.
MAX. 4-1/2 OZS.
TO START DETENT MOVING

(B) REVERSING SLIDE ADJUSTING STUD
REQUIREMENT

TYPE BOX CLUTCH DISENGAGED.
WITH NO. 3 CODE BAR IN SPACING POSITION (RIGHT), THE REVERSING SLIDE DETENT
ROLLERS SHOULD BE FULLY SEATED IN THE RIGHT-HAND NOTCHES OF THE DETENT LEVER.
WITH NO. 3 CODE BAR IN MARKING POSITION (LEFT), THE REVERSING SLIDE DETENT
ROLLERS SHOULD BE FULLY SEATED IN THE LEFT-HAND NOTCHES OF THE DETENT LEVER.
TO ADJUST
POSITION THE REVERSING SLIDE STUD IN ITS ELONGATED HOLE WITH ITS MOUNTING
NUT LOOSENED.



(C) REVERSING SLIDE BRACKETS
REQUIREMENT

TYPE BOX CLUTCH, CODE BAR CLUTCH,
AND FUNCTION CLUTCH DISENGAGED.
REVERSING SLIDE MOVED TO RIGHT AND
LEFT THROUGH ITS FULL TRAVEL RIGHT
MOTION SHOULD BUCKLE LEFT HORI-
ZONTAL POSITIONING DRIVE LINKAGE
AND LEFT MOTION SHOULD BUCKLE
RIGHT HORIZONTAL POSITIONING
DRIVE LINKAGE. THE AMOUNT OF
BUCKLING IN EACH CASE SHOULD BE
MIN. 0.030 INCH
MAX. 0.050 INCH
MEASURED AT POINT OF MAXIMUM
CLEARANCE

TO ADJUST
POSITION EACH REVERSING SLIDE
BRACKET WITH THEIR CLAMP SCREWS
LOOSENED.

SECTION 573-115-700

2.35 Positioning Mechanism (Cont.)

NOTE: THESE ADJUSTMENTS APPLY ONLY TO HORIZONTAL POSITIONING DRIVE MECHANISMS EQUIPPED WITH TORSION SPRINGS.

HORIZONTAL POSITIONING DRIVE LINKAGE

REQUIREMENT

TYPE BOX CLUTCH DISENGAGED.

CODE BARS 4 AND 5 TO SPACING (RIGHT).


CLEARANCE BETWEEN EACH SIDE OF CENTER HORIZONTAL STOP SLIDE AND DECELERATING SLIDES, ON SIDE WHERE KNEE LINK IS STRAIGHT SHOULD BE EQUAL (WITHIN 0.008 INCH)

MIN. 0.090 INCH

MAX. 0.110 INCH

TO ADJUST

LOOSEN BEARING STUD MOUNTING SCREWS AND CONNECTING STRIP MOUNTING SCREWS FRICTION TIGHT. POSITION ONE OR BOTH BEARING STUDS ON THE CONNECTING STRIP TO PROVIDE 0.095 INCH TO 0.105 INCH BETWEEN THE CENTER HORIZONTAL SLIDE AND THE DECELERATING SLIDE ON THE SIDE WHERE THE LINKAGE IS NOT BUCKLED. TIGHTEN THE TWO INNER MOUNTING SCREWS. CHANGE POSITION OF REVERSING SLIDE AND CHECK OPPOSITE CLEARANCE. EQUALIZE BY SHIFTING BOTH STUDS AND CONNECTING STRIP AS A UNIT. HOLD THE DRIVE LINKAGE HUB AGAINST THE LOWER VERTICAL LINK OF THE DRIVE LINKAGE. TIGHTEN THE TWO OUTER BEARING STUD MOUNTING SCREWS. CHECK THE LINKAGE FOR FREENESS THROUGHOUT A COMPLETE CYCLE. THE TYPE BOX CLUTCH DISK SHOULD HAVE SOME MOVEMENT IN THE NORMAL DIRECTION OF ROTATION IN THE STOP POSITION.



NOTE: FOR EARLIER DESIGN SEE PAR. 4.10

2.36 Positioning Mechanism (Cont.)

VERTICAL POSITIONING LOCK LEVER

(1) REQUIREMENT


LETTERS COMBINATION SET UP ON CODE BARS. MAIN SIDE OPERATING LEVERS AT UPPER END OF TRAVEL. UPPER NOTCH OF VERTICAL POSITIONING LOCK LEVER FULLY ENGAGED (MANUALLY IF NECESSARY) WITH VERTICAL SLIDE PROJECTION. UPPER SURFACE OF FOLLOWER ARM REAR EXTENSION SHOULD BE MIN. IN CONTACT WITH MAX. 0.004 INCH AWAY FROM INNER EXTENSION OF MAIN SIDE LEVER.

(2) REQUIREMENT


WITH PLAY TAKEN UP BY PULLING UPWARD WITH 8 OZS. TENSION ON TYPE BOX CARRIAGE TRACK, VERTICAL SURFACES MIN. IN CONTACT WITH MAX. 0.012 INCH AWAY FROM EACH OTHER

TO ADJUST

POSITION RIGHT AND LEFT VERTICAL POSITIONING LOCK LEVERS WITH CLAMP SCREWS LOOSENED.



2.37 Spacing Mechanism (cont.)



LOWER DRAW-WIRE ROPE PULLEY BAIL SPRING REQUIREMENT

SPRING UNHOOKED FROM PULLEY BAIL, BAIL EXTENSION RESTING ON OPENING IN FRONT PLATE.
 MIN. 18 OZS.
 MAX. 22 OZS.
 TO PULL SPRING TO POSITION LENGTH.


CARRIAGE DRAW-WIRE ROPE REQUIREMENT

CLEARANCE BETWEEN LOWER DRAW-WIRE ROPE AND CARRIAGE RETURN LATCH BAIL POST SHOULD BE AT LEAST 0.006 INCH. WITH THE HORIZONTAL POSITIONING MECHANISM IN ITS LOWEST POSITION, CLEARANCE BETWEEN THE LOWER DRAW-WIRE ROPE AND THE LEFT HORIZONTAL POSITIONING DRIVE LINKAGE SHOULD BE MIN. 0.030 INCH

TO ADJUST


ADVANCE PRINTING CARRIAGE TO EXTREME RIGHT HAND POSITION. ROTATE TYPE BOX CLUTCH 1/2 REVOLUTION. LOOSEN ROPE CLAMP SCREW ONE TURN ONLY. POSITION PULLEY BEARING STUDS, WITH THEIR MOUNTING SCREWS LOOSENED, TO MEET REQUIREMENT. CHECK THAT CABLE HAS MOVED AROUND ITS EQUALIZING CLAMP SO THAT REAR CABLE HAS SLIGHTLY GREATER TENSION THAN FRONT CABLE, GAUGED BY FEEL. TIGHTEN THE CLAMP SCREW.

2.38 Spacing Mechanism (Cont.)



CARRIAGE RETURN SPRING REQUIREMENT
 PULL REQUIRED TO START SPRING DRUM MOVING
 MIN. 3-1/2 LBS.
 MAX. 4 LBS.
TO CHECK
 SPACING DRUM IN ITS RETURNED POSITION. PRINTING TRACK IN LOWER POSITION. REMOVE LOWER CABLE ROLLER SPRING. HOLD SPACING PAWL, BUFFER SLIDE AND CARRIAGE RETURN LATCH TO PREVENT INTERFERENCE WITH SPACING DRUM.
TO ADJUST
 SPRING DRUM NUT LOOSENED. ROTATE SPRING DRUM RATCHET WHEEL TO INCREASE TENSION. OPERATE ESCAPEMENT LEVER TO DECREASE TENSION.

SPACING FEED PAWL RELEASE LINK SPRING REQUIREMENT
 MIN. 1/2 OZ.
 MAX. 2-1/2 OZS.
 TO START SPRING STRETCHING.



2.39 Spacing Mechanism (Cont.)


(A)
CARRIAGE RETURN LATCH BAIL
REQUIREMENT

CARRIAGE FULLY RETURNED (SEE PAR. 2.43)
PLAY IN CARRIAGE RETURN BAIL TAKEN UP
TO RIGHT BY HOLDING RIGHT SIDE OF BAIL
AGAINST ITS RETAINER. CLEARANCE BETWEEN
CARRIAGE RETURN LATCH BAIL AND CARRIAGE
RETURN LEVER.

MIN. 0.004 INCH
MAX. 0.040 INCH

TO ADJUST


POSITION LATCH BAIL PLATE WITH CLAMP
SCREW LOOSENED.




(B)
CARRIAGE RETURN LATCH
BAIL SPRING
REQUIREMENT

SPACING DRUM FULLY RETURNED
MIN. 3 OZS.
MAX. 4-1/2 OZS.
TO START LATCH BAIL MOVING

2.40 Spacing Mechanism (Cont.)



2. 41 Spacing Mechanism (Cont.)



DASH POT VENT SCREW REQUIREMENT

TYPE BOX CARRIAGE SHOULD RETURN FROM ANY LENGTH OF LINE WITHOUT BOUNCING.

TO CHECK

PRINTER OPERATED AT ANY SPEED FROM AUTOMATIC TRANSMISSION WITH ONE CR AND ONE LF SIGNAL BETWEEN LINES. FIRST CHARACTER OF EACH LINE SHOULD BE PRINTED IN SAME LOCATION AS IF UNIT WAS MANUALLY OPERATED SLOWLY.

TO ADJUST

TURN DOWN VENT SCREW UNTIL SLIGHT PNEUMATIC BOUNCE IS PERCEPTIBLE. BACK OFF SCREW UNTIL EFFECT DISAPPEARS. FOR DASHPOTS WITH ONE VENT HOLE: THEN BACK SCREW OFF ONE FULL TURN. TIGHTEN NUT. FOR DASHPOTS WITH TWO VENT HOLES: THEN BACK SCREW OFF 1/4 TURN. TIGHTEN NUT.

TRANSFER SLIDE SPRING

REQUIREMENT

TRANSFER SLIDE IN EXTREME LEFT POSITION. SPRING UNHOOKED.


MIN. 3-1/2 OZS.

MAX. 4-1/2 OZS.

TO PULL SPRING TO INSTALLED LENGTH.

2. 42 Function Mechanism (Cont.)

KEYBOARD LOCK LEVERS SLIDE ARM



KEYBOARD LOCK LEVER SPRING
(IF UNIT IS EQUIPPED)

REQUIREMENT (UNIT UPSIDE DOWN)


SCALE APPLIED TO BELL CRANK

MIN. 1/2 OZ.

MAX. 1-1/2 OZS.

TO START KEYBOARD LOCK LEVER MOVING

2.43 Spacing Mechanism (Cont.)



LEFT MARGIN

REQUIREMENTS --- (72 CHARACTER TYPICAL LINE).

(1) WITH TYPE BOX CLUTCH DISENGAGED, SPACING DRUM IN ITS RETURN POSITION AND TYPE BOX SHIFTED TO LETTERS POSITION; CLEARANCE BETWEEN LEFT EDGE OF PLATEN AND LETTERS PRINT INDICATOR. (SEE NOTE 3).

MIN. 15/16 INCH --- MAX. 1-1/16 INCH.

TO ADJUST --- POSITION STOP ARM OF SPACING DRUM* WITH ITS CLAMP SCREWS LOOSENED.

(2) WITH SPACING CLUTCH DISENGAGED, FRONT SPACING FEED PAWL FARTHEST ADVANCED, SPACING DRUM FULLY RETURNED (DASH POT PLUNGER DEPRESSED FULLY) PLAY IN SPACING SHAFT GEAR (PAR. 2.24) TAKEN UP IN CLOCKWISE DIRECTION; CLEARANCE BETWEEN PAWL AND SHOULDER OF RATCHET WHEEL TOOTH IMMEDIATELY AHEAD.

MIN. SOME --- MAX. 0.008 INCH.

(3) THE REAR PAWL, WHEN FARTHEST ADVANCED, SHOULD DROP INTO INDENTATION BETWEEN RATCHET WHEEL TEETH AND SHOULD BOTTOM FIRMLY IN NOTCH.


TO ADJUST --- REFINE REQUIREMENT (1) ABOVE.

*SHIFT TYPE BOX TO LTRS. POSITION, RETURN PRINT CARRIAGE TO ITS LEFT POSITION AND LOOSEN CARRIAGE RETURN RING MOUNTING SCREWS (4). HOLD CARRIAGE RETURN RING IN ITS COUNTER-CLOCKWISE POSITION, AND POSITION TYPE BOX SO THAT ITS LTRS. INDICATOR ALIGNS WITH REQUIRED MARGIN. TIGHTEN MOUNTING SCREWS.

NOTES


1. WHEN ADJUSTMENTS ON THIS PAGE ARE MADE CHECK RELATED REQUIREMENTS IN PARS. 2.30, 2.44, AND 2.47.
2. FOR SPROCKET FEED PRINTER REQUIREMENTS REFER TO ADJUSTMENTS IN PARS. 2.71 THROUGH 2.75.
3. LEFT MARGIN MAY BE VARIED AS REQUIRED FROM ZERO TO ONE INCH. MAXIMUM RANGE OF ADJUSTMENT FOR MECHANISMS WITH STANDARD (10 CHARACTERS-PER-INCH) SPACING IS AS FOLLOWS:
 (a) FRICTION FEED PLATEN - 85 CHARACTERS
 (b) SPROCKET FEED PLATEN - 74 CHARACTERS
4. PRINTING CARRIAGE POSITION REQUIREMENT REFER TO STANDARD ADJUSTMENT --- PAR. 2.47
5. FOR EARLY DESIGN REFER TO PAR. 4.12.

AUTOMATIC CR/LF BELL CRANK SPRING REQUIREMENT --- (FOR UNITS SO EQUIPPED).
 WITH FUNCTION CLUTCH DISENGAGED.
 MIN. 2-1/2 OZS. --- MAX. 7 OZS.
 TO MOVE THE BELL CRANK.



2.44 Spacing Mechanism (Cont.)

NOTE: CHECK RELATED ADJUSTMENTS, PARS. 2.30, 2.43 AND 2.47 IF THE FOLLOWING ADJUSTMENTS ARE REMADE.



RIGHT MARGIN REQUIREMENT

TYPE BOX CLUTCH DISENGAGED. CARRIAGE IN POSITION TO PRINT CHARACTER ON WHICH SPACING CUTOUT IS TO OCCUR. FRONT FEED PAWL FARTHEST ADVANCED. SPACING CUTOUT TRANSFER BAIL HELD IN ITS UPPERMOST POSITION. ON UNITS HAVING TWO PIECE SPACING CUTOUT BAIL PUSH THE CUTOUT BAIL TOWARDS REAR OF UNIT THROUGH HOLE IN FRONT PLATE. CLEARANCE BETWEEN EXTENSION ON SPACE SUPPRESSION RING AND TRANSFER BAIL

TO ADJUST

POSITION SPACE SUPPRESSION RING WITH FOUR INDICATED MOUNTING SCREWS LOOSENED.

NOTE

- (1) RANGE OF ADJUSTMENT IS FROM 0 TO 85 CHARACTERS.
- (2) ON UNITS EQUIPPED WITH AUTOMATIC CARRIAGE RETURN - LINE FEED RING, THIS ADJUSTMENT IS NOT APPLICABLE. (SEE PAR. 2.62)

REQUIREMENT

MIN. 1 OZ.
MAX. 3-1/2 OZS.
TO START BAIL MOVING.

NOTE: FOR EARLIER DESIGN SEE PAR. 4.13

2.45 Positioning Mechanism (Cont.)

DECELERATING SLIDE SPRING

REQUIREMENT

PRINTING BAIL IN DOWNWARD POSITION. PRINTING
CARRIAGE AND DECELERATING SLIDE ASSEMBLY IN
RIGHT HAND POSITION.


MIN. 1/2 OZ.

MAX. 1-1/2 OZS.

TO START THE SLIDE MOVING.


WITH THE PRINTING CARRIAGE AND DECELERATING
SLIDE IN THEIR LEFT HAND POSITION

CHECK THE LEFT HAND DECELERATING SLIDE SPRING




NOTE: FOR EARLIER DESIGN SEE PAR. 4.13

2.46 Printing Mechanism



PRINTING CARRIAGE LOWER ROLLER REQUIREMENT

CARRIAGE WIRE ROPE CLAMP SCREWS LOOSENED. PLAY OF CARRIAGE ON TRACK-MIN. WITHOUT BIND, THROUGHOUT TRACK'S FULL LENGTH TO ADJUST (ECCENTRIC BUSHING) POSITION LOWER ROLLER WITH SCREW NUT LOOSENED. KEEP HIGH PART OF ECCENTRIC (CHAMFERED CORNER) TOWARD THE RIGHT TO ADJUST (SLIDING SCREW) POSITION LOWER ROLLER WITH MOUNTING SCREW LOOSENED.




TYPE BOX CARRIAGE ROLLER ARM SPRING REQUIREMENT

MIN. 28 OZS.
MAX. 36 OZS.
TO START UPPER ROLLER, NEAREST TYPE BOX LATCH, MOVING AWAY FROM CARRIAGE TRACK.

NOTE: FOR EARLIER DESIGN SEE PAR. 4.14

2.47 Printing Mechanism (Cont.)

NOTE: CHECK RELATED ADJUSTMENTS, PARS. 2.30, 2.38, AND 2.44, IF THE FOLLOWING ADJUSTMENTS ARE REMADE. FOR TYPING UNITS OF EARLIER DESIGN, CHECK RELATED ADJUSTMENTS, PARS. 4.07, 2.38, 2.39, AND 4.13.




PRINTING CARRIAGE POSITION REQUIREMENT

TYPE BOX IN LETTERS POSITION. M TYPE PALLET SELECTED. CARRIAGE AT APPROXIMATE MIDPOINT OF PLATEN. TYPE BOX IN PRINTING POSITION. M TYPE PALLET SHOULD BE APPROXIMATELY IN CENTER OF PRINTING HAMMER WHEN HAMMER IS JUST TOUCHING M TYPE PALLET. TAKE UP PLAY IN TYPE BOX CARRIAGE IN EACH DIRECTION AND SET HAMMER IN CENTER OF PLAY.

TO ADJUST

POSITION PRINTING CARRIAGE ON WIRE ROPE WITH CLAMP SCREWS LOOSENED.



PRINTING HAMMER BEARING STUD REQUIREMENT

TYPE BOX AT MIDPOINT OF PLATEN AND IN POSITION TO PRINT PERIOD. PRINTING HAMMER IN CONTACT WITH TYPE PALLET AND PRESSED DOWNWARD AT BEARING POST. FACE OF HAMMER SHOULD BE FULLY ON END OF TYPE PALLET.


TO ADJUST

ADD OR REMOVE SHIMS BETWEEN SHOULDER ON BEARING POST AND STOP BRACKET

2.48 Positioning Mechanism (Cont.)


(A) SHIFT LINKAGE REQUIREMENT

CARRIAGE NEAR MIDPOINT OF PLATEN, TYPE BOX IN POSITION TO PRINT LETTER "O". MANUALLY BUCKLE RIGHT SHIFT LINKAGE, SHIFT TYPE BOX TO LEFT. FIGURE "9" TYPE PALLET SHOULD BE APPROXIMATELY IN CENTER OF PRINT HAMMER WHEN HAMMER IS JUST TOUCHING "9" TYPE PALLET.



TO ADJUST POSITION LEFT SHIFT LINKAGE ON OSCILLATOR RAIL WITH TWO CLAMP SCREWS LOOSENED.

TO RECHECK SHIFT ALTERNATELY FROM "W" TO "2". TAKE UP PLAY IN EACH DIRECTION. REFINE ADJUSTMENT IF NECESSARY.



(B) SHIFT LINKAGE SPRING REQUIREMENT

LINK IN STRAIGHT POSITION
 MIN. 6 OZS.
 MAX. 14 OZS.
 TO START EACH LINK MOVING.

NOTE: FOR SHIFT MECHANISMS WITH TORSION SPRINGS SEE PAR. 4.15

2.49 Printing Mechanism (Cont.)


(A) PRINTING TRACK REQUIREMENT

PRINTING TRACK IN ITS EXTREME DOWNWARD POSITION. BLANK SELECTION IN FIGURES. PRINTING HAMMER OPERATING BAIL LATCHING EXTENSION HELD WITH LEFT FACE IN LINE WITH THE LATCH SHOULDER. PRINTING ARM SLIDE POSITIONED ALTERNATELY OVER EACH TRACK MOUNTING SCREW. PRINTING BAIL RESET EACH TIME. CLEARANCE BETWEEN LATCHING EXTENSION AND OPERATING BAIL LATCH SHOULD BE

MIN. 0.015 INCH
MAX. 0.040 INCH

TO ADJUST

POSITION THE PRINTING TRACK UP OR DOWN WITH ITS MOUNTING SCREWS LOOSENED. HOLD CLEARANCE TO MAXIMUM.



2.50 Printing Mechanism (Cont.)

PRINTING HAMMER STOP BRACKET

REQUIREMENT --- WITH TYPE BOX IN POSITION TO PRINT CHARACTER "M", PRINTING TRACK IN ITS MAXIMUM DOWNWARD POSITION, AND PRINTING HAMMER STOP BRACKET HELD TOWARD THE PLATEN WITH PRESSURE OF 8 OZS; CLEARANCE BETWEEN PRINTING HAMMER AND "M" TYPE PALLET.

MIN. 0.005 INCH

MAX. 0.035 INCH

AT ANY POINT ALONG THE ENTIRE LENGTH OF THE PLATEN.

TO ADJUST---POSITION STOP BRACKET BY MEANS OF ITS TWO MOUNTING SCREWS.

TYPE PALLET SPRING



REQUIREMENT

TYPE BOX REMOVED FROM THE UNIT. 8 OZS. SCALE APPLIED VERTICALLY TO THE END OF THE PALLET SHANK.

MIN. 1/4 OZS.

MAX. 3/4 OZS.

TO START PALLET MOVING.



PRINTING ARM

(1) REQUIREMENT

PRINTING TRACK IN MAXIMUM DOWNWARD POSITION.

PRINTING HAMMER OPERATING BAIL AGAINST ITS STOP.

SOME CLEARANCE BETWEEN SECONDARY PRINTING ARM AND FORWARD EXTENSION OF HAMMER OPERATING BAIL.

MAX. 0.015 INCH

WHEN PRINTING ARM SLIDE IS HELD DOWNWARD OVER EACH PRINTING TRACK MOUNTING SCREW FOR MAXIMUM CLEARANCE

(2) REQUIREMENT

PRINTING TRACK IN UPPERMOST POSITION. LATCHING EXTENSION OF PRINTING HAMMER OPERATING BAIL SHOULD OVERTRAVEL LATCHING SURFACE OF OPERATING BAIL LATCH BY MIN. 0.006 INCH

CHECK RIGHT AND LEFT POSITIONS

TO ADJUST

POSITION SECONDARY PRINTING ARM WITH CLAMP SCREWS LOOSENED.

NOTE 2

FOR EARLIER DESIGN SEE PAR. 4.16

NOTE 1
THE PRINTING ARM ADJUSTMENT SHOULD ALWAYS BE MADE WITH THE PRINTING HAMMER OPERATING BAIL SPRING BRACKET IN THE NO. 1 POSITION. POSITIONS NO. 2 AND 3 ARE TO BE USED ONLY FOR MAKING MULTIPLE COPIES.

2.51 Printing Mechanism (Cont.)


NOTE: THIS ADJUSTMENT APPLIES ONLY TO UNITS SO EQUIPPED AND SHOULD BE MADE WITH THE TYPEBOX IN ITS UPPER POSITION.

NOTE: RECHECK PRINTING STOP BRACKET ADJUSTMENT PAR. 2.50, AND READJUST IF NECESSARY.

TYPE BOX ALIGNMENT REQUIREMENT

PRINTED IMPRESSION OF CHARACTERS AT TOP AND AT BOTTOM SHOULD BE EQUAL. (GAUGE VISUALLY)


TO ADJUST
 LOOSEN NUT. OPERATE PRINTER UNDER POWER. REPEAT CHARACTERS E AND Z. TURN ADJUSTING SCREW IN OR OUT (IN STEPS OF 1/4 TURN) TO MEET REQUIREMENT. TIGHTEN NUT.



NOTE: SOME TYPING UNITS ARE EQUIPPED WITH A RIBBON GUIDE WHICH HAS A TYPE BOX RETAINING CLIP WITH A LIMITED YIELD. IN CASES WHERE IT IS NECESSARY TO BACK THE ADJUSTING SCREW OUT TO PROVIDE HEAVIER PRINTING AT THE TOP OF A CHARACTER, IT MAY BE NECESSARY TO BEND THE SPRING CLIP ON THE RIBBON GUIDE TOWARD THE FRONT SO THAT THE TAB AT THE BOTTOM OF THE TYPE BOX IS HELD AGAINST THE HEAD OF THE ADJUSTING SCREW.

2.52 Printing Mechanism (Cont.)

CHECK THE TWO COLOR RIBBON REQUIREMENTS PARS. 3.44 AND 3.45 ON UNITS SO EQUIPPED.




(A) RIBBON REVERSE SPUR GEAR REQUIREMENT

WHEN RIGHT REVERSING LEVER IS IN MAXIMUM DOWNWARD POSITION, THE LEFT REVERSING LEVER SHOULD BE IN ITS MAXIMUM UPWARD POSITION.

TO ADJUST

LOOSEN THE SET SCREWS IN THE DETENT CAM. LOOSEN THE LEFT SPUR GEAR NUT. SECURELY TIGHTEN THE RIGHT SPUR GEAR NUT. MOVE THE RIGHT REVERSING LEVER TO ITS MAXIMUM DOWNWARD POSITION AND HOLD LEFT REVERSING LEVER IN ITS MAXIMUM UPWARD POSITION. THEN TIGHTEN THE LEFT SPUR GEAR NUT.

NOTE: ROTATE TYPE BOX CLUTCH 1/2 TURN AND MOVE RIGHT REVERSING LEVER UNDER THE SEGMENT. THERE SHOULD BE SOME CLEARANCE BETWEEN SEGMENT AND THE LEVER. REFINE ADJ. IF NECESSARY



(B) RIBBON REVERSE DETENT REQUIREMENT

RIBBON REVERSE DETENT LINK BUCKLED IN ITS DOWNWARD POSITION, CLEARANCE BETWEEN DETENT LINK AND DETENT LEVER.


MIN. SOME---MAX. 0.055 INCH

WHEN PLAY IN THE LEVER IS TAKEN UP LIGHTLY TOWARD THE RIGHT SIDE OF THE PRINTER.

TO ADJUST

HOLD LEFT RIBBON REVERSING LEVER IN ITS DOWNWARD POSITION, POSITION DETENT LINK, AND TIGHTEN THE UPPER SET SCREW IN THE HUB OF THE DETENT LINK. BUCKLE THE DETENT LINK UPWARD AND TIGHTEN LOWER SET SCREW.

NOTE: FOR EARLIER DESIGN SEE PAR. 4.17



(C) RIBBON REVERSE DETENT LEVER SPRING (IF UNIT IS EQUIPPED)

REQUIREMENT

DETENT LINK BUCKLED IN UPWARD POSITION

MIN. 10 OZS.

MAX. 18 OZS.

TO START DETENT LEVER MOVING TOWARD REAR.


2. 53 Printing Mechanism (Cont.)

RIBBON FEED LEVER BRACKET

(1) REQUIREMENT (LEFT-HAND MECHANISM)
 LEFT REVERSING LEVER IN UPWARD POSITION.
 RIBBON MECHANISM IN UPPER POSITION.
 RATCHET WHEEL HELD AGAINST THE DETENT LEVER.
 CLEARANCE BETWEEN THE FRONT FACE OF THE
 FEED LEVER AND THE SHOULDER OF A TOOTH
 ON THE RATCHET WHEEL.
 MIN. 0.015 INCH
 MAX. 0.035 INCH
 TO ADJUST
 POSITION THE FEED LEVER BRACKET WITH ITS
 MOUNTING SCREWS LOOSENED.

(2) REQUIREMENT (RIGHT-HAND MECHANISM)
 RIGHT REVERSING LEVER AND RIBBON
 MECHANISM IN UPWARD POSITION.
 ADJUST FEED LEVER BRACKET IN THE
 SAME MANNER

NOTE
 ROTATE THE MAIN SHAFT. THE
 RATCHET WHEEL SHOULD STEP ONE
 TOOTH ONLY WITH EACH OPERATION.



REFER TO PARS. 3.44 AND 3.45
 FOR TWO COLOR RIBBON MECHANISM

RIBBON FEED LEVER SPRING

REQUIREMENT
 RIBBON FEED LEVERS IN UPPERMOST POSITION.
 FOR LONG LEVER: PUSH DOWNWARD NEAR
 ITS SPRING.
 FOR SHORT LEVER: PUSH DOWNWARD AT POINT
 NEAR LONG LEVER SPRING.
 MIN. 3/4 OZ.
 MAX. 2 OZS.
 TO START FEED LEVERS MOVING.
 MEASURE ALL FOUR PAWLs.

RIBBON RATCHET WHEEL FRICTION
 SPRING

REQUIREMENT
 FEED LEVERS DISENGAGED.
 MIN. 3 OZS.
 MAX. 7-1/2 OZS.
 TO START THE RATCHET WHEEL MOVING.

NOTE: IF MINIMUM REQUIREMENT OF SHORT LEVER IS
 NOT MET, PULL LOWER END OF TORSION
 SPRING TO REAR.

*TWO COLOR RIBBON REQUIREMENT
 MIN. 3 OZS.---MAX. 4 OZS.
 TO START RATCHET WHEEL MOVING.

SECTION 573-115-700

2.54 Printing Mechanism (Cont.)


RIBBON LEVER SPRING

REQUIREMENT

MIN. 1-1/2 OZS.

MAX. 3 OZS.

TO START THE LEVER MOVING. CHECK
BOTH RIGHT AND LEFT SPRINGS



RIBBON TENSION SPRING

REQUIREMENT

RIBBON RATCHET WHEEL POSITIONED SO
THAT EACH DRIVING PIN IS TOWARD
THE OUTSIDE OF THE SPOOL SHAFT.

MIN. 3 OZS.

MAX. 5-1/2 OZS.

TO START SPOOL SHAFT MOVING.

2.55 Function Mechanism (Cont.)

NOTE: REFER TO BULLETIN 1149B FOR INSTRUCTIONS ON CODING THE UNCODED FUNCTION BAR.

(A) FUNCTION LEVER SPRING

NOTE: IF A FUNCTION LEVER OPERATES A CONTACT OR A SLIDE, HOLD OFF THE CONTACT OR SLIDE WHEN CHECKING THE SPRING TENSION

REQUIREMENT

FUNCTION LEVER IN UNOPERATED POSITION.
SUPPRESSION BAIL HELD FORWARD.


STANDARD
MIN. 1-1/2 OZS.
MAX. 2-3/4 OZS.

LEVER WITH STUD THAT OPERATES TWO CONTACTS
2 OZS.
3-1/2 OZS.

TO START FUNCTION LEVER MOVING, CHECK EACH SPRING.

(B) FUNCTION PAWL SPRING
REQUIREMENT

REAR END OF FUNCTION PAWL RESTING ON FUNCTION BAR
ONE STOP FUNCTION CLUTCH UNITS:
MIN. 3 OZS.
MAX. 5 OZS.
TWO STOP FUNCTION CLUTCH UNITS:
MIN. 7 OZS.
MAX. 10-1/2 OZS.
TO START PAWL MOVING, CHECK EACH SPRING.




(C) FUNCTION BAR SPRING
REQUIREMENT


FUNCTION CLUTCH DISENGAGED
FUNCTION PAWL HELD AWAY.
MIN. 2-1/2 OZS.
MAX. 3-1/2 OZS.
TO START FUNCTION BAR MOVING.

CAUTION: SEVERE WEAR TO THE POINT OF OPERATIONAL FAILURE WILL RESULT IF THE TELETYPEWRITER IS OPERATED WITHOUT EACH FUNCTION PAWL HAVING EITHER A RELATED FUNCTION BAR OR, WHERE A FUNCTION BAR IS MISSING, A RELATED FUNCTION PAWL CLIP TO HOLD THE FUNCTION PAWL AWAY FROM THE STRIPPER BLADE.


2.56 Function Mechanism (Cont.)



STUNT BOX CLIP (FOR UNITS EQUIPPED WITH CLIPS ONLY)



(1) REQUIREMENT (RIGHT-HAND POSITION)
 THE CLIP SHOULD NOT PREVENT THE ASSOCIATED
 FUNCTION PAWL FROM ENGAGING ITS FUNCTION BAR.
 TO ADJUST
 POSITION THE CLIP TO ITS EXTREME RIGHT-HAND POSITION



(2) REQUIREMENT (CENTER POSITION)
 THE CLIP SHOULD HOLD THE FUNCTION PAWL OUT OF
 ENGAGEMENT WITH ITS FUNCTION BAR BUT SHOULD NOT
 INTERFERE WITH THE FUNCTION LEVER.
 TO ADJUST
 POSITION THE CLIP WITH ITS MOUNTING SCREW LOOSENED.

(3) REQUIREMENT (LEFT-HAND POSITION)
 THE CLIP SHOULD HOLD THE FUNCTION PAWL UPWARD OUT OF
 ENGAGEMENT WITH ITS FUNCTION BAR. IT SHOULD ALSO HOLD THE
 TOP END OF THE FUNCTION LEVER IN ITS REAR POSITION.
 TO ADJUST
 POSITION THE CLIP TO ITS EXTREME LEFT-HAND POSITION.

FUNCTION BAR

(RIGHT SIDE VIEW)

2.57 Line Feed and Platen Mechanism (Cont.)

(B) PLATEN DETENT BAIL SPRING

REQUIREMENT

DETENT SEATED BETWEEN TWO TEETH ON LINE FEED SPUR GEAR.

MIN. 16 OZS.
MAX. 32 OZS.

TO START DETENT BAIL MOVING.

DETENT ECCENTRIC

DETENT STUD

(C) LINE FEED BAR RELEASE LEVER SPRING

REQUIREMENT

MIN. 3 OZS.

MAX. 8 OZS.

TO START LEVER MOVING.

ON LP68

MIN. 8 OZS.

MAX. 12 OZS.

HAND WHEEL

LINE FEED BAR RELEASE LEVER

**(A) LINE FEED SPUR GEAR
DETENT ECCENTRIC**

REQUIREMENT

LINE FEED CLUTCH DISENGAGED. PLATEN ROTATED UNTIL DETENT STUD IS SEATED BETWEEN TWO TEETH ON LINE FEED SPUR GEAR. WHEN HAND WHEEL IS RELEASED, MANUALLY SET THE TEETH ON THE FEED BARS INTO ENGAGEMENT WITH THE TEETH ON THE LINE FEED SPUR GEAR. THE DETENT STUD SHOULD CONTACT ONE GEAR TOOTH AND BE NOT MORE THAN 0.010 INCH FROM OTHER TOOTH TO ADJUST ROTATE THE DETENT ECCENTRIC WITH ITS MOUNTING SCREW LOOSENED. KEEP HIGH PART OF ECCENTRIC UPWARD.

LINE FEED SPUR GEAR

(D) LINE FEED BAR BELL CRANK SPRING

REQUIREMENT

LEFT-HAND LINE FEED BAR IN REAR POSITION.

FRICITION FEED	SPROCKET FEED
MIN. 19 OZS.	28 OZS.
MAX. 24 OZS.	38 OZS.

MIN. 19 OZS.

28 OZS.

MAX. 24 OZS.

38 OZS.

TO START BAR MOVING.

LINE FEED BAR BELL CRANK

LINE FEED BAR

2.58 Function Mechanism (Cont.)

STRIPPER BLADE DRIVE CAM POSITION

REQUIREMENT

STRIPPER BLADE DRIVE CAM SHOULD MOVE EACH STRIPPER BLADE CAM ARM AN EQUAL DISTANCE ABOVE AND BELOW CENTER LINE OF ITS PIVOT (GAUGE BY EYE)


- A. UPWARD DIRECTION
- B. DOWNWARD DIRECTION

TO CHECK


WITH FUNCTION CLUTCH DISENGAGED OBSERVE ENGAGEMENT OF STRIPPER BLADE DRIVE CAM (UPPER PEAK) WITH STRIPPER BLADE CAM ARM. THEN ROTATE CLUTCH TO TURN CAM TO ITS EXTREME DOWNWARD POSITION AND OBSERVE ENGAGEMENT OF LOWER CAM PEAK.

TO ADJUST

WITH STRIPPER BLADE DRIVE ARM MOUNTING SCREWS LOOSENED, EQUALIZE THE OVERTRAVEL OF EACH CAM PEAK.



2.59 Spacing Mechanism (Cont.)



SPACING SUPPRESSION BAIL SPRING

REQUIREMENT


SPACING SUPPRESSION BAIL IN REAR POSITION. SCALE APPLIED NEAR CENTER OF HORIZONTAL PORTION OF BAIL.

MIN. 1/2 OZ.

MAX. 1-1/2 OZS.

TO START BAIL MOVING.

2.60 Line Feed and Platen Mechanism (Cont.)



LINE FEED STRIPPER BAIL SPRING

REQUIREMENT

LINE FEED CLUTCH DISENGAGED. SCALE HOOKED UNDER LINE FEED STRIPPER BAIL.

MIN. 1/2 OZ.

MAX. 2 OZS.

TO START STRIPPER BAIL MOVING UPWARD.

EARLY DESIGN


REFER TO PAR. 2.61 FOR LATER DESIGN

LINE FEED STRIPPER BAIL SPRING


STRIPPER BAIL

LINE FEED CLUTCH

2.61 Line Feed and Platen Mechanism (Cont.)




2.62 Spacing Mechanism (Cont.)



NOTE: FOR ADJUSTMENT ON EARLIER MODELS SEE PAR. 4.19


2.63 Positioning Mechanism (Cont.)



HORIZONTAL STOP SLIDE SPRING REQUIREMENT

CODE BARS IN MARKING POSITION (LEFT)
 TYPE BOX CLUTCH ROTATED 1/4 TURN FROM ITS STOP POSITION
 HORIZONTAL MOTION DECELERATING SLIDES (PAR. 2.35) HELD
 AWAY FROM HORIZONTAL STOP SLIDES
 MIN. 1/2 OZ. MAX. 1-1/2 OZS. FOR UPPER AND LOWER SLIDES
 MIN. 1-3/4 OZS. MAX. 3 OZS. FOR MIDDLE SLIDE
 TO START SLIDE MOVING.
 NOTE: WHEN CHECKING UPPER AND LOWER SLIDES, HOLD MIDDLE
 SLIDE 1/32 INCH FORWARD.


2.64 Line Feed and Platen Mechanism (Cont.)



PAPER STRAIGHTENER COLLAR REQUIREMENT

LEFT COLLAR SPACE
 MIN. 9/32 INCH
 MAX. 21/64 INCH
 FROM THE LEFT SHOULDER ON THE
 PAPER STRAIGHTENER SHAFT.
 RIGHT COLLAR SPACED.
 MIN. 1/16 INCH
 MAX. 5/64 INCH
 FROM THE RIGHT SHOULDER.

TO ADJUST
 POSITION COLLARS ON SHAFT WITH
 SET SCREWS LOOSENED.




PAPER STRAIGHTENER LEVER SPRING REQUIREMENT

MIN. 1-1/2 OZS.
 MAX. 4 OZS.
 TO START THE LEVER MOVING.

NOTE: FOR SPROCKET FEED MECHANISM SEE PAR. 2.75

2.65 Line Feed and Platen Mechanism (Cont.)



PAPER FINGER

REQUIREMENT

THE PRESSURE END OF THE PAPER FINGERS SHOULD OVERLAP THE PAPER FROM 3/8 INCH TO 1/2 INCH.

TO ADJUST

POSITION THE PAPER FINGERS BY SLIDING THEM ON THEIR SHAFT.


PAPER FINGER SPRING

REQUIREMENT

PULL UPWARD ON RIGHT PAPER FINGER TO START LEFT PAPER FINGER MOVING FROM PLATEN.

MIN. 3 OZS.

MAX. 6 OZS.



PRESSURE ROLLER LEVER SPRING

REQUIREMENT

MIN. 28 OZS.

MAX. 36 OZS.

TO START EACH CENTER LEVER MOVING. ALTERNATELY

PAPER PRESSURE BAIL SPRING

REQUIREMENT

SCALE HOOKED OVER PRESSURE BAIL AT EACH END OF PLATEN.


MIN. 7 OZS.

MAX. 20 OZS.


TO MOVE PRESSURE BAIL FROM PLATEN.

NOTE: FOR SPROCKET FEED MECHANISM SEE PAR. 2.73

2.66 Function Mechanism (Cont.)




NOTE: FOR EARLIER DESIGN SEE PAR. 4.21 AND 4.22



NOTE: IF THE SWITCHES ARE REMOVED FROM THE STUNT BOX, THE FOLLOWING REQUIREMENTS APPLY:

- (1) PROVIDE AT LEAST 0.006 INCH CLEARANCE BETWEEN THE CONTACT ARM AND THE VERTICAL PORTION OF THE CONTACT CLIP. IF THE SWITCH HAS CONTACTS FRONT AND REAR, THIS CLEARANCE APPLIES TO BOTH FRONT AND REAR. TO OBTAIN THIS CLEARANCE, POSITION THE CONTACT PLATE BEFORE TIGHTENING THE CONTACT PLATE SCREWS. THE CONTACT MUST BE MADE BEFORE THE FUNCTION LEVER TOUCHES THE TOP PLATE.
- (2) ON SWITCHES WITH CONTACTS FRONT AND REAR, CHECK TO SEE THAT THERE IS A GAP OF 0.008 TO 0.028 INCH BETWEEN THE FORMED-OVER END OF THE FRONT CONTACT CLIP AND THE BOTTOM OF THE CONTACT ARM WHEN THE REAR CONTACT IS CLOSED.

2.67 Function Mechanism (Cont.)

UNSHIFT-ON-SPACE FUNCTION PAWL

(1) REQUIREMENT

TO PREVENT UNSHIFT-ON-SPACE FUNCTION, PROVIDE CLEARANCE BETWEEN THE LOWER EDGE OF THE UNSHIFT-ON-SPACE FUNCTION PAWL AND ITS FUNCTION BAR.

MIN. 0.015 INCH

MAX. 0.060 INCH

TO ADJUST

LOOSEN THE LOCK NUT AND TURN THE DISABLING SCREW IN.

(2) REQUIREMENT

TO RESTORE THE UNSHIFT-ON-SPACE FUNCTION, BACK OFF THE SCREW SO THAT PAWL FULLY ENGAGES THE FUNCTION BAR. THEN CONTINUE TO TURN THE SCREW OUT ONE TO THREE TURNS.

2.08 Codebar Mechanism (Cont.)

CODE BAR DETENT

REQUIREMENT

FRONT PLATE REMOVED. ALL CLUTCHES DISENGAGED.
 SUPPRESSION AND SHIFT CODE BARS SHOULD
 DETENT EQUALLY (GAUGED BY EYE)

TO ADJUST

EQUALIZE THE DETENTING OF THE CODE BARS
 BY ADDING OR REMOVING SHIMS BETWEEN
 THE CASTING AND THE CODE BAR BRACKET.

CODE BAR DETENT SPRING

NOTE

UNLESS THERE IS REASON TO BELIEVE THAT THESE
 SPRINGS ARE CAUSING OPERATING FAILURE DO NOT
 CHECK THIS REQUIREMENT.


REQUIREMENT

CODE BAR DETENT BRACKET CAREFULLY REMOVED
 AND CODE BARS REMOVED FROM DETENT
 BRACKET. SCALE APPLIED TO DETENT BALL AND
 PULLED IN DIRECTION OF BALL TRAVEL

MIN. 1-1/2 OZS.

MAX. 3-1/2 OZS.

TO START BALL MOVING AGAINST COMPRESSION
 OF SPRING. CHECK EACH BALL



CODE BAR YIELD SPRING (IF SO EQUIPPED)

REQUIREMENT


SELECTOR CLUTCH, CODE BAR CLUTCH, AND TYPE BOX
 CLUTCH DISENGAGED. NO. 1 CODE BAR IN SPACING
 POSITION

MIN. 14 OZS.

MAX. 23 OZS.

TO START CODE BAR SHIFT BAR PIVOT MOVING AWAY
 FROM CODE BAR. CHECK NO. 2 AND COMMON CODE
 BAR SHIFT BAR IN THE SAME MANNER.

2.69 Spacing Mechanism (Cont.)



NOTE: FOR EARLIER DESIGN SEE PAR. 4.23

MARGIN INDICATOR LAMP


REQUIREMENT

OPERATING UNDER POWER, THE LAMP SHOULD LIGHT ON THE DESIRED CHARACTER.

TO ADJUST

SET THE TYPE BOX CARRIAGE TO PRINT THE DESIRED CHARACTER AND POSITION THE CAM DISK COUNTERCLOCKWISE ON THE SPRING DRUM WITH ITS THREE MOUNTING SCREWS LOOSENED SO THAT THE SWITCH JUST OPENS. IF A LINE SHORTER THAN 72 CHARACTERS IS REQUIRED, IT MAY BE NECESSARY TO REMOVE THE CAM DISK SCREWS AND INSERT THEM IN ADJACENT SLOTS IN THE DISK, IF THE RANGE OF ROTATION IN ONE SLOT IS NOT ENOUGH.

2.70 Positioning Mechanism (Cont.)




TYPE BOX POSITION
REQUIREMENT


TYPE BOX AND SPACING CLUTCHES DISENGAGED. TYPE BOX SHIFTED TO LETTERS POSITION. FOUR MOUNTING SCREWS LOOSENED SO THAT SPACE SUPPRESSION RING, OR AUTOMATIC CARRIAGE RETURN LINE FEED RING, IS FREE TO ROTATE ON DRUM. (UNITS EQUIPPED WITH LIMITED ADJUSTMENT SPACING DRUM: SPACING CUT OUT AND AUTOMATIC CARRIAGE RETURN LINE FEED ARMS IN MAXIMUM COUNTER-CLOCKWISE POSITION. SEE PAR. 4.07) CLEARANCE BETWEEN LETTERS PRINT INDICATOR AND CENTER LINE OF SPROCKET PINS IN RIGHT HUB:
MIN. 5/16 INCH
MAX. 7/16 INCH

TO ADJUST

LOOSEN TWO TYPE BOX CLAMP SCREWS AND TWO PRINTING CARRIAGE CLAMP SCREWS. POSITION TYPE BOX. TIGHTEN TYPE BOX CLAMP SCREWS. DO NOT TIGHTEN PRINTING CARRIAGE CLAMP SCREWS UNTIL PRINTING CARRIAGE POSITION ADJUSTMENT IS MADE.



2.71 Line Feed and Platen Mechanism (Con't)



(A) LEFT MARGIN REQUIREMENT

(1) TYPE BOX CLUTCH DISENGAGED, SPACING DRUM FULLY RETURNED, AND TYPE BOX SHIFTED TO LETTERS POSITION: CLEARANCE BETWEEN CENTER OF LETTERS PRINT INDICATOR ON TYPE BOX AND CENTER LINE OF SPROCKET PINS AT LEFT HUB SHOULD BE:

MIN. 5/16 INCH --- MAX. 7/16 INCH

TO ADJUST --- POSITION CARRIAGE RETURN RING WITH ITS MOUNTING SCREWS LOOSENED.

(2) SPACING CLUTCH DISENGAGED, FRONT SPACING FEED PAWL IN ITS FARTHEST ADVANCED POSITION, SPACING DRUM FULLY RETURNED, AND PLAY IN SPACING GEAR (PAR. 2.24) TAKEN UP-CLOCKWISE: CLEARANCE BETWEEN PAWL AND SHOULDER OF RATCHET WHEEL TOOTH IMMEDIATELY AHEAD:

MIN. SOME --- MAX. 0.008 INCH

(3) THE REAR PAWL WHEN FARTHEST ADVANCED SHOULD DROP INTO THE INDENTATION BETWEEN RATCHET WHEEL TEETH AND SHOULD BOTTOM FIRMLY IN NOTCH.

TO ADJUST --- REFINE REQUIREMENT (1) ABOVE

(B) PRINTING HAMMER STOP BRACKET

(1) FOR UNITS WITH THICK TYPEBOX AND DUMMY TYPE PALLETS USE CORRESPONDING STANDARD ADJUSTMENT EXCEPT CLEARANCE BETWEEN PRINTING HAMMER AND DUMMY TYPE PALLET SHOULD BE

MIN. SOME --- MAX. 0.020 INCH

(2) FOR UNITS WITH THIN TYPEBOX - NO DUMMY TYPE PALLETS, USE CORRESPONDING STANDARD ADJUSTMENT.


(3) CERTAIN MULTIPLE FORM UNITS WILL REQUIRE A REFINEMENT OF STANDARD ADJUSTMENT FOR THE STOP BRACKET TO

MIN. 0.005 INCH --- MAX. 0.015 INCH

(C) RIGHT MARGIN

(1) FOR UNITS WITH LIMITED ADJUSTMENT SPACING DRUM, USE CORRESPONDING STANDARD ADJUSTMENT.

(2) FOR UNITS WITH UNIVERSAL SPACING DRUM, USE CORRESPONDING STANDARD ADJUSTMENT.



(FRONT VIEW)
UNIVERSAL
SPACING
DRUM

(D) PRINTING CARRIAGE POSITION

USE PAR. 2.47


(E) TYPE BOX ALIGNMENT

USE PAR. 2.51

FOLLOWING THIS ADJUSTMENT, ALL SCREWS SHOULD BE TIGHTENED.

2.72 Line Feed and Platen Mechanism (Con't)

(A) LINE FEED SPUR GEAR DETENT ECCENTRIC
USE PAR. 2.57



(B) PRINTED LINE REQUIREMENT

THE BOTTOM OF THE PRINTED LINE SHOULD BE $1/32$ INCH \pm $1/64$ INCH (PLUS A MULTIPLE OF $1/6$ INCH IF REQUIRED) ABOVE A HORIZONTAL LINE DRAWN EVEN WITH THE BOTTOM EDGE OF ANY SPROCKET HOLE.

TO ADJUST

LOOSEN SCREWS AND POSITION LEFT SPROCKET. IF OTHER THAN STANDARD PAPER IS USED, IT MAY BE NECESSARY TO MAKE A VARIATION IN THIS ADJUSTMENT.

NOTE: SPUR GEAR AND LEFT PLATEN RETAINER MUST BE REMOVED TO MAKE PRINTED LINE ADJUSTMENT.

(C) PLATEN END PLAY REQUIREMENT

LINE FEED PAWLS DISENGAGED. PLATEN SHAFT SHOULD HAVE SOME END PLAY
MAX. 0.010 INCH

TO ADJUST

POSITION PLATEN SPUR GEAR WITH CLAMP SCREW LOOSENED.

(D) SPROCKET PIN SEPARATION

(1) REQUIREMENT


WITH SINGLE SHEET OF SPROCKET FEED PAPER PLACED ON THE PLATEN THE SPROCKET PINS SHOULD BE CENTRALLY LOCATED IN THE FEED HOLES OF THE PAPER

(2) REQUIREMENT


PRINTED LINE SHOULD BE PARALLEL TO A LINE DRAWN PERPENDICULAR TO EDGE OF PAPER WITHIN PLUS OR MINUS $1/32$ INCH

TO ADJUST

POSITION RIGHT SPROCKET WITH CLAMP SCREW LOOSENED.




(RIGHT SIDE SPROCKET)




SPROCKET CAM AND GEAR RETAINING SCREW

(LEFT SIDE SPROCKET)



(FRONT VIEW)

2.73 Line Feed and Platen Mechanism (Con't)



PAPER FINGER OR GUIDE BRACKET

(1) REQUIREMENT

SPROCKET PIN SHOULD BE CENTRALLY LOCATED IN THE PAPER FINGER OR GUIDE BRACKET SLOT.

(2) REQUIREMENT *

THE GAP BETWEEN THE PLATEN AND THE PAPER FINGER OR GUIDE BRACKET SHOULD BE

STAPLED
MULTIPLE COPY
 MIN. 0.050 INCH
 MAX. 0.105 INCH

SINGLE COPY OR
UNSTAPLED MULTIPLE COPY
 0.020 INCH
 0.060 INCH

TO ADJUST


WITH PAPER FINGER OR GUIDE BRACKET ASSEMBLY IN LATCHED POSITION, LOOSEN BOTH CLAMP SCREWS, POSITION ASSEMBLY HORIZONTALLY TO MEET REQUIREMENT (1). ROTATE ASSEMBLY TO MEET REQUIREMENT (2).

(3) REQUIREMENT (NOT ILLUSTRATED)

MIN. 0.035 INCH
 BETWEEN LEADING EDGE OF PAPER FINGER OR GUIDE BRACKET AND RIBBON GUIDE. BOTH RIGHT AND LEFT PAPER FINGERS MUST BE PARALLEL TO THE SAME PRINTED LINE AS GAUGED BY EYE.


TO ADJUST

SELECT LETTERS COMBINATION AND ROTATE TYPE BOX CLUTCH 1/2 REVOLUTION. POSITION PAPER FINGERS BY MEANS OF ELONGATED MOUNTING HOLES. AFTER TIGHTENING THE SCREWS RECHECK THESE REQUIREMENTS.



*NOTE --- A MINIMUM CLEARANCE THAT WILL PASS STATIONERY FREELY IS DESIRED. THIS MINIMUM VALUE IS DEPENDENT UPON TYPE OF PAPER, NUMBER OF COPIES, STAPLING ETC.

2.74 Line Feed and Platen Mechanism (Cont.)



(B) SPROCKET PIN SPRING
REQUIREMENT

MIN. 6 OZS.
MAX. 8 OZS.

TO START DEPRESSING THE PIN.

(A) PAPER GUIDE *
REQUIREMENT

THE CLEARANCE BETWEEN THE PLATEN AND THE FRONT EDGE OF THE PAPER GUIDE SHOULD BE

STAPLED		SINGLE COPY OR UNSTAPLED	
MULTIPLE COPY		MULTIPLE	COPY
MIN.	0.050 INCH	0.020 INCH	
MAX.	0.105 INCH	0.060 INCH	

TO ADJUST

POSITION THE GUIDE WITH ITS REAR MOUNTING SCREWS LOOSENED.


*NOTE --- A MINIMUM CLEARANCE THAT WILL PASS STATIONERY FREELY IS DESIRED. THIS MINIMUM VALUE IS DEPENDENT UPON TYPE OF PAPER, NUMBER OF COPIES, STAPLING ETC.

(C) RIBBON REVERSE SPUR GEAR
USE PAR. 2.52

(D) RIBBON REVERSE DETENT
USE PAR. 2.52

(E) LINE FEED BAR BELL CRANK SPRING
USE PAR. 2.57 EXCEPT
MIN. 28 OZS.
MAX. 38 OZS.
TO START BAR MOVING.

2.75 Line Feed and Platen Mechanism (Con't)



NOTE
 SPROCKET FEED MECHANISM WITH RETRACTABLE PINS


PAPER FINGER LOCKING ARM SPRING
 REQUIREMENT --- IT SHALL REQUIRE
 MIN 1 OZ --- MAX 1-1/2 OZS
 TO MOVE ARM AWAY FROM PLATEN

PLATEN DETENT BAIL SPRING
 USE PAR. 2.57

3. VARIABLE FEATURES

3.01 Horizontal Tabulator Mechanism

NOTE: FOR EARLIER DESIGN SEE PARS. 4.24 THROUGH 4.29.



REQUIREMENT


SPACING CLUTCH DISENGAGED. TRIP LEVER ARM AND INTERMEDIATE BAIL IN THEIR UPWARD POSITION. THE OUTER SURFACE OF THE TRIP LEVER SHOULD BE FLUSH WITH THE OUTER SURFACE OF THE SHOE LEVER OR UNDER FLUSH TO .010 INCH. CHECK AT STOP LUG WITH LEAST BITE.

TO ADJUST

USE ADJUSTING SCREW TO POSITION SPACING CLUTCH TRIP LEVER.

NOTE

IF THIS ADJUSTMENT IS CHANGED, CHECK THE LATCH BAIL ADJUSTING PLATE - PAR. 3.03



REQUIREMENT

SPACING CLUTCH ENGAGED. ROTATE CLUTCH UNTIL TRIP LEVER RESTS ON STOP LUG.

MIN. 11 OZS.

MAX. 16 OZS.

TO MOVE TRIP LEVER AWAY FROM STOP LUG.

3.02 Horizontal Tabulator Mechanism (Con't)

OPERATING LEVER SLIDE ARM

NOTE

PRIOR TO THIS ADJUSTMENT CHECK THE FUNCTION RESET BAIL BLADE ADJUSTMENT .
REQUIREMENT

ON UNITS WITH TWO-STOP FUNCTION CLUTCHES. FUNCTION CLUTCH DISENGAGED. TYPE BOX CLUTCH ROTATED 1/2 REVOLUTION PAST STOP POSITION. ON UNITS WITH ONE-STOP FUNCTION CLUTCH, ROTATE FUNCTION CLUTCH UNTIL FUNCTION PAWL STRIPPER BLADE IS IN ITS LOWER POSITION AND THE FUNCTION RESET BAIL ROLLER IS ON THE HIGH PART OF ITS CAM. HORIZONTAL TABULATOR FUNCTION PAWL PULLED TO REAR UNTIL LATCHED ON ITS FUNCTION BAR. CLEARANCE BETWEEN FRONT END OF OPERATING LEVER SLIDE ARM AND BLOCKING SURFACE OF BLOCKING LEVER MIN. 0.015 INCH---MAX. 0.035 INCH


TO ADJUST

POSITION SLIDE ARM ON OPERATING LEVER WITH MOUNTING STUD FRICTION TIGHT.

NOTE

WHEN PULLING FUNCTION PAWL TO THE REAR, IF THE OPERATING LEVER CAM ARM SHOULD BE STRIPPED OFF THE TABULATOR SLIDE ARM BEFORE THE FUNCTION PAWL IS LATCHED ON THE FUNCTION BAR, TEMPORARILY DISABLE THE STRIPPER BAIL ARM BY LOOSENING ITS ADJUSTING SCREW.

(LEFT VIEW)



OPERATING LEVER SLIDE ARM SPRING
REQUIREMENT

TRIP LEVER ARM LATCH BAIL SPRING UNHOOKED. OPERATING LEVER IN OPERATED POSITION WITH SLIDE ARM AGAINST BLOCKING LEVER. MIN. 8-3/4 OZS.---MAX. 10-3/4 OZS. TO START LINK MOVING.

NOTE

ON UNITS EQUIPPED WITH TRANSMITTER CONTROL CONTACT, HOLD CONTACT SPRING AWAY FROM STUD WHEN MEASURING TENSION.

OPERATING LEVER ADJUSTING PLATE
REQUIREMENT

OPERATING LEVER IN UNOPERATED POSITION. TAKE UP PLAY IN SLIDE ARM AND BLOCKING LEVER TO MINIMIZE CLEARANCE. CLEARANCE BETWEEN FRONT END OF SLIDE ARM AND LOWER PROJECTION OF BLOCKING LEVER MIN. 0.020 INCH---MAX. 0.045 INCH


TO ADJUST

POSITION ADJUSTING PLATE ON BRACKET WITH MOUNTING SCREWS LOOSENED.

NOTE

IF OPERATING LEVER SLIDE ARM OR OPERATING LEVER ADJUSTING PLATE ADJUSTMENT IS CHANGED ON UNITS EQUIPPED WITH TRANSMITTER CONTROL CONTACT, CHECK CONTROL CONTACT GAP AND REMAKE IF NECESSARY.

3.03 Horizontal Tabulator Mechanism (Con't)



TRIP LEVER ARM LATCH BAIL REQUIREMENT
 OPERATING LEVER UNOPERATED.
 TRIP LEVER ARM UP. CLEARANCE BETWEEN THE TRIP LEVER ARM AND THE TRIP LEVER ARM LATCH BAIL MIN. 0.020 INCH---MAX. 0.040 INCH
 TO ADJUST POSITION LATCH BAIL ADJUSTING SCREW WITH ITS LOCK NUT LOOSENED

TRIP LEVER ARM LATCH BAIL SPRING REQUIREMENT
 OPERATING LEVER UNOPERATED.
 MIN. 2-1/2 OZS.---MAX. 4-1/2 OZS.
 TO START LATCH BAIL MOVING.

INTERMEDIATE BAIL SPRING REQUIREMENT
 TRIP LEVER ARM AND INTERMEDIATE BAIL IN UNOPERATED POSITION.
 MIN. 1-1/2 OZS.---MAX. 3-1/2 OZS.
 TO PULL SPRING TO INSTALLED LENGTH.

LATCH BAIL ADJUSTING PLATE REQUIREMENT
 OPERATING LEVER SLIDE ARM POSITIONED TO REAR AND LATCHED ON BLOCKING LEVER. TRIP LEVER ARM LATCH BAIL IN FULLY LATCHED POSITION. SPACING TRIP LEVER DISENGAGED FROM INTERMEDIATE BAIL BY PUSHING FORWARD ON SPACE SUPPRESSION BAIL. CLEARANCE BETWEEN CLUTCH TRIP LEVER AND CLUTCH SHOE LEVER
 MIN. SOME---MAX. 0.008 INCH
 TO ADJUST POSITION LATCH BAIL ADJUSTING PLATE WITH MOUNTING SCREWS LOOSENED. CHECK AT THE CLUTCH SHOE LEVER WITH THE LEAST CLEARANCE.

3.04 Horizontal Tabulator Mechanism (Cont.)

HORIZONTAL TABULATOR SLIDE ARM SPRING

REQUIREMENT

OPERATING LEVER IN OPERATED POSITION.
SLIDE ARM IN UNOPERATED POSITION.
MIN. 1 OZ.
MAX. 4 OZS.
TO START SLIDE ARM MOVING.

OPERATING LEVER CAM ARM SPRING

HORIZONTAL TABULATOR SLIDE ARM SPRING

HORIZONTAL TABULATOR SLIDE ARM

STRIPPER BAIL ARM

STRIPPER BAIL ARM SCREW

STRIPPER BAIL

OPERATING LEVER

OPERATING LEVER CAM ARM

SPACING CAM

OPERATING LEVER CAM ARM SPRING

REQUIREMENT

OPERATING LEVER IN UNOPERATED POSITION. HORIZONTAL TABULATOR FUNCTION PAWL UNLATCHED.
MIN. 4 OZS.
MAX. 9 OZS.
TO START STRIPPER BAIL MOVING.

(LEFT SIDE VIEW)

CAM ARM STRIPPER BAIL

REQUIREMENT

OPERATING LEVER AND TABULATOR SLIDE ARM IN UNOPERATED POSITIONS. SPACING CLUTCH ROTATED UNTIL HIGH PART OF SPACING CAM IS OPPOSITE STRIPPER BAIL. CLEARANCE BETWEEN SPACING CAM AND STRIPPER BAIL

MIN. 0.010 INCH
MAX. 0.025 INCH

TO ADJUST

POSITION STRIPPER BAIL ARM ON STRIPPER BAIL WITH STRIPPER BAIL ARM SCREW FRICTION TIGHT.

TRANSFER BAIL EXTENSION ARM

SPACING CUT-OUT TRANSFER BAIL

SET COLLAR

ADJUSTING SCREW

(BOTTOM VIEW)

SPACING CUT-OUT TRANSFER BAIL

SET COLLAR

REQUIREMENT

TRANSFER BAIL SHOULD HAVE SOME END PLAY.
MAX. 0.008 INCH
TO ADJUST POSITION SET COLLAR WITH ADJUSTING SCREW LOOSENED.

SECTION 573-115-700

3.05 Horizontal Tabulator Mechanism (Cont.)

SPACE SUPPRESSION
BY-PASS SPRING

REQUIREMENT
MIN. 20 OZS.
MAX. 26 OZS.
TO START BAIL
EXTENSION MOVING

RIGHT MARGIN

REQUIREMENT
CLEARANCE BETWEEN SPACING CUT-OUT
LEVER ON SPACING DRUM AND BAIL
EXTENSION ARM
MIN. 0.006 INCH
MAX. 0.025 INCH

TO CHECK
PLACE TYPE BOX IN POSITION TO PRINT
CHARACTER ON WHICH SPACING CUT-OUT
IS DESIRED. PULL FORWARD ON PART OF
TRANSFER BAIL EXTENDING BELOW MOUNT-
ING SHAFT UNTIL BAIL IS IN FULLY OPERATED
POSITION. GAGE CLEARANCE.

TO ADJUST
POSITION CUT-OUT LEVER WITH CLAMP
SCREW LOOSENED.

NOTE

FOUR SCREWS MUST BE LOOSENED TO
ADJUST CIRCULAR CUT-OUT LEVERS. DO
NOT LOOSEN HEX. HEAD SCREW THAT
CLAMPS FRONT RING.

SPACING CUT-OUT TRANSFER BAIL


BAIL EXTENSION ARM

SPACING CUT-OUT LEVER
ON SPACING DRUM

SPACE SUPPRESSION BY-PASS SPRING

(RIGHT SIDE VIEW)

3.03 Horizontal Tabulator Mechanism (Con't)

**TABULATOR PAWL (PRELIMINARY)****NOTE:**

BEFORE MAKING THIS ADJUSTMENT, CHECK LEFT MARGIN AND SPACING GEAR PHASING ADJUSTMENTS.

PURPOSE

TO SELECT TABULATOR STOP TO BE USED AS REFERENCE IN MAKING FINAL TABULATOR PAWL HORIZONTAL AND VERTICAL ADJUSTMENTS.

PROCEDURE

- (1) BEGINNING WITH 15TH SLOT COUNTERCLOCKWISE FROM ROLLER ON TABULATOR RING, PLACE TABULATOR STOPS APPROXIMATELY AN EQUAL NUMBER OF SLOTS APART AROUND REMAINING SLOTTED PERIPHERY OF RING CORRESPONDING TO LENGTH OF PRINTED LINE.
- (2) TO MOVE STOPS, HOOK SMALL SPRING HOOK IN HOLE AND PULL OUT RADially FROM DRUM. HOLDING STOP AWAY FROM DRUM, SLIDE IT ON GARTER SPRING TO DESIRED LOCATION AND INSERT IN SLOT. SPACING DRUM MAY HAVE TO BE ROTATED TO MAKE SOME SLOTS ACCESSIBLE. CAUTION: MAKE SURE ALL STOPS ARE FIRMLY SEATED AND NOT TURNED SIDWAYS. DO NOT USE PLIERS TO MOVE STOPS.
- (3) DISENGAGE ALL CLUTCHES SO FRONT SPACING FEED PAWL IS IN LOWER POSITION. PLACE PAWL ADJUSTING PLATE AT CENTER OF HORIZONTAL AND VERTICAL ADJUSTMENT: TO ADJUST VERTICALLY, LOOSEN BOTH MOUNTING SCREWS: TO ADJUST HORIZONTALLY, LOOSEN ONLY LEFT SCREW. HORIZONTAL ADJUSTMENT SHOULD BE MADE AFTER VERTICAL. DISENGAGE SPACING FEED PAWLS AND ALLOW DRUM TO ROTATE TO EXTREME COUNTERCLOCKWISE POSITION. KEEPING SPACING CLUTCH DISENGAGED, MANUALLY ADVANCE DRUM UNTIL FIRST STOP IS IMMEDIATELY TO LEFT OF PAWL. POSITION ADJUSTING PLATE HORIZONTALLY SO THAT STOP IS ALIGNED WITH LEFT EDGE OF PAWL SHOULDER.
- (4) PLACE BLOCKING LEVER AND OPERATING LEVER SLIDE ARM IN UNBLOCKED POSITION. DISENGAGE FEED PAWLS AND LET DRUM ROTATE TWO SPACES COUNTERCLOCKWISE. BOTH FEED PAWLS SHOULD BE FULLY ENGAGED. BLOCK SLIDE ARM WITH BLOCKING LEVER. GAGE AND NOTE CLEARANCE BETWEEN STOP AND SLOPE ON PAWL.
- (5) ROTATE DRUM CLOCKWISE UNTIL NEXT STOP IS JUST TO LEFT OF PAWL. REPEAT PROCEDURE DESCRIBED IN PARAGRAPH (4) FOR THIS STOP. REPEAT PROCEDURE FOR REMAINING STOPS, NOTING EACH CLEARANCE.
- (6) STOP WITH MAXIMUM CLEARANCE SHOULD BE USED AS REFERENCE IN MAKING FINAL HORIZONTAL AND VERTICAL PAWL ADJUSTMENTS.

3.07 Horizontal Tabulator Mechanism (Cont.)

TABULATOR PAWL - VERTICAL (FINAL)

TO CHECK


POSITION SPACING DRUM SUCH THAT REFERENCE TABULATOR STOP, AS DETERMINED BY PRELIMINARY TABULATOR PAWL ADJUSTMENT (PAR. 3.06), IS OPPOSITE SHOULDER ON PAWL. BLOCK OPERATING LEVER SLIDE ARM WITH BLOCKING LEVER.

REQUIREMENT

CLEARANCE BETWEEN PAWL AND STOP:
MIN. 0.055 INCH MAX. 0.075 INCH

TO ADJUST

POSITION PAWL ADJUSTING PLATE WITH BOTH MOUNTING SCREWS LOOSENED. TIGHTEN RIGHT SCREW ONLY, USING WRENCH TO PREVENT BUSHING FROM TURNING.



TABULATOR PAWL SPRING
REQUIREMENT

MIN. 3 OZS. MAX. 5 OZS.
TO START PAWL MOVING.


BLOCKING LEVER SPRING
TO CHECK

HOLD OPERATING LEVER SLIDE ARM TO THE REAR.

REQUIREMENT

MIN. 2-1/2 OZS. MAX. 4-1/2 OZS.
TO START BLOCKING LEVER MOVING.

3.08 Horizontal Tabulator Mechanism (Cont.)



TABULATOR PAWL - HORIZONTAL (FINAL)
TO CHECK

(1) DISENGAGE ALL CLUTCHES SO THAT FRONT SPACING FEED PAWL IS IN LOWER POSITION (AS SHOWN IN PAR. 3.06). POSITION SPACING DRUM SO THAT REFERENCE TABULATOR STOP, AS DETERMINED IN PRELIMINARY TABULATOR PAWL ADJUSTMENT (PAR. 3.06), IS IMMEDIATELY TO LEFT OF PAWL. OPERATING LEVER SLIDE ARM SHOULD BE FORWARD IN UNBLOCKED POSITION. DISENGAGE FEED PAWLS AND ALLOW DRUM TO ROTATE ONE SPACE COUNTER-CLOCKWISE. BOTH FEED PAWLS SHOULD BE FULLY ENGAGED. MOVE SLIDE ARM TO REAR TO BLOCKED POSITION.

(2) TRIP SPACING CLUTCH STOP LEVER AND SLOWLY ROTATE MAIN SHAFT UNTIL BLOCKING LEVER IS JUST TRIPPED. TAKE UP PLAY IN SPACING SHAFT TOWARD REAR.

REQUIREMENT

SOME PORTION OF CLUTCH DISK STOP LUG SHOULD BE ALIGNED WITH REAR SURFACE OF SPACING SHAFT GEAR.


TO ADJUST

REPEAT PROCEDURE SET FORTH IN PARAGRAPH (1) ABOVE. TRIP SPACING CLUTCH AND ROTATE SHAFT UNTIL MIDDLE OF STOP LUG IS IN LINE WITH REAR SURFACE OF GEAR. IF BLOCKING LEVER TRIPPED TOO SOON, WITH LEFT MOUNTING SCREW LOOSENED, POSITION PAWL ADJUSTING PLATE TO LEFT UNTIL SLIDE ARM CAN BE BLOCKED. SLOWLY MOVE PLATE TO RIGHT UNTIL BLOCKING LEVER JUST TRIPS. WHEN ADJUSTING TRIP-OFF POINT, CARE SHOULD BE TAKEN THAT BLOCKING LEVER IS CAMMED DOWN BY STOP AND NOT MANUALLY MOVED OUT OF BLOCKED POSITION BY ACCIDENT. RECHECK REQUIREMENT.


NOTE:

AFTER OBTAINING TRIP-OFF POINT, CONTINUE ROTATING MAIN SHAFT UNTIL SPACING CLUTCH IS DISENGAGED. PAWL SHOULD BE TO RIGHT OF STOP. WHEN SLIDE ARM IS MOVED TO REAR, BLOCKING LEVER SHOULD MOVE TO BLOCKED POSITION. IF TIP OF PAWL SHOULD REST ON END OF STOP, READJUST PLATE TO RIGHT SO THAT CLEARANCE BETWEEN PAWL AND STOP IS:

MIN. 0.003 --- MAX. 0.008



3.09 Horizontal Tabulator Mechanism (Cont.)

TABULATOR STOP SETTINGS

NOTE:

FOR INSTRUCTIONS ON HOW TO MOVE TABULATOR STOPS, SEE TABULATOR PAWL PRELIMINARY ADJUSTMENT. PAR. 3.06 (2)

(1) COLUMNAR TABULATOR STOPS

PLACE CARRIAGE IN POSITION TO PRINT FIRST CHARACTER IN COLUMN. PLACE STOP IN SLOT IMMEDIATELY TO LEFT OF PAWL. TO FACILITATE INSERTING STOPS, MARK DESIRED SLOT AND ROTATE DRUM TO MORE ACCESSIBLE POSITION. FOR SETTINGS NEAR LEFT MARGIN, COUNT NUMBER OF SPACING OPERATIONS FROM LEFT MARGIN AND PLACE STOP CORRESPONDING NUMBER OF SLOTS COUNTERCLOCKWISE FROM ROLLER.

NOTE: WHEN PRINTING FORMS, CHECK STOP SETTINGS IN RELATION TO COLUMNS. CORRESPONDING STOPS ON ALL MACHINES ON A CIRCUIT MUST BE THE SAME NUMBER OF SLOTS FROM LEFT MARGIN.

(2) RIGHT MARGIN TABULATOR STOP (WITH WIDE SHELF)

NOTE: BEFORE MAKING THIS ADJUSTMENT, CHECK RIGHT MARGIN AND TABULATOR PAWL ADJUSTMENTS.

POSITION PRINTING CARRIAGE AT RIGHT MARGIN (SPACING CUTOUT OPERATED). INSERT STOP WITH WIDE SHELF IN SLOT IMMEDIATELY TO LEFT OF PAWL. SHELF SHOULD EXTEND TO RIGHT SO THAT PAWL RESTS ON IT.

3.10 Horizontal Tabulator Mechanism (Cont.)

NOTE

THE FOLLOWING TWO HORIZONTAL TABULATOR MECHANISM ADJUSTMENTS SHOULD BE CHECKED BEFORE MAKING THE TRANSMITTER CONTROL

ADJUSTMENTS SHOWN BELOW.

1. OPERATING LEVER SLIDE ARM (PAR. 3.02)
2. OPERATING LEVER ADJUSTING PLATE (PAR. 3.02)

IF EITHER OF THE ABOVE ADJUSTMENTS ARE CHANGED, THE TRANSMITTER CONTROL ADJUSTMENTS SHOULD BE RECHECKED.

TRANSMITTER CONTROL CONTACT SPRING

REQUIREMENT

OPERATING LEVER IN UNOPERATED POSITION.


MIN. 3-1/2 OZS.

MAX. 4-1/2 OZS.

TO JUST OPEN CONTACTS.

TO ADJUST

BEND THE LONG CONTACT SPRING



TRANSMITTER CONTROL CONTACT GAP

REQUIREMENT

OPERATING LEVER SLIDE ARM PULLED TO REAR UNTIL BLOCKED BY BLOCKING LEVER. CLEARANCE BETWEEN CONTACTS


MIN. 0.010 INCH

MAX. 0.020 INCH

TO ADJUST

POSITION THE CONTACT ASSEMBLY BRACKET WITH THE MOUNTING SCREW LOOSENED. THE BRACKET PIVOTS ABOUT A PIN AT THE UPPER END OF THE BRACKET.

3.11 Page Feed-Out Mechanism




3.12 Page Feed-Out Mechanism (Cont.)

(F) POINTER

REQUIREMENT

LINE FEED CLUTCH DISENGAGED.
INDEX PLATE ADJACENT TO BAIL
AS SHOWN IN PAR. 3.11. POINTER
SHOULD LINE UP WITH NOTCH IN
INDEXING DISK AND CLEAR DISK BY
APPROXIMATELY 1/16 INCH.

TO ADJUST
POSITION POINTER WITH MOUNTING
SCREWS LOOSENED.



(C) BLOCKING ARM

REQUIREMENT

BAIL ON PEAK OF INDEX
PLATE. CLEARANCE
MIN. 0.005 INCH
MAX. 0.045 INCH

TO ADJUST
POSITION ADJUSTABLE ARM
WITH MOUNTING SCREWS
LOOSENED.

NOTE

IF REQUIREMENT CANNOT
BE MET FOR EACH PLATE,
REPOSITION PLATE WITH
MOUNTING SCREW LOOSENED.

(H) BLOCKING ARM SPRING


REQUIREMENT

BLOCKING ARM IN UNBLOCKED
POSITION.
MIN. 3 OZS.
MAX. 5 OZS.
TO PULL SPRING TO OPERATING
LENGTH.

3.13 Selective Calling Mechanism

TYPE BOX CLUTCH TRIP LEVER
 (SELECTIVE - CALLING UNITS WITH OR WITHOUT
 OFF-LINE SHIFT SOLENOID)
 CLEARANCE BETWEEN TYPE BOX CLUTCH TRIP
 LEVER AND CLUTCH DISK STOP LUG SHOULD BE
 MIN. 0.040 INCH---MAX. 0.055 INCH
 SEE PAR. 2.22.

PRINT SUPPRESSOR CODE BAR SPRING
REQUIREMENT
 SUPPRESSOR CODE BAR TO LEFT.
 MIN. 4-1/2 OZS.---MAX. 7-1/2 OZS.
 TO START CODE BAR MOVING. CODE
 BAR SHOULD BE FREE OF BINDS.



NOTE: TO CHECK REQUIREMENTS (A, B, AND D), SET
 FUNCTION CLUTCH IN STOP POSITION AND
 ALL CODE BARS TO THE RIGHT.

(A) CODE BAR SHIFT MECHANISM
REQUIREMENTS

1. WITH FUNCTION CLUTCH IN STOP POSITION, LATCH FUNCTION LEVER (SHIFT MECH.)
 ON ITS LOWER RELEASING LATCH. NOTCH IN SUPP. CODE BAR SHOULD ALIGN WITH
 NOTCHES IN OTHER CODE BARS WHEN ALL CODE BARS ARE SHIFTED TO THE RIGHT.
 TO ADJUST

POSITION UPPER OR LOWER GUIDE PLATE (PAR. 2.33) WITH ITS CLAMP NUTS LOOSENED.

2. REPEAT FOR EACH STUNT CASE CODE BAR SHIFT MECHANISM.

NOTE --- POSITION THE ASSOCIATED GUIDE PLATE SO THAT THE MOVEMENT OF THE
 FORK IS NOT RESTRICTED WITHIN THE RANGE OF ADJUSTMENT.

(D) OFF LINE SHIFT SOLENOID BRACKET ASSEMBLY (OFF LINE ONLY)
REQUIREMENT

NOTCH IN SUPPRESSION CODE BAR SHOULD ALIGN
 WITH NOTCHES IN OTHER CODE BARS WHEN ALL
 CODE BARS ARE SHIFTED TO THE RIGHT.

TO ADJUST

POSITION THE SOLENOID BRACKET ASSEMBLY WITH
 ITS MOUNTING SCREWS LOOSENED.

(C) TYPE BOX CLUTCH SUPPRESSION ARM
 SEE PAR. 3.14


(B) CONDITION CODE (ZERO) CODE BAR SHIFT MECHANISM
REQUIREMENT

WITH FUNCTION CLUTCH IN STOP POSITION, LATCH FUNCTION LEVER (SHIFT
 MECH.). THE NOTCH IN CONDITION CODE (ZERO) CODE BAR SHOULD ALIGN
 WITH NOTCHES IN OTHER CODE BARS WHEN ALL CODE BARS ARE SHIFTED TO THE
 RIGHT.

TO ADJUST

POSITION THE UPPER OR LOWER GUIDE PLATE (PAR. 2.33) WITH ITS CLAMP NUTS
 LOOSENED.

NOTE --- POSITION THE ASSOCIATED GUIDE PLATE SO THAT THE MOVEMENT OF THE
 FORK IS NOT RESTRICTED.



3.14 Selective Calling Mechanism (Con't)

(C) TYPE BOX CLUTCH SUPPRESSION ARM (WITH OR WITHOUT SOLENOID SHIFT)


REQUIREMENT

SUPPRESSION ARM IN BLOCKING POSITION. SHAFT ROTATED UNTIL THE FUNCTION CLUTCH SHOE LEVER IS OPPOSITE THE FUNCTION CLUTCH TRIP LEVER.

1. AT LEAST 0.003 INCH CLEARANCE BETWEEN TRIP ARM EXTENSION AND CLUTCH TRIP LEVER.
2. AT LEAST 0.006 INCH CLEARANCE BETWEEN THE FUNCTION CLUTCH SHOE LEVER AND FUNCTION CLUTCH TRIP LEVER.

TO ADJUST

POSITION SUPPRESSION ARM WITH ITS MOUNTING SCREWS LOOSENED.



OFF LINE STUNT SHIFT SOLENOID SPRING
REQUIREMENT
 WITH SOLENOID UNOPERATED.
 MIN. 2 OZS. MAX. 4-1/2 OZS.
 TO PULL SPRING TO ITS INSTALLED LENGTH.

SUPP
 4
 1
 5
 2
 3
 COMM.
 0
 5

CODE BARS

BLOCKING BAIL
REQUIREMENT


1. LATCH FUNCTION LEVER OF ANY STUNT CASE CODE BAR SHIFT MECHANISM AND ROTATE MAIN SHAFT UNTIL LOWER SURFACE OF THE SUPPRESSION ARM IS ALIGNED (APPROX) WITH BOTTOM SURFACE OF THE BLOCKING BAIL EXTENSION. CLEARANCE BETWEEN SUPPRESSION ARM AND BLOCKING BAIL EXTENSION, WITH PLAY TAKEN UP TO PRODUCE MINIMUM CLEARANCE.
 MIN. 0.008 INCH ————— MAX. 0.055 INCH

TO ADJUST

POSITION EXTENSION WITH ITS MOUNTING SCREW LOOSENED. REFINE THE ADJUSTMENT IF NECESSARY, AND RECHECK EACH SHIFT MECHANISM.

2. REFINE THE STUNT CASE CODE BAR SHIFT MECHANISM ADJUSTMENT OF ANY SHIFT MECHANISM THAT DOES NOT MEET THE ABOVE REQUIREMENT.

3.15 Selective Calling Mechanism (Cont.)



CONDITION CODE SHIFT FORK SPRING


REQUIREMENT

WITH CONDITION CODE SHIFT IN ITS UNOPERATED POSITION.

MIN. 1 OZ.

MAX. 3 OZS.

TO PULL SPRING TO ITS INSTALLED POSITION.



(TOP VIEW)

AUTOMATIC CARRIAGE RETURN - LINE FEED BLOCKING SLIDE SPRING

REQUIREMENT



WITH CONDITION CODE SHIFT FORK IN ITS UNOPERATED POSITION.

MIN. 1 OZ.


MAX. 3 OZS.

TO PULL SPRING TO ITS INSTALLED POSITION

3.16 Local Back Space Mechanism



3. 17 Reverse Line Feed Mechanism



REVERSE LINE FEED SLIDE LINK SPRING REQUIREMENT
SLIDE LINK RESTING ON ITS STOP BRACKET,
LINE FEED CLUTCH DISENGAGED.
MIN. 1-1/2 OZS.
MAX. 3-1/2 OZS.
TO PULL SPRING TO INSTALLED LENGTH.

REVERSE LINE FEED SLIDE LINK STOP BRACKET REQUIREMENT

WHEN THE LINE FEED BAR IS NEAREST THE SLIDE LINK STOP BRACKET DURING A FORWARD LINE FEED OPERATION, THERE SHOULD BE A MINIMUM OF 0.045 INCH CLEARANCE BETWEEN TOP SURFACE OF SLIDE LINK AND LOWER EDGE OF CLOSEST LINE FEED BAR.

TO ADJUST
POSITION THE SLIDE LINK STOP BRACKET WITH
ITS MOUNTING SCREWS LOOSENED.

3.18 Reverse Line Feed Mechanism (Cont.)


LINE FEED CLUTCH SPUR GEAR REQUIREMENT

LINE FEED CLUTCH DISENGAGED. SLIDE LINK RAISED UPWARD SO AS TO FULLY ENGAGE THE END OF THE LOWER LINE FEED BAR, SLIDE HELD FORWARD BY ITS SPRING CLEARANCE BETWEEN SLIDE LINK AND LOWER LINE FEED BAR.


MIN. 0.005 INCH
MAX. 0.040 INCH

TO ADJUST


SET LINE FEED CLUTCH SPUR GEAR AT CENTER OF ADJUSTING RANGE DISENGAGE LINE FEED CLUTCH, LOOSEN ECCENTRIC ASSEMBLY BEARING POST. MESH THE TWO GEARS SO THAT THE FORWARD EDGES OF THE LOWER ENDS OF THE LINE FEED BARS ARE IN LINE WITH EACH OTHER WITHIN 0.040 INCH. ROTATE THE LINE FEED CLUTCH SPUR GEAR RELATIVE TO ITS MOUNTING PLATE WITH THE GEAR MOUNTING SCREWS LOOSENED. CHECK BOTH BARS FOR THE REQUIRED CLEARANCE AT EACH STOP POSITION OF THE CLUTCH



3.19 Reverse Line Feed Mechanism (Cont.)



3.20 Reverse Line Feed Mechanism (Cont.)



LINE FEED BAR SPRINGS

REQUIREMENT


LINE FEED BAR ENGAGED
WITH PLATEN GEAR.

MIN. 2-1/2 OZS.


MAX. 5 OZS.

TO PULL EACH SPRING
TO INSTALLED LENGTH.


3.21 Reverse Line Feed Mechanism (Cont.)



3.22 Answer-Back Mechanism (Switched Circuit Network)




3.23 Print Suppression Mechanism



3.24 Continuous Spacing Mechanism

SOLENOID PLUNGER SPRING REQUIREMENT

SOLENOID DE-ENERGIZED, SPRING UNHOOKED
MIN. 1-1/2 OZS.
MAX. 3 OZS.
TO PULL SPRING TO POSITION LENGTH.




FUNCTION CLUTCH TRIP LEVER REQUIREMENT

WITH THE SOLENOID DE-ENERGIZED AND THE FUNCTION CLUTCH DISENGAGED, THE FUNCTION CLUTCH TRIP LEVER SHOULD ENGAGE THE CLUTCH SHOE LEVER BY THE FULL THICKNESS OF THE SHOE LEVER (CHECK AT LUG WITH LEAST BITE ON TWO STOP CLUTCHES).

TO ADJUST POSITION THE SOLENOID MOUNTING PLATE WITH ITS MOUNTING SCREWS LOOSENED. IN POSITIONING THE PLATE MOVE EACH END EQUALLY TO AVOID BINDS IN THE SOLENOID PLUNGER AND FUNCTION CLUTCH TRIP LEVER.

3.25 Continuous Spacing Mechanism (Cont.)



SUPPRESSION BAIL ADJUSTING BRACKET REQUIREMENT

FUNCTION CLUTCH ROTATED UNTIL SUPPRESSION BAIL IS IN EXTREME FORWARD POSITION. CR AND LF FUNCTION SLIDE ARMS MANUALLY PUSHED FORWARD UNTIL THE CR AND LF LEVERS ARE TRIPPED. SLIDE ARMS RESTING BACK AGAINST THEIR SLIDE ARM BRACKETS. CLEARANCE BETWEEN PROJECTION ON CR SLIDE ARM AND GUIDE BAR

MIN. 0.070 INCH --- MAX. 0.095 INCH

TO ADJUST

POSITION THE CONNECTING LINK ON THE ADJUSTING BRACKET WITH ITS CLAMP SCREW LOOSENED. RECHECK AFTER TIGHTENING SCREW. ON TWO-STOP CLUTCHES, CHECK WITH CLUTCH IN EACH POSITION.

NOTE

BEFORE MAKING THE FOLLOWING ADJUSTMENT CHECK THE CARRIAGE RETURN LEVER ADJUSTMENT. WITH THE STUNT BOX REMOVED, THE STANDARD ADJUSTING PROCEDURE CANNOT BE FOLLOWED. REFER TO PAR. 2.40 AND USE THE FOLLOWING PROCEDURE.

CARRIAGE RETURN LEVER REQUIREMENT

CLEARANCE BETWEEN CARRIAGE RETURN LATCH BAIL AND CARRIAGE RETURN LEVER (PAR. 2.40)

SHOULD BE

MIN. 0.006 INCH---MAX. 0.040 INCH

TO CHECK

PRINTING CARRIAGE IN RETURNED POSITION. TRIP FUNCTION CLUTCH AND ROTATE MAIN SHAFT UNTIL SUPPRESSION BAIL IS IN EXTREME FORWARD POSITION. LOCATE SPACING DRUM SO THAT CARRIAGE RETURN LATCH BAIL RESETS AGAINST CARRIAGE RETURN LEVER EXTENSION.

TO ADJUST


POSITION CR LEVER ON CR LATCH BAIL WITH CLAMP SCREW LOOSENED.

RESET BAIL OPERATING SPRING REQUIREMENT

FUNCTION RESET BAIL IN FORWARD POSITION

MIN. 2-1/4 LBS. ---MAX. 3-1/2 LBS.

TO START BAIL MOVING.



(LEFT SIDE VIEW)


3.26 Paper-Out Alarm Mechanism

FOR EARLY DESIGN
SEE PARAGRAPH 4.30

(A) SWITCH POSITION

REQUIREMENT --- HORIZONTAL AXIS OF SWITCH SHALL LIE IN A PLANE PARALLEL TO THE SWITCH BRACKET WHEN THE SWITCH IS MOVED TOWARD UPPER LIMIT OF ITS TRAVEL IN THE MOUNTING HOLES.

TO ADJUST --- WITH ITS MOUNTING SCREWS (2) LOOSENED, POSITION AND ALIGN THE SWITCH.




(C) SWITCH BRACKET SPRING

REQUIREMENT --- WITH SPRING SCALE APPLIED AT THE TOP SWITCH BRACKET OPERATING LEVER NEAR SPRING HOOK, IT SHALL REQUIRE MIN. 11 OZS. --- MAX. 18 OZS. TO MOVE SWITCH BRACKET CLEAR OF SWITCH PLUNGER (GAUGE BY EYE)

(B) SWITCH OPERATING LEVER

REQUIREMENT --- WITH PAPER ROLL REMOVED, UPPER SURFACE OF SWITCH BRACKET OPERATING LEVER SHALL LIE IN A PLANE THAT IS PARALLEL WITH UNDER SIDE OF HEXAGONAL PAPER SPINDLE AND REST APPROXIMATELY 1/4 INCH FROM THE SPINDLE.

TO ADJUST --- LOOSEN SCREW THAT SECURE THE SWITCH ASSEMBLY MOUNTING BRACKET AND POSITION THE ASSEMBLY UPWARD OR DOWNWARD.



3.27 Vertical Tabulation and Transmitter Distributor Control Mechanism

(C) PAGE FEED-OUT GEAR PLAY
REQUIREMENT

BARELY PERCEPTIBLE BACKLASH BETWEEN IDLER GEAR AND FEED-OUT GEAR

TO ADJUST
POSITION GEAR PIVOT POST WITH NUT LOOSENED.

NOTE: GEARS SHOULD MESH ACCURATELY WHEN CHECKED AT 3 EQUAL DISTANCES AROUND CIRCUMFERENCE OF GEAR.


(D) BLOCKING LEVER
SEE PAR. 3.28

(E) INDEXING DISK
REQUIREMENT

CLEARANCE BETWEEN INDEX PLATE AND PAWL SHOULD BE
MIN. 0.015 INCH---MAX. 0.040 INCH

TO CHECK
LINE FEED CLUTCH DISENGAGED. INDEX PLATE ADJACENT TO PAWL. SLACK IN GEARS TAKEN UP TO MAKE GAP A MINIMUM.

TO ADJUST
PULL FEED-OUT GEAR OUT OF ENGAGEMENT WITH IDLER GEAR. TURN FEED-OUT GEAR HAND WHEEL CLOCKWISE UNTIL INDEX PLATE JUST OPERATES THE PAWL, THEN ENGAGE FIRST TOOTH ON IDLER. POSITION INDEXING DISK WITH THREE MOUNTING SCREWS LOOSENED.



(A) VERTICAL TABULATOR SLIDE RETAINER
ON UNITS SO EQUIPPED
REQUIREMENT

CLEARANCE BETWEEN VERTICAL TAB SLIDE AND RETAINING EDGE OF RETAINER SHOULD BE
MIN. SOME---MAX. 0.012

TO ADJUST
POSITION RETAINER FORWARD AND LOCATE IT UP OR DOWN WITH MOUNTING SCREWS LOOSENED.

(B) MOUNTING BRACKET
REQUIREMENT

1. CLEARANCE BETWEEN FEED-OUT BLOCKING LEVER (INNER LEVER) AND FEED-OUT SLIDE
MIN. SOME---MAX. 0.020 INCH

TO CHECK
SELECT UPPER CASE "Z" AND ROTATE MAIN SHAFT UNTIL PAGE FEED-OUT SLIDE IS IN ITS MOST FORWARD POSITION. TAKE UP PLAY IN PAGE FEED-OUT BLOCKING LEVER TO MAKE CLEARANCE A MINIMUM.

2. CLEARANCE BETWEEN VERTICAL TAB SLIDE AND VERTICAL TAB BLOCKING LEVER (OUTER LEVER) --- MIN. 0.002 INCH

TO CHECK
SELECT UPPER CASE "J" AND ROTATE MAIN SHAFT UNTIL VERTICAL TAB SLIDE IS IN ITS MOST FORWARD POSITION. TAKE UP PLAY IN VERTICAL TAB BLOCKING LEVER TO MAKE CLEARANCE A MINIMUM.

TO ADJUST
POSITION LOWER PORTION OF MOUNTING BRACKET WITH MOUNTING SCREWS LOOSENED.

3.28 Vertical Tabulation and Transmitter Distributor Control Mechanism (Cont.)

(H) POINTER

REQUIREMENT


LINE FEED CLUTCH DISENGAGED. INDEX PLATE ADJACENT TO PAWL. POINTER SHOULD LINE UP WITH NOTCH IN INDEXING DISK AND CLEAR ANY INDEX PLATE BY APPROXIMATELY 1/16 INCH.

TO ADJUST

POSITION POINTER ON SIDE FRAME WITH ITS MOUNTING SCREW LOOSENED.

(I) PAGE FEED-OUT INDEX PLATE POSITION
SEE PAR. 3.31

(J) TABULATION INDEX PLATE POSITION
SEE PAR. 3.30



(F) SWITCH CONTACT PRESSURE
(TRANSMITTER CONTROL ONLY)
REQUIREMENT

CONTACTS CLOSED
MIN. 2 OZS. --- MAX. 3 OZS.
TO MOVE CONTACT SWINGER AWAY
FROM ITS MATING CONTACT.
TO ADJUST --- BEND SWINGER

* TRANSFER TYPE CONTACTS SEE PARS. 3.29 AND 3.30


(D) BLOCKING LEVER
REQUIREMENT

CLEARANCE BETWEEN BOTTOM OF BLOCKING LEVER AND TOP OF SLIDE WHEN PAWL IS ON PEAK OF INDEX PLATE SHOULD BE
MIN. 0.005 INCH --- MAX. 0.045 INCH

TO ADJUST

TRIP LINE FEED CLUTCH. ROTATE MAIN SHAFT UNTIL PAWL IS ON PEAK OF INDEX PLATE. POSITION ADJUSTABLE ARM WITH MOUNTING SCREWS LOOSENED. MAKE ADJUSTMENT FOR EACH BLOCKING LEVER.

3.29 Vertical Tabulation and Transmitter Distributor Control Mechanism (Cont.)

TRANSMITTER CONTROL SWITCH (TRANSMITTER CONTROL ONLY)REQUIREMENTS --- FOR TRANSFER TYPE CONTACTS


1. WITH NORMALLY CLOSED (LOWER) CONTACTS CLOSED, CLEARANCE BETWEEN INSULATED EXTENSION OF SWINGER AND LOBES OF FEED-OUT AND VERTICAL TABULATOR BLOCKING LEVER SHALL BE MIN. SOME CLEARANCE ----- MAX 0.005 INCH

TO CHECK --- ROTATE MAINSHAFT UNTIL FEED-OUT AND VERTICAL TABULATOR BLOCKING LEVERS ARE UNOPERATED (BLOCKING LEVERS RESTING ON SLIDES).

TO ADJUST - WITH TRANSMITTER CONTROL SWITCH MOUNTING SCREWS LOOSENED, POSITION THE CONTACT ASSEMBLY.

2. WITH THE NORMALLY OPEN (UPPER) CONTACTS CLOSED
- LOBE OF FEED-OUT BLOCKING LEVER (INNER LEVER) SHALL FULLY ENGAGE INSULATED EXTENSION OF CONTACT SWINGER.
 - THE FEED-OUT BLOCKING LEVER SHALL REST FIRMLY ON THE FUNCTION ARM GUIDE BAR (INTERNAL --- CHECK BY LIFTING LEVER LIGHTLY AT CONTACT END) AND ALSO SEPARATE THE NORMALLY OPEN CONTACT SPRING FROM ITS STIFFENER AS THE UPPER CONTACT CLOSES.
- TO CHECK --- SELECT FEED-OUT CODE COMBINATION, ROTATE MAIN SHAFT UNTIL FEED-OUT SLIDE IS IN ITS EXTREME FORWARD POSITION AND FEED-OUT BLOCKING LEVER DROPS BEHIND ITS SLIDE TO CLOSE NORMALLY OPENED CONTACTS.
- TO ADJUST --- WITH CONTACT PILE-UP MOUNTING SCREWS LOOSENED, POSITION THE ASSEMBLY.
3. WITH THE NORMALLY OPEN (UPPER) CONTACTS CLOSED
- LOBE OF VERTICAL TABULATOR BLOCKING LEVER (OUTER) SHALL FULLY ENGAGE THE INSULATED EXTENSION OF THE SWINGER.
 - THE VERTICAL TABULATOR BLOCKING LEVER SHALL REST FIRMLY ON THE FUNCTION ARM GUIDE BAR (INTERNAL --- CHECK BY LIFTING LEVER LIGHTLY AT CONTACT END.) AND ALSO SEPARATE NORMALLY OPEN CONTACT SPRING FROM ITS STIFFENER AS UPPER CONTACT CLOSES.
- TO CHECK --- SELECT VERTICAL TABULATOR COMBINATION AND PROCEED AS IN ITEM TO CHECK OF REQUIREMENT 2 ABOVE.

3. 30 Vertical Tabulation and Transmitter Distributor Control Mechanism (Cont.)



(J) TABULATION INDEX PLATE POSITION REQUIREMENT --- WITH REQUIREMENT (I) MET, LINE FEED PLATEN TO DESIRED FIRST LINE OF PRINTING IN THAT FORM. TO POSITION --- PLACE TABULATION INDEX PLATE TO ALIGN WITH POINTER ON SIDE OF PRINTER. INSTALL ADDITIONAL TAB INDEX PLATES AT SUCCEEDING DESIRED PRINTING LINES WITHIN THE FORM. WHEN TABULATION AT A GIVEN POINT IS NOT NEEDED, ROTATE TAB INDEX PLATES (1/4 TURN) ON THEIR SIDES.

(K) BLOCKING LEVER SPRING *
 REQUIREMENT --- WITH SPRING UNHOOKED AND BLOCKING LEVER ON TOP OF SLIDE. MIN. 9 OZS. --- MAX. 11 OZS. TO PULL RESPECTIVE SPRING TO POSITION LENGTH.

*BLOCKING LEVER SPRINGS USED WITH TRANSFER TYPE SWITCH (PAR. 3.31)
 MIN 12 OZS --- MAX 13-1/2 OZS

(G) TRANSMITTER CONTROL SWITCH (TRANSMITTER CONTROL ONLY) REQUIREMENTS --- FOR SINGLE-CONTACT TYPE CONTROL

1. WITH TRANSMITTER CONTROL CONTACTS CLOSED, THERE SHOULD BE SOME CLEARANCE BETWEEN INSULATED EXTENSION OF SWINGER AND LOBE OF FEED-OUT AND VERTICAL TABULATOR BLOCKING LEVERS.
 TO CHECK - ROTATE MAIN SHAFT UNTIL FEED-OUT AND VERTICAL TABULATOR BLOCKING LEVERS ARE UNOPERATED (RESTING ON TOP OF SLIDES).
 TO ADJUST - POSITION THE CONTACT ASSEMBLY WITH ITS MOUNTING SCREWS LOOSENED.
2. WITH TRANSMITTER CONTROL CONTACTS OPENED BY FEED-OUT BLOCKING LEVER, CLEARANCE BETWEEN SWITCH CONTACTS SHALL BE
 MIN 0.010 INCH ----- MAX 0.020 INCH
 TO CHECK - SELECT FEED-OUT CODE COMBINATION. ROTATE MAIN SHAFT UNTIL FEED-OUT SLIDE IS IN ITS EXTREME FORWARD POSITION AND FEED-OUT BLOCKING LEVER DROPS BEHIND ITS SLIDE TO OPEN CONTACTS
 TO ADJUST - REFINE REQUIREMENT NO. 1 ABOVE.
3. WITH CONTROL CONTACTS OPENED BY VERTICAL TABULATOR BLOCKING LEVER, CLEARANCE BETWEEN SWITCH CONTACTS SHOULD BE
 MIN 0.010 INCH ----- MAX 0.020 INCH
 TO CHECK - SELECT VERTICAL TABULATOR CODE COMBINATION. ROTATE MAIN SHAFT UNTIL VERTICAL TAB SLIDE IS IN ITS EXTREME FORWARD POSITION AND VERTICAL TABULATOR BLOCKING LEVER DROPS BEHIND ITS SLIDE
 TO ADJUST - REFINE REQUIREMENT NO. 1. ABOVE.

3. 31 Vertical Tabulation and Transmitter Distributor Control Mechanism (Cont.)

(I) PAGE FEED-OUT INDEX PLATE POSITION

REQUIREMENT --- PLACE AN INDEX PLATE IN THE NUMBERED SLOTS ON DISK CORRESPONDING TO LENGTH OF PAGE FORM TO BE USED. SYNCHRONIZE PAGE FEED-OUT WITH A FORM BY POSITIONING FORM SO THAT TYPING UNIT WILL PRINT IN FIRST TYPING LINE OF THE FORM. WHEN TYPING UNIT IS IN STOP POSITION, TOP OF RIBBON GUIDE SHOULD ALIGN WITH BOTTOM OF PRINTING LINE.

TO POSITION --- WITH PAGE FORM IN DESIRED POSITION, DISENGAGE PAGE FEED-OUT GEAR FROM ITS IDLER GEAR. ROTATE FEED-OUT GEAR UNTIL NOTCH IN INDEXING DISK ALIGNS WITH POINTER ON SIDE OF PRINTER, RE-ENGAGE GEARS.

SWITCH CONTACTS (TRANSMITTER CONTROL ONLY)REQUIREMENTS --- FOR TRANSFER TYPE CONTROL SWITCH

1. WITH NORMALLY CLOSED (LOWER) CONTACTS CLOSED, LIFT SWINGER FREE OF MATING CONTACT. IT SHALL REQUIRE A MINIMUM OF 30 GRAMS TO MOVE LOWER CONTACT SPRING AWAY FROM ITS STIFFENER.

TO ADJUST - FORM THE LOWER CONTACT SPRING BY BENDING.

2. WITH LOWER CONTACT CLOSED

MIN 30 GRAMS ----- MAX 45 GRAMS.

TO MOVE SWINGER FROM ITS MATING CONTACTS.

TO ADJUST - FORM THE SWINGER BY BENDING.

3. WITH LOWER CONTACT CLOSED

(a) GAP BETWEEN UPPER CONTACT AND MATING CONTACT OF SWINGER

MIN 0.008 INCH ----- MAX 0.015 INCH

TO ADJUST - POSITION STIFFENER OF NORMALLY CLOSED CONTACT.


(b) WITH A GAP OF 0.008 TO 0.015 INCH, IT SHALL REQUIRE

MIN 25 GRAMS ----- MAX 35 GRAMS

TO PULL UPPER CONTACT AWAY FROM ITS STIFFENER


TO ADJUST - FORM THE UPPER CONTACT SPRING BY BENDING.

RECHECK REQUIREMENT (a).




3. 32 Vertical Tabulation and Transmitter Distributor Control Mechanism (Cont.)

(L) LINE FEED CLUTCH TRIP LEVER SPRING
SEE PAR. 2.20



(O) STUNT BOX SWITCH SPRING
SEE PAR. 2.66



3. 33 Universal Contact (Selector) Mechanism

(A) CONTACT MOUNTING BRACKET
REQUIREMENT

THE DRIVE ARM LINKAGE SHOULD BE VERTICALLY ALIGNED TO PREVENT BINDS.
TO ADJUST
POSITION THE CONTACT MOUNTING BRACKET WITH ITS MOUNTING SCREWS LOOSENED.

(B) CONTACT BLOCK
REQUIREMENT

THE CONTACT FACES SHOULD BE IN A VERTICAL STRAIGHT LINE
TO ADJUST
LOOSEN THE TWO CONTACT MOUNTING SCREWS. PRESS THE CONTACT BLOCK TOWARD THE REAR OF THE TYPING UNIT FIRMLY AGAINST THE SCREWS AND TIGHTEN THE SCREWS.

CONTACT MOUNTING BRACKET

BRACKET MOUNTING SCREW

CONTACT BLOCK

CONTACT BLOCK MOUNTING SCREWS

CONTACT ARM

DRIVE LINK

CONTACT DRIVE ARM


DRIVE ARM CLAMP SCREW

(C) CONTACT DRIVE ARM POSITION
REQUIREMENT

THE CONTACTS SHOULD OPEN EQUALLY WITHIN 0.010 INCH
TO CHECK
ROTATE CODE BAR CLUTCH UNTIL IT IS DISENGAGED AND LATCHED IN STOP POSITION. MEASURE GAP BETWEEN UPPER CONTACTS. TRIP CODE BAR CLUTCH AND ROTATE 180 DEGREES OR UNTIL LOWER CONTACT GAP REACHES ITS MAXIMUM OPENING. MEASURE THE GAP.
TO ADJUST
POSITION CONTACT DRIVE ARM WITH ITS CLAMP SCREW LOOSENED.

(D) CONTACT ARM SPRING
REQUIREMENT

WITH SHOULDER SCREW WHICH CONNECTS CONTACT ARM TO DRIVE LINK REMOVED AND SPRING SCALE APPLIED VERTICALLY UPWARD OR DOWNWARD
MIN. 2 OZS. ---MAX. 5 OZS.
TO OPEN EITHER CONTACT.



3.34 Universal Contact (Stunt Box) Mechanism

- NOTE: 1. THESE ADJUSTMENTS SHOULD BE MADE WITH THE CONTACT BRACKET ASSEMBLY REMOVED
NOTE: 2. IF CONTACT SCREWS ARE DISTURBED TO OBTAIN A REQUIREMENT, THEY MUST BE RETIGHTENED AND ALL PRECEDING REQUIREMENTS RECHECKED.


CAUTION: IF IT IS NECESSARY TO INCREASE THE CONTACT SPRING TENSIONS, IT IS ADVISABLE TO REMOVE THE CONTACT SPRING TO INCREASE ITS CURVATURE. AVOID DAMAGE TO CONTACT SPRINGS WHEN ADJUSTING THE STIFFENERS IN THE ASSEMBLY.

(A) CONTACT

1. REQUIREMENT
 CONTACT SPRINGS AND STIFFENERS MOUNTED VERTICALLY AND CONTACT POINTS IN ALIGNMENT (GAUGE BY EYE).
 TO ADJUST
 POSITION THE CONTACT SPRINGS AND STIFFENERS WITH ASSEMBLY SCREWS LOOSENED.
2. REQUIREMENT
 STIFFENERS SHOULD BE PARALLEL WITH THE CONTACT BRACKETS.
 TO ADJUST
 FORM THE STIFFENER
3. REQUIREMENT
 CONTACT SPRINGS SHOULD REST AGAINST THEIR STIFFENERS THROUGHOUT THEIR WIDTH.
 TO ADJUST
 BEND TOP FORMED SECTION OF STIFFENER. IF NECESSARY, BEND CONTACT SPRINGS.

(B) NORMALLY OPEN CONTACT GAP
REQUIREMENT

- WITH THE NORMALLY CLOSED CONTACTS CLOSED, THE NORMALLY OPEN CONTACT SHOULD BE OPEN
 MIN 0.020 INCH
 MAX 0.025 INCH
 TO ADJUST
 BEND STIFFENER




(C) CONTACT SPRING (TWO SPRINGS)
REQUIREMENT

- MIN 2 OZ
 MAX 3 OZ
 TO MOVE EACH CONTACT SPRING AWAY FROM ITS STIFFENER, WITH THE SWINGER HELD AWAY
 TO ADJUST
 REMOVE AND FORM THE SPRING.

(D) SWINGER SPRING
REQUIREMENT

- MIN 4 OZ
 MAX 6 OZ
 TO MOVE SWINGER FROM NORMALLY CLOSED CONTACT.
 TO ADJUST
 BEND SWINGER

3.35 Universal Contact (Stunt Box) Mechanism (continued)



3. 36 Universal Contact (Stunt Box) Mechanism (continued)

NOTE: THE FOLLOWING ADJUSTMENTS ARE TO BE MADE WITH THE CONTACT ASSEMBLY INSTALLED ON THE STUNT BOX

CONTACT BRACKET AND DRIVE CAM

1. REQUIREMENT

WITH DRIVE LINK IN ITS UPPERMOST POSITION, CLEARANCE BETWEEN TOP OF LATCH LEVER AND LATCH CAM

MIN 0.003 INCH
MAX 0.008 INCH


2. REQUIREMENT

WITH THE MAIN SHAFT ROTATED ON UNTIL THE CLEARANCE IN REQUIREMENT 1. IS CLOSED AND THE LATCH CAM RESTS FIRMLY ON THE LATCH LEVER. CLEARANCE BETWEEN THE NORMALLY OPEN CONTACT SPRING AND THE UPPER END OF ITS STIFFENER

MIN 0.005 INCH
MAX 0.010 INCH

TO ADJUST

REPOSITION THE CONTACT BRACKET, AND, IF NECESSARY, THE DRIVE CAM.



3. 37 Universal Contact (Stunt Box) Mechanism (continued)

GENERAL APPLICATION TIMING - FINAL (USING DXD OR SIMILAR EQUIPMENT)CONTACT BRACKET AND DRIVE CAM POSITION REQUIREMENT

THE NORMALLY OPEN UNIVERSAL CONTACTS SHOULD CLOSE WITHIN ± 5 MILLISECONDS OF THE CLOSURE OF THE NORMALLY OPEN STUNT BOX CONTACT.

TO ADJUST

REFINE THE DRIVE CAM (AND, IF NECESSARY, THE BRACKET) ADJUSTMENT BY ROTATING THE DRIVE CAM WITHIN THE SPECIFIED LIMITS.

TRIP CAMREQUIREMENT

THE NORMALLY OPEN UNIVERSAL CONTACTS SHOULD OPEN WITHIN $-5 +0$ MILLISECONDS OF THE OPENING OF THE NORMALLY OPEN STUNT BOX CONTACT.

TO ADJUST

REFINE THE TRIP CAM ADJUSTMENT BY ROTATING THE TRIP CAM ON ITS SHAFT WITHIN THE SPECIFIED LIMITS.

SPECIAL ADJUSTMENTS (FOR 100 WPM)

NOTE: TO PREVENT EXCESSIVE FLEXING OF THE SWINGER, THE NORMALLY OPEN CONTACT SPRING STIFFENER MUST BE BENT TO HOLD THE SPRING AWAY FROM THE SWINGER WITH THE DRIVE LINK IN ITS UPPERMOST POSITION.

NORMALLY OPEN CONTACT GAP (100 WPM)REQUIREMENT

WITH THE SWINGER RESTING AGAINST THE NORMALLY CLOSED CONTACT THE GAP SHOULD BE

MIN 0.075 INCH

MAX 0.085 INCH

TO ADJUST

BEND THE CONTACT SPRING STIFFENER.

CONTACT BRACKET AND DRIVE CAM POSITION (100 WPM)REQUIREMENT

WITH THE LATCH CAM IN ITS FULLY LATCHED POSITION

MIN 0.015 INCH

MAX 0.025 INCH

BETWEEN THE NORMALLY OPEN CONTACT SPRING AND ITS STIFFENER.

TO ADJUST

POSITION THE DRIVE CAM AND/OR, IF NECESSARY, THE CONTACT BRACKET.

SPECIAL APPLICATION TIMING (USING DXD OR SIMILAR EQUIPMENT)A. NORMALLY CLOSED CONTACTS (100 WPM FOR 83B2 SWITCHING SYSTEM)

1. THE NORMALLY CLOSED CONTACTS SHOULD CLOSE WITHIN 50 TO 80 DIVISIONS AFTER THE START OF THE STOP PULSE.
2. THE NORMALLY OPEN CONTACT SHOULD CLOSE PRIOR TO THE END OF NO. 3 PULSE.
3. THE NORMALLY OPEN CONTACTS SHOULD REMAIN CLOSED FOR AT LEAST 238 DIVISIONS (100 WPM DXD WITH 742 SCALE DIVISIONS).

NOTE: THE RELATION BETWEEN THE NORMALLY CLOSED UNIVERSAL CONTACT MARKING PULSE AND THE STOP IMPULSE OF THE RECEIVED SIGNAL VARIES WITH THE RANGE SCALE SETTING OF THE UNIT.

SECTION 573-115-700

3. 38 Universal Contact (Stunt Box) Mechanism (continued)

B. NORMALLY CLOSED CONTACTS (100 WPM USED IN DELTA AND UNITED AIRLINES SYSTEM)

WHEN THE NORMALLY OPEN CONTACTS ARE NOT USED, THE NORMALLY CLOSED CONTACTS SHOULD REMAIN OPEN FOR 53.88 MILLISECONDS OR $400 + 15 \text{ DXD}$ DIVISIONS. TO ADJUST REFINE THE DRIVE CAM, TRIP CAM AND, IF NECESSARY, THE BRACKET POSITIONS TO MEET THE TIMING REQUIREMENTS.

NOTE 1:

THE NORMAL 0.003 TO 0.008 INCH OVERTRAVEL OF THE LATCH CAM OVER THE LATCH LEVER WITH THE DRIVE LINK IN ITS UPPERMOST POSITION MUST BE INCREASED IN ORDER TO DECREASE NORMALLY CLOSED CONTACT GAP IN THE LATCHED POSITION OF THE LATCH CAM. THIS PREVENTS THE CONTACT FROM BOUNCING WHEN THE LATCH LEVER IS RELEASED.

NOTE 2:

WITH THE LATCH CAM IN ITS LATCHED POSITION, THERE SHOULD BE 0.015 INCH MINIMUM CONTACT GAP BETWEEN THE NORMALLY CLOSED CONTACTS.

GENERAL REQUIREMENTS AFTER TIMING ADJUSTMENTS

NOTE: IT IS VERY IMPORTANT THAT THE FOLLOWING REQUIREMENTS BE MET

A. WITH THE DRIVE LINK IN ITS UPPERMOST POSITION:

1. THE LATCH CAM SHALL NOT OVERTRAVEL OR HANG UP ON THE SWINGER INSULATOR.
2. THERE SHALL BE AT LEAST 0.003 INCH CLEARANCE BETWEEN THE LATCHING SURFACE OF THE LATCH CAM AND THE LATCHING SURFACE OF THE LATCH LEVER.
3. THE CLEARANCE BETWEEN THE NORMALLY OPEN CONTACT SPRING AND ITS STIFFENER SHALL NOT EXCEED 0.025 INCH.

B. WITH THE DRIVE LINK IN ITS LOWERMOST POSITION:

1. THE TOP OF THE SWINGER INSULATOR MUST CLEAR THE CUT-OUT SECTION OF THE LATCH CAM.
2. THERE SHALL BE AT LEAST 0.003 INCH CLEARANCE BETWEEN THE FRONT EDGE OF THE LATCH LEVER LATCHING SURFACE AND THE HIGH PART OF THE LATCH CAM.

C. WITH THE LATCH CAM IN ITS LATCHED POSITION, THERE SHALL BE AT LEAST 0.005 INCH CLEARANCE BETWEEN THE NORMALLY OPEN CONTACT SPRING AND THE UPPER END OF ITS STIFFENER.

D. THE LATCHING SURFACE OF THE LATCH LEVER SHALL COVER THE WIDTH OF THE TRIP CAM AND LATCH CAM.

3. 39 Form Alignment Switch Mechanism

(A) FORM FEED-OUT ADJUSTMENT
SEE PARS. 3.11 AND 3.12

(B) FORM ALIGNMENT SWITCH
(REMOVE POWER FROM SWITCH)
REQUIREMENT


SWITCH SHOULD BE OPERATED WHEN SWITCH LEVER IS WITHIN 0.010 INCH OF BOTTOM OF NOTCH IN FORM-OUT DISK AND SHOULD NOT BE OPERATED WHEN LEVER IS ON OUTER EDGE OF DISK.

TO CHECK

1. ROTATE DISK UNTIL LEVER FALLS INTO NOTCH. PLACE 0.010 INCH FEELER GAGE BENEATH LEVER. LIFT LEVER AND ALLOW IT TO COME TO REST ON GAGE. SWITCH SHOULD BE OPERATED.
2. ROTATE DISK UNTIL LEVER RESTS ON OUTER EDGE. SWITCH SHOULD NOT BE OPERATED.

TO ADJUST

POSITION SWITCH, AT PRY POINTS, WITH ITS MOUNTING SCREWS LOOSENED.



(C) FORM ALIGNMENT SWITCH SPRING
REQUIREMENT

MIN. 6 OZS.
MAX. 8 OZS.

TO MOVE THE LEVER FROM OUTER-EDGE OF DISK.

TO CHECK


SWITCH OPERATING LEVER ON OUTER EDGE OF DISK
(NOT IN NOTCH AS SHOWN)

LEFT VIEW

3.40 DC Magnet Operated Print Suppression Mechanism

(D) ARMATURE EXTENSION OVERTRAVEL REQUIREMENT

1. OVERTRAVEL OF ARMATURE EXTENSION SHOULD BE MIN. 0.010 INCH --MAX. 0.015 INCH
 2. THERE SHOULD BE NO CLEARANCE BETWEEN BLOCKING SURFACE OF ARMATURE EXTENSION AND BOTTOM SURFACE OF SUPPRESSION ARM.
TO CHECK (REQUIREMENTS 1 AND 2.)
SUPPRESSION ARM BLOCKED BY BLOCKING BAIL EXTENSION. HOLD ARMATURE AGAINST POLE FACE OF MAGNET.
 3. ROTATE BLOCKING BAIL EXTENSION. IT SHOULD SLIDE UNDER THE SUPPRESSION ARM WITH NO PERCEPTIBLE CLEARANCE.
TO CHECK (REQUIREMENT 3.)
SUPPRESSION ARM BLOCKED BY ARMATURE EXTENSION
- TO ADJUST
PIVOT MAGNET BRACKET, UP OR DOWN AND TO THE FRONT OR REAR, WITH ITS MOUNTING SCREWS LOOSENED, USING AN ECCENTRIC ADJUSTING TOOL. PRESS ARMATURE EXTENSION FIRMLY AGAINST BOTTOM OF SUPPRESSION ARM. IF NECESSARY, ADD OR REMOVE SHIMS BETWEEN SUPPRESSION ARM AND TYPE BOX CLUTCH TRIP ARM. RECHECK (B) AND (C).




(A) TYPE BOX CLUTCH TRIP LEVER
SEE PAR. 2.22 AND REFINE REQUIREMENT TO MIN. 0.040 INCH---MAX. 0.055 INCH

(B) TYPE BOX CLUTCH SUPPRESSION ARM
SEE PAR. 3.14

(C) BLOCKING BAIL
SEE PAR. 3.14

TYPE BOX CLUTCH TRIP ARM



(F) BLOCKING BAIL EXTENSION CLEARANCE REQUIREMENT
THERE SHOULD BE NO INTERFERENCE BETWEEN ARMATURE EXTENSION AND BLOCKING BAIL EXTENSION.

TO ADJUST
REFINE ABOVE ADJUSTMENTS AS NECESSARY.

(E) ARMATURE EXTENSION CLEARANCE REQUIREMENT

CLEARANCE BETWEEN END OF ARMATURE EXTENSION AND SUPPRESSION ARM SHOULD BE MIN. 0.012 INCH---MAX. 0.030 INCH
TO CHECK
ARMATURE RELEASED
TO ADJUST
POSITION ARMATURE WITH ARMATURE STOP SCREW. RECHECK (D).

3.41 Print Suppression and Offline Stunt Shift Control Mechanism

(A) SUPPRESSION CODE BAR POSITION REQUIREMENT


NOTCHES IN SUPPRESSION CODE BAR SHOULD ALIGN WITH NOTCHES IN OTHER CODE BARS. VIEW FROM REAR OF UNIT ABOVE STUNT BOX. GAGE BY EYE.

TO CHECK

ENERGIZE THE PRINT SUPPRESSION MAGNET AND PLACE ALL CODE BARS IN SPACING POSITION.

TO ADJUST

OPERATE MAGNET ARMATURE MANUALLY OR ELECTRICALLY. PLACE ALL CODE BARS IN SPACING POSITION. PIVOT THE ARMATURE EXTENSION IN ITS ELONGATED MOUNTING HOLE WITH THE MOUNTING SCREWS LOOSENED.

(B) TYPE BOX CLUTCH TRIP LEVER

SEE PAR. 2.22 AND REFINE REQUIREMENT TO
MIN. 0.040 INCH
MAX. 0.055 INCH

(C) TYPE BOX CLUTCH SUPPRESSION ARM
SEE PAR. 3.14(D) BLOCKING BAIL
SEE PAR. 3.14(E) PRINT SUPPRESSION MAGNET ARMATURE RETURN SPRING REQUIREMENT

MIN. 7 OZS.
MAX. 10-1/2 OZS.

TO START MAGNET ARMATURE MOVING TOWARD CORE
TO CHECK
PRINT SUPPRESSION MAGNET UNOPERATED


NOTE: KEEP POLE FACE FREE
OF OIL AND GREASE.

3.42 Letters - Figures Codebar Shift Magnet Mechanism

(A) SHIFT MAGNET YOKE REQUIREMENT

CLEARANCE BETWEEN ARMATURE AND END OF HEELPIECE SHOULD BE MIN. SOME --- MAX. 0.003 INCH
 TO CHECK
 MAGNET ARMATURE HELD AGAINST CORE. CHECK CLEARANCE ACROSS END OF HEELPIECE
 TO ADJUST
 POSITION YOKE WITH ITS CLAMP SCREW LOOSENED.

NOTE: KEEP POLE FACE FREE OF OIL AND GREASE.



(B) SHIFT MAGNET ARMATURE REQUIREMENT


1. CLEARANCE BETWEEN ARMATURE AND TRANSFER LEVER SHOULD BE MIN. SOME --- MAX. 0.005 INCH
 TO CHECK
 MAGNET ARMATURE ATTRACTED. SHIFT CODE BAR IN FULL MARKING POSITION.
 TO ADJUST
 POSITION MAGNET FORWARD OR BACKWARD WITH BRACKET MOUNTING SCREWS LOOSENED.
 2. CLEARANCE BETWEEN ARMATURE AND TRANSFER LEVER SHOULD BE MIN. SOME --- MAX. 0.010 INCH
 TO CHECK
 MAGNET ARMATURE UNOPERATED. SHIFT CODE BAR IN FULL SPACING POSITION.
 TO ADJUST
 POSITION ARMATURE BACKSTOP SCREW WITH LOCK NUT LOOSENED.

(C) SHIFT MAGNET ARMATURE RETURN SPRING REQUIREMENT


MIN. 1 OZ. --- MAX. 3 OZS.
 TO PULL SPRING TO INSTALLED LENGTH

(D) SHIFT CODE BAR RETURN SPRING REQUIREMENT

MIN. 3 OZS. --- MAX. 7 OZS.
 TO START CODE BAR MOVING
 TO CHECK
 TRIP TYPE BOX CLUTCH, ROTATE MAIN SHAFT UNTIL PRINTING TRACK IS IN LOWEST POSITION



3.43 Form Feed-Out Mechanism



FORM FEED-OUT TORSION SPRING
REQUIREMENT *

MIN. 1/8 OZ.

MAX. 1-1/4 OZ.

TO START BAIL MOVING TOWARDS REAR OF UNIT.
TO CHECK

DISENGAGE LINE FEED CLUTCH TRIP LEVER.

*RECEIVE ONLY UNITS

MIN 2 OZS

MAX 6 OZS

3.44 Two Color Ribbon Mechanism


SEE NOTES 1 THROUGH 5 ON FOLLOWING PAGE

(A) RIBBON MAGNET HINGE BRACKET (LEFT AND RIGHT) (PRELIMINARY)
 REQUIREMENT --- MAGNET ENERGIZED OR IN ATTRACTED POSITION, ARMATURE ON POLE PIECE.
 CLEARANCE BETWEEN ARMATURE AND POLE PIECE SHOULD BE NOT MORE THAN .005 INCH.
 TO ADJUST --- POSITION HINGE BRACKET WITH MOUNTING SCREWS LOOSENED.


(B) RIBBON MAGNET BRACKET (LEFT AND RIGHT) (PRELIMINARY)
 REQUIREMENT --- ADJUSTING SCREW IN LOWEST POSITION, ALL CLUTCHES DISENGAGED,
 POSITION RIBBON MAGNET BRACKET AS FOLLOWS:
 1. HOLD MAGNET ARMATURE STOP LEVER AGAINST MAGNET CORE, LEVER SHOULD BE PARALLEL
 TO OSCILLATING LEVER TOP SURFACE AND ENGAGE THE OSCILLATING LEVER BY AT LEAST
 1/2 OF THE STOP LEVER THICKNESS. GAUGE BY EYE.
 2. STOP LEVER HELD AGAINST MAGNET CORE. CLEARANCE BETWEEN STOP LEVER AND
 OSCILLATING LEVER SHOULD BE: MIN. 0.005 INCH --- MAX. 0.020 INCH WITH PLAY
 TAKEN UP TOWARD FRONT OF UNIT.

TO ADJUST --- LOOSEN AND POSITION RIBBON MAGNET BRACKET TO MEET ABOVE REQUIREMENTS.

(C) RIBBON MAGNET HINGE BRACKET (LEFT AND RIGHT) (FINAL)
 REQUIREMENT --- MAGNET DE-ENERGIZED OR IN RELEASED POSITION, ROTATE MAIN SHAFT UNTIL
 OSCILLATING LEVER IS FULLY UNDER STOP LEVER. CLEARANCE BETWEEN OSCILLATING LEVER
 AND STOP LEVER SHOULD BE: MIN. 0.020 INCH --- MAX. 0.040 INCH.
 TO ADJUST --- POSITION STOP LEVER ADJUSTING SCREW WITH LOCK NUT LOOSENED.



ARMATURE SPRING (LEFT AND RIGHT)
 REQUIREMENT --- MIN. 2-1/2 OZS. --- MAX. 3-1/2 OZS.
 TO SEAT ARMATURE AGAINST POLE PIECE.



(END VIEW)

3. 45 Two Color Ribbon Mechanism

OPERATIONAL REQUIREMENT - RIBBON MAGNET BRACKET (FINAL) (SEE PRECEDING FIGURE)

PRINTER OPERATING AT 60, 75, OR 100 WPM, TEST BEING PRINTED.

REQUIREMENT

PRINTS RED WHEN RIBBON MAGNETS ARE ENERGIZED.


TO ADJUST

TURN LEFT AND RIGHT RIBBON BRACKET ROLLER BAIL ADJUSTING SCREWS
1/2 TURN UP. REFINE RIBBON AND RIBBON HINGE BRACKET ADJUSTMENTS.
REPEAT ABOVE PROCEDURE IF BLACK IS PRINTED.

RIBBON ROLLER BAIL SPRING (LEFT AND RIGHT) (SEE PRECEDING FIGURE)

REQUIREMENT

ALL CLUTCHES DISENGAGED, ADJUSTING SCREW IN LOWEST POSITION
MIN. 4 OZS. --- MAX. 6 OZS.
TO START LIFTER BAIL MOVING.



NOTES


REFER TO RELATED REQUIREMENTS

1. VERTICAL POSITION LOCK LEVER EXTENSION - PAR. 2.36
2. RIBBON REVERSE SPUR GEAR - PAR. 2.52
3. RIBBON REVERSE DETENT - PAR. 2.52
4. RIBBON FEED LEVER BRACKET - PAR. 2.53
5. RIBBON RATCHET WHEEL FRICTION SPRING - PAR. 2.53
(MIN 3-1/3 OZS --- MAX 4-1/2 OZS).

RIBBON REVERSING LEVER SPRING (LEFT AND RIGHT)

REQUIREMENT

MIN. 1/2 OZ --- MAX. 1-1/2 OZS.
TO START LEVER MOVING.



RIBBON GUIDE LEVER SPRING (LEFT AND RIGHT)

REQUIREMENT

MIN. 1 OZ --- MAX. 2 OZS
TO START LEVER MOVING.


4. EARLIER DESIGN MECHANISMS
BASIC UNITS

4.01 SELECTOR MECHANISM

NOTE: BAIL LEVER GUIDE ADJUSTMENT
APPLIES ONLY TO UNITS
EQUIPPED WITH ADJUSTABLE GUIDES

START LEVER SPRING
REQUIREMENT

LATCH LEVER SPRING UNHOOKED. STOP
ARM BAIL IN INDENT OF ITS CAM.
RANGE SCALE SET AT 60
MIN. 2-1/2 OZS.
MAX. 4-1/2 OZS.
TO START THE STOP ARM MOVING.



BAIL LEVER GUIDE
REQUIREMENT


SOME CLEARANCE BETWEEN
EACH SIDE OF GUIDE FORK
AND EXTENSION OF START
LEVER THROUGHOUT ITS
TRAVEL.

TO ADJUST
POSITION BAIL LEVER GUIDE
WITH MOUNTING NUT LOOSENED.

(RIGHT SIDE VIEW)

4.02 Selector Mechanism

SELECTOR ARMATURE
 FOR REQUIREMENTS (1) AND (2) SEE PAR. 2.01 UNDER BASIC UNITS




TO ADJUST


1. POSITION ARMATURE SPRING ADJUSTING NUT TO HOLD ARMATURE FIRMLY AGAINST PIVOT EDGE OF CASTING.
2. POSITION ARMATURE AND BACKSTOP WITH MOUNTING SCREWS LOOSENED.

SECTION 573-115-700

4.03 Codebar Mechanism



4.04 Codebar Mechanism (Cont.)



MOTION OF FRONT AND REAR CODE BAR SHIFT LEVERS SHOULD BE EQUALIZED WITH RESPECT TO CODE BAR TRAVEL.

TO CHECK (FRONT)

SELECT BLANK COMBINATION AND ROTATE MAIN SHAFT UNTIL CODE BAR SHIFT LEVER LINK REACHES HIGHEST TRAVEL. TAKE UP PLAY FOR MAXIMUM CLEARANCE. CLEARANCE BETWEEN FRONT CODE BAR SHIFT LEVER AND SHOULDER ON NEAREST CODE BAR SHIFT BAR

MIN. 0.002 INCH---MAX. 0.025 INCH

TO CHECK (REAR)

SELECT LETTERS COMBINATION. CHECK CLEARANCE BETWEEN REAR CODE BAR SHIFT LEVER AND SHOULDER OF CODE BAR SHIFT BAR IN SAME WAY.

MIN. 0.002 INCH---MAX. 0.025 INCH

TO ADJUST

POSITION CODE BAR SHIFT LEVER LINK GUIDE BRACKET BY MEANS OF MOUNTING SCREWS (3).

SECTION 573-115-700

4.05 Main Shaft and Trip Shaft Mechanisms

(A) CLUTCH TRIP SHAFT SET COLLARS

(1) REQUIREMENT

SPACING CLUTCH LATCH LEVER SHOULD HAVE SIDE PLAY
MIN. SOME
MAX. 0.008 INCH
TO ADJUST
POSITION SPACING CLUTCH LATCH LEVER SET COLLAR.

(2) REQUIREMENT

APPROXIMATE ALIGNMENT OF RIGHT END OF STOP EXTENSIONS ON TRIP LEVER AND SHOE LEVER
TO ADJUST
POSITION LINE FEED CLUTCH TRIP LEVER SET COLLAR.

(3) REQUIREMENT

LINE FEED CLUTCH LATCH LEVER SHOULD HAVE SIDE PLAY
MIN. SOME
MAX. 0.008 INCH
TO ADJUST
POSITION LINE FEED CLUTCH LATCH LEVER SET COLLAR

SPACING CLUTCH LATCH LEVER SET COLLAR

TRIP SHAFT

TRIP LEVER

LINE FEED CLUTCH TRIP LEVER SET COLLAR

LINE FEED CLUTCH LATCH LEVER SET COLLAR

MAIN SHAFT

SHOE LEVER

LINE FEED CLUTCH

LATCH LEVER

SPACING CLUTCH

(REAR VIEW)

MOUNTING SCREWS

TRIP SHAFT

NOTE: ANTI-DEFLECTION PLATE ADJUSTMENT APPLIES ONLY TO UNITS SO EQUIPPED.

(B) ANTI-DEFLECTION PLATE

REQUIREMENT

WITH TYPING UNIT UPSIDE DOWN AND FUNCTION, SPACING, LINE FEED, AND TYPE BOX CLUTCHES LATCHED DISENGAGED.

MIN. 1 LB.

MAX. 5 LBS.


TO PULL TRIP SHAFT AWAY FROM ANTI-DEFLECTION PLATE.

TO ADJUST

POSITION PLATE WITH MOUNTING SCREWS LOOSENED.

(LEFT SIDE VIEW, UPSIDE DOWN)

4.06 Main Shaft and Trip Shaft Mechanisms (Cont.)



SPACING CLUTCH TRIP LEVER

REQUIREMENT

SPACING AND TYPE BOX CLUTCHES DISENGAGED
TRIP LEVER ARM IN UPWARD POSITION.

FOR UNITS WITHOUT U-SHAPED LINE
FEED CLUTCH TRIP LEVER:


SPACING CLUTCH TRIP LEVER SHOULD
BE FLUSH OR UNDERFLUSH BY 1/2
THICKNESS OF SHOE LEVER WITH
OUTER SURFACE OF SHOE LEVER.

FOR UNITS WITH U-SHAPED LINE
FEED CLUTCH TRIP LEVER:

SPACING CLUTCH TRIP LEVER SHOULD
ENGAGE SHOE LEVER BY FULL
THICKNESS OF SHOE LEVER
CHECK AT STOP LUG WITH LEAST BITE.

TO ADJUST

USE ADJUSTING SCREW TO POSITION
SPACING CLUTCH TRIP ARM.



CLUTCH TRIP LEVER SPRING
REQUIREMENT

CLUTCH ENGAGED AND ROTATED UNTIL
TRIP LEVER RESTS ON STOP LUG.


<u>CLUTCH</u>	<u>MIN.</u>	<u>MAX.</u>
SPACING	11 OZS.	16 OZS.
LINE FEED	9 OZS.	12 OZS.
TYPE BOX	5 OZS.	7-1/4 OZS.

TO MOVE LEVER AWAY FROM
STOP LUG.


(REAR VIEW)

4.07 Spacing Mechanism

NOTE: CHECK RELATED ADJUSTMENTS, PARS. 4.12, 4.13, 2.47, IF THE FOLLOWING ADJUSTMENTS ARE REMADE.



OSCILLATING RAIL SLIDE POSITION REQUIREMENT
 SPACING CUTOUT LEVER AND AUTOMATIC CR-LF ARM IN MAXIMUM COUNTERCLOCKWISE POSITION ON SPACING DRUM. SPACING CLUTCH DISENGAGED. FARTHEST ADVANCED SPACING PAWL ENGAGED WITH TOOTH JUST ABOVE CUT-AWAY SECTION IN RATCHET WHEEL. RIGHT END OF OSCILLATING RAIL SLIDE SHOULD CLEAR PULLEY.
 MIN. 0.025 INCH---MAX. 0.050 INCH
 TO ADJUST POSITION SLIDE ON WIRE ROPE WITH CLAMP SCREWS LOOSENED.




SPACING FEED PAWL SPRING REQUIREMENT
 EACH SPACING PAWL IN LEAST ADVANCED POSITION, RESTING AGAINST RACHET WHEEL. EACH SPRING UNHOOKED FROM BRACKET
 MIN. 2-1/2 OZS. ---MAX. 4 OZS.
 TO PULL SPRINGS TO INSTALLED LENGTH.

SPACING FEED PAWL SPRING BRACKET

NOTE:
 ON UNITS EQUIPPED FOR 6 SPACES PER INCH, THIS TENSION SHOULD BE MIN. 8 OZS. ---MAX. 10 OZS.
 TO PULL SPRINGS TO INSTALLED LENGTH.

4.08 Function Mechanism

NOTE: 1. THIS ADJUSTMENT APPLIES ONLY TO UNITS WITH NON-ADJUSTABLE GUIDE PLATES
 2. FOR UNITS WITH ADJUSTABLE GUIDE PLATES SEE PAR. 2.32.



FIGS - LTRS SHIFT CODE BAR OPERATING MECHANISM

REQUIREMENT: (FOR TWO STOP FUNCTION CLUTCH)

DISENGAGE FUNCTION CLUTCH AT POSITION GIVING LEAST CLEARANCE. ROTATE TYPE BOX CLUTCH 1/2 REVOLUTION. HOLD FIGURES FUNCTION LEVER IN REARWARD POSITION WITH TENSION OF 32 OZS. CLEARANCE BETWEEN THE FUNCTION PAWL SHOULDER AND FACE OF FUNCTION BAR
 MIN. 0.002 INCH
 MAX. 0.015 INCH

WHEN PLAY IN PAWL IS TAKEN FOR MAXIMUM CLEARANCE.

DISENGAGE FIGURES FUNCTION PAWL. CHECK LETTERS FUNCTION PAWL IN SAME MANNER.


TO ADJUST

POSITION SHIFT ASSEMBLY WITH CLAMP SCREWS LOOSENED. TAKE UP PLAY IN MOUNTING HOLES TO REAR.

CAUTION: MANUALLY OPERATE LETTERS AND FIGURES FUNCTION LEVER ALTERNATELY
 LEVERS SHOULD BE FREE OF BINDS.

4.09 Function Mechanism (Cont.)

- NOTE: 1. THIS ADJUSTMENT APPLIES ONLY TO UNITS WITH A TWO STOP FUNCTION CLUTCH.
 2. FOR UNITS WITH A ONE STOP FUNCTION CLUTCH SEE PAR. 2.33.



FUNCTION RESET BAIL BLADE

(1) REQUIREMENT

FUNCTION CLUTCH DISENGAGED AT STOP POSITION GIVING LEAST CLEARANCE. TYPE BOX CLUTCH DISENGAGED. ALL FUNCTION PAWLS UNLATCHED FROM THEIR FUNCTION BARS. FUNCTION BAR HELD IN MAXIMUM REARWARD POSITION. CLEARANCE BETWEEN FUNCTION BAR AND RESET BAIL BLADE

MIN. 0.018 INCH---MAX. 0.035 INCH

TO CHECK

MEASURE CLEARANCE AT BARS LOCATED IN STUNT BOX SLOTS. 1, 4, 11, 18, 23, 33, 38, AND 41. IF THERE IS NO BAR IN A DESIGNATED SLOT, USE NEAREST BAR. IF THERE IS A BAR ON EACH SIDE OF A DESIGNATED VACANT SLOT, USE BAR IN HIGHEST NUMBERED SLOT. (NOTE: FACING REAR OF UNIT, SLOTS ARE NUMBERED FROM LEFT TO RIGHT)

TO ADJUST

POSITION BLADE ON RESET BAIL WITH BLADE MOUNTING SCREWS FRICTION TIGHT.


(2) REQUIREMENT

TYPE BOX CLUTCH ROTATED 1/2 REVOLUTION, FUNCTION LEVER HELD IN REARMOST POSITION WITH 2 LBS. MAXIMUM TENSION. LATCH ASSOCIATED PAWL ONLY ONE AT A TIME. WITH 32 OZS. TENSION APPLIED TO FUNCTION PAWL, IT SHOULD OVERTRAVEL ITS BAR

MIN. 0.002 INCH

TO ADJUST

REFINE REQUIREMENT (1).




4.10 Positioning Mechanism

NOTE: THESE ADJUSTMENTS APPLY ONLY TO HORIZONTAL POSITIONING DRIVE MECHANISMS EQUIPPED WITH TENSION SPRINGS.

NOTE: THE LOOPS OF THIS SPRING ARE OFF-SET FROM CENTER IN THE SAME DIRECTION. THE SPRING MUST BE HOOKED ON ITS ANCHORS SO THAT THE SIDE OF THE SPRING ON WHICH THE LOOPS ARE LOCATED, IS TOWARD THE REAR OF THE MACHINE. WHEN REMOVING EITHER SPRING EXERCISE CARE TO AVOID KINKS IN LOOPS.

HORIZONTAL POSITIONING DRIVE LINKAGE SPRING REQUIREMENT

SPRING UNHOOKED FROM ITS POST.
LINKAGE IN ITS UNBUCKLED POSITION.
MIN. 14 OZS. --- MAX. 18 OZS.
TO PULL SPRING TO INSTALLED LENGTH.



HORIZONTAL POSITIONING DRIVE LINKAGE REQUIREMENT

TYPE BOX CLUTCH DISENGAGED. CODE BARS 4 AND 5 TO SPACING (RIGHT).
CLEARANCE BETWEEN EACH SIDE OF CENTER HORIZONTAL STOP SLIDE AND DECELERATING SLIDES ON SIDE WHERE KNEE LINK IS STRAIGHT, SHOULD BE EQUAL (WITHIN 0.005 INCH)
MIN. 0.020 INCH --- MAX. 0.040 INCH

TO ADJUST

LOOSEN BEARING STUD MOUNTING SCREWS AND CONNECTING STRIP MOUNTING SCREWS FRICTION TIGHT. POSITION ONE OR BOTH BEARING STUDS ON THE CONNECTING STRIP TO PROVIDE 0.025 INCH TO 0.035 INCH BETWEEN THE CENTER HORIZONTAL SLIDE AND THE DECELERATING SLIDE ON THE SIDE WHERE THE LINKAGE IS NOT BUCKLED. TIGHTEN THE TWO INNER MOUNTING SCREWS. CHANGE POSITION OF REVERSING SLIDE AND CHECK OPPOSITE CLEARANCE. EQUALIZE BY SHIFTING BOTH STUDS AND CONNECTING STRIP AS A UNIT. HOLD THE DRIVE LINKAGE HUB AGAINST THE LOWER VERTICAL LINK OF THE DRIVE LINKAGE. TIGHTEN THE TWO OUTER BEARING STUD MOUNTING SCREWS. CHECK THE LINKAGE FOR FREENESS THROUGHOUT A COMPLETE CYCLE. THE TYPE BOX CLUTCH DISK SHOULD HAVE SOME MOVEMENT IN THE NORMAL DIRECTION OF ROTATION IN THE STOP POSITION.

4.11 Positioning Mechanism (Cont.)


NOTE: THESE ADJUSTMENTS APPLY ONLY TO HORIZONTAL POSITIONING DRIVE MECHANISMS EQUIPPED WITH TORSION SPRINGS.

HORIZONTAL POSITIONING DRIVE LINKAGE REQUIREMENT

TYPE BOX CLUTCH DISENGAGED.
 CODE BARS 4 AND 5 TO SPACING (RIGHT).
 CLEARANCE BETWEEN EACH SIDE OF CENTER HORIZONTAL STOP SLIDE AND DECELERATING SLIDES, ON SIDE WHERE KNEE LINK IS STRAIGHT SHOULD BE EQUAL (WITHIN 0.008 INCH)
 MIN. 0.015 INCH
 MAX. 0.040 INCH

TO ADJUST


LOOSEN BEARING STUD MOUNTING SCREWS AND CONNECTING STRIP MOUNTING SCREWS FRICTION TIGHT. POSITION ONE OR BOTH BEARING STUDS ON THE CONNECTING STRIP TO PROVIDE 0.025 INCH TO 0.035 INCH BETWEEN THE CENTER HORIZONTAL SLIDE AND THE DECELERATING SLIDE ON THE SIDE WHERE THE LINKAGE IS NOT BUCKLED. TIGHTEN THE TWO INNER MOUNTING SCREWS. CHANGE POSITION OF REVERSING SLIDE AND CHECK OPPOSITE CLEARANCE. EQUALIZE BY SHIFTING BOTH STUDS AND CONNECTING STRIP AS A UNIT. HOLD THE DRIVE LINKAGE HUB AGAINST THE LOWER VERTICAL LINK OF THE DRIVE LINKAGE. TIGHTEN THE TWO OUTER BEARING STUD MOUNTING SCREWS. CHECK THE LINKAGE FOR FREENESS THROUGHOUT A COMPLETE CYCLE. THE TYPE BOX CLUTCH DISK SHOULD HAVE SOME MOVEMENT IN THE NORMAL DIRECTION OF ROTATION IN THE STOP POSITION.



HORIZONTAL POSITIONING DRIVE LINKAGE REQUIREMENT
 WITH LINKAGE IN UNBUCKLED POSITION, SCALE APPLIED NEAR END OF UPPER EXTENSION
 MIN. 6 OZS.
 MAX. 12 OZS.
 TO START LINK BUCKLING.

4.12 Spacing Mechanism (Cont.)

NOTE: CHECK RELATED ADJUSTMENTS, PARS. 4.07, 4.13 AND 2.47 IF THE FOLLOWING ADJUSTMENTS ARE REMADE.



(B) LEFT MARGIN (FOR SPROCKET FEED UNITS SEE PAR. 2.71)


(1) REQUIREMENT (FOR 72 CHARACTER LINE)

TYPE BOX CLUTCH DISENGAGED. SPACING DRUM IN RETURNED POSITION. TYPE BOX SHIFTED TO THE LETTERS POSITION. CENTER OF THE LETTERS PRINT INDICATOR ON THE TYPE BOX SHOULD BE MIN. 15/16 INCH---MAX. 1-1/16 INCH FROM THE LEFT EDGE OF THE PLATEN.

(C) AUTOMATIC CR-LF BELL CRANK SPRING REQUIREMENT

FUNCTION CLUTCH DISENGAGED. MIN. 6-1/2 OZS.---MAX. 11 OZS. TO MOVE THE BELL CRANK.

- (2) REQUIREMENT
 SPACING CLUTCH DISENGAGED. FRONT SPACING FEED PAWL FARTHEST ADVANCED. SPACING DRUM FULLY RETURNED. PLAY IN SPACING SHAFT GEAR PAR. 2.24 TAKEN UP CLOCKWISE. CLEARANCE BETWEEN PAWL AND SHOULDER OF RATCHET WHEEL TOOTH IMMEDIATELY AHEAD MIN. 0.002 INCH---MAX. 0.015 INCH
- (3) REQUIREMENT
 REAR PAWL, WHEN FARTHEST ADVANCED, SHOULD REST AT BOTTOM OF INDENTATION BETWEEN RATCHET WHEEL TEETH. TO ADJUST POSITION STOP ARM ON SPACING DRUM WITH MOUNTING SCREWS LOOSENED.



(A) PRINTING CARRIAGE POSITION (USE STANDARD ADJUSTMENT PAR. 2.47)

SPACING DRUM RATCHET WHEEL



NOTE:
 FOR OTHER LENGTHS OF LINE, RANGING FROM 65 TO 85 CHARACTERS THE MARGIN CAN BE VARIED AS REQUIRED.

NOTE
 THIS VIEW SHOWS THE SPACING DRUM FULLY RETURNED.


(FRONT VIEW)

4.13 Spacing Mechanism (Cont.)


NOTE: CHECK RELATED ADJUSTMENTS, PARS. 4.07, 2.38 AND 2.47, IF THE FOLLOWING ADJUSTMENT ARE REMADE.



4. 14 Printing Mechanism



4. 15 Positioning Mechanism (Cont.)



SECTION 573-115-700

4.16 Printing Mechanism (Cont.)

(A) PRINTING HAMMER STOP BRACKET

(FOR THICK TYPE BOX WITH DUMMY PALLETS)

REQUIREMENT

TYPE BOX IN BLANK OR CR POSITION (WHICHEVER DOES NOT PRINT) AND NEAR CENTER OF PLATEN. PRINTING TRACK IN ITS DOWNWARD POSITION. PRINTING HAMMER HELD AGAINST ITS STOP WITH 8 OZS. OF PRESSURE. CLEARANCE BETWEEN PRINTING HAMMER AND DUMMY TYPE PALLET

FRICTION FEED

MIN. 0.008 INCH

MAX. 0.020 INCH

TO ADJUST

POSITION THE STOP BRACKET WITH ITS MOUNTING SCREW AND THE PRINTING HAMMER BAIL PIVOT STUD LOOSENED.

(FOR SPROCKET FEED UNITS, SEE PAR. 2.71)

(C) TYPE PALLET SPRING


REQUIREMENT

TYPE BOX REMOVED FROM THE UNIT. 8 OZ. SCALE APPLIED VERTICALLY TO THE END OF THE PALLET SHANK.

MIN. 1/4 OZ.

MAX. 3/4 OZ.

TO START PALLET MOVING



(B) PRINTING ARM

(1) REQUIREMENT

PRINTING TRACK IN MAXIMUM DOWNWARD POSITION. PRINTING HAMMER OPERATING BAIL AGAINST ITS STOP. SOME CLEARANCE BETWEEN SECONDARY PRINTING ARM AND FORWARD EXTENSION OF HAMMER OPERATING BAIL.

MAX. 0.015 INCH

WHEN PRINTING ARM SLIDE IS HELD DOWNWARD OVER EACH PRINTING TRACK MOUNTING SCREW FOR MAXIMUM CLEARANCE.

(2) REQUIREMENT

PRINTING TRACK IN UPPERMOST POSITION. LATCHING EXTENSION OF PRINTING HAMMER OPERATING BAIL SHOULD OVERTRAVEL LATCHING SURFACE OF OPERATING BAIL LATCH BY MIN. 0.006 INCH

CHECK RIGHT AND LEFT POSITION


TO ADJUST

POSITION SECONDARY PRINTING ARM WITH CLAMP SCREWS LOOSENED.


NOTE

THE PRINTING ARM ADJUSTMENT SHOULD ALWAYS BE MADE WITH THE PRINTING HAMMER OPERATING BAIL SPRING BRACKET (PAR. 2.38) IN THE NO. 1 POSITION POSITIONS NO. 2 AND NO. 3 ARE TO BE USED ONLY FOR MAKING MULTIPLE COPIES.

(FRONT VIEW)





4.17 Printing Mechanism (Cont.)



(A) RIBBON REVERSE SPUR GEAR REQUIREMENT

WHEN RIGHT REVERSING LEVER IS IN MAXIMUM DOWNWARD POSITION, THE LEFT REVERSING LEVER SHOULD BE IN ITS MAXIMUM UPWARD POSITION.
 TO ADJUST
 LOOSEN THE SET SCREWS IN THE DETENT CAM. LOOSEN THE LEFT SPUR GEAR NUT. SECURELY TIGHTEN THE RIGHT SPUR GEAR NUT. MOVE THE RIGHT REVERSING LEVER TO ITS MAXIMUM DOWNWARD POSITION AND HOLD LEFT REVERSING LEVER IN ITS MAXIMUM UPWARD POSITION. THEN TIGHTEN THE LEFT SPUR GEAR NUT.




(C) RIBBON REVERSE DETENT LEVER SPRING REQUIREMENT

DETENT SEATED IN NOTCH OF CAM. RIGHT RIBBON REVERSING LEVER HELD DOWNWARD.
 MIN. 6-1/2 OZS. --- MAX. 9 OZS.
 TO START THE DETENT LEVER MOVING.

(B) RIBBON REVERSE DETENT REQUIREMENT
 DETENT SEATED APPROXIMATELY EQUAL IN UPPER AND LOWER POSITIONS OF DETENT CAM
 TO ADJUST
 POSITION CAM ON SHAFT WITH SET SCREWS LOOSENED. LET LEFT END OF DETENT STUD BE APPROXIMATELY FLUSH WITH LEFT FACE OF CAM (PLAY IN DETENT TAKEN TO RIGHT OF PRINTER)

SECTION 573-115-700

4.18 Function Mechanism (Cont.)



FUNCTION STRIPPER BLADE ARMS
REQUIREMENT

TYPE BOX CLUTCH AND FUNCTION CLUTCH DISENGAGED. LEFT LINE FEED FUNCTION PAWL HELD IN ITS REAR POSITION AND RESTING ON THE UPPER EDGE OF THE STRIPPER BLADE. CLEARANCE BETWEEN UPPER EDGE OF FUNCTION BAR AND LOWER SURFACE OF NOTCHED SECTION OF FUNCTION PAWL.

MIN. 0.055 INCH

MAX. 0.065 INCH

THE LETTERS FUNCTION PAWL NEAR THE OPPOSITE END OF THE STRIPPER BLADE SHOULD HAVE THE SAME CLEARANCE.


TO ADJUST

POSITION THE SHOULDER BUSHING AT THE LOWER END OF THE RIGHT AND LEFT STRIPPER BLADE ARM WITH THE LOCK NUT LOOSENED.

NOTE

WHEN CHECKING THIS ADJUSTMENT SINGLE-DOUBLE LINE FEED LEVER MUST BE IN DOUBLE LINE FEED POSITION.

4.19 Spacing Mechanism (Cont.)



AUTOMATIC CARRIAGE RETURN AND
LINE FEED ARM

REQUIREMENT (OPERATING ON BASE)

CARRIAGE IN POSITION TO PRINT TWO SPACES BEFORE THE LAST DESIRED CHARACTERS, AND FRONT SPACING PAWL FARTHEST ADVANCED. CLEARANCE BETWEEN LEADING END OF AUTOMATIC CARRIAGE RETURN ARM AND BELL CRANK.

MIN. 0.040 INCH

MAX. 0.055 INCH

TO ADJUST

POSITION AUTOMATIC CARRIAGE RETURN ARM WITH MOUNTING SCREWS LOOSENED.

NOTE


RANGE OF ADJUSTMENT IS FROM 65TH TO 85TH CHARACTERS.

NOTE


FOR UNITS EQUIPPED WITH UNIVERSAL SPACING DRUM, SEE PAR. 2.62.

4.20 Line Feed Mechanism and Platen Mechanism


NOTE: THIS ADJUSTMENT APPLIES ONLY TO UNITS WITH A TWO-STOP FUNCTION CLUTCH




4.21 Function Mechanism (Cont.)




4.22 Function Mechanism (Cont.)



CAUTION: CARE SHOULD BE EXERCISED IN SOLDERING TO CONTACT SPRINGS SINCE EXCESSIVE HEAT WILL ANNEAL THE SPRINGS.



4.23 Spacing Mechanism (Cont.)



MARGIN INDICATOR LAMP
REQUIREMENT

OPERATING UNDER POWER, THE LAMP SHOULD LIGHT ON THE DESIRED CHARACTER.
TO ADJUST

SET THE TYPE BOX CARRIAGE TO PRINT THE DESIRED CHARACTER AND POSITION THE CAM DISK COUNTERCLOCKWISE ON THE SPRING DRUM WITH ITS THREE MOUNTING SCREWS LOOSENED SO THAT THE SWITCH JUST OPENS. IF A LINE SHORTER THAN 72 CHARACTERS IS REQUIRED, IT MAY BE NECESSARY TO REMOVE THE CAM DISK SCREWS AND INSERT THEM IN ADJACENT SLOTS OF THE DISK, IF THE RANGE OF ROTATION IN ONE SLOT IS NOT ENOUGH.

VARIABLE FEATURES

4.24 Horizontal Tabulator Mechanism

(A)

OPERATING LEVER SLIDE ARM

NOTE

PRIOR TO THIS ADJUSTMENT CHECK FUNCTION
RESET BAIL BLADE ADJUSTMENT (PAR. 4.09)

REQUIREMENT

ON UNITS WITH TWO-STOP FUNCTION CLUTCHES.
FUNCTION CLUTCH DISENGAGED. TYPE BOX CLUTCH
ROTATED 1/2 REVOLUTION PAST STOP POSITION. ON UNITS
WITH ONE-STOP FUNCTION CLUTCH, ROTATE CLUTCH
UNTIL FUNCTION PAWL STRIPPER BLADE IS IN ITS
LOWER POSITION AND THE FUNCTION RESET BAIL ROLLER
IS ON THE HIGH PART OF CAM. HORIZONTAL TABULATOR
FUNCTION PAWL PULLED TO REAR AND LATCHED OVER
FUNCTION BAR. CLEARANCE

MIN. 0.020 INCH
MAX. 0.030 INCH

TO ADJUST

POSITION SLIDE ARM ON OPERATING LEVER WITH
MOUNTING STUD FRICTION TIGHT

(D) TABULATOR SHAFT SPRING (TORSION)

NOTE

FOR LOCATION OF SPRING
SEE PAR. 4.27

REQUIREMENT

OPERATING LEVER IN
UNOPERATED POSITION.
(AS IN LOWER FIGURE)
MIN. 1-1/2 OZS.
MAX. 3-1/2 OZS.
TO START SLIDE ARM
MOVING.

(C)

OPERATING LEVER EXTENSION
LINK SPRING

REQUIREMENT

TRIP ARM LATCH BAIL SPRING
UNHOOKED. OPERATING LEVER
IN OPERATED POSITION.
SLIDE ARM AGAINST
BLOCKING LINK.

MIN. 8-3/4 OZS.
MAX. 10-3/4 OZS.

TO START LINK MOVING.

(B)


OPERATING LEVER ADJUSTING PLATE

REQUIREMENT


OPERATING LEVER IN UNOPERATED
POSITION. CLEARANCE
MIN. 0.070 INCH
MAX. 0.085 INCH

TO ADJUST


POSITION ADJUSTING PLATE ON
BRACKET WITH MOUNTING
SCREWS LOOSE.




4.25 Horizontal Tabulator Mechanism (Cont.)



TRIP ARM LATCH BAIL ADJUSTING PLATE REQUIREMENT
 SPACING CLUTCH AND TYPE BOX
 CLUTCH DISENGAGED. OPERATING
 LEVER SLIDE ARM TO REAR AND
 LATCHED ON BLOCKING ARM. LATCH
 BAIL IN FULLY LATCHED POSITION.
 SPACING TRIP ARM DOWN AND
 BEARING UP AGAINST LATCHING
 SURFACE OF LATCH BAIL. CLEARANCE
 MIN. SOME
 MAX. 0.008 INCH
 TO ADJUST
 POSITION LATCH BAIL ADJUSTING
 PLATE WITH MOUNTING SCREW
 FRICTION TIGHT.



4.26 Horizontal Tabulator Mechanism (Cont.)



SECTION 573-115-700

4.27 Horizontal Tabulator Mechanism (Cont.)


(A) RIGHT MARGIN

REQUIREMENT
CLEARANCE
MIN. 0.006 INCH---MAX. 0.025 INCH

TO CHECK
PLACE TYPE BOX IN POSITION TO PRINT CHARACTER ON WHICH SPACING CUTOUT IS DESIRED. PULL FORWARD ON PART OF TRANSFER BAIL EXTENDING BELOW MOUNTING SHAFT UNTIL BAIL IS IN FULLY OPERATED POSITION. GAUGE CLEARANCE.


TO ADJUST
POSITION CUTOUT LEVER WITH CLAMP SCREW LOOSENED. (FOR LOCATION OF CLAMP SCREW SEE PAR.4.13)

NOTE: FOUR SCREWS MUST BE LOOSENED TO ADJUST CIRCULAR CUTOUT LEVERS.



(B) SPACE SUPPRESSION BY-PASS SPRING

REQUIREMENT
MIN. 20 OZS.
MAX. 26 OZS.
TO START ARM MOVING.



(D) TABULATOR PAWL SPRING


REQUIREMENT
MIN. 1-3/4 OZS.
MAX. 3 OZS.
TO PULL SPRING TO INSTALLED LENGTH.

(C) TABULATOR SHAFT MOUNTING BRACKETS

REQUIREMENT
LEVER SLIDE ARM TO REAR SO THAT BLOCKING ARM AND TABULATOR STOP ARE IN EXTREME UPPER POSITION.
CLEARANCE
MIN. 0.050 INCH---MAX. 0.065 INCH
CLEARANCE MEASURED NEAR LEFT AND RIGHT END OF SHAFT EQUAL WITHIN 0.007 INCH.

TO ADJUST
POSITION MOUNTING BRACKETS WITH MOUNTING SCREWS LOOSENED.
NOTE: MAKE SURE SHAFT IS FREE OF BINDS.

4.28 Horizontal Tabulator Mechanism (Cont.)



NOTE --- PRIOR TO THIS ADJUSTMENT, CHECK THE FOLLOWING: OSCILLATING RAIL SLIDE (PAR. 2.30), PRINTING CARRIAGE POSITION (PAR. 2.47) AND PRINTING CARRIAGE LOWER ROLLER (PAR. 2.46).

REQUIREMENT (UNITS WITH FRICTION FEED PLATENS)

SPACING CLUTCH DISENGAGED. SPACING PAWL, WHICH IS FARTHEST ADVANCED, ENGAGING TOOTH IMMEDIATELY ABOVE CUTAWAY SECTION OF RATCHET. TABULATOR PAWL RIDING UP ON FIXED STOP. HIGH PART OF ECCENTRIC TOWARD FORK OF MOUNTING ARM. CLEARANCE

MIN. 0.070 INCH MAX. 0.090 INCH


REQUIREMENT (UNITS WITH SPROCKET FEED PLATENS)

HIGH PART OF ECCENTRIC TOWARD LOWER ROLLER MOUNTING SCREW.

TO ADJUST

POSITION ECCENTRIC.

4.29 Horizontal Tabulator Mechanism (Cont.)



PAWL MOUNTING ARM OPERATING RANGE (FINAL)

REQUIREMENT

CLEARANCE MIDWAY BETWEEN MINIMUM AND MAXIMUM LIMITS OF OPERATING RANGE.

TO CHECK

TO DETERMINE MAXIMUM LIMIT. . . (A) SET FIVE TABULATOR STOPS AS SHOWN IN FIGURE. (B) POSITION PAWL IMMEDIATELY TO RIGHT OF STOP NO. 1. (C) POSITION ECCENTRIC TO SET CLEARANCE APPROXIMATELY 0.030 INCH. (NOTE . . . MEASURE ALL CLEARANCES AT STOP NO. 1. WITH PLAY TAKEN UP IN CARRIAGE TO REDUCE GAP TO MINIMUM.) (D) MARK COLUMN LOCATION BY PRINTING A CHARACTER ON PAPER. (E) POSITION PAWL IMMEDIATELY TO RIGHT OF STOP NO. 2 AND MARK COLUMN LOCATION AS IN STEP (D). (F) REPEAT STEP (E) FOR OTHER THREE STOPS. (G) GRADUALLY INCREASE CLEARANCE UNTIL CARRIAGE STOPS ONE SPACE BEFORE ANY COLUMN WHILE RECEIVING FIGURES G LETTERS X FROM TRANSMITTER DISTRIBUTOR. (NOTE . . . IF UNIT IS NOT EQUIPPED WITH XD CONTROL, PUT FILL-IN CHARACTERS OF LETTERS OR FIGURES IN TAPE TO DELAY PRINTING UNTIL CARRIAGE COMPLETES TRAVEL.) (H) DECREASE CLEARANCE UNTIL TEN LINES OF TABULAR OPERATION CAN BE MADE WITHOUT ERROR. (I) GAUGE AND RECORD VALUES OF CLEARANCE. (2) GAGE ALL CLEARANCES WITH FRONT FEED PAWL FARTHEST ADVANCED.

TO DETERMINE MINIMUM LIMITS . . . (A) REPEAT STEPS (B) AND (C) ABOVE. (B) GRADUALLY DECREASE CLEARANCE UNTIL CARRIAGE STOPS ONE SPACE AFTER ANY COLUMN. (C) INCREASE CLEARANCE UNTIL TEN LINES OF TABULAR OPERATION CAN BE MADE WITHOUT ERROR. (I) GAUGE AND RECORD VALUE OF CLEARANCE.

TO ADJUST

IF MINIMUM LIMIT IS POSITIVE, ADD IT TO MAXIMUM LIMIT AND DIVIDE THE SUM BY TWO. SET RESULTANT AMOUNT AS MIDPOINT OF RANGE. IF MINIMUM LIMIT IS ZERO OR LESS, DIVIDE MAXIMUM LIMIT BY TWO AND SET THIS AMOUNT AS MIDPOINT OF RANGE. THE DIFFERENCES BETWEEN LIMITS NORMALLY IS NOT LESS THAN 0.045 INCH.

TABULATOR STOP SETTING (NOT ILLUSTRATED)

RIGHT MARGIN TABULATOR STOP (WITH WIDE SHELF)

NOTE: PRIOR TO THIS ADJUSTMENT, CHECK THE FOLLOWING: RIGHT MARGIN (PAR. 4.27) AND PAWL MOUNTING ARM OPERATING RANGE (PAR. 4.28 AND 4.29).


POSITION PRINTING CARRIAGE AT RIGHT MARGIN (SPACING CUTOUT OPERATED). INSERT STOP WITH WIDE SHELF IN SLOT IMMEDIATELY TO LEFT OF TABULATOR PAWL.

COLUMNAR TABULATOR STOPS

PLACE CARRIAGE IN POSITION TO PRINT FIRST CHARACTER IN COLUMN. INSERT STOP IN SLOT IMMEDIATELY TO LEFT OF TABULATOR PAWL. STORE EXTRA STOPS IN SLOTS BEYOND PRINTING LINE AT EITHER END OF SHAFT.

NOTE . . . WHEN PRINTING FORMS, CHECK STOP SETTINGS WITH RELATION TO COLUMNS. CORRESPONDING STOPS ON ALL MACHINES CONNECTED IN A CIRCUIT MUST BE THE SAME NUMBER OF SPACING OPERATIONS FROM LEFT MARGIN.

4. 30 Paper-Out Alarm Mechanism



BELL CRANK FOLLOWER REQUIREMENT
 THE BELL CRANK FOLLOWER SHOULD BE APPROXIMATELY 1/4 INCH FROM A FLAT SIDE OF THE PAPER SPINDLE.
 TO ADJUST POSITION THE SWITCH WITH ITS MOUNTING SCREWS LOOSENED.



REPLACING PAGE ADDENDUM

Filing Instructions

1. Remove from the section the pages numbered the same as those attached to this sheet.
2. Insert the attached pages into the section in their place.
3. Place this sheet ahead of Page 1 of the section.

28 TYPING AND NONTYPING PERFORATORS

ADJUSTMENTS

1. GENERAL

1.001 This addendum supplements Section 573-139-700TC, Issue 1, and is issued to incorporate engineering changes to the backspace mechanism, and to change the requirement tolerance for the LATCH LEVER CLEARANCE adjustment of the punch mechanism. Arrows in the margins indicate changes.

1.002 Insert the attached pages in accordance with the filing instructions above.

Attached:

Page 1 dated May 1966, reissued; April 1968, reissued
Page 2 dated May 1966, revised; April 1968, reissued
Page 17 dated April 1968, revised
Page 18 dated April 1968, reissued
Page 57 dated May 1966, revised; April 1968, reissued
Page 58 dated May 1966, revised; April 1968, reissued
Page 61 dated May 1966, reissued; April 1968, reissued
Page 62 dated May 1966, revised; April 1968, reissued



28 TYPING AND NONTYPING PERFORATORS

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	3	Punch slide downstop position	14
2. BASIC UNIT	5	Punch slide guide position	14
Function Mechanism		Punch slide spring	25
Clutch shoe lever spring	6	Retractor bail springs	25
Clutch shoe spring	6	Tape guide spring	26
Function clutch drum end play	5	Punch Mechanism (For Fully Perforated Tape)	
Function clutch latch lever spring	34	Punch pin penetration	15
Function clutch release spring	10	Punch slide downstop position	15
Function clutch shoe lever	5	Punch slide guide	15
Function clutch trip lever	9	Punch slide spring	27
Main trip lever	10	Tape guide spring (punch block)	27
Main trip lever spring	10	Punch Mechanism (For Fully Perforated Tape with Indentations of Feed Wheel Between the Feed Holes)	
Release downstop bracket	31	Detent	24
Reset arm	9	Feed hole lateral alignment	24
Rocker bail	7	Feed hole spacing (final)	23
Rocker bail guide bracket	8	Punch Mechanism (For Fully Perforated Tape with Indentations of Feed Wheel Fully Punched Out)	
Punch Mechanism		Feed wheel indentation alignment	22
Detent lever spring	30	Feed hole spacing	21
Feed pawl (preliminary)	17	Punch Mechanism (For Nontyping Perforator)	
Feed pawl spring	30	Perforator position (final)	11
Latch lever clearance	17	Perforator position (preliminary)	11
Perforator drive link spring	13	Punch Mechanism (For Typing Perforator)	
Reset bail trip lever	16	Perforator position	12
Tape depressor slide spring	28	Ribbon Feed Mechanism	
Tape guide	28	Detent spring	56
Tape guide assembly spring	26	Drive arm	55
Tape guide (early design)	29	Drive arm spring	56
Tape guide (latest design)	29	Feed pawl spring	55
Tape guide spring (for units not equipped with tape guide adjusting plate)	29	Ratchet wheel torque spring	55
Tape guide spring (tape chute)	26		
Tape shoe torsion spring	28		
Toggle bail eccentric (preliminary)	13		
Toggle operating arm	13		
Punch Mechanism (For Chadless Tape)			
Detent lever	19		
Feed hole lateral alignment	20		
Feed hole spacing (final)	18		
Feed hole spacing (preliminary)	18		
Punch pin penetration	14		

CONTENTS	PAGE
Typing Mechanism	
Accelerator spring	52
Axial corrector (yielding)	47
Axial corrector (non-yielding)	46
Axial output rack guide roller	45
Axial sector alignment	44
Bell crank springs	32
Corrector drive link (yielding) extension spring	47
Corrector drive link spring (non-yielding)	42
Eccentric shaft	44
Figures arm assembly spring	37
Figures extension spring	37
Function blade springs	42
Function box	35
Idler gear eccentric shaft	46
Letters and figures yield arm	37
Letters arm assembly spring	38
Letters extension arm spring	38
Lifter arm	39
Lifter arm eccentric screw	39
Lifter spring	42
Lifter toggle link spring	42
Lock lever	40
Lock lever trip post	41
No. 5 pulse beam spring	40
Oscillating bail drive link	43
Oscillating pivot	43
Print hammer spring	52
Printing latch spring	52
Printing trip link	52
Printing trip link spring	52
Pushbar guide bracket	45
Pushbar operating blade (final)	33
Pushbar operating blade (preliminary)	32
Rocker bail pilot stud	34
Rotary correcting lever	48
Transfer mounting bracket	36
Typing Mechanism (For Chadless Tape)	
Print hammer	53
Ribbon carrier	50
Typewheel	53
Typing Mechanism (For Fully Perforated Tape)	
Print hammer (preliminary)	54
Ribbon carrier	51
Typewheel positioning and print hammer (final)	54

CONTENTS	PAGE
3. VARIABLE FEATURES	57
Chad Chute Assembly	80
Code Reading Contacts	
Code reading contacts (strobing)	76
Contact bracket (preliminary) make type contacts	71
Contact bracket (preliminary) transfer type contacts	70
Contact mounting bracket	69
Contact mounting plate	69
Marking contact backstops	67
Marking contact springs (preliminary)	67
Spacing contact backstops (preliminary)	68
Spacing contact springs (preliminary)	68
Swinger contact springs (preliminary)	68
Manual and Power Drive Back- space Mechanism	
Early Design	
Armature hinge	61
Armature upstop	61
Latch	63
Latch extension	62
Non-repeat arm	63
For Chadless Tape	
→ Drive arm	62
Feed pawl adjusting plate	57
→ Feed pawl eccentric	58
Rake	57
Return latch	58
For Chadless Tape (Early Design)	
Armature bail spring	64
Bell crank spring	64
Latch extension spring (power drive only)	64
Gear segment spring	64
Feed pawl spring	64
Latch spring	64
For Fully Perforated Tape	
Backspace pawl clearance	59
Backspace ratchet	59
Drive link	60
Feed pawl disabling	60

CONTENTS	PAGE
For Fully Perforated Tape (Early Design)	
Armature bail spring	65
Armature latch spring	65
Bell crank spring	65
Feed pawl spring	65
For Non-Adjustable Backspace Magnet Assembly (Latest Design)	
Armature spring	66
Latch extension	66
Magnet position	66
For Chadless and Fully Perforated Tape	
Final manual or power drive	66
Timing Contacts	
Contact alignment	72
Contact backstop (double contact assembly)	72
Contact bracket (preliminary) for units with one-cycle cams	74
Contact bracket (preliminary) for units with two-cycle cams	75
Left contact gap	73
Left contact spring	73
Operating bail springs	74
Timing contacts (strobing)	78
Swinger contact spring (preliminary) .	73
Unshift-On-Space Mechanism	
Unshift-on-space function blade	79
Unshift-on-space function blade spring	79

1. GENERAL

1.01 This section has been revised to include recent engineering changes and additions, and to rearrange the text, so as to bring the section generally up-to-date. Since this is an extensive revision, marginal arrows ordinarily used to indicate changes have been omitted.

1.02 This section contains the specific requirements and adjustments for the 28 typing and non-typing perforators.

1.03 Maintenance procedures which apply only to mechanisms of a particular design, or to certain models of 28 typing or non-typing perforators are so indicated in the titles of the paragraphs which contain these particular adjustment requirements.

1.04 The adjustments of each unit are arranged in a sequence that should be followed if a complete readjustment of the unit were undertaken. The tools and spring scales required to perform these adjustments are listed in the applicable section. After an adjustment is completed, be sure to tighten any nuts or screws that are loosened. The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions and the angles at which scales should be applied when measuring spring tensions. If a part mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same number is replaced when the part is re-mounted.

1.05 Reference made to left or right, up or down, front or rear, etc apply to the unit in its normal operating position as viewed from the front.

1.06 When a requirement calls for a clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latch lever so that the clutch shoes release their tension on the clutch drum. When engaged, the clutch shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum.

Note: When the signalgenerator shaft is rotated by hand, the clutch does not fully disengage upon reaching its stop position. In order to relieve drag and permit the main shaft to rotate freely, apply pressure on the lug of the clutch disc with a screwdriver to cause it to engage its latch lever and fully disengage the clutch.

1.07 All electrical contact points should meet squarely. Contacts with the same diameter should not be out of alignment more than 25 per cent of the contact diameter. Check contacts for pitting and corrosion and clean or burnish them before making specified adjustments or tolerance measurement. Avoid sharp kinks or bends in the contact springs.

CAUTION: KEEP ALL ELECTRICAL CONTACTS FREE OF OIL AND GREASE.




Figure 1 - 28 Non-Typing Perforator - Chadless Tape (With Code Reading Contacts, Timing Contacts and Backspace Mechanism)




Figure 2 - 28 Typing Perforator - Chadless Tape (With Backspace Mechanism)

2. BASIC UNIT

2.01 Function Mechanism

NOTE: UNLESS OTHERWISE SPECIFIED, THESE ADJUSTMENTS APPLY TO BOTH TYPING AND NON-TYPING PERFORATORS.

(A) FUNCTION CLUTCH SHOE LEVER TO CHECK


- (1) DISENGAGE CLUTCH. MEASURE CLEARANCE.
- (2) ALIGN HEAD OF CLUTCH DRUM MOUNTING SCREW WITH STOP LUG. ENGAGE CLUTCH. MANUALLY PRESS SHOE LEVER AND STOP LUG TOGETHER AND ALLOW TO SNAP APART. MEASURE CLEARANCE.

REQUIREMENT

CLEARANCE BETWEEN SHOE LEVER AND STOP LUG.
 MIN. 0.055 INCH --- MAX. 0.085 INCH
 GREATER WHEN CLUTCH IS ENGAGED (2) THAN WHEN DISENGAGED (1).

TO ADJUST

ENGAGE WRENCH OR SCREWDRIVER WITH LUG ON ADJUSTING DISK. ROTATE DISK WITH CLAMP SCREWS LOOSENED.





(B) FUNCTION CLUTCH DRUM END PLAY REQUIREMENT

WITH FUNCTION CLUTCH DISENGAGED.
 MIN. SOME --- MAX. 0.015 INCH
 BETWEEN CAM SLEEVE AND COLLAR WHEN PLAY IS TAKEN UP TO MAKE CLEARANCE MAXIMUM.


TO ADJUST

POSITION COLLAR WITH MOUNTING SCREW LOOSENED.

2.02 Function Mechanism continued



2.03 Function Mechanism continued



ROCKER BAIL
REQUIREMENT

WITH ROCKER BAIL POSITIONED TO ITS
EXTREME LEFT AND UPPER ROLLER IN
CONTACT WITH FUNCTION CAM:
MIN. SOME -----MAX. 0.004 INCH
CLEARANCE BETWEEN CAM AND LOWER
ROLLER AT POINT OF LEAST CLEARANCE.

TO ADJUST

POSITION LOWER ROLLER MOUNTING
SCREW IN ELONGATED SLOT WITH LOCK
NUT LOOSENED. CHECK THROUGHOUT
A COMPLETE REVOLUTION FOR BINDS.

(REAR VIEW)

2.04 Function Mechanism continued


ROCKER BAIL GUIDE BRACKET
(TYPING PERFORATOR ONLY)

REQUIREMENT

- (1) ROCKER BAIL ROLLERS SHOULD ENGAGE FULL THICKNESS OF FUNCTION CAM.
- (2) LIFTER ROLLER IN FULL ENGAGEMENT WITH ROCKER BAIL CAMMING SURFACE. SEE PARAGRAPH 2.36.

TO ADJUST

POSITION ROCKER BAIL AND GUIDE BRACKET WITH GUIDE BRACKET MOUNTING SCREWS LOOSENED.



ROCKER BAIL GUIDE BRACKET
(NON-TYPING PERFORATOR ONLY)

REQUIREMENT

CLEARANCE BETWEEN UPPER ROLLER AND RESET PINS; BETWEEN LOWER ROLLER SCREW HEAD AND FRONT CAM; BETWEEN ROCKER BAIL AND REAR ROCKER CAM.
MIN. 0.010 INCH

TO ADJUST

POSITION ROCKER BAIL WITH GUIDE MOUNTING SCREWS LOOSENED.




2.05 Function Mechanism continued

(A) FUNCTION CLUTCH TRIP LEVER
REQUIREMENT

(1) WITH RELEASE RESTING ON MAIN TRIP LEVER (SEE BELOW), FUNCTION CLUTCH TRIP LEVER SHOULD ENGAGE FULL THICKNESS OF SHOE LEVER AT THE STOP WHERE BITE IS LEAST

(2) TRIP LEVER END PLAY:
MIN. SOME --- MAX. 0.010 INCH

TO ADJUST POSITION TRIP LEVER ON ITS SHAFT WITH CLAMP SCREW LOOSENED.



(3) CLEARANCE BETWEEN RELEASE LEVER AND FUNCTION CAM:
MIN. SOME

(B) RESET ARM

TO CHECK TRIP FUNCTION CLUTCH AND POSITION MAIN SHAFT SO THAT RESET ARM IS HELD IN ITS HIGHEST POSITION BY CAM.

REQUIREMENT

(1) CLEARANCE BETWEEN RELEASE AND MAIN TRIP LEVER.

	<u>NON-TYPING PERFORATOR</u>	<u>TYPING PERFORATOR</u>
MIN.	0.005 INCH	0.005 INCH
MAX.	0.030 INCH	0.030 INCH

(2) LATCH LEVER END PLAY:
MIN. SOME
MAX. 0.010 INCH


TO ADJUST

POSITION RESET ARM ON ITS SHAFT WITH ITS CLAMP SCREW LOOSENED.


2.06 Function Mechanism continued

(A) MAIN TRIP LEVER REQUIREMENT
 CLUTCH LATCHED, PUNCH RESET BAIL MUST BE IN ITS UPPERMOST POSITION WHEN THE TRIP LEVER IS FLUSH WITH THE END OF THE RELEASE.
 TO ADJUST POSITION MAIN TRIP LEVER WITH ITS CLAMP SCREW LOOSENED.

(B) FUNCTION CLUTCH RELEASE SPRING REQUIREMENT
 PERFORATOR CLUTCH DISENGAGED.
 MIN. 5 OZS.
 MAX. 8 OZS.
 TO START RELEASE MOVING.



(C) MAIN TRIP LEVER SPRING REQUIREMENT
 WITH THE RESET BAIL TRIP LEVER EXTENSION TRIPPED.
 MIN. 1 OZ.
 MAX. 4 OZS.
 TO START MAIN TRIP LEVER MOVING.



NOTE: ON UNITS EQUIPPED WITH RIBBON FEED IT WILL BE NECESSARY TO REMOVE THE RIBBON FEED MECHANISM.

2.07 Punch Mechanism


PERFORATOR POSITION -PRELIMINARY - (FOR NON-TYPING PERFORATOR ONLY)REQUIREMENT

THE PERFORATOR MECHANISM MOUNTING SCREW BENEATH PUNCH BLOCK AND MOUNTING SCREW AT LOWER EDGE OF PERFORATOR MECHANISM BACKPLATE SHALL BE LOCATED CENTRALLY WITHIN THEIR RESPECTIVE MOUNTING HOLES.

NOTE: THE MOUNTING HOLES ARE OVERSIZE TO FACILITATE USE OF PERFORATOR MECHANISM ON THE TYPING REPERFORATOR.

TO ADJUST

REMOVE MOUNTING SCREW AT THE LOWER EDGE OF PERFORATOR MECHANISM BACKPLATE, WITH THE TWO REMAINING BACKPLATE MOUNTING SCREWS AND MOUNTING BRACKET SCREW FRICTION TIGHT, POSITION PERFORATOR MECHANISM SO THAT THE TAPPED HOLE OF THE FRAME IS CENTRALLY LOCATED (AS GAUGED BY EYE) WITHIN LARGE BODY HOLE OF PUNCH MECHANISM BACKPLATE. TIGHTEN THE TWO BACKPLATE MOUNTING SCREWS AND RECHECK TO SEE THAT REQUIREMENT IS MET. REPLACE AND TIGHTEN THE LOWER BACKPLATE MOUNTING SCREW. TIGHTEN THE BRACKET MOUNTING SCREW.

PERFORATOR POSITION -FINAL - (FOR NON-TYPING PERFORATOR ONLY)REQUIREMENT

WITH LETTERS COMBINATION SELECTED AND FUNCTION CLUTCH JUST TRIPPED.

MIN. 0.015 INCH --- MAX. 0.045 INCH

CLEARANCE BETWEEN THE CLOSEST LATCH LEVER AND ASSOCIATED PUNCH SLIDE.

TO ADJUST

LOOSEN (FRICTION TIGHT) REAR FRAME MOUNTING SCREWS (AND PIVOT LOCATING PLATE CLAMP SCREW IF THE TYPING UNIT IS USED ON THE PUNCH), THE FRONT MOUNTING BRACKET SCREWS, PLACE TIP OF SCREWDRIVER BETWEEN HEX HEAD SCREW AND ITS CLEARANCE HOLE RIM AND PRY UP OR DOWN. TIGHTEN SCREWS. (IF THE TYPING UNIT IS BEING USED, TIGHTEN PIVOT LOCATING PLATE CLAMP SCREW ONLY, AS THE NEXT ADJUSTMENT WILL BE TO OBTAIN CLEARANCE BETWEEN TYPEWHEEL AND PUNCH.


2.08 Punch Mechanism continued

PERFORATOR POSITION (FOR TYPING PERFORATOR ONLY)

- (1) REQUIREMENT - (FOR TYPING PERFORATOR WITH SPRING RETRACTED PUNCH UNIT) WITH UNIT IN STOP POSITION AND TYPEWHEEL IN THE LETTERS FIELD. CLEARANCE BETWEEN THE LETTER "Z" ON THE TYPEWHEEL AND THE TOP OF THE STRIPPER PLATFORM. MIN. 0.090 INCH --- MAX. 0.110 INCH
- (2) REQUIREMENT - (FOR TYPING PERFORATOR WITH POWER RETRACTED PUNCH UNIT) WITH UNIT IN STOP POSITION AND TYPEWHEEL IN THE FIGURES FIELD. CLEARANCE BETWEEN THE FIGURE "5" ON THE TYPEWHEEL AND THE TOP OF THE STRIPPER PLATFORM. MIN. 0.075 INCH --- MAX. 0.095 INCH


TO ADJUST

REMOVE RIBBON FROM CARRIER. POSITION PERFORATOR WITH TWO MOUNTING SCREWS, ADJUSTING CLAMP PIVOT SCREW AND ANCHOR BRACKET SCREW LOOSENED. CHECK RESET BAIL TRIP LEVER REQUIREMENT FOR SOME CLEARANCE AND ADJUST IF NECESSARY.



2.09 Punch Mechanism continued


NOTE: BEFORE PROCEEDING WITH THE PUNCH MECHANISM ADJUSTMENTS, CHECK THE ROCKER BAIL CAM FOLLOWER ROLLER ADJUSTMENT AND LOOSEN THE PUNCH SLIDE DOWNSTOP MOUNTING NUT AND GUIDE MOUNTING STUD.



*AFTER FEED PAWL ADJUSTMENT HAS BEEN MADE, IF PUNCH PIN PENETRATION AND FEED PAWL REQUIREMENTS ARE MET, THIS REQUIREMENT SHOULD BE CONSIDERED FULFILLED.

2.10 Punch Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO CHADLESS TAPE MECHANISM.



(A) PUNCH SLIDE DOWNSTOP POSITION
REQUIREMENT

FUNCTION CLUTCH DISENGAGED. UP AND DOWN PLAY AT LEFT END OF PUNCH SLIDES TAKEN UP TOWARD TOP, CLEARANCE BETWEEN FRONT AND REAR PUNCH SLIDES AND THEIR DOWNSTOP PLATE.

MIN. SOME --- MAX. 0.008 INCH
ALL OTHER PUNCHES SHOULD HAVE SOME CLEARANCE.

TO ADJUST

REMOVE PUNCH SLIDE GUIDE, LOOSEN DOWNSTOP PLATE MOUNTING STUDS AND POSITION THE DOWNSTOP PLATE. TIGHTEN STUDS AND REPLACE GUIDE SO THAT PUNCH SLIDES ALIGN WITH PUNCH PINS (AS GAUGED BY EYE).

NOTE: TO CHECK FOR SOME CLEARANCE PLACE UNIT IN THE STOP POSITION, TRIP FUNCTION TRIP MECHANISM AND LATCHES, THE PUNCH SLIDES SHALL MOVE FREELY TO THEIR OPERATED POSITION.


(B) PUNCH PIN PENETRATION
REQUIREMENT

LETTERS MANUALLY SELECTED, CLUTCH ENGAGED AND ROTATED UNTIL PUNCH PINS HAVE TRAVELED MAXIMUM DISTANCE INTO THE DIE PLATE, CLEARANCE BETWEEN LOWER EDGE OF PUNCH RETRACTOR BAIL AND UPPER SIDE OF GUIDE PLATE (MEASURED AT LEFT EDGE OF PUNCH PINS WHERE CLEARANCE IS LEAST). THE CODE PUNCHES SHOULD PUNCH A FULL LID WITH A MINIMUM AMOUNT OF TEAR. (REFINE ADJUSTMENT).

MIN. 0.060 INCH --- MAX. 0.075 INCH

TO ADJUST

ROTATE THE TOGGLE BAIL ECCENTRIC SHAFT WITH ITS LOCK NUT LOOSENED. KEEP THE INDENTATION IN THE ECCENTRIC SHAFT TO THE LEFT OF A VERTICAL CENTER LINE THROUGH THE SHAFT.



(C) PUNCH SLIDE GUIDE POSITION
REQUIREMENT

LETTERS SELECTED. FUNCTION CLUTCH ENGAGED AND ROTATED UNTIL THE PUNCH SLIDES JUST TOUCH THE PUNCH PINS. THE PUNCH SLIDES SHOULD ALIGN CENTRALLY WITH THEIR RESPECTIVE PUNCH PINS (GAUGED BY EYE).

TO ADJUST

POSITION THE PUNCH SLIDE GUIDE WITH ITS MOUNTING NUTS LOOSENED.

2.11 Punch Mechanism continued


(A) PUNCH PIN PENETRATION
REQUIREMENT

- (1) WITH THE LETTERS COMBINATION SELECTED FUNCTION CLUTCH ENGAGED, ROTATE MAIN SHAFT UNTIL ALL PUNCH PINS ARE INTO OR ABOVE THE TAPE APERTURE IN PUNCH BLOCK, WITH THE TP159926 GAUGE IN POSITION
MIN. 0.050 INCH
CLEARANCE BETWEEN FEED PAWL STUD AND THE GAUGE.
- (2) WITH LETTERS COMBINATION SELECTED, FUNCTION CLUTCH ENGAGED, ROTATE MAIN SHAFT UNTIL ALL PUNCH PINS HAVE CLEARED THE PUNCH BLOCK. WITH THE TP159926 GAUGE IN POSITION
MAX. 0.080 INCH
CLEARANCE BETWEEN FEED PAWL STUD AND GAUGE.

TO ADJUST

REFINE THE TOGGLE BAIL ECCENTRIC ADJUSTMENT KEEPING THE INDENT TO THE RIGHT OF A VERTICAL CENTERLINE THROUGH THE SHAFT.

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO FULLY PERFORATED TAPE MECHANISM.



(C) PUNCH SLIDE DOWNSTOP POSITION
REQUIREMENT

WITH FUNCTION CLUTCH DISENGAGED AND LATCHED. PLAY TAKEN UP TOWARD THE TOP CLEARANCE BETWEEN BOTH THE FRONT AND REAR PUNCH SLIDES AND THE DOWNSTOP PLATE
MIN. SOME --- MAX. 0.008 INCH
ALL OTHER PUNCH SLIDES SHALL HAVE SOME CLEARANCE.

(B) PUNCH SLIDE GUIDE
REQUIREMENT

THE PUNCH SLIDES SHOULD ALIGN WITH THEIR CORRESPONDING PUNCH PINS AND BE FREE OF BINDS AFTER TIGHTENING THE GUIDE MOUNTING STUDS. EACH PUNCH SLIDE SHOULD RETURN FREELY AFTER BEING PUSHED IN NOT MORE THAN 1/16 INCH.

TO ADJUST

POSITION THE GUIDE WITH ITS MOUNTING STUDS FRICTION TIGHT.

NOTE: TO CHECK FOR SOME CLEARANCE, PLACE UNIT IN STOP POSITION, TRIP FUNCTION TRIP MECHANISM AND LATCHES, THE PUNCH SLIDES SHALL MOVE FULLY TO THEIR OPERATED POSITION.

TO ADJUST

WITH UNIT IN STOP POSITION, LOOSEN THE TWO DOWNSTOP PLATE MOUNTING LOCK NUTS AND LOCATE THE DOWNSTOP PLATE TO MEET THE REQUIREMENT.

2.12 Punch Mechanism continued


RESET BAIL TRIP LEVER

REQUIREMENT

- (1) MANUALLY SELECT BLANK COMBINATION. MANUALLY ROTATE RESET BAIL TRIP LEVER. THE PUNCH SLIDE RESET BAIL SHALL TRIP BEFORE THE FUNCTION CLUTCH IS TRIPPED.
- (2) WITH FUNCTION AND SELECTOR CLUTCHES DIS-ENGAGED AND LATCHED, THE PUNCH SLIDE RESET BAIL SHALL FULLY ENGAGE THE PUNCH SLIDE LATCHING SURFACE WHEN PLAY IN PARTS IS TAKEN UP IN DIRECTION TO MAKE THE ENGAGEMENT THE LEAST.

TO ADJUST

- (1) WITH TRIP LEVER EXTENSION LOCK SCREW FRICTION TIGHT AND LETTERS' COMBINATION SELECTED, POSITION RESET BAIL AGAINST PUNCH SLIDES. TAKE UP PLAY BETWEEN RESET BAIL AND TRIP LEVER IN A COUNTER CLOCKWISE DIRECTION. POSITION TRIP LEVER BY MEANS OF ITS PRY POINT.
- (2) RECHECK REQUIREMENT (1) ABOVE AND REFINE ADJUSTMENT IF NECESSARY.



2.13 Punch Mechanism continued

LATCH LEVER CLEARANCE

REQUIREMENT (FOR BOTH TYPING AND NON-TYPING PERFORATORS)

WITH "BLANK" COMBINATION SELECTED, THE FUNCTION CLUTCH DISENGAGED AND LATCHED, CLEARANCE BETWEEN THE PUNCH SLIDE AND ITS ASSOCIATED LATCH LEVER.

MIN. 0.008 INCH



MAX. 0.020 INCH

FOR THE SLIDE HAVING THE LEAST CLEARANCE.

TO ADJUST

LOOSEN THE LOCK NUT ON THE RESET BAIL ECCENTRIC SHAFT AND POSITION THE RESET BAIL BY ROTATING THE ECCENTRIC SHAFT TO MEET THE REQUIREMENT: THE INDENT SHALL BE KEPT ABOVE THE HORIZONTAL CENTER LINE OF THE ECCENTRIC.

NOTE: ON KEYBOARD PERFORATORS NOT HAVING A "BLANK" KEY, SUBSTITUTE USE OF THE "T" KEY WHENEVER USE OF THE "BLANK" KEY IS REQUIRED.



FEED PAWL REQUIREMENT (PRELIMINARY)
 FUNCTION CLUTCH DISENGAGED, IDENTATION IN DETENT LEVER ECCENTRIC AT RIGHT ANGLE TO LEVER, DETENT ROLLER IN CONTACT WITH RATCHET WHEEL, HIGH PART OF FEED PAWL ECCENTRIC TO THE RIGHT OF ITS LOCK SCREW, THE FEED PAWL SHOULD ENGAGE THE FIRST TOOTH BELOW A HORIZONTAL CENTER LINE THROUGH THE RATCHET WHEEL WITH NO PERCEPTIBLE CLEARANCE.
TO ADJUST
 ROTATE THE FEED PAWL ECCENTRIC WITH LOCK NUT LOOSENED.

NOTE: THIS ADJUSTMENT IS RELATED TO FEED HOLE SPACING AND THE TWO ADJUSTMENTS MUST BE MADE AT THE SAME TIME.

2.14 Punch Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO CHADLESS TAPE MECHANISM.

FEED HOLE SPACING (PRELIMINARY) REQUIREMENT



THE INDENT OF DIE WHEEL ECCENTRIC STUD SHALL BE POINTING DOWNWARD. TO ADJUST POSITION DIE WHEEL ECCENTRIC STUD WITH LOCK NUT LOOSENED.

NOTE

BEFORE PROCEEDING WITH THE FOLLOWING ADJUSTMENTS, CHECK BOTH TAPE GUIDE SPRING TENSIONS.

FEED HOLE SPACING (FINAL) REQUIREMENT

- (1) WITH TAPE SHOE BLOCKED AWAY FROM THE FEED WHEEL, THE FEED PAWL AND DETENT DISENGAGED, AND TAPE REMOVED FROM THE PUNCH MECHANISM, THE FEED WHEEL SHALL ROTATE FREELY. (CHECK THROUGH 3 OR 4 ROTATIONS).
- (2) PERFORATE SIX SERIES OF (9) "BLANK" COMBINATIONS FOLLOWED BY (1) "LETTERS" COMBINATION. OPEN CHADS SO CODE HOLES ARE VISIBLE. PLACE TAPE OVER SMOOTH SIDE OF THE TP156011 TAPE GAUGE SO CIRCULAR PORTION OF THE FIRST NUMBER TWO CODE HOLE IN TAPE IS CONCENTRIC WITH THE FIRST (0.072) HOLE OF TAPE GAUGE. (SEE NOTE). THE NEXT FOUR 0.072 HOLES IN TAPE GAUGE SHALL BE VISIBLE THROUGH THE NUMBER TWO CODE HOLES IN TAPE AND CIRCULAR PORTION OF THE LAST (SIXTH) NUMBER TWO CODE HOLE IN TAPE SHALL BE ENTIRELY WITHIN THE 0.086 DIA. HOLE OF TAPE GAUGE.



NOTE: THE FIRST FIVE HOLES IN GAUGE ARE THE SAME SIZE AS CODE HOLES IN TAPE (0.072 INCH DIAMETER) BUT THE SIXTH HOLE IN GAUGE IS LARGER THAN THE FIRST FIVE (0.086 INCH DIAMETER). THIS ARRANGEMENT ALLOWS ± 0.007 INCH VARIATION IN FIVE (5) INCHES.

TO ADJUST


- (1) WITH TAPE REMOVED FROM PUNCH MECHANISM, LOOSEN DIE WHEEL ECCENTRIC STUD LOCK NUT AND ADJUST DIE WHEEL SO THAT IT JUST BINDS ON FEED WHEEL, BACK OFF ECCENTRIC SO DIE WHEEL IS JUST FREE (CHECK FREENESS THROUGH 3 OR 4 ROTATIONS). KEEP INDENT OF ECCENTRIC STUD BELOW THE HORIZONTAL CENTER LINE OF STUD.
- (2) CHECK TEN CHARACTERS PER INCH REQUIREMENT AND REFINE FEED WHEEL DIE WHEEL CLEARANCE ADJUSTMENT TO MEET THE REQUIREMENT BY MOVING INDENT OF DIE WHEEL ECCENTRIC STUD TOWARD FEED WHEEL TO DECREASE CHARACTER SPACING AND AWAY FROM FEED WHEEL TO INCREASE THE CHARACTER SPACING.

CAUTION: WITH THE TAPE REMOVED FROM THE PUNCH MECHANISM, BE SURE THE DIE WHEEL DOES NOT BIND.

- (3) WITH THE TAPE SHOE AWAY FROM THE FEED WHEEL, THE FEED PAWL AND DETENT DISENGAGED, AND THE TAPE REMOVED FROM THE PUNCH MECHANISM, THE FEED WHEEL SHALL ROTATE FREELY. FAILURE TO MEET THIS REQUIREMENT INDICATES THE DIE WHEEL ECCENTRIC HAS BEEN OVER-ADJUSTED. TO MEET THIS REQUIREMENT, REFINE THE ADJUSTMENT.

2.15 Punch Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO CHADLESS TAPE MECHANISM.




REQUIREMENT

A PIECE OF TAPE CONTAINING NINE FEED HOLES FOLLOWED BY A LETTERS COMBINATION PERFORATED ON THE PERFORATOR MUST CONFORM TO THE TP156011 TAPE GAUGE. THE LATERAL CENTERLINE THROUGH THE CODE HOLES IN THE TAPE SHOULD COINCIDE WITH A LATERAL CENTERLINE THROUGH THE HOLES IN THE GAUGE.

TO ADJUST

ROTATE THE DETENT ECCENTRIC CLOCKWISE TO MOVE THE FEED HOLES TOWARD THE HINGED EDGE OF THE CODE HOLES AND COUNTERCLOCKWISE TO MOVE THE FEED HOLES TOWARD THE TRAILING EDGE OF THE CODE HOLES. TIGHTEN THE ECCENTRIC LOCK NUT AND REFINISH THE FEED PAWL ADJUSTMENT.

RECHECK FEED PAWL ADJUSTMENT.



2.16 Punch Mechanism continued


FEED HOLE LATERAL ALIGNMENT REQUIREMENT

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO CHADLESS TAPE MECHANISM.

WITH MACHINE OPERATING UNDER POWER, OBTAIN A TAPE CONSISTING OF A SERIES OF NINE "BLANKS" FOLLOWED BY A "LETTERS" COMBINATION. OPEN CHADS SO CODE HOLES ARE VISIBLE AND PLACE TAPE OVER THE TP156011 TAPE GAUGE WITH "LETTERS" COMBINATION FEED HOLES ENGAGING FEED PINS. THE LARGE HOLES IN GAUGE ARE THE SAME DIAMETER AS THE CIRCULAR PORTION OF CODE HOLES IN TAPE. THE SMALL HOLES IN GAUGE SERVE AS A GUIDE FOR GAUGING. THE CIRCULAR PORTION OF CODE HOLES IN TAPE SHALL BE CONCENTRIC WITH HOLES IN TAPE GAUGE.


TO ADJUST

LOOSEN ADJUSTING SCREW LOCK NUT AND POSITION ADJUSTING SCREW. TO MOVE HOLES OF GAUGE AWAY FROM REFERENCE EDGE OF TAPE, MOVE FEED WHEEL TOWARDS FRONT PLATE OF PUNCH MECHANISM BY ROTATING ADJUSTING SCREW COUNTER CLOCKWISE. TO MOVE HOLES OF GAUGE TOWARD THE REFERENCE EDGE OF TAPE, MOVE FEED WHEEL TOWARD BACKPLATE OF PUNCH MECHANISM BY ROTATING ADJUSTING SCREW CLOCKWISE. TIGHTEN THE LOCK NUT. REFINE DETENT ADJUSTMENT TO ALIGN LATERAL CENTER LINES OF CODE HOLES AND FEED HOLE IF REQUIRED.



2.17 Punch Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO PERFORATOR MECHANISM FOR FULLY PERFORATED TAPE WITH INDENTATIONS OF THE FEED WHEEL FULLY PUNCHED OUT.



NOTE: BEFORE PROCEEDING WITH THE FOLLOWING ADJUSTMENT CHECK BOTH TAPE GUIDE SPRING TENSIONS

FEED HOLE SPACING

(1) REQUIREMENT

WITH A PIECE OF TAPE PERFORATED WITH SIX SERIES OF 9 BLANK CODE COMBINATIONS FOLLOWED BY A LETTERS COMBINATION PLACED OVER THE SMOOTH SIDE OF THE 156011 TAPE GAUGE SO THAT THE CIRCULAR PORTION OF THE FIRST NUMBER 2 CODE HOLE IN THE TAPE IS CONCENTRIC WITH THE FIRST HOLE OF THE TAPE GAUGE, THE NEXT FOUR HOLES IN THE TAPE GAUGE SHOULD BE VISIBLE THROUGH THE NUMBER 2 CODE HOLES IN THE TAPE AND THE CIRCULAR PORTION OF THE LAST (SIXTH) NUMBER 2 CODE HOLE IN THE TAPE SHALL BE ENTIRELY WITHIN THE 0.086 DIAMETER HOLE OF THE TAPE GAUGE.

(2) REQUIREMENT

WITH TAPE SHOE HELD AWAY FROM FEED WHEEL, FEED PAWL AND DETENT DIS-ENGAGED AND TAPE REMOVED, FEED WHEEL SHOULD ROTATE FREELY.

TO ADJUST

WITH TAPE REMOVED FROM THE PUNCH MECHANISM, LOOSEN THE ECCENTRIC LOCK NUT AND ROTATE THE DIE WHEEL ECCENTRIC SHAFT UNTIL IT BINDS AGAINST THE FEED WHEEL. BACK OFF THE ECCENTRIC UNTIL THE DIE WHEEL IS JUST FREE. KEEP THE INDENT OF THE ECCENTRIC BELOW THE HORIZONTAL CENTERLINE OF THE STUD. REFINE ADJUSTMENT FOR REQUIREMENT (1), IF NECESSARY, BY MOVING THE DIE WHEEL TOWARD THE FEED WHEEL TO DECREASE THE CHARACTER SPACING AND AWAY FROM THE FEED WHEEL TO INCREASE THE CHARACTER SPACING.

2.18 Punch Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO PERFORATOR MECHANISM FOR FULLY PERFORATED TAPE WITH INDENTATIONS OF THE FEED WHEEL FULLY PUNCHED OUT.

FEED WHEEL INDENTATION ALIGNMENT


(1) REQUIREMENT

WHEN A PIECE OF TAPE IS PERFORATED WITH A SERIES OF BLANK CODE COMBINATIONS THE INDENTATIONS OF THE FEED WHEEL SHALL BE FULLY PUNCHED OUT.

TO ADJUST

RIGHT OR LEFT, ROTATE THE DETENT LEVER ECCENTRIC STUD CLOCKWISE TO MOVE THE FEED PERFORATION TOWARD THE LEADING EDGE OF THE CODE HOLES, AND COUNTER CLOCKWISE TO MOVE THE FEED WHEEL PERFORATIONS TOWARD THE TRAILING EDGE OF THE CODE HOLES. REFINE THE FEED PAWL ADJUSTMENT.

FRONT TO REAR, LOOSEN THE LOCK NUT ON THE ADJUSTING SCREW AND TURN THE SCREW CLOCKWISE TO MOVE TAPE TOWARD REFERENCE EDGE (REAR), AND COUNTER CLOCKWISE TO MOVE THE TAPE AWAY FROM REFERENCE EDGE (FRONT).



2.19 Punch Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO PERFORATOR MECHANISM FOR FULLY PERFORATED TAPE WITH INDENTATIONS OF THE FEED WHEEL BETWEEN THE FEED HOLES.

NOTE: BEFORE PROCEEDING WITH THE FOLLOWING ADJUSTMENTS, CHECK BOTH TAPE GUIDE SPRING TENSIONS.

FEED HOLE SPACING (FINAL)
REQUIREMENT

- (1) WITH TAPE SHOE BLOCKED AWAY FROM THE FEED WHEEL, THE FEED PAWL AND DETENT DISENGAGED, AND TAPE REMOVED FROM THE PUNCH MECHANISM, THE FEED WHEEL SHALL ROTATE FREELY. (CHECK THROUGH 3 OR 4 ROTATIONS).
- (2) PERFORATE SIX SERIES OF (9) "BLANK" COMBINATIONS FOLLOWED BY (1) "LETTERS" COMBINATION. PLACE TAPE OVER SMOOTH SIDE OF THE TP156011 TAPE GAUGE SO CIRCULAR PORTION OF THE FIRST NUMBER TWO CODE HOLE IN TAPE IS CONCENTRIC WITH THE FIRST (0.072) HOLE OF TAPE GAUGE. (SEE NOTE). THE NEXT FOUR 0.072 HOLES IN TAPE GAUGE SHALL BE VISIBLE THROUGH THE NUMBER TWO CODE HOLES IN TAPE AND CIRCULAR PORTION OF THE LAST (SIXTH) NUMBER TWO CODE HOLE IN TAPE SHALL BE ENTIRELY WITHIN THE 0.086 DIA. HOLE OF TAPE GAUGE.

NOTE:

THE FIRST FIVE HOLES IN GAUGE ARE THE SAME SIZE AS CODE HOLES IN TAPE (0.072 INCH DIAMETER) BUT THE SIXTH HOLE IN GAUGE IS LARGER THAN THE FIRST FIVE (0.086 INCH DIAMETER). THIS ARRANGEMENT ALLOWS ± 0.007 INCH VARIATION IN FIVE (5) INCHES.


TO ADJUST

- (1) WITH TAPE REMOVED FROM PUNCH MECHANISM, LOOSEN DIE WHEEL ECCENTRIC STUD LOCK NUT AND ADJUST DIE WHEEL SO THAT IT JUST BINDS ON FEED WHEEL, BACK OFF ECCENTRIC SO DIE WHEEL IS JUST FREE (CHECK FREENESS THROUGH 3 OR 4 ROTATIONS). KEEP INDENT OFF ECCENTRIC STUD BELOW THE HORIZONTAL CENTER LINE OF STUD.
- (2) CHECK TEN CHARACTERS PER INCH REQUIREMENT AND REFINE FEED WHEEL DIE WHEEL CLEARANCE ADJUSTMENT TO MEET THE REQUIREMENT BY MOVING INDENT OF DIE WHEEL ECCENTRIC STUD TOWARD FEED WHEEL TO DECREASE CHARACTER SPACING AND AWAY FROM FEED WHEEL TO INCREASE THE CHARACTER SPACING.

CAUTION: WITH THE TAPE REMOVED FROM THE PUNCH MECHANISM, BE SURE THE DIE WHEEL DOES NOT BIND.

- (3) WITH THE TAPE SHOE AWAY FROM THE FEED WHEEL, THE FEED PAWL AND DETENT DISENGAGED, AND THE TAPE REMOVED FROM THE PUNCH MECHANISM, THE FEED WHEEL SHALL ROTATE FREELY.

FAILURE TO MEET THIS REQUIREMENT INDICATES THE DIE WHEEL ECCENTRIC HAS BEEN OVER-ADJUSTED. TO MEET THIS REQUIREMENT, REFINES THE ADJUSTMENT.




2.20 Punch Mechanism continued

DETENT (FOR FULLY PERFORATED TAPE WITH INDENTATION OF FEED WHEEL BETWEEN THE FEED HOLES)
REQUIREMENT

WITH THE UNIT OPERATING UNDER POWER, THE INDENTATIONS OF THE FEED WHEEL SHALL BE CENTRALLY LOCATED BETWEEN TWO FULLY PERFORATED FEED HOLES, AS GAUGED BY EYE.

TO ADJUST

LOOSEN THE DETENT LEVER ECCENTRIC STUD LOCK NUT AND TURN THE ECCENTRIC STUD CLOCKWISE TO MOVE THE INDENTATION TOWARD THE LEADING EDGE OF THE FEED HOLE AND COUNTERCLOCKWISE TO MOVE THE INDENTATION TOWARD THE TRAILING EDGE. TIGHTEN THE LOCK NUT AND RE-CHECK THE FEED PAWL ADJUSTMENT.



NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO PERFORATOR MECHANISM FOR FULLY PERFORATED TAPE WITH INDENTATIONS OF THE FEED WHEEL BETWEEN THE FEED HOLES.




FEED HOLE LATERAL ALIGNMENT
REQUIREMENT

WITH THE UNIT OPERATING UNDER POWER, THE INDENTATIONS OF THE FEED WHEEL SHOULD BE ON A CENTERLINE BETWEEN THE FULLY PERFORATED FEED HOLES, AS GAUGED BY EYE.

TO ADJUST

WITH THE ADJUSTING SCREW LOCK NUT LOOSE TURN THE ADJUSTING SCREW CLOCKWISE TO MOVE THE INDENTATION TOWARD THE REAR AND COUNTERCLOCKWISE TO MOVE THE INDENTATIONS TOWARD THE FRONT.

2.21 Punch Mechanism continued



2.22 Punch Mechanism continued

(B) TAPE GUIDE ASSEMBLY SPRING
REQUIREMENT


THE TAPE GUIDE ASSEMBLY SHOULD BE FREE TO RETURN TO REST AGAINST THE TAPE GUIDE BLOCK AFTER A MIN. 16 OZS.

IS USED TO PULL THE TAPE GUIDE ASSEMBLY AWAY FROM THE BLOCK.

TO ADJUST

REPLACE SPRING IF REQUIREMENT IS NOT MET.

IF THE TAPE GUIDE ASSEMBLY IS NOT FREE TO RETURN, REPOSITION THE TAPE GUIDE ASSEMBLY MOUNTING POST TO FREE THE TAPE GUIDE ASSEMBLY.



(A) TAPE GUIDE SPRING (TAPE CHUTE)
REQUIREMENT

CLUTCH DISENGAGED AND TAPE THREADED THROUGH THE PUNCH ASSEMBLY, IT SHOULD REQUIRE

MIN. 1-1/4 OZS.


MAX. 2-1/4 OZS.

TO JUST MOVE THE SPRING AWAY FROM THE TAPE.

TO ADJUST

BEND THE SPRING.

NOTE: IN ORDER TO CHECK THIS SPRING TENSION ON UNITS EQUIPPED WITH BACKSPACE MECHANISM, IT IS NECESSARY TO REMOVE SEVERAL PARTS. IT SHOULD NOT BE CHECKED UNLESS THERE IS REASON TO BELIEVE THAT REQUIREMENTS CANNOT BE MET.



(C) TAPE GUIDE SPRING PUNCH BLOCK (FOR CHADLESS TAPE MECHANISM)

(1) REQUIREMENT

WITH THE TAPE REMOVED FROM THE PUNCH BLOCK THE TAPE GUIDE SPRING SHOULD REST AGAINST THE CLEARANCE SLOT IN THE BLOCK IN A SYMMETRICAL MANNER.

(2) REQUIREMENT


WITH TAPE IN THE PUNCH BLOCK AND THE PERFORATOR OPERATING UNDER POWER, THE SPRING SHOULD NOT DISTORT THE EDGE OF THE TAPE.

TO ADJUST

BEND THE SPRING AND POSITION IT WITH ITS MOUNTING SCREW LOOSENED.



TAPE GUIDE SPRING

PUNCH BLOCK



2.23 Punch Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO FULLY PERFORATED TAPE MECHANISM.




2.24 Punch Mechanism continued

TAPE SHOE TORSION SPRING

REQUIREMENT

MIN. 13 OZS. ---- MAX. 18 OZS.
TO MOVE TAPE SHOE FROM FEED WHEEL



TAPE GUIDE

TO CHECK

ROTATE FEED WHEEL UNTIL OIL HOLE IS UPWARD.
CENTER TAPE SHOE AND TAPE GUIDE. HOLD TAPE
GUIDE DOWNWARD.

REQUIREMENT

CLEARANCE BETWEEN ADJUSTING PLATE AND
BACKSTOP POST

MIN. 0.002 INCH
MAX. 0.008 INCH


TO ADJUST

POSITION ADJUSTING PLATE WITH ITS CLAMP
SCREW LOOSENED.


TAPE DEPRESSOR SLIDE SPRING

REQUIREMENT

ROCKER BAIL IN ITS EXTREME LEFT POSITION
MIN. 1 1/2 OZS. -- MAX. 2 1/2 OZS.
TO START DEPRESSOR SLIDE MOVING.



2.25 Punch Mechanism continued



TAPE GUIDE (EARLY DESIGN)
REQUIREMENT

WITH TAPE GUIDE UNDER AND IN CONTACT WITH V SHAPED PROJECTION OF DIE PLATE*
MIN. 0.008 INCH -- MAX. 0.015 INCH
CLEARANCE BETWEEN GUIDE AND TAPE PLATFORM.

TO ADJUST



WITH MOUNTING SCREW FRICTION TIGHT, PLACE 0.010 INCH FLAT GAUGE BETWEEN GUIDE AND TAPE PLATFORM. PRESS GUIDE DOWN AND TO LEFT. TIGHTEN MOUNTING SCREW WHILE HOLDING FEED WHEEL ADJUSTING SCREW STATIONARY BY MEANS OF AN ALLEN WRENCH.

*GUIDE IS CONSIDERED "IN CONTACT" WITH PROJECTION WHEN 0.0015 INCH GAUGE CANNOT BE INSERTED BETWEEN THEM.

TAPE GUIDE SPRING (ON UNITS NOT EQUIPPED WITH TAPE GUIDE ADJUSTING PLATE)

REQUIREMENT

MIN. 8 OZS. TO START TAPE GUIDE BAIL MOVING UPWARD.



TAPE GUIDE (LATEST DESIGN)
REQUIREMENT

CLEARANCE UNDER THE TAPE GUIDE.

MIN. 0.008 INCH

MAX. 0.015 INCH

TO ADJUST

WITH MOUNTING SCREW FRICTION TIGHT, POSITION THE TAPE GUIDE, KEEPING THE GUIDE AGAINST THE FRONT PLATE OF THE PUNCH.

2.26 Punch Mechanism continued

(A)


FEED PAWL SPRING

REQUIREMENT

FUNCTION CLUTCH DISENGAGED AND LATCHED.
DETENT SPRING UNHOOKED FROM TOGGLE BAIL

MIN. 3 OZS.
MAX. 4-1/2 OZS.

TO START THE DETENT LEVER MOVING.



(B)


DETENT LEVER SPRING

REQUIREMENT


FUNCTION CLUTCH DISENGAGED AND LATCHED.
FEED PAWL SPRING UNHOOKED.

MIN. 7 OZS.
MAX. 10 OZS.

TO START THE DETENT LEVER MOVING.



2.27 Function Mechanism continued



RELEASE DOWNSTOP BRACKET
REQUIREMENT

WITH FUNCTION CLUTCH TRIPPED, ROTATE SHAFT UNTIL CLEARANCE BETWEEN FUNCTION CLUTCH DISK STOP LUG AND CLUTCH STOP LEVER IS AT A MINIMUM. RELEASE RESTING AGAINST DOWNSTOP BRACKET. CLEARANCE BETWEEN FUNCTION CLUTCH DISK STOP LUG AND STOP LEVER:

MIN. 0.002 INCH---MAX. 0.045 INCH

TO ADJUST

REMOVE TAPE GUARD. WITH DOWNSTOP BRACKET MOUNTING SCREWS FRICTION TIGHT POSITION BRACKET. RECHECK FOR SOME CLEARANCE BETWEEN TRIP LEVER EXTENSION AND LEFT END OF SLOT IN RELEASE LEVER DOWNSTOP BRACKET.

NOTE: ON NON-TYPING PERFORATORS WITH 2-STOP FUNCTION CLUTCH, GAUGE AT STOP HAVING LEAST CLEARANCE.

2.28 Typing Mechanism

PUSH BAR OPERATING BLADE (PRELIMINARY)

TO CHECK

MANUALLY SELECT LETTERS CODE COMBINATION (12345). ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS. HOLD NO. 2 AND 3 BELL CRANKS AGAINST STOP POST.


REQUIREMENT

OPERATING BLADE PARALLEL TO (NOT NECESSARILY FLUSH) TO TOP OF NO. 2 AND 3 PUSH BAR LATCHING SURFACES.

TO ADJUST

WITH ITS MOUNTING SCREWS FRICTION TIGHT, PRY TRANSFER MOUNTING BRACKET ALL THE WAY TO THE RIGHT.

ADD OR REMOVE SHIMS UNDER THE REAR LEG OF THE OPERATING BLADE. PLACE EXTRA SHIMS ON REAR MOUNTING SCREW BETWEEN BLADE AND FLAT WASHER.



BELL CRANK SPRINGS (5)

TO CHECK

SELECT LETTERS CODE COMBINATION (12345). ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS.

REQUIREMENT

MIN. 1 OZ. ---MAX. 3 OZS.

TO START PUSH BAR MOVING

NOTE:

CHECK ALL FIVE SPRINGS.

2.29 Typing Mechanism continued

PUSH BAR OPERATING BLADE (FINAL)

(1) TO CHECK

MANUALLY SELECT LETTERS CODE COMBINATION (12345). ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS. MANUALLY SEAT PUSH BARS IN DETENTED POSITION. IN BAR WHICH IS NEAREST LEFT EDGE OF BLADE, TAKE UP PLAY TO LEFT AND REAR, AND THEN RELEASE.

REQUIREMENT

CLEARANCE BETWEEN BAR AND LEFT EDGE OF BLADE:

MIN. 0.015 INCH --- MAX. 0.030 INCH

(2) REQUIREMENT

SOME CLEARANCE BETWEEN RIGHT EDGE OF BLADE AND PUSH BARS WHEN PLAY IN BARS HAS BEEN TAKEN UP TO RIGHT AND RELEASED.

(3) REQUIREMENT


WITH UNIT IN STOP POSITION, SOME CLEARANCE BETWEEN RIGHT EDGE OF BLADE AND BARS WHEN PLAY IN BARS HAS BEEN TAKEN UP TO RIGHT AND RELEASED.

TO ADJUST


WITH MOUNTING SCREWS LOOSENED, POSITION OPERATING BLADE IN ELONGATED HOLES.

NOTE:

IT MAY BE NECESSARY TO REFINE THIS ADJUSTMENT AFTER ROCKER BAIL PILOT STUD ADJUSTMENT.



2.30 Typing Mechanism continued



(A) ROCKER BAIL PILOT STUD REQUIREMENT

SELECT BLANK COMBINATION AND THE TRIP FUNCTION CLUTCH. POSITION ROCKER BAIL THROUGH A COMPLETE CYCLE, TAKING UP PLAY BETWEEN ROCKER BAIL AND FUNCTION BOX REAR PLATE FOR MINIMUM CLEARANCE.

REQUIREMENT

CLEARANCE BETWEEN FUNCTION BOX REAR PLATE AND REAR EDGE OF PUSH BAR OPERATING BLADE.

MIN. 0.005 INCH

MAX. 0.020 INCH

AT POINT IN THE CYCLE WHERE CLEARANCE IS MINIMUM.


TO ADJUST POSITION ROCKER BAIL PILOT STUD IN ELONGATED HOLE WITH LOCK NUT LOOSENEED.

2.31 Function Mechanism continued

(B) FUNCTION CLUTCH LATCH LEVER SPRING REQUIREMENT

WITH FUNCTION CLUTCH TURNED TO STOP POSITION AND LATCH LEVER UNLATCHED:

MIN. 12 OZS. --- MAX. 15 OZS. TO START LATCH LEVER MOVING.




2.32 Typing Mechanism continued

FUNCTION BOX
REQUIREMENT

MANUALLY SELECT LETTERS CODE COMBINATION (12345). ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS, AND PUNCH SLIDES ARE DISENGAGED FROM LATCHES. THE TOP OF THE OPERATING BLADE SHALL BE:

FLUSH --- MAX. 0.020 INCH




BELOW THE TOPS OF THE NO. 2 AND 3 PUSH BARS. TAKE UP PLAY IN PUSHBARS IN A DOWNWARD DIRECTION THEN RELEASE.

NOTE: WHEN UNIT IS MOUNTED AS PART OF THE KEYBOARD PERFORATOR TRANSMITTER, IT MAY BE NECESSARY TO REFINE THE ADJUSTMENT WITHIN ITS LIMITS TO INCREASE OPERATING MARGINS OF THE UNIT.

TO ADJUST


WITH THREE MOUNTING SCREWS IN REAR PLATE AND ONE MOUNTING SCREW IN FRONT PLATE LOOSENED, POSITION FUNCTION BOX BY MEANS OF PRY POINT. CHECK POSITION OF BELL CRANK SPRING BRACKET.



NOTE:

ON UNITS EQUIPPED WITH TWO-PIECE TRIP BRACKET, SET ABOVE ADJUSTMENT IN CENTER OF ITS RANGE AND TIGHTEN SCREWS. LOOSEN TWO SCREWS WHICH MOUNT GUIDE TO BRACKET AND POSITION GUIDE TO MEET ABOVE REQUIREMENT.

2.33 Typing Mechanism continued



TRANSFER MOUNTING BRACKET
TO CHECK

MANUALLY SELECT BLANK CODE COMBINATION. ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS.

REQUIREMENT

WITH PUNCH SLIDES LATCHED, CLEARANCE BETWEEN BELL CRANK AND STOP POST:

MA. 0.018 INCH*


AT BELL CRANK WHERE CLEARANCE IS MAXIMUM, WHEN BELL CRANK WITH MINIMUM CLEARANCE IS TOUCHING POST.

TO ADJUST

WITH MOUNTING SCREWS FRICTION TIGHT, PLY TRANSFER MOUNTING BRACKET TO LEFT UNTIL CLOSEST BELL CRANK TOUCHES POST. TIGHTEN MOUNTING SCREWS AND CHECK REQUIREMENT.

CAUTION: BELL CRANK THAT YIELDS MOST SHOULD NOT YIELD MORE THAN 0.007 INCH MEASURED AT POST.

*NOTE: REMOVAL OF FUNCTION BLADES WILL FACILITATE MEASURING CLEARANCE.



2.34 Typing Mechanism continued

(A) LETTERS AND FIGURES YIELD ARMS

(1) TO CHECK

TRIP FUNCTION CLUTCH AND ROTATE MAIN SHAFT UNTIL ROCKER BAIL IS TO EXTREME LEFT. MANUALLY PLACE ARM ASSEMBLIES IN LETTERS POSITION. HOLD LETTERS-FIGURES BELL CRANK AGAINST LEFT EDGE OF STOP POST.

REQUIREMENT

MIN. SOME-----MAX. 0.006 INCH*
CLEARANCE BETWEEN BELL CRANK AND LETTERS EXTENSION ARM.

(CONTINUED ON FOLLOWING PAGE)

(B) FIGURES ARM ASSEMBLY SPRING

REQUIREMENT

WITH ARM ASSEMBLIES IN LETTERS POSITION:


MIN. 1-1/2 OZS.-----MAX. 3-1/2 OZS.
TO PULL SPRING TO INSTALLED LENGTH.

(C) FIGURES EXTENSION ARM SPRING

REQUIREMENT

WITH ARM ASSEMBLIES IN LETTERS POSITION AND LETTERS EXTENSION ARM MANUALLY HELD IN POSITION.

MIN. 5 OZS.-----MAX. 8 OZS.
TO PULL SPRING TO INSTALLED LENGTH.



*NOTE
REMOVAL OF FUNCTION BLADES
WILL FACILITATE MEASURING CLEARANCE.


2.35 Typing Mechanism continued

(B) LETTERS ARM ASSEMBLY SPRING

REQUIREMENT
WITH ARM ASSEMBLIES IN FIGURES POSITION:
MIN. 1-1/2 OZS. ----MAX. 3-1/2 OZS.
TO PULL SPRING TO INSTALLED LENGTH.

(A) LETTERS AND FIGURES YIELD ARMS
(CONTINUED FROM PRECEDING PAGE)

(2) TO CHECK
MANUALLY PLACE ARM ASSEMBLIES IN FIGURES POSITION.
REQUIREMENT
MIN. SOME ----MAX. 0.006 INCH*
CLEARANCE BETWEEN BELL CRANK AND FIGURES EXTENSION ARM.




(C) LETTERS EXTENSION ARM SPRING

REQUIREMENT
WITH ARM ASSEMBLIES IN FIGURES POSITION AND LETTERS EXTENSION ARM MANUALLY HELD IN POSITION
MIN. 5 OZS. ----MAX. 8 OZS.
TO PULL SPRING TO INSTALLED LENGTH.

TO ADJUST
LOOSEN CLAMP SCREWS IN BOTH LETTERS AND FIGURES YIELD ARMS. PLACE ARM ASSEMBLIES IN LETTERS POSITION HOLD LETTERS-FIGURES BELL CRANK AGAINST LEFT SIDE OF STOP POST, AND BY MEANS OF PRY POINT, POSITION LETTERS YIELD ARM TO MEET CLEARANCE REQUIREMENT UNDER (A)(1) ON PREVIOUS PAGE. TIGHTEN LETTERS YIELD ARM CLAMP SCREW. PLACE ARM ASSEMBLIES IN FIGURES POSITION. HOLD LETTERS-FIGURES BELL CRANK AGAINST RIGHT SIDE OF STOP POST, AND BY MEANS OF PRY POINT POSITION FIGURES YIELD ARM TO MEET REQUIREMENT UNDER (2) ABOVE. TIGHTEN FIGURES YIELD ARM CLAMP SCREW. CAUTION: ARM ASSEMBLIES MAY CHANGE POSITION DURING ADJUSTMENT. AS TIGHTENING OF SCREWS MAY AFFECT ADJUSTMENT, RECHECK REQUIREMENTS.

*NOTE: REMOVAL OF FUNCTION BLADES WILL FACILITATE MEASURING CLEARANCE.

2.36 Typing Mechanism continued



(A) LIFTER ARM TO CHECK

TRIP FUNCTION CLUTCH. MOVE ROCKER BAIL TO EXTREME LEFT POSITION AND OBSERVE TRAVEL OF LIFTER ROLLER ON RIGHT DWELL SURFACE. MOVE ROCKER BAIL TO EXTREME RIGHT POSITION AND OBSERVE TRAVEL OF ROLLER ON LEFT DWELL SURFACE.

REQUIREMENT

APPROXIMATELY EQUAL TRAVEL ON EACH DWELL SURFACE.

TO ADJUST*

LOOSEN LOCK PLATE SCREW UNTIL FRICTION TIGHT. WITH ECCENTRIC SCREW LOCK NUT FRICTION TIGHT, POSITION LIFTER ARM ON LIFTER. TIGHTEN LOCK PLATE SCREW. DO NOT TIGHTEN LOCK NUT.

*NOTE: REMOVE TIMING CONTACTS IF UNIT IS SO EQUIPPED.

(B) LIFTER ARM ECCENTRIC SCREW

REQUIREMENT

WITH FUNCTION CLUTCH DISENGAGED:

(1) CLEARANCE BETWEEN CLOSEST PROJECTION OF BELL CRANKS AND ASSOCIATED LETTERS OR FIGURES FUNCTION BLADE PROJECTION:


MIN. 0.008 INCH--- MAX. 0.026 INCH

(2) MIN. 0.005 INCH CLEARANCE

FOR FUNCTION BLADES OTHER THAN LETTERS AND FIGURES IF UNIT IS SO EQUIPPED.

TO ADJUST

POSITION LIFTER ARM ECCENTRIC SCREW WITH LOCK NUT LOOSENED.




2.37 Typing Mechanism continued

(A) LOCK LEVER

REQUIREMENT

(1) WITH LETTERS CODE COMBINATION (12345) SELECTED AND ROCKER BAIL TO EXTREME LEFT, TOGGLE LINKAGE SHOULD MOVE THROUGH POINT WHERE TOGGLE LINK AND LOCK LEVER ARE IN STRAIGHT LINE WITHOUT RAISING LIFTER.

(2) WITH TOGGLE LINK AND LOCK LEVER IN STRAIGHT LINE, CLEARANCE BETWEEN TOGGLE LINK AND LIFTER PIN:
MIN. SOME --- MAX. 0.015 INCH.



TO ADJUST

POSITION LOCK LEVER ON LOCK ARM ASSEMBLY WITH CLAMP SCREW FRICTION TIGHT.


NOTE:

TO AVOID INTERFERENCE WITH LOCK LEVER, IT MAY BE NECESSARY TO MOVE HIGH PART OF CORRECTING DRIVE LINK ECCENTRIC BUSHING ABOVE HORIZONTAL CENTER LINE.

(B) NO. 5 PULSE BEAM SPRING

REQUIREMENT

MIN. 10 OZS. --- MAX. 15 OZS.
TO PULL SPRING TO LENGTH OF 7/16 INCH.



2.38 Typing Mechanism continued


LOCK LEVER TRIP POST

REQUIREMENT


AS ROCKER BAIL APPROACHES EXTREME RIGHT POSITION, LOCK LEVER TOGGLE LINKAGE SHOULD BREAK AND LIFTER ROLLER SHOULD DROP ONTO RIGHT DWELL SURFACE.

TO ADJUST


BY MEANS OF PRY POINTS, POSITION LOCK LEVER TRIP POST WITH CLAMP SCREW LOOSENED.



2.39 Typing Mechanism continued



2. 40 Typing Mechanism continued




OSCILLATING BAIL PIVOT
REQUIREMENT

WITH "BLANK" COMBINATION SELECTED, ROTATE MAIN SHAFT, TAKING UP AXIAL PLAY IN TYPE WHEEL SHAFT TOWARD FRONT OF UNIT, THE AXIAL CORRECTOR ROLLER SHALL ENTER THE FIRST NOTCH OF THE SECTOR CENTRALLY.

TO ADJUST

LOOSEN OSCILLATING BAIL ADJUSTING SCREW. SELECT "BLANK" COMBINATION. POSITION OSCILLATING BAIL BY MEANS OF ITS ELONGATED MOUNTING HOLE SO CORRECTOR ROLLER ENTERS FIRST NOTCH OF SECTOR WHEN ROCKER BAIL MOVES TO ITS EXTREME LEFT POSITION. HOLD CORRECTOR ROLLER FIRMLY IN FIRST NOTCH AND TAKE UP PLAY IN OSCILLATING BAIL LINKAGE BY APPLYING A FORCE TO OSCILLATING BAIL TOWARD REAR OF UNIT. TIGHTEN THE OSCILLATING BAIL ADJUSTING SCREW.

2. 41 Typing Mechanism continued



(A) AXIAL SECTOR ALIGNMENT
REQUIREMENT

(1) TEETH OF AXIAL SECTOR AND AXIAL OUTPUT RACK SHOULD ENGAGE BY THEIR FULL THICKNESS.

(2) GUIDE ROLLER FREE TO ROTATE.
TO ADJUST

LOOSEN LOCK NUT. DISENGAGE RACK. REMOVE RETAINING RING AND GUIDE ROLLER. ADD OR REMOVE SHIMS. PLACE EXTRA SHIMS ON TOP OF SHIM USED TO RETAIN FELT WASHER.


NOTE: ON UNITS WITH LARGER 0.594 INCH DIAMETER ROLLER, NO ADJUSTMENT IS NECESSARY.

(B) ECCENTRIC SHAFT
DETENT LEVER SPRINGS

MIN. 7 OZS. ---MAX. 10 OZS.
TO START DETENT LEVER MOVING.



NOTE:

CHECK ALL SIX SPRINGS. THERE ARE TWO ON THE AXIAL POSITIONING MECHANISM AND FOUR ON THE ROTARY POSITIONING MECHANISM.




(TOP VIEW OF SPRINGS ON AXIAL POSITIONING MECHANISM)

2.42 Typing Mechanism continued



2. 43 Typing Mechanism continued




2.44 Typing Mechanism continued

CORRECTOR DRIVE LINK (YIELDING)
EXTENSION SPRING TENSION

REQUIREMENT

WITH ALL SPACING CODE COMBINATION SELECTED, THE FUNCTION CLUTCH TRIPPED, AND THE ROCKER BAIL IN ITS EXTREME LEFT POSITION, PLACE A 32 OZS. SPRING HOOK ON THE END OF THE CORRECTOR AXIAL PLATE. IT SHOULD TAKE MIN. 16 OZS. ---MAX. 32 OZS. TO MOVE THE ROLLER FROM THE NOTCH IN THE SECTOR.



AXIAL CORRECTOR (YIELDING)

REQUIREMENT

WITH ALL SPACING CODE COMBINATION SELECTED, FUNCTION CLUTCH TRIPPED AND ROCKER BAIL IN ITS EXTREME LEFT POSITION, THE AXIAL CORRECTOR ROLLER SHOULD SEAT IN THE FIRST SECTOR NOTCH AND THERE SHOULD BE MIN. 0.005 INCH BETWEEN THE ENDS OF THE SLOT AND THE SPRING POST. CHECK BOTH SIDES AND CHECK SEATING IN FOURTH NOTCH (LETTERS SELECTION). TURN THE TRU ARC FASTENING THE DRIVE LINK EXTENSION TO THE CORRECTOR PLATE TO CHECK THE MINIMUM REQUIREMENT.

TO ADJUST

LOOSEN TWO DRIVE LINK ADJUSTING SCREWS. POSITION DRIVE LINK TO MEET THE REQUIREMENT AND RETIGHTEN THE SCREWS.

2.45 Typing Mechanism continued

ROTARY CORRECTING LEVER

(1) TO CHECK

LOOSEN CORRECTING CLAMP ADJUSTING SCREW. WITH UNIT IN FIGURES CONDITION, SELECT NO. 9 CODE COMBINATION (---45). TRIP FUNCTION CLUTCH AND POSITION ROCKER BAIL TO EXTREME LEFT. MANUALLY SEAT ROTARY CORRECTING LEVER IN TYPE WHEEL RACK.

REQUIREMENT

SECOND TOOTH FROM TOP OF RACK SEATED BETWEEN LOBES OF CORRECTING LEVER.

TO ADJUST

LOOSEN ECCENTRIC BUSHING LOCK NUT. WITH CLAMP ADJUSTING SCREW LOOSENED AND CORRECTING LEVER PIVOT TO RIGHT OF CENTER LINE, POSITION CORRECTING LEVER. TIGHTEN BUSHING LOCK NUT. DO NOT TIGHTEN CLAMP ADJUSTING SCREW AT THIS TIME.


(2) TO CHECK

IN A MANNER SIMILAR TO THAT DESCRIBED ABOVE CHECK ENGAGEMENT OF FIFTH TOOTH (--34- CODE COMBINATION SELECTED IN FIGURES CONDITION), NINTH TOOTH (---4- CODE COMBINATION SELECTED IN LETTERS CONDITION) AND SIXTEENTH TOOTH (--3-5 CODE COMBINATION SELECTED IN LETTERS CONDITION).


TO ADJUST

REFINE ADJUSTMENT UNDER (1) ABOVE.

ADJUSTMENT CONTINUED ON FOLLOWING PAGE.



2.46 Typing Mechanism continued




ROTARY CORRECTING LEVER - ADJUSTMENT CONTINUED FROM PRECEDING PAGE.

(3) TO CHECK
 WITH UNIT IN LETTERS CONDITION, SELECT LETTERS CODE COMBINATION (12345). POSITION ROCKER BAIL TO EXTREME LEFT. MANUALLY SEAT CORRECTING LEVER IN RACK.
 REQUIREMENT
 A. LOBES OF ROTARY CORRECTING LEVER FIRMLY SEATED IN TYPEWHEEL RACK.
 B. END PLAY BETWEEN CORRECTING CLAMP AND ECCENTRIC BUSHING:
 MIN. SOME----MAX. 0.006 INCH

TO ADJUST
 WITH CORRECTING CLAMP ADJUSTING SCREW LOOSENED, TRIP FUNCTION CLUTCH AND ROTATE MAIN SHAFT UNTIL ROLLER ON AXIAL CORRECTING PLATE APPROACHES SEATED POSITION IN NOTCH OF AXIAL SECTOR. WHEN CLEARANCE BETWEEN ROLLER AND SECTOR IS
 MIN. SOME----MAX. 0.005 INCH
 POSITION CORRECTING LEVER FINGER-TIGHT AGAINST RACK. TIGHTEN CORRECTING CLAMP ADJUSTING SCREW.


2. 47 Typing Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO CHADLESS TAPE MECHANISM.



2.48 Typing Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO FULLY PERFORATED TAPE MECHANISM.



2.49 Typing Mechanism continued


PRINTING TRIP LINK
TO CHECK

TRIP FUNCTION CLUTCH AND POSITION ROCKER BAIL TO EXTREME LEFT. MANUALLY LIFT ACCELERATOR SO THAT LATCHING SURFACES OF PRINTING LATCH AND ACCELERATOR ARE EVEN.
REQUIREMENT

MIN. SOME --- MAX. 0.015 INCH
CLEARANCE BETWEEN ACCELERATOR AND LATCH.


TO ADJUST

WITH LOCK NUT LOOSENED, POSITION PRINTING TRIP LINK BY MEANS OF ECCENTRIC MOUNTING SCREW. KEEP HIGH PART OF SCREW TO LEFT OF CENTER LINE.



2.50 Typing Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO CHADLESS TAPE MECHANISM.



(A)
TYPEWHEEL
TO CHECK

SELECT "M" CODE COMBINATION (--345). PLACE ROCKER BAIL TO EXTREME LEFT. CORRECTING LEVER SHOULD BE FIRMLY SEATED IN TYPEWHEEL RACK.

REQUIREMENT

TYPEWHEEL ALIGNED SO THAT FULL CHARACTER IS PRINTED UNIFORMLY AND $6 \pm 1/4$ CODE HOLE SPACES BEHIND ITS PERFORATED CODE HOLES.

TO ADJUST

POSITION TYPEWHEEL WITH LOCK NUT LOOSENED. CHECK PRINTING BY MANUALLY LIFTING ACCELERATOR TO LATCHED POSITION AND RELEASING IT.

NOTE:


FOR BEST RESULTS IT MAY BE NECESSARY TO MAKE PRINT HAMMER ADJUSTMENT (BELOW) AND THEN REFINE THIS ADJUSTMENT.

(B)
PRINT HAMMER
REQUIREMENT

WHEN OPERATING UNDER POWER, PRINT HAMMER AND TYPEWHEEL ALIGNED SO AS TO OBTAIN BEST QUALITY OF PRINTING.

TO ADJUST

POSITION PRINT HAMMER SHAFT WITH LOCK NUT LOOSENED.



NOTE:

IT MAY BE NECESSARY TO REMAKE TYPEWHEEL ADJUSTMENT (ABOVE) AND THEN REFINE THIS ADJUSTMENT.

2.51 Typing Mechanism continued

NOTE: THE ADJUSTMENTS ON THIS PAGE APPLY ONLY TO FULLY PERFORATED TAPE MECHANISM.

PRINT HAMMER (PRELIMINARY)


REQUIREMENT

POSITION PRINT HAMMER

MIN. 0.030 INCH --- MAX. 0.040 INCH FROM THE PIN POINTS ON THE FEED WHEEL.

TO ADJUST

WITH THE PRINT HAMMER SHAFT LOCK NUT LOOSE POSITION THE PRINT HAMMER BY TURNING THE SHAFT CLOCKWISE TO MOVE PRINT HAMMER TOWARD THE FEED WHEEL AND COUNTER CLOCKWISE TO MOVE THE PRINT HAMMER AWAY FROM THE FEED WHEEL.




TYPE WHEEL POSITIONING AND PRINT HAMMER (FINAL)

REQUIREMENT

WITH "M" CODE COMBINATION (--345) SELECTED, AND ROCKER BAIL IN ITS EXTREME LEFT POSITION CHECK THAT THE ROTARY CORRECTOR IS FIRMLY SEATED IN THE TYPE WHEEL RACK. THE TYPE WHEEL AND PRINT HAMMER ALIGNMENT COULD BE SUCH THAT A FULL CHARACTER IS PRINTED UNIFORMLY BETWEEN THE FEED HOLES.

TO ADJUST


WITH TYPEWHEEL LOCK NUT LOOSE POSITION THE TYPE WHEEL. IF NECESSARY, REFINE THE PRINT HAMMER ADJUSTMENT MAKING CERTAIN THE PRINT HAMMER HEAD DOES NOT COME IN CONTACT WITH THE FEED WHEEL.



2.52 Ribbon Mechanism

FEED PAWL SPRING
REQUIREMENT
 WITH ROCKER BAIL TO EXTREME RIGHT:
 MIN. 4 OZS. --- MAX. 6 OZS.
 TO PULL FEED PAWL SPRING TO
 INSTALLED LENGTH.

RATCHET WHEEL TORQUE SPRING
REQUIREMENT
 MIN. 1 OZS. --- MAX. 3 OZS.
 APPLIED TANGENTIALLY TO THE RATCHET
 WHEEL TO START IT TO ROTATE.




DRIVE ARM
TO CHECK
 POSITION ROCKER BAIL TO EXTREME LEFT.
 HOLD THE RIBBON REVERSING ARM UNDER LOWER
 REVERSING EXTENSION OF FEED PAWL.
REQUIREMENT
 (1) CLEARANCE BETWEEN BLOCKING EDGE OF
 RIBBON REVERSE ARM AND REVERSING
 EXTENSION OF FEED PAWL:
 MIN. SOME
 (2) CLEARANCE SHALL NOT BE SO GREAT AS
 TO ALLOW FEED PAWL TO FEED MORE
 THAN TWO TEETH AT A TIME.
 (3) FEED PAWL DETENTED IN BOTH ITS RIGHT
 AND LEFT POSITION.
TO ADJUST
 POSITION DRIVE ARM ADJUSTABLE EXTENSION
 LEVER WITH ITS MOUNTING SCREW LOOSENED.

2.53 Ribbon Mechanism continued

DRIVE ARM SPRING

REQUIREMENT

WITH ROCKER BAIL TO EXTREME RIGHT:
MIN. 9 OZS. --- MAX. 14 OZS.
TO PULL DRIVE ARM SPRING TO
INSTALLED LENGTH.



DETENT SPRING

DETENT SPRING

REQUIREMENT

WITH REVERSING ARM IN ITS EXTREME
RIGHT OR LEFT POSITION:
MIN. 2 OZS. --- MAX. 4 OZS.
TO PULL DETENT SPRING TO ITS
INSTALLED LENGTH.

3. VARIABLE FEATURES

NOTE: UNLESS OTHERWISE SPECIFIED, THE FOLLOWING BACKSPACE ADJUSTMENTS APPLY TO BOTH THE CHADLESS AND FULLY PERFORATED TAPE MECHANISMS.

3.01 Manual and Power Drive Backspace Mechanism (For Chadless Tape)


RAKE (A)

(1) REQUIREMENT

WITH ROTATIONAL PLAY IN RAKE TAKEN UP TO LEFT, BOTTOM SURFACE OF RAKE TEETH SHOULD BE WITHIN 0.040 INCH OF THE SAME VERTICAL PLANE AS LEFT SIDE OF PUNCH BLOCK OR SLIGHTLY TO THE RIGHT.

TO ADJUST

REMOVE TWO MOUNTING SCREWS FROM REAR PLATE. POSITION RAKE SHAFT GEAR IN RELATION TO GEAR SEGMENT. REPLACE MOUNTING SCREWS.




(2) REQUIREMENT

WITH BELL CRANK SPRING UNHOOKED AND RAKE IN OPERATED POSITION, CLEARANCE BETWEEN BOTTOM OF RAKE TEETH AND LOWER SURFACE OF TAPE SLOT:

MIN. 0.007 INCH---MAX. 0.011 INCH
(CHECK AT NO. 1 & 5 PINS.)

TO ADJUST

LOOSEN THE FOUR PUNCH BLOCK MOUNTING SCREWS FRICTION TIGHT, POSITION THE RAKE MOUNTING PLATE AND BELL CRANK MOUNTING PLATE SO THAT THE FRONT EDGE OF BOTH PLATES IS APPROXIMATELY IN LINE WITH THE VERTICAL PLANE OF THE PUNCH BLOCK. WITH THE RAKE IN THE OPERATED POSITION (BELL CRANK IN MAXIMUM DOWNWARD POSITION) MOVE THE RAKE UP OR DOWN TO MEET CLEARANCE REQUIREMENT. TIGHTEN SCREWS AND REPLACE THE BELL CRANK SPRING.



(B) FEED PAWL ADJUSTING PLATE
REQUIREMENT

(1) PRELIMINARY: WITH BELL CRANK ROTATED CLOCKWISE, FEED PAWL SHALL MISS FIRST TOOTH AT POINT OF LEAST CLEARANCE BY


MIN. 0.006 INCH---MAX. 0.040 INCH

(2) FINAL: FEED PAWL SHALL MISS FIRST TOOTH AND ENGAGE SECOND TOOTH BY AT LEAST 1/2 OF RIGHT ENGAGING SURFACE OF FEED PAWL (AS GAUGED BY EYE WHEN FEED PAWL FIRST CONTACTS RATCHET TOOTH).

TO ADJUST


POSITION ADJUSTING PLATE WITH MOUNTING SCREW FRICTION TIGHT.

3.02 Manual and Power Drive Backspace Mechanism (For Chadless Tape) continued



(A) RETURN LATCH REQUIREMENT

BACKSPACE MECHANISM IN UNOPERATED POSITION. CLEARANCE BETWEEN RETURN LATCH AND FEED PAWL EXTENSION
 MIN. 0.004 INCH
 MAX. 0.020 INCH
 TO ADJUST
 ADJUST ECCENTRIC WITH MOUNTING SCREW FRICTION TIGHT.



(B) FEED PAWL ECCENTRIC MANUAL BACKSPACE (PRELIMINARY) REQUIREMENT

WITH THE BACKSPACE BELL CRANK IN ITS OPERATED POSITION AND THE FEED WHEEL DETENTED BACK ONE SPACE:

MIN. SOME---MAX. 0.003 INCH
 CLEARANCE BETWEEN THE FEED WHEEL RATCHET TOOTH AND THE BACKSPACE FEED PAWL.


POWER DRIVE BACKSPACE

WITH THE BACKSPACE BELL CRANK IN ITS OPERATED POSITION, THE HIGH SIDE OF THE ECCENTRIC SHOULD BE IN ITS UPPERMOST POSITION.

TO ADJUST

LOOSEN THE NUT POST (FRICTION TIGHT) AND ROTATE ECCENTRIC WITH AN ALLEN WRENCH. TIGHTEN THE NUT POST.

3.03 Manual and Power Drive Backspace Mechanism (For Fully Perforated Tape)



3.04 Manual and Power Drive Backspace Mechanism (For Fully Perforated Tape) continued


(A) FEED PAWL DISABLING

REQUIREMENT

WHEN BELL CRANK IS IN OPERATED POSITION HIGH SIDE OF FEED PAWL DISABLING ECCENTRIC SHOULD BE IN UPPERMOST POSITION.

TO ADJUST

WITH NUT POST FRICTION TIGHT, ROTATE ECCENTRIC WITH A 0.060" ALLEN WRENCH.



3.05 Power Drive Backspace Mechanism (For Fully Perforated Tape) (Early Design)

(B) DRIVE LINK

REQUIREMENT


WITH HIGH PART OF ECCENTRIC ARM IN LEFT HAND POSITION, ARMATURE AGAINST POLE FACE TO ALLOW DRIVE ARM LATCH LEVER TO REST AGAINST ECCENTRIC ARM. CLEARANCE BETWEEN STEP ON ECCENTRIC ARM AND LATCH.

MIN. 0.040 INCH

MAX. 0.045 INCH

TO ADJUST

WITH DRIVE LINK SCREW FRICTION TIGHT POSITION ADJUSTING LINK.




3.06 Power Drive Backspace Mechanism (Early Design) continued

(A) ARMATURE HINGE REQUIREMENT

ARMATURE BAIL SPRING REMOVED. WITH ARMATURE HELD AGAINST POLE FACE AND PLAY TAKEN UP AT HINGE IN DOWNWARD DIRECTION, CLEARANCE BETWEEN ARMATURE AND MAGNET BRACKET MIN. SOME --- MAX. 0.004 INCH


TO ADJUST WITH HINGE MOUNTING SCREWS LOOSENED POSITION ARMATURE.

NOTE: THE FOLLOWING ADJUSTMENTS ARE FOR USE WITH THE EARLY DESIGN BACKSPACE MAGNET ASSEMBLY. LATER DESIGN USE A NON-ADJUSTABLE BACKSPACE MAGNET ASSEMBLY.



NOTE: FOR "DC" OPERATION, THE BACKSPACE MAGNET ARMATURE SHALL BE POSITIONED SO THAT THE SIDE MARKED "C" SHALL FACE THE POLE FACE OF THE MAGNET CORE. FOR "AC" OPERATION, THE UNMARKED SIDE OF THE MAGNET ARMATURE SHALL FACE THE POLE FACE OF THE MAGNET CORE.

NOTE: THIS ADJUSTMENT IS MADE AT FACTORY AND SHOULD NOT BE DISTURBED UNLESS A REASSEMBLY OF THE UNIT IS UNDERTAKEN. IF NECESSARY TO MAKE THIS ADJUSTMENT, THE PUNCH UNIT SHOULD BE REMOVED. SEE DISASSEMBLY AND REASSEMBLY. REMAKE PUNCH UNIT POSITION ADJUSTMENT.




(B) ARMATURE UP-STOP REQUIREMENT

ARMATURE IN UNOPERATED POSITION. GAP BETWEEN ARMATURE AND POLE FACE MIN. 0.025 INCH. MAX. 0.030 INCH. AT CLOSEST POINT.

TO ADJUST ROTATE ECCENTRIC WITH MOUNTING NUT LOOSENED. KEEP HIGH PART OF ECCENTRIC TO LEFT.

3.07 Power Drive Backspace Mechanism (For Chadless Tape) (Early Design) continued



(A) DRIVE ARM REQUIREMENT

WITH DRIVE ARM LATCH LEVER ENGAGED WITH ECCENTRIC LINK, MAIN SHAFT ROTATED TO PLACE ECCENTRIC IN ITS EXTREME RIGHT HAND POSITION AND FEED WHEEL DETENTED BACK ONE SPACE:

MIN. SOME---MAX. 0.003 INCH

CLEARANCE BETWEEN THE BACKSPACE FEED PAWL AND THE RATCHET TOOTH. CHECK WITH FEED WHEEL SHAFT OIL HOLE IN THE UPPERMOST POSITION AND RECHECK EACH 90 DEGREES ABOUT THE PERIPHERY OF THE FEED WHEEL.


TO ADJUST

LOOSEN DRIVE ARM SCREW (FRICTION TIGHT) AND POSITION ADJUSTING PLATE.

3.08 Power Drive Backspace Mechanism (Early Design) continued

NOTE:

THIS ADJUSTMENT IS MADE AT FACTORY AND SHOULD NOT BE DISTURBED UNLESS A REASSEMBLY OF THE UNIT IS UNDERTAKEN. IF NECESSARY TO MAKE THIS ADJUSTMENT, PUNCH SHOULD BE REMOVED. SEE DISASSEMBLY AND REASSEMBLY. REMAKE PUNCH POSITION ADJUSTMENT.



(B) LATCH EXTENSION REQUIREMENT

BACKSPACE MECHANISM IN UNOPERATED POSITION. HIGH PART OF ECCENTRIC TO LEFT. ARMATURE AGAINST POLE FACE. LATCH RESTING ON ECCENTRIC ARM NOTCH. CLEARANCE BETWEEN TOP OF ARMATURE BAIL EXTENSION AND LATCH EXTENSION

MIN. 0.005 INCH

MAX. 0.020 INCH

TO ADJUST

SWING MAGNET CLOCKWISE OR COUNTERCLOCKWISE, AS NECESSARY, WITH MOUNTING SCREWS FRICTION TIGHT.

3.09 Power Drive Backspace Mechanism (Early Design) continued

(A) LATCH

REQUIREMENT


BACKSPACE MECHANISM IN UNOPERATED POSITION. ARMATURE OFF POLE FACE (DE-ENERGIZED). LATCH EXTENSION AGAINST END OF ARMATURE BAIL EXTENSION. ECCENTRIC ARM AT ITS CLOSEST POINT TO UNDERSIDE OF LATCH. CLEARANCE BETWEEN LATCH AND ECCENTRIC ARM.

MIN. 0.005 INCH
MAX. 0.025 INCH

TO ADJUST POSITION LATCH WITH LATCH EXTENSION SCREW LOOSENED.

NOTE 1:

ON UNITS EQUIPPED WITH ONE PIECE NON-ADJUSTABLE LATCH LEVER THE REQUIREMENTS IN THE "FINAL POWER OR MANUAL" MUST BE MET.



(B) NON-REPEAT ARM
REQUIREMENT


BACKSPACE MECHANISM IN UNOPERATED POSITION. CLEARANCE BETWEEN TOP SURFACE OF NON-REPEAT ARM AND LOWEST POINT OF LATCH EXTENSION

MIN. 0.002 INCH
MAX. 0.010 INCH


TO ADJUST POSITION ADJUSTING ARM WITH ARM SCREW LOOSENED FRICTION TIGHT.

NOTE 2:


MUST NOT BE OPERATED WITH LATCH AGAINST ARMATURE EXTENSION.




3.10 Manual and Power Drive Backspace Mechanism (For Chadless Tape) (Early Design) continued



3.11 Manual and Power Drive Backspace Mechanism (For Fully Perforated Tape)
(Early Design) continued



3.12 Power Drive Backspace Mechanism (Latest Design)
(Non-Adjustable Backspace Magnet Assembly)



3.13 Manual and Power Drive Backspace Mechanism (Chadless and Fully Perforated Tape)

(D) FINAL MANUAL OR POWER REQUIREMENT

UNIT OPERATING UNDER POWER AND TAPE IN THE PUNCH UNIT. PLACE THE FEED WHEEL SHAFT OIL HOLE IN ITS UPPERMOST POSITION AND OPERATE THE BACKSPACE MECHANISM ONCE. THE BACKSPACE RATCHET WHEEL SHALL BE BACKED ONE SPACE AND THE FEED WHEEL RATCHET TO A FULLY DETENTED POSITION. RECHECK EVERY 90° FOR ONE FULL REVOLUTION OF THE BACKSPACE RATCHET WHEEL.

NOTE 1: A FULLY DETENTED POSITION IS DEFINED AS: WITH THE DETENT ROLLER IN CONTACT WITH THE RATCHET WHEEL THE PUNCH UNIT FEED PAWL SHALL ENGAGE THE FIRST TOOTH BELOW THE HORIZONTAL CENTER LINE OF THE RATCHET FEED WHEEL WITH NO PERCEPTIBLE CLEARANCE.

TO ADJUST
(FOR CHADLESS TAPE MECHANISM) REFINE FEED PAWL ADJUSTMENTS.
(FOR FULLY PERFORATED TAPE MECHANISM) LOOSEN ARM ADJUSTING SCREW AND MOVE ADJUSTING PLATE.


3.14 Code Reading Contacts

NOTE 1:

UNLESS SPECIFICALLY STATED OTHERWISE, THE FOLLOWING CODE READING CONTACT ADJUSTMENTS APPLY TO BOTH THE TRANSFER (BREAK BEFORE MAKE) TYPE AND MAKE TYPE CONTACTS. WHEN AN ADJUSTMENT IS APPLICABLE TO BOTH TYPES, THE TRANSFER TYPE CONTACTS ARE USED IN THE ILLUSTRATIONS. WHEN TESTING THESE CONTACTS ON ASR SETS THE CONTROL KNOB SHOULD BE IN THE K-T POSITION.

NOTE 2: IT IS RECOMMENDED THAT THE FOLLOWING ADJUSTMENTS BE MADE WITH THE CODE READING CONTACT ASSEMBLY REMOVED FROM THE UNIT.

NOTE 3: WHEN USING THE CONTACT SPRING BENDER, START WITH THE CONTACT PILE-UP FARTHEST FROM THE HANDLE OF THE TOOL AND WORK TOWARD THE HANDLE SO AS NOT TO DISTURB ADJUSTMENTS ALREADY MADE.




NOTE 4:


TO INCREASE TENSION OF MARKING CONTACT SPRING, IT MAY BE NECESSARY TO BEND BACKSTOP AWAY FROM SPRING, BEND SPRING AND THEN RE-BEND BACKSTOP TO MEET REQUIREMENT OF MARKING CONTACT BACKSTOPS ADJUSTMENT (ABOVE).

3.15 Code Reading Contacts continued


- (A) SWINGER CONTACT SPRINGS-PRELIMINARY REQUIREMENT
 MIN. 30 GRAMS
 MAX. 40 GRAMS
 TO OPEN MARKING CONTACTS.
 TO ADJUST BEND SWINGER CONTACT SPRINGS.




NOTE 1: SPACING CONTACTS (ON TRANSFER TYPE CONTACT ASSEMBLIES ONLY) ARE NORMALLY OPEN WHEN CONTACT ASSEMBLY IS REMOVED FROM UNIT.



- (B) SPACING CONTACT BACKSTOPS - PRELIMINARY (APPLIES TO TRANSFER TYPE CONTACTS ONLY) REQUIREMENT
 GAP BETWEEN SPACING CONTACTS
 MIN. 0.018 INCH
 MAX. 0.025 INCH
 TO ADJUST BEND SPACING CONTACT BACKSTOPS.




- (C) SPACING CONTACT SPRINGS-PRELIMINARY (APPLIES TO TRANSFER TYPE CONTACTS ONLY) REQUIREMENT
 MIN. 35 GRAMS
 MAX. 50 GRAMS
 TO MOVE EACH CONTACT SPRING AWAY FROM BACKSTOP.
 TO ADJUST BEND SPACING CONTACT SPRINGS.



NOTE 2: TO INCREASE TENSION OF SPRING, IT MAY BE NECESSARY TO BEND BACKSTOP AWAY FROM SPRING, BEND SPRING, AND THEN RE-BEND BACKSTOP TO MEET REQUIREMENT OF SPACING CONTACT BACKSTOPS ADJUSTMENT ABOVE.

3.16 Code Reading Contacts continued

NOTE 1: THE FOLLOWING CODE READING CONTACT ADJUSTMENTS SHOULD BE MADE WITH THE CONTACT ASSEMBLIES MOUNTED ON THE UNIT.



(A) CONTACT MOUNTING BRACKET REQUIREMENT


- (1) WITH FUNCTION CLUTCH DISENGAGED AND LATCHED, THERE SHALL BE MIN. 0.015 INCH CLEARANCE BETWEEN THE CLOSEST NORMALLY CLOSED CONTACT SPRING (MARKING CONTACT) AND PUNCH SLIDE INSULATOR.
- (2) WITH LETTERS COMBINATION SELECTED AND PUNCH PINS IN THEIR UPPERMOST POSITION, THE SWINGER SHALL BE PARALLEL TO RIGHT END OF PUNCH SLIDE AND EXTEND BELOW ITS CENTER, AS GAGED BY EYE.

TO ADJUST POSITION CONTACT MOUNTING BRACKET WITH MOUNTING SCREWS LOOSENED.


(B) CONTACT MOUNTING PLATE REQUIREMENT

EACH SWINGER CONTACT SPRING SHOULD BE ALIGNED WITH ITS ASSOCIATED PUNCH SLIDE INSULATOR AS GAUGED BY EYE.

TO ADJUST POSITION CONTACT MOUNTING PLATE WITH MOUNTING SCREWS LOOSENED.



3.17 Code Reading Contacts continued



CONTACT BRACKET-PRELIMINARY (APPLIES TO TRANSFER TYPE CONTACTS ONLY)

(1) REQUIREMENT

MANUALLY SELECT BLANK CODE COMBINATION. ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS. SOME CLEARANCE BETWEEN SPACING CONTACT SPRING AND ITS BACKSTOP.

MIN. SOME
MAX. 0.008 INCH


(2) REQUIREMENT

WITH SELECTOR AND FUNCTION CLUTCHES DISENGAGED AND LATCHED, MANUALLY SELECT LETTERS CODE COMBINATION. ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS. CLEARANCE BETWEEN PUNCH SLIDE INSULATOR AND SWINGER CONTACT SPRING.

MIN. 0.028 INCH

TO ADJUST

POSITION CONTACT BRACKET WITH ITS MOUNTING SCREWS. LOOSENED TO MEET REQUIREMENT (1). TO PRY BRACKET TO LEFT, INSERT SCREWDRIVER BETWEEN BRACKET AND LEFT EDGE OF MOUNTING SCREWS; TO PRY BRACKET TO RIGHT, INSERT SCREWDRIVER BETWEEN BRACKET AND RIGHT EDGE OF MOUNTING SCREWS. CHECK REQUIREMENT (2). IF NOT MET, REFINE ADJUSTMENT.





3.18 Code Reading Contacts continued

CONTACT BRACKET-PRELIMINARY (APPLIES TO MAKE TYPE CONTACTS ONLY)

(1) REQUIREMENT

MANUALLY SELECT BLANK CODE COMBINATION.
 ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS
 AND PUNCH SLIDES ARE AGAINST THEIR RESPECTIVE LATCHES.
 GAP BETWEEN CONTACTS.
 MIN. 0.020 INCH
 MAX. 0.025 INCH



(2) REQUIREMENT


WITH SELECTOR AND FUNCTION CLUTCHES
 DISENGAGED AND LATCHED, MANUALLY
 SELECT LETTERS CODE COMBINATION.
 ROTATE MAIN SHAFT UNTIL FUNCTION
 CLUTCH TRIPS. CLEARANCE BETWEEN
 PUNCH SLIDE INSULATOR AND SWINGER
 CONTACT SPRING.
 MIN. 0.028 INCH

TO ADJUST
 POSITION CONTACT BRACKET WITH MOUNTING SCREWS
 FRICTION TIGHT. TO PRY BRACKET TO LEFT,
 INSERT SCREW DRIVER BETWEEN BRACKET AND
 LEFT EDGE OF MOUNTING SCREW; TO PRY BRACKET TO
 RIGHT, INSERT SCREW DRIVER BETWEEN BRACKET
 AND RIGHT EDGE OF MOUNTING SCREW.

3.19 Timing Contacts


NOTE 1: THERE ARE TWO TYPES OF TIMING CONTACT ASSEMBLIES, SINGLE AND DOUBLE. SINGLE CONTACT ASSEMBLIES HAVE A FRONT CONTACT ONLY, NO REAR CONTACT. IF UNIT IS EQUIPPED WITH A DOUBLE CONTACT ASSEMBLY, THE FOLLOWING ADJUSTMENTS APPLY TO BOTH FRONT AND REAR CONTACTS.

NOTE 2: IN CASE OF SINGLE-CONTACT ASSEMBLY, MAKE CERTAIN CONTACT BRACKET MOUNTING SCREWS ARE CENTRALLY LOCATED IN ELONGATED SLOTS, AND PROCEED TO NEXT ADJUSTMENT.



3.20 Timing Contacts continued

NOTE 1: IT IS RECOMMENDED THAT THE FOLLOWING TIMING CONTACT ADJUSTMENTS BE MADE WITH CONTACT ASSEMBLIES REMOVED FROM THE UNIT.




3.21 Timing Contacts continued

NOTE 1: THE FOLLOWING TIMING CONTACT ADJUSTMENTS SHOULD BE MADE WITH CONTACT ASSEMBLY MOUNTED ON UNIT.

(B) OPERATING BAIL SPRINGS
REQUIREMENT

OPERATING BAIL HELD SO THAT SWINGER IS AGAINST BACKSTOP.
MIN. 7 OZS.
MAX. 12 OZS.
TO PULL SPRING TO INSTALLED LENGTH.



(A) CONTACT BRACKET-PRELIMINARY (FOR UNITS EQUIPPED WITH ONE-CYCLE CAMS)


LOOSEN LOCKING SCREW. POSITION CAM FOLLOWER ARM, BY MEANS OF ITS ELONGATED MOUNTING HOLE, TO ITS MINIMUM LENGTH ON OPERATING BAIL. TIGHTEN LOCKING SCREW.

REQUIREMENT

SELECTOR AND FUNCTION CLUTCHES DISENGAGED AND LATCHED. CLEARANCE BETWEEN CAM FOLLOWER ROLLER AND FUNCTION CAM.
MIN. 0.050 INCH
MAX. 0.055 INCH

TO ADJUST

POSITION CONTACT BRACKET WITH MOUNTING SCREWS LOOSENED.



NOTE 2: ON UNITS EQUIPPED WITH DOUBLE CONTACT ASSEMBLIES, RECHECK CONTACT BACKSTOP ADJUSTMENT. IF REQUIREMENT IS NOT MET, REFINES CONTACT BRACKET ADJUSTMENT.

3.22 Code Reading Contacts continued

CONTACT BRACKET-PRELIMINARY (FOR UNITS EQUIPPED WITH TWO-CYCLE CAMS)

LOOSEN LOCKING SCREW. POSITION CAM FOLLOWER ARM, BY MEANS OF ITS ELONGATED MOUNTING HOLES, TO ITS MAXIMUM LENGTH ON OPERATING BAIL. TIGHTEN LOCKING SCREW.


REQUIREMENT

SELECTOR AND FUNCTION CLUTCHES DISENGAGED AND LATCHED. CLEARANCE BETWEEN BAIL AND SWINGER INSULATOR OF PILE-UP HAVING LEAST CLEARANCE SHOULD BE 0.118 INCH MINUS CLEARANCE "X" BETWEEN BACKSTOP AND SWINGER INSULATOR.

TO ADJUST

POSITION CONTACT BRACKET WITH ITS MOUNTING SCREWS LOOSENED.

NOTE 1: THE RANGE OF THIS ADJUSTMENT IS 0.005 INCH. FOR EXAMPLE; IF CLEARANCE "X" IS 0.080 INCH, THE NORMAL ADJUSTMENT IS 0.038 INCH AND THE RANGE OF ADJUSTMENT IS 0.035 INCH TO 0.040 INCH.




3.23 Code Reading Contacts Strobing (Using Signal Distortion Test Set)

THE FOLLOWING TESTS REQUIRE THE USE OF A TELETYPE SIGNAL DISTORTION TEST SET. THEY SHOULD BE MADE AFTER THE CONTACT ASSEMBLIES HAVE BEEN ADJUSTED AS INSTRUCTED ON THE PRECEDING PAGES. WHERE REQUIREMENTS ARE NOT MET, DESIGNATED ADJUSTMENTS MUST BE REFINED, AND/OR RELATED LENGTHS MAY HAVE TO BE CHANGED TO MEET TIMING REQUIREMENTS.

ALL TEST SHOULD BE MADE WITH THE CONTROL KNOB OF THE MODEL 28 ASR IN THE K-T POSITION AND WITH THE UNIT AND TEST SET OPERATING AT 600 O.P.M.

OBSERVATIONS ARE TO BE MADE OF A NEON TRACE ON THE GRADUATED DISC OF A TEST SET. TRACE WILL HAVE TENDENCY TO "JUMP"; THAT IS, IT WILL NOT BE STEADY ENOUGH TO BE ACCURATELY MEASURED. VARIATION MAY BE AS HIGH AS TEN DIVISIONS ON SCALE. MINIMUM SIGNAL LENGTH IS MEASURED BETWEEN LATEST START AND EARLIEST END OF ALL TRACES. MAXIMUM SIGNAL LENGTH IS MEASURED BETWEEN EARLIEST START AND LATEST END OF ALL TRACES.




TO ZERO TEST SET

CONNECT NEON TRACE TO NO. 1 CODE READING CONTACT (REARMOST). WITH UNIT RECEIVING LETTERS CODE COMBINATIONS, OBSERVE AND NOTE POINT AT WHICH TRACE ENDS. TRACES WILL JUMP AS DESCRIBED ABOVE; NOTE EARLIEST END OF TRACES. REPEAT FOR REMAINING CONTACTS. OF ALL TRACES OBSERVED, CHOOSE ONE THAT STARTS THE LATEST. SET "START-ZERO" MARK OF SCALE AT LATEST START OF CHOSEN TRACE. RECORD EARLIEST END OF CHOSEN TRACE FOR FUTURE ADJUSTMENT REFERENCES.

3.24 Code Reading Contacts Strobing continued

NOTE 1: TEST PROCEDURES ON THIS PAGE APPLY TO A UNIT WITH 2-CYCLE CLUTCH

**CODE READING CONTACTS**


- (1) ZERO TEST SET AS PREVIOUSLY INSTRUCTED.
- (2) CONNECT NEON TRACE TO MARKING SIDE OF CODE READING CONTACT. (NORMALLY OPEN WHEN UNIT IS IN IDLE CONDITION). WITH UNIT RECEIVING LETTERS CODE COMBINATIONS, OBSERVE TRACE.

REQUIREMENTS

- A. SIGNAL LENGTH
MIN. 245 DIVISIONS
MAX. 425 DIVISIONS
 - B. BOUNCE SHOULD END WITHIN MAX. OF 20 DIVISIONS OF EARLIEST START AND EARLIEST END OF TRACE.
- (3) TO ADJUST
 - A. IF REQUIREMENTS UNDER (2)A. ARE NOT MET, REFINE CONTACT BRACKET ADJUSTMENT. IF NECESSARY, REFINE CONTACT GAP TO MEET STROBE REQUIREMENTS. RECHECK CONTACT SPRING TENSIONS.
 - B. IF BOUNCE REQUIREMENTS UNDER (2)B. ARE NOT MET, REFINE MARKING CONTACT SPRING AND SWINGER CONTROL SPRING TENSIONS.
 - C. IF ANY REFINEMENTS ARE NECESSARY, REPEAT COMPLETE TEST PROCEDURE.

3.25 Timing Contacts Strobing

NOTE 1: TEST PROCEDURES ON THIS PAGE APPLY TO A UNIT WITH 2-CYCLE CLUTCH

**TIMING CONTACTS**

- (1) ZERO TEST SET AS PREVIOUSLY DESCRIBED.
- (2) CONNECT NEON TRACE TO RIGHT SIDE OF FRONT CONTACT (NORMALLY OPEN WHEN UNIT IS IN IDLE CONDITION). WITH UNIT RECEIVING LETTERS CODE COMBINATIONS FROM KEYBOARD TRANSMISSION, OBSERVE TRACE.

REQUIREMENTS

 - A. EARLIEST START MIN. 22 DIVISIONS AFTER START-ZERO MARK.
 - B. LATEST END MIN. 22 DIVISIONS BEFORE EARLIEST END OF CODE READING CONTACT TRACES.
 - C. TRACE LENGTH
 - MIN. 163 DIVISIONS
 - MAX. 200 DIVISIONS
 - D. BOUNCE SHOULD END WITHIN MAX. OF 5 DIVISIONS OF EARLIEST START OR LATEST END OF TRACE.
- (3) TO ADJUST
 - A. IF REQUIREMENTS UNDER (2)A., B., AND C. ARE NOT MET, REFINE RIGHT CONTACT GAP, LEFT CONTACT GAP, SWINGER CONTACT SPRING, AND LEFT CONTACT SPRING.
 - B. IF BOUNCE REQUIREMENTS UNDER (2)D. ARE NOT MET, REFINE SWINGER CONTACT SPRING AND LEFT CONTACT SPRING.
 - C. IF ANY REFINEMENTS ARE NECESSARY, REPEAT COMPLETE TEST PROCEDURE.

3.26 Unshift-On-Space Mechanism

(A) UNSHIFT-ON-SPACE FUNCTION BLADE

(1) TO CHECK

REMOVE SIGNAL BELL CONTACT ASSEMBLY WITH BRACKET AND SIGNAL BELL FUNCTION BLADE.

SELECT FIGURES CODE COMBINATION (12-45). ROTATE MAIN SHAFT UNTIL LIFTER ROLLER IS ON LOW PART OF ROCKER BAIL'S CAMMING SURFACE AND UNSHIFT-ON-SPACE FUNCTION BLADE RESTS ON BELL CRANKS.

REQUIREMENT

MIN. SOME---MAX. 0.015 INCH BETWEEN STRIPPER BLADE AND LETTERS EXTENSION ARM.

(2) TO CHECK

SELECT SPACE CODE COMBINATION (--3--). ROTATE MAIN SHAFT UNTIL STRIPPER BLADE TOUCHES LETTERS EXTENSION ARM.



REQUIREMENT

WHEN PLAY IS TAKEN UP IN EITHER DIRECTION, STRIPPER BLADE SHOULD ENGAGE AN EQUAL THICKNESS OF LETTERS EXTENSION ARM.

TO ADJUST

POSITION STRIPPER BLADE ON FUNCTION BLADE WITH TWO MOUNTING SCREWS LOOSENED, REINSTALL SIGNAL BELL CONTACT ASSEMBLY WITH BRACKET AND SIGNAL BELL FUNCTION BLADE.

MAKE SIGNAL BELL CONTACT MOUNTING BRACKET ADJUSTMENT



(B) UNSHIFT-ON-SPACE FUNCTION BLADE SPRING

REQUIREMENT

WITH UNIT IN STOP POSITION AND LONG SLOT IN BLOCKING SLEEVE ENGAGING FUNCTION BLADE:

MIN. 10 OZS. ---- MAX. 13 OZS. TO START BLADE MOVING.

3.27 Chad Chute Assembly (Keyboard Perforator Typing or Non-Typing)


CHAD CHUTE ASSEMBLY (KEYBOARD PERFORATOR "TYPING OR NON-TYPING"
AUTOMATIC SEND-RECEIVE SET)

REQUIREMENT

CLEARANCE BETWEEN EACH CHAD CHUTE AND
ADJACENT UNITS SHOULD BE EQUAL IN ALL
DIRECTIONS.

TO ADJUST

WITH MOUNTING SCREWS FRICTION TIGHT POSITION
EACH CHUTE BY MEANS OF THEIR ELONGATED
SLOTS.



28 TYPING REPERFORATOR AND TAPE PRINTER

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	6	Tape depressor slide spring	44
2. BASIC UNITS	11	Tape guide assembly spring	37
Chad Chute Assemblies for Fully Perforated Tape		Tape guide (early design)	44, 45
Chad chute (for self-contained typing reperforator set)	73	Tape guide (latest design)	45
Chad chute assembly (for auxiliary reperforator—automatic send-receive)	76	Tape guide spring	45
Chad chute assembly (for keyboard reperforator—automatic send-receive)	75	Tape shoe torsion spring	44
Chad chute assembly (for multiple reperforator set)	74	Toggle bail eccentric (preliminary)	28
Function Mechanism		Toggle operating arm	28
Adjusting arm spring (earlier design)	23	Punch Mechanism (For Chadless Tape)	
Adjusting arm torsion spring (later design)	23	Detent lever	34
Clutch shoe lever	11	Feed hole lateral alignment	35
Clutch shoe lever spring	12	Feed hole spacing (final)	33
Clutch shoe spring	12	Feed hole spacing (preliminary)	33
Follower lever	23	Perforator position	27
Function clutch drum end play	11	Punch pin penetration	29
Function clutch latch lever spring	48	Punch slide downstop plate position	29
Function clutch release lever spring	46	Punch slide guide	29
Function clutch trip lever	22	Punch slide latch spring	25
Main trip lever spring	23	Punch slide spring	36
Release lever downstop bracket	46	Retractor bail springs	36
Reset arm	22	Tape guide assembly spring	37
Reset bail trip lever	31	Tape guide spring (punch block)	37
Rocker bail	24	Tape guide spring (tape guide)	37
Rocker bail guide bracket	24	Punch Mechanism (For Fully Perforated Tape)	
Punch Mechanism		Perforator position	26
Detent lever spring	43	Punch pin penetration	30
Feed pawl (preliminary)	32	Punch slide downstop position	30
Feed pawl spring	43	Punch slide guide	30
Latch lever clearance	32	Punch slide latch springs	25
Perforator drive link spring	28	Punch slide spring	42
		Tape guide assembly spring	42
		Tape guide spring (punch block)	42
		Tape guide spring (tape guide)	42
		Punch Mechanism (For Fully Perforated Tape with Indentations of Feed Wheel Between the Feed Holes)	
		Detent	41
		Feed hole lateral alignment	41
		Feed hole spacing (final)	40

CONTENTS	PAGE
Punch Mechanism (For Fully Perforated Tape with Indentations of Feed Wheel Fully Punched Out)	
Feed wheel indentation alignment . . .	39
Feed hole spacing	38
Ribbon Mechanism (Later Design)	
Detent spring	70
Drive arm	69
Drive arm spring	70
Feed pawl spring	69
Ratchet wheel torque spring	69
Selector Mechanism	
Clutch shoe lever	11
Clutch shoe lever spring	12
Clutch shoe spring	12
Marking locklever spring	17
Punch slide latch spring	25
Pushlever reset bail spring	19
Range scale knob	20
Selector armature	13
Selector armature downstop bracket	13
Selector armature spring (final) (single button armature)	14
Selector armature spring (final) (two button armature)	15
Selector armature spring (preliminary) (single button armature)	14
Selector armature spring (preliminary) (two button armature)	15
Selector cam lubricator	22
Selector clutch drum endplay	18
Selector clutch latch lever spring	19
Selector clutch stop arm	20
Selector lever spring	18
Selector magnet bracket	16
Selector push lever spring	18
Selector receiving margin	21
Spacing lock lever spring	19
Start lever spring	21
Slack Tape Mechanism	
Clamp plate spring	71
Tape platform	71
Tape Guide Chute Mechanism	
Tape guide chute (for auxiliary typing reperfector—(automatic send-receive)	77
Tape Printer Unit	
Feed wheel	72

CONTENTS	PAGE
Special requirement	72
Tape guide	72
Typing Mechanism	
Accelerator spring	67
Axial corrector (yielding)	61
Axial corrector (non-yielding)	60
Axial output rack guide roller	59
Axial sector alignment	58
Bell crank springs	47
Corrector drive link (yielding) extension spring	61
Corrector drive link spring (non-yielding)	56
Eccentric shaft detent lever springs	58
Figure arm assembly spring	51
Figures extension arm spring	51
Function blade springs	56
Function box	49
Letters and figures yield arm	51
Letters arm assembly spring	52
Letters extension arm spring	52
Lifter arm	53
Lifter arm eccentric screw	53
Lifter spring	56
Lifter toggle link spring	56
Lock lever	54
Lock lever trip post	55
No. 5 pulse beam spring	54
Oscillating drive bail	57
Oscillating drive link	57
Print hammer spring	67
Printing latch	67
Printing latch spring	67
Printing trip link spring	67
Pushbar guide bracket	59
Pushbar operating blade (final)	47
Pushbar operating blade (preliminary)	47
Rocker bail pilot stud	48
Rotary corrector arm	63
Rotary corrector mesh	62
Transfer mounting bracket	50
Typewheel rack clearance	60
Typing Mechanism (For Chadless Tape)	
Print hammer	65
Ribbon carrier	64
Typewheel (final)	65
Typewheel (preliminary)	65
Typing Mechanism (For Fully Perforated Tape)	
Print hammer (final)	68

CONTENTS	PAGE	CONTENTS	PAGE
Ribbon carrier	66	Contact bracket (preliminary) for units with one-cycle cams	88
Typewheel (final)	68	Left contact gap	87
Typewheel (preliminary)	68	Left contact spring (preliminary) . . .	87
3. VARIABLE FEATURES	78	Operating bail springs	88
Automatic and Remote Control Non- interfering BLANK Tape Feed-Out Mechanism		Right contact gap	87
Blocking link	121	Swinger contact spring (preliminary) .	87
Blocking link torsion spring	121	Unshift-On-Space Mechanism	
Automatic and Remote Control Non- interfering LTRS and BLANK Tape Feed-Out Mechanisms		Unshift-on-space function blade	78
Adjusting lever	118	Unshift-on-space function blade spring	78
Drive arm spring	117	Blank Delete Mechanism	
Feed pawl and front check pawl springs.	115	Armature bail spring	137
Follower lever	118	Armature hinge	135
Front ratchet stop block	115	Armature stop	137
Punch slide latch	117	Blank contact	140
Ratchet return spring	116	Blank function blade	132
Rear check pawl	115	Blocking arm spring	139
Rear check pawl spring	115	Blocking lever	136
Reset bail latch	122	Blocking lever with shaft mounting plate	134
Reset bail latch spring	122	Contact assembly (earlier design) . . .	140
Reset bail triplever	119	Contact assembly (later design)	140
Tape length adjusting plate	120	Contact gap	140
Time-delay lever	116	Contact spring tension	140
Time-delay lever spring	116	Eccentric stud	138
Triplever extension spring	122	Feed pawl readjustment	133
Automatic Noninterfering LTRS and BLANK Tape Feed-Out Mechanisms		Function blade torsion spring	132
Latch lever	109	Latch lever torsion spring	136
Latch lever spring	109	Magnet assembly	135
Release arm	110	Open contact gap	140
Release arm spring	110	Print suppressor blocking arm	139
Release lever spring	109	Print suppressor stop	139
Safety latch	109	Swinger contact spring tension	140
Safety latch spring	109	Transfer shaft spring	137
Auxiliary Contact Assembly		Code Reading Contacts	
Auxiliary contact assembly	130	Contact bracket (preliminary) make type contacts	85
Normally closed contact	130	Contact bracket (preliminary) trans- fer type contacts	84
Normally open contact gap	130	Contact mounting bracket	83
Normally open contact spring	130	Contact mounting plate	83
Auxiliary Timing Contacts Mechanism		Marking contact backstops	81
Contact alignment	86	Marking contact spring (preliminary) .	81
Contact backstop (double contact assembly)	86	Spacing contact backstops (preliminary)	82
		Spacing contact springs (preliminary)	82
		Swinger contact springs (preliminary)	82

CONTENTS	PAGE
Contact Timing Measurements	
Code-reading contacts	91
LTRS-FIGS contacts	93
Timing contacts	92, 94
To zero test set	90, 94
End of Feed-Out Timing Contacts for Noninterfering LTRS and BLANK Tape Feed-Out Mechanism	
Contact assembly	123
Contact assembly mounting bracket . .	124
Contact spring gap	123
Contact swinger	123
Tape length adjusting plate	124
External Manual Interfering LTRS Tape Feed-Out Mechanism	
Arm.	127
Lever.	127
LTRS-FIGS Contact Mechanism	
Lower contact spring	89
Middle contact spring	89
Mounting bracket	89
Operating lever spring	89
Manual and Power Drive Backspace Mechanism	
Early Design	
Armature hinge	101
Armature upstop	101
Latch	105
Latch extension	104
Non-repeat latch	105
For Chadless Tape	
Feed pawl adjusting plate	97
Feed pawl eccentric	98
Rake	97
Return latch	98
For Chadless Tape (Early Design)	
Armature bail spring	106
Bell crank spring	106
Drive arm	103
Latch extension spring (power drive only)	106
Gear segment spring	106

CONTENTS	PAGE
Feed pawl spring	106
Latch spring	106
For Fully Perforated Tape	
Backspace pawl clearance (final)	99
Backspace pawl clearance (preliminary)	99
Backspace ratchet	99
Drive arm	102
Feed pawl eccentric	100
For Fully Perforated Tape (Early Design)	
Armature bail spring	107
Armature latch spring	107
Bell crank spring	107
Feed pawl spring	107
For Non-Adjustable Backspace Magnet Assembly (Latest Design)	
Armature spring	108
Latch extension	108
Magnet position	108
For Chadless and Fully Perforated Tape	
Final manual or power drive	108
Manual- and Solenoid-Operated Interfering LTRS Tape Feed-Out Mechanisms	
Drive shaft rear bearing	125
Triplever - manually operated	126
Triplever - solenoid operated	126
Triplever spring	126
Manual Print Suppression Mechanism	141
Multiple-Mounted Function Blade Contact Mechanism	
Normally closed contact	131
Normally open contact gap (A) (C) . . .	131
Print Suppression on Function Mechanism	
Print hammer stop - final	96
Print hammer stop - preliminary	96

CONTENTS	PAGE
Remote Control NonInterfering LTRS and BLANK Tape Feed-Out Mechanism	
Armature backstop	112
Armature hinge	111
Blocking bail spring	112
Blocking latch torsion spring	112
Drive bail spring	111
Latchlever	113
Latchlever spring	113
Magnet assembly	111
Mounting plate	111
Nonrepeat lever spring	112
Release arm	114
Release arm spring	114
Release lever	112
Release lever spring	113
Signal-Bell Contact Mechanism (Later Design)	
Contact bracket assembly	79
Function blade spring	79
Signal-bell contact	79
Tape Absence Contact Assembly	
Tape absence contact assembly position	80
Tape absence contacts cable assembly position	80
Tape absence contacts sensing finger end play	80
Tape absence long contact spring	80
Tape absence short contact spring position	80
Time Delay Motor Stop Mechanism	
Time delay clamp arm	143
Time delay contact assembly	144
Time delay contact gap	145
Time delay contact operating pawl spring	146
Time delay disabling device	148
Time delay drive pawl	147
Time delay eccentric follower drive arm spring	148
Time delay latch pawl spring	146
Time delay long contact spring	144
Time delay ratchet wheel tension	142
Time delay short contact spring	145
Timing Contact Mechanism (Operated by Selector)	
Alignment of operating lever with cam	129
Contact assembly position	129

CONTENTS	PAGE
"B" contact springs	128
"M" contact springs	128
Operating lever spring	129
"S" - "B" contact springs	128
"S" - "M" contact gap	128
Twin "B" contact springs	128
Twin springs ("M" contacts)	128
Vacuum Chad Removal (Send-Receive Typing Reperforator Set)	149
4. EARLIER DESIGN MECHANISMS	150
LTRS-FIGS Contact Mechanism (Early Design)	
Ltrs-figs contact test	154
Mounting bracket	154
Multiple Mounted Function Blade Contacts (Early Design)	
Normally closed contact gap	170
Normally closed contact spring	170
Normally open contact gap	170
Normally open contact spring	170
Noninterfering BLANK Tape Feed- Out Mechanism (Early Design)	
Armature hinge	158
Armature lock lever spring	163
Armature spring	158
Contacting mounting bracket	167
Contact lever	167
Contact lever spring	167
Contact pulse closure	167
Contact springs	166
Drive arm	155
Drive arm shaft rear bearing	155
Drive arm spring	165
Feed-out bracket	155
Feed-out pawl	157
Feed-out pawl spring	157
Feed-out switch	168
Feed-out switch (with pulse closure)	169
Inner ratchet check pawl	161
Inner ratchet check pawl spring	161
Kick-out arm	163
Latch arm spring	163
Lifter lever	160
Magnet mounting bracket	158
Metering feed pawl spring	160
Noninterfering clamp arm	162
Outer ratchet check pawl spring	160
Outer ratchet return spring	162

CONTENTS	PAGE
Release arm	156
Release arm latch	159
Release arm latch spring.	159
Release arm spring	165
Switch lever adjusting bracket	169
Switch lever spring.	168
Tape length adjusting plate.	164
Ribbon-Feed Mechanism for Chadless Tape and Fully Perforated Tape (Earlier Design)	
Ribbon feed drive arm spring.	151
Ribbon feed eccentric stud.	150
Ribbon feed pawl downstop eccentric	151
Ribbon feed pawl spring.	150
Ribbon feed reversing arm spring.	152
Ribbon ratchet wheel spring washers.	151
Ribbon reversing plate	152
Signal-Bell Contact Mechanism (Earlier Design)	
Contact bracket mounting assembly	153
Function blade spring	153

1. GENERAL

1.01 This section contains the specific requirements and adjustments for the 28 typing reperforators and tape printers.

1.02 This section has been revised to include recent engineering changes and additions, and to rearrange the text, so as to bring the section generally up-to-date. Since this is an extensive revision, marginal arrows ordinarily used to indicate changes have been omitted.

Note: Remove power from set or unit before making adjustment.

1.03 Maintenance procedures which apply only to mechanisms of a particular design, or to certain models of 28 typing reperforators and tape printers are so indicated in the titles of the paragraphs which contain these particular adjustment requirements.

1.04 The adjustments are arranged in a sequence that should be followed if a complete readjustment of the unit were undertaken. The tools and spring scales required to perform these adjustments are listed in the applicable section. After an adjustment is completed, be

sure to tighten any nuts or screws that are loosened. The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions and the angles at which scales should be applied when measuring spring tensions. If a part mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same number is replaced when the part is remounted.

1.05 Reference made to left or right, up or down, front or rear, etc apply to the unit in its normal operating position as viewed from the front.

1.06 When a requirement calls for a clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latch lever so that the clutch shoes release their tension on the clutch drum. When engaged, the clutch shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum.

Note: When the main shaft is rotated by hand, the clutch does not fully disengage upon reaching its stop position. In order to relieve drag and permit the main shaft to rotate freely, apply pressure on the lug of the clutch disc with a screwdriver to cause it to engage its latch lever and fully disengage the clutch.

1.07 To manually operate the typing reperforator or tape printer proceed as follows:

(1) Attach the TP312709 armature clip to the selector magnet armature by carefully placing the spring loop over the magnet terminal insulator and pressing down to engage the hook of the clip on the underside of the armature and releasing. The spring tension of the armature clip will hold the selector armature in the marking (attracted) position.

(2) While holding the selector magnet armature operated by means of the armature clip, use the handwheel, included with the special tools for servicing 28 teletypewriter apparatus, to manually rotate the main shaft in a counterclockwise direction until all the clutches are brought to their disengaged position.

(3) Fully disengage all clutches in accordance with 1.06, Note.

(4) Release the selector magnet armature momentarily to permit the selector clutch to engage.

- (5) Rotate the main shaft slowly until all the pushlevers have fallen to the left of their selecting levers.
- (6) Strip the pushlevers from their selector levers, which are spacing in the code combination of the character function that is being selected, and allow the pushlevers to move to the right.
- (7) The pushlevers and the selector levers move in succession starting with the inner lever No. 1 to the outer lever No. 5.
- (8) Continue to rotate the main shaft until all operations initiated by the selector action clear through the unit.

1.08 All electrical contact points should meet squarely. Contacts with the same diameter should not be out of alignment more than 25 per cent of the contact diameter. Check contacts for pitting and corrosion and clean or burnish them before making specified adjustments or tolerance measurement. Avoid sharp kinks or bends in the contact springs.

CAUTION: KEEP ALL ELECTRICAL CONTACTS FREE OF OIL AND GREASE.

1.09 Where a typing reperforator is used as a component of the 28 reperforator-transmitter unit or the 28 reperforator-transmitter base or the multiple reperforator base, refer to the applicable sections for the additional adjustments.




Figure 1 - 28 Typing Reperforator Unit
(Fully Perforated Tape)




Figure 2 - 28 Tape Printer Unit With Manual Interfering LTRS Tape Feed-Out Mechanism




Figure 3 - 28 Typing Reperforator Unit With Remote Control BLANK Tape Feed-Out Mechanism (Fully Perforated Tape)




Figure 4 - 28 Typing Reperforator Unit With Remote Control LTRS Tape Feed-Out Mechanism (Rear View)

2. BASIC UNITS

2.01 Selector and Function Clutch Mechanisms

Note: To facilitate adjustments, remove typing reperforator from base as follows:

- (1) For typing reperforator equipped with one-shaft mechanism, refer to section containing the disassembly and reassembly routines for the 28 typing reperforator.
- (2) For typing reperforator equipped with two-shaft mechanism, refer to section containing the disassembly and reassembly routines for the 28 perforator-transmitter base.

(A) CLUTCH SHOE LEVER

NOTE: THIS ADJUSTMENT SHALL BE MADE FOR BOTH SELECTOR AND FUNCTION CLUTCHES. TO CHECK

- (1) DISENGAGE CLUTCH. MEASURE CLEARANCE.
- (2) ALIGN HEAD OF CLUTCH DRUM MOUNTING SCREW WITH STOP LUG. ENGAGE CLUTCH. MANUALLY PRESS SHOE LEVER AND STOP LUG TOGETHER AND ALLOW TO SNAP APART. MEASURE CLEARANCE.

REQUIREMENT

CLEARANCE BETWEEN SHOE LEVER AND STOP LUG


MIN. 0.055 INCH---MAX. 0.085 INCH

GREATER WHEN CLUTCH ENGAGED (2) THAN WHEN DISENGAGED (1).

TO ADJUST

ENGAGE WRENCH OR SCREWDRIVER WITH LUG ON ADJUSTING DISC. ROTATE DISC WITH CLAMP SCREWS LOOSENED.

NOTE: AFTER MAKING ADJUSTMENT, DISENGAGE CLUTCH. REMOVE DRUM MOUNTING SCREW. ROTATE DRUM IN NORMAL DIRECTION AND CHECK TO SEE IF IT DRAGS ON SHOE. IF IT DOES, REFINES ADJUSTMENT.



(B) FUNCTION CLUTCH DRUM END PLAY (FOR ONE-SHAFT UNIT)


REQUIREMENT

WITH CLUTCH SHOE LEVER HELD IN DISENGAGED POSITION:

MIN. SOME --- MAX. 0.015 INCH
WHEN PLAY IS TAKEN UP TO MAKE CLEARANCE MAX.

TO ADJUST

WITH ITS MOUNTING SCREW LOOSENED, MOVE DRUM TO EXTREME FRONT POSITION. TIGHTEN DRUM MOUNTING SCREW. POSITION COLLAR WITH MOUNTING SCREW LOOSENED.



(C) FUNCTION CLUTCH DRUM END PLAY (FOR TWO-SHAFT UNIT)

REQUIREMENT

WITH FUNCTION CLUTCH DISENGAGED:



MIN. SOME --- MAX. 0.015 INCH
BETWEEN CAM SLEEVE AND COLLAR WHEN PLAY IS TAKEN UP TO MAKE CLEARANCE MAXIMUM.

TO ADJUST

POSITION COLLAR WITH MOUNTING SCREW LOOSENED.


2.02 Selector and Function Clutch Mechanisms continued

NOTE:
THESE SPRING TENSIONS APPLY TO BOTH CLUTCHES.



2.03 Selector Mechanism

NOTE: TO FACILITATE MAKING THE FOLLOWING ADJUSTMENTS, REMOVE THE RANGE FINDER AND SELECTOR MAGNET ASSEMBLIES. TO INSURE BETTER OPERATION, PULL A PIECE OF BOND PAPER BETWEEN THE ARMATURE AND THE POLE PIECES TO REMOVE ANY OIL OR FOREIGN MATTER THAT MAY BE PRESENT. MAKE CERTAIN THAT NO LINT OR PIECES OR PAPER REMAIN BETWEEN THE POLE PIECES AND ARMATURE.


SELECTOR ARMATURE**NOTE:**

THESE REQUIREMENTS NEED NOT BE MADE NOR CHECKED IF THE SELECTOR MAGNET BRACKET AND RECEIVING MARGIN REQUIREMENTS ARE MET.

- (1) REQUIREMENT
 CLEARANCE
 MIN. 0.025 INCH
 MAX. 0.045 INCH
 BETWEEN ARMATURE CLAMP STRIP AND
 MAGNET BRACKET CASTING.
- (2) REQUIREMENT
 OUTER EDGE OF ARMATURE SHOULD BE FLUSH WITHIN 0.015 INCH
 WITH OUTER EDGE OF POLE PIECES.
- (3) REQUIREMENT
 START LEVER SHALL DROP FREELY INTO ARMATURE EXTENSION SLOT.

TO ADJUST

POSITION ARMATURE SPRING ADJUSTING NUT TO HOLD ARMATURE FIRMLY AGAINST PIVOT EDGE OF CASTING. POSITION ARMATURE WITH MOUNTING SCREWS LOOSENED.

SELECTOR ARMATURE DOWNSTOP BRACKET
REQUIREMENT

REMOVE OIL SHIELD. WITH MAGNET DE-ENERGIZED, LOCK LEVER ON HIGH PART OF THEIR CAM, AND ARMATURE RESTING AGAINST ITS DOWNSTOP, CLEARANCE BETWEEN END OF ARMATURE AND LEFT EDGE OF LEFT POLE PIECE.

MIN. 0.025 INCH
 MAX. 0.030 INCH

TO ADJUST

POSITION DOWNSTOP BRACKET WITH MOUNTING SCREW LOOSENED.

2.04 Selector Mechanism continued

SELECTOR ARMATURE SPRING (PRELIMINARY)

(FOR UNITS EMPLOYING SELECTOR ARMATURE WITH SINGLE ANTI-FREEZE BUTTON ONLY).

REQUIREMENT

WITH LOCKING LEVERS AND START LEVER ON HIGH PART OF THEIR CAMS, SCALE APPLIED AS NEARLY VERTICAL AS POSSIBLE UNDER END OF ARMATURE EXTENSION. IT SHALL REQUIRE THE FOLLOWING TENSIONS TO MOVE ARMATURE TO MARKING POSITION:


0.060 AMPERES
MIN. 2-1/2 OZS. --- MAX. 3 OZS.

0.020 AMPERES AND 0.035 AMPERES
MIN. 1-1/2 OZS. --- MAX. 2 OZS.

NOTE:

THIS SPRING CAN BE ADJUSTED FOR MAXIMUM SELECTOR PERFORMANCE ONLY WHEN PRINTER IS CONNECTED TO THE SPECIFIC CIRCUIT OVER WHICH IT IS TO OPERATE UNDER SERVICE CONDITIONS. SINCE THERE ARE SEVERAL OPERATING SPEEDS AND SINCE CIRCUITS VARY WIDELY, IT IS IMPOSSIBLE TO ADJUST SPRING FOR MAXIMUM PERFORMANCE AT THE FACTORY. THE FOREGOING SPRING TENSION REQUIREMENT IS GIVEN TO PERMIT OPERATION PRIOR TO MEASUREMENT OF RECEIVING MARGINS. READJUSTMENT MADE TO OBTAIN SATISFACTORY RECEIVING MARGIN SHOULD NOT BE DISTURBED IN ORDER TO MEET REQUIREMENTS OF THIS ADJUSTMENT.

TO ADJUST
POSITION ADJUSTING NUT.



SELECTOR ARMATURE SPRING (FINAL)

REQUIREMENT


(SEE SELECTOR RECEIVING MARGIN ADJUSTMENT)

2.05 Selector Mechanism continued

SELECTOR ARMATURE SPRING (PRELIMINARY)


(FOR UNITS EMPLOYING SELECTOR ARMATURE WITH TWO ANTI-FREEZE BUTTONS ONLY).
REQUIREMENT

WITH LOCKING LEVERS AND START LEVER ON HIGH PART OF THEIR CAMS, SCALE APPLIED AS NEARLY VERTICAL AS POSSIBLE UNDER END OF ARMATURE EXTENSION. IT SHALL REQUIRE APPROXIMATELY THE FOLLOWING TENSIONS TO MOVE THE REAR ANTI-FREEZE BUTTON AGAINST THE MAGNET CORE:


SELECTOR ARMATURE SPRING (FINAL)

REQUIREMENT

WHEN A DISTORTION TEST SET IS AVAILABLE, THE SELECTOR ARMATURE SPRING TENSION SHOULD BE REFINED, IF NECESSARY, TO OBTAIN SATISFACTORY RECEIVING MARGINS. THE FRONT ANTI-FREEZE BUTTON MUST CONTACT THE MAGNET CORE WHEN THE MAGNET COILS ARE ENERGIZED.



2.06 Selector Mechanism continued



NOTE:
THE APPROPRIATE PRELIMINARY SELECTOR
ARMATURE SPRING TENSION ADJUSTMENT MUST
BE MADE PRIOR TO THIS ADJUSTMENT.

SELECTOR MAGNET BRACKET

(1) REQUIREMENT

SPACING LOCK LEVER ON HIGH PART OF CAM. ARMATURE
IN CONTACT WITH POLE PIECE. CLEARANCE BETWEEN END
OF ARMATURE EXTENSION AND SHOULDER ON SPACING
LOCK LEVER.

MIN. 0.020 INCH

MAX. 0.035 INCH

TO ADJUST

LOOSEN TWO MAGNET BRACKET MOUNTING SCREWS AND
ADJUSTING LINK CLAMP SCREW. POSITION MAGNET
BRACKET BY MEANS OF ADJUSTING LINK AND TIGHTEN
LINK CLAMP SCREW ONLY.

(2) REQUIREMENT


SPACING LOCK LEVER ON HIGH PART OF CAM. ARMATURE IN CONTACT WITH POLE
PIECE. SOME CLEARANCE BETWEEN UPPER SURFACE OF ARMATURE EXTENSION AND
LOWER SURFACE OF SPACING LOCK LEVER WHEN LOCK LEVER IS HELD DOWNWARD.

MAX. 0.003 INCH

TO ADJUST

POSITION UPPER END OF MAGNET BRACKET. TIGHTEN TWO MAGNET BRACKET
MOUNTING SCREWS. RECHECK REQUIREMENT (1).

2.07 Selector Mechanism continued





MARKING LOCK LEVER

MARKING LOCK LEVER SPRING


MARKING LOCK LEVER SPRING REQUIREMENT

LETTERS COMBINATION SELECTED, MAIN SHAFT ROTATED UNTIL SELECTOR CLUTCH IS DISENGAGED. PUSH SCALE APPLIED TO LOWER EXTENSION OF LOCK LEVER. MIN. 1-1/2 OZS. MAX. 3 OZS. TO START LEVER MOVING.

2.08 Selector Mechanism continued



2.09 Selector Mechanism continued




2.10 Selector Mechanism continued

(A) RANGE SCALE KNOB
REQUIREMENT

WITH RANGE SCALE KNOB TURNED TO EITHER END OF RACK, ZERO MARK ON SCALE SHOULD BE WITHIN 3 POINTS OF SCRIBED LINE ON RANGE SCALE PLATE AND THE INNER TEETH OF THE KNOB AND SECTOR ASSEMBLY ARE ENGAGED.

TO ADJUST

LOOSEN RANGE SCALE MOUNTING NUT, DISENGAGE RANGE SCALE GEAR FROM RACK TEETH REPOSITION RANGE SCALE AND TIGHTEN MOUNTING NUT.




(B) SELECTOR CLUTCH STOP ARM
REQUIREMENT

RANGE SCALE SET AT 60. SELECTOR CLUTCH DISENGAGED. ARMATURE IN MARKING POSITION. CLUTCH STOP ARM SHALL ENGAGE CLUTCH SHOE LEVER BY APPROXIMATELY FULL THICKNESS OF SHOE LEVER.

TO ADJUST

POSITION STOP ARM ON STOP ARM BAIL WITH CLAMP SCREW LOOSENED.

2.11 Selector Mechanism continued



START LEVER SPRING REQUIREMENT
 LATCH LEVER SPRING UNHOOKED. STOP ARM BAIL IN INDENT OF ITS CAM. RANGE SCALE SET AT 60.
 MIN. 2-1/2 OZS.
 MAX. 4-1/2 OZS.
 TO START STOP ARM MOVING.

NOTE:
 TYPING REPERFORATORS OPERATING WITH 30 MILLIAMPERE SELECTOR COIL CURRENT WITH COILS IN SERIES SHALL HAVE RECEIVING MARGIN TESTS RUN AT, AND MEET THE REQUIREMENTS FOR 100 WPM SPEED, 60 MILLIAMPERE SELECTOR COILS IN PARALLEL. TESTING AT 30 MILLIAMPERE IS NOT REQUIRED.

SELECTOR RECEIVING MARGIN

REQUIREMENT (FOR UNITS EMPLOYING ARMATURE WITH ONE ANTI-FREEZE BUTTON)

WHEN A SIGNAL DISTORTION TEST SET IS USED FOR DETERMINING THE RECEIVING MARGINS OF THE SELECTOR, AND WHERE THE CONDITION OF THE COMPONENTS IS EQUIVALENT TO THAT OF NEW EQUIPMENT, THE RANGE AND DISTORTION TOLERANCES BELOW SHOULD BE MET.

REQUIREMENT (FOR UNITS EMPLOYING ARMATURE WITH TWO ANTI-FREEZE BUTTONS)


WHEN A DISTORTION TEST SET IS AVAILABLE, THE SELECTOR ARMATURE SPRING TENSION SHOULD BE REFINED, IF NECESSARY, TO OBTAIN SATISFACTORY RECEIVING MARGINS. THE FRONT ANTI-FREEZE BUTTON MUST CONTACT THE MAGNET CORE WHEN THE MAGNET COILS ARE ENERGIZED.

TO ADJUST: REFINE THE SELECTOR ARMATURE SPRING.

SELECTOR RECEIVING MARGIN MINIMUM REQUIREMENTS

<u>CURRENT</u>	<u>SPEED IN W.P.M.</u>	<u>POINTS RANGE WITH ZERO DISTORTION</u>	<u>PERCENTAGE OF MARKING AND SPACING BIAS TOLERATED</u>	<u>END DISTORTION TOLERATED WITH SCALE AT BIAS OPTIMUM SETTING</u>
0.060 AMP. (WINDINGS PARALLEL)	60	72	40	35
	75			
	100			
0.020 AMP. (WINDINGS SERIES)	60	72	40	35
	75			
0.035 AMP. (WINDINGS SERIES)	65 (45.5 BAUD)	72	40	35
	106 (75.0 BAUD)			

2.12 Selector and Function Mechanisms



2.13 Function Mechanisms


(A) FOLLOWER LEVER

REQUIREMENT

WITH FOLLOWER LEVER ON HIGH PART OF CAM

- (1) CLEARANCE BETWEEN RELEASE LEVER AND MAIN TRIP LEVER
MIN. 0.010 INCH---MAX. 0.030 INCH


- (2) SOME CLEARANCE BETWEEN MAIN TRIP LEVER AND DOWNSTOP BRACKET.
TO ADJUST
BY MEANS OF PRY POINT, POSITION ADJUSTING ARM OF FOLLOWER LEVER
WITH LOCK NUT LOOSENED.



- (C2) MAIN TRIP LEVER SPRING (LATER DESIGN)
REQUIREMENT
WITH FUNCTION CLUTCH
TRIPPED
MIN. 1 OZ.---MAX. 4 OZS.
TO START MAIN TRIP LEVER MOVING.

NOTE: IT MAY BE NECESSARY TO REMOVE RIBBON-FEED MECHANISM WHEN CHECKING THIS TENSION.



- (C1) MAIN TRIP LEVER SPRING (EARLIER DESIGN)
REQUIREMENT
WITH FOLLOWER LEVER ON HIGH
PART OF TRIP CAM
MIN. 2-1/2 OZS.---MAX. 4-1/2 OZS.
TO START TRIP LEVER MOVING.




- (B1) ADJUSTING ARM SPRING (EARLIER DESIGN)
REQUIREMENT
WITH FOLLOWER LEVER ON HIGH
PART OF TRIP CAM AND MAIN TRIP
LEVER HELD AWAY FROM ADJUSTING
ARM
MIN. 2-1/2 OZS.---MAX. 4 OZS.
TO START ADJUSTING ARM MOVING.

- (B2) ADJUSTING ARM TORSION SPRING (LATER DESIGN)
REQUIREMENT
WITH FOLLOWER LEVER ON LOW
PART OF TRIP CAM AND MAIN
TRIP LEVER HELD AWAY FROM
ADJUSTING ARM
MIN. 1 OZ.---MAX. 4 OZS.
TO START ADJUSTING ARM MOVING.

2.14 Function Mechanisms continued



2.15 Selector Mechanisms



PUNCH SLIDE LATCH SPRINGS
TO CHECK

SELECT LETTERS CODE COMBINATION (12345). POSITION ROCKER BAIL TO EXTREME LEFT. STRIP PUSH LEVERS FROM SELECTING LEVERS.

REQUIREMENT


FOR ONE-SHAFT UNIT

MIN. 1 OZS. --- MAX. 3 OZS.
TO START LATCH MOVING.

FOR TWO-SHAFT UNIT

MIN. 3/4 OZS. --- MAX. 2 OZS.
TO START LATCH MOVING.

2.16 Punch Mechanisms



PERFORATOR POSITION REQUIREMENT

WITH LETTERS COMBINATION SELECTED AND FUNCTION CLUTCH JUST TRIPPED.
 MIN. 0.015 INCH --- MAX. 0.045 INCH

CLEARANCE BETWEEN THE CLOSEST LATCH LEVER AND ASSOCIATED PUNCH SLIDE.

TO ADJUST

LOOSEN (FRICTION TIGHT) REAR FRAME MOUNTING SCREWS (AND PIVOT LOCATING PLATE CLAMP SCREW IF THE TYPING UNIT IS USED ON THE PUNCH), THE ANCHOR BRACKET MOUNTING SCREWS, PLACE TIP OF SCREWDRIVER BETWEEN HEX HEAD SCREW AND ITS CLEARANCE HOLE RIM AND PRY UP OR DOWN. TIGHTEN SCREWS. TIGHTEN PIVOT LOCATING PLATE CLAMP SCREW ONLY, AS THE NEXT ADJUSTMENT WILL BE TO OBTAIN CLEARANCE BETWEEN TYPEWHEEL AND PUNCH.


2.17 Punch Mechanisms continued

PERFORATOR POSITION

- (1) REQUIREMENT - (FOR TYPING REPERFORATOR WITH SPRING RETRACTED PUNCH UNIT) WITH UNIT IN STOP POSITION AND TYPEWHEEL IN THE LETTERS FIELD. CLEARANCE BETWEEN THE LETTER "Z" ON THE TYPEWHEEL AND THE TOP OF THE STRIPPER PLATFORM. MIN. 0.090 INCH --- MAX. 0.110 INCH
- (2) REQUIREMENT - (FOR TYPING REPERFORATOR WITH POWER RETRACTED PUNCH UNIT) WITH UNIT IN STOP POSITION AND TYPEWHEEL IN THE FIGURES FIELD. CLEARANCE BETWEEN THE FIGURE "5" ON THE TYPEWHEEL AND THE TOP OF THE STRIPPER PLATFORM. MIN. 0.075 INCH --- MAX. 0.095 INCH


TO ADJUST

REMOVE RIBBON FROM CARRIER. POSITION PERFORATOR WITH TWO MOUNTING SCREWS, ADJUSTING CLAMP PIVOT SCREW AND ANCHOR BRACKET SCREW LOOSENED. CHECK RESET BAIL TRIP LEVER REQUIREMENT FOR SOME CLEARANCE AND ADJUST IF NECESSARY.




2.18 Punch Mechanisms continued


NOTE: BEFORE PROCEEDING WITH THE PUNCH MECHANISM ADJUSTMENTS, CHECK THE ROCKER BAIL CAM FOLLOWER ROLLER ADJUSTMENT AND LOOSEN THE PUNCH SLIDE DOWNSTOP MOUNTING NUT AND GUIDE MOUNTING STUD.



(A) TOGGLE BAIL ECCENTRIC (PRELIMINARY) REQUIREMENT
 THE INDENT (HIGH SIDE OF ECCENTRIC) SHALL BE IN ITS UPPERMOST POSITION.
 TO ADJUST WITH THE TOGGLE ECCENTRIC SHAFT LOCK NUT FRICTION TIGHT POSITION ECCENTRIC.




(B) TOGGLE OPERATING ARM
 *(1) REQUIREMENT
 TRIP FUNCTION CLUTCH AND ROTATE MAIN SHAFT UNTIL THE UPPER ROCKER BAIL ROLLER IS ON HIGH PART OF ITS CAM.
 MIN. SOME---MAX. 0.009 INCH
 CLEARANCE BETWEEN FEED PAWL STUD AND THE TP159926 GAUGE.
 (2) CLEARANCE BETWEEN ARM AND OSCILLATING SHAFT BEARING HUB.
 ---MIN. 0.002 INCH---MAX. 0.015 INCH
 WITH PLAY TAKEN UP IN DIRECTION TO MAKE CLEARANCE MAXIMUM.
 TO ADJUST WITH LOCKSCREW FRICTION TIGHT, POSITION TOGGLE BAIL AND OPERATING ARM.



(C) PERFORATOR DRIVE LINK SPRING REQUIREMENT
 MIN. 3-1/2 OZS.
 MAX. 8 OZS.
 TO PULL SPRINGS TO INSTALLED LENGTH.

*AFTER FEED PAWL ADJUSTMENT HAS BEEN MADE, IF PUNCH PIN PENETRATION AND FEED PAWL REQUIREMENTS ARE MET, THIS REQUIREMENT SHOULD BE CONSIDERED FULFILLED.

2.19 Punch Mechanisms for Chadless Tape




2.20 Punch Mechanisms for Fully Perforated Tape

(A) PUNCH PIN PENETRATION REQUIREMENT

- (1) WITH THE LETTERS COMBINATION SELECTED, FUNCTION CLUTCH ENGAGED. ROTATE MAIN SHAFT UNTIL ALL PUNCH PINS ARE INTO OR ABOVE THE TAPE APERTURE IN PUNCH BLOCK. WITH THE TP159926 GAUGE IN POSITION
MIN. 0.050 INCH
CLEARANCE BETWEEN FEED PAWL STUD AND THE GAUGE.
- (2) WITH LETTERS COMBINATION SELECTED, FUNCTION CLUTCH ENGAGED. ROTATE MAIN SHAFT UNTIL ALL PUNCH PINS HAVE CLEARED THE PUNCH BLOCK. WITH THE TP159926 GAUGE IN POSITION
MAX. 0.080 INCH
CLEARANCE BETWEEN FEED PAWL STUD AND GAUGE.

TO ADJUST

REFINE THE TOGGLE BAIL ECCENTRIC ADJUSTMENT KEEPING THE INDENT TO THE RIGHT OF A VERTICAL CENTERLINE THROUGH THE SHAFT.



(C) PUNCH SLIDE DOWNSTOP POSITION REQUIREMENT

WITH FUNCTION CLUTCH DISENGAGED AND LATCHED. PLAY TAKEN UP TOWARD THE TOP CLEARANCE BETWEEN BOTH THE FRONT AND REAR PUNCH SLIDES AND THE DOWNSTOP PLATE
MIN. SOME---MAX. 0.008 INCH
ALL OTHER PUNCH SLIDES SHALL HAVE SOME CLEARANCE.

NOTE: TO CHECK FOR SOME CLEARANCE, PLACE UNIT IN STOP POSITION, TRIP FUNCTION TRIP MECHANISM AND LATCHES, THE PUNCH SLIDES SHALL MOVE FULLY TO THEIR OPERATED POSITION.

TO ADJUST

WITH UNIT IN STOP POSITION, LOOSEN THE TWO DOWNSTOP PLATE MOUNTING LOCK NUTS AND LOCATE THE DOWNSTOP PLATE TO MEET THE REQUIREMENT.

NOTE: ADJUSTMENTS ON THIS PAGE DO NOT APPLY TO TAPE PRINTER.

(B) PUNCH SLIDE GUIDE REQUIREMENT

THE PUNCH SLIDES SHOULD ALIGN WITH THEIR CORRESPONDING PUNCH PINS AND BE FREE OF BINDS AFTER TIGHTENING THE GUIDE MOUNTING STUDS. EACH PUNCH SLIDE SHOULD RETURN FREELY AFTER BEING PUSHED IN NOT MORE THAN 1/16 INCH.

TO ADJUST

POSITION THE GUIDE WITH ITS MOUNTING STUDS FRICTION TIGHT.


2.21 Function Mechanism continued

RESET BAIL TRIP LEVER
REQUIREMENT

- (1) MANUALLY SELECT BLANK COMBINATION. MANUALLY ROTATE RESET BAIL TRIP LEVER. THE PUNCH SLIDE RESET BAIL SHALL TRIP BEFORE THE FUNCTION CLUTCH IS TRIPPED.
- (2) WITH FUNCTION AND SELECTOR CLUTCHES DIS-ENGAGED AND LATCHED, THE PUNCH SLIDE RESET BAIL SHALL FULLY ENGAGE THE PUNCH SLIDE LATCHING SURFACE WHEN PLAY IN PARTS IS TAKEN UP IN DIRECTION TO MAKE THE ENGAGEMENT THE LEAST.

TO ADJUST

- (1) WITH TRIP LEVER EXTENSION LOCK SCREW FRICTION TIGHT AND LETTERS COMBINATION SELECTED, POSITION RESET BAIL AGAINST PUNCH SLIDES. TAKE UP PLAY BETWEEN RESET BAIL AND TRIP LEVER IN A COUNTER CLOCKWISE DIRECTION. POSITION TRIP LEVER BY MEANS OF ITS PRY POINT.
- (2) RECHECK REQUIREMENT (1) ABOVE AND REFINE ADJUSTMENT IF NECESSARY.



2.22 Punch Mechanism continued

(A) LATCH LEVER CLEARANCE
TO CHECK

PUNCH SLIDES SHALL BE IN SPACING POSITION.

REQUIREMENT


WITH FUNCTION CLUTCH DISENGAGED AND LATCHED. CLEARANCE BETWEEN PUNCH SLIDE AND PUNCH SLIDE LATCH

MIN. 0.008 INCH --- MAX. 0.020 INCH

FOR SLIDE HAVING THE LEAST CLEARANCE.

TO ADJUST

ROTATE THE RESET BAIL ECCENTRIC SHAFT WITH ITS LOCK NUT LOOSENED. KEEP INDENTATION IN ECCENTRIC ABOVE HORIZONTAL CENTER OF SHAFT.



(B) FEED PAWL (PRELIMINARY)
TO CHECK

FEED WHEEL OIL HOLE SHALL BE IN UP POSITION.

REQUIREMENT

FUNCTION CLUTCH DISENGAGED, INDENTATION IN DETENT LEVER ECCENTRIC AT RIGHT ANGLE TO LEVER, DETENT ROLLER IN CONTACT WITH RATCHET WHEEL, HIGH PART OF FEED PAWL ECCENTRIC TO THE RIGHT OF ITS LOCK SCREW. THE FEED PAWL SHALL ENGAGE THE FIRST TOOTH BELOW A HORIZONTAL CENTERLINE THROUGH THE RATCHET WHEEL WITH NO PERCEPTIBLE CLEARANCE.

TO ADJUST

ROTATE THE FEED PAWL ECCENTRIC WITH LOCK SCREW LOOSENED.

NOTE:

THIS ADJUSTMENT IS RELATED TO FEED HOLE SPACING AND TWO ADJUSTMENTS SHALL BE MADE AT THE SAME TIME.

2.23 Punch Mechanism for Chadless Tape continued

FEED HOLE SPACING (PRELIMINARY)
REQUIREMENT


INDENT OF DIE WHEEL ECCENTRIC STUD POINTING DOWNWARD.

TO ADJUST

POSITION DIE WHEEL ECCENTRIC STUD WITH LOCK NUT LOOSENED.

<p>NOTE: ADJUSTMENTS ON THIS PAGE DO NOT APPLY TO TAPE PRINTER.</p>
--

NOTE: BEFORE PROCEEDING WITH THE FOLLOWING ADJUSTMENTS, CHECK BOTH TAPE GUIDE SPRING ADJUSTMENTS.




TO ADJUST

- (1) WITH TAPE REMOVED FROM PUNCH MECHANISM, LOOSEN DIE WHEEL ECCENTRIC STUD LOCK-NUT. ADJUST DIE WHEEL SO THAT IT JUST BINDS ON FEED WHEEL. BACK OFF ECCENTRIC SO DIE WHEEL IS JUST FREE (CHECK FREENESS THROUGH 3 OR 4 REVOLUTIONS). KEEP INDENT OF ECCENTRIC STUD BELOW HORIZONTAL CENTERLINE OF STUD.
- (2) REFINE ABOVE ADJUSTMENT TO MEET REQUIREMENT (2). IF NECESSARY, MOVE INDENT OF DIE WHEEL ECCENTRIC STUD TOWARD FEED WHEEL TO DECREASE CHARACTER SPACING AND AWAY FROM FEED WHEEL TO INCREASE CHARACTER SPACING.
CAUTION: WITH TAPE REMOVED FROM PUNCH MECHANISM, MAKE SURE DIE WHEEL DOES NOT BIND.
- (3) RECHECK REQUIREMENT (1). IF IT IS NOT MET, DIE WHEEL ECCENTRIC HAS BEEN OVER ADJUSTED.
REFINE.

NOTE:

FIRST THROUGH FIFTH HOLES IN GAUGE ARE SAME SIZE AS CODE IN TAPE (0.072 INCH DIAMETER). BUT SIXTH HOLE IN GAUGE IS LARGER (0.086 INCH). THIS ARRANGEMENT ALLOWS ± 0.007 INCH VARIATION IN 5 INCHES.

2.24 Punch Mechanism for Chadless Tape continued



DETENT LEVER

REQUIREMENT


A PIECE OF TAPE CONTAINING NINE FEED HOLES FOLLOWED BY A LETTERS COMBINATION PERFORATED ON THE PERFORATOR MUST CONFORM TO THE TP156011 TAPE GAUGE. THE LATERAL CENTERLINE THROUGH THE CODE HOLES IN THE TAPE SHOULD COINCIDE WITH A LATERAL CENTERLINE THROUGH THE HOLES IN THE GAUGE.

NOTE: ADJUSTMENTS ON THIS PAGE DO NOT APPLY TO TAPE PRINTER.

TO ADJUST

ROTATE THE DETENT ECCENTRIC CLOCKWISE TO MOVE THE FEED HOLES TOWARD THE HINGED EDGE OF THE CODE HOLES AND COUNTERCLOCKWISE TO MOVE THE FEED HOLES TOWARD THE TRAILING EDGE OF THE CODE HOLES. TIGHTEN THE ECCENTRIC LOCK NUT AND RE-FINE THE FEED PAWL ADJUSTMENT.

RECHECK FEED PAWL ADJUSTMENT.



2.25 Punch Mechanism for Chadless Tape continued


NOTE: IF UNIT IS EQUIPPED WITH TAPE GUIDE (EARLIER DESIGN), LOCKNUT MUST BE LOOSENED BEFORE FEED HOLE LATERAL ALIGNMENT ADJUSTMENT IS MADE.

FEED HOLE LATERAL ALIGNMENT REQUIREMENT


WITH REPERFORATOR OPERATING UNDER POWER, OBTAIN A PIECE OF TAPE CONTAINING A SERIES OF NINE BLANK CODE COMBINATIONS FOLLOWED BY A LTRS COMBINATION. OPEN CHADS SO CODE HOLES ARE VISIBLE AND PLACE TAPE OVER TP156011 TAPE GAUGE WITH LTRS COMBINATION FEED HOLES ENGAGING FEED PINS. LARGE HOLES IN GAUGE ARE SAME DIAMETER AS CIRCULAR PORTION OF CODE HOLES IN TAPE. SMALL HOLES IN GAUGE SERVE AS GUIDE FOR GAUGING. CIRCULAR PORTION OF CODE HOLES IN TAPE SHALL BE CONCENTRIC WITH HOLES IN TAPE GAUGE.

TO ADJUST

LOOSEN ADJUSTING SCREW LOCKNUT AND POSITION ADJUSTING SCREW. TO MOVE HOLES OF GAUGE AWAY FROM REFERENCE EDGE OF TAPE, MOVE FEED WHEEL TOWARD FRONT PLATE OF PUNCH MECHANISM BY ROTATING ADJUSTING SCREW COUNTERCLOCKWISE. TO MOVE HOLES OF GAUGE TOWARD REFERENCE EDGE OF TAPE, MOVE FEED WHEEL TOWARDS BACKPLATE OF PUNCH MECHANISM BY ROTATING ADJUSTING SCREW CLOCKWISE. TIGHTEN LOCKNUT. REFINE DETENT LEVER ADJUSTMENT TO ALIGN LATERAL CENTERLINES OF CODE HOLES AND FEED HOLES, IF REQUIRED.



NOTE: ADJUSTMENTS ON THIS PAGE DO NOT APPLY TO TAPE PRINTER.



2.26 Punch Mechanism for Chadless Tape continued

(A)

PUNCH SLIDE SPRING

REQUIREMENT


LETTERS COMBINATION SET UP. FUNCTION CLUTCH TRIPPED. PUNCH SLIDES IN SELECTED POSITION UNDER PUNCH PINS.

MIN. 2 1/4 OZS.

MAX. 3 1/4 OZS.

TO START EACH SLIDE MOVING,

PUNCH PINS




NOTE: ADJUSTMENTS ON THIS PAGE DO NOT APPLY TO TAPE PRINTER.

RETRACTOR BAIL COMPRESSION SPRING

RETRACTOR BAIL

PUNCH BLOCK



(B)

RETRACTOR BAIL SPRINGS

(1) REQUIREMENT (COMPRESSION SPRINGS ONLY)

WITH FUNCTION CLUTCH DISENGAGED AND TENSION SPRINGS UNHOOKED:

MIN. 15 OZS.


MAX. 32 OZS.

TO LIFT RETRACTOR BAIL AWAY FROM LOWER GUIDE OR PUNCH BLOCK.

LOWER GUIDE

PUNCH PINS

(LEFT SIDE VIEW)



(2) REQUIREMENT (COMBINED COMPRESSION AND TENSION SPRINGS)

UNDER THE SAME CONDITIONS AS REQUIREMENT (1) ABOVE, EXCEPT WITH TENSION SPRINGS HOOKED*

MIN. 4 LBS. --- MAX. 5 LBS.

*TO FACILITATE REHOOKING TENSION SPRINGS, PLACE PUNCH PINS IN UPPER-MOST POSITION.

2. 27 Punch Mechanism for Chadless Tape continued

(B) TAPE GUIDE ASSEMBLY SPRING
REQUIREMENT


THE TAPE GUIDE ASSEMBLY SHOULD BE FREE TO RETURN TO REST AGAINST THE TAPE GUIDE BLOCK AFTER A MIN. 16 OZS.

IS USED TO PULL THE TAPE GUIDE ASSEMBLY AWAY FROM THE BLOCK.

TO ADJUST

REPLACE SPRING IF REQUIREMENT IS NOT MET.

IF THE TAPE GUIDE ASSEMBLY IS NOT FREE TO RETURN, REPOSITION THE TAPE GUIDE ASSEMBLY MOUNTING POST TO FREE THE TAPE GUIDE ASSEMBLY.



(A) TAPE GUIDE SPRING (TAPE GUIDE)
REQUIREMENT

CLUTCH DISENGAGED AND TAPE THREADED THROUGH THE PUNCH ASSEMBLY, IT SHOULD REQUIRE

MIN. 1-1/4 OZS.


MAX. 2-1/4 OZS.

TO JUST MOVE THE SPRING AWAY FROM THE TAPE.

TO ADJUST

BEND THE SPRING.

NOTE: IN ORDER TO CHECK THIS SPRING TENSION ON UNITS EQUIPPED WITH BACKSPACE MECHANISM, IT IS NECESSARY TO REMOVE SEVERAL PARTS. IT SHOULD NOT BE CHECKED UNLESS THERE IS REASON TO BELIEVE THAT REQUIREMENTS CANNOT BE MET.



(C) TAPE GUIDE SPRING (PUNCH BLOCK)

(1) REQUIREMENT

WITH THE TAPE REMOVED FROM THE PUNCH BLOCK THE TAPE GUIDE SPRING SHOULD REST AGAINST THE CLEARANCE SLOT IN THE BLOCK IN A SYMMETRICAL MANNER.


(2) REQUIREMENT

WITH TAPE IN THE PUNCH BLOCK AND THE PERFORATOR OPERATING UNDER POWER, THE SPRING SHOULD NOT DISTORT THE EDGE OF THE TAPE.

TO ADJUST


BEND THE SPRING AND POSITION IT WITH ITS MOUNTING SCREW LOOSENED.

TAPE GUIDE SPRING



2.28 Punch Mechanism for Fully Perforated Tape continued

NOTE: INDENTATIONS OF THE FEED WHEEL FULLY PUNCHED OUT BY THE FEED PUNCH



NOTE: BEFORE PROCEEDING WITH THE FOLLOWING ADJUSTMENTS, CHECK BOTH TAPE GUIDE SPRING ADJUSTMENTS.

FEED HOLE SPACING

(1) REQUIREMENT

WITH TAPE SHOE BLOCKED AWAY FROM FEED WHEEL, FEED PAWL AND DETENT DISENGAGED, AND TAPE REMOVED FROM THE PUNCH MECHANISM, FEED WHEEL SHALL ROTATE FREELY. (SHALL BE CHECKED THROUGH 3 OR 4 REVOLUTIONS.)

(2) REQUIREMENT

PERFORATE SIX SERIES OF NINE BLANK CODE COMBINATIONS FOLLOWED BY A LTRS COMBINATION. PLACE TAPE OVER SMOOTH SIDE OF TP156011 TAPE GAUGE SO THAT CIRCULAR PORTION OF FIRST NO. 2 CODE HOLE IS CONCENTRIC WITH FIRST (0.072 INCH) HOLE OF TAPE GAUGE. (SEE NOTE BELOW.) SECOND THROUGH FIFTH HOLES IN TAPE GAUGE SHALL BE VISIBLE THROUGH NO. 2 CODE HOLES IN TAPE. CIRCULAR PORTION OF SIXTH NO. 2 CODE HOLE IN TAPE SHALL BE ENTIRELY WITHIN (0.086 INCH) HOLE OF TAPE GAUGE.

TO ADJUST

- (1) WITH TAPE REMOVED FROM PUNCH MECHANISM, LOOSEN DIE WHEEL ECCENTRIC STUD LOCKNUT. ADJUST DIE WHEEL SO THAT IT JUST BINDS ON FEED WHEEL. BACK OFF ECCENTRIC SO DIE WHEEL IS JUST FREE (CHECK FREENESS THROUGH 3 OR 4 REVOLUTIONS). KEEP INDENT OF ECCENTRIC STUD BELOW HORIZONTAL CENTERLINE OF STUD.
- (2) REFINE ABOVE ADJUSTMENT TO MEET REQUIREMENT (2). IF NECESSARY, MOVE INDENT OF DIE WHEEL ECCENTRIC STUD TOWARD FEED WHEEL TO DECREASE CHARACTER SPACING AND AWAY FROM FEED WHEEL TO INCREASE CHARACTER SPACING.
CAUTION: WITH TAPE REMOVED FROM PUNCH MECHANISM, MAKE SURE DIE WHEEL DOES NOT BIND.
- (3) RECHECK REQUIREMENT (1). IF IT IS NOT MET, DIE WHEEL ECCENTRIC HAS BEEN OVERADJUSTED. REFINE.

NOTE: FIRST THROUGH FIFTH HOLES IN GAUGE ARE SAME SIZE AS CODE IN TAPE (0.072 INCH DIAMETER). BUT SIXTH HOLE IN GAUGE IS LARGER (0.086 INCH). THIS ARRANGEMENT ALLOWS ±0.007 INCH VARIATION IN 5 INCHES.

2.29 Punch Mechanism for Fully Perforated Tape continued

NOTE:
(INDENTATION OF THE FEED WHEEL FULLY PUNCHED OUT BY
THE FEED PUNCH)

**NOTE: IF UNIT IS EQUIPPED WITH TAPE GUIDE (EARLIER DESIGN), LOCKNUT MUST
BE LOOSENED BEFORE FEED HOLE LATERAL ALIGNMENT ADJUSTMENT IS MADE.**


FEED WHEEL INDENTATION ALIGNMENT**(1) REQUIREMENT**

WHEN A PIECE OF TAPE IS PERFORATED WITH A SERIES OF BLANK CODE COMBINATIONS, THE INDENTATIONS OF THE FEED WHEEL SHALL BE FULLY PUNCHED OUT.

TO ADJUST

RIGHT OR LEFT, ROTATE THE DETENT LEVER ECCENTRIC STUD CLOCKWISE TO MOVE THE FEED WHEEL PERFORATIONS TOWARD THE LEADING EDGE OF THE CODE HOLES, AND COUNTERCLOCKWISE TO MOVE THE FEED WHEEL PERFORATIONS TOWARD THE TRAILING EDGE OF THE CODE HOLES. REFINE THE FEED PAWL ADJUSTMENT.

FRONT TO REAR, LOOSEN THE LOCK NUT ON THE ADJUSTING SCREW AND TURN THE SCREW CLOCKWISE TO MOVE TAPE TOWARD REFERENCE EDGE (REAR), AND COUNTERCLOCKWISE TO MOVE THE TAPE AWAY FROM REFERENCE EDGE (FRONT).



2.30 Punch Mechanism for Fully Perforated Tape continued
(Indentations of the Feed Wheel Between Feed Holes.)

NOTE: BEFORE PROCEEDING WITH THE FOLLOWING ADJUSTMENTS, CHECK BOTH TAPE GUIDE SPRING TENSIONS.

NOTE: ADJUSTMENTS ON THIS PAGE DO NOT APPLY TO TAPE PRINTER.

FEEED HOLE SPACING (FINAL) *(SEE NOTE BELOW)

REQUIREMENT

- (1) WITH TAPE SHOE BLOCKED AWAY FROM THE FEED WHEEL, THE FEED PAWL AND DETENT DISENGAGED, AND TAPE REMOVED FROM THE PUNCH MECHANISM, THE FEED WHEEL SHALL ROTATE FREELY. (CHECK THROUGH 3 OR 4 ROTATIONS).
- (2) PERFORATE SIX SERIES OF (9) "BLANK" COMBINATIONS FOLLOWED BY (1) "LETTERS" COMBINATION. PLACE TAPE OVER SMOOTH SIDE OF THE TP156011 TAPE GAUGE SO CIRCULAR PORTION OF THE FIRST NUMBER TWO CODE HOLE IN TAPE IS CONCENTRIC WITH THE FIRST (0.072) HOLE OF TAPE GAUGE. (SEE NOTE). THE NEXT FOUR 0.072 HOLES IN TAPE GAUGE SHALL BE VISIBLE THROUGH THE NUMBER TWO CODE HOLES IN TAPE AND CIRCULAR PORTION OF THE LAST (SIXTH) NUMBER TWO CODE HOLE IN TAPE SHALL BE ENTIRELY WITHIN THE 0.086 DIA. HOLE OF TAPE GAUGE.

NOTE: THE FIRST FIVE HOLES IN GAUGE ARE THE SAME SIZE AS CODE HOLES IN TAPE (0.072 INCH DIAMETER) BUT THE SIXTH HOLE IN GAUGE IS LARGER THAN THE FIRST FIVE (0.086 INCH DIAMETER). THIS ARRANGEMENT ALLOWS ± 0.007 INCH VARIATION IN FIVE (5) INCHES.

TO ADJUST



- (1) WITH TAPE REMOVED FROM PUNCH MECHANISM, LOOSEN DIE WHEEL ECCENTRIC STUD LOCK NUT AND ADJUST DIE WHEEL SO THAT IT JUST BINDS ON FEED WHEEL, BACK OFF ECCENTRIC SO DIE WHEEL IS JUST FREE (CHECK FREENESS THROUGH 3 OR 4 ROTATIONS). KEEP INDENT OFF ECCENTRIC STUD BELOW THE HORIZONTAL CENTER LINE OF STUD.
- (2) CHECK TEN CHARACTERS PER INCH REQUIREMENT AND REFINE FEED WHEEL DIE WHEEL CLEARANCE ADJUSTMENT TO MEET THE REQUIREMENT BY MOVING INDENT OF DIE WHEEL ECCENTRIC STUD TOWARD FEED WHEEL TO DECREASE CHARACTER SPACING AND AWAY FROM FEED WHEEL TO INCREASE THE CHARACTER SPACING.

CAUTION: WITH THE TAPE REMOVED FROM THE PUNCH MECHANISM, BE SURE THE DIE WHEEL DOES NOT BIND.

- (3) WITH THE TAPE SHOE AWAY FROM THE FEED WHEEL, THE FEED PAWL AND DETENT DISENGAGED, AND THE TAPE REMOVED FROM THE PUNCH MECHANISM, THE FEED WHEEL SHALL ROTATE FREELY. FAILURE TO MEET THIS REQUIREMENT INDICATES THE DIE WHEEL ECCENTRIC HAS BEEN OVER-ADJUSTED. TO MEET THIS REQUIREMENT, REFINE THE ADJUSTMENT.

* **NOTE:** THE ADJUSTMENTS ON THIS PAGE ARE FOR FIVE LEVEL FULLY PERFORATED TAPES, WITH INDENTATION OF FEED WHEEL BETWEEN FEED HOLES.

- (1) 11/16 INCH WIDE TAPE WITH PRINTING BETWEEN FEED HOLES.
- (2) 7/8 INCH WIDE TAPE HAVING A MARGIN FOR PRINTING AT TOP OF TAPE.
- (3) 7/8 INCH WIDE TAPE HAVING A MARGIN FOR PRINTING AT BOTTOM OF TAPE.
(SEE FIGURE ON FOLLOWING PAGE)



2.31 Punch Mechanism For Fully Perforated Tape continued
(Indentation of Feed Wheel Between The Feed Holes)

DETENT


REQUIREMENT *(SEE NOTE BELOW)

WITH THE UNIT OPERATING UNDER POWER, THE INDENTATIONS OF THE FEED WHEEL SHALL BE CENTRALLY LOCATED BETWEEN TWO FULLY PERFORATED FEED HOLES, AS GAUGED BY EYE.

TO ADJUST

LOOSEN THE DETENT LEVER ECCENTRIC STUD LOCK NUT AND TURN THE ECCENTRIC STUD CLOCKWISE TO MOVE THE INDENTATION TOWARD THE LEADING EDGE OF THE FEED HOLE AND COUNTERCLOCKWISE TO MOVE THE INDENTATION TOWARD THE TRAILING EDGE. TIGHTEN THE LOCK NUT AND RE-CHECK THE FEED PAWL ADJUSTMENT.

NOTE: ADJUSTMENTS ON THIS PAGE DO NOT APPLY TO TAPE PRINTER.



FEED HOLE LATERAL ALIGNMENT REQUIREMENT

WITH THE UNIT OPERATING UNDER POWER, THE INDENTATIONS OF THE FEED WHEEL SHOULD BE ON A CENTERLINE BETWEEN THE FULLY PERFORATED FEED HOLES, AS GAUGED BY EYE.

TO ADJUST

WITH THE ADJUSTING SCREW LOCK NUT LOOSE, TURN THE ADJUSTING SCREW CLOCKWISE TO MOVE THE INDENTATION TOWARD THE REAR AND COUNTERCLOCKWISE TO MOVE THE INDENTATIONS TOWARD THE FRONT.

*** NOTE:**


THE ADJUSTMENTS ON THIS PAGE ARE FOR FIVE-LEVEL FULLY PERFORATED TAPES, WITH INDENTATION OF FEED WHEEL BETWEEN FEED HOLES.

- (1) 11/16 INCH WIDE TAPE WITH PRINTING BETWEEN FEED HOLES.
- (2) 7/8 INCH WIDE TAPE HAVING A MARGIN FOR PRINTING AT TOP OF TAPE.
- (3) 7/8 INCH WIDE TAPE HAVING A MARGIN FOR PRINTING AT BOTTOM OF TAPE.

2.32 Punch Mechanism For Fully Perforated Tape continued


(A) PUNCH SLIDE SPRING REQUIREMENT

LETTERS COMBINATION SET UP AND PUNCH SLIDES IN SELECTED POSITION.
 MIN. 2-1/4 OZS.
 MAX. 3-1/4 OZS.
 TO START EACH SLIDE MOVING.



NOTE: ON UNITS EQUIPPED WITH BACKSPACE MECHANISM, IT IS NECESSARY TO REMOVE SEVERAL PARTS IN ORDER TO CHECK THIS SPRING TENSION. IT SHOULD NOT BE CHECKED UNLESS THERE IS GOOD REASON TO BELIEVE THAT IT DOES NOT MEET ITS REQUIREMENTS.

NOTE: ADJUSTMENTS (B), (C) AND (D) ON THIS PAGE DO NOT APPLY TO TAPE PRINTER.



(B) TAPE GUIDE ASSEMBLY SPRING REQUIREMENT

THE TAPE GUIDE ASSEMBLY SHALL BE FREE TO RETURN TO REST AGAINST THE TAPE GUIDE BLOCK.
 MIN. 16 OZS.

TO PULL THE TAPE GUIDE ASSEMBLY AWAY FROM THE BLOCK. TO ADJUST

IF THE SPRING DOES NOT MEET THE REQUIREMENT, REPLACE THE SPRING. IF THE TAPE GUIDE ASSEMBLY IS NOT FREE TO RETURN, REPOSITION THE TAPE GUIDE ASSEMBLY MOUNTING POST TO FREE THE TAPE GUIDE ASSEMBLY.

(C) TAPE GUIDE SPRING (TAPE GUIDE) REQUIREMENT

CLUTCH DISENGAGED AND TAPE THREADED THROUGH THE PUNCH ASSEMBLY, IT SHOULD REQUIRE

MIN. 1-1/4 OZS. ---MAX. 2-1/4 OZS.

TO JUST MOVE THE SPRING AWAY FROM THE TAPE.

TO ADJUST

BEND THE SPRING.

(D) TAPE GUIDE SPRING (PUNCH BLOCK)

(1) REQUIREMENT



WITH TAPE REMOVED FROM THE PUNCH BLOCK THE TAPE GUIDE SPRING SHOULD REST AGAINST THE CLEARANCE SLOT IN THE BLOCK IN A SYMMETRICAL MANNER.

(2) REQUIREMENT



WITH TAPE IN THE PUNCH BLOCK AND THE REPERFORATOR OPERATING UNDER POWER, THE SPRING SHOULD NOT DISTORT THE EDGE OF THE TAPE.

TO ADJUST

BEND THE SPRING AND POSITION IT WITH ITS MOUNTING SCREW LOOSENED.



2.33 Punch Mechanism continued




2.34 Punch Mechanism continued

(A) TAPE SHOE TORSION SPRING
REQUIREMENT

MIN. 13 OZS. --- MAX. 18 OZS.
TO MOVE TAPE FROM FEED WHEEL.

NOTE: ADJUSTMENTS
ON THIS PAGE DO
NOT APPLY TO TAPE
PRINTER.



(B) TAPE GUIDE
TO CHECK

ROTATE FEED WHEEL UNTIL OIL HOLE IS UPWARD.
CENTER TAPE SHOE AND TAPE GUIDE. HOLD TAPE
GUIDE DOWNWARD.

REQUIREMENT

CLEARANCE BETWEEN ADJUSTING PLATE AND
BACKSTOP POST

MIN. 0.002 INCH
MAX. 0.008 INCH


TO ADJUST

POSITION ADJUSTING PLATE WITH ITS
CLAMP SCREW LOOSENED.

(C) TAPE DEPRESSOR SLIDE SPRING
REQUIREMENT


ROCKER BAIL IN ITS EXTREME LEFT POSITION
MIN. 1-1/2 OZS. --- MAX. 2-1/2 OZS.

TO START DEPRESSOR SLIDE MOVING.



2.35 Punch Mechanism continued

NOTE: ADJUSTMENTS ON THIS PAGE DO NOT APPLY TO TAPE PRINTER.





TAPE GUIDE (EARLY DESIGN)
REQUIREMENT

WITH TAPE GUIDE UNDER AND IN CONTACT WITH V SHAPED PROJECTION OF DIE PLATE*
MIN. 0.008 INCH -- MAX. 0.015 INCH
CLEARANCE BETWEEN GUIDE AND TAPE PLATFORM.

TO ADJUST
WITH MOUNTING SCREW FRICTION TIGHT, PLACE 0.010 INCH FLAT GAUGE BETWEEN GUIDE AND TAPE PLATFORM. PRESS GUIDE DOWN AND TO LEFT. TIGHTEN MOUNTING SCREW WHILE HOLDING FEED WHEEL ADJUSTING SCREW STATIONARY BY MEANS OF AN ALLEN WRENCH.

TAPE GUIDE SPRING (ON UNITS NOT EQUIPPED WITH TAPE GUIDE ADJUSTING PLATE)
REQUIREMENT
MIN. 8 OZS. TO START TAPE GUIDE BAIL MOVING UPWARD.

*GUIDE IS CONSIDERED "IN CONTACT" WITH PROJECTION WHEN 0.0015 INCH GAUGE CANNOT BE INSERTED BETWEEN THEM.



TAPE GUIDE (LATEST DESIGN)
REQUIREMENT


CLEARANCE UNDER THE TAPE GUIDE.
MIN. 0.008 INCH
MAX. 0.015 INCH

TO ADJUST
WITH MOUNTING SCREW FRICTION TIGHT, POSITION THE TAPE GUIDE. KEEP THE GUIDE AGAINST THE FRONT PLATE OF THE PUNCH.

2.36 Function Mechanism

(A) FUNCTION CLUTCH RELEASE LEVER SPRING REQUIREMENT

TRIP FUNCTION CLUTCH, ROTATE MAIN SHAFT UNTIL RELEASE LEVER IS RESET ON MAIN TRIP LEVER
MIN. 5 OZS.---MAX. 8 OZS.
TO START RELEASE LEVER MOVING.



(B) RELEASE LEVER DOWNSTOP BRACKET REQUIREMENT

WITH FUNCTION CLUTCH TRIPPED, ROTATE SHAFT UNTIL CLEARANCE BETWEEN FUNCTION CLUTCH DISC STOP LUG AND CLUTCH TRIP LEVER IS AT A MINIMUM. RELEASE LEVER RESTING AGAINST DOWNSTOP BRACKET. CLEARANCE BETWEEN FUNCTION CLUTCH DISC STOP LUG AND TRIP LEVER
MIN. 0.002 INCH---MAX. 0.045 INCH

TO ADJUST

REMOVE TAPE GUARD. WITH DOWNSTOP BRACKET MOUNTING SCREWS FRICTION TIGHT, POSITION BRACKET. RECHECK FOR SOME CLEARANCE BETWEEN TRIP LEVER EXTENSION AND LEFT END OF SLOT IN RELEASE LEVER DOWNSTOP BRACKET.

2.37 Typing Mechanism

(A) PUSH BAR OPERATING BLADE (PRELIMINARY)
TO CHECK

MANUALLY SELECT LTRS CODE COMBINATION (12345) ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS. HOLE NO. 2 AND 3 BELL CRANKS AGAINST STOP POST.


REQUIREMENT

OPERATING BLADE PARALLEL TO (NOT NECESSARILY FLUSH) TO TOP OF NO. 2 AND 3 PUSH BAR LATCHING SURFACES.

TO ADJUST

WITH ITS MOUNTING SCREWS FRICTION TIGHT PRY TRANSFER MOUNTING BRACKET ALL THE WAY TO THE RIGHT.

ADD OR REMOVE SHIMS UNDER THE REAR LEG OF THE OPERATING BLADE. PLACE EXTRA SHIMS ON REAR MOUNTING SCREW BETWEEN BLADE AND FLAT WASHER.



(B) PUSH BAR OPERATING BLADE (FINAL)
(1) TO CHECK

MANUALLY SELECT LTRS CODE COMBINATION (12345). ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS. MANUALLY SEAT PUSH BARS IN DETENTED POSITION. IN BAR WHICH IS NEAREST LEFT EDGE OF BLADE, TAKE UP PLAY TO LEFT AND REAR, AND THEN RELEASE.

REQUIREMENT

CLEARANCE BETWEEN BAR AND LEFT EDGE OF BLADE.

MIN. 0.015 INCH---MAX. 0.030 INCH

(2) REQUIREMENT

SOME CLEARANCE BETWEEN RIGHT EDGE OF BLADE AND PUSH BARS WHEN PLAY IN BARS HAS BEEN TAKEN UP TO RIGHT AND RELEASED.

(3) REQUIREMENT

WITH UNIT IN STOP POSITION, SOME CLEARANCE BETWEEN RIGHT EDGE OF BLADE AND BARS WHEN PLAY IN BARS HAS BEEN TAKEN UP TO RIGHT AND RELEASED.

TO ADJUST

WITH MOUNTING SCREWS LOOSENED, POSITION OPERATING BLADE IN ELONGATED HOLES.

(C) BELL CRANK SPRINGS (5)
TO CHECK

SELECT LTRS CODE COMBINATION (12345). ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS.


REQUIREMENT

MIN. 1 OZ.---MAX. 3 OZS. TO START PUSH BAR MOVING.

NOTE:

CHECK ALL FIVE SPRINGS.

- NO. 2 PUSH BAR
- NO. 1 PUSH BAR
- NO. 4 PUSH BAR
- NO. 5 PUSH BAR
- LTRS PUSH BAR
- FIGS. PUSH BAR
- NO. 3 PUSH BAR
- PUSH BAR OPERATING BLADE




(TOP VIEW)

NOTE:

IT MAY BE NECESSARY TO REFINE THIS ADJUSTMENT AFTER ROCKER BAIL PILOT STUD ADJUSTMENT.

2.38 Typing Mechanism continued



(A) ROCKER BAIL PILOT STUD

TO CHECK


SELECT BLANK COMBINATION. POSITION ROCKER BAIL THROUGH A COMPLETE CYCLE TO INSURE THE CLEARANCE IS A MINIMUM.

REQUIREMENT

CLEARANCE BETWEEN FUNCTION BOX REAR PLATE AND PUSH BAR OPERATING BLADE
 MIN. 0.005 INCH---MAX. 0.020 INCH
 AT A POINT IN THE CYCLE AND WHEN PLAY IS TAKEN UP TO MAKE CLEARANCE MINIMUM.

TO ADJUST

POSITION ROCKER BAIL PILOT STUD IN ELONGATED HOLE WITH LOCK NUT LOOSENED.



(B) FUNCTION CLUTCH LATCH LEVER SPRING


REQUIREMENT

WITH FUNCTION CLUTCH TURNED TO STOP POSITION AND LATCH LEVER UNLATCHED
 MIN. 12 OZS. ---MAX. 15 OZS.
 TO START LATCH LEVER MOVING.

2.39 Typing Mechanism continued

FUNCTION BOX
REQUIREMENT

MANUALLY SELECT LETTERS CODE COMBINATION (12345). ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS, AND PUNCH SLIDES ARE DISENGAGED FROM LATCHES. THE TOP OF THE OPERATING BLADE SHALL BE
FLUSH --- MAX. 0.020 INCH




BELOW THE TOPS OF THE NO. 2 AND 3 PUSHBARS. TAKE UP PLAY IN PUSHBARS IN A DOWNWARD DIRECTION THEN RELEASE.

NOTE:

WHEN UNIT IS MOUNTED AS PART OF THE KEYBOARD PERFORATOR TRANSMITTER, IT MAY BE NECESSARY TO REFINE THE ADJUSTMENT WITHIN ITS LIMITS TO INCREASE OPERATING MARGINS OF THE UNIT.


TO ADJUST

WITH THREE MOUNTING SCREWS IN REAR PLATE AND ONE MOUNTING SCREW IN FRONT PLATE LOOSENED, POSITION FUNCTION BOX BY MEANS OF PRY POINT. CHECK POSITION OF BELL CRANK.

NOTE:

ON UNITS EQUIPPED WITH TWO-PIECE TRIP BRACKET, SET ABOVE ADJUSTMENT IN CENTER OF ITS RANGE AND TIGHTEN SCREWS. LOOSEN TWO SCREWS WHICH MOUNT GUIDE TO BRACKET AND POSITION GUIDE TO MEET ABOVE REQUIREMENT.

2.40 Typing Mechanism continued



TRANSFER MOUNTING BRACKET TO CHECK

MANUALLY SELECT BLANK CODE COMBINATION. ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS.


REQUIREMENT

WITH PUNCH SLIDES LATCHED, CLEARANCE BETWEEN BELL CRANK AND STOP POST
 MAX. 0.018 INCH*
 AT BELL CRANK WHERE CLEARANCE IS MAXIMUM WHEN BELL CRANK WITH MINIMUM CLEARANCE IS TOUCHING POST.

TO ADJUST


WITH MOUNTING SCREWS FRICTION TIGHT, PRY TRANSFER MOUNTING BRACKET TO LEFT UNTIL CLOSEST BELL CRANK TOUCHES POST. TIGHTEN MOUNTING SCREWS AND CHECK REQUIREMENT.

CAUTION: BELL CRANK THAT YIELDS MOST SHALL NOT YIELD MORE THAN 0.007 INCH MEASURED AT POST.



*NOTE: REMOVAL OF FUNCTION BLADES WILL FACILITATE MEASURING CLEARANCE.

2.41 Typing Mechanism continued



2. 42 Typing Mechanism continued


(B)

LTRS ARM ASSEMBLY SPRING

REQUIREMENT

WITH ARM ASSEMBLIES IN FIGS POSITION

MIN. 1-1/2 OZS. ---MAX. 3-1/2 OZS.
TO PULL SPRING TO INSTALLED LENGTH.



(A)

LTRS - FIGS YIELD ARMS (CONTINUED FROM PREVIOUS PAGE)

(2) TO CHECK

MANUALLY PLACE ARM ASSEMBLIES IN FIGS POSITION.
HOLD LTRS - FIGS BELL CRANK AGAINST RIGHT EDGE OF STOP POST.

REQUIREMENT


MIN. SOME ---MAX. 0.006 INCH*
CLEARANCE BETWEEN BELL CRANK AND FIGS EXTENSION ARM.

(C)

LTRS EXTENSION ARM SPRING

REQUIREMENT

WITH ARM ASSEMBLIES IN FIGS POSITION AND LTRS EXTENSION ARM MANUALLY HELD IN POSITION
MIN. 5 OZS. ---MAX. 8 OZS.
TO PULL SPRING TO INSTALLED LENGTH.




***NOTE:**
REMOVAL OF FUNCTION BLADES WILL FACILITATE MEASURING CLEARANCE.

TO ADJUST

LOOSEN CLAMP SCREWS IN BOTH LTRS-FIGS YIELD ARMS. PLACE ARM ASSEMBLIES IN LTRS POSITION. HOLD LTRS-FIGS BELL CRANK AGAINST LEFT SIDE OF STOP POST, AND BY MEANS OF PRY POINT, POSITION LTRS YIELD ARM TO MEET CLEARANCE REQUIREMENT UNDER (A) (1) FIG. ON PREVIOUS PAGE. TIGHTEN LTRS YIELD ARM CLAMP SCREW. PLACE ARM ASSEMBLIES IN FIGS POSITION AND BY MEANS OF PRY POINT, POSITION FIGS YIELD ARM TO MEET REQUIREMENT UNDER (2) ABOVE. TIGHTEN FIGS YIELD ARM CLAMP SCREW. **CAUTION:** ARM ASSEMBLIES MAY CHANGE POSITION DURING ADJUSTMENT. AS TIGHTENING OF SCREWS MAY AFFECT ADJUSTMENT, RECHECK REQUIREMENTS.

2.43 Typing Mechanism continued



(A) LIFTER ARM TO CHECK

TRIP FUNCTION CLUTCH. MOVE ROCKER BAIL TO EXTREME LEFT POSITION AND OBSERVE TRAVEL OF LIFTER ROLLER ON RIGHT DWELL SURFACE. MOVE ROCKER BAIL TO EXTREME RIGHT POSITION AND OBSERVE TRAVEL OF ROLLER ON LEFT DWELL SURFACE.

REQUIREMENT

APPROXIMATELY EQUAL TRAVEL ON EACH DWELL SURFACE.

TO ADJUST*


LOOSEN LOCK PLATE SCREW UNTIL FRICTION TIGHT. WITH ECCENTRIC SCREW LOCK NUT FRICTION TIGHT, POSITION LIFTER ARM ON LIFTER. TIGHTEN LOCK PLATE SCREW. DO NOT TIGHTEN LOCK NUT.

(B) LIFTER ARM ECCENTRIC SCREW REQUIREMENT

WITH FUNCTION CLUTCH DISENGAGED
 (1) CLEARANCE BETWEEN CLOSEST PROJECTION OF BELL CRANKS AND ASSOCIATED LTRS-FIGS FUNCTION BLADE PROJECTION
 MIN. 0.008 INCH---MAX. 0.020 INCH
 (2) MIN. 0.005 INCH CLEARANCE FOR FUNCTION BLADES OTHER THAN LTRS-FIGS IF UNIT IS SO EQUIPPED


TO ADJUST

POSITION LIFTER ARM ECCENTRIC SCREW WITH LOCK NUT LOOSENED.



*NOTE:
 REMOVE TIMING CONTACTS IF UNIT IS SO EQUIPPED.

2.44 Typing Mechanism continued




LOCK LEVER REQUIREMENT

- (1) WITH LETTERS CODE COMBINATION (12345) SELECTED AND ROCKER BAIL TO EXTREME LEFT, TOGGLE LINKAGE SHOULD MOVE THROUGH POINT WHERE TOGGLE LINK AND LOCK LEVER ARE IN STRAIGHT LINE WITHOUT RAISING LIFTER.
- (2) WITH TOGGLE LINK AND LOCK LEVER IN STRAIGHT LINE, CLEARANCE BETWEEN TOGGLE LINK AND LIFTER PIN (WITH RETAINING RING REMOVED) MIN. SOME---MAX. 0.015 INCH.

TO ADJUST POSITION LOCK LEVER ON LOCK ARM ASSEMBLY WITH CLAMP SCREW FRICTION TIGHT.

NOTE: TO AVOID INTERFERENCE WITH LOCK LEVER, IT MAY BE NECESSARY TO MOVE HIGH PART OF CORRECTING DRIVE LINK ECCENTRIC BUSHING ABOVE HORIZONTAL CENTERLINE.

NO. 5 PULSE BEAM SPRING REQUIREMENT
 MIN. 10 OZS.---MAX. 15 OZS.
 TO PULL SPRING TO LENGTH OF 7/16 INCH.




2.45 Typing Mechanism continued

LOCK LEVER TRIP POSTREQUIREMENT

AS ROCKER BAIL APPROACHES EXTREME RIGHT POSITION, LOCK LEVER TOGGLE LINKAGE SHOULD BREAK AND LIFTER ROLLER SHOULD DROP ONTO RIGHT DWELL SURFACE.



TO ADJUST

BY MEANS OF PRY POINTS, POSITION LOCK LEVER TRIP POST WITH CLAMP SCREW LOOSENED.



(REAR VIEW)

2.46 Typing Mechanism continued



2.47 Typing Mechanism continued

(A) OSCILLATING DRIVE LINK

TO CHECK


POSITION ROCKER BAIL TO ITS EXTREME LEFT.

REQUIREMENT

SECTOR MOUNTING STUD, TOGGLE PIVOT SCREW AND OSCILLATING DRIVE BAIL MOUNTING SCREW SHOULD APPROXIMATELY LINE UP.

TO ADJUST

POSITION OSCILLATING DRIVE LINK BY MEANS OF ITS ECCENTRIC BUSHING.



(B)


OSCILLATING DRIVE BAIL
REQUIREMENT

WITH "BLANK" COMBINATION SELECTED, ROTATE MAIN SHAFT, TAKING UP AXIAL PLAY IN TYPE WHEEL SHAFT TOWARD FRONT OF UNIT, THE AXIAL CORRECTOR ROLLER SHALL ENTER THE FIRST NOTCH OF THE SECTOR CENTRALLY.

TO ADJUST

LOOSEN OSCILLATING BAIL ADJUSTING SCREW. SELECT "BLANK" COMBINATION. POSITION OSCILLATING BAIL BY MEANS OF ITS ELONGATED MOUNTING HOLE SO CORRECTOR ROLLER ENTERS FIRST NOTCH OF SECTOR WHEN ROCKER BAIL MOVES TO ITS EXTREME LEFT POSITION. HOLD CORRECTOR ROLLER FIRMLY IN FIRST NOTCH AND TAKE UP PLAY IN OSCILLATING BAIL LINKAGE BY APPLYING A FORCE TO OSCILLATING BAIL TOWARD REAR OF UNIT. TIGHTEN THE OSCILLATING BAIL ADJUSTING SCREW.

2. 48 Typing Mechanism continued




(B) **ECCENTRIC SHAFT**

DETENT LEVER SPRINGS (6)

MIN. 7 OZS. ---MAX. 10 OZS.
 TO START DETENT LEVER MOVING.



NOTE:

CHECK ALL 6 SPRINGS. THERE ARE TWO ON THE AXIAL POSITIONING MECHANISM AND FOUR ON THE ROTARY POSITIONING MECHANISM.



(TOP VIEW OF SPRINGS ON AXIAL POSITIONING MECHANISM)

2.49 Typing Mechanism continued



2.50 Typing Mechanism continued

AXIAL CORRECTOR (NON-YIELDING)

(1) TO CHECK

SELECT BLANK CODE COMBINATION. TRIP FUNCTION CLUTCH AND MOVE ROCKER BAIL TO EXTREME LEFT.

REQUIREMENT


ROLLER ON AXIAL CORRECTING PLATE FIRMLY SEATED IN FIRST NOTCH OF AXIAL SECTOR.

(2) TO CHECK

SELECT LETTERS CODE COMBINATION (12345). TRIP FUNCTION CLUTCH AND MOVE ROCKER BAIL TO EXTREME LEFT.


REQUIREMENT

ROLLER ON AXIAL CORRECTING PLATE FIRMLY SEATED IN FOURTH NOTCH OF AXIAL SECTOR.



TO ADJUST

- (1) LOOSEN THE TWO DRIVE LINK ADJUSTING SCREWS. FIRMLY SEAT THE AXIAL CORRECTOR ROLLER INTO THE FIRST NOTCH OF THE SECTOR BY MANUALLY APPLYING AND HOLDING THIS POSITION FOR THE NEXT PART OF THE ADJUSTMENT.
- (2) APPLY A MANUAL PRESSURE ON THE DRIVE LINK SUCH THAT THE SLOT IN THE LINK WILL BOTTOM AGAINST THE BUSHING OF THE ROCKER BAIL.
- (3) MAINTAINING PRESSURE AT THESE TWO PLACES, TIGHTEN ADJUSTING SCREWS.




TYPWHEEL RACK CLEARANCE REQUIREMENT

WITH UNIT IN LETTERS FIELD, FUNCTION CLUTCH DISENGAGED.

MAX. 0.015 INCH

CLEARANCE BETWEEN IDLER GEAR AND RACK AT THE CLOSEST POINT WITH ALL THE PLAY TAKEN UP IN A DIRECTION TO MAKE THE CLEARANCE MAXIMUM. THERE SHALL BE SOME CLEARANCE THROUGHOUT THE TRAVEL OF THE RACK.



TO ADJUST


WITH MOUNTING SCREW LOOSENED, POSITION IDLER GEAR ECCENTRIC SHAFT BY MEANS OF THREE ADJUSTING HOLES. CHECK RACK THROUGHOUT ITS TRAVEL FOR BINDS.

2.51 Typing Mechanism continued

CORRECTOR DRIVE LINK (YIELDING)
EXTENSION SPRING TENSION

REQUIREMENT

WITH ALL SPACING CODE COMBINATION SELECTED, THE FUNCTION CLUTCH TRIPPED, AND THE ROCKER BAIL IN ITS EXTREME LEFT POSITION, PLACE A 32 OZS. SPRING HOOK ON THE END OF THE CORRECTOR AXIAL PLATE. IT SHOULD TAKE MIN. 16 OZS. ---MAX. 32 OZS. TO MOVE THE ROLLER FROM THE NOTCH IN THE SECTOR.

AXIAL CORRECTOR (YIELDING)

REQUIREMENT

WITH BLANK CODE COMBINATION SELECTED, FUNCTION CLUTCH TRIPPED AND ROCKER BAIL IN ITS EXTREME LEFT POSITION, THE AXIAL CORRECTOR ROLLER SHOULD SEAT IN THE FIRST SECTOR NOTCH AND THERE SHOULD BE

MIN. 0.005 INCH

BETWEEN THE ENDS OF THE SLOT AND THE SPRING POST. CHECK BOTH SIDES AND CHECK SEATING IN FOURTH NOTCH (LETTERS SELECTION). TURN THE RETAINING RING FASTENING THE DRIVE LINK EXTENSION TO THE CORRECTOR PLATE TO CHECK THE MINIMUM REQUIREMENT.

TO ADJUST

LOOSEN TWO DRIVE LINK ADJUSTING SCREWS. POSITION DRIVE LINK TO MEET THE REQUIREMENT AND RETIGHTEN THE SCREWS.

2.52 Typing Mechanism continued

ROTARY CORRECTOR MESH

(1) TO CHECK

WITH CLAMP ARM LOOSENED, "FIGURE 9" COMBINATION SELECTED (NO. 4 AND NO. 5 PULSE MARKING IN THE FIGURES POSITION) AND THE ROCKER BAIL IN ITS EXTREME LEFT POSITION.

REQUIREMENT

THE SECOND TOOTH FROM THE TOP OF THE ROTARY OUTPUT RACK (WITH THE PUSH BARS MANUALLY DETENTED) SHOULD SEAT FIRMLY BETWEEN THE LOBES OF THE ROTARY CORRECTOR ARM.

TO ADJUST


LOOSEN CLAMP ARM SCREW AND ECCENTRIC BUSHING LOCK NUT. WITH THE PIVOT OF THE CORRECTOR ARM TO THE RIGHT OF THE CENTER OF THE BUSHING, POSITION THE ROTARY CORRECTOR. TIGHTEN BUSHING LOCK NUT. DO NOT TIGHTEN CLAMP ARM SCREW AT THIS POINT.

(2) TO CHECK



CHECK ENGAGEMENT IN A SIMILAR MANNER AS IN (1) ABOVE WITH THE FIFTH TOOTH (NO. 3 AND NO. 4 MARKING IN FIGURES POSITION), NINTH TOOTH (NO. 4 PULSE MARKING IN THE LETTERS POSITION), SIXTEENTH TOOTH (NO. 3 AND NO. 5 PULSE MARKING IN THE LETTERS FIELD).

TO ADJUST

REFINE ADJUSTMENT UNDER (1) ABOVE.



2.53 Typing Mechanism continued



ROTARY CORRECTOR ARM
TO CHECK

WITH THE LETTERS COMBINATION SELECTED IN THE LETTERS FIELD AND THE ROCKER BAIL IN ITS EXTREME LEFT POSITION.

REQUIREMENT

THE ROTARY CORRECTOR ARM SHALL SEAT FIRMLY IN THE TYPEWHEEL RACK.

MIN. SOME----MAX. 0.006 INCH
END PLAY BETWEEN CLAMP ARM AND BUSHING,
WITH UNIT IN THE STOP POSITION.

TO ADJUST

(UNITS EQUIPPED WITH NON-YIELDING AXIAL CORRECTOR)


AS THE ROCKER BAIL APPROACHES THE EXTREME LEFT, MEASURE CLEARANCE BETWEEN THE AXIAL CORRECTOR ROLLER AND THE SECTOR NOTCH. WHEN CLEARANCE IS

MIN. SOME----MAX. 0.005 INCH


POSITION ROTARY CORRECTOR ARM FINGER TIGHT AGAINST TYPEWHEEL RACK, AND TIGHTEN CORRECTING CLAMP ARM SCREW.

(UNITS EQUIPPED WITH A YIELDING AXIAL CORRECTOR)


AS THE ROCKER BAIL APPROACHES THE EXTREME LEFT AND THE SPRING POST OF THE AXIAL CORRECTOR STARTS TO LEAVE THE END OF ITS SLOT, POSITION THE ROTARY CORRECTOR ARM FINGER TIGHT AGAINST TYPEWHEEL RACK AND TIGHTEN CORRECTING CLAMP ARM SCREW.



2.54 Typing Mechanism for Chadless Tape continued



2.55 Typing Mechanism for Chadless Tape continued



(A) TYPEWHEEL (PRELIMINARY)
TO CHECK

SELECT "H" CODE COMBINATION (--3-5). PLACE ROCKER BAIL TO EXTREME LEFT. THE ROTARY CORRECTOR ARM FIRMLY ENGAGED.

REQUIREMENT

TYPEWHEEL ALIGNED SO THAT FULL CHARACTER IS PRINTED UNIFORMLY AND $6 \pm 1/4$ CODE HOLE SPACES BEHIND ITS PERFORATED CODE HOLES.

TO ADJUST

POSITION TYPEWHEEL WITH LOCK NUT LOOSENED. CHECK PRINTING BY MANUALLY LIFTING ACCELERATOR TO LATCHED POSITION AND RELEASING IT.

NOTE:

FOR BEST RESULTS IT MAY BE NECESSARY TO PROCEED TO THE NEXT ADJUSTMENT THEN COME BACK AND REFINE THE ABOVE.

(B) TYPEWHEEL (FINAL)
REQUIREMENT


ALL CHARACTERS SHALL BE LEGIBLE AND $6 \pm 1/4$ CODE HOLE SPACES BEHIND THE PERFORATED CODE HOLES WITH UNIT OPERATING UNDER POWER.

TO ADJUST

REFINE THE TYPEWHEEL POSITION WITH ITS LOCK NUT LOOSENED.

NOTE:

FOR BEST RESULTS IT MAY BE NECESSARY TO MAKE THE PRINT HAMMER ADJUSTMENT AND THEN REFINE THIS ADJUSTMENT.



(C) PRINT HAMMER
REQUIREMENT

WHEN OPERATING UNDER POWER, PRINT HAMMER AND TYPEWHEEL ALIGNED SO AS TO OBTAIN BEST QUALITY OF PRINTING.


TO ADJUST

POSITION PRINT HAMMER SHAFT WITH LOCK NUT LOOSENED.

NOTE:

IT MAY BE NECESSARY TO REMAKE TYPEWHEEL ADJUSTMENT (ABOVE) AND THEN REFINE THIS ADJUSTMENT.

2.56 Typing Mechanism for Fully Perforated Tape continued



2.57 Typing Mechanism continued

(A) PRINTING LATCH (FOR UNITS WITH ADJUSTABLE PRINTING LATCH MOUNTING BRACKETS)


NOTE: FOR UNITS WITH NON-ADJUSTABLE PRINTING LATCH MOUNTING BRACKET REFER TO REQUIREMENT (1) AND TO ADJUST (3) BELOW ONLY.

REQUIREMENTS

- (1) ROCKER BAIL IN EXTREME LEFT POSITION. MANUALLY LIFT PRINT HAMMER ACCELERATOR SO THAT LATCHING SURFACES OF PRINTING LATCH AND ACCELERATOR ARE AT THE CLOSEST POINT. MIN. SOME---MAX. 0.015 INCH CLEARANCE BETWEEN ACCELERATOR AND LATCH.
- (2) ROCKER BAIL IN ITS EXTREME RIGHT POSITION. THERE SHOULD BE SOME OVERTRAVEL OF THE PRINT HAMMER ACCELERATOR WITH RESPECT TO THE LATCHING SURFACE OF THE PRINTING LATCH AND SOME CLEARANCE BETWEEN THE PRINT HAMMER ACCELERATOR AND THE RIBBON CARRIER.


TO ADJUST

- (1) POSITION THE ROCKER BAIL TO THE EXTREME RIGHT. ADJUST THE ECCENTRIC SO THAT THERE IS APPROXIMATELY 0.065 INCH CLEARANCE BETWEEN THE PRINT HAMMER ACCELERATOR AND THE RIBBON CARRIER, KEEPING THE HIGH PART OF THE ECCENTRIC TO THE LEFT. LOOSEN THE TWO SCREWS WHICH FASTEN THE PRINTING LATCH MOUNTING BRACKET UNTIL THEY ARE JUST FRICTION TIGHT, AND MOVE THE BRACKET TO ITS EXTREME REAR POSITION.
- (2) POSITION THE ROCKER BAIL TO THE EXTREME LEFT. MOVE THE PRINTING LATCH MOUNTING BRACKET TOWARD THE FRONT UNTIL THE PRINT HAMMER ACCELERATOR JUST TRIPS. TIGHTEN THE TWO SCREWS WHICH FASTEN THE PRINTING LATCH MOUNTING BRACKET.
- (3) WITH THE ROCKER BAIL TO THE EXTREME LEFT, POSITION THE PRINTING TRIP LINK BY ADJUSTING THE ECCENTRIC UNTIL THERE IS:
MIN. SOME---MAX. 0.015 INCH CLEARANCE BETWEEN THE PRINTING LATCH AND THE PRINT HAMMER ACCELERATOR. THE HIGH PART OF THE ECCENTRIC SHOULD BE TO THE LEFT.



2.58 Typing Mechanism for Fully Perforated Tape continued

NOTE:
ADJUSTMENTS ON THIS PAGE DO NOT
APPLY TO TAPE PRINTER.



**(A) TYPEWHEEL (PRELIMINARY)
TO CHECK**

SELECT "H" CODE COMBINATION (--3-5). PLACE ROCKER BAIL TO EXTREME LEFT. THE ROTARY CORRECTOR FIRMLY ENGAGED.

REQUIREMENT

TYPEWHEEL ALIGNED SO THAT FULL CHARACTER IS PRINTED UNIFORMLY AND 6-1/2 CODE HOLE SPACES BEHIND ITS PERFORATED CODE HOLES.

TO ADJUST

POSITION TYPEWHEEL WITH LOCK NUT LOOSENED. CHECK PRINTING BY MANUALLY LIFTING ACCELERATOR TO LATCHED POSITION AND RELEASING IT.

NOTE:

FOR BEST RESULTS IT MAY BE NECESSARY TO PROCEED TO THE NEXT ADJUSTMENT THEN COME BACK AND REFINE THE ABOVE.

**(B) TYPEWHEEL (FINAL)
REQUIREMENT**


ALL CHARACTERS SHALL BE LEGIBLE AND 6-1/2 CODE HOLE SPACES BEHIND THE PERFORATED CODE HOLES WITH UNIT OPERATING UNDER POWER.

TO ADJUST

REFINE THE TYPEWHEEL POSITION WITH ITS LOCK NUT LOOSENED.

NOTE:

FOR BEST RESULTS IT MAY BE NECESSARY TO MAKE THE PRINT HAMMER ADJUSTMENT AND THEN REFINE THIS ADJUSTMENT.



**(C) PRINT HAMMER
REQUIREMENT**

WHEN OPERATING UNDER POWER, PRINT HAMMER AND TYPEWHEEL ALIGNED SO AS TO OBTAIN BEST QUALITY OF PRINTING.

TO ADJUST

POSITION PRINT HAMMER SHAFT WITH LOCK NUT LOOSENED.

NOTE:

IT MAY BE NECESSARY TO REMAKE TYPEWHEEL ADJUSTMENT (ABOVE) AND THEN REFINE THIS ADJUSTMENT.

2.59 Ribbon Mechanism (Later Design)

(For Earlier Design see Par. 4.01 through 4.03)

FEED PAWL SPRING


REQUIREMENT

WITH ROCKER BAIL TO EXTREME RIGHT:
 MIN. 4 OZS. --- MAX. 6 OZS.
 TO PULL FEED PAWL SPRING TO
 INSTALLED LENGTH.

RATCHET WHEEL TORQUE SPRING

REQUIREMENT

MIN. 1 OZS. --- MAX. 3 OZS.
 APPLIED TANGENTIALLY TO THE RATCHET
 WHEEL TO START IT TO ROTATE.



DRIVE ARM

TO CHECK

POSITION ROCKER BAIL TO EXTREME LEFT.
 HOLD THE RIBBON REVERSING ARM UNDER LOWER
 REVERSING EXTENSION OF FEED PAWL.

REQUIREMENT

- (1) CLEARANCE BETWEEN BLOCKING EDGE OF RIBBON REVERSE ARM AND REVERSING EXTENSION OF FEED PAWL:
 MIN. SOME
- (2) CLEARANCE SHALL NOT BE SO GREAT AS TO ALLOW FEED PAWL TO FEED MORE THAN TWO TEETH AT A TIME.
- (3) FEED PAWL DETENTED IN BOTH ITS RIGHT AND LEFT POSITION.

TO ADJUST

POSITION DRIVE ARM ADJUSTABLE EXTENSION
 LEVER WITH ITS MOUNTING SCREW LOOSENED.


2.60 Ribbon Mechanism (Later Design) continued

(For Earlier Design see Par. 4.01 through 4.03)

DRIVE ARM SPRING

REQUIREMENT

WITH ROCKER BAIL TO EXTREME RIGHT:
MIN. 9 OZS. --- MAX. 14 OZS.
TO PULL DRIVE ARM SPRING TO
INSTALLED LENGTH.




DETENT SPRING

REQUIREMENT

WITH REVERSING ARM IN ITS EXTREME
RIGHT OR LEFT POSITION:
MIN. 2 OZS. --- MAX. 4 OZS.
TO PULL DETENT SPRING TO ITS
INSTALLED LENGTH.

2.61 Slack Tape Mechanism



TAPE PLATFORM REQUIREMENT

TOP SURFACE OF TAPE PLATFORM SHOULD BE FLUSH WITH TOP SURFACE OF TAPE GUIDE.

TO ADJUST

WITH TAPE PLATFORM MOUNTING SCREWS LOOSENED, POSITION TAPE PLATFORM.

CLAMP PLATE SPRING REQUIREMENT

FUNCTION CLUTCH DISENGAGED AND LATCHED. CLAMP PLATE SPRING BOWED TO THE RIGHT.

MIN. 18 OZS. --- MAX. 24 OZS. ---

TO MOVE CLAMP PLATE FROM BOTTOM OF SLOT IN TAPE DEPRESSOR.

2.62 Model 28 Tape Printer Unit

NOTE:

THESE ADJUSTMENTS, PLUS APPLICABLE MODEL 28 TYPING REPERFORATOR ADJUSTMENTS, ARE REQUIRED TO ADJUST THE MODEL 28 TAPE PRINTER.


FEED WHEEL

REQUIREMENT (PRELIMINARY)

- (1) CLEARANCE BETWEEN FEED WHEEL RATCHET AND FRONT PLATE:
MIN. 0.085 --- MAX. 0.095 INCH
- (2) (FINAL)
PRINTING CENTRALLY LOCATED ON TAPE
TO ADJUST
TURN ADJUSTING SCREW WITH LOCK NUT LOOSENED.

TAPE GUIDE
REQUIREMENT

THE TAPE SHALL "RUN" IN THE CENTER OF TAPE GUIDE (GAGE BY EYE).
TO ADJUST
WITH MOUNTING NUTS FRICTION TIGHT, POSITION TAPE GUIDE WITH ROLLER UP OR DOWN TO MEET REQUIREMENT.



SPECIAL REQUIREMENT


IF THE MODEL 28 TAPE PRINTER IS USED ON A MODEL 28 TYPING REPERFORATOR SINGLE OR DOUBLE PLATE BASE, A TAPE REEL WILL HAVE TO BE USED TO ACCOMMODATE THE 3/8 INCH TAPE. THIS TAPE REEL CONSISTS OF A DISC W/HUB AND A DISC W/NUT.

2.63 Chad Chute Assembly for Self-contained Typing Reperforator Set for Fully Perforated Tape

CHAD CHUTE (SELF CONTAINED TYPING REPERFORATOR SET)
REQUIREMENT

CHAD CHUTE SHOULD BE FLUSH WITH
TOP OF PUNCH BLOCK.

TO ADJUST
WITH MOUNTING SCREWS FRICTION TIGHT
POSITION CHAD CHUTE .




2.64 Chad Chute Assembly for Multiple Typing Reperforator Set for Fully Perforated Tape

CHAD CHUTE ASSEMBLY (MULTIPLE REPERFORATOR SET)
REQUIREMENT

- (1) CHAD CHUTE SHOULD BE FLUSH WITH TOP OF PUNCH BLOCK .
- (2) CHAD CHUTE ASSEMBLY SHOULD BE ADJUSTED SO CLEARANCE IS MAXIMUM IN ALL DIRECTIONS BETWEEN EACH CHAD CHUTE AND REPERFORATOR CASTING .
- (3) POSITION TAPE GUIDE IN ITS MOUNTING SLOTS SO THAT TOP OF ROLLER IS PARALLEL TO AND ABOVE THE TAPE EXIT OF THE PUNCH BLOCK .

TO ADJUST WITH MOUNTING SCREWS FRICTION TIGHT POSITION CHAD CHUTE AND CHAD CHUTE ASSEMBLY BY MEANS OF ELONGATED SLOTS.



2.65 Chad Chute Assembly for Keyboard Typing Reperator on Automatic Send-Receive for Fully Perforated Tape


CHAD CHUTE ASSEMBLY (KEYBOARD REPERFORATOR - AUTOMATIC SEND-RECEIVE SET)

REQUIREMENT


CLEARANCE BETWEEN EACH CHAD CHUTE AND ADJACENT UNITS SHOULD BE EQUAL IN ALL DIRECTIONS.

TO ADJUST

WITH MOUNTING SCREWS FRICTION TIGHT POSITION EACH CHUTE BY MEANS OF THEIR ELONGATED SLOTS.



2.66 Chad Chute Assembly for Auxiliary Typing Reperforator on Automatic Send-Receive for Fully Perforated Tape



CHAD CHUTE ASSEMBLY (FOR AUXILIARY REPERFORATOR - AUTOMATIC SEND-RECEIVE SET)

REQUIREMENT
 CLEARANCE BETWEEN EACH CHAD CHUTE AND ADJACENT UNITS SHOULD BE EQUAL IN ALL DIRECTIONS.
 TO ADJUST
 WITH MOUNTING SCREWS FRICTION TIGHT POSITION CHAD CHUTE AND CHAD CHUTE W/BACKET BY MEANS OF THEIR ELONGATED SLOTS.

2.67 Tape Guide Chute Mechanism for Auxiliary Typing Reperforator on Automatic Send-Receive


TAPE GUIDE CHUTE (AUXILIARY TYPING REPERFORATOR) (AUTOMATIC SEND-RECEIVE SET)
REQUIREMENT

WITH LEFT-TOP AND MIDDLE DOME DOORS OPEN, FRONT AND REAR ENDS OF CHUTE ALIGN WITH PUNCH BLOCK TAPE APERTURE AND WITH HOLE IN AUXILIARY CONTROL PANEL.

TO ADJUST


POSITION MOUNTING BRACKET WITH MOUNTING SCREWS FRICTION TIGHT UNTIL CHUTE IS POSITIONED HORIZONTALLY. WITH UPPER ADJUSTING SCREW FRICTION TIGHT IN ITS NUT PLATE, POSITION CHUTE VERTICALLY.

NOTE: TAPE GUIDE CHUTE SHOULD NOT TOUCH TYPING REPERFORATOR OR CABINET. TAPE SHOULD FEED WITHOUT BINDING OR TWISTING.



3. VARIABLE FEATURES

3.01 Unshift-on-Space Mechanism



(A) UNSHIFT-ON-SPACE FUNCTION BLADE

(1) TO CHECK
 REMOVE SIGNAL BELL CONTACT ASSEMBLY WITH BRACKET AND SIGNAL BELL FUNCTION BLADE.
 SELECT FIGURES CODE COMBINATION (12-45). ROTATE MAIN SHAFT UNTIL LIFTER ROLLER IS ON LOW PART OF ROCKER BAIL'S CAMMING SURFACE AND UNSHIFT-ON-SPACE FUNCTION BLADE RESTS ON BELL CRANKS.

REQUIREMENT
 MIN. SOME---MAX. 0.015 INCH BETWEEN STRIPPER BLADE AND LETTERS EXTENSION ARM.

(2) TO CHECK
 SELECT SPACE CODE COMBINATION (---3---). ROTATE MAIN SHAFT UNTIL STRIPPER BLADE TOUCHES LETTERS EXTENSION ARM.

REQUIREMENT
 WHEN PLAY IS TAKEN UP IN EITHER DIRECTION, STRIPPER BLADE SHOULD ENGAGE AN EQUAL THICKNESS OF LETTERS EXTENSION ARM.


TO ADJUST
 POSITION STRIPPER BLADE ON FUNCTION BLADE WITH TWO MOUNTING SCREWS LOOSENED, REINSTALL SIGNAL BELL CONTACT ASSEMBLY WITH BRACKET AND SIGNAL BELL FUNCTION BLADE.

NOTE:
MAKE SIGNAL BELL CONTACT MOUNTING BRACKET ADJUSTMENT

(B) UNSHIFT-ON-SPACE FUNCTION BLADE SPRING REQUIREMENT


WITH UNIT IN STOP POSITION AND LONG SLOT IN BLOCKING SLEEVE ENGAGING FUNCTION BLADE
 MIN. 10 OZS.---MAX. 13 OZS. TO START BLADE MOVING.

3.02 Signal-bell Contact Mechanism (Later Design)
 (For Earlier Design see Par. 4.04)



- (1) REQUIREMENT
 THE CONTACT ASSEMBLY SHALL BE CENTRALLY LOCATED OVER THE BELL FUNCTION BLADE INSULATOR.
- (2) REQUIREMENT
 WITH LETTERS CODE COMBINATION (12345) SELECTED ROTATE MAIN SHAFT UNTIL BELL FUNCTION BLADE IS IN ITS LOWEST POSITION (RESTING ON BELL CRANKS). GAP BETWEEN CONTACTS.
 MIN. 0.015 INCH
 MAX. 0.025 INCH
- (3) REQUIREMENT
 WITH BELL FUNCTION BLADE IN ITS SELECTED POSITION, THE CONTACTS SHALL BE CLOSED.
 TO ADJUST
 WITH MOUNTING SCREWS LOOSENED, POSITION CONTACT BRACKET ASSEMBLY.


NOTE: SEE FUNCTION BLADE SPRING FOR TENSION.



(A) SIGNAL BELL CONTACT

NOTE:
 COMPLETE THE FOLLOWING ADJUSTMENTS WITH THE SIGNAL BELL CONTACT ASSEMBLY REMOVED FROM THE FUNCTION BOX FRONT PLATE.

- (1) REQUIREMENT
 CONTACT SPRINGS SHALL BE APPROXIMATELY PARALLEL TO TOP OF BRACKET.
 TO ADJUST
 BEND CONTACT SPRING.
- (2) REQUIREMENT
 MIN. 1-1/2 OZS.
 MAX. 2-1/2 OZS.
 WITH PULL APPLIED AT CONTACT POINT TO OPEN CONTACTS.
 TO ADJUST
 BEND UPPER CONTACT SPRING.



3.03 Tape Absence Contact Assembly

(A) TAPE ABSENCE LONG CONTACT SPRING REQUIREMENT

TAPE SENSING FINGER IN ITS EXTREME COUNTERCLOCKWISE POSITION.

MIN. 35 GRAMS
MAX. 45 GRAMS

TO ADJUST
REMOVE GUARD. BEND LONG CONTACT SPRING.

(D) TAPE ABSENCE CONTACT ASSEMBLY GUARD POSITION REQUIREMENT


THE GUARD SHOULD NOT INTERFERE WITH MOVEMENT OF SENSING FINGER.

TO ADJUST,
WITH MOUNTING NUT LOOSENED, POSITION THE GUARD.

(B) TAPE ABSENCE CONTACT ASSEMBLY POSITION REQUIREMENT

CONTACT POINTS ALIGNED, INSULATOR ON LONG CONTACT SPRING CENTRALLY LOCATED WITH SENSING FINGER EXTENSION.

TO ADJUST
WITH CONTACT ASSEMBLY GUARD REMOVED, MOUNTING SCREWS LOOSENED, POSITION CONTACT SPRINGS.



(C) TAPE ABSENCE SHORT CONTACT SPRING POSITION REQUIREMENT


TAPE SENSING FINGER IN ITS EXTREME COUNTER-CLOCKWISE POSITION.
MIN. 0.010 INCH
MAX. 0.020 INCH
CLEARANCE BETWEEN SENSING FINGER EXTENSION AND CLOSEST POINT ON BAKELITE INSULATOR OF LONG CONTACT SPRING.

TO ADJUST
WITH GUARD REMOVED, BEND THE SHORT CONTACT SPRING.

(F) TAPE ABSENCE CONTACTS CABLE ASSEMBLY POSITION REQUIREMENT

THE CABLE ASSEMBLY FOR THE TAPE ABSENCE CONTACTS SHOULD BE ROUTED TOGETHER WITH THE SELECTOR MAGNET CABLE ASSEMBLY AND, IF PRESENT, THE CODE READING CONTACTS CABLE ASSEMBLY. FORM THE CABLES SO THAT THEY DO NOT INTERFERE WITH THE MOVEMENT OF THE TAPE SENSING FINGER.

TO ADJUST:
SECURE THE POSITION OF THE CABLE ASSEMBLIES BY MEANS OF AN APPROPRIATE CABLE CLAMP LOCATED BEHIND THE SELECTOR MAGNETS.



(E) TAPE ABSENCE CONTACTS SENSING FINGER END PLAY REQUIREMENT

THE END PLAY BETWEEN TAPE SENSING FINGER AND TAPE GUARD SHOULD BE:
MIN. 0.006 INCH
MAX. 0.035 INCH

TO ADJUST
BEND THE TAPE SENSING FINGER.


3.04 Code-reading Contact Mechanisms (Make-only and Transfer Types)

NOTE 1:

UNLESS SPECIFICALLY STATED OTHERWISE, THE FOLLOWING CODE READING CONTACT ADJUSTMENTS APPLY TO BOTH THE TRANSFER (BREAK BEFORE MAKE) TYPE AND MAKE TYPE CONTACTS. WHEN AN ADJUSTMENT IS APPLICABLE TO BOTH TYPES, THE TRANSFER TYPE CONTACTS ARE USED IN THE ILLUSTRATIONS. WHEN TESTING THESE CONTACTS ON ASR SETS THE CONTROL KNOB SHOULD BE IN THE K-T POSITION.

NOTE 2:

IT IS RECOMMENDED THAT THE FOLLOWING ADJUSTMENTS BE MADE WITH THE CODE READING CONTACT ASSEMBLY REMOVED FROM THE UNIT.




WHEN USING THE CONTACT SPRING BENDER, START WITH THE CONTACT PILE-UP FARTHEST FROM THE HANDLE OF THE TOOL AND WORK TOWARD THE HANDLE SO AS NOT TO DISTURB ADJUSTMENTS ALREADY MADE.

(A)

MARKING CONTACT BACKSTOPS
REQUIREMENT

AS GAUGED BY EYE, FIVE MARKING CONTACT SPRINGS SHOULD ALIGN WITH EACH OTHER AND BE PARALLEL WITH MOUNTING PLATE.

TO ADJUST
BEND MARKING CONTACT BACKSTOPS.



(B)


MARKING CONTACT SPRINGS-PRELIMINARY
REQUIREMENT

WITH SWINGER CONTACT SPRING HELD AWAY:
MIN. 2 OZS.
MAX. 6 OZS.

TO MOVE EACH SPRING AWAY FROM BACKSTOP.
TO ADJUST
BEND MARKING CONTACT SPRINGS.

NOTE:

TO INCREASE TENSION OF MARKING CONTACT SPRING, IT MAY BE NECESSARY TO BEND BACKSTOP AWAY FROM SPRING, BEND SPRING AND THEN RE-BEND BACKSTOP TO MEET REQUIREMENT OF MARKING CONTACT BACKSTOPS ADJUSTMENT (ABOVE).



3.05 Code-reading Contact Mechanisms (Make-only and Transfer Types) continued

(A) SWINGER CONTACT SPRINGS-PRELIMINARY

REQUIREMENT


MIN. 30 GRAMS

MAX. 40 GRAMS

TO OPEN MARKING CONTACTS.

TO ADJUST

BEND SWINGER CONTACT SPRINGS.



NOTE:

SPACING CONTACTS (ON TRANSFER TYPE CONTACT ASSEMBLIES ONLY) ARE NORMALLY OPEN WHEN CONTACT ASSEMBLY IS REMOVED FROM UNIT.

(B) SPACING CONTACT BACKSTOPS - PRELIMINARY
(APPLIES TO TRANSFER TYPE CONTACTS ONLY)

REQUIREMENT


GAP BETWEEN SPACING CONTACTS

MIN. 0.018 INCH

MAX. 0.025 INCH

TO ADJUST

BEND SPACING CONTACT BACKSTOPS.



(C) SPACING CONTACT SPRINGS-PRELIMINARY
(APPLIES TO TRANSFER TYPE CONTACTS ONLY)

REQUIREMENT

MIN. 35 GRAMS

MAX. 50 GRAMS

TO MOVE EACH CONTACT SPRING AWAY FROM BACKSTOP.

TO ADJUST

BEND SPACING CONTACT SPRINGS.



NOTE:

TO INCREASE TENSION OF SPRING, IT MAY BE NECESSARY TO BEND BACKSTOP AWAY FROM SPRING, BEND SPRING, AND THEN RE-BEND BACKSTOP TO MEET REQUIREMENT OF SPACING CONTACT BACKSTOPS ADJUSTMENT ABOVE.

3.06 Code-reading Contact Mechanisms (Make-only and Transfer Types) continued

NOTE:

THE FOLLOWING CODE READING CONTACT ADJUSTMENTS SHOULD BE MADE WITH THE CONTACT ASSEMBLIES MOUNTED ON THE UNIT.



(A) CONTACT MOUNTING BRACKET REQUIREMENT


- (1) WITH FUNCTION CLUTCH DISENGAGED AND LATCHED, THERE SHALL BE MIN. 0.015 INCH CLEARANCE BETWEEN THE CLOSEST NORMALLY CLOSED CONTACT SPRING (MARKING CONTACT) AND PUNCH SLIDE INSULATOR.
- (2) WITH LETTERS COMBINATION SELECTED AND PUNCH PINS IN THEIR UPPERMOST POSITION, THE SWINGER SHALL BE PARALLEL TO RIGHT END OF PUNCH SLIDE AND EXTEND BELOW ITS CENTER, AS GAUGED BY EYE.

TO ADJUST POSITION CONTACT MOUNTING BRACKET WITH MOUNTING SCREWS LOOSENED.

(B) CONTACT MOUNTING PLATE REQUIREMENT

EACH SWINGER CONTACT SPRING SHOULD BE ALIGNED WITH ITS ASSOCIATED PUNCH SLIDE INSULATOR AS GAUGED BY EYE.

TO ADJUST POSITION CONTACT MOUNTING PLATE WITH MOUNTING SCREWS LOOSENED.




3.07 Code-reading Contact Mechanism (Transfer Type)

CONTACT BRACKET-PRELIMINARY (APPLIES TO TRANSFER - TYPE CONTACTS ONLY)

(1) REQUIREMENT

MANUALLY SELECT BLANK CODE COMBINATION. ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS. SOME CLEARANCE BETWEEN SPACING CONTACT SPRING AND ITS BACKSTOP. MAX. 0.008 INCH



(2) REQUIREMENT

WITH THE SELECTOR AND FUNCTION CLUTCHES DISENGAGED AND LATCHED, MANUALLY SELECT THE LTRS CODE COMBINATIONS AND TRIP THE FUNCTION CLUTCH. CLEARANCE BETWEEN PUNCH SLIDE INSULATOR AND SWINGER CONTACT SPRING MIN. 0.028 INCH


TO ADJUST

POSITION CONTACT BRACKET WITH ITS MOUNTING SCREWS LOOSENED TO MEET REQUIREMENT (1). TO PRY BRACKET TO LEFT, INSERT SCREWDRIVER BETWEEN BRACKET AND LEFT EDGE OF MOUNTING SCREWS; TO PRY BRACKET TO RIGHT, INSERT SCREWDRIVER BETWEEN BRACKET AND RIGHT EDGE OF MOUNTING SCREWS. CHECK REQUIREMENT (2). IF NOT MET, REFINE ADJUSTMENT.

3.08 Code-reading Contact Mechanism (Make-only Type)

CONTACT BRACKET (APPLIES TO MAKE-TYPE CONTACTS ONLY)---PRELIMINARY (1) REQUIREMENT

MANUALLY SELECT BLANK CODE COMBINATION.
 ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS AND PUNCH SLIDES ARE AGAINST THEIR RESPECTIVE LATCHES.
 GAP BETWEEN CONTACTS.
 MIN. 0.010 INCH
 MAX. 0.015 INCH (SEE NOTE)




NOTE:

WHERE A TYPING REPERFORATOR IS PART OF A 28 PERFORATOR-TRANSMITTER-BASE, CONTACT GAP SHALL BE

MIN. 0.020 INCH
 MAX. 0.025 INCH

(2) TO CHECK WITH THE SELECTOR AND FUNCTION CLUTCHES DISENGAGED AND LATCHED, MANUALLY SELECT THE LTRS CODE COMBINATION AND TRIP THE FUNCTION CLUTCH.
 REQUIREMENT
 CLEARANCE BETWEEN PUNCH SLIDE INSULATOR AND SWINGER CONTACT SPRING
 MIN. 0.028 INCH



TO ADJUST

POSITION CONTACT BRACKET WITH MOUNTING SCREWS FRICTION TIGHT. TO PRY BRACKET TO LEFT, INSERT SCREWDRIVER BETWEEN BRACKET AND LEFT EDGE OF MOUNTING SCREW; TO PRY BRACKET TO RIGHT, INSERT SCREWDRIVER BETWEEN BRACKET AND RIGHT EDGE OF MOUNTING SCREW.


3.09 Auxiliary Timing Contact Mechanisms (Single-contact and Double-contact Types)

NOTE 1:


THERE ARE TWO TYPES OF TIMING CONTACT ASSEMBLIES, SINGLE AND DOUBLE. SINGLE CONTACT ASSEMBLIES HAVE A FRONT CONTACT ONLY, NO REAR CONTACT. IF UNIT IS EQUIPPED WITH A DOUBLE CONTACT ASSEMBLY, THE FOLLOWING ADJUSTMENTS APPLY TO BOTH FRONT AND REAR CONTACTS.

NOTE 2:

IN CASE OF SINGLE-CONTACT ASSEMBLY, MAKE CERTAIN CONTACT BRACKET MOUNTING SCREWS ARE CENTRALLY LOCATED IN ELONGATED SLOTS, AND PROCEED TO NEXT ADJUSTMENT.




3.10 Auxiliary Timing Contact Mechanisms (Single-contact and Double-contact Types) continued




(A) RIGHT CONTACT GAP (NORMALLY CLOSED WHEN CONTACT ASSEMBLY IS REMOVED FROM UNIT).
 REQUIREMENT
 SWINGER HELD AGAINST ITS BACKSTOP.
 GAP BETWEEN CONTACTS:
 MIN. 0.020 INCH
 MAX. 0.025 INCH
 TO ADJUST
 BEND RIGHT CONTACT SPRING.

(B) SWINGER CONTACT SPRING-PRELIMINARY
 REQUIREMENT
 OPERATING BAIL HELD AWAY FROM SWINGER
 MIN. 4-1/2 OZS.
 MAX. 5-1/2 OZS.
 TO OPEN RIGHT SIDE OF CONTACT
 TO ADJUST
 BEND SWINGER CONTACT SPRING. RECHECK
RIGHT CONTACT GAP AND READJUST IF
 NECESSARY.



(C) LEFT CONTACT GAP (NORMALLY OPEN WHEN CONTACT ASSEMBLY IS REMOVED FROM UNIT)
 REQUIREMENT
 OPERATING BAIL HELD AWAY FROM SWINGER, GAP BETWEEN CONTACTS:
 MIN. 0.020 INCH
 MAX. 0.025 INCH
 TO ADJUST
 BEND STIFFENER.



(D) LEFT CONTACT SPRING-PRELIMINARY
 REQUIREMENT
 SWINGER HELD AGAINST BACKSTOP BY ITS OPERATING BAIL AND SPRING.
 MIN. 4-1/2 OZS.
 MAX. 5-1/2 OZS.
 TO OPEN LEFT SIDE OF CONTACT.
 TO ADJUST
 BEND LEFT CONTACT SPRING. RECHECK
RIGHT CONTACT GAP AND LEFT CONTACT GAP, AND READJUST IF NECESSARY.

3.11 Auxiliary Timing Contact Mechanisms (Single-contact and Double-contact Types) continued


NOTE:

THE FOLLOWING TIMING CONTACT ADJUSTMENTS SHOULD BE MADE WITH CONTACT ASSEMBLY MOUNTED ON UNIT.

(A) OPERATING BAIL SPRINGS

REQUIREMENT

OPERATING BAIL HELD SO THAT SWINGER IS AGAINST BACKSTOP.
 MIN. 7 OZS.
 MAX. 12 OZS.
 TO PULL SPRING TO INSTALLED LENGTH.



(B)

CONTACT BRACKET-PRELIMINARY (FOR UNITS EQUIPPED WITH ONE-CYCLE CAMS)

LOOSEN LOCKING SCREW. POSITION CAM FOLLOWER ARM, BY MEANS OF ITS ELONGATED MOUNTING HOLE, TO ITS MINIMUM LENGTH ON OPERATING BAIL. TIGHTEN LOCKING SCREW.


REQUIREMENT

SELECTOR AND FUNCTION CLUTCHES DISENGAGED AND LATCHED. CLEARANCE BETWEEN CAM FOLLOWER ROLLER AND FUNCTION CAM.

MIN. 0.050 INCH
 MAX. 0.055 INCH

TO ADJUST

POSITION CONTACT BRACKET WITH MOUNTING SCREWS LOOSENED.



NOTE:

ON UNITS EQUIPPED WITH DOUBLE CONTACT ASSEMBLIES, RECHECK CONTACT BACKSTOP ADJUSTMENT. IF REQUIREMENT IS NOT MET, REFINES CONTACT BRACKET ADJUSTMENT.

3.12 LTRS-FIGS Contact Mechanism (Later Design)

(For Earlier Design see Par. 4.05)

NOTE:

TO FACILITATE CONTACT SPRING ADJUSTMENT,
REMOVE CONTACT ASSEMBLY FROM UNIT.

(A) MIDDLE CONTACT SPRING

REQUIREMENT

MIN. 25 GRAMS---MAX. 40 GRAMS
TO OPEN UPPER SIDE OF CONTACT.

TO ADJUST
BEND MIDDLE CONTACT SPRING.


(B) LOWER CONTACT SPRING

REQUIREMENT

WITH UPPER SIDE OF CONTACT
CLOSED:

MIN. 0.012 INCH---MAX. 0.020 INCH
GAP AT LOWER SIDE OF CONTACT.

TO ADJUST
BEND LOWER CONTACT SPRING.



(C) OPERATING LEVER SPRING

REQUIREMENT

MIN. 1 OZ.---MAX. 2 OZS.
TO START OPERATING LEVER
MOVING.

(D) MOUNTING BRACKET

NOTE: CONTACT ASSEMBLY SHOULD BE
MOUNTED ON UNIT BEFORE THIS
ADJUSTMENT IS MADE.


REQUIREMENT

WITH UNIT IN LETTERS CONDITION
AND FUNCTION CLUTCH DISENGAGED:

MIN. 0.005 INCH---MAX. 0.015 INCH
BETWEEN OPERATING LEVER AND
INSULATOR ON MIDDLE CONTACT SPRING.

TO ADJUST

WITH MOUNTING NUT AND UPPER
MOUNTING SCREW LOOSENED, PO-
SITION MOUNTING BRACKET.




3.13 Contact Timing Measurements (To Zero Test Set)

THE FOLLOWING TESTS REQUIRE THE USE OF A TELETYPE SIGNAL DISTORTION TEST SET. THEY SHOULD BE MADE AFTER THE CONTACT ASSEMBLIES HAVE BEEN ADJUSTED AS INSTRUCTED ON THE PRECEDING PAGES. WHERE REQUIREMENTS ARE NOT MET, DESIGNATED ADJUSTMENTS MUST BE REFINED, AND/OR RELATED LENGTHS MAY HAVE TO BE CHANGED TO MEET TIMING REQUIREMENTS.

TESTS ON 600 OPERATION PER MINUTE UNITS OR LOWER SHOULD BE MADE WITH THE PERFORATOR OR REPERFORATOR AND THE TEST SET OPERATING AT 600 O.P.M.
 TESTS ON 900 O.P.M. UNITS USED ON THE AUTOMATIC SEND-RECEIVE (ASR) SET SHOULD BE MADE WITH THE TEST SET OPERATING AT 600 O.P.M. AND USING KEYBOARD TRANSMISSION.
 TESTS ON 1200 O.P.M. UNITS SHOULD BE MADE WITH THE REPERFORATOR OPERATING AT 1200 O.P.M. AND THE TEST SET EQUIPPED WITH A TWO CYCLE SCALE AND OPERATING AT 600 O.P.M.

OBSERVATIONS ARE TO BE MADE OF A NEON TRACE ON THE GRADUATED DISC OF A TEST SET. TRACE WILL HAVE TENDENCY TO "JUMP"; THAT IS, IT WILL NOT BE STEADY ENOUGH TO BE ACCURATELY MEASURED. VARIATION MAY BE AS HIGH AS TEN DIVISIONS ON SCALE. MINIMUM SIGNAL LENGTH IS MEASURED BETWEEN LATEST START AND EARLIEST END OF ALL TRACES. MAXIMUM SIGNAL LENGTH IS MEASURED BETWEEN EARLIEST START AND LATEST END OF ALL TRACES.


**TO ZERO TEST SET**

CONNECT NEON TRACE TO NO. 1 CODE READING CONTACT (REARMOST). WITH UNIT RECEIVING LETTERS CODE COMBINATIONS, OBSERVE AND NOTE POINT AT WHICH TRACE ENDS. TRACES WILL JUMP AS DESCRIBED ABOVE; NOTE EARLIEST END OF TRACES. REPEAT FOR REMAINING CONTACTS. OF ALL TRACES OBSERVED, CHOOSE ONE THAT STARTS THE LATEST. SET "START-ZERO" MARK OF SCALE AT LATEST START OF CHOSEN TRACE. RECORD EARLIEST END OF CHOSEN TRACE FOR FUTURE ADJUSTMENT REFERENCES.

3.14 Contact-timing Measurements for Code-reading Contacts

NOTE:

TEST PROCEDURES ON THIS PAGE APPLY TO 600 O.P.M. UNITS OR LOWER ONLY.

CODE READING CONTACTS

(1) ZERO TEST SET AS PREVIOUSLY INSTRUCTED.

(2) CONNECT NEON TRACE TO MARKING SIDE OF A CODE READING CONTACT (NORMALLY OPEN WHEN UNIT IS IN IDLE CONDITION). WITH UNIT RECEIVING CONTINUOUS LETTERS CODE COMBINATIONS, OBSERVE TRACE. REPEAT FOR ALL FIVE CONTACTS.

REQUIREMENTSA. SIGNAL LENGTH FOR EACH CONTACT TRACE AND COMBINED CONTACT TRACES.

MIN. 450 DIVISIONS

MAX. 594 DIVISIONS

B. BOUNCE SHOULD END WITHIN MAX. OF 20 DIVISIONS OF EARLIEST START AND LATEST END OF ALL TRACES.

(3) (APPLIES TO TRANSFER TYPE CONTACTS ONLY) CONNECT NEON TRACE TO BOTH SIDES OF CONTACT. WITH UNIT RECEIVING LETTERS CODE COMBINATIONS, OBSERVE TRACE.

REQUIREMENTSA. BREAK IN TRACE INDICATING BREAK BEFORE MAKE.

MIN. 3 DIVISIONS

B. SIGNAL LENGTH OF SPACING SIDE OF CONTACT

MIN. 100 DIVISIONS


C. BOUNCE SHOULD END WITHIN 30 DIVISIONS OF EARLIEST START AND LATEST END OF TRACE.

(4) TO ADJUST

A. IF REQUIREMENTS UNDER (2) A., (3) A., OR (3) B. ARE NOT MET, REFINE CONTACT BRACKET ADJUSTMENT. WHEN REFINING (2) A., ATTEMPT TO ADJUST TOWARD MAXIMUM SIGNAL LENGTH.B. IF BOUNCE REQUIREMENTS UNDER (2) B. AND (3) C. ARE NOT MET, REFINE MARKING AND SWINGER CONTACT SPRING AND SPACING CONTACT SPRING TENSIONS.C. IF ANY REFINEMENTS ARE NECESSARY, REPEAT COMPLETE TEST PROCEDURE.


3.15 Contact-timing Measurements for Auxiliary Timing Contacts

TEST PROCEDURES ON THIS PAGE APPLY
ONLY TO 600 O.P.M.
UNITS (BELL 82B1 SYSTEM)
USING ONE-CYCLE CAMS.

TIMING CONTACTS

- (1) ZERO TEST SET AS PREVIOUSLY DESCRIBED.
- (2) REAR CONTACT
 - A. CONNECT NEON TRACE TO RIGHT SIDE OF REAR CONTACT (NORMALLY OPEN WHEN UNIT IS IN IDLE CONDITION). WITH UNIT RECEIVING LETTERS CODE COMBINATIONS, OBSERVE TRACE. REQUIREMENTS
 1. EARLIEST START MIN. OF 35 DIVISIONS AFTER START ZERO MARK.
 2. LATEST END MIN. OF 35 DIVISIONS BEFORE EARLIEST END OF CODE READING CONTACT TRACES RECORDED WHEN ZEROING TEST SET.
 3. MIN. TRACE LENGTH 225 DIVISIONS.
 4. BOUNCE SHOULD END WITHIN MAX. 5 DIVISIONS OF START AND END OF ANY TRACE.
- (3) FRONT CONTACT
 - A. CONNECT NEON TRACE TO BOTH SIDES OF FRONT CONTACT. WITH UNIT RECEIVING LETTERS CODE COMBINATIONS, OBSERVE TRACE. REQUIREMENTS
 1. BREAK IN TRACE TO INDICATE BREAK BEFORE MAKE. MIN. 10 DIVISIONS
 2. BETWEEN EARLIEST STARTS OF TRACES OF RIGHT AND LEFT (NORMALLY OPEN AND NORMALLY CLOSED) SIDES OF CONTACT. MIN. 325 DIVISIONS---MAX. 420 DIVISIONS
 3. BOUNCE SHOULD END WITHIN MAX. 5 DIVISIONS OF EARLIEST START AND LATEST END OF ANY TRACE.
- (4) TO ADJUST
 - A. IF TIMING REQUIREMENTS UNDER (2) A. 1., 2., 3., AND (3) A. 1. AND 2. ARE NOT MET, REFINE CONTACT BRACKET ADJUSTMENT AND/OR RIGHT CONTACT GAP, LEFT CONTACT GAP, SWINGER CONTACT SPRING, AND LEFT CONTACT SPRING ADJUSTMENTS.
 - B. IF BOUNCE REQUIREMENTS UNDER (2) A. 4. AND (3) A. 3. ARE NOT MET, REFINE SWINGER CONTACT SPRING AND LEFT CONTACT SPRING TENSIONS.
 - C. IF ANY REFINEMENTS ARE NECESSARY, REPEAT COMPLETE TEST PROCEDURE.

3.16 Contact-timing Measurements for LTRS-FIGS Contacts (Later Design)
(For Earlier Design see Par. 4.05)



NOTE:

IF UNIT IS EQUIPPED WITH CODE READING AND/OR TIMING CONTACTS, TEST IS TO BE MADE AFTER INSTALLATION AND ADJUSTMENT OF THESE CONTACTS.

LETTERS-FIGURES CONTACT TEST

TO CHECK

CONNECT CABLE LEADS OF LETTERS-FIGURES CONTACT TO NEON TRACE LAMP OF SIGNAL DISTORTION TEST SET. SET CONTROL SWITCHES OF TEST SET TO FOLLOWING POSITIONS: (1) VIEW-TRANSMIT SWITCH TO VIEW; (2) LINE-DIST. SWITCH TO LINE; AND MOTOR SWITCH TO ON. ALTERNATELY SELECT LETTERS (12345) AND FIGURES (12-45). SET START-ZERO MARK OF TEST-SET SCALE AT START OF CONTACT TRACE. CONNECT RIGHT SIDE OF FRONT TIMING CONTACT (PROBE) TO NEON TRACE LAMP; RECORD START AND END OF TRACE. RECONNECT LETTERS-FIGURES CONTACT TO TRACE LAMP AND ALTERNATELY SELECT LETTERS AND FIGURES.

REQUIREMENT

- (1) NO CHATTER OR BOUNCE OF LETTERS-FIGURES CONTACT DURING TIME WHEN TIMING CONTACT IS CLOSED.
- (2) TRACE OF LETTERS-FIGURES CONTACT START MIN. OF 40 DIVISIONS BEFORE START OF TRACE OF TIMING CONTACT AND END MIN. OF 5 DIVISIONS AFTER END OF TIMING CONTACT.


TO ADJUST

- (1) IF (1) OF REQUIREMENT IS NOT MET, REFINE MIDDLE AND LOWER CONTACT SPRING ADJUSTMENTS.
- (2) IF (2) OF REQUIREMENT IS NOT MET, REFINE MOUNTING BRACKET ADJUSTMENT.
- (3) IF TEST REQUIREMENTS ARE NOT MET, REFINE LTRS-FIGS CONTACT MECHANISM ADJUSTMENTS.

3.17 Contact Timing Measurements (To Zero Test Set)

NOTE:

TEST PROCEDURES ON THIS PAGE AND THE FOLLOWING PAGE APPLY ONLY TO 600 O.P.M. UNITS (WESTERN UNION PLAN 55 SYSTEM) USING ONE-CYCLE CAMS.

TIMING CONTACTS

(1) ZERO TEST SET AS PREVIOUSLY DESCRIBED.

(2) FRONT CONTACT

A. CONNECT NEON TRACE TO RIGHT SIDE OF FRONT CONTACT (NORMALLY OPEN WHEN UNIT IS IN IDLE CONDITION). WITH UNIT RECEIVING CONTINUOUS LETTERS CODE COMBINATIONS, OBSERVE TRACE.

REQUIREMENTS

1. LATEST END MIN. OF 35 DIVISIONS BEFORE EARLIEST END OF CODE READING CONTACT TRACES.
2. EARLIEST START MIN. OF 35 DIVISIONS AFTER LATEST START OF CODE READING CONTACT TRACES.
3. MIN. TRACE LENGTH 200 DIVISIONS.
4. BOUNCE SHOULD END WITHIN MAX. 5 DIVISIONS OF EARLIEST START AND LATEST END OF ANY TRACE.

B. RECORD LATEST START AND EARLIEST END OF TRACE.


C. (APPLIES ONLY IF COMPLETE TRANSFER CONTACT IS USED). CONNECT NEON TRACE TO BOTH SIDES OF FRONT CONTACT. OBSERVE TRACE.

REQUIREMENT

1. BREAK IN TRACE AT TWO PLACES TO INDICATE BREAK BEFORE MAKE. MIN. 10 DIVISIONS

TEST CONTINUED ON NEXT PAGE)

3.18 Contact Timing Measurements (To Zero Test Set) continued



(3) REAR CONTACT

- A.** CONNECT NEON TRACE TO RIGHT SIDE OF REAR CONTACT (NORMALLY OPEN WHEN UNIT IS IN IDLE CONDITION). WITH UNIT RECEIVING LETTERS CODE COMBINATIONS, OBSERVE TRACE.

REQUIREMENTS

- 1.** LATEST END OF TRACE MIN. OF 35 DIVISIONS BEFORE EARLIEST END OF TRACE OF RIGHT SIDE OF FRONT CONTACT RECORDED IN (2) **B.**
- 2.** MIN. TRACE LENGTH 111 DIVISIONS.
- 3.** EARLIEST START OF TRACE MIN. OF 35 DIVISIONS AFTER LATEST START OF TRACE OF RIGHT SIDE OF FRONT CONTACT RECORDED IN (2) **B.**
- 4.** BOUNCE SHOULD END WITHIN MAX. 5 DIVISIONS OF EARLIEST START AND LATEST END OF ANY TRACE.

- B.** (APPLIES ONLY IF COMPLETE TRANSFER CONTACT IS USED). CONNECT NEON TRACE TO BOTH SIDES OF REAR CONTACT. OBSERVE TRACE.


REQUIREMENTS

- 1.** BREAK IN TRACE AT TWO PLACES TO INDICATE BREAK BEFORE MAKE.
MIN. 10 DIVISIONS

(4) TO ADJUST

- A.** IF TRACE LENGTHS UNDER (2) **A.** 3. AND (3) **A.** 2. ARE BOTH SHORT, REFINE CONTACT BRACKET ADJUSTMENT. IF ONLY ONE TRACE IS SHORT, REFINE CONTACT BACKSTOP ADJUSTMENT AND CHECK RIGHT CONTACT GAP, LEFT CONTACT GAP, SWINGER CONTACT SPRING, AND LEFT CONTACT SPRING ADJUSTMENTS.
- B.** IF BREAK BEFORE MAKE REQUIREMENTS UNDER (2) **C.** 1. AND (3) **B.** 1. ARE NOT MET, REFINE RIGHT CONTACT GAP, LEFT CONTACT GAP, SWINGER CONTACT SPRING, AND LEFT CONTACT SPRING ADJUSTMENTS.
- C.** IF ANY REFINEMENTS ARE NECESSARY, REPEAT COMPLETE TEST PROCEDURE.

3.19 Print Suppression on Function Mechanism



(A) PRINT HAMMER STOP --- PRELIMINARY REQUIREMENT

WITH HEAD OF PRINT HAMMER AGAINST CHARACTER ON TYPEWHEEL
MIN. SOME --- MAX. 0.010 INCH
CLEARANCE BETWEEN PRINT HAMMER
LEVER AND PRINT HAMMER STOP.

TO ADJUST

WITH MOUNTING SCREWS LOOSENED POSITION
PRINT HAMMER STOP BY MEANS OF ITS
ELONGATED UPPER HOLE.

(B) PRINT HAMMER STOP --- FINAL REQUIREMENT

WITH UNIT OPERATING UNDER POWER, THE
AMOUNT OF SMUDGE SHALL BE HELD TO
A MINIMUM WHERE PRINT SUPPRESSION IS
REQUIRED.

TO ADJUST

REFINE PRINT HAMMER STOP (PRELIMINARY)
ADJUSTMENT.

NOTE: UNLESS OTHERWISE SPECIFIED, THE FOLLOWING BACKSPACE ADJUSTMENTS APPLY TO BOTH THE CHADLESS AND FULLY PERFORATED TAPE MECHANISMS.

3.20 Manual and Power Drive Backspace Mechanism (For Chadless Tape)


RAKE (A)

(1) REQUIREMENT

WITH ROTATIONAL PLAY IN RAKE TAKEN UP TO LEFT, BOTTOM SURFACE OF RAKE TEETH SHOULD BE WITHIN 0.040 INCH OF THE SAME VERTICAL PLANE AS LEFT SIDE OF PUNCH BLOCK OR SLIGHTLY TO THE RIGHT.

TO ADJUST

REMOVE TWO MOUNTING SCREWS FROM REAR PLATE. POSITION RAKE SHAFT GEAR IN RELATION TO GEAR SEGMENT. REPLACE MOUNTING SCREWS.



(2) REQUIREMENT

WITH BELLCRANK SPRING UNHOOKED AND RAKE IN OPERATED POSITION, CLEARANCE BETWEEN BOTTOM OF RAKE TEETH AND LOWER SURFACE OF TAPE SLOT:


MIN. 0.007 INCH

MAX. 0.011 INCH

(CHECK AT NO. 1 & 5 PINS.)

TO ADJUST

LOOSEN THREE MOUNTING SCREWS AND ECCENTRIC MOUNT SCREW UNTIL FRICTION TIGHT. POSITION FRONT AND REAR PLATES, WITH BELL CRANK HANDLE FULLY DEPRESSED, UNTIL LEFT EDGES OF BOTH PLATES ARE APPROXIMATELY IN LINE WITH VERTICAL PLANE OF PUNCH BLOCK AND CLEARANCE MEETS THE REQUIREMENT. TIGHTEN MOUNTING SCREWS AND REPLACE BELL CRANK SPRING.



FEED PAWL ADJUSTING PLATE REQUIREMENT


(1) PRELIMINARY: WITH BELL CRANK ROTATED CLOCKWISE, FEED PAWL SHALL MISS FIRST TOOTH AT POINT OF LEAST CLEARANCE BY
MIN. 0.006 INCH --- MAX. 0.040 INCH

(2) FINAL: FEED PAWL SHALL MISS FIRST TOOTH AND ENGAGE SECOND TOOTH BY AT LEAST 1/2 OF RIGHT ENGAGING SURFACE OF FEED PAWL (AS GAUGED BY EYE WHEN FEED PAWL FIRST CONTACTS RATCHET TOOTH)

TO ADJUST

POSITION ADJUSTING PLATE WITH MOUNTING SCREW FRICTION TIGHT.

3.21 Manual and Power Drive Backspace Mechanism (For Chadless Tape) continued




(A) RETURN LATCH REQUIREMENT

BACKSPACE MECHANISM IN UNOPERATED POSITION. CLEARANCE BETWEEN RETURN LATCH AND FEED PAWL EXTENSION

MIN. 0.004 INCH
MAX. 0.020 INCH

TO ADJUST

ADJUST ECCENTRIC WITH MOUNTING SCREW FRICTION TIGHT.



(B) FEED PAWL ECCENTRIC MANUAL BACKSPACE (PRELIMINARY) REQUIREMENT

WITH THE BACKSPACE BELL CRANK IN ITS OPERATED POSITION AND THE FEED WHEEL DETENTED BACK ONE SPACE.

MIN. SOME---MAX. 0.003 INCH CLEARANCE BETWEEN THE FEED WHEEL RATCHET TOOTH AND THE BACKSPACE FEED PAWL.


POWER DRIVE BACKSPACE

WITH THE BACKSPACE BELL CRANK IN ITS OPERATED POSITION, THE HIGH SIDE OF THE ECCENTRIC SHOULD BE IN ITS UPPERMOST POSITION.

TO ADJUST

LOOSEN THE NUT POST (FRICTION TIGHT) AND ROTATE ECCENTRIC WITH AN ALLEN WRENCH. TIGHTEN THE NUT POST.

3.22 Manual and Power Drive Backspace Mechanism (For Fully Perforated Tape)



3.23 Manual and Power Drive Backspace Mechanism (For Fully Perforated Tape) continued

FEED PAWL ECCENTRIC

MANUAL BACKSPACE (PRELIMINARY)

REQUIREMENT

WITH THE BACKSPACE BELL CRANK ASSEMBLY IN ITS OPERATED POSITION AND THE FEED WHEEL DETENTED BACK ONE SPACE.

MIN. SOME --- MAX. 0.003 INCH

CLEARANCE BETWEEN THE BACKSPACE RATCHET TOOTH AND THE BACKSPACE FEED PAWL WITH ALL THE ROTATIONAL PLAY OF THE BACKSPACE RATCHET TAKEN UP IN A DIRECTION TO MAKE THE CLEARANCE MAXIMUM.


POWER DRIVE BACKSPACE

REQUIREMENT

WITH THE BACKSPACE BELL CRANK ASSEMBLY IN ITS OPERATED POSITION, THE HIGH SIDE OF THE ECCENTRIC SHOULD BE IN ITS UPPERMOST POSITION.

TO ADJUST

LOOSEN THE NUT POST (FRICTION TIGHT) AND ROTATE THE ECCENTRIC WITH AN ALLEN WRENCH. TIGHTEN THE NUT POST.




3.24 Power Drive Backspace Mechanism (Early Design)

(A) ARMATURE HINGE REQUIREMENT

ARMATURE BAIL SPRING REMOVED. WITH ARMATURE HELD AGAINST POLE FACE AND PLAY TAKEN UP AT HINGE IN DOWNWARD DIRECTION, CLEARANCE BETWEEN ARMATURE AND MAGNET BRACKET MIN. SOME --- MAX. 0.004 INCH

TO ADJUST

WITH HINGE MOUNTING SCREWS LOOSENED, POSITION ARMATURE. THE ARMATURE SHOULD TOUCH FRONT AND REAR OF MAGNET CORE. TIGHTEN SCREWS AND RECHECK ADJUSTMENT.

NOTE 2:


FOR "DC" OPERATION, THE BACKSPACE MAGNET ARMATURE SHALL BE POSITIONED SO THAT THE SIDE MARKED "C" SHALL FACE THE POLE FACE OF THE MAGNET CORE. FOR "AC" OPERATION, THE UNMARKED SIDE OF THE MAGNET ARMATURE SHALL FACE THE POLE FACE OF THE MAGNET CORE.

NOTE 1:

THE FOLLOWING ADJUSTMENTS ARE FOR USE WITH THE EARLY DESIGN BACKSPACE MAGNET ASSEMBLY. LATER DESIGN USE A NON-ADJUSTABLE BACKSPACE MAGNET ASSEMBLY.

NOTE 3:

THIS ADJUSTMENT IS MADE AT FACTORY AND SHOULD NOT BE DISTURBED UNLESS A REASSEMBLY OF THE UNIT IS UNDERTAKEN. IF NECESSARY TO MAKE THIS ADJUSTMENT, THE PUNCH UNIT SHOULD BE REMOVED. SEE DISASSEMBLY AND REASSEMBLY. REMAKE PUNCH UNIT POSITION ADJUSTMENT.

(B) ARMATURE UP-STOP REQUIREMENT

ARMATURE IN UNOPERATED POSITION. GAP BETWEEN ARMATURE AND POLE FACE MIN. 0.025 INCH. MAX. 0.030 INCH. AT CLOSEST POINT.

TO ADJUST

ROTATE ECCENTRIC WITH MOUNTING NUT LOOSENED. KEEP HIGH PART OF ECCENTRIC TO LEFT.

SECTION 573-118-700


3.25 Power Drive Backspace Mechanism (For Fully Perforated Tape) (Early Design) continued

DRIVE ARM


REQUIREMENT (PRELIMINARY)

WITH HIGH PART OF ECCENTRIC LINK IN LEFT HAND POSITION, ARMATURE AGAINST POLE FACE TO ALLOW DRIVE ARM LATCH LEVER TO REST AGAINST ECCENTRIC LINK. CLEARANCE BETWEEN STEP ON ECCENTRIC LINK AND LATCH LEVER WITH PLAY TAKEN UP TO MAKE GAP MINIMUM.

MIN. 0.040 INCH
MAX. 0.045 INCH



3.26 Manual and Power Drive Backspace Mechanism (For Chadless Tape) (Early Design) continued



DRIVE ARM

REQUIREMENT (PRELIMINARY)

WITH DRIVE-ARM LATCH LEVER ENGAGED WITH ECCENTRIC LINK, MAIN SHAFT ROTATED TO PLACE ECCENTRIC IN ITS EXTREME RIGHT HAND POSITION AND FEED WHEEL DETENTED BACK ONE SPACE.

— MIN. SOME --- MAX. 0.003 INCH

CLEARANCE BETWEEN THE BACKSPACE FEED PAWL AND THE RATCHET TOOTH. CHECK WITH FEED WHEEL SHAFT OIL HOLE IN THE UPPERMOST POSITION AND RECHECK EACH 90 DEGREES ABOUT THE PERIPHERY OF THE FEED WHEEL.

TO ADJUST


LOOSEN DRIVE ARM SCREW (FRICTION TIGHT) AND MOVE ADJUSTING PLATE.

SECTION 573-118-700

3.27 Power Drive Backspace Mechanism
(Early Design) continued

NOTE:

THIS ADJUSTMENT IS MADE AT FACTORY AND SHOULD NOT BE DISTURBED UNLESS A REASSEMBLY OF THE UNIT IS UNDERTAKEN. IF NECESSARY TO MAKE THIS ADJUSTMENT, PUNCH SHOULD BE REMOVED. SEE DISASSEMBLY AND REASSEMBLY. REMAKE PUNCH POSITION ADJUSTMENT.



**LATCH EXTENSION
REQUIREMENT**

BACKSPACE MECHANISM IN UNOPERATED POSITION. HIGH PART OF ECCENTRIC TO LEFT. ARMATURE AGAINST POLE FACE. LATCH RESTING ON ECCENTRIC LINK NOTCH. CLEARANCE BETWEEN TOP OF ARMATURE EXTENSION AND LATCH EXTENSION

MIN. 0.005 INCH

MAX. 0.020 INCH

TO ADJUST

SWING MAGNET CLOCKWISE OR COUNTERCLOCKWISE, AS NECESSARY, WITH MOUNTING SCREWS FRICTION TIGHT.

3.28 Power Drive Backspace Mechanism (Early Design) continued

(A) LATCH REQUIREMENT

BACKSPACE MECHANISM IN UNOPERATED POSITION. ARMATURE OFF POLE FACE (DE-ENERGIZED). LATCH EXTENSION AGAINST END OF ARMATURE. ECCENTRIC LINK AT ITS CLOSEST POINT TO UNDERSIDE OF LATCH. CLEARANCE BETWEEN LATCH AND ECCENTRIC LINK.


MIN. 0.005 INCH
MAX. 0.025 INCH

TO ADJUST POSITION LATCH WITH LATCH EXTENSION SCREW LOOSENED.

NOTE 1:

ON UNITS EQUIPPED WITH ONE PIECE NON-ADJUSTABLE LATCH LEVER THE REQUIREMENTS IN THE "FINAL POWER OR MANUAL" MUST BE MET.

LATCH EXTENSION SCREW
ARMATURE




(B) NON-REPEAT LATCH REQUIREMENT

BACKSPACE MECHANISM IN UNOPERATED POSITION. CLEARANCE BETWEEN TOP SURFACE OF NON-REPEAT LATCH AND LOWEST POINT OF LATCH EXTENSION

MIN. 0.002 INCH
MAX. 0.010 INCH

TO ADJUST POSITION ADJUSTING PLATE WITH LATCH SCREW LOOSENED FRICTION TIGHT.


LATCH EXTENSION




NOTE 2:

MUST NOT BE OPERATED WITH LATCH AGAINST ARMATURE EXTENSION.


3.29 Manual and Power Drive Backspace Mechanism (For Chadless Tape (Early Design) continued



**3.30 Power Drive Backspace Mechanism (For Fully Perforated Tape)
(Early Design) continued**



3.31 Power Drive Backspace Mechanism (Latest Design)
(Non-Adjustable Backspace Magnet Assembly)



3.32 Manual and Power Drive Backspace Mechanism (Chadless and Fully Perforated Tape)

NOTE: THE FINAL ADJUSTMENT REQUIREMENT FOR ALL BACKSPACE MECHANISMS, MANUAL OR POWER DRIVE, REGARDLESS OF THE TYPE OF UNIT WILL READ AS FOLLOWS:

FINAL POWER OR MANUAL REQUIREMENT

- (1) WITH TAPE IN THE UNIT, PLACE THE FEED WHEEL SHAFT OIL HOLE IN ITS UPPERMOST POSITION, OPERATE THE BACKSPACE MECHANISM ONCE. THE RATCHET WHEEL SHALL BE BACKED ONE SPACE INTO A FULLY DETENTED POSITION.

NOTE: A FULLY DETENTED POSITION IS DEFINED AS: WITH THE DETENT ROLLER IN CONTACT WITH THE RATCHET WHEEL THE PUNCH UNIT FEED PAWL SHALL ENGAGE THE FIRST TOOTH BELOW THE HORIZONTAL CENTERLINE OF THE FEED WHEEL RATCHET WITH NO PERCEPTIBLE CLEARANCE.


REQUIREMENT

- (2) WITH THE UNIT OPERATING UNDER POWER, PERFORATE APPROXIMATELY TWO (2) INCHES OF TAPE WITH THE "LETTERS" COMBINATION SELECTED. BACKSPACE TWELVE (12) CHARACTERS IN SUCCESSION WITH THE UNIT STILL UNDER POWER. AGAIN PERFORATE APPROXIMATELY TWO (2) INCHES OF TAPE WITH THE "LETTERS" COMBINATION SELECTED. CLIPPING OF THE CODE HOLES SHALL BE HELD TO A MINIMUM AND SHALL NOT EXCEED MORE THAN 0.005 INCH AS GAUGED BY EYE.

TO ADJUST

ON MANUAL OPERATED BACKSPACE MECHANISMS REFINE THE FEED PAWL PRELIMINARY ADJUSTMENT. ON BACKSPACE MECHANISMS EQUIPPED WITH POWER DRIVE, LOOSEN THE ARM ADJUSTING SCREW AND POSITION THE ADJUSTING PLATE. TIGHTEN THE ARM ADJUSTING SCREW.

3.33 Automatic Noninterfering LTRS and Blank Tape Feed-out Mechanisms



3.34 Automatic Noninterfering LTRS and Blank Tape Feed-out Mechanisms continued

(A) RELEASE ARM TO CHECK


PLACE UNIT IN FEED OUT CYCLE BY POSITIONING RELEASE LEVER ON LOWER STEP OF LATCH LEVER. ADVANCE RATCHETS BEYOND TIME DELAY (HIGH PART OF TIME DELAY CAM BEYOND TIME DELAY LEVER). POSITION FEED OUT CAM AS SHOWN.

REQUIREMENT

- (1) MIN. 0.010 INCH---MAX. 0.030 INCH BETWEEN DRIVE ARM AND RELEASE ARM.
- (2) WITH UNIT IN THE STOP POSITION MAX. 0.015 INCH OF THE DRIVE BAIL UNENGAGED BY THE RELEASE ARM.

TO ADJUST

WITH CLAMP NUT LOOSENED, POSITION RELEASE ARM BY MEANS OF ECCENTRIC SCREW ON TIME DELAY LEVER.




(B) RELEASE ARM SPRING

REQUIREMENT


WITH CLUTCHES DISENGAGED AND DRIVE ARM LATCHED BY RELEASE ARM:
 MIN. 2 OZS. ---MAX. 5 OZS.
 TO PULL SPRING TO INSTALLED LENGTH.

3.35 Remote-control Noninterfering LTRS and Blank Tape Feed-out Mechanisms
 (For Earlier Design Noninterfering BLANK
 Tape Feed-Out Mechanism see Par. 4.06)



- (A) ARMATURE HINGE REQUIREMENT
 WITH ARMATURE MANUALLY OPERATED. IT SHALL BE FLUSH AGAINST POLE FACE AND MAGNET BRACKET EXTENSION.
 TO ADJUST
 LOOSEN ARMATURE-HINGE BRACKET MOUNTING SCREWS, POSITION ARMATURE AND TIGHTEN SCREWS.
- (B) DRIVE BAIL SPRING REQUIREMENT
 ROTATE MAIN SHAFT UNTIL DRIVE BAIL IS ON HIGH PART OF ITS CAM.
 MIN. 20 OZS. ---MAX. 28 OZS.
 TO START THE DRIVE BAIL MOVING.
- (C) MOUNTING PLATE REQUIREMENT
 WITH ARMATURE IN UNOPERATED POSITION. ROTATE MAIN SHAFT UNTIL DRIVE BAIL IS ON HIGH PART OF ITS CAM. CLEARANCE BETWEEN THE BLOCKING BAIL AND DRIVE BAIL SURFACE.
 MIN. 0.006 INCH
 MAX. 0.015 INCH
 TO ADJUST
 POSITION BLOCKING BAIL WITH MOUNTING PLATE CLAMP SCREW AND SPRING POST FRICTION TIGHT.

- (D) MAGNET ASSEMBLY REQUIREMENT
 WITH ARMATURE HELD IN OPERATED POSITION, ROTATE MAIN SHAFT UNTIL DRIVE BAIL ROLLER IS ON HIGH PART OF ITS CAM. CLEARANCE BETWEEN BLOCKING BAIL AND RIGHT EDGE OF DRIVE BAIL.
 MIN. 0.005 INCH
 MAX. 0.015 INCH
 TO ADJUST
 POSITION MAGNET ASSEMBLY, ARMATURE HELD AGAINST MAGNET POLE PIECE WITH MAGNET BRACKET MOUNTING SCREWS FRICTION TIGHT.



3.36 Remote-control Noninterfering LTRS and Blank Tape Feed-out Mechanisms continued

(A)
BLOCKING LATCH TORSION SPRING

REQUIREMENT

WITH ARMATURE IN UNOPERATED POSITION AND DRIVE BAIL ROLLER ON HIGH PART OF ITS CAM. MIN. 15 GRAMS --- MAX. 40 GRAMS TO START BLOCKING LATCH MOVING.

(B)
ARMATURE BACKSTOP

TO CHECK


WITH ARMATURE IN UNOPERATED POSITION, ROTATE MAIN SHAFT UNTIL DRIVE BAIL ROLLER IS ON HIGH PART OF ITS CAM.

REQUIREMENT

MIN. SOME---MAX. 0.005 INCH CLEARANCE BETWEEN THE BLOCKING LATCH AND NON-REPEAT LATCH. THE DRIVE BAIL SHOULD ENGAGE THE BLOCKING BAIL BY AT LEAST 2/3 OF ITS THICKNESS.

TO ADJUST

LOOSEN THE ARMATURE BACKSTOP MOUNTING SCREWS AND POSITION BY MEANS OF PRYPOINT.



(C)
NON-REPEAT LEVER SPRING

REQUIREMENT

WITH ARMATURE IN UNOPERATED POSITION AND DRIVE BAIL ROLLER ON HIGH PART OF ITS CAM MIN. 6 OZS. --- MAX. 9 OZS. TO PULL SPRING TO INSTALLED LENGTH.

(D)
BLOCKING BAIL SPRING

REQUIREMENT

WITH ARMATURE IN UNOPERATED POSITION AND DRIVE BAIL ROLLER ON HIGH PART OF ITS CAM. MIN. 3 OZS. --- MAX. 5 OZS. TO PULL SPRING TO INSTALLED LENGTH.

(E)
RELEASE LEVER

REQUIREMENT


WITH ARMATURE IN OPERATED POSITION. ROTATE MAIN SHAFT UNTIL DRIVE BAIL ROLLER IS IN IN-IDENT OF ITS CAM. CLEARANCE BETWEEN RELEASE LEVER AND LATCH LEVER.

MIN. 0.010 INCH
MAX. 0.025 INCH


TO ADJUST

WITH CLAMP SCREW FRICTION TIGHT POSITION RELEASE LEVER.

3.37 Remote-control Noninterfering LTRS and Blank Tape Feed-out Mechanisms continued



3.38 Remote-control Noninterfering LTRS and Blank Tape Feed-out Mechanisms continued



3.39 Automatic and Remote-control Noninterfering LTRS and Blank Tape Feed-out Mechanisms

(C) FEED PAWL AND FRONT CHECK PAWL SPRINGS

FRONT CHECK PAWL SPRING

REQUIREMENT

WITH UNIT IN FEED OUT CYCLE (SEE "TO CHECK" OF REAR CHECK PAWL ADJUSTMENT BELOW):

MIN. 1 OZ. --- MAX. 3 OZS.
TO PULL EACH SPRING TO INSTALLED LENGTH.

(A)

REAR CHECK PAWL

TO CHECK

PLACE UNIT IN FEED OUT CYCLE BY POSITIONING RELEASE LEVER ON LOWER STEP OF LATCH LEVER AND ADVANCING HIGH PART OF TIME DELAY CAM BEYOND TIME DELAY LEVER. POSITION FEED PAWL TO EXTREME LEFT.

REQUIREMENT

MIN. 0.008 INCH --- MAX. 0.020 INCH BETWEEN REAR CHECK PAWL AND RATCHET TOOTH.


TO ADJUST

WITH CLAMP SCREW LOOSENED, POSITION REAR CHECK PAWL BY MEANS OF PRY POINT.

(D) REAR CHECK PAWL SPRING

REQUIREMENT

MIN. 28 GRAMS --- MAX. 56 GRAMS TO START REAR CHECK PAWL MOVING.



(B)

FRONT RATCHET STOP BLOCK

TO CHECK

WITH UNIT IN STOP POSITION, PLACE RELEASE LEVER ON LOWER STEP OF LATCH LEVER. PERMIT STOP ON FRONT RATCHET TO REST AGAINST STOP BLOCK. ROTATE MAIN SHAFT UNTIL FEED PAWL IS IN EXTREME RIGHT POSITION.

REQUIREMENT

MIN. 0.002 INCH --- MAX. 0.015 INCH BETWEEN FRONT CHECK PAWL AND FRONT RATCHET TOOTH.

TO ADJUST


WITH TWO CLAMP SCREWS LOOSENED POSITION STOP BLOCK BY MEANS OF PRY POINT.

3.40 Automatic and Remote-control Noninterfering LTRS and Blank Tape Feed-out Mechanisms continued

(B) TIME DELAY LEVER SPRING

REQUIREMENT

WITH UNIT IN STOP POSITION:
MIN. 2 OZS. ---MAX. 3 OZS.
TO PULL SPRING TO INSTALLED
LENGTH.



(A) TIME DELAY LEVER

(1) TO CHECK

TRIP SELECTOR CLUTCH AND ROTATE
MAIN SHAFT UNTIL STRIPPER CAM
FOLLOWER IS ON HIGH PART OF ITS
CAM.

REQUIREMENT

MIN. 0.040 INCH ---MAX. 0.060 INCH
CLEARANCE BETWEEN TIME DELAY LEVER AND
HIGH PART OF TIME DELAY CAM.

(2) REQUIREMENT

WITH UNIT IN STOP POSITION:
MIN. SOME _____

CLEARANCE BETWEEN TIME DELAY LEVER AND
HIGH PART OF TIME DELAY CAM.

TO ADJUST

WITH CLAMP SCREW LOOSENED, POSITION
ECCENTRIC BUSHING.

(C) RATCHET RETURN SPRING


REQUIREMENT

WITH UNIT IN STOP POSITION:
MIN. 5 OZS. ---MAX. 7 OZS.
TO PULL SPRING TO INSTALLED
LENGTH.

3.41 Automatic and Remote-control Noninterfering LTRS and Blank Tape Feed-out Mechanisms continued

DRIVE ARM SPRING REQUIREMENT

WITH UNIT IN FEED-OUT CYCLE AND DRIVE ARM ROLLER HELD FIRMLY AGAINST ITS CAM INDENT, IT SHALL REQUIRE
 MIN. 42 OZS. --- MAX. 50 OZS.
 TO PULL SPRING TO INSTALLED LENGTH.



3.42 Automatic and Remote Control Noninterfering LTRS Tape Feed-out Mechanisms continued

PUNCH SLIDE LATCH TO CHECK

SET UP BLANK CODE COMBINATION (-----) IN SELECTOR. PLACE UNIT IN FEED-OUT CYCLE, THE RATCHETS ADVANCED BEYOND THE TIME DELAY AND THE DRIVE ARM ON THE LOW PART OF ITS CAM. REQUIREMENT

MIN. 0.010 INCH---MAX. 0.030 INCH

BETWEEN PUNCH SLIDE AND PUNCH SLIDE LATCH AT SLIDE WHERE CLEARANCE IS LEAST.

NOTE: SEE THAT RESET BAIL IS TRIPPED.
 TO ADJUST

WITH CLAMP SCREW LOOSENED, POSITION DRIVE ARM ADJUSTING PLATE BY MEANS OF PRY POINT.

3.43 Automatic and Remote-control Noninterfering LTRS and Blank Tape Feed-out Mechanisms continued

(B) ADJUSTING LEVER
TO CHECK

PLACE UNIT IN FEED-OUT CYCLE, THE RATCHETS ADVANCED BEYOND THE TIME DELAY AND THE DRIVE ARM ON THE LOW PART OF FEED-OUT CAM.

REQUIREMENT

- (1) MIN. 0.010 INCH---MAX. 0.030 INCH CLEARANCE BETWEEN THE TRIP LEVER AND CLUTCH RELEASE LEVER.
- (2) MIN. SOME CLEARANCE BETWEEN TRIP LEVER AND LEFT END OF SLOT IN RELEASE LEVER DOWNSTOP BRACKET.

TO ADJUST

WITH CLAMP SCREW LOOSENED, POSITION ADJUSTING LEVER MAKING SURE IT RIDES FULLY ON THE SLIDE TRIP LEVER.

(A) FOLLOWER LEVER


REQUIREMENT

WITH FOLLOWER LEVER ON HIGH PART OF TRIP CAM:

- (1) MIN. 0.010 INCH---MAX. 0.030 INCH BETWEEN RELEASE AND MAIN TRIP LEVER.
- (2) SOME CLEARANCE BETWEEN MAIN TRIP LEVER AND DOWNSTOP BRACKET.


TO ADJUST

WITH LOCK NUT LOOSENED, POSITION ADJUSTING ARM BY MEANS OF PRY POINT.



3.44 Automatic and Remote Control Noninterfering LTRS and BLANK Tape Feed-Out Mechanisms continued

Note: After making this adjustment recheck (B) on the preceding page.



RESET BAIL TRIP LEVER
TO CHECK


LETTERS COMBINATION SELECTED, FUNCTION CLUTCH TRIPPED, TRIP CAM FOLLOWER RESTING ON THE HIGH PART OF CAM, PUNCH SLIDES AGAINST THEIR DOWNSTOP.

- (1) REQUIREMENT
MIN. 0.008 INCH---MAX. 0.020 INCH
CLEARANCE BETWEEN LOWER EDGE OF SLIDE AND UPPER EDGE OF RESET BAIL.
- (2) REQUIREMENT
WITH CLUTCHES FULLY DISENGAGED, RESET BAIL SHOULD FULLY ENGAGE NOTCHES IN PUNCH SLIDES.

TO ADJUST

WITH CLAMP SCREW LOOSENED, POSITION RESET BAIL TRIP LEVER BY MEANS OF ADJUSTING SLOT.

3.45 Automatic and Remote Control Noninterfering LTRS and BLANK
Tape Feed-Out Mechanisms continued



TAPE LENGTH ADJUSTING PLATE

NOTE: CAN BE SET TO FEED OUT TAPE OF ANY LENGTH UP TO 18 INCHES.

(1) REQUIREMENT

PLACE UNIT IN FEED OUT CYCLE BY POSITIONING RELEASE LEVER ON LOWER STEP OF LATCH LEVER. MANUALLY ADVANCE RATCHETS SO THAT FRONT RATCHET IS IN TOOTH PRECEDING TRIP OFF. ROTATE MAIN SHAFT UNTIL FEED PAWL IS IN EXTREME LEFT POSITION. CLEARANCE BETWEEN ADJUSTING PLATE AND LATCH LEVER PROJECTION

MIN. 0.002 INCH---MAX. 0.020 INCH

(2) REQUIREMENT

WHEN OPERATING UNDER POWER, UNIT SHOULD FEED OUT CORRECT LENGTH OF TAPE.


TO ADJUST

WITH SPRING POST LOOSENED, POSITION ADJUSTING PLATE.

3.46 Automatic and Remote Control Noninterfering BLANK Tape Feed-Out Mechanisms continued

BLOCKING LINK TORSION SPRING
REQUIREMENT

WITH UNIT IN STOP POSITION AND RELEASE LEVER ON LOWER STEP OF LATCH LEVER
MIN. 25 GRAMS---MAX. 45 GRAMS
TO START THE BLOCK LINK MOVING.



BLOCKING LINK

TO CHECK (HORIZONTAL CLEARANCE)


WITH UNIT IN STOP POSITION AND RELEASE LEVER IN UPPER STEP OF LATCH LEVER, MANUALLY TRIP FUNCTION CLUTCH.

REQUIREMENT

- (1) MIN. 0.005 INCH---MAX. 0.018 INCH BETWEEN THE RIGHT EDGE OF PUNCH SLIDE RESET BAIL AND BLOCKING LINK.
- (2) WITH SELECTOR RANGE SCALE SET AT 120 THE BLOCKING LINK SHOULD BE CENTERED BETWEEN THE CLUTCH DISC MOUNTING SCREWS AND THE SELECTOR STOP ARM BAIL.

TO ADJUST

LOOSEN CLAMP SCREW ON ADJUSTING LEVER AND POSITION BLOCKING LINK TO MEET REQUIREMENT.



3.47 Automatic and Remote Control
Noninterfering LTRS and BLANK
Tape Feed-Out Mechanisms continued

(A) RESET BAIL LATCH

(1) TO CHECK (VERTICAL CLEARANCE)

SELECT LETTERS CODE COMBINATION (12345). ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS AND PUNCH SLIDES ARE TO EXTREME LEFT. SET UP BLANK CODE COMBINATION (-----) IN SELECTOR BY STRIPPING ALL PUSH LEVERS FROM SELECTING LEVERS. ROTATE MAIN SHAFT UNTIL PUNCH SLIDES ARE JUST LATCHED.

REQUIREMENT

MIN. 0.008 INCH---MAX. 0.020 INCH BETWEEN RESET BAIL AND RESET BAIL LATCH. TO ADJUST WITH MOUNTING SCREWS LOOSENED, POSITION MOUNTING PLATE BY MEANS OF PRY POINTS.

(2) REQUIREMENT (HORIZONTAL CLEARANCE)


WITH CLUTCHES DISENGAGED, MIN. 0.005 INCH---MAX. 0.020 INCH BETWEEN RESET BAIL AND RESET BAIL LATCH. TO ADJUST POSITION RESET BAIL SO THAT APPROX. HALF ITS THICKNESS IS BELOW TOP SURFACE OF ITS LATCH. WITH CLAMP SCREW LOOSENED, POSITION RESET BAIL LATCH BY MEANS OF PRY POINT.

(3) TO CHECK

SELECT LETTERS CODE COMBINATION (12345). ROTATE MAIN SHAFT UNTIL FUNCTION CLUTCH TRIPS. SET UP BLANK CODE COMBINATION (-----) IN SELECTOR BY STRIPPING ALL PUSH LEVERS FROM SELECTING LEVERS. ROTATE MAIN SHAFT TO STOP POSITION.

REQUIREMENT


PUNCH SLIDES LATCHED BY PUNCH SLIDE LATCHES. TO ADJUST REFINE (1) AND (2) ABOVE.



(B) RESET BAIL LATCH SPRING

REQUIREMENT

WITH UNIT IN STOP CONDITION
MIN. 1 OZ. ---MAX. 3 OZS.
TO START RESET BAIL LATCH MOVING.




(C) TRIP LEVER EXTENSION SPRING
TO CHECK

DISENGAGE BOTH CLUTCHES. TRIP FUNCTION CLUTCH BY PIVOTING MAIN TRIP LEVER COUNTERCLOCKWISE. HOLD TRIP LEVER EXTENSION UP AGAINST RESET BAIL.

REQUIREMENT



MIN. 18 OZS. ---MAX. 24 OZS.
TO PULL SPRING TO INSTALLED LENGTH.



3.48 End of Feed-Out Timing Contacts for Noninterfering LTRS and BLANK Tape Feed-Out Mechanisms


(A) CONTACT SWINGER --- PRELIMINARY REQUIREMENT
 MIN. 1-1/2 OZS. --- MAX. 2-1/2 OZS.
 TO OPEN NORMALLY CLOSED CONTACT.
 TO ADJUST BEND SWINGER.

(B) CONTACT SPRING GAP --- PRELIMINARY REQUIREMENT
 NORMALLY OPEN CONTACT GAP
 MIN. 0.012 INCH --- MAX. 0.020 INCH
 TO ADJUST BEND CONTACT SPRING.




(C) CONTACT ASSEMBLY REQUIREMENT
 INSULATOR BUTTON ON SWINGER SHOULD BE CENTRALLY LOCATED IN BAIL EXTENSION YOKE.
 TO ADJUST WITH MOUNTING SCREWS LOOSENED POSITION CONTACT ASSEMBLY.


3. 49 End of Feed-Out Timing Contacts for Noninterfering LTRS and BLANK Tape Feed-Out Mechanisms continued



3.50 Manual- and Solenoid-Operated Interfering LTRS Tape Feed-Out Mechanisms



3.51 Manual- and Solenoid-Operated Interfering LTRS Tape Feed-Out Mechanisms continued



(B) TRIP LEVER - MANUALLY OPERATED TO CHECK

WITH UNIT IN STOP POSITION, TRIP SELECTOR CLUTCH BY POSITIONING HAND LEVER TO LEFT UNTIL STOP LEVER RESTS AGAINST CASTING.

REQUIREMENT

- (1) MIN. SOME---MAX. 0.015 INCH BETWEEN START LEVER AND ARMATURE AT POINT OF MIN. CLEARANCE.
- (2) START LEVER ENGAGING APPROX. CENTER OF TRIP LEVER'S OPERATING SURFACE.

TO ADJUST WITH CLAMP SCREW LOOSENED, POSITION TRIP LEVER ON SHAFT.

(A) TRIP LEVER - SOLENOID OPERATED TO CHECK

WITH UNIT IN STOP POSITION, TRIP SELECTOR CLUTCH BY ENERGIZING SOLENOID. TAKE UP PLAY IN STOP LEVER TO RIGHT (I.E., PLAY BETWEEN STOP LEVER AND PLUNGER).

REQUIREMENT

- (1) MIN. SOME---MAX. 0.008 INCH BETWEEN START LEVER AND ARMATURE AT POINT OF MIN. CLEARANCE.
- (2) START LEVER ENGAGING APPROX. CENTER OF TRIP LEVER'S OPERATING SURFACE.


TO ADJUST WITH CLAMP SCREW LOOSENED, POSITION TRIP LEVER ON SHAFT.

(C) TRIP LEVER SPRING REQUIREMENT

- MIN. 3 4 OZS.
- MAX. 2 OZ.

TO PULL SPRING TO ITS INSTALLED LENGTH.

3.52 External Manual Interfering LTRS Tape Feed-Out Mechanism



3.53 Timing Contact Mechanism (Operated by Selector)

SEE NOTE BELOW

NOTE

PARTS SHOULD BE WELL ALIGNED AND FREE OF SHARP BENDS. CONTACT POINTS MISALIGNMENT SHALL NOT EXCEED 1/4 THE DIAMETER OF POINTS.

(B) "B" CONTACT SPRINGS

REQUIREMENT

MIN. 4 OZS.
TO MOVE CONTACT SPRING AWAY FROM ITS STIFFENER.
TO ADJUST BEND CONTACT SPRING.

(A) "M" CONTACT SPRINGS

REQUIREMENT


MIN. 4 OZS.
TO MOVE CONTACT SPRING AWAY FROM ITS STIFFENER.
TO ADJUST BEND CONTACT SPRING.

(C) "S" - "B" CONTACT SPRINGS

REQUIREMENT

MIN. 3-1/2 OZS.
MAX. 4-1/4 OZS.
TO MOVE SWINGER CONTACT AWAY FROM NORMALLY BREAK CONTACT.
TO ADJUST BEND SWINGER CONTACT SPRING.

CONTACT ASSEMBLY



STIFFENER

SWINGER CONTACT W/INSULATOR

(D) TWIN "B" CONTACT SPRINGS

(1) REQUIREMENT

BOTH CONTACTS SHOULD OPEN AT THE SAME TIME.

(2) REQUIREMENT

THE INSERTION OF AN 0.008 INCH GAUGE BETWEEN ONE PAIR OF POINTS SHOULD NOT CAUSE THE OTHER PAIR TO SEPARATE.


TO ADJUST BEND SPRINGS OR SLIGHTLY TWIST STIFFENER. RECHECK CONTACT PRESSURE.

(E) "S" - "M" CONTACT GAP

REQUIREMENT

MIN. 0.012 INCH
MAX. 0.020 INCH
TO ADJUST BEND STIFFENER.

CONTACT MOUNTING BRACKET



SWINGER CONTACT W/INSULATOR

NOTE 1:

IN THIS TEXT, THE LETTERS S, B AND M ARE USED TO DENOTE RESPECTIVELY THE "SWINGER", "BREAK" (NORMALLY CLOSED WITH LEVER RIDING CAM DEPRESSION) AND "MAKE" (NORMALLY OPEN; CLOSED ONLY WITH LEVER RIDING CAM PEAK) CONTACT SPRINGS.

NOTE 2:

WHEN MAKING ADJUSTMENTS (F) THROUGH (H) MAKE CERTAIN THE "S" SPRING INSULATOR IS CLEAR OF THE OPERATING LEVER.

(F) TWIN SPRINGS ("M" CONTACTS)

REQUIREMENT

BOTH BREAK AND SWINGER CONTACTS SHOULD MAKE APPROXIMATELY THE SAME TIME.

TO ADJUST BEND BREAK CONTACT SPRINGS OR SLIGHTLY TWIST STIFFENER.

3.54 Timing Contact Mechanism (Operated by Selector) continued

(H) CONTACT ASSEMBLY POSITION

(1) REQUIREMENT

SET RANGE SCALE AT 50 (IMPORTANT).
ROTATE SHAFT SO OPERATING LEVER IS
ON LOWEST PART OF CAM.

TO ADJUST

WITH MOUNTING SCREWS LOOSENED
POSITION CONTACT ASSEMBLY BY MEANS
OF ITS OVERSIZE MOUNTING HOLES SO
LEVER CAN BE MOVED

MIN. 0.002 INCH


MAX. 0.006 INCH

BEFORE IT TOUCHES THE SWINGER SPRING,
AND SO FIRST TOUCH IS ON LOWER HALF
OF SPRING STUD WEARING PLATE.

(2) REQUIREMENT

(AT HIGHER SETTINGS, MOVEMENT WILL
BE LARGER; DISREGARD). TIGHTEN SCREWS
AND RECHECK. ROTATE SHAFT AND NOTE
THE HIGH PART OF CAM CAUSES
BOTH "M" CONTACTS TO MOVE AT LEAST,

MIN. 0.012 INCH
IF THIS CONTACT MOVEMENT IS NOT MET
AT SETTING 60 AND 90, CHECK FOR IN-
SECURE PARTS AND REFINE CONTACT GAP
BETWEEN SWINGER AND MAKE CONTACT.
IF STILL NOT MET, REPLACE RANGE SCALE
SELECTOR RACK.



(G) ALIGNMENT OF OPERATING LEVER WITH CAM

(1) REQUIREMENT

OPERATING LEVER'S FULL THICKNESS SHOULD
RIDE CAM.

TO CHECK

TAKE UP ALL CAM END PLAY TOWARD
SELECTOR CLUTCH DRUM, ALL OPERATING
LEVER END PLAY (AT ITS BEARING) IN
OPPOSITE DIRECTION. OBSERVE LEVER
AND CAM FOR FULL ENGAGEMENT.

(2) REQUIREMENT

LEVER SHOULD NOT EXERT PRESSURE
AGAINST FACE OF CLUTCH DISC.

TO ADJUST

REFINE CLUTCH DRUM END PLAY.

(I) OPERATING LEVER SPRING

REQUIREMENT

THE SPRING SHOULD HOLD OPERATING LEVER
AGAINST CAM WITH LIGHT PRESSURE. WITH
SPRING REMOVED.

MIN. 2 OZS.


MAX. 3 OZS.

TO STRETCH SPRING 5/8 INCH LENGTH.

3.55 Auxiliary Contact Assembly

NOTE:

THE FOLLOWING ADJUSTMENTS SHOULD BE MADE PRIOR TO INSTALLATION OF CONTACT BRACKET ASSEMBLY ON THE UNIT.



(A) NORMALLY OPEN CONTACT SPRING REQUIREMENT

MIN. 4-1/2 OZS.
MAX. 5-1/2 OZS.

TO MOVE CONTACT SPRING AWAY FROM ITS STIFFENER.

TO ADJUST BEND CONTACT SPRING. RECHECK CONTACT GAP.

(B) NORMALLY OPEN CONTACT GAP REQUIREMENT

MIN. 0.020 INCH
MAX. 0.025 INCH

TO ADJUST BEND STIFFENER.


(C) NORMALLY CLOSED CONTACT REQUIREMENT

MIN. 3 OZS.
MAX. 4 OZS.

TO MOVE SWINGER CONTACT AWAY FROM NORMALLY CLOSED CONTACT.

TO ADJUST BEND SWINGER CONTACT.

CONTACT BRACKET ASSEMBLY



(D) AUXILIARY CONTACT ASSEMBLY REQUIREMENT

TRIP FUNCTION CLUTCH AND ROTATE UNTIL CLEARANCE BETWEEN PAD AND ACTUATOR IS MAXIMUM.

MIN. SOME
MAX. 0.008 INCH

CLEARANCE BETWEEN SWINGER PAD AND ACTUATING LEVER WHEN PLAY IS TAKEN UP TO MAKE CLEARANCE A MINIMUM.

TO ADJUST

LOOSEN MOUNTING SCREWS AND POSITION CONTACT BRACKET ASSEMBLY ON MOUNTING BRACKET. IT MAY BE NECESSARY TO REPOSITION MOUNTING BRACKET TO MEET REQUIREMENT.

(REAR VIEW)

3.56 Multiple Mounted Function Blade Contact Mechanism

Note: For early design see par 4.21.

NOTE 1:


THE FOLLOWING ADJUSTMENTS SHOULD BE MADE PRIOR TO INSTALLING THE CONTACT BRACKET ASSEMBLY ON UNIT.

(A) NORMALLY OPEN CONTACT GAP

REQUIREMENT

MIN. 0.008 INCH
MAX. 0.015 INCH

TO ADJUST
BEND NORMALLY OPEN
CONTACT SPRING.




(B) NORMALLY CLOSED CONTACT
REQUIREMENT

MIN. 8 GRAMS
MAX. 15 GRAMS

TO MOVE THE SWINGER CONTACT
AWAY FROM THE NORMALLY CLOSED CONTACT.
TO ADJUST
BEND NORMALLY CLOSED
CONTACT SPRING.

NOTE 2:

THE FOLLOWING ADJUSTMENTS SHOULD BE MADE AFTER THE CONTACT BRACKET ASSEMBLY IS MOUNTED TO THE UNIT.



(C) NORMALLY OPEN CONTACT GAP

(1) REQUIREMENT

WITH THE FUNCTION BLADE IN ITS LOWEST POSITION IN THE NON-SELECTED CONDITION. CLEARANCE BETWEEN THE CONTACT SWINGER INSULATOR BUTTON AND THE FUNCTION BLADE:

MIN. SOME

(2) REQUIREMENT

CONTACT GAP
MIN. 0.008 INCH
MAX. 0.015 INCH

TO ADJUST
BEND NORMALLY CLOSED CONTACT SPRING.


(3) REQUIREMENT

WITH THE FUNCTION BLADE IN ITS LOWEST POSITION IN THE SELECTED CONDITION. GAP BETWEEN THE SWINGER CONTACT AND NORMALLY CLOSED (NOW OPEN) CONTACT


MIN. 0.015 INCH

AND SOME OVERTRAVEL OF THE NORMALLY OPEN CONTACT.

TO ADJUST
BEND NORMALLY CLOSED CONTACT SPRING.
REFINE PREVIOUS ADJUSTMENTS TO MAINTAIN REQUIREMENTS.



3. 57 Blank Delete Mechanism



(B) FUNCTION BLADE TORSION SPRING REQUIREMENT
MIN. 2 OZS.
MAX. 5 OZS.
TO START LIFTING THE BLANK FUNCTION BLADE FROM BLANK SENSING POSITION WITHOUT BLANK FUNCTION BLADE CONTACT INTERFERENCE.

NOTE
TAKE UP PLAY IN LETTERS FUNCTION BLADE TO MAKE THE GAP MAXIMUM.

(A) BLANK FUNCTION BLADE REQUIREMENT
WITH BLANK CODE COMBINATION SELECTED AND BLANK FUNCTION BLADE IN ITS SELECTED POSITION, CLEARANCE BETWEEN BLANK FUNCTION BLADE AND LETTERS FUNCTION BLADE
MIN. SOME
MAX. 0.020 INCH
TO ADJUST
WITH FUNCTION BLADE MOUNTING SCREW FRICTION TIGHT, ADJUST ECCENTRIC BUSHING KEEPING HIGH PART OF ECCENTRIC TOWARDS THE TOP OF UNIT.

3.58 Blank Delete Mechanism continued

FEED PAWL READJUSTMENT**REQUIREMENT**


WITH FEED WHEEL RATCHET IN ITS FULLY DETENTED POSITION, THE FEED PAWL IN ITS UPPERMOST POSITION MUST JUST TOUCH THE LOWER PART OF A TOOTH ON THE RATCHET.

TO ADJUST

WITH LOCK SCREW FRICTION TIGHT, ROTATE THE FEED PAWL ECCENTRIC, KEEPING HIGH PART OF ECCENTRIC TO RIGHT OF LOCK SCREW.

NOTE:

THE ECCENTRIC STUD SHOULD BE BACKED OFF TO ELIMINATE ANY INTERFERENCE WITH THIS ADJUSTMENT.



3. 59 Blank Delete Mechanism continued


BLOCKING LEVER WITH SHAFT MOUNTING PLATE
REQUIREMENT

WITH THE UNIT IN THE STOP POSITION, (ALL CLUTCHES LATCHED)


MIN. 0.015 INCH--MAX. 0.030 INCH
CLEARANCE BETWEEN THE BLOCKING LEVER AND
THE LATCH LEVER.

TO ADJUST
LOOSEN MOUNTING SCREWS AND POSITION
THE BLOCKING LEVER WITH SHAFT MOUNTING
PLATE.

NOTE: CHECK THAT THE HUB ON THE
STUD WITH BUSHING
DOES NOT RUB AGAINST THE REAR
PUNCH PLATE CAUSING THE BLOCKING
LEVER SHAFT TO BIND.




3.60 Blank Delete Mechanism continued



(B) MAGNET ASSEMBLY REQUIREMENT
 WITH FUNCTION BLADES IN SENSING POSITION AND ARMATURE MANUALLY HELD OPERATED, THE ROD SHOULD FULLY CONTACT THE ADJUSTING SCREW.
 TO ADJUST WITH MOUNTING SCREWS FRICTION TIGHT, POSITION MAGNET ASSEMBLY TO MEET REQUIREMENT.

3.61 Blank Delete Mechanism continued



BLOCKING LEVER
REQUIREMENT

WITH FUNCTION BLADES IN SENSING POSITION AND
MAGNET ARMATURE MANUALLY HELD OPERATED,
CLEARANCE BETWEEN BLOCKING LEVER AND LATCH LEVER
MIN. SOME
MAX. 0.005 INCH

TO ADJUST


WITH MAGNET ARMATURE MANUALLY HELD OPERATED
AND LOCKNUT ON ADJUSTING SCREW LOOSENED,
ROTATE ADJUSTING SCREW TO MEET THE REQUIREMENT.

RECHECK

TIGHTEN LOCK NUT ON ADJUSTING SCREW AND
RECHECK ADJUSTMENT.

NOTE: IF UNIT IS EQUIPPED WITH FEED SUPPRESSION,
THE LEVER ON TAPE SHOE ARM SHOULD BE PIVOTED
OUT OF POSITION WHEN MAKING THIS ADJUSTMENT.

3.62 Blank Delete Mechanism continued



3.63 Blank Delete Mechanism continued

ECCENTRIC STUD

REQUIREMENT

WITH LATCH LEVER AND BLOCKING LEVER IN LATCHED POSITION AND FEED PAWL IN ITS UPWARD TRAVEL, CLEARANCE BETWEEN TIP OF ENGAGING FEED WHEEL RATCHET TOOTH AND FEED PAWL TOOTH AT ITS CLOSEST POINT

MIN. 0.010 INCH

MAX. 0.020 INCH

TO ADJUST


WITH LOCK NUT ON ECCENTRIC STUD FRICTION TIGHT, ADJUST ECCENTRIC STUD ON BLOCKING LEVER TO MEET REQUIREMENT.

RECHECK


TIGHTEN LOCK NUT ON ECCENTRIC STUD AND RECHECK ADJUSTMENT.

NOTE:

THE ECCENTRIC SHOULD BE TOWARDS THE TOP OF UNIT IN ITS FULLY ADJUSTED POSITION.




3.64 Blank Delete Mechanism continued



(FRONT VIEW)

(A) PRINT SUPPRESSOR BLOCKING ARM REQUIREMENT
 WITH FUNCTION BLADES IN SENSING POSITION, BLOCKING LEVER LATCHED, AT THE CLOSEST POINT THERE SHALL BE
 MIN. 0.003 INCH---MAX. 0.015 INCH
 CLEARANCE BETWEEN THE LEFT SIDE OF THE PRINT HAMMER LEVER AND BLOCKING ARM WHEN ALL THE PLAY IN THE PRINT HAMMER LEVER IS TAKEN UP IN A DIRECTION TO MAKE THE CLEARANCE MINIMUM.
 TO ADJUST
 LOOSEN NUT FRICTION TIGHT AND ADJUST ECCENTRIC SHOULDER SCREW TO MEET REQUIREMENT.

NOTE: IT MAY BE NECESSARY TO FAVOR THE POSITION OF THE ECCENTRIC SHOULDER SCREW IN ITS MOUNTING HOLE TO MEET THE REQUIREMENT.



(REAR VIEW)

(B) PRINT SUPPRESSOR STOP REQUIREMENT
 WITH BLOCKING LEVER IN UNLATCHED POSITION
 CLEARANCE BETWEEN BLOCKING ARM AND PRINT HAMMER
 MIN. .005
 MAX. 0.015 INCH
 WHEN PLAY IN PRINT HAMMER IS TAKEN UP IN A DIRECTION TO MAKE THE CLEARANCE A MINIMUM.
 TO ADJUST
 WITH LOCK NUT FRICTION TIGHT, POSITION STOP TO MEET REQUIREMENT.
 RECHECK
 PRINT SUPPRESSOR BLOCKING ARM ADJUSTMENT.

(C) BLOCKING ARM SPRING REQUIREMENT
 WITH UNIT IN STOP POSITION
 MIN. 10 GRAMS
 MAX. 50 GRAMS
 TO START MOVING THE BLOCKING ARM AWAY FROM STOP.

3.65 Blank Delete Mechanism continued

CONTACT SPRING TENSION REQUIREMENT

MIN. 4-1/2 OZS.
MAX. 5-1/2 OZS.

TO MOVE THE CONTACT SPRING AWAY FROM ITS STIFFENER.

TO ADJUST

BEND CONTACT SPRING TO MEET REQUIREMENT.

RECHECK

OPEN CONTACT GAP ADJUSTMENT.

SWINGER CONTACT SPRING TENSION REQUIREMENT

MIN. 2 OZS. ---MAX. 3 OZS.


TO JUST MOVE THE SWINGER CONTACT SPRING AWAY FROM THE NORMALLY CLOSED CONTACT.

TO ADJUST

BEND CONTACT SPRING TO MEET REQUIREMENT.

BLANK CONTACT

(THE FOLLOWING ADJUSTMENTS SHOULD BE MADE PRIOR TO INSTALLING THE CONTACT BRACKET ASSEMBLY ON THE UNIT.)



OPEN CONTACT GAP REQUIREMENT

NORMALLY OPEN CONTACT GAP

MIN. 0.010 INCH

MAX. 0.015 INCH

BEND STIFFENER TO MEET REQUIREMENT.

NOTE:

THE FOLLOWING ADJUSTMENTS SHOULD BE MADE AFTER CONTACT BRACKET ASSEMBLY IS MOUNTED ON UNIT.


CONTACT ASSEMBLY (EARLIER DESIGN)

REQUIREMENT

CONTACT ASSEMBLY SHOULD LINE UP CENTRALLY WITH INSULATOR ON BLANK FUNCTION BLADE.

TO ADJUST

WITH MOUNTING SCREWS LOOSENED LINE UP THE CONTACT ASSEMBLY TO MEET REQUIREMENT.



CONTACT GAP REQUIREMENT


SELECT SPACING COMBINATION (--3--) AND ROTATE MAIN SHAFT UNTIL BLANK FUNCTION BLADE DROPS INTO SENSING POSITION. CLEARANCE BETWEEN CONTACT SPRINGS.

MIN. 0.010 INCH

MAX. 0.015 INCH

TO ADJUST

WITH MOUNTING SCREWS LOOSENED, POSITION CONTACT MOUNTING BRACKET.



CONTACT ASSEMBLY (LATER DESIGN)

THIS CONTACT ASSEMBLY SHOULD BE EQUIPPED WITH A GUARD LOCATED UNDER THE PLATE TO ELIMINATE A SHOCK HAZARD.

3.66 Manual Print Suppression Mechanism


MANUAL PRINT SUPPRESSION MECHANISM
 THE MANUAL PRINT SUPPRESSION MECHANISM CONSISTS OF A BLOCKING ARM WHICH CAN BE LOCKED IN A PRINT OR NON-PRINT CONDITION AT THE TIME OF UNIT INSTALLATION.

REQUIREMENT


- (1) BLOCKING ARM TO BE ADJUSTED IN NON-PRINT CONDITION TO ASSURE THAT PRINT HAMMER ARM IS BLOCKED BY BLOCKING ARM.
- (2) THE BLOCKING ARM SHOULD BE READJUSTED TO THE PRINT CONDITION AND LOCKED IN PLACE.

TO ADJUST

WITH MOUNTING SCREW FRICTION TIGHT, ROTATE ECCENTRIC BUSHING AND MANUALLY POSITION BLOCKING ARM TO NON-PRINT OR PRINT CONDITION.




3.67 Time Delay Motor Stop Mechanism




(A) TIME DELAY RATCHET WHEEL TENSION
REQUIREMENT
HOLD ALL PAWLS OFF RATCHET WHEELS.
MIN. 2 OZS.
MAX. 8 OZS.
TO MOVE EACH RATCHET WHEEL.
TO ADJUST
REMOVE AND BEND FRICTION SPRINGS
OF RATCHET WHEEL.


3.68 Time Delay Motor Stop Mechanism continued



3.69 Time Delay Motor Stop Mechanism continued



3.70 Time Delay Motor Stop Mechanism continued




(F) TIME DELAY SHORT CONTACT SPRING


REQUIREMENT
 SELECTOR AND FUNCTION CLUTCHES DIS-
 ENGAGED AND LATCHED; CONTACT OPERATING
 PAWL IN INDENTATIONS OF BOTH RATCHET
 WHEEL FLANGES.
 MIN. 2 OZS.
 MAX. 3 OZS.
 TO JUST SEPARATE CONTACT POINTS OF
 LONG AND SHORT CONTACT SPRINGS.
 TO ADJUST
 BEND SHORT CONTACT SPRING.

(E) TIME DELAY CONTACT GAP

REQUIREMENT
 SELECTOR AND FUNCTION CLUTCHES DISENGAGED
 AND LATCHED; CONTACT OPERATING PAWL REST-
 ING ON HIGH PART OF BOTH RATCHET WHEEL FLANGES.
 MIN. 0.010 INCH
 MAX. 0.015 INCH
 CLEARANCE BETWEEN CONTACT POINTS OF LONG
 AND SHORT CONTACT SPRINGS.
 TO ADJUST
 BEND SHORT CONTACT SPRING STIFFENER.



3.71 Time Delay Motor Stop Mechanism continued



(G) TIME DELAY LATCH PAWL SPRING

REQUIREMENT

LATCH PAWL SPRING UNHOOKED FROM PAWL;
LATCH PAWL HELD ON HIGH PART OF BOTH
RATCHET WHEEL FLANGES.

MIN. 12 OZS.

MAX. 15 OZS.

TO PULL SPRING TO INSTALLED LENGTH.

(H) TIME DELAY CONTACT OPERATING PAWL SPRING

REQUIREMENT


CONTACT OPERATING PAWL SPRING UNHOOKED
FROM LATCH LEVER; CONTACT OPERATING
PAWL HELD BLOCKED BY LATCH LEVER.

MIN. 2-1/4 OZS.

MAX. 3-1/4 OZS.

TO PULL SPRING TO INSTALLED LENGTH.

3.72 Time Delay Motor Stop Mechanism continued



(I) TIME DELAY DRIVE PAWL
REQUIREMENT

ROTATE BOTH RATCHET WHEELS UNTIL LATCH PAWL DROPS INTO INDENTATIONS OF BOTH RATCHET WHEEL FLANGES. DEPRESS DRIVE PAWL DOWNWARD OUT OF ENGAGEMENT WITH RATCHET TEETH AND TAKE UP PLAY BETWEEN LATCH PAWL AND RATCHET WHEELS BY MOVING RATCHET WHEELS BACKWARD (COUNTER-CLOCKWISE). WITH ECCENTRIC FOLLOWER DRIVE ARM AT END OF ITS EXTREME LEFT TRAVEL, POSITION DRIVE PAWL ON DRIVE ARM SO POINT OF UPPER BEVELED EDGE OF PAWL RESTS ON PEAK OF FIRST RATCHET WHEEL TOOTH TO RIGHT OF VERTICAL CENTERLINE THROUGH RATCHET WHEELS OR OVERTRAVELS PEAK.

MIN. SOME
 MAX. 0.010 INCH

TO ADJUST

WITH MOUNTING SCREWS LOOSENED, POSITION DRIVE PAWL ON ITS DRIVE ARM.

3.73 Time Delay Motor Stop Mechanism continued

(J) TIME DELAY ECCENTRIC FOLLOWER DRIVE ARM SPRING

REQUIREMENT


ECCENTRIC FOLLOWER DRIVE ARM AT END OF ITS
EXTREME RIGHT TRAVEL.

MIN. 3 OZS.

MAX. 4 OZS.

TO JUST START DRIVE PAWL MOVING DOWNWARD
AWAY FROM RATCHET WHEELS.

ECCENTRIC FOLLOWER
DRIVE ARM




(K) TIME DELAY DISABLING DEVICE

REQUIREMENT

DISABLE THE TIME DELAY MOTOR STOP
CONTACT MECHANISM WHEN NOT REQUIRED.

TO ADJUST

REMOVE PILOT SCREW FROM ITS UPPER MOUNT-
ING HOLE IN RATCHET WHEEL BRACKET AND
REINSTALL IT IN ITS LOWER MOUNTING HOLE
SO THAT IT HOLDS DRIVE PAWL OUT OF
ENGAGEMENT WITH RATCHET WHEELS.




3.74 Vacuum Chad Removal (Send-Receive Typing Reperforator Set)

VACUUM CHAD REMOVAL (SEND-RECEIVE TYPING REPERFORATOR SET)
REQUIREMENTS

- (1) DIRECTS THE PUNCHED CHAD TO A CONVENIENT DISPOSAL OUTSIDE THE SET.
- (2) SYNCHRONOUS MOTOR WITH OPEN TINES OF THE FAN WHEEL FACING AWAY FROM THE MOTOR PROVIDES POWER FOR CHAD DISPOSAL.
- (3) A NYLON BAG OR A NYLON CHUTE ATTACHED TO EXHAUST END OF FAN WHEEL ASSEMBLY FURNISHED AS ALTERNATE MEANS OF CHAD DISPOSAL OUTSIDE OF CABINET.

TO ADJUST
WITH MOUNTING HARDWARE FRICTION TIGHT POSITION CHAD CHUTE ASSEMBLY, TUBING, AND FAN WHEEL CASING ASSEMBLY SO THERE IS NO INTERFERENCE WITH ADJACENT UNITS.




4. EARLIER DESIGN MECHANISMS ADJUSTMENTS

4.01 Ribbon Feed Mechanism for Chadless Tape and Fully Perforated Tape
(For Later Design see Par. 2.59 and 2.60)

(A) RIBBON FEED PAWL SPRING REQUIREMENT

WITH ROCKER BAIL TO EXTREME LEFT
MIN. 10 OZS. --- MAX. 14 OZS.
TO PULL SPRING TO INSTALLED LENGTH.



(B) RIBBON FEED ECCENTRIC STUD REQUIREMENT


(1) WITH ROCKER BAIL TO EXTREME LEFT, THERE SHOULD BE
MIN. 0.012 INCH --- MAX. 0.028 INCH
BETWEEN RETAINING PAWL AND RATCHET
TOOTH ON SIDE WHERE CLEARANCE IS
LEAST.

TO ADJUST

- (1) UNITS EQUIPPED WITH ECCENTRIC STUD: POSITION STUD WITH LOCK NUT LOOSENED.
- (2) UNITS EQUIPPED WITH ADJUSTABLE ARM: BY MEANS OF PRY POINT, POSITION ADJUSTABLE ARM WITH MOUNTING SCREWS FRICTION TIGHT.

ECCENTRIC STUD
(LOCK NUT ON
OTHER END)

ROCKER BAIL



NOTE: UNITS IN WHICH THE OLD STYLE ROCKER BAIL IS PRESENT, POSITION THE ECCENTRIC IN ITS NEUTRAL POSITION AND MAKE THE ADJUSTMENT WITH THE ADJUSTABLE DRIVE ARM.


4.02 Ribbon Feed Mechanism for Chadless Tape and Fully Perforated Tape continued

(A) RIBBON FEED DRIVE ARM SPRING REQUIREMENT

WITH UNIT IN STOP POSITION
 MIN. 3 OZS. --- MAX. 5 OZS.
 TO PULL SPRING TO INSTALLED LENGTH.

(C) RIBBON RATCHET WHEEL SPRING WASHERS REQUIREMENT

WITH FEED PAWL AND RETAINING PAWL SHIFTED TO OPPOSITE RATCHET WHEEL
 MIN. 1 OZ. --- MAX. 2-1/2 OZS.
 TO START WHEEL TURNING.
 TO ADJUST
 REMOVE RETAINING RING AND BEND SPRING WASHER.
NOTE:
 MAKE THIS ADJUSTMENT FOR BOTH RATCHET WHEELS.



(B) RIBBON FEED PAWL DOWNSTOP ECCENTRIC TO CHECK

DISENGAGE FUNCTION CLUTCH. TAKE UP BACKLASH IN RATCHET WHEEL SO THAT CLEARANCE BETWEEN FEED PAWL AND RATCHET TOOTH IS AT MINIMUM. MEASURE CLEARANCE. REPEAT FOR OTHER RATCHET WHEEL.

REQUIREMENT

- (1) CLEARANCE BETWEEN FEED PAWL AND RATCHET TOOTH
 MIN. 0.020 INCH --- MAX. 0.040 INCH
 ON SIDE WHERE CLEARANCE IS LEAST.
- (2) PAWL SHOULD FEED ONE TOOTH AT A TIME.

TO ADJUST

POSITION DOWNSTOP ECCENTRIC WITH LOCK NUT LOOSENED.

RETAINING PAWL

(REAR VIEW)

DOWNSTOP ECCENTRIC
 (LOCK NUT ON OTHER END)

4.03 Ribbon Feed Mechanism for Chadless Tape and Fully Perforated Tapé continued

(A) RIBBON REVERSING PLATE
TO CHECK

POSITION ROCKER BAIL TO EXTREME LEFT. HOLD REVERSING ARM UNDER REVERSING PLATE AND MEASURE CLEARANCE. WITH FEED PAWL AGAINST OTHER RATCHET, REPEAT PROCEDURE FOR OTHER REVERSING ARM.

REQUIREMENT


CLEARANCE BETWEEN REVERSING ARM AND REVERSING PLATE

MIN. 0.010 INCH---MAX. 0.020 INCH

AT REVERSING ARM WHERE CLEARANCE IS LEAST.

TO ADJUST


POSITION REVERSING PLATE WITH CLAMP SCREW LOOSENED.




(B) RIBBON FEED REVERSING ARM SPRING
REQUIREMENT

WITH FEED PAWL IN HIGHEST POSITION
MIN. 10 GRAMS TO 30 GRAMS
TO START REVERSING ARM MOVING.

4.04 Signal Bell Contact Mechanism (For Later Design see Par. 3.02)



4.05 Letters - Figures Contact Mechanism
(For Later Design see Par. 3.12 and 3.16)



(REAR VIEW)


MOUNTING BRACKET REQUIREMENT

WITH UNIT IN LETTERS CONDITION AND FUNCTION CLUTCH DISENGAGED, LEFT SIDE OF CONTACT SHOULD BE CLOSED.

TO ADJUST

WITH MOUNTING NUTS LOOSENED, ROTATE MOUNTING BRACKET UNTIL LEFT SIDE OF CONTACT JUST CLOSSES AND NOTE POSITION OF ACTUATING BLADE. ROTATE BRACKET FURTHER UNTIL ACTUATING BLADE IS APPROXIMATELY 0.020 INCH BEYOND NOTED POSITION.

POSITION OF BLADE AT INITIAL CLOSURE



TO CHECK

RECORD START AND END OF TRACE OF RIGHT SIDE OF FRONT TIMING CONTACT. CONNECT NEON TRACE LAMP ACROSS LEFT SIDE OF LETTERS-FIGURES CONTACT. ALTERNATELY SELECT LETTERS (12345) AND FIGURES (12-45) CODE COMBINATIONS AND OBSERVE TRACE. SET START-ZERO MARK OF TEST SET SCALE AT START OF TRACE.


REQUIREMENT

- (1) LEFT SIDE OF LETTERS-FIGURES CONTACT SHOULD CLOSE BEFORE RIGHT SIDE OF TIMING CONTACTS CLOSE AND SHOULD OPEN AFTER RIGHT SIDE OF TIMING CONTACTS OPEN.
- (2) NO BOUNCE OR CHATTER OF LETTERS-FIGURES CONTACT DURING PART OF FUNCTION CYCLE WHEN RIGHT SIDE OF TIMING CONTACTS ARE CLOSED.

4.06 Noninterfering BLANK Tape Feed-Out Mechanism (Earlier Design)
 (For Later Design see Par. 3.36)


(A) FEED OUT BRACKET REQUIREMENT

OUTER RATCHET CHECK PAWL RIDING FULLY ON RATCHET WHEN PLAY IS TAKEN UP IN EITHER DIRECTION. TO ADJUST POSITION FEED OUT BRACKET WITH MOUNTING SCREWS LOOSENED.



(B) DRIVE ARM SHAFT REAR BEARING REQUIREMENT


DRIVE ARM SHAFT FINGER FREE IN ITS BEARINGS. TO ADJUST POSITION REAR BEARING WITH MOUNTING SCREWS LOOSENED.



(C) DRIVE ARM REQUIREMENT

- (1) WHEN PLAY IS TAKEN UP TO MAKE IT MINIMUM, AT LEAST SOME CLEARANCE BETWEEN DRIVE ARM AND FUNCTION CAM.
- (2) DRIVE ARM SHOULD ENGAGE FULL THICKNESS OF RELEASE ARM.

TO ADJUST POSITION DRIVE ARM ON SHAFT WITH CLAMP SCREW LOOSENED.



4.07 Noninterfering BLANK Tape Feed-Out Mechanism continued



RELEASE ARM

REQUIREMENT

WITH DRIVE ARM ON HIGH PART OF
ECCENTRIC COLLAR, CLEARANCE
BETWEEN DRIVE ARM AND RELEASE ARM
MIN. 0.003 ---- MAX. 0.010 INCH.

TO ADJUST

POSITION RELEASE ARM PIVOT SHAFT IN
ELONGATED MOUNTING HOLE WITH
CLAMP NUT LOOSENED.



NOTE: FEED PAWL MUST BE DISENGAGED
FROM FEED WHEEL RATCHET.

4.08 Noninterfering BLANK Tape Feed-Out Mechanism continued

(A) FEED OUT PAWL TO CHECK

WITH UNIT OPERATING UNDER POWER, ALLOW FEED OUT OPERATION TO BE INTERRUPTED BY AN INCOMING MESSAGE.

REQUIREMENT

FEED HOLE AND CODE HOLES OF FIRST CHARACTER ON SAME CENTER LINE.

TO ADJUST




WITH POWER OFF, CHECK DETENT ROLLER FOR FULL ENGAGEMENT WITH RATCHET. LATCH FEED OUT MECHANISM IN OPERATED POSITION.

POSITION MAIN SHAFT SO THAT DRIVE ARM IS ON HIGH PART OF ECCENTRIC COLLAR. WITH CLAMP SCREW LOOSENED, POSITION FEED OUT PAWL AGAINST FIRST RATCHET TOOTH TO LEFT OF VERTICAL CENTER LINE.

TIGHTEN CLAMP SCREW FRICITION TIGHT. ROTATE MAIN SHAFT UNTIL FEED OUT PAWL HAS RETRACTED

MIN. 0.020 INCH---MAX. 0.030 INCH

REPOSITION PAWL AGAINST TOOTH. TIGHTEN CLAMP SCREW. RECHECK REQUIREMENT.



(B) FEED OUT PAWL SPRING REQUIREMENT



MIN. 1/2 OZ.---MAX. 2 OZS. TO START PAWL MOVING.

NOTE: AFTER COMPLETION OF A MESSAGE (FEED OUT MECHANISM UNLATCHED) THE FEED OUT PAWL SHOULD REST ON THE UPPER PORTION OF A FEED WHEEL RATCHET TOOTH AND SHOULD NOT ENGAGE THE VERTICAL FACE OF ANY TOOTH. REFINE ADJUSTMENT IF NECESSARY.

4.09 Noninterfering BLANK Tape Feed-Out Mechanism continued

(A) ARMATURE HINGE

REQUIREMENT
 WITH ARMATURE HELD AGAINST
 MAGNET CORE
 MAX. 0.003 INCH
 BETWEEN ARMATURE AND
 MAGNET MOUNTING BRACKET.
 TO ADJUST
 WITH MOUNTING SCREW AND
 ARMATURE SPRING POST LOOSENED,
 POSITION ARMATURE HINGE.



(C) ARMATURE SPRING
 REQUIREMENT
 MIN. 7 OZS. --- MAX. 8 OZS.
 TO PULL SPRING TO INSTALLED
 LENGTH.

(REAR VIEW)

(B) MAGNET MOUNTING BRACKET
 TO CHECK

PLACE TAPE-OUT MECHANISM IN UNOPERATED CONDITION (MAGNET DE-ENERGIZED AND DRIVE ARM LATCHED BY RELEASE ARM). TAKE UP ALL CLEARANCE BETWEEN LOCK LEVER ROLLER AND ARMATURE BAIL.

REQUIREMENT
 CLEARANCE BETWEEN MAGNET CORE AND ARMATURE ANTI-FREEZE BUTTON
 MIN. 0.020 INCH --- MAX. 0.025 INCH

TO ADJUST
 BY MEANS OF PRY POINT, POSITION MAGNET MOUNTING BRACKET WITH MOUNTING SCREWS LOOSENED.

4.10 Noninterfering BLANK Tape Feed-Out Mechanism continued

(A) RELEASE ARM LATCH


REQUIREMENT

(1) WITH KICK-OUT ROLLER POSITIONED AWAY FROM LOCK LEVER AND MAGNET ENERGIZED, CLEARANCE BETWEEN RELEASE ARM AND RELEASE ARM LATCH

MIN. SOME---MAX. 0.005 INCH

(2) WHEN FEED OUT PAWL IS TOO EXTREME RIGHT, IT SHOULD FULLY ENGAGE A RATCHET TOOTH WHEN MAGNET IS ENERGIZED.

TO ADJUST POSITION LATCH SHAFT IN ELONGATED HOLE WITH LOCK NUT LOOSENED.



(B) RELEASE ARM LATCH SPRING


REQUIREMENT

MIN. 1-1/2 OZS. --- MAX. 2-1/2 OZS.
TO PULL SPRING TO INSTALLED LENGTH.

4. 11 Noninterfering BLANK Tape Feed-Out Mechanism continued

(B) METERING FEED PAWL SPRING REQUIREMENT
 WITH DRIVE ARM LATCHED BY RELEASE ARM
 MIN. 2-1/2 OZS. ---MAX. 4-1/2 OZS.
 TO PULL SPRING TO INSTALLED LENGTH.

(C) OUTER RATCHET CHECK PAWL SPRING REQUIREMENT
 MIN. 2-1/2 OZS. ---MAX. 4-1/2 OZS.
 TO PULL SPRING TO MAX. INSTALLED LENGTH.



- (A) LIFTER LEVER REQUIREMENT
 WITH FEED-OUT MECHANISM IN OPERATED CONDITION (RELEASE ARM LATCHED)
 PRELIMINARY
- (1) METERING FEED PAWL SHOULD FULLY SEAT IN DEEP NOTCHES OF INNER METERING RATCHET.
 - (2) SOME CLEARANCE BETWEEN RELEASE ARM AND LIFTER LEVER WHEN PLAY IN LIFTER LEVER IS TAKEN UP TO MAKE CLEARANCE MAX.
 - (3) WITH RELEASE ARM UNLATCHED, FEED PAWL SHOULD CLEAR ALL RATCHET TEETH.

TO ADJUST WITH LOCK NUT LOOSENED, POSITION LIFTER LEVER BY MEANS OF ITS ECCENTRIC SHAFT.

4.12 Noninterfering BLANK Tape Feed-Out Mechanism continued

(A) INNER RATCHET CHECK PAWLTO CHECK

WITH FEED-OUT MECHANISM IN OPERATED CONDITION (DRIVE ARM UNLATCHED), PRESENT A DEEP NOTCH OF BOTH RATCHETS TO METERING FEED PAWL AND POSITION PAWL TO EXTREME LEFT.


REQUIREMENT

CLEARANCE BETWEEN INNER RATCHET CHECK PAWL AND RATCHET TOOTH

MIN. 0.005 INCH---MAX. 0.015 INCH

TO ADJUST

POSITION CHECK PAWL MOUNTING PLATE WITH MOUNTING SCREWS LOOSENED.

(B) INNER RATCHET CHECK PAWL SPRINGREQUIREMENT

MIN. 1/2 OZ.---MAX. 1-1/2 OZS.

TO PULL CHECK PAWL AWAY FROM RATCHET.


TO ADJUST

POSITION SPRING WITH LOCK NUT LOOSENED. ROTATING SPRING CLOCKWISE INCREASES TENSION; ROTATING SPRING COUNTERCLOCKWISE DECREASES TENSION.

4.13 Noninterfering BLANK Tape Feed-Out Mechanism continued

NOTE

LOOSEN THE STRIPPER BAIL CLAMP SCREW AND TAKE UP THE PLAY BETWEEN THE STRIPPER BAIL AND THE SHAFT IN A CLOCKWISE DIRECTION BEFORE MAKING THE FOLLOWING ADJUSTMENT. TIGHTEN THE STRIPPER BAIL CLAMP SCREW.



(A) NONINTERFERING CLAMP ARM

(1) TO CHECK


WITH ITS MOUNTING SCREW LOOSENED, TAKE UP PLAY IN NONINTERFERING ARM IN CLOCKWISE DIRECTION. TIGHTEN MOUNTING SCREW. POSITION RESET BAIL ON HIGH PART OF ITS CAM.

REQUIREMENT

MIN. 0.002 INCH---MAX. 0.015 INCH
BETWEEN RELEASE ARM AND RELEASE ARM LATCH.

(2) REQUIREMENT


MIN. SOME---MAX. 0.006 INCH
END PLAY BETWEEN CLAMP ARM AND BUSHING.
TO ADJUST
WITH CLAMP SCREW LOOSENED, POSITION
CLAMP ARM.




(B) OUTER RATCHET RETURN SPRING

REQUIREMENT


WITH DRIVE ARM LATCHED BY
RELEASE ARM
MIN. 2 OZS. ---- MAX. 3 OZS.
TO PULL SPRING TO INSTALLED
LENGTH.



4. 14 Noninterfering BLANK Tape Feed-Out Mechanism continued



4. 15 Noninterfering BLANK Tape Feed-Out Mechanism continued



TO INCREASE TAPE LENGTH:
ROTATE PLATE CLOCKWISE.

TO DECREASE TAPE LENGTH:
ROTATE PLATE COUNTERCLOCKWISE.

TAPE LENGTH ADJUSTING PLATE

NOTE:


AMOUNT OF TAPE FED OUT CAN BE SET FOR ANY LENGTH UP TO 17 INCHES.

REQUIREMENT

- (1) WHEN UNIT IS OPERATING UNDER POWER AND FEED-OUT MAGNET IS ENERGIZED, CORRECT LENGTH OF TAPE SHOULD BE FED OUT.
- (2) WHEN UNIT IS NOT OPERATING UNDER POWER AND THE FEED-OUT MECHANISM IN ITS LATCHED POSITION, MANUALLY POSITION RATCHET SO THE NEXT FEED-OUT CYCLE WILL CAUSE FEED-OUT MECHANISM TO STOP. MANUALLY HOLDING FEED PAWL AGAINST THE RATCHET, ROTATE MAIN SHAFT UNTIL RELEASE ARM LATCH RELEASES RELEASE ARM AND FEED PAWL IS IN ITS EXTREME LEFT POSITION. CLEARANCE BETWEEN RELEASE ARM AND THE RELEASE ARM LATCH
MIN. SOME---MAX. 0.080 INCH

TO ADJUST
WITH SPRING POST LOOSENED, POSITION TAPE LENGTH ADJUSTING PLATE.

4.16 Noninterfering BLANK Tape Feed-Out Mechanism continued



(A) DRIVE ARM SPRING
 REQUIREMENT
 WITH DRIVE ARM ON LOW
 PART OF ECCENTRIC COLLAR:
 MIN. 3 OZS. ---- MAX. 5 OZS.
 TO START ARM MOVING.

(B) RELEASE ARM SPRING
 REQUIREMENT
 WITH DRIVE ARM LATCHED BY
 RELEASE ARM:
 MIN. 12 OZS. ---- MAX. 15 OZS.
 TO PULL SPRING TO INSTALLED
 LENGTH.

4.17 Noninterfering BLANK Tape-Feed-Out Mechanism continued

NOTE:



- (1) FOR UNITS EQUIPPED WITH SWITCH IN PLACE OF CONTACTS(SEE PAR. 4.19).
- (2) IN THIS FIGURE, REFERENCES TO LEFT OR RIGHT INDICATE THE VIEWERS LEFT OR RIGHT AS HE FACES THE REAR OF THE EQUIPMENT.

CONTACT SPRINGS

(1) REQUIREMENT

ALL SPRINGS PARALLEL TO REAR EDGE OF MOUNTING BRACKET AND CONTACT ACTUATING LEVER ENGAGE CONTACT BUTTON BY A MINIMUM OF 75% OF THE CONTACT BUTTON.

TO ADJUST POSITION SPRINGS WITH MOUNTING SCREWS LOOSENED.



- (2) REQUIREMENT
LEFT CONTACT SPRING APPROXIMATELY PARALLEL TO FACE OF MOUNTING BRACKET.

TO ADJUST BEND LEFT CONTACT SPRING.


- (3) REQUIREMENT
WITH CONTACT LEVER FREE OF CENTER CONTACT SPRING
MIN. 20 GRAMS---MAX. 40 GRAMS
TO JUST OPEN LEFT SIDE OF CONTACT.

TO ADJUST BEND CENTER CONTACT SPRING.

- (4) REQUIREMENT
WITH CONTACT LEVER AWAY FROM CENTER CONTACT SPRING
MIN. 0.010 INCH---MAX. 0.018 INCH
GAP AT RIGHT SIDE OF CONTACT.

TO ADJUST BEND CONTACT SPRING.

4. 18 Noninterfering BLANK Tape-Feed-Out Mechanism continued

(A) CONTACT LEVER TO CHECK

FULLY LATCH RELEASE ARM ON RELEASE ARM LATCH. HOLD CENTER CONTACT SPRING AWAY FROM CONTACT LEVER. ALLOW CONTACT LEVER'S EXTENSION TO REST AGAINST LATCH. MEASURE CLEARANCE BETWEEN FEED-OUT BRACKET AND CONTACT LEVER AT TOP OF LEVER.

REQUIREMENT

MIN. SOME---MAX. 0.020 INCH

TO ADJUST

POSITION CONTACT LEVER WITH CLAMP SCREW LOOSENED. (FOR POSITION OF CLAMP SCREW SEE ILLUSTRATION BELOW.)

(B) CONTACTING MOUNTING BRACKET REQUIREMENT

WITH RELEASE ARM UNLATCHED

MIN. 0.010 INCH---MAX. 0.040 INCH BETWEEN CONTACT LEVER AND CENTER CONTACT SPRING.

TO ADJUST

POSITION MOUNTING BRACKET WITH MOUNTING SCREW AND NUT LOOSENED.

NOTE: BY MEANS OF TEST LAMP, CHECK CONTINUITY OF CONTACT WITH CONTACT LEVER IN EACH POSITION.

CONTACT MOUNTING BRACKET

MOUNTING SCREW AND NUT


(C) CONTACT LEVER SPRING REQUIREMENT

MIN. 3 OZS.---MAX. 6 OZS. TO PULL TO INSTALLED LENGTH.

(D) CONTACT PULSE CLOSURE


NOTE: PRECEDING ADJUSTMENTS SHOULD BE MADE PRIOR TO THIS ADJUSTMENT.

EXTERNAL CIRCUITRY MAY REQUIRE A PULSE AT END OF FEED-OUT OPERATION. TO OBTAIN THIS CONDITION, REMOVE CLAMP SCREW AND ADJUSTING BRACKET AND HOOK CONTACT LEVER SPRING IN TAPPED HOLE. CONTACTS WILL THEN BE OPEN OR CLOSED, DEPENDING ON CHOICE OF CONTACT, EXCEPT FOR SHORT PERIOD AT END OF FEED-OUT OPERATION.



4. 19 Noninterfering BLANK Tape Feed-Out Mechanism continued

(For Units Equipped with Contacts in Place of Switch see Par. 4. 17)




4.20 Noninterfering BLANK Tape Feed-Out Mechanism continued

(A) SWITCH LEVER ADJUSTING BRACKET
REQUIREMENT

WITH CLUTCHES DISENGAGED AND FEED OUT MECHANISM IN UNOPERATED CONDITION (DRIVE ARM LATCHED BY RELEASE ARM MIN. SOME---MAX. 0.010 INCH CLEARANCE BETWEEN SWITCH LEVER AND SWITCH ACTUATOR.

TO ADJUST POSITION ADJUSTING BRACKET ON SWITCH LEVER WITH CLAMP SCREW LOOSENED.

(B) FEED OUT SWITCH (WITH PULSE CLOSURE)

NOTE: EXTERNAL CIRCUITRY MAY REQUIRE A PULSE AT END OF FEED-OUT OPERATION: TO OBTAIN THIS CONDITION, REMOVE ADJUSTING BRACKET AND HOOK SPRING IN TAPPED HOLE IN SWITCH LEVER. SWITCH WILL THEN BE CLOSED EXCEPT FOR SHORT PERIOD AT END OF FEED-OUT OPERATION. FOR REVERSE CONDITION---I.E. SWITCH OPEN EXCEPT FOR SHORT PERIOD AT END OF OPERATION---REMOVE WHITE AND BLUE LEAD AND SOLDER TO SPARE TERMINAL.

TO CHECK


SAME AS FEED OUT SWITCH EXCEPT 0.040 INCH GAUGE SHOULD BE SUBSTITUTED FOR 0.045 INCH GAUGE.

REQUIREMENT

SWITCH SHOULD NOT OPERATE WHEN 0.040 INCH GAUGE IS BETWEEN FRAME AND LEVER, AND SHOULD OPERATE WHEN 0.020 INCH GAUGE IS IN SAME POSITION.


TO ADJUST

SAME AS FEED OUT SWITCH.




4. 21 Multiple Mounted Function Blade Contacts
(For later design see par 3.56)

NOTE 1:
THE FOLLOWING ADJUSTMENTS SHOULD BE MADE PRIOR TO
INSTALLING THE CONTACT BRACKET ASSEMBLY ON UNIT.



NOTE 2:
THE FOLLOWING ADJUSTMENTS SHOULD BE
MADE AFTER THE CONTACT BRACKET
ASSEMBLY IS MOUNTED ON THE UNIT.



NOTE 3:
SELECT EACH FUNCTION BLADE IN TURN AND DETERMINE
THAT THERE IS A DEFINITE TRANSFER FROM MAKE TO
BREAK CONTACTS. REFINE ABOVE ADJUSTMENT.

28 REPERFORATOR AND TAPE PRINTER BASES

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1	Tape-Out Mechanism	
2. RECEIVE-ONLY BASES	3	Switch lever spring	12
Intermediate Drive Mechanism		Tape-out lever	12
Gear mesh	5	Tape-out lever spring	12
Timing belt	5	Tape-out switch assembly	12
Wire tape guide	5	5. RECEIVE-ONLY MINIATURIZED TAPE PRINTER BASE	14
Tape-Out Mechanism		Pinion and gear	14
Switch lever	4	6. RECEIVE-ONLY MINIATURIZED TYPING REPERFORATOR BASE	16
Switch lever springs	3	Base Assembly and Variable Speed Mechanism	
Switch mechanism mounting plate . . .	4	Variable speed mechanism	19
Tape-out lever	3	Vibration isolator immobilization . . .	19
Tape-out lever spring	3	Tape Container Assembly	
Variable Speed Drive Mechanism		Low tape switch	18
Gear assembly	7	Switch bail spring	18
Gear shift guide plate	6	Tape container	17
Grease retainer plate	7	Tape-out switch	18
Motor adjusting stud	7	Tape sensing bail spring	18
Timing belt	7	Tape Guide and Control Panel Bracket	
3. MULTIPLE RECEIVE-ONLY BASES . . .	9	Control panel bracket	16
Drive Mechanism		Tape guide	16
Timing belt	9	7. SLIDING SUBBASE	21
Motor adjusting stud	11	Quick disconnect knob	21
Tape-Out Mechanism		Quick disconnect latch	21
Tape-out lever spring	10	Stabilizing bracket	21
Tape-out switch assembly	10	1. GENERAL	
4. AUXILIARY RECEIVE-ONLY BASES . . .	12	1.01 This section contains the sepcific adjust- ments for the following 28 reperforator and tape printer bases:	
Drive Mechanism			
Intermediate drive assembly	13		
Tape container	13		
Timing belt	13		

SECTION 573-121-700

- (a) Receive-only base
- (b) Multiple receive-only base
- (c) Auxiliary receive-only base
- (d) Receive-only miniaturized tape printer base
- (e) Receive-only miniaturized typing re-perforator base
- (f) Sliding subbase

Note: Remove power from set (or unit) before making adjustment.

1.02 This section has been revised to include recent engineering changes and additions, and to rearrange the text so as to bring the section generally up-to-date. Since this is an extensive revision, marginal arrows ordinarily used to indicate changes have been omitted.

1.03 Maintenance procedures which apply only to mechanisms of a particular design, or to certain models of 28 bases, are so indicated in the titles of the paragraphs which contain these particular adjustment requirements.

1.04 The adjustments are arranged in a sequence that should be followed if a complete readjustment of the unit were undertaken. The tools and spring scales required to perform these adjustments are listed in the applicable section. After an adjustment is completed, be sure to tighten any nuts or screws that are loosened. The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions and the angles at which scales should be applied when measuring spring tension. If a part mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same number is replaced when the part is remounted.

1.05 References made to left or right, up or down, front or rear, etc apply to the unit as viewed from the front (Figures 1, 2, 3 and 4).

1.06 All electrical contact points should meet squarely. Contacts with the same diameter should not be out of alignment more than 25 per cent of the contact diameter. Check contacts for pitting and corrosion and clean or burish them before making specified adjustment or tolerance measurement. Avoid sharp kinks or bends in the contact springs.

CAUTION: KEEP ALL ELECTRICAL CONTACTS FREE OF OIL AND GREASE.




Figure 1 - 28 Receive-Only Reperforator Base (Rear View)


2. RECEIVE-ONLY BASES

2.01 Tape-Out Mechanism

(A) TAPE-OUT LEVER
REQUIREMENT

TAPE-OUT LEVER SHOULD BE ABLE TO PUSH BOTH SWITCH LEVERS AWAY FROM SWITCH ACTUATORS BUT SHOULD NOT BE ABLE TO LIFT WOOD FILLER WITH DEPLETED TAPE ROLL OUT OF SLOTS IN TAPE CONTAINER.

TO ADJUST
IF REQUIREMENT IS NOT MET, CHECK TAPE-OUT LEVER AND SWITCH LEVER SPRING TENSIONS (BELOW).




(B) TAPE-OUT LEVER SPRING

REQUIREMENT

MIN. 6 OZS. -----MAX. 8 OZS.
TO PULL SPRING TO LENGTH OF 1-17/32 INCHES.

TAPE-OUT LEVER SPRING



(RIGHT SIDE VIEW)

(C) SWITCH LEVER SPRINGS (2)

REQUIREMENT


MIN. 1-3/4 OZS. -----MAX. 2-1/4 OZS.
TO PULL SPRING TO LENGTH OF 1-5/16 INCHES.

2.02 Tape-Out Mechanism continued

NOTE 1:

THE INNER ELEMENTS ARE THESE NEARER THE MOUNTING PLATE; THE OUTER ELEMENTS, THOSE FARTHER FROM THE MOUNTING PLATE

(RIGHT SIDE VIEW)



(A)
SWITCH LEVER

REQUIREMENT

(1) OUTER SWITCH SHOULD OPERATE BEFORE INNER SWITCH.

(2) BOTH SWITCHES SHOULD OPERATE WITHIN LIMITS OF MOTION OF TAPE-OUT LEVER AND WHEN DIAMETER OF TAPE ROLL IS REDUCED TO

FIRST 1-5/16 INCHES DIAMETER, THEN TO 1-3/16 INCHES DIAMETER (WHEN USING A 1 INCH DIAMETER CORE)

FIRST 2-7/16 INCHES DIAMETER, THEN TO 2-5/16 INCHES DIAMETER (WHEN USING A 2 INCH DIAMETER CORE)

TO ADJUST

BEND OUTER SWITCH LEVER TOWARD SWITCH ASSEMBLY.

NOTE 2:

ADJUSTMENT CAN BE FACILITATED BY REMOVING SWITCH MECHANISM FROM TAPE CONTAINER.

(B)
SWITCH MECHANISM MOUNTING PLATE

REQUIREMENT

OUTER SWITCH SHOULD JUST OPERATE WHEN DIAMETER OF TAPE ROLL IS REDUCED TO


1-5/16 INCHES WHEN USING A 1 INCH DIAMETER CORE.

2-3/8 INCHES WHEN USING A 2 INCH DIAMETER CORE.

TO ADJUST

POSITION MOUNTING PLATE WITH MOUNTING SCREWS LOOSENED.

(LEFT SIDE VIEW)



2.03 Intermediate Drive Mechanism

(A) TIMING BELT

REQUIREMENT


SLIGHT PRESSURE (8 ± 1 OZ.) AT CENTER OF SPAN SHOULD DEFLECT BELT:

MIN. $3/32$ INCH---MAX. $5/32$ INCH

CAUTION: BELT SHOULD NOT BE TIGHT.

TO ADJUST

POSITION INTERMEDIATE DRIVE ASSEMBLY WITH MOUNTING SCREWS LOOSENED.



TIMING BELT

(B) GEAR MESH

REQUIREMENT


MOTOR DRIVE GEAR AND INTERMEDIATE SHAFT DRIVEN GEAR SHOULD MESH AT RIGHT ANGLES.

TO ADJUST

POSITION DRIVE ASSEMBLY WITH MOUNTING SCREWS LOOSENED. RE-CHECK TIMING BELT ADJUSTMENT (ABOVE).

INTERMEDIATE DRIVE ASSEMBLY

MOUNTING SCREWS



(TOP VIEW)

(C)

WIRE TAPE GUIDE

REQUIREMENT

TAPE SHOULD PASS FREELY THROUGH WIRE GUIDE AND BE ALIGNED WITH PERFORATOR GUIDE ASSEMBLY.


TO ADJUST

BEND OR POSITION WIRE GUIDE

2.04 Variable Speed Drive Mechanism

GEAR SHIFT GUIDE PLATE

REQUIREMENT----WITH SPEED SELECTOR LEVER DETENTED IN CENTER POSITION, 100 W.P.M. DRIVING AND DRIVEN GEAR SHOULD MESH FULLY AND EDGE OF EACH GEAR SHOULD BE APPROXIMATELY IN LINE. (SEE NOTES 1 & 2)
TO ADJUST----WITH MOUNTING SCREWS FRICTION TIGHT, POSITION GUIDE PLATE TO LEFT OR RIGHT.




NOTE 1:
SPEED SELECTOR LEVER
(LIFT UPWARD AND MOVE Laterally WHILE ORIENTATING GEARS)

NOTE 2:
MOVABLE GEAR CLUSTER
(SLIDING SURFACES AND SHAFT SHOULD BE FREE OF BINDS)

GEAR ASSEMBLY MOUNTING SCREWS

2.05 Variable Speed Drive Mechanism continued







Figure 2 - 28 Multiple Reperforator Receive-Only Base (Front View)

3. MULTIPLE RECEIVE-ONLY BASES

3.01 Drive Mechanism

NOTE: THIS ADJUSTMENT SHOULD BE MADE FOR EACH TYPING REPERFORATOR UNIT.



REQUIREMENT

SLIGHT PRESSURE AT CENTER OF SPAN (8 ± 1 OZ.) SHOULD DEFLECT BELT.


MIN. $3/32$ INCH ---MAX. $5/32$ INCH

CAUTION: BELT SHOULD NOT BE TIGHT.

TO ADJUST:

WITH TWO ANCHOR BRACKET SCREWS AND THREE MOUNTING SCREWS LOOSENED, POSITION TYPING REPERFORATOR UNIT. TIGHTEN THREE MOUNTING SCREWS. PRESS ANCHOR BRACKET AGAINST BASE PLATE AND TIGHTEN SCREW HOLDING BRACKET TO REPERFORATOR. TIGHTEN SCREW HOLDING BRACKET TO BASE.

3.02 Tape-Out Mechanism



TAPE-OUT LEVER SPRING

REQUIREMENT

TAPE-OUT LEVER CAPABLE OF PUSHING SWITCH LEVER AWAY FROM SWITCH ACTUATOR BUT INCAPABLE OF LIFTING DISC WITH HUB WITH DEPLETED CARDBOARD TAPE ROLL OUT OF SLOTS IN CONTAINER.

NOTE: IF NECESSARY, HAND FORM RIGHT STOP TAB ON SPROCKET GUARD SO THAT IT WILL STOP ON TOP OF BEARING MOUNTING PLATE.

TAPE-OUT SWITCH ASSEMBLY

REQUIREMENT

SWITCH SHOULD OPERATE WHEN DIAMETER OF TAPE ROLL IS
 MIN. 2-3/8 INCH---MAX. 2-5/8 INCH
 (CHECK WITH TEST LAMP.)

TO ADJUST

WITH TWO MOUNTING SCREWS LOOSENED, POSITION SWITCH ASSEMBLY ON TAPE CONTAINER.


3.03 Motor Adjusting Stud

MOTOR ADJUSTING STUDREQUIREMENT

BARELY PERCEPTIBLE BACKLASH
BETWEEN DRIVE GEAR AND
DRIVEN GEAR AT THEIR CLOSEST
POINT.

TO ADJUST

WITH LOCK NUT LOOSENED,
POSITION ADJUSTING STUD.
TIGHTEN NUT WHILE HOLDING
STUD IN POSITION.

CAUTION:

IF MOTOR BECOMES BLOCKED FOR SEVERAL SECONDS, THERMAL CUT-OUT SWITCH WILL BREAK CIRCUIT. SHOULD THIS HAPPEN, ALLOW MOTOR TO COOL AT LEAST 5 MINUTES BEFORE DEPRESSING RED RESET BUTTON. CHECK UNIT TO SEE WHY MOTOR WAS BLOCKED.

4. AUXILIARY RECEIVE-ONLY BASE

4.01 Tape-Out Mechanism

TAPE-OUT SWITCH ASSEMBLY

REQUIREMENT

SWITCH JUST CLOSED
WHEN TAPE ROLL IS
REDUCED TO

2-3/8 INCH

TO ADJUST

POSITION SWITCH
ASSEMBLY WITH MOUNT-
ING SCREWS LOOSENED.

SWITCH LEVER SPRING

REQUIREMENT

MIN. 8-1/2 OZS. ---MAX. 10 OZS.
TO PULL SPRING TO 1-1/4
INCHES.


TAPE-OUT LEVER

REQUIREMENT

SWITCH LEVER OUT OF
ENGAGEMENT WITH SWITCH
ACTUATOR WHEN TAPE ROLL
REMOVED.

TO ADJUST

CHECK TAPE-OUT LEVER
AND SWITCH LEVER SPRING
TENSIONS. REPLACE SPRINGS
WHICH DO NOT MEET REQUIREMENTS.




TAPE-OUT LEVER SPRING

REQUIREMENT

MIN. 6 OZS. ---MAX. 8 OZS.
TO PULL SPRING TO 1-17/32
INCHES.

4.02 Drive Mechanism



5. RECEIVE-ONLY MINIATURIZED TAPE PRINTER BASE

5.01 Pinion and Gear


PINION-GEAR (FOR RECEIVE-ONLY MINIATURIZED TAPE PRINTER SET)

REQUIREMENT

BARELY PERCEPTIBLE BACKLASH BETWEEN MOTOR PINION AND DRIVEN GEAR MOUNTED IN SINGLE SPEED DRIVE ASSEMBLY.

TO ADJUST

LOOSEN FOUR MOUNTING SCREWS SECURING MOTOR TO UPPER BASE PLATE. INCREASE OR DECREASE BACKLASH BY ROTATING MIDDLE NUTS ON MOUNTING SCREWS OPPOSITE PINION END. TO INSURE MOTOR IS PROPERLY ALIGNED WITH DRIVEN GEAR, THE BOTTOM EDGE OF THE MOTOR MOUNT BRACKET OPPOSITE THE PINION END SHALL BE PARALLEL WITH UPPER BASE PLATE.








Figure 3 - 28 Receive-Only Miniaturized Base with Motor and Subbase
(Front View)

6. RECEIVE-ONLY MINIATURIZED TYPING REPERFORATOR BASE

6.01 Tape Guide and Control Panel Bracket




6.02 Tape Container Assembly



TAPE CONTAINER REQUIREMENT
 CLEARANCE BETWEEN THE REPERFORATOR AND THE TAPE CONTAINER ASSEMBLY AT ANY POINT
 MIN. 0.063 INCH--- MAX. 0.125 INCH
 TO ADJUST
 WITH MOUNTING SCREWS FRICTION TIGHT,
 POSITION TAPE CONTAINER ASSEMBLY.

6.03 Tape Container Assembly continued



SWITCH BAIL SPRING REQUIREMENT

MIN. 1-1/2 OZS. --- MAX. 2-1/2 OZS.
TO OPEN NORMALLY CLOSED SWITCH WHEN SPRING SCALE IS HOOKED UNDER TIP OF SWITCH BAIL AND ROTATED AWAY FROM SWITCH. TAPE SENSING BAIL SHOULD NOT TOUCH THE SWITCH BAIL.

TAPES SENSING BAIL SPRING REQUIREMENT

MIN. 3/4 OZ. --- MAX. 1-1/2 OZS.
TO MOVE TAPE SENSING BAIL TO THE INSIDE DIAMETER OF TAPE CONTAINER.

INSIDE DIAMETER OF TAPE CONTAINER

LOW TAPE SWITCH

NOTE :

THIS SWITCH IS NOT SUPPLIED WITH THIS BASE, HOWEVER, PROVISION IS MADE TO ACCEPT THE LOW TAPE SWITCH. IF THE SWITCH IS PROVIDED THE ADJUSTMENT IS AS FOLLOWS:

REQUIREMENT

THE SECOND OR TOP SWITCH LOCATED ON THE TAPE CONTAINER ASSEMBLY SHOULD OPERATE WHEN THE TAPE ROLL IN THE CONTAINER IS REDUCED TO 2-7/16 INCHES.

TO ADJUST

BEND THE UPPER PRONG OF SWITCH BAIL. RE-CHECK TAPE OUT SWITCH ADJUSTMENT.

TAPES-OUT SWITCH

REQUIREMENT

THE SWITCH SHOULD OPERATE WHEN THE TAPE ROLL IN THE CONTAINER IS REDUCED IN DIAMETER TO 2-5/16 INCHES.


TO ADJUST

BEND THE LOWER PRONG OF THE SWITCH BAIL.

6.04 Base Assembly and Variable Speed Mechanism

VIBRATION ISOLATOR IMMOBILIZATION REQUIREMENT

NO CLEARANCE BETWEEN TOP OF RUBBER ISOLATOR AND BOTTOM OF METAL WASHER WITH NO COMPRESSION OF THE RUBBER.
TO ADJUST
TURN THE ELASTIC STOP NUT.

VARIABLE SPEED MECHANISM (SEE PAR. 2.04 AND 2.05)

(1) REQUIREMENT

THERE SHOULD BE A BARELY PERCEPTIBLE AMOUNT OF BACKLASH BETWEEN THE MOTOR PINION AND THE DRIVEN GEAR AT THEIR CLOSEST POINT.

TO ADJUST

WITH THE FOUR MOUNTING SCREWS FASTENING THE VARIABLE SPEED DEVICE TO THE VIBRATION ISOLATORS FRICTION TIGHT, POSITION THE VARIABLE SPEED ASSEMBLY.

(2) REQUIREMENT

WITH SPEED SELECTOR LEVER DETENTED IN CENTER POSITION 100 W.P.M. THERE SHALL BE FULL MESH BETWEEN GEARS.

TO ADJUST

WITH THE GEAR SHIFT BRACKET MOUNTING SCREWS FRICTION TIGHT, POSITION GEAR SHIFT BRACKET.




Figure 4 - 28 Sliding Subbase Assembly For Miniaturized Receiving-Only Typing Reperforator Set (Extended - Front View)

7. SLIDING SUBBASE FOR MINIATURIZED RECEIVING-ONLY TYPING REPERFORATOR SET

7.01 Sliding Subbase

QUICK DISCONNECT LATCHREQUIREMENT


WITH SLIDE IN THE FULLY RETRACTED POSITION THE LOCKING CYLINDER OF THE QUICK - DISCONNECT DEVICE SHALL BE FIRMLY SEATED AGAINST THE STOP SURFACE OF THE BOTTOM PLATE:

--- MIN. 0.002 INCH --- MAX. 0.012 INCH

END PLAY BETWEEN LOCKING CYLINDER AND THE TWO MOUNTING BLOCKS.

TO ADJUST

WITH THE MOUNTING SCREWS OF THE TWO BLOCKS FRICTION TIGHT AND THE SLIDE FULLY DEPRESSED, POSITION THE TWO BLOCKS.

STABILIZING BRACKETREQUIREMENT

NO CLEARANCE BETWEEN THE PERMANENT STABILIZING SEGMENT OF LOWER BASE PLATE AND THE ADJUSTABLE STABILIZING STOP PLATE OF THE UPPER BASE PLATE WHEN THE SLIDE IS IN THE FULLY RETRACTED LOCKED POSITION.

TO ADJUST

WITH MOUNTING SCREWS OF EACH OF THE FOUR STABILIZING STOP PLATES FRICTION TIGHT, POSITION EACH STABILIZING STOP PLATE.

CHECK

TO INSURE THAT THERE IS NO ROTATION WHEN THE TOP AND BOTTOM PLATES ARE "ROTATED" TOWARD EACH OTHER WITHOUT BENDING EITHER OF THE PLATES,

QUICK DISCONNECT KNOBREQUIREMENT

WITH KNOBS IN THE OPEN POSITION:

MIN. 0.093 INCH --- MAX. 0.140 INCH

CLEARANCE BETWEEN COVER AND LOCKING

DEVICE KNOBS.

TO ADJUST

WITH THE TWO SET SCREWS IN EACH KNOB FRICTION TIGHT, POSITION KNOBS.

NOTE:

THE KNOB LOCKING CYLINDER ASSEMBLY MUST SNAP INTO THE LOCKED POSITION WHEN THE KNOBS ARE RELEASED FROM AN ANGULAR DISPLACEMENT OF APPROXIMATELY 45° FROM THE HORIZONTAL.



28 TRANSMITTER DISTRIBUTOR UNIT (LXD)

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	2	Start-Stop Switch Assembly and Tight-Tape Mechanism	
2. BASIC UNITS	4	Start-stop switch bracket.	17
Basic Gear Adjustments		Start-stop switch bracket (for units equipped with tape lid sensing lever) .	18
Intermediate gear — transmitter distributor gear backlash.	31	Tight-tape intermediate arm	19
Clutch Mechanism		Tight-tape intermediate arm spring	19
Armature bail spring	7	Tight-tape start-stop contact spring	17
Clutch latchlever spring	6	Tape Lid	
Clutch magnet assembly	7	Start-stop detent bail spring.	10
Clutch shoe lever.	5	Tape guide	9
Clutch shoe lever spring	4	Tape guideplate	11
Clutch shoe spring	4	Tape lid	8
Clutch trip lever	6	Tape lid release plunger spring	10
Clutch trip lever spring.	6	Tape lid spring	10
Main bail latch spring.	7	Tape-Out Switch Assembly	
Feed Wheel Mechanism		Depressor bail torsion spring.	15
Feed pawl.	22	Intermediate tape-out bail spring . . .	15
Feed pawl spring	22	Tape-out contact assembly.	14
Feed ratchet detent spring.	20	Tape-out contact bracket.	14
Feed wheel detent.	21	Tape-out sensing pin.	15
Main bail	20	Tape-out sensing pin (for units with tape lid sensing lever)	16
Main bail spring.	20	Tape-out sensing pin spring.	14
Main bail trip lever	20	Top and Cover Plates	
Sensing pin spring	21	Cover plate.	13
Main Bail and Transfer Mechanisms		Cover plate detent spring.	13
Locking bail spring.	23	Top plate	12
Main bail	24	3. VARIABLE FEATURES.	32
Stabilizer spring	25	Auxiliary Contacts	
Transfer bail stabilizer.	25	Auxiliary contact operating bail spring	41
Transfer lever spring.	23	Contact sensing arm.	41
Signal Contacts			
Drive link spring	26		
Signal contact clearance	26		
Signal contacts — electrical	27		
Signal contact spring.	26		

SECTION 573-127-703TC

CONTENTS	PAGE
Contact swinger — operating bail clearance	42
Normally closed contacts	40
Normally open contacts	40
Code Reading Contacts	
Contact assembly positioning	37
Contact sensing arm — up-stop clearance	38
Contact swinger — sensing arm clearance	37
Contact swinger — sensing arm clearance (strobing)	39
Normally closed contacts — backstop	36
Normally closed contacts — spring	36
Normally open contacts — gap	36
Normally open contacts — spring	36
Sensing arm spring	38
Sensing arm — transfer lever alignment	38
Split bail eccentric	38
Rub-Out Deleter	
Rub-out deleter bail guide	47
Rub-out deleter bail spring	47
Sensing pin spring	47
Start-Stop Pulse Contact	
Contact bracket	45
Contact bracket (strobing)	46
Contact gap (start and stop contacts)	45
Contact lever	45
Tape Deflector	
Tape deflector bracket	44
Tape deflector spring	44
Tape Feed Assurance Mechanism	
Detent lever spring	33
Tape motion contact gap	33
Tape motion contact swinger	33
Tape sensing feed wheel phasing	33

CONTENTS	PAGE
Tape Lid Sensing Lever	
Switch lever	43
Switch lever spring	43
Tape Notch Sensing Mechanism	
Contact bracket (strobing)	49
Tape notch sensing contact	48
Tape notch sensing pin spring	48
Tape-Out Mechanism	
Tape-out bail torsion spring	34
Tape-out contact	34
Tape-out pin	35
Tape-out pin spring	35
Tape Slack Arm	
Tape slack contacts	51
Tape Withhold Mechanism	
Blocking bail arm eccentric	52
Blocking bail eccentric pivot	52
Magnet armature gap	52
Tight-Tape and Tape Shoe Mechanism	
Tape shoe	32
Tight-tape switch	32
Torsion spring	32
Transmitter Stop Mechanism	
Start-stop contact gap (for tabulator control)	50
Timing bail spring	50
4. EARLY MODELS	53
Tape Lid Mechanism	
Tape lid	53
Tape lid release plunger spring (for units without tape lid spring)	54

1. GENERAL

1.01 This section provides specific adjustments for the single contact 28 transmitter distributor. It reflects 5- and 6-level operation for LXD unit.

1.02 The adjustments are arranged in a sequence that should be followed if a complete readjustment is undertaken. The tools and

spring scales required to perform these adjustments are found in tool section 570-005-800TC. A complete adjusting procedure should be read before attempting to make the adjustment. After an adjustment is completed, be sure to tighten any nuts or screws that may have been loosened. Where an illustration shows interrelated parts, the sequence that should be followed in checking the requirements and making the adjustments is indicated by the letters, (A), (B), (C), etc.

1.03 The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions, and the angle at which scales should be applied. Coil springs which do not meet the requirements, and for which there are no adjusting procedures, should be discarded and replaced with new springs. If a part mounted on shims is removed, the number of shims used at each mounting screw should be noted so that the same number is replaced when the part is re-mounted.

Note: Remove power from unit before making adjustments.

1.04 When the requirement calls for the clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latchlever so that the clutch shoes release their tension on the clutch drum. When engaged, the clutch shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum. When the main shaft is rotated by hand, the clutch does not fully disengage upon reaching its stop position. In order to relieve the drag on the clutch and permit the main shaft to rotate freely, apply pressure on a lug of the clutch disc with a screwdriver to cause it to engage its latchlever and thus disengage the internal expansion clutch shoes from the clutch drum.

1.05 The covers may be removed for inspection and minor repair of the unit; however, when more extensive maintenance is to be undertaken, it is recommended that the unit be disconnected from its source of power as a safety precaution.

1.06 References made to left, right, up, down, front, or rear, apply to the set in its operating position, as viewed from the operator's position.

1.07 All electrical contact points should meet squarely. Contacts with the same diameter should not be out of alignment more than 25 percent of the contact diameter. Check contacts for pitting and corrosion and clean or burnish them before making specified adjustment or tolerance measurement. Avoid sharp kinks or bends in the contact springs.

CAUTION: KEEP ALL ELECTRICAL CONTACTS FREE OF OIL AND GREASE.

1.08 Units may have signal contacts made of either unplated or gold-plated tungsten. If in doubt as to the type of contacts, remove contact box cover and inspect contacts for gold

plating. Do not use burnishers, files, etc which will remove gold plating.

1.09 Use twill jean cloth (KS2423) (TP107162) to clean gold-plated contacts. Open contacts. Allow contacts to close on surface of twill jean. Draw twill jean part way through. Open contacts and withdraw twill jean.

1.10 This procedure prevents small fibers at edges of twill jean strip from becoming lodged between contacts.

1.11 Clean unplated tungsten contacts in accordance with standard procedures (Paragraph 1.07).

Servicing For Certain Low-Voltage Applications

1.12 For standard applications, including those with data sets, observe standard maintenance procedures and intervals. Certain low-voltage applications are covered below.

1.13 For optimum reliable operation in these low-voltage applications, clean gold-plated contacts with twill jean, as instructed above, at intervals of approximately 50 hours of actual contact operation. Since maintenance interval and life expectancy of the contacts are dependent on the signal circuit, maintenance interval may be lengthened for specific applications.

Note 1: Applying operating voltage of standard Distortion Test Set directly to contacts may damage gold plating and impair low-voltage operation. When electrically adjusting or testing contacts (2.23), use an intermediate device, keyed by the contacts, to interrupt current to stroboscopic lamp of test set. This intermediate device must be capable of being keyed by a 3 to 20 volt change at maximum of 20 milliamperes.

Note 2: Normally for low-voltage applications, contacts should be used in circuits operating between 3 and 20 volts dc at a current level not to exceed 60 milliamperes. Between 20 and 70 volts dc the current should be adjusted so as not to exceed a 120 milliwatt power level. The contacts are not normally intended for use with voltages above 70 volts dc. Exceeding this level for an appreciable length of time may result in damage to the gold plating and make them unfit for low-voltage applications.


2. BASIC UNITS

2.01 Clutch Mechanism

Note 1: Remove the transmitter distributor from its base before making a complete re-adjustment or spring tension checks.

Note 2: Adjustments (A) and (B) are made at the factory and should not be disturbed unless good reasons exist that the requirements are not met.

(A) CLUTCH SHOE LEVER SPRING



To Check

Invert unit and rotate main shaft until clutch shoe lever and stop lug are up. With clutch engaged, hold cam disc to prevent turning.


Requirement

Min 15 oz---Max 20 oz
to move shoe lever in contact with stop lug.

(Where set is equipped with tape slack mechanism)

Min 9 oz---Max 11 oz

(Rear View)



(B) CLUTCH SHOE SPRING

To Check

Remove the clutch from the main shaft. With the clutch drum removed, hook spring scale as shown.

Requirement

Min 3 oz---Max 5 oz
to start primary shoe moving away from secondary shoe at point of contact.

(Rear View)

2.02 Clutch Mechanism (continued)

Note: Remove transmitter distributor from base before making adjustments.

(A) CLUTCH SHOE LEVER

To Check

Trip transmitter distributor clutch. Pull shoe lever opposite the stop lug with a force of 32 oz. Release the force slowly to engage clutch shoes. Note clearance between clutch shoe lever and stop lug. Disengage the clutch, and again pull the lever opposite the stop lug with a force of 32 oz. Release the force slowly. Note clearance between the shoe lever and the stop lug.


Requirement

Min 0.055 inch---Max 0.085 inch greater clearance with clutch engaged than with clutch disengaged.

To Adjust

Loosen clutch disc clampscrews. Place wrench over stop lug and move disc. Retighten screws.

Note: Drum must not drag on shoes when clutch is disengaged and rotated in its normal direction. Refine CLUTCH SHOE LEVER adjustment to correct shoe drag.



(Left Side View)

2.03 Clutch Mechanism (continued)

(D) CLUTCH LATCHLEVER SPRING

To Check

Trip clutch and rotate until latchlever is on low part of disc.

Requirement

Min 3 oz---Max 5 oz
to start clutch latchlever moving.

MAIN BAIL
(Front View)

CLAMP NUT

(B) CLUTCH TRIP LEVER

To Check

Trip transmitter distributor clutch.
With main bail in highest position,
rotate clutch until stop lug is opposite
trip lever.

(1) Requirement


With trip bail play taken up to
make clearance maximum.
Min 0.012 inch---Max 0.025 inch
between stop lug and trip lever.

(2) Requirement

With trip bail play taken up to make
clearance minimum
some clearance
between stop lug and trip lever.

To Adjust

Loosen clamp nut friction tight and
rotate trip bail eccentric post. Check
Requirement (1). Retighten clamp-
screw.



(C) CLUTCH TRIP LEVER SPRING

Requirement

With clutch engaged
Min 7 oz---Max 10-1/2 oz
to start clutch trip lever moving.

2.04 Clutch Mechanism (continued)

(A) CLUTCH MAGNET ASSEMBLY

(1) To Check

Place armature in attracted (energized) position.

Requirement

Armature to contact core face of top magnet with
 Min some---Max 0.004 inch
 between armature and core face of bottom magnet at point of least clearance. (Sets with Tape Shoe and Tape Feed Assurance Mechanisms
 Min 0.004 inch---Max 0.007 inch)

To Adjust

Remove magnet mounting bracket screws and lift clutch magnet assembly from the unit. Loosen mounting screws and position hinge.

(2) To Check

Place high part of backstop eccentric toward top of unit. Hold armature in attracted (energized) position.

Requirement

Min 0.045 inch---Max 0.055 inch
 between armature bail and backstop eccentric.

To Adjust

Loosen backstop clamp nut and position eccentric. Retighten backstop clamp nut.

(3) To Check

If clutch magnet assembly was removed in (1) To Check, replace it in unit to its lowest position. Tighten magnet mounting bracket screws friction tight. Disengage clutch.

Requirement

Min 0.007 inch---Max 0.015 inch
 between end of armature bail extension and main bail latch.

To Adjust

Position clutch magnet assembly using adjusting slot.

Note: Under ac power, armature "chatter" must be at a minimum. If excessive "chatter" is present, refine requirement under (1) To Check, and recheck requirements under (2) and (3) To Check.


(B) ARMATURE BAIL SPRING

To Check

Place armature in de-energized position and hold main bail latch lever away from armature bail extension.

Requirement

Min 1 oz---Max 2 oz
 (Sets with Tape Shoe and Tape Feed Assurance Mechanisms only
 Min 3-3/4 oz---Max 4-3/4 oz)
 to start bail moving.



(C) MAIN BAIL LATCH SPRING

To Check

Invert unit. Release main bail latch.

Requirement

Min 3/4 oz---Max 2 oz
 to start main bail latch moving.

2.05 Tape Lid

TAPE LID


To Check

Remove top plate and tape guideplate.
Lubricate before adjustment.

(1) Requirement

With tape lid held against notch in tape guideplate, feed wheel groove lined up with slot in tape guideplate, and tape-out pin holes lined up

Min some---Max 0.010 inch
between tape lid and pivot shoulder.



To Adjust

Loosen bracket mounting nuts. Insert tip of appropriate gauge (Note 1) through slot in tape guideplate and into feed wheel groove. Position bracket. Tighten nuts.

Note 1: Use one of the following three gauges in making this adjustment:

<u>TAPE</u>	<u>GAUGE</u>
5-Level	TP156743
6-Level	TP170311 (In-Line Feed Hole)
6-Level	TP173503 (Advance Feed Hole)

(2) Requirement

With front bearing surface of tape lid touching tape guideplate


Min 0.010 inch---Max 0.018 inch
between fin indicated and tape guideplate.

To Adjust

Loosen bearing bracket mounting screws. While pressing tape lid against tape guideplate, position bearing bracket. Recheck Requirement (1).

Note 2: If Requirement (2) cannot be met, position bearing bracket so that its mounting screws are located in centers of holes in bracket. Repeat Requirements (1) and (2).

Note 3: When tape guideplate and top plate are assembled to reader, tape lid may touch top plate, and a different clearance from that specified in Requirement (2) can be expected. However, with tape lid closed, there must always be at least 0.002 inch clearance between tape guideplate and heel pad.



(3) Requirement

With tape lid latched against tape guideplate, release plunger must have some endplay.

To Adjust

Loosen locknut. Raise tape lid and rotate high part of eccentric towards bearing bracket. Close tape lid and continue rotating high part of eccentric towards bearing bracket until latch bail just falls under flat on post. Recheck operation of latch bail by depressing release plunger with tape lid held down.

2.06 Tape Lid (continued)



TAPE GUIDE

To Check
Unlatch tape lid and position gauge as illustrated.

- (1) Requirement
Min some---Max 0.003 inch between gauge and each tape guide.
- (2) Requirement
Edge of wear plate flush with edge of tape guideplate.
- (3) Requirement
Tape must not ride up the sides of the tape guides.


To Adjust
Loosen mounting nuts. Position wear plate until it overhangs tape guideplate. Push gauge down until top two studs butt up against tape guideplate thus positioning edge of wear plate flush with edge of tape guideplate. Hold gauge and wear plate and position each tape guide to meet Requirement (1). Tighten mounting nuts.

Note: Tape guides may touch gauge, but they must not bind against gauge when it is removed.



(Bottom View)

2.07 Tape Lid (continued)



(Rear View)

(A) START-STOP DETENT BAIL SPRING

To Check
Place control lever in run position.

Requirement
Min 14 oz---Max 22 oz
to start detent bail moving away from control lever.

(B) TAPE LID RELEASE PLUNGER SPRING


To Check
Unlatch tape lid. Place tape guideplate in a horizontal position and hold it there.

Requirement
Min 28 oz---Max 48 oz
to start tape lid bail moving.

(C) TAPE LID SPRING


To Check
Hold release plunger fully depressed.
Hold tape guideplate in horizontal position.

Requirement
Min 2-1/2 oz---Max 4-1/2 oz
to move open end of tape lid against tape guideplate.



(Right Side View)

2.08 Tape Lid (continued)



(Front View)

Note 1: To prevent damage to the tape-out pin, position stop arm to its lowest position and hold control lever bail extension from feed wheel ratchet.

TAPE GUIDEPLATE

(1) Requirement

Feed wheel post is not to interfere with mounting brackets of top plate and tape guideplate.

To Adjust

Loosen clamp nut and rotate feed wheel post.

(2) Requirement

Tape guideplate to rest firmly against a minimum of three of the four projections on side plates.

To Adjust

Rotate unit clutch to its stop position. Trip clutch to put sensing pins in their highest positions. Unlatch tape lid and place control lever to run position. Loosen mounting screws and mounting nuts. Position tape guideplate on reader to meet Requirement (2). Position tape-out pin into hole in tape guideplate. Tighten mounting screws.

Note 2: Mounting nuts loosened in Requirement (2) are tightened after performing Requirement (3) and TOP PLATE adjustment.

(3) Requirement

Edge of tape guideplate to project over side plates by equal amounts as gauged by eye.

To Adjust

Position type guideplate.

Note 3: Tight-tape bail extension must be under top plate.

2.09 Top Plate

TOP PLATE

To Check

Remove cover plate and unlatch the tape lid.

(1) Requirement

Min flush---Max 0.003 inch
below top surface of tape guideplate
along width of tape lid when top plate
is resting on a minimum of five of the
six projections on side plates.

To Adjust

Loosen mounting screws and mounting
nuts friction tight. Position top plate.
Tighten mounting screws. Tighten tape
guideplate mounting nuts left friction
tight in TAPE GUIDEPLATE adjustment.

Note: Mounting nuts loosened in
Requirement (1) above are tightened
after performing Requirement (2)
below.

(2) Requirement

Feed wheel slot to align with slot in
tape guideplate so that feed wheel ro-
tates freely with control lever in free
position.

To Adjust


Position top plate toward one side plate
or the other. Tighten mounting nuts
left friction tight in Requirement (1)
above.

(3) Requirement

With tape lid latched
Min 0.010 inch at end of extension
covering feed wheel slot
Min 0.010 inch---Max 0.018 at tape
guideplate adjacent to sensing pins
Min 0.010 inch---Max 0.025 at all
other areas
between tape lid projection and top plate
with play taken up toward tape guide-
plate.

To Adjust

Loosen tape lid bearing bracket mount-
ing screws. Position tape lid. Recheck
TAPE LID adjustment, Requirements
(1) and (2).




2.10 Cover Plate

(A) COVER PLATE

- (1) Requirement
Right edge of cover plate holds flush against left edge of top plate by the cover plate detents.
- (2) Requirement
Cover plate rests against at least three of the four projections (front and rear plate).
- (3) Requirement
Front edge of cover plate and top plate align.

To Adjust


With detenting nut clampscrew (front and rear plate) friction tight, move clampscrews to their extreme lower right position, then tighten screws. Loosen detent bracket and spring plate mounting nuts. Place cover on unit and position horizontally to meet requirements. Retighten mounting nuts.



(B) COVER PLATE DETENT SPRING

Requirement

With spring scale applied to center of one detent
 --- Min 28 oz---Max 48 oz
 to start plunger moving.



Note: Outer edge of each mounting bracket should be approximately in line with shoulder of its mounting stud. Replace tape guideplate, tape-out tension spring, top plate, and cover plate.

(Bottom View)

2.11 Tape-Out Switch Assembly

(A) TAPE-OUT CONTACT ASSEMBLY

To Check

Loosen spring bracket and move downward until tape-out pin extension no longer touches insulation on contact swinger.

(1) Requirement


Min 8 grams---Max 15 grams to separate normally closed contacts.

(2) Requirement

Min 0.008 inch---Max 0.015 inch between normally open contacts.

To Adjust

Remove tape-out contact assembly from unit by unhooking tape-out pin spring and removing bracket mounting screws. Form contact swinger using TP110445 spring bender. Replace contact assembly with swinger over tape-out pin extension. Place spring bracket shoulder bushing on upper hole and the washer on lower mounting hole. Rehook tape-out pin spring.



(B) TAPE-OUT SENSING PIN SPRING

To Check


Place control lever in run position.

Requirement

Min 38 grams---Max 45 grams to move tape-out pin to a position flush with tape guideplate.

To Adjust

Loosen lower bracket mounting screw and position spring bracket to meet requirement. Retighten bracket mounting screw.



(C) TAPE-OUT CONTACT BRACKET

To Check


Insert tape under tape lid to hold tape-out pin down.

Requirement

Min 0.006 inch---Max 0.020 inch between tape-out pin upper extension and underside of insulation on swinger contact.

To Adjust

Loosen bracket mounting screws and adjust bracket. Retighten mounting bracket screws.



2.12 Tape-Out Switch Assembly (continued)

(B) DEPRESSOR BAIL TORSION SPRING

To Check

Place control lever in stop position.
Unhook one end of intermediate tape-out bail spring.

Requirement

Min 2-3/4 oz---Max 5-1/2 oz
to start tape-out bail moving away
from tape-out pin depressor bail.

(C) INTERMEDIATE TAPE-OUT BAIL SPRING

To Check

Place control lever in run position.
Unhook intermediate tape-out bail
spring at post end.

Requirement

Min 3 oz---Max 5 oz
*Min 2 oz---Max 3 oz
to pull intermediate tape-out bail to
its installed length.
*5-level only

(A) TAPE-OUT SENSING PIN

(1) To Check

Place control lever in stop position.

Requirement

Top of pin to be
Min flush---Max 0.010 inch
below surface of tape guideplate.

To Adjust

Loosen stop arm clampscrew.
friction tight. Position stop arm
to meet requirement. Retighten
clampscrew.

(2) To Check


Place control lever in run position.

Requirement

Clearance as shown should be
Min 0.055 inch

To Adjust

Loosen tape-out bail clampscrew.
Position extension arm to meet
requirement. Retighten clamp
screw. Recheck requirement under
(1) To Check.



SECTION 573-127-703TC

2.13 Tape-Out Switch Assembly (continued)

TAPE-OUT SENSING PIN (For Units Equipped with
Tape Lid Sensing Lever)

To Check


Hold tape-out pin manually against stop
arm.

Requirement

Top of pin to be
Min flush---Max 0.010 inch
below top surface of guideplate.

To Adjust

Loosen switch bracket mounting screws.
Position switch bracket to meet require-
ment. Retighten mounting screws.



(Front View)

2.14 Start-Stop Switch Assembly

(A) START-STOP SWITCH BRACKET

To Check
Place control lever in run position.
Disengage clutch.

(1) Requirement
Min 0.006 inch---Max 0.015 inch
between start-stop bail extension
and insulator on start-stop switch
swinger.

To Adjust
Loosen switch bracket mounting
screws. Position switch bracket
to meet requirement. Retighten
bracket mounting screws.

(2) Requirement
Start-stop bail extension and con-
tact arm to fully engage insulated
portion of start-stop switch
swinger.



To Adjust
Loosen mounting screws and
position start-stop switch swinger
to meet requirement. Retighten
mounting screw.

(B) TIGHT-TAPE START-STOP CONTACT SPRING

To Check
Place control lever in run position.

Requirement
Min 3 oz---Max 4 oz---
to separate contacts.

To Adjust
Bend break contact spring with
TP110445 bending tool. Recheck
START-STOP SWITCH BRACKET
adjustment.



2.15 Tight-Tape Mechanism

START-STOP SWITCH BRACKET (For Units Equipped with Tape Lid Sensing Lever)

To Check

Place intermediate tight-tape arm to center of its adjusting range with the contact arm.

(1) Requirement

Tight-tape start-stop contacts to:

- (a) Remain closed when tight-tape bail is raised 0.045 inch
- (b) Open as bail is raised to 0.075 inch.

To Adjust


- (a) Loosen tight-tape intermediate arm clampscrew. Position pry point midway in contact operating arm adjusting slot. Retighten clampscrew.
- (b) Loosen switch bracket screws friction tight. Position contact pile-up to meet requirement.

(2) Requirement


Contact arm to fully engage insulated part of switch swinger.

To Adjust

Loosen contact pile-up mounting screws. Position contact pile-up mounting bracket. Retighten mounting screws.



(Top View)




2.16 Tight-Tape Mechanism (continued)

(A) TIGHT-TAPE INTERMEDIATE ARM

To Check
Place control lever in run position.

Requirement
Start-stop contacts when tight-tape bail is raised away from tape guideplate:
(a) Remain closed when bail is raised 0.045 inch.
(b) Open as bail is raised to 0.075 inch.

To Adjust
Loosen clampscrew and position tight-tape intermediate arm using pry points. Retighten clampscrew.



(B) TIGHT-TAPE INTERMEDIATE ARM SPRING

To Check
Place control lever in run position.

Requirement
Min 20 grams (3/4 oz)---Max 40 grams (1-1/2 oz) to start yield arm moving.

2.17 Feed Wheel Mechanism

(D) MAIN BAIL

To Check
Place sensing pins in their lowest position.

Requirement
Highest sensing pin should be
Min 0.010---Max 0.020 inch
below surface of tape guideplate.

To Adjust
Loosen nut on main bail eccentric.
Keeping high part towards right, adjust
eccentric to meet this requirement.
Retighten nut on main bail eccentric.

(B) FEED RATCHET DETENT SPRING

To Check
Rotate clutch to stop position. Hold
feed pawl away from feed wheel
ratchet.


Requirement
Min 8 oz---Max 13 oz
to start detent moving.

(C) MAIN BAIL TRIP LEVER

To Check
Replace top plate. Disengage unit
clutch.

Requirement
Tip of highest sensing pin to be
Min flush---Max 0.005 inch
below top surface of tape guideplate.

To Adjust
Loosen nuts which secure transfer
lever guide post and rotate it so that
guide post eccentric positions main
bail trip lever to meet requirement.
Tighten nuts. Trip clutch and rotate
it while checking operation of moving
parts.



(A) MAIN BAIL SPRING

To Check
Remove top plate. Disengage clutch.
Unhook spring end from main bail.

Requirement
Min 6 oz---Max 10 oz
to pull main bail to installed length.

2.18 Feed Wheel Mechanism (continued)

(A) SENSING PIN SPRING

To Check

Open tape lid, and disengage unit clutch. Then hold armature in the attracted position to unlatch main bail and place sensing pins in their uppermost position. Hold rub-out deleter bail (if present) away from the sensing pins.

Requirement

*Chadless tape

Min 3 oz---Max 5 oz


**Perforated tape

Min 2 oz---Max 3 oz

to move each sensing pin flush with tape guide plate.

*For units using TP154349 spring —
5-level units

**For units using TP151103 spring —
6-level units



(Front View)

(B) FEED WHEEL DETENT

To Check

Open tape lid. Disengage the unit clutch to place sensing pins in their lowest position. Place high part of feed wheel ratchet detent eccentric toward the right. With an all marking code combination punched into a new piece of tape, place the tape on the feed wheel and over the sensing pins. Take up play in tape lightly toward the right.


To Adjust

Loosen feed wheel ratchet detent eccentric friction tight and hold feed pawl away from feed wheel ratchet. Rotate feed wheel ratchet detent eccentric, keeping high part of eccentric towards the right.

Note: When unit is used to read chadless spliced tape, the sensing pins should be made to favor the trailing edge of the code hole.

Requirement

Tip of each sensing pin to be centrally located in its code hole.



(Top View)

SECTION 573-127-703TC

2.19 Feed Wheel Mechanism (continued)

(A) FEED PAWL

To Check

Remove the top plate. With the high part of the feed pawl eccentric towards the right,* (viewed from rear plate) disengage the clutch to place the sensing pins in their lowest position.


*Left for units equipped with tape withhold mechanism.

Requirement


Min some---Max 0.003 inch between feed pawl and ratchet tooth just engaged.

To Adjust

Loosen feed pawl eccentric locknut, and position feed pawl eccentric. Re-check requirement at four positions on feed wheel ratchet approximately 90 degrees apart.



2.20 Transfer Mechanism




(A) TRANSFER LEVER SPRING

To Check
Disengage unit clutch.

Requirement
Min 1/2 oz---Max 1-1/2 oz
to start each transfer lever spring
moving.

(Rear View)




(B) LOCKING BAIL SPRING

Requirement
Min 10 oz---Max 14 oz
to pull locking bail spring to its
installed length.

(Front View)

2.21 Main Bail



MAIN BAIL

- (1) To Check
 Hold armature in its attracted (energized) position and rotate clutch until main bail is on its lowest position.

Requirement

Min 0.005 inch---Max 0.015 inch
 between main bail and main bail trip lever.

- (2) To Check
 Hold armature in its attracted (energized) position and rotate clutch until main bail is in its highest position.

Requirement

Min 0.005 inch
 between vertical surfaces of main bail and main bail trip lever.

To Adjust

Loosen nut on main bail and position main bail eccentric. Retighten nut. Check MAIN BAIL TRIP LEVER adjustment. Refine, if necessary.

2.22 Transfer Bail

(A) TRANSFER BAIL STABILIZER

- (1) To Check
 Select a LETTERS combination.
 Rotate main shaft until #3 transfer lever is on high part of its cam.
 Check clearance between side of transfer bail extension and marking latch.
- (2) To Check
 Select a BLANKS combination.
 Rotate main shaft until #3 transfer lever is on high part of its cam.
 Check clearance between side of transfer bail extension and spacing latch.

Requirement

Clearance in marking and spacing positions should be equal within 0.002 inch.

To Adjust

Loosen stabilizer assembly mounting screws friction tight, and position the assembly. Retighten assembly mounting screws.


(B) STABILIZER SPRING**To Check**

Rotate clutch to stop position.

Requirement

Min 2-1/2 oz---Max 5 oz
 to start stabilizer latch moving.

Note: Latches should drop in place as other transfer levers cam the transfer bail.



2.23 Signal Contacts

(A) SIGNAL CONTACT CLEARANCE

To Check

Remove cover plate and signal contact box cover. Engage the unit clutch and rotate main shaft slowly until spacing contact is fully open. Measure the gap. Continue rotating the main shaft until marking contact is fully open. Measure the gap.

Requirement

Marking and spacing contact gaps measured in To Check to be equal within 0.001 inch.

To Adjust

Loosen mounting screws and position contact box using eccentric.

Note: Before operating, refine SIGNAL CONTACT CLEARANCE adjustment in accordance with Signal Contacts — Electrical.

CAUTION: IF CONTACTS ARE GOLD PLATED, CLEAN THEM BY PARTIALLY DRAWING A STRIP OF TP107162 TWILL JEAN BETWEEN THEM.

(B) DRIVE LINK SPRING

To Check

Trip clutch and rotate main shaft to stop position. Unhook stabilizer spring, and move latches away from transfer bail extension. Hold toggle firmly against spacing contact.

Requirement

Min 6 oz---Max 12 oz to start transfer bail extension moving.


(C) SIGNAL CONTACT SPRING (TRANSMITTER DISTRIBUTOR SETS ONLY)

To Check

Place transmitter in stop position. Remove contact box cover, and toggle drive link spring from its link end. Move transfer bail towards the right (spacing) position, so that both toggle contacts are closed. Hook an 8-oz scale over the pivot screw and pull horizontally to the left.

Requirement

Min 2 oz---Max 3-1/2 oz to open left-hand contact. Replace toggle drive link spring to its link.



(Top View - Right Side)

Signal Contacts — Electrical

2.24 The strobing adjustment procedure is used for checking and adjusting signal contacts electrically, and at the same time, refining the mechanical adjustments for the transmitter distributor. The same procedure is used for checking both the marking and spacing pulses for both 5 and 6 level, and all unit codes. Differences exist, however, in the number, width, and tolerance of pulses, and in the allowable break width. The data appropriate to each level and unit code is tabulated on the associated Pulse Data Table. By following the general procedures given in Paragraphs 2.25 and 2.26 following, and using data from the appropriate table, the marking and spacing pulse adjustment can be made for all units. To illustrate the procedure further, the data appropriate to a 5-level, 7.42 unit code is added parenthetically as an example in the general adjustment procedure following.

Note: Gold-plated signal contacts should not be electrically adjusted unless there is an intermediate device available which, when keyed by the signal contacts, will interrupt the current to the stroboscopic test set. The intermediate device must be capable of being keyed by a 3- to 20-volt change in voltage at a current not in excess of 20 milliamperes. The standard stroboscopic test set operating voltage must not be applied directly to the signal contacts because of the possibility of damaging the contacts' gold plating and thus impairing their operating efficiency in this low-energy level application. (Refer to Paragraphs 1.08 through 1.13.)

2.25 Marking Pulse Adjustments

(a) Plug a signal distortion test set having the appropriate scale (eg, 7.42) into the signal line so that the marking contacts of the transmitter-distributor unit under test will interrupt the current to the stroboscopic lamp within the DXD. Have the transmitter-distributor transmitting "Y" or "R" continuously and the test set and transmitter-distributor operating at the same speed (100 wpm). Rotate the test scale to align the 0-scale mark of the START segment (end of STOP segment) with the end of the stop pulse image indicated by the rotating strobe light.


Note: The end of the stop pulse image should not vary more than one division in

either direction when the scale is positioned so that the variation is centered about the 0-scale mark of the START segment.

(b) Check the position of each of the pulses against the position tabulated. Each pulse should be in its designated segment on the test scale, within the specified tolerance figure (eg, 15 div).

Note: Each marking code pulse may have one break, provided the break is not longer than the allowable break width specified (eg, 1 div) and the break comes within the tolerance range (eg, 5 div) and the end of the pulse.

(c) To adjust, loosen the two contact box mounting screws until they are friction tight. Rotate the eccentric of the contact box mounting bracket toward the right or left until the requirements are met. Tighten the mounting screws and recheck the adjustment.



(Front View)

Note: If these signal requirements cannot be met, refine the TRANSMITTER DISTRIBUTOR GEAR BACKLASH adjustment (See BASES) and the TRANSFER BAIL STABILIZER adjustment, viewing the signal on the test set.

2.26 Spacing Pulse Adjustments: The general procedure for adjusting the spacing pulse is identical to that outlined for marking pulses. The tolerances for spacing pulses may not be the same as for marking pulses however. Refer to the appropriate Pulse Data Table when making adjustments.

SECTION 573-127-703TC

Note: On units equipped with signal regenerators, remove regenerator circuit card before applying test set probes to contact access terminals.

THEM UNSUITABLE FOR LOW-VOLTAGE APPLICATIONS. REFER TO 1.12 FOR SERVICING INSTRUCTIONS.

CAUTION: APPLYING OPERATING VOLTAGE OF DISTORTION TEST SET DIRECTLY TO GOLD-PLATED CONTACTS MAY MAKE

2.27 Follow the general procedure outlined in Paragraphs 2.25 and 2.26 substituting the appropriate data from the following table.

PULSE DATA TABLE
FIVE-LEVEL UNITS, 7.00 UNIT CODE

PULSE	MARKING		SPACING	
	*NOMINAL	TOLERANCE	*NOMINAL	TOLERANCE
STOP PULSE	36 (STOP) TO 142 (STOP)	BEGIN ±5 DIV END ±1/2 DIV	36 (STOP) TO 142 (START)	BEGIN ±6 DIV END ±1/2 DIV
START PULSE	142 (STOP) TO 6 (ONE)	BEGIN ±5 DIV END ±5 DIV	142 (STOP) TO 6 (ONE)	BEGIN ±6 DIV END -5, ±6 DIV
PULSE 1	6 (ONE) TO 12 (TWO)	BEGIN ±5 DIV END ±5 DIV	6 (ONE) TO 12 (TWO)	BEGIN ±6 DIV END -5, ±6 DIV
PULSE 2	12 (TWO) TO 18 (THREE)	BEGIN ±5 DIV END ±5 DIV	12 (TWO) TO 18 (THREE)	BEGIN ±6 DIV END -5, ±6 DIV
PULSE 3	18 (THREE) TO 24 (FOUR)	BEGIN ±5 DIV END ±5 DIV	18 (THREE) TO 24 (FOUR)	BEGIN ±6 DIV END -5, ±6 DIV
PULSE 4	24 (FOUR) TO 30 (FIVE)	BEGIN ±5 DIV END ±5 DIV	24 (FOUR) TO 30 (FIVE)	BEGIN ±6 DIV END -5, ±6 DIV
PULSE 5	30 (FIVE) TO 36 (STOP)	BEGIN ±5 DIV END ±5 DIV	30 (FIVE) TO 36 (STOP)	BEGIN ±6 DIV END -5, ±6 DIV
ALLOWABLE BREAK WIDTH	1 DIV	MUST FALL WITHIN PULSE TOLERANCE	1 DIV	MUST FALL WITHIN PULSE TOLERANCE

*Ranges specified apply only for test sets (DXD) having a 7.42 unit code scale.

- 2.28 Follow the general provisions outlined in Paragraphs 2.25 and 2.26 substituting the appropriate data from the following table.

PULSE DATA TABLE
FIVE-LEVEL UNITS, 7.42 UNIT CODE

PULSE	MARKING		SPACING	
	RANGE	NOMINAL	TOLERANCE	NOMINAL
STOP PULSE	0 (STOP) TO 0 (START)	BEGIN ± 5 DIV END $\pm 1/2$ DIV	0 (STOP) TO 0 (START)	BEGIN ± 6 DIV END $\pm 1/2$ DIV
START PULSE	0 (START) TO 0 (ONE)	BEGIN ± 5 DIV END ± 5 DIV	0 (START) TO 0 (ONE)	BEGIN ± 6 DIV END ± 6 DIV
PULSE 1	0 (ONE) TO 0 (TWO)	BEGIN ± 5 DIV END ± 5 DIV	0 (ONE) TO 0 (TWO)	BEGIN ± 6 DIV END ± 6 DIV
PULSE 2	0 (TWO) TO 0 (THREE)	BEGIN ± 5 DIV END ± 5 DIV	0 (TWO) TO 0 (THREE)	BEGIN ± 6 DIV END ± 6 DIV
PULSE 3	0 (THREE) TO 0 (FOUR)	BEGIN ± 5 DIV END ± 5 DIV	0 (THREE) TO 0 (FOUR)	BEGIN ± 6 DIV END ± 6 DIV
PULSE 4	0 (FOUR) TO 0 (FIVE)	BEGIN ± 5 DIV END ± 5 DIV	0 (FOUR) TO 0 (FIVE)	BEGIN ± 6 DIV END ± 6 DIV
PULSE 5	0 (FIVE) TO 0 (STOP)	BEGIN ± 5 DIV END ± 5 DIV	0 (FIVE) TO 0 (STOP)	BEGIN ± 6 DIV END ± 6 DIV
ALLOWABLE BREAK WIDTH	± 1 DIV	MUST FALL WITHIN TOLERANCE LIMITS	± 1 DIV	MUST FALL WITHIN TOLERANCE LIMITS


SECTION 573-127-703TC

2.29 Follow the general provisions outlined in Paragraphs 2.25 and 2.26 substituting the appropriate data from the following table.

PULSE DATA TABLE
SIX-LEVEL UNITS, 8.50 UNIT CODE

PULSE	MARKING		SPACING	
	RANGE	NOMINAL	TOLERANCE	NOMINAL
STOP PULSE	0 (STOP) TO 0 (START)	BEGIN ±7 DIV END ±1/2 DIV	0 (STOP) TO 0 (START)	BEGIN ±8 DIV END ±1/2 DIV
START PULSE	0 (START) TO 0 (ONE)	BEGIN ±7 DIV END ±7 DIV	0 (START) TO 0 (ONE)	BEGIN ±8 DIV END ±8 DIV
PULSE 1	0 (ONE) TO 0 (TWO)	BEGIN ±7 DIV END ±7 DIV	0 (ONE) TO 0 (TWO)	BEGIN ±8 DIV END ±8 DIV
PULSE 2	0 (TWO) TO 0 (THREE)	BEGIN ±7 DIV END ±7 DIV	0 (TWO) TO 0 (THREE)	BEGIN ±8 DIV END ±8 DIV
PULSE 3	0 (THREE) TO 0 (FOUR)	BEGIN ±7 DIV END ±7 DIV	0 (THREE) TO 0 (FOUR)	BEGIN ±8 DIV END ±8 DIV
PULSE 4	0 (FOUR) TO 0 (FIVE)	BEGIN ±7 DIV END ±7 DIV	0 (FOUR) TO 0 (FIVE)	BEGIN ±8 DIV END ±8 DIV
PULSE 5	0 (FIVE) TO 0 (SIX)	BEGIN ±7 DIV END ±7 DIV	0 (FIVE) TO 0 (SIX)	BEGIN ±8 DIV END ±8 DIV
PULSE 6	0 (SIX) TO 0 (STOP)	BEGIN ±7 DIV END ±7 DIV	0 (SIX) TO 0 (STOP)	BEGIN ±8 DIV END ±8 DIV
ALLOWABLE BREAK WIDTH	1 DIV	MUST LIE WITHIN TOLERANCE LIMITS	1 DIV	MUST LIE WITHIN TOLERANCE LIMITS

2.30 Basic Gear Adjustments



INTERMEDIATE GEAR — TRANSMITTER DISTRIBUTOR GEAR BACKLASH

(Left Side View)

To Check

With the MOTOR POSITION and TRANSMITTER DISTRIBUTOR POSITION adjustments completed, check the backlash between the gears.

(1) Requirement

Only a perceptible amount of backlash between the intermediate driving gear and the transmitter distributor gear.

To Adjust

Loosen three mounting screws that secure the transmitter distributor unit to its base. Position transmitter distributor to meet the requirement. Retighten the mounting screws.

(2) Requirement

Only a perceptible amount of backlash between the drive gear and the transmitter distributor gear.

To Adjust

Loosen three mounting screws that secure the transmitter distributor to its base. Position transmitter distributor to meet this requirement. Retighten the screws.

3. VARIABLE FEATURES

3.01 Tight-Tape and Tape Shoe Mechanism

(A) TIGHT-TAPE SWITCH

To Check


Place control lever in run position.

Requirement

Min $9/32$ inch---Max $13/32$ inch to open contacts when tight-tape arm is raised.

To Adjust


Loosen clampscrew. Using adjusting slot, position tight-tape intermediate arm to meet this requirement. Re-tighten clampscrew.



(B) TORSION SPRING

Requirement

Min 2-1/2 oz to lift tape shoe.



(C) TAPE SHOE

To Check

Latch tape lid in position. Check clearance between tape guideplate and tape shoe.

Requirement

Min 0.005 inch---Max 0.008 inch

To Adjust

Loosen locknut. Rotate adjusting screw to meet the requirement. Retighten locknut.

(Rear View)

3.02 Tape Feed Assurance Mechanism

(A) TAPE SENSING FEED WHEEL PHASING

To Check

Place fresh, fully perforated tape (10 holes per inch) on tape guideplate across the feed wheel and tape feed assurance wheel. Set detent adjusting lever screw at midrange.

Requirement

Tape must lie flat on tape guideplate between feed wheel and tape feed assurance wheel.

To Adjust

Loosen bracket mounting screws friction tight. Position bracket to meet requirement. Retighten bracket mounting screws. Refine adjustment (if necessary) by rotating the detent lever adjusting screw.

Note: If tape is not available, use TPI65800 gauge.

(B) TAPE MOTION CONTACT GAP

To Check

Place detent lever in detented position.

Requirement

Min 0.005 inch---Max 0.010 inch gap between the normally closed contacts.

To Adjust

Bend contact leaf and stiffener to meet requirement.

(C) TAPE MOTION CONTACT SWINGER

To Check

Hold detent lever from contact swinger.

Requirement

Min 15 grams---Max 25 grams to separate contacts.

To Adjust

Bend swinger to meet requirement. Recheck TAPE MOTION CONTACT GAP.


(D) DETENT LEVER SPRING

To Check

Hold contact lever away from detent lever.

Requirement

Min 3 oz---Max 4 oz to move the roller from the ratchet.



(Rear View)

3.03 Tape-Out Mechanism

(A) TAPE-OUT CONTACT

- (1) To Check
Loosen contact bracket mounting screws. Pivot contact assembly until pad on tape-out pin extension is not touching the swinger pad. Check gap between normally open (top) contact points.

Requirement
Min 0.015 inch---Max 0.025 inch between normally open (top) contacts.

To Adjust
Bend upper contact spring to meet requirement.

- (2) To Check
With assembly still in position, check force required to just separate normally closed (lower) contacts.

Requirement
Min 8 grams---Max 15 grams to just separate normally closed (lower) contacts.

To Adjust
Bend contact swinger. Recheck requirement under (1) To Check above.


- (3) To Check
Hold tape-out pin down. With some clearance between tape-out pin extension and underside of contact swinger, without tape, tape lid closed, and unit in run position, check gap between normally closed contacts.

Requirement
Min 0.008 inch---Max 0.018 inch gap between normally closed contacts.

To Adjust
With contact bracket mounting screws loosened, adjust contact mounting bracket to meet requirement. Retighten contact bracket mounting screws.

(B) TAPE-OUT BAIL TORSION SPRING

Requirement
Min 8 oz---Max 12 oz to separate bail from tape-out pin.



3.04 Tape-Out Mechanism (continued)

(C) TAPE-OUT PIN SPRING

To Check

Remove tape and open tape lid.

Requirement

Min 38 grams---Max 45 grams
to press pin flush with tape guideplate.

To Adjust

Loosen tape-out spring bracket mounting screw and position bracket to meet requirement. Retighten bracket mounting screw.

To Adjust

With control lever in stop position, loosen screw which secures the stop arm to the bracket with posts. Adjust stop arm to meet requirement. Tighten screw.

(2) To Check

Place control lever in run position. Check clearance between lower tape-out pin extension and tape-out bail extension.

Requirement

Min 0.055 inch
clearance between lower tape-out pin extension and tape-out bail extension.

To Adjust

With control lever in run position, loosen screw which secures the extension arm to the intermediate tape-out bail. Using a tommy wrench or suitable tool, change relative position of extension arm to bail to obtain required clearance. Tighten screw. Check requirement under (1) To Check and refine, if necessary.


(D) TAPE-OUT PIN

(1) To Check

Place control lever in free or stop position. Check position of tape-out pin in relation to tape guideplate.

Requirement

Tape-out pin should be
Min flush---Max 0.010 inch
below surface of tape guideplate.



(Front View)

3.05 Code Reading Contacts

Note 1: Remove code reading contact assembly from transmitter distributor unit before making initial adjustments.

Note 2: When using the contact spring bender, start with the contact pile-up farthest from the handle of the tool and work toward the handle so as not to disturb adjustments already made.

(A) NORMALLY CLOSED CONTACTS — BACKSTOP

Requirement

Lower contact leaves for all levels should be parallel with the mounting plate and in line with one another.

To Adjust

Bend backstop to meet the requirement.

(B) NORMALLY CLOSED CONTACTS — SPRING

(1) **Requirement**

With swinger held away
Min 2 oz---Max 6 oz
to move lower contact leaf from backstop.

To Adjust

Bend lower leaf.

(2) **Requirement**




Min 30 grams---Max 40 grams
to open normally closed contacts.

To Adjust

Bend swinger.

Note 3: If it is necessary to bend backstop to obtain required tension, reposition backstop to meet NORMALLY CLOSED CONTACTS — BACKSTOP requirement.

MOUNTING PLATE



(C) NORMALLY OPEN CONTACTS — GAP

Requirement

Min 0.010 inch---Max 0.015 inch
gap between normally open contacts.

To Adjust

Bend associated backstop to meet requirement.

(D) NORMALLY OPEN CONTACTS — SPRING

Requirement


Min 30 grams---Max 40 grams
to move normally open contact away from backstop.

To Adjust

Bend upper contact leaf.

Note 4: If it is necessary to bend backstop to obtain required tension, reposition backstop to meet NORMALLY OPEN CONTACTS — GAP requirement.

UPPER CONTACT LEAF



BACKSTOP

(Front Views)

3.06 Code Reading Contacts (continued)

Note: Secondary adjustments should be made with code reading contact assembly installed in the transmitter distributor and with the contact assembly bracket approximately centered in its adjustment range. (Remove contact box to facilitate adjustment.)

(A) CONTACT ASSEMBLY POSITIONING

To Check


Align each swinger with its associated sensing arm. (Gauge by eye.)

Requirement

Swinger to be aligned with its sensing arm.

To Adjust

Loosen screws which mount the contact assembly to the contact bracket. Position the assembly to meet the requirement.



(Front Views)

(B) CONTACT SWINGER — SENSING ARM CLEARANCE

To Check


Place up-stop post out of the way and sensing arms in their uppermost positions. Select a BLANK combination.

Requirement

Min some---Max 0.010 inch gap between contact assembly swinger and insulator on contact sensing arm.

To Adjust

Loosen contact bracket mounting screws. Position bracket to meet the requirement. Tighten contact bracket mounting screws.



3.07 Code Reading Contacts (continued)

(A) CONTACT SENSING ARM — UP-STOP CLEARANCE

To Check


Rotate main shaft until sensing arms are in their highest positions. Engage clutch. Select a LETTERS combination.

Requirement

Min some---Max 0.008 inch clearance between upper contact leaf and its backstop.

To Adjust

Loosen nut that secures the eccentric up-stop to the front plate. Turn the eccentric to meet requirement. (High part of the eccentric should be toward the left.) Retighten eccentric nut.



(B) SENSING ARM — TRANSFER LEVER ALIGNMENT

To Check


Trip clutch. Select BLANK combination.

Requirement

Sensing arms must engage a minimum of 2/3 of their respective transfer levers.

To Adjust

Add TP8896 shims between plate assembly and the split bail spacer to meet requirement. (Store remaining shims under flat washer at end of split bail eccentric screw.)



(Front Views)

(C) SENSING ARM SPRING

To Check

Disengage clutch.

Requirement

Min 2-1/2 oz---Max 3-1/2 oz to start sensing arm moving.

(D) SPLIT BAIL ECCENTRIC

To Check

Trip clutch. Select BLANK combination. Check clearance between closest transfer lever and its associated sensing arm.

Requirement

Min 0.005 inch---Max 0.010 inch

To Adjust

Loosen split bail eccentric locknut. Rotate split bail eccentric to meet requirement. Retighten locknut.

3.08 Code Reading Contacts (continued)

CONTACT SWINGER — SENSING ARM
CLEARANCE (STROBING)

Note 1: When strobing the code reading contacts, use a DXD scale whose unit corresponds to that of the unit being checked. Refer to Contact Operating Requirements Table. The signal generator on the transmitter distributor must be synchronized with the DXD so that the end of the stop pulse image is in line with the end of the stop pulse on the DXD scale when transmission is continuous. Use a normal signal line direct current of 60 ma $\pm 10\%$ or 20 ma $\pm 10\%$ to strobe the contacts.

(1) Requirement

Contacts must open and close within the range specified on the Contact Operating Requirements Table.

(2) Requirement

Breaks in the pulses must be confined to the first and last 10 divisions of the trace.

CONTACT OPERATING REQUIREMENTS TABLE

Levels	Unit Code	Beginning Pulse			End of Pulse			Max. Pulse Length Osc (Div)
		Scale Segment	Scale Division	Tolerance (Div)	Scale Segment	Scale Division	Tolerance (Div)	
5	7.00	Pulse 1	25	± 20	Pulse 5	15	± 20	3
5	7.42	Pulse 1	30	± 20	Pulse 5	40	± 20	3
6	8.50	Pulse 0	45	± 25	Pulse 5	5	± 25	4

To Adjust

Loosen contact bracket mounting screws.
Position bracket to meet requirements.
Retighten contact bracket mounting screws.

Note 2: After making the adjustment, check clearance between contact swinger and insulator on the contact sensing arm when a BLANK combination has been selected and the main shaft rotated to place the sensing arms in their highest position. There must be some clearance. If the requirements cannot be met, recheck initial mechanical adjustments.

3.09 Auxiliary Contacts

Note: Make initial adjustments with the auxiliary contacts removed from the transmitter distributor unit.

(A) NORMALLY OPEN CONTACTS

(1) Requirement

Min 5-1/2 oz --- Max 6 oz
to move normally open contact
away from stiffener.

To Adjust


Bend normally open contact leaf
to meet requirement.

(2) Requirement

Min 0.015 inch --- Max 0.020 inch
gap between normally open contacts.

To Adjust

Bend contact stiffener to meet
requirements.



(B) NORMALLY CLOSED CONTACTS

Requirement

Min 4 oz --- Max 5 oz
to open normally closed contact.

To Adjust

Bend swinger contact to meet re-
quirement.

(Front View)

3.10 Auxiliary Contacts (continued)


Note: Make secondary adjustments with the auxiliary contacts installed in the transmitter distributor.

(A) CONTACT SENSING ARM

- (1) To Check
Disengage and latch clutch. Check clearance between insulator on swinger and bail.

Requirement
Swinger insulator should be centrally located with respect to its operating bail.

To Adjust
Loosen contact assembly screws. Position swinger and contact springs. Retighten contact assembly screws.



(Front View)

- (2) To Check
Check position of swinger with respect to its bail.

Requirement
Min 0.040 inch—Max 0.050 inch between insulator on swinger and its bail.

To Adjust
Loosen contact bracket mounting screws. Position contact bracket to meet requirement. Retighten contact bracket mounting screws.

(B) AUXILIARY CONTACT OPERATING BAIL SPRING

- To Check
Disengage clutch.

Requirement
Min 5 oz---Max 7 oz to pull spring to its installed length.

3.11 Auxiliary Contacts (continued)

CONTACT SWINGER — OPERATING BAIL
CLEARANCE

Note: When strobing the auxiliary contacts, use a DXD scale whose unit code corresponds to that of the unit being checked. (Refer to Contact Operating Requirements Table.) Synchronize the signal generator of the transmitter distributor with the DXD so that the end of the stop pulse image is in line with the end of the stop pulse on the DXD scale when transmission is continuous. Use normal direct current line signal of 60 ma $\pm 10\%$ or 20 ma $\pm 10\%$ to strobe the contacts.

Requirement

The contacts must open and close within the range specified in the Contact Operating Requirements Table.


To Adjust

Loosen the contact bracket mounting screws. Position the contacts to meet the requirements. Retighten contact bracket mounting screws.

CONTACT OPERATING REQUIREMENTS TABLE

Levels	Unit Code	Start of Pulse			End of Pulse		
		Scale Segment	Scale Division	Tolerance (Div)	Scale Segment	Scale Division	Tolerance (Div)
5	7.00	Pulse 1	65	± 15	Pulse 4	65	± 15
5	7.42	Pulse 1	75	± 15	Pulse 4	90	± 15
6	8.50	Pulse 1	0	± 20	Pulse 4	60	± 20

3.12 Tape Lid Sensing Lever



To Adjust
 Loosen the adjustment screw. With the tape lid sensing lever seated firmly against the tape guideplate, rotate the switch lever clockwise or counter-clockwise to meet requirement. Re-tighten adjustment screw.

3.13 Tape Deflector

(A) TAPE DEFLECTOR BRACKET

To Check


Check position of deflector tang in relation to its hole in top plate when the unit is in its operating position.

Requirement

Deflector tang should be located centrally in its hole in the top plate.

To Adjust

Remove rear screw which secures tape deflector spring to the cover plate. Loosen forward screw. Position tape deflector. Replace rear screw, and tighten both forward and rear screws.



(B) TAPE DEFLECTOR SPRING

Requirement

Min 1-1/2 oz---Max 4 oz
to start the deflector moving from its operating position.

To Adjust

Loosen mounting screw. Position the spring using the enlarged mounting slot. Retighten mounting screw.

3.14 Start-Stop Pulse Contact

(A) CONTACT LEVER

To Check


Remove contact assembly from unit. Insure that no clearance exists between the contact lever and insulator.

Requirement

Min 20 grams---Max 30 grams to move insulator from contact operating lever.

To Adjust

Bend upper contact spring.



(B) CONTACT GAP (START AND STOP CONTACTS)

Requirement

Min 0.012 inch---Max 0.018 inch

To Adjust

Bend lower contact spring.

(Front Views)

(C) CONTACT BRACKET

To Check


Place unit in stop position. Latch clutch. Check clearance between contact operating lever and transfer lever.

Requirement

Min 0.012 inch---Max 0.018 inch

To Adjust

Loosen mounting bracket screws. Position contact assembly to meet requirement. Retighten mounting bracket screws. Replace contact assembly in unit.



SECTION 573-127-703TC

3.15 Start-Stop Pulse Contact (continued)

CONTACT BRACKET (STROBING)

Note 1: When strobing auxiliary contacts, use a 7.42 unit DXD scale. Synchronize the signal generator of the transmitter distributor with the DXD so that the end of the stop pulse image is in line with the end of the stop pulse on the DXD scale when transmission is continuous. Use normal signal line direct current of 60 ma \pm 10% or 20 ma \pm 10% to strobe the contacts.

Requirement

Contacts must close within the following range.

	MIN CLOSURE	CLOSURE RANGE
STOP CONTACT	95 DIV	0 DIV OF STOP SEGMENT TO 142ND DIV OF STOP SEGMENT
START CONTACT	60 DIV	122ND DIV OF STOP SEGMENT TO 95TH DIV OF START SEGMENT


Note 2: Breaks are permissible within 5 divisions of the beginning or end of a trace.

To Adjust

Loosen contact bracket mounting screws. Position the contact bracket to meet requirements. Retighten contact bracket mounting screws.

3.16 Rub-Out Deleter

(A) RUB-OUT DELETER BAIL GUIDE



To Check

Place sensing pins in their highest position. Check that deleter bail moves freely in its guide.

Requirement

When the rub-out permutation code is present, the rub-out deleter bail should rest against the lower projection of the sensing pin.

To Adjust

Loosen mounting screws friction tight. Position deleter bail guide. Retighten mounting screws.


(B) SENSING PIN SPRING

To Check

Place sensing pin in its highest position. Hold rub-out deleter bail away from the pin.

Requirement

Min 3 oz --- Max 5 oz to move pin flush with tape guide.



(C) RUB-OUT DELETER BAIL SPRING


To Check

Place sensing pin in highest position.

Requirement

Min 1 oz --- Max 2-1/2 oz to move bail away from the sensing pin.

3.17 Tape Notch Sensing Mechanism



3.18 Tape Notch Sensing Mechanism (continued)

CONTACT BRACKET (STROBING)

Note: When using the tape notch sensing contacts, use a 7.42 unit DXD scale. Synchronize the transmitter distributor so that the end of the stop pulse image is in line with the end of the stop pulse on the DXD scale when transmission is continuous. Use a normal direct current line signal of 60 ma $\pm 10\%$ or 20 ma $\pm 10\%$ to strobe these contacts.

(FOR UNITS WITH TAPE SLACK ARM)

- (1) Requirement
The contact should open no earlier than the 15 mark of the first pulse and open no later than the 55 mark of the first pulse.
- (2) Requirement
The contact should close no earlier than the 15 mark of the fifth pulse and close no later than the 55 mark of the fifth pulse.
- (3) Requirement
Contact breaks will be permitted between the 15 mark and the 55 mark of the fifth pulse. The magnitude of the breaks must not extend beyond these limits.

To Adjust

Loosen bracket contact mounting screws. Position contact bracket to meet requirements. Retighten mounting screws.

(FOR UNITS WITHOUT TAPE SLACK ARM)

- (1) Requirement
The contact should close no earlier than the 15 mark of the first pulse and close no later than the 55 mark of the first pulse.
- (2) Requirement
The contact should open no earlier than the 15 mark of the fifth pulse and open no later than the 55 mark of the fifth pulse.
- (3) Requirement
Contact breaks will be permitted between the 15 and 55 marks of the first pulse. The magnitude of the breaks must not extend beyond these limits.

To Adjust

Loosen bracket contact mounting screws. Position contact bracket to meet requirements. Retighten mounting screws.

3.19 Transmitter Stop Mechanism

(A) START-STOP CONTACT GAP (FOR TABULATOR CONTROL)

To Check


Place timing bail on lower part of its cam. Check start-stop contact gap.

Requirement

Min 0.018 inch---Max 0.025 inch

To Adjust

Loosen clampscrew securing yield arm to timing arm friction tight. Position timing arm to meet requirement. Retighten clampscrew.



(B) TIMING BAIL SPRING

Requirement

Min 5-1/2 oz---Max 8 oz
to start the bail moving.

3.20 Tape Slack Arm

TAPE SLACK CONTACTS

To Check


Close tape lid. Place control lever in run position. Check clearance between contacts when tape slack arm is raised to its maximum height.

Requirement

Min 0.010 inch---Max 0.020 inch

To Adjust

Loosen clampscrew. Set contact gap by positioning pry points. Retighten clampscrew.



3.21 Tape Withhold Mechanism

(A) MAGNET ARMATURE GAP

To Check


With the armature attracted, check the gap between the end of the armature adjusting screw and the plate.

Requirement

Min 0.020 inch---Max 0.025 inch

To Adjust

Loosen armature adjusting screw locknut friction tight. Rotate adjusting screw to meet requirement. Retighten locknut.



(B) BLOCKING BAIL ARM ECCENTRIC

To Check

Place sensing pins in their lowest position. Place high part of block bail arm eccentric pivot to right at approximately the same angular position as the feed pawl eccentric.

Requirement

some clearance between the extension on the blocking bail and the tail of the feed pawl.

To Adjust

Loosen arm eccentric clampscrew. Rotate arm eccentric to meet requirement. Retighten clampscrew.

(C) BLOCKING BAIL ECCENTRIC PIVOT

To Check

Trip clutch. Hold armature attracted. Hold main shaft latched in stop position. Check clearance between blocking bail extension and feed pawl at closest point.

Requirement

Min 0.002 inch---Max 0.035 inch


To Adjust

Loosen eccentric pivot clampscrew friction tight. Rotate eccentric pivot to meet requirement. Retighten clampscrew.

Note 1: Check BLOCKING BAIL ARM ECCENTRIC adjustment, and refine if necessary.

Note 2: As a final check on this adjustment there should be some---to---0.015 inch clearance between the feed pawl and the feed ratchet at the closest point, as the feed pawl is cammed out of the ratchet during the blocking operation (magnet armature attracted). If necessary, refine BLOCKING BAIL ARM ECCENTRIC PIVOT adjustments to meet this requirement.

(Front Views)



4. EARLY MODELS

4.01 Tape Lid Mechanism

Note: Remove top and tape guideplate.
Lubricate before adjustment.

TAPE LID

(1) To Check

Hold tape against notch in tape guideplate. Align feed wheel groove in tape lid with slot in plate. Align tape-out pin hole in plate tape lid with hole in plate. Check clearance between tape lid and pivot shoulder.

Requirement

Min some---Max 0.010 inch clearance between tape lid and pivot shoulder.

To Adjust

Loosen tape lid mounting nuts friction tight. Insert tip of TP156743 gauge through slot and into groove of lid. Position tape lid bracket. Retighten nuts.

(2) To Check

Tape lid front bearing surface should rest squarely against tape guideplate. Check rear bearing surface clearance.

Note: When both plates are assembled on unit, left edge of lid may touch top plate and some change in this clearance may be expected.

Requirement

Min some---Max 0.003 inch clearance between rear bearing surface and tape guideplate.

To Adjust

Loosen tape lid bracket mounting screws friction tight. Press tape lid against tape guideplate. Position bracket. Recheck requirement. Retighten bracket mounting screws.

(3) To Check


Latch tape lid against tape guideplate. Check release plunger for endplay.

Requirement

Some endplay when lid is latched against tape guideplate.

To Adjust

Loosen eccentric mounting post lock-nut friction tight. Raise tape lid. Rotate high part of eccentric toward tape guideplate. Close lid and rotate eccentric toward bracket until latch just falls under flat on post. Recheck by depressing plunger. With lid held down operate plunger. Tip of latch should clear post.



SECTION 573-127-703TC

4.02 Tape Lid (continued)


TAPE LID RELEASE PLUNGER SPRING (For Units without
Tape Lid Spring)

To Check

Hold tape guideplate horizontally. Unlatch
tape lid.

Requirement

Min 28 oz---Max 48 oz
to start tape lid bail moving.



(Right Side View)

MOTOR UNITS
 ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1	Governor contact backstop	6
2. MINIATURIZED SYNCHRONOUS MOTOR UNITS	2	Motor positioning	6
Air ducts	4	Motor speed	7
Capacitor position	4		
Motor gear	2	1. GENERAL	
Motor positioning	2	1.01 This section is reissued to include ad- justments formerly given in other sec- tions, to include the latest engineering informa- tion, and to change the title. Since this revision is of a general nature, marginal arrows which indicate changes have been omitted.	
Motor shield	3	1.02 The adjustment information given in this section and the section covering general teletypewriter requirements and adjustments provide the information necessary for mainte- nance of the motor unit.	
3. STANDARD AND HEAVY DUTY SYNCHRONOUS MOTOR UNITS	5	1.03 The illustrations in this section show the adjusting tolerances, positions of moving parts, and spring tensions.	
Motor adjusting stud	5		
Motor positioning	5		
4. SERIES GOVERNED MOTOR UNITS	6		
Governor brush spring	7		
Governor contact	6		

2. MINIATURIZED SYNCHRONOUS MOTOR UNITS

2.01 Motor Positioning

(A) MOTOR POSITIONING


Requirement

Position motor so that leads are approx 30° from center line with oil holes up.

Note: If necessary, position bracket with bracket screws loosened.

To Adjust

With mounting strap screws loosened, rotate motor.



(B) MOTOR GEAR

Requirement


Barely perceptible amount of backlash between the motor driving gear and the main shaft driven gear at the point where backlash is least.

To Adjust

Raise or lower the gear end of the motor by means of the adjusting studs with their lock nuts loosened.

CAUTION: IF THE MOTOR SHOULD BECOME BLOCKED FOR SEVERAL SECONDS, THE THERMOSTATIC CUTOFF SWITCH WILL OPEN THE CIRCUIT. SHOULD THIS HAPPEN, ALLOW MOTOR TO COOL AT LEAST 5 MINUTES BEFORE MANUALLY RESETTING THE SWITCH BY DEPRESSING THE RED BUTTON. AVOID REPEATED RESETTING.


2.02 Motor Shield



MOTOR SHIELD (IF SO EQUIPPED)

- (2) Requirement
Clearance between motor shield and
motor mounting bracket should be
Min 0.062 inch



To Adjust
Position motor shield with its mount-
ing screws loosened.



- (1) Requirement
Equal clearance between front and
rear ends of motor and motor shield.


(TOP VIEW)

2.03 Air Ducts and Capacitor Position



3. STANDARD AND HEAVY DUTY SYNCHRONOUS MOTOR UNITS

3.01 Motor Positioning



MOTOR POSITIONING

- (1) Requirement (Upright Mounted Motors)
Oilers should be upward and approximately equidistant from a vertical line through motor shaft.
- (2) Requirement (Inverted Mounted Motors)
Oilers should be downward and approximately equidistant from a vertical line through motor shaft.

To Adjust
Position motor with clamp screws (2) loosened.

MOTOR ADJUSTING STUD (IF SO EQUIPPED)

Requirement
Barely perceptible backlash between drive gear and driven gear at point where backlash is least.

To Adjust
With lock nut loosened, position adjusting stud. Tighten nut while holding stud in position.

CAUTION: IF MOTOR BECOMES BLOCKED FOR SEVERAL SECONDS, THERMOSTATIC CUTOFF SWITCH (ON UNITS SO EQUIPPED) WILL BREAK CIRCUIT. SHOULD THIS HAPPEN, ALLOW MOTOR TO COOL AT LEAST 5 MINUTES BEFORE DEPRESSING RED RESET BUTTON. AVOID REPEATED RESETTING.

SECTION 570-220-700

4. SERIES GOVERNED MOTOR UNITS

4.01 Motor Positioning and Governor

MOTOR POSITIONING (NOT ILLUSTRATED)

Requirement

Motor should be centrally positioned in its rubber mounts so as to provide at least 0.020 clearance between the motor housing and the cradle at the governor end. The cable should also clear the grommet in the screen by at least 0.030 inch.

(A) GOVERNOR CONTACT BACKSTOP

Requirement

Clearance between the movable contact arm and its eccentric backstop.

Min 0.020 inch---Max 0.040 inch

To Adjust

Rotate the eccentric backstop with clamping screw loosened.


(B) GOVERNOR CONTACT

Requirement

The contacts should meet squarely and not overlap more than 0.010 inch.

To Adjust


Position the stationary contact and contact arm with the clamp screw and post loosened.



**CAUTION: EXCESSIVE PRESSURE
AGAINST GOVERNOR COVER
ASSEMBLY DURING REMOVAL
MAY DAMAGE SCREENED WINDOW.**

4.02 Motor Governor

Note: Replace governor brushes that have worn to a length of approximately 15/32 inch (2/3 of original length).



Requirement


With target illuminated and viewed through the vibrating shutters of a 120 vps turning fork the spots on the 4-spot target should appear stationary while rotating. With target illuminated and viewed through the vibrating shutters of an 87.6 vps tuning fork the spots on the 6-spot target should appear stationary while rotating and with speed slightly increased the spots on the 35 spot target should appear stationary.

To Adjust

Stop the motor and turn the adjusting screw as indicated on governor cover. For units with screened governor covers, stop the motor, remove the TP152035 plug from cover. Turn adjusting screw as indicated on periphery of target.

Note: It is possible to adjust the motor at some multiple of the correct speed. To check motor speed when used with a page printer, return typebox carriage to left margin, set up any character in selector and manually trip typebox clutch trip lever. Printing should occur as follows:

WPM	PRINTED CHARACTERS	REQUIRED TIME
60	70	10 seconds
75	44	5 seconds
100	57	5 seconds



28 CABINET FOR AUTOMATIC SEND-RECEIVE

TELETYPEWRITER SETS

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. LUBRICATION	2
Cabinet	
Cabinet mechanism	2
Dome latch mechanism	3
Line guide mechanism	3
Low paper and paper out switch mechanism	3

1. GENERAL

1.01 The 28 Cabinet should be lubricated as directed in this section. The figures indicate the points to be lubricated and the quantity of lubricant to be used. Lubricate the assembly just prior to placing it in service.

1.02 The cabinet should be lubricated after each six months period of time or after each 1500 hours of service when the operating components of the set are serviced.

1.03 Use TP88970 oil at all points requiring oil and TP88973 grease at all points requiring grease.

1.04 The unit should be thoroughly lubricated, but over-lubrication which might allow oil or grease to be thrown to other parts, should be avoided. The following general instructions supplement the specific lubrication points indicated.

- a. Apply one drop of oil to all spring hooks.
- b. Apply oil to all pivot points.
- c. Apply oil to all sliding surfaces.


1.05 Specific lubrication requirements and the amount of lubricant are indicated at each lubrication point in accordance with the following code:

- O Apply 1 drop of oil.
- O2 Apply 2 drops of oil.
- O3 Apply 3 drops of oil.
- G Apply thin film of grease.


1.06 Remove any oil from finished surfaces with a soft clean cloth.

2. LUBRICATION


2.01 CABINET MECHANISM




2.02 LINE GUIDE MECHANISM



2.03 DOME LATCH MECHANISM



2.04 LOW PAPER AND PAPER OUT SWITCH MECHANISM





28 ELECTRICAL SERVICE UNIT
LUBRICATION

1. GENERAL

1.01 This section provides specific lubrication procedures for the 28 electrical service units. It is being reissued to conform to more of a standard format. Since this is a general revision marginal arrows used to indicate changes and additions, have been omitted.

1.02 The figure indicates points to be lubricated and the kind and quantity of lubricant to be used. Lubricate the units prior to placing them in service. After that, lubricate as deemed necessary to provide smooth operation.


1.03 The lubricating symbol in the text of the figure indicates lubrication directions as follows:

- O1 Apply one drop of oil
- O2 Apply two drops of oil
- O3 Apply three drops of oil
- G Apply thin coat of grease
- SAT Saturate (felt oilers, washers, wicks) with oil

1.04 Use TP88970 (KS7470) oil at all locations where the use of oil is indicated. Use TP88973 (KS7471) grease on all surfaces where grease is indicated.

2. LUBRICATION DETAILS

2.01 Stop Magnet





28 PERFORATOR-TRANSMITTER BASE

LUBRICATION

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1-2	Lockbar latch mechanism	10
2. LUBRICATION	3	Locking bail mechanism	12
Answer-Back Mechanism		Margin indicating mechanism	10
Answer-back armature mechanism . .	20	Nonrepeat lever mechanism	8
Answer-back codebars and		Remote control gear shift	18
sensing levers	22	Repeat on space mechanism	16
Answer-back driving mechanism . . .	22	Reset cam follower mechanism	13
Answer-back keyboard lock bail		Selector lever mechanism	5
mechanism	23	Signal generator mechanism	8-12
Answer-back mechanism	20	Space bar mechanism	3
Answer-back sensing lever		Synchronous pulse	17
mechanism	20	Synchronous pulsed magnet	17
Answer-back stepping pawl	23	mechanism	19
Answer-back stop lever	21	Time delay mechanism	10
Keyboard Mechanism		Transfer bail mechanism	9
Break lever mechanism	4	Transfer lever mechanism	13
Character counter and electrical		Universal bail latchlever mechanism .	13
break mechanism	14		
Character counter	14-15	1. GENERAL	
Clutch tripbar link mechanism	6	1.01 This section has been revised to include	
Clutch tripbar mechanism	9	recent engineering changes and additions,	
Codebar and local line feed		and to rearrange the text so as to bring the sec-	
mechanism	7	tion generally up-to-date. Since this is an ex-	
Codebar bail mechanism	13	tensive revision, marginal arrows ordinarily	
Codebar extension bail mechanism . .	6	used to indicate changes have been omitted.	
Codebar extension mechanism	6	1.02 The 28 Perforator-Transmitter Base	
Codebar guide	17	should be lubricated as directed in this	
Codebar mechanism	7	section. The figures indicate points to be lu-	
Codelever mechanism	4	bricated and the kind and quantity of lubricant	
Codelever universal bail mechanism .	7	to be used. Lubricate the keyboard just prior to	
Contact box	9	placing it in service. After a few weeks in serv-	
Contact swinger	17	ice, relubricate to make certain that all points	
Detent lever mechanism	5	receive lubrication. The following lubrication	
Electrical line break mechanism . . .	15	schedule should be followed thereafter:	
Extension basket mechanism	5		
Intermediate gear mechanism	11	OPERATING SPEEDS	LUBRICATION
Keyboard	3	<u>IN WORDS PER MINUTE</u>	<u>INTERVAL</u>
Keyboard clutch mechanism	10	60	3000 hr or 1 yr*
Keyboard lock mechanism	4	75	2400 hr or 9 mo*
Keyboard mechanism	11	100	1500 hr or 6 mo*
Keyboard shaft mechanism	3	150	1000 hr or 6 mo*
Local carriage return mechanism . . .	8		
Local line feed mechanism	11		
Local paper feed-out mechanism . . .	15		

*Whichever occurs first.

SECTION 573-117-701

1.03 Use TP88970 oil at all locations where the use of oil is indicated. Use TP88973 grease on all surfaces where grease is indicated.

1.04 All spring wicks and felt oilers should be saturated. The friction surfaces of all moving parts should be thoroughly lubricated. Over-lubrication, however, which will permit oil or grease to drip or be thrown on other parts, should be avoided. Special care must be taken to prevent any oil or grease from getting between electrical contacts.

1.05 Apply a thick film of grease to all gears.

1.06 Apply oil to all cams, including the camming surfaces of each clutch disc.

1.07 The photographs show the paragraph numbers referring to particular line drawings of mechanisms and where these mechanisms are located on the unit. Parts in the line drawings are shown in an upright position unless otherwise specified.

1.08 The illustration symbols indicate the following lubrication directions:

- O Apply 1 drop of oil.
- O2 Apply 2 drops of oil.
- O3 Apply 3 drops of oil.
- O20 Apply 20 drops of oil, etc.
- G Apply thin film of grease.
- SAT Saturate (felt oilers, washers, wicks) with oil.





Figure 1 - 28 Perforator-Transmitter Base

2. LUBRICATION


2.01 KEYBOARD

NOTE: REST PERFORATOR TRANSMITTER BOTTOM SIDE UP.



(BOTTOM VIEW)

2.02 SPACE BAR MECHANISM



0 BEARING SURFACE SPACE BAR
(LEFT & RIGHT)


0 ENGAGING SURFACE (36 LEVERS) KEYTOP LEVERS

2.03 KEYLEVER MECHANISM




2.07 EXTENSION BASKET MECHANISM

NOTE: REST PERFORATOR TRANSMITTER BOTTOM SIDE UP.




(BOTTOM VIEW)


2.08 DETENT LEVER MECHANISM



2.09 SELECTOR LEVER MECHANISM




2.13 CODE BAR AND LOCAL LINE FEED MECHANISM
 NOTE: REST PERFORATOR IN UPRIGHT POSITION.




(TOP VIEW)


2.14 CODE BAR MECHANISM




2.15 CODE LEVER UNIVERSAL BAIL MECHANISM



2.19 CLUTCH TRIP BAR MECHANISM




2.20 TRANSFER LEVER MECHANISM




2.21 CONTACT BOX


DISASSEMBLY: REMOVE NUT AND LOCK WASHER SECURING CONTACT BOX COVER AND REMOVE COVER.




2.26 LOCAL LINE FEED MECHANISM




2.27 KEYBOARD SHAFT MECHANISM




2.28 INTERMEDIATE GEAR MECHANISM




2.31 CODE BAR BAIL MECHANISM




2.32 UNIVERSAL BAIL LATCH LEVER MECHANISM



2.33 RESET CAM FOLLOWER MECHANISM




2.36 CHARACTER COUNTER MECHANISM continued




- 0 CONTACT SURFACE ANTI-BOUNCE LATCH
- 0 BEARING SURFACE ANTI-BOUNCE LATCH
- 02 BEARING SURFACE RATCHET DRUM
- G TEETH RATCHET
- 0 ENGAGING SURFACES (2 PLACES) RESET LEVER EXTENSION
- 0 HOOKS-EACH END (3 SPRINGS) SPRING
- 0 BEARING SURFACE RESET BAIL
- 0 BEARING SURFACE DRIVE LEVER FEED BAIL
- 0 ENGAGING SURFACES (3 SURFACES) DRIVE LEVER FEED BAIL & RESET BAIL

2.37 ELECTRICAL LINE BREAK MECHANISM




- 0 HOOKS-EACH END SPRING
- G CONTACT SURFACE SENSITIVE SWITCH
- 0 BEARING SURFACE BREAK LEVER

2.38 LOCAL PAPER FEED-OUT MECHANISM



- G ENGAGING SURFACE LOCAL LINE FEED TRIP LINK
- 0 HOOKS-EACH END SPRING
- 02 BEARING SURFACE LEVER
- G ENGAGING SURFACE MAGNETIC BLOWOUT SWITCH

2.41 SYNCHRONOUS PULSE




FRONT

2.42 CODE BAR GUIDE




○ GUIDE SLOTS (LEFT, RIGHT, TOP AND BOTTOM)

2.43 SYNCHRONOUS PULSED
MAGNET MECHANISM




○ HOOKS-EACH END UNIVERSAL CODE BAR SPRING
 ○ HOOKS-EACH END CLUTCH TRIP BAR SPRING
 SAT FELT WASHERS ARMATURE-PIVOT

2.44 CONTACT SWINGER




G ENGAGING SURFACE


2.46 TIME DELAY MECHANISM




2.50 ANSWER-BACK — STOP LEVER



2.53 ANSWER-BACK — STEPPING PAWL



2.54 ANSWER-BACK — KEYBOARD LOCK BAIL MECHANISM



28 TYPING UNIT
LUBRICATION

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	2	Vertical positioning mechanism (left side)	11
2. BASIC UNITS	4	Vertical positioning mechanism (right side)	9
Carriage return mechanism	17	3. VARIABLE FEATURES	29
Code bar detents	7	CONTINUOUS SPACING MECHANISM	40
Code bar mechanism	6, 12	Compression spring	41
Function rocker shaft mechanism	15	Slide arm bracket	41
Horizontal positioning mechanism	18, 19	Trip mechanism	40
Letters-figures shift mechanism	20, 21	Typing unit - rear view	41
Line feed mechanism (friction feed)	26	DC MAGNET OPERATED PRINT SUPPRESSION MECHANISM	49
Line feed mechanism (sprocket feed)	27	Suppression mechanism	49
Main shaft (clutches, gears, etc.)	23, 24	FORM ALIGNMENT SWITCH MECHANISM	48
Main shaft mechanism	23	Operating mechanism	48
Oscillating mechanism	21, 22	FORM FEED-OUT MECHANISM	50
Paper feed mechanism (front view)	7	Feed-out bail	50
Paper guide mechanism (sprocket feed)	28	HORIZONTAL TABULATOR MECHANISM (EARLIER DESIGN)	29
Paper spindle latch mechanism	26	Operating lever mechanism	30
Printing mechanism	4, 5	Space suppression mechanism	29
Ribbon feed mechanism (left side)	10	Spacing clutch mechanism	31
Ribbon feed mechanism (right side)	8, 9	Tabulator shaft mechanism	29
Ribbon reverse mechanism	14	Typing unit - bottom view	30
Selector mechanism	12, 13	Typing unit - front view	29
Selector cam clutch assembly	23	HORIZONTAL TABULATOR MECHANISM (LATER DESIGN)	42
Shift mechanism	15	Bail extension arm	44
Spacing drum drive mechanism (earlier design)	16	Blocking lever	43
Spacing drum drive mechanism (later design)	16	Intermediate bail	44
Spacing drum feed mechanism	17	Latch bail	44
Spacing mechanism	25	Operating lever	43, 44
Stripper blade mechanism	14		
Stunt box mechanism	14		
Track guide mechanism	17		
Type box carriage mechanism	5		
Typing unit - bottom view	22, 24		
Typing unit - front bottom view	15		
Typing unit - front view	4, 6, 18, 20		
Typing unit - left front view	7		
Typing unit - rear left end view	8		
Typing unit - rear left view	26		
Typing unit - rear top view	27		
Typing unit - rear view	13		
Typing unit - right end view	8, 11		

CAUTION: SPECIAL CARE MUST BE TAKEN TO PREVENT ANY OIL OR GREASE FROM GETTING BETWEEN THE SELECTOR ARMATURE AND ITS MAGNET POLE FACES. KEEP ALL ELECTRICAL CONTACTS FREE OF OIL AND GREASE.

1.06 Apply a thick film of grease to all gears and the spacing clutch reset cam plate.

1.07 Apply oil to all cams, including the camming surfaces of each clutch disc.

1.08 The photographs show the paragraph numbers referring to particular line drawings of mechanisms and where these mechanisms are located on the unit. Parts in the line drawings are shown in an upright position unless otherwise specified.

Note: References made to left or right, top or bottom, and front or rear apply to the typing unit in its normal operating position as viewed by the operator facing the unit.

1.09 The following list of symbols apply to the specific lubrication instructions given in each paragraph.

O Apply 1 drop of oil.
 O2 Apply 2 drops of oil.
 O3 Apply 3 drops of oil, etc.
 G Apply thin film of grease.
 SAT Saturate (felt oilers, washers, wicks) with oil.

1.10 During each lubrication period, check the following items. Requirements and adjustments are given in Section 573-115-700.

(1) Printing Carriage Position

(2) Printing Hammer Bearing Stud


(3) Printing Track

(4) Printing Hammer Stop Bracket (Also see Note 2, Par. 2.48, 573-115-700 which refers to Printing Hammer Operating Bail Spring Bracket Position.)


(5) Carriage Draw Wire Rope

(6) Dashpot Vent Screw (Check dashpot transfer slide for freeness.)


2.03 Printing Mechanism (Cont'd)




2.04 Type Box Carriage Mechanism




2.07 Typing Unit - Left Front View




2.08 Codebar Detents




2.09 Paper Feed Mechanism - Front View




2.13 Ribbon Feed Mechanism - Right Side (Cont'd)




2.14 Vertical Positioning Mechanism - Right Side




2.17 Vertical Positioning Mechanism - Left Side




2.18 Typing Unit - Right End View




2.21 Selector Mechanism (Cont'd)




2.22 Typing Unit - Rear View




2.23 Typing Unit - Rear View




2.27 Shift Mechanism




2.28 Function Rocker Shaft Mechanism




2.29 Typing Unit - Front Bottom View



2.32 Carriage Return Mechanism




2.33 Spacing Drum Feed Mechanism



2.34 Track Guide Mechanism




2.37 Horizontal Positioning Mechanism (Cont'd)



- O HOOKS—EACH END SPRING
- SAT FELT WASHER CODE BAR BELL CRANK
- O2 ENGAGING SURFACES (3 SLIDES) HORIZONTAL MOTION STOP SLIDES


2.38 Horizontal Positioning Mechanism (Cont'd)



- O2 ENGAGING SURFACES DECELERATING SLIDE (SEE NOTE 1)
- O HOOKS—EACH END (2 SPRINGS) SPRING
- O2 BEARING SURFACES (2 BELL CRANKS) DECELERATING SLIDE BELL CRANKS
- O2 ENGAGING SURFACES (2 SLIDES) DECELERATING SLIDES (SEE NOTE 2)
- SAT FELT WASHERS (3 WASHERS) SHIFT SLIDE DRIVE LINKS
- O BEARING SURFACES (8 PLACES) SHIFT SLIDE DRIVE LINKS


- NOTES**
1. WITH SPRINGS LOCATED ON REAR SIDE OF SLIDE
 2. WITH SPRINGS LOCATED ABOVE THE SLIDE

2.39 Horizontal Positioning Mechanism (Cont'd)




- O2 GUIDING SURFACE HORIZONTAL POSITIONING LOCK LEVER
- O2 BEARING SURFACE HORIZONTAL LOCK LEVER ARM
- SAT FELT WICK ROLLER
- O HOOKS—EACH END SPRING WICK
- SAT FELT WASHER SPRING
- HORIZONTAL POSITIONING LOCK LEVER

2. 42 Letters - Figures Shift Mechanism (Cont'd)




(RIGHT SIDE)




(LEFT SIDE)


2. 43 Oscillating Mechanism




2.46 Main Shaft - Clutches, Gears, Etc.




2.47 Main Shaft Mechanism



2.48 Selector Cam Clutch Assembly




2.51 Spacing Mechanism




- | | | |
|-----|--------------------------------------|----------------------------------|
| O2 | ENGAGING SURFACES | SPACING TRIP LEVER |
| SAT | FELT WASHERS
(2 WASHERS) | SPACING SUPPRESSION
SLIDE |
| SAT | FELT WASHER | SPACING TRIP LEVER |
| SAT | FELT WASHER | SPACING TRIP LEVER
BAIL SHAFT |
| O2 | ENGAGING SURFACE | SPACING TRIP LEVER
BAIL |
| G | ENGAGING SURFACE
HOOKS - EACH END | TRIP RESET CAM |
| O | HOOKS - EACH END
(2 SPRINGS) | TRIP RESET CAM
SPRING PLATE |

2.52 Spacing Mechanism (Cont'd)




- | | | |
|----|----------|--------------------|
| O2 | OIL HOLE | SPACING SHAFT |
| G | TEETH | SPACING SHAFT GEAR |

2.53 Spacing Mechanism (Cont'd)




- | | | |
|-----|-----------------------------|----------------------------------|
| O2 | ENGAGING SURFACE | SPACING CUT-OUT
TRANSFER BAIL |
| SAT | FELT WASHERS
(2 WASHERS) | SPACING CUT-OUT
TRANSFER BAIL |
| SAT | FELT WASHER | SPACING CUT-OUT
BAIL |
| O2 | ENGAGING SURFACE | SPACING CUT-OUT BAIL |
| SAT | FELT WASHERS
(2 WASHERS) | CARRIAGE RETURN BAIL
SHAFT |
| O | HOOKS - EACH END | SPRING |

2.57 Typing Unit - Rear Top View




2.58 Line Feed Mechanism - Sprocket Feed




3. VARIABLE FEATURES

HORIZONTAL TABULATOR MECHANISM - EARLIER DESIGN


3.01 Typing Unit - Front View




3.02 Tabulator Shaft Mechanism



3.03 Space Suppression Mechanism




3.06 Spacing Clutch Mechanism




SELECTIVE CALLING MECHANISM


3.07 Typing Unit - Rear View




3.10 Typing Unit - Rear View - Stunt Box Removed



3.11 Single-Double Line Feed Mechanism




3.14 Clutch Suppression Mechanism




LOCAL BACKSPACE MECHANISM

3.15 Typing Unit - Front View




3.18 Trip Mechanism



(LEFT SIDE VIEW)

LOCAL BACKSPACE MECHANISM (Cont'd)


3.19 Trip Mechanism




(LEFT SIDE VIEW)

PAGE FEED-OUT MECHANISM


3.22 Typing Unit - Rear Left End View



3.23 Drive Mechanism




3.26 Slide Arm Bracket




- 02 ENGAGING SURFACE (TWO BRACKETS)
- SAT FELT WASHERS (EACH END)
- 02 ENGAGING SURFACE (EACH END)

- C.R. SLIDE ARM BRACKET
- L.F. SLIDE ARM BRACKET
- CONNECTING LINK
- COMPRESSION SPRING (LP 6 & 9 ONLY)


3.27 Compression Spring




3.28 Typing Unit - Rear View




3.31 Blocking Lever



3.32 Slide Arm




3.33 Operating Lever




TWO COLOR RIBBON MECHANISM

3.39 Oscillating Lever




3.40 Ribbon Operating Mechanism



VERTICAL TABULATION AND TRANSMITTER DISTRIBUTOR CONTROL MECHANISM

3.43 Control Mechanism




(LEFT VIEW)
SEE PAR. 3.22

- G GEAR PAGE FEED-OUT
- G GEAR IDLER
- O2 BEARING HANDWHEEL
- PIVOT ADJUSTABLE ARM
- BEARING SURFACE ADJUSTABLE ARM AND BLOCKING LEVER
- SPRING (BOTH ENDS) BLOCKING LEVER
- PIVOT BLOCKING LEVER
- SLIDES (2) PAGE FEED-OUT AND VERTICAL TAB


DC MAGNET OPERATED PRINT SUPPRESSION MECHANISM

3.46 Suppression Mechanism



LETTERS-FIGURES CODEBAR SHIFT MAGNET MECHANISM

3.47 Shift Magnet Mechanism




28 TYPING AND NONTYPING PERFORATORS

LUBRICATION


CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL.	1-2	Rear bearing bracket gear mechanism	5
2. LUBRICATION.	3	Reset bail mechanism	9
Axial positioning mechanism (typing perforator only)	14	Retractor bail mechanism	7
Detent assemblies	15	Ribbon feed mechanism (latest design)	10
Feed wheel mechanism	9	Rocker arm mechanism	9
Function box (typing perforator only)	14	Rocker bail mechanism (nontyping only)	4
Function cam-clutch trip mechanism	13	Rocker bail mechanism (typing perforator only)	16
Manual and power backspace mechanism for chadless tape	17	Rotary positioning (typing perforator only)	11
Manual and power backspace mechanism for fully perforated tape	18	Shaft mechanism (typing perforator only)	15
Perforated mechanism for fully perforated tape	8	Signal bell contact mechanism	21
Perforator clutch and reset cam mechanism	3	Single auxiliary timing contact mechanism	20
Perforator clutch driving shaft mechanism (nontyping only)	3	Tape-out switch mechanism	20
Perforator clutch gear mechanism (nontyping only)	4	Tape shoe arm mechanism	7
Perforator clutch mechanism (nontyping only)	4	Transfer mechanism (typing perforator only)	12
Perforator gear and motor pinion	20	Typing perforator	10
Perforator mechanism	5	Unshift on space mechanism	21
Perforator mechanism reset and perforator mechanism in upright position	3		
Perforator trip lever mechanism (nontyping only)	5	1. GENERAL	
Power drive backspace mechanism (early design)	18	1.01 This section contains the specific lubrication procedures for the 28 Typing and Nontyping Perforators. Included in the section are recent engineering changes and additions bringing it generally up-to-date.	
Power drive backspace mechanism (latest design)	19	1.02 The 28 Typing and Nontyping Perforators should be lubricated as directed in this section. The figures indicate points to be lubricated and the kind and quantity of lubricant to be used. Lubricate the perforators just prior to placing them in service. After a few weeks in service, relubricate to make certain that all points receive lubrication. The following lubrication schedule should be followed thereafter:	
Printing mechanism (typing perforator only)	16		
Punch mechanism	6		
Punch pin mechanism	7		
Punch slide latch mechanism	6		
Punch slide mechanism	7		
Push bars (typing perforator only)	12		

2. LUBRICATION


2.01 PERFORATOR MECHANISM RESET AND PERFORATOR MECHANISM IN UPRIGHT POSITION




2.02 PERFORATOR CLUTCH DRIVING SHAFT MECHANISM (NON-TYPING ONLY)



2.03 PERFORATOR CLUTCH AND RESET CAM MECHANISM




2.07 PERFORATOR MECHANISM (continued) REST PERFORATOR TRANSMITTER IN UPRIGHT POSITION




(FRONT VIEW)


2.08 REAR BEARING BRACKET GEAR MECHANISM



2.09 PERFORATOR TRIP LEVER MECHANISM (NON-TYPING ONLY)




2.12 TAPE SHOE ARM MECHANISM




- 0 BEARING SURFACE TAPE SHOE
- 0 BEARING SURFACE (2) (FRONT AND REAR) TAPE SHOE ARM

2.13 RETRACTOR BAIL MECHANISM




- 0 HOOKS-EACH END (4 SPRINGS) ROCKER BAIL SPRING
- SAT FELT WASHERS (2-FRONT & REAR) RETRACTOR BAIL
- 0 BEARING SURFACE (2-FRONT & REAR) RETRACTOR BAIL

2.14 PUNCH PIN MECHANISM




- 0 GUIDES AND NOTCHES (3 PLACES) PUNCH PINS
- 0 SPRING RETRACTOR SPRING

2.15 PUNCH SLIDE MECHANISM




- 02 ENGAGING SURFACE PUNCH SLIDE GUIDE
- 0 HOOKS-EACH END (5 SPRINGS) SPRINGS
- G ENGAGING SURFACE (5) RESET BAIL


2.18 FEED WHEEL MECHANISM




2.19 RESET BAIL MECHANISM




2.20 ROCKER ARM MECHANISM




2.23 RIBBON FEED MECHANISM (LATE DESIGN)




2.24 ROTARY POSITIONING MECHANISM (TYPING PERFORATOR ONLY)



2.25 TRANSFER MECHANISM (TYPING PERFORATOR ONLY)




2.26 PUSH BARS (TYPING PERFORATOR ONLY)




2.27 TYPING PERFORATOR


NOTE: PLACE PERFORATOR IN UPRIGHT POSITION.




2.28 FUNCTION CAM — CLUTCH TRIP MECHANISM




2.29 FUNCTION BOX (TYPING PERFORATOR ONLY)




2.30 AXIAL POSITIONING MECHANISM (TYPING PERFORATOR ONLY)



2.31 AXIAL POSITIONING MECHANISM (TYPING PERFORATOR ONLY)




2.32 DETENT ASSEMBLIES (TWO ON AXIAL POSITIONING MECHANISM)




2.33 SHAFT MECHANISMS (TYPING PERFORATOR ONLY)


* IF FUNCTION CAM NEEDLE BEARINGS ARE DISSASSEMBLED AT ANY TIME, REPACK BEARINGS WITH GREASE.




2.34 PRINTING MECHANISM (TYPING PERFORATOR ONLY)



2.35 ROCKER BAIL MECHANISM (TYPING PERFORATOR ONLY)




2.36 MANUAL AND POWER DRIVE BACKSPACE MECHANISM FOR CHADLESS TAPE
 NOTE: REST PERFORATOR TRANSMITTER IN UPRIGHT POSITION.




(FRONT VIEW)


2.37 MANUAL AND POWER DRIVE BACKSPACE MECHANISM FOR CHADLESS TAPE




2.38 MANUAL AND POWER DRIVE BACKSPACE MECHANISM FOR FULLY PERFORATED TAPE




2.39 POWER DRIVE BACKSPACE MECHANISM (EARLY DESIGN)




2.40 POWER DRIVE BACKSPACE MECHANISM (LATEST DESIGN)




2.41 SINGLE AUXILIARY TIMING CONTACTS MECHANISM




2.42 TAPE-OUT SWITCH MECHANISM




2.43 PERFORATOR GEAR AND MOTOR PINION




2.44 UNSHIFT ON SPACE MECHANISM



2.45 SIGNAL BELL CONTACT MECHANISM





28 TYPING REPERFORATOR AND TAPE PRINTER

LUBRICATION

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1	End of tape feed-out timing con- tacts for noninterfering LTRS and BLANK tape feed-out mechanisms . .	29
2. BASIC UNITS	2	Letters-figures contact mechanism (later design)	34
Axial positioning mechanism	13, 14	Manual and power drive backspace mechanisms (for chadless tape)	36
Detent assemblies	14	Manual and solenoid operated interfering LTRS tape feed-out mechanisms	21, 22
Function box mechanism	13	Print suppression on functions	31
Function cam clutch trip mechanism .	17	Remote control noninterfering LTRS and BLANK tape feed-out mechanisms	25
Main shaft and jack shaft mechanisms (two shaft unit)	18	Signal bell contact mechanism	20, 21
Main shaft mechanism	10	Time delay motor stop mechanism . .	39
Printing mechanism	15	Timing contacts	35
Punch mechanism (for chadless tape).	4, 5	Timing contact mechanism (operated by selector)	30
Punch mechanism (for fully perfo- rated tape)	6, 7	Unshift-on-space mechanism	20
Push bars	11	4. EARLIER DESIGN MECHANISMS . . .	40
Range finder mechanism	10	Remote control noninterfering BLANK tape feed-out mechanism . .	41-46
Ribbon feed mechanism (later design)	3	Ribbon feed mechanism	40
Rocker bail mechanism	16	Timing contacts	46
Rotary positioning mechanism	9		
Selector mechanism	9	1. GENERAL	
Signal bell contact mechanism	17	1.01 This section contains the lubrication pro- cedures for the 28 typing reperforator and tapeprinter units. The section has been revised to include recent engineering changes and addi- tions and to rearrange the text, so as to bring the section generally up-to-date. Since this is an extensive revision, marginal arrows ordinari- ly used to indicate changes have been omitted.	
Slack tape mechanism (for 28 tape printer unit)	19	1.02 The figures indicate points to be lubri- cated and the kind and quantity of lubri- cant to be used. Lubricate the units just prior to placing them in service. After a few weeks in service, relubricate to make certain that all points receive lubrication. The following lubri- cation schedule should be followed thereafter:	
Transfer mechanism	11		
Typing reperforator unit	2, 8, 12		
3. VARIABLE FEATURES	20		
Automatic and remote control non- interfering BLANK tape feed-out mechanisms	28		
Automatic and remote control non- interfering LTRS and BLANK tape feed-out mechanisms	24, 26, 27		
Automatic and remote control non- interfering LTRS tape feed-out mechanisms	23		
Backspace mechanism for chadless tape (manual)	37		
Backspace mechanism for chadless tape (power drive)	37		
Backspace mechanism for fully perforated tape (power drive)	38		
Blank delete mechanism	32, 33		
Code reading contacts	35		

OPERATING SPEEDS
IN WORDS PER MINUTE

60
75
100

LUBRICATION
INTERVAL

3000 hours
or 1 year*
2400 hours
or 9 months*
1500 hours
or 6 months*

*Whichever occurs first.

1.03 Use TP88970 (KS7470) oil at all locations where the use of oil is indicated. Use TP88973 (KS7471) grease on all surfaces where grease is indicated. If the function cam needle bearings are disassembled at any time, repack the bearings with TP195298 grease (Beacon 325 grease or its equivalent).

1.04 All spring wicks and felt oilers should be saturated. The friction surfaces of all moving parts should be thoroughly lubricated. Over lubrication, however, which will permit oil or grease to drip or be thrown on other parts, should be avoided. Take special care to prevent oil or grease from getting between armatures and pole faces or between electrical contact

2. BASIC UNITS
2.01 Typing Reperforator Unit

points. Pull a piece of "BOND" paper between the armature and the pole pieces to remove any oil or foreign matter that may be present. Make certain that no lint or pieces of paper remain between the pole pieces and armature.


1.05 Apply a thick film of grease to all gears.

1.06 Apply oil to all cams, including the camming surfaces of each clutch disc.

1.07 The photographs show the paragraph numbers referring to particular line drawings of mechanisms and where these mechanisms are located on the unit. Parts in the line drawings are shown in an upright position unless otherwise specified.



1.08 The illustration symbols indicate the following lubrication directions:

- O1 Apply 1 drop of oil.
- O2 Apply 2 drops of oil.
- O3 Apply 3 drops of oil, etc.
- G Apply thin film of grease.
- SAT Saturate (felt oilers, washers, wicks) with oil.





2.02 Ribbon Feed Mechanism (Later Design)



(For Earlier Design
See Part 4.)





2.03 Punch Mechanism for Chadless Tape





2.04 Punch Mechanism for Chadless Tape continued




2.05 Punch Mechanism for Fully Perforated Tape




2.06 Punch Mechanism for Fully Perforated Tape continued




2.07 Typing Reperforator Unit




2.08 Rotary Positioning Mechanism



2.09 Selector Mechanism




2.10 Range Finder Mechanism




2.11 Main Shaft Mechanism


*IF FUNCTION CAM NEEDLE BEARINGS ARE DISASSEMBLED AT ANY TIME, REPACK BEARINGS WITH GREASE (BEACON 325) (TP195298) OR ITS EQUIVALENT.




2.12 Transfer Mechanism




2.13 Push Bars




2.14 Typing Reperforator Unit




2.15 Function Box Mechanism



2.16 Axial Positioning Mechanism




2.17 Axial Positioning Mechanism continued (Left Side View)




2.18 Detent Assemblies (Bottom View)

NOTE: THERE ARE TWO DETENT ASSEMBLIES ON THE AXIAL POSITIONING MECHANISM.




2.19 Printing Mechanism With Steel Print Hammer (Left Side View)




2.20 Printing Mechanism With Resilient Print Hammer (Left Side View): The printing mechanism with resilient print hammer (not illustrated) shall be lubricated in the same manner as the steel print hammer shown in 2.19 but in addition, the felt washer between the resilient

print hammer accelerator and the frame shall be saturated with oil in accordance with general lubrication procedures. Where a mechanism is equipped with print suppression parts, a thin film of grease shall be applied on print hammer stop at the point of contact with the print hammer lever.


2.21 Rocker Bail Mechanism (Rear View)



2.22 Function Cam Clutch Trip Mechanism





2.23 Slack Tape Mechanism




2.24 Main Shaft and Jack Shaft Mechanisms (Two Shaft Unit)

*IF FUNCTION CAM NEEDLE BEARINGS ARE DISASSEMBLED AT ANY TIME, REPACK BEARINGS WITH GREASE (BEACON 325) (TPI 95298) OR ITS EQUIVALENT.



2.25 Tape Mechanism for 28 Tape Printer Unit

(THIS LUBRICATION INSTRUCTION PLUS APPLICABLE
28 TYPING REPERFORATOR LUBRICATION
INSTRUCTIONS ARE REQUIRED TO LUBRICATE THE
28 TAPE PRINTER UNIT)




SAT FELT WASHER


TAPE MECHANISM

3. VARIABLE FEATURES


3.01 Unshift-On-Space Mechanism




3.02 Signal Bell Contact Mechanism (Right Side View)




3.03 Manual and Solenoid Operated Interfering LTRS Tape Feed-Out Mechanism and Signal Bell Mechanism




3.04 Manual and Solenoid Operated Interfering LTRS Tape Feed-Out Mechanism





3.05 Automatic and Remote Control Noninterfering LTRS Tape Feed-Out Mechanisms




3.06 Automatic and Remote Control Noninterfering LTRS and BLANK Tape Feed-Out Mechanisms





3.07 Remote Control Noninterfering LTRS and BLANK Tape Feed-Out Mechanism





3.08 Automatic and Remote Control Noninterfering LTRS and BLANK Tape Feed-Out Mechanisms continued




3.09 Automatic and Remote Control Noninterfering LTRS and BLANK Tape Feed-Out Mechanisms continued




3.10 Automatic and Remote Control Noninterfering BLANK Tape Feed-Out Mechanisms



3.11 End of Tape Feed-Out Timing Contacts for Noninterfering LTRS and BLANK
Tape Feed-Out Mechanisms




3. 12 Timing Contact Mechanism (Operated by Selector)




- | | | |
|-----|------------------------------------|-----------------------------------|
| G | METAL FACE TOWARD
OPERATING ARM | SWINGER SPRING
INSULATOR |
| SAT | FELT WASHERS (3) | OPERATING LEVER |
| O2 | BEARING-EACH END | OPERATING LEVER |
| O1 | HOOKS-EACH END | OPERATING LEVER
COILED SPRINGS |
| G | OPERATING SURFACE | CAM |



3.13 Print Suppression on Functions




3.14 Blank Delete Mechanism




3. 15 Blank Delete Mechanism continued




3.16 Letters-Figures Contact Mechanism (Later Design)




3.17 Timing Contacts




3.18 Code Reading Contacts




3.19 Manual and Power Drive Backspace Mechanisms (for Chadless Tape)





3.20 Backspace Mechanism for Chadless Tape (Manual)




3.21 Backspace Mechanism for Chadless Tape (Power Drive)




3.22 Backspace Mechanism for Fully Perforated Tape (Power Drive)




3.23 Time Delay Motor Stop Mechanism



- O1 HOOKS-EACH END SPRING
- O1 ENGAGING SURFACE CONTACT OPERATING PAWL AND LATCH LEVER
- SAT FELT WASHERS LATCH LEVER
- O1 ENGAGING SURFACE BELL CRANK AND CONTACT OPERATING PAWL
- O1 ENGAGING SURFACE LATCH PAWL AND LATCH LEVER
- O1 HOOKS-EACH END SPRING
- SAT FELT WASHERS LATCH PAWL
- O2 BEARING SURFACE EACH END RATCHET WHEEL SHAFT
- O1 BEARING SURFACE EACH END BELLCRANK AND SUPPORTING STUD
- G TEETH AND FLANGES RATCHET WHEELS
- O1 ENGAGING SURFACE CLAMP ARM AND BELLCRANK
- SAT FELT WASHERS CONTACT PAWL
- O2 BEARING SURFACE (2) TIME DELAY RESET SHAFT BUSHING




- O3 BEARING SURFACE ECCENTRIC FOLLOWER DRIVE ARM AND ECCENTRIC
- O1 HOOKS-EACH END SPRING
- G ENGAGING SURFACE DRIVE ARM
- G ENGAGING SURFACE CONTACT OPERATING PAWL AND CONTACT INSULATOR



- O1 ENGAGING SURFACE SELECTOR RESET BAIL TIME DELAY RESET LEVER


4. EARLIER DESIGN MECHANISMS

4.01 Ribbon Feed Mechanism
(For Later Design
See Par. 2.02.)





4.02 Remote Control Noninterfering BLANK Tape Feed-Out Mechanism



(For Later Design
See Part 3 Variable Features)






4.03 Remote Control Noninterfering BLANK Tape Feed-Out Mechanism continued
 (For Later Design See Part 3 Variable Features)




4.04 Remote Control Noninterfering BLANK Tape Feed-Out Mechanism continued
 (For Later Design
 See Part 3 Variable Features)




4.05 Remote Control Noninterfering BLANK Tape Feed-Out Mechanism continued
 (For Later Design See Part 3 Variable Features)



4.06 Remote Control Noninterfering BLANK Tape Feed-Out Mechanism continued
(For Later Design See Part 3 Variable Features)



4.07 Remote Control Noninterfering Tape Feed-Out Mechanism continued and Timing Contacts



28 TRANSMITTER-DISTRIBUTOR UNIT (LXD)

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNIT	3
Center-plate assembly	9
Clutch trip assembly	6
Front plate assembly	10, 11
Main shaft	8
Main shaft, oil reservoir, and center-plate assembly	7
Sensing and feed assembly	11
Signal contact assembly	5
Tape guideplate	4
Transfer mechanism	12
Transmitter-distributor	3
3. VARIABLE FEATURES	13
All gears	18
Code reading contacts	14
Rub-out deleter	16
Start-stop pulse contact	16
Tape deflector	15
Tape feed assurance mechanism	13
Tape lid sensing lever	15
Tape-out sensing mechanism	13
Tape withhold mechanism	17
Transmitter stop mechanism	17

1. GENERAL

1.01 This section provides lubrication information for the 5-level 28 transmitter-distributor unit (single contact).

CAUTION: THE UNIT IS SHIPPED WITH OIL RESERVOIR EMPTY. REMOVE COVER PLATE FOR ACCESS AND FILL OIL RESERVOIR AS INDICATED IN 2.07.

1.02 In this section, the general areas of the unit are shown by photographs. The specific points of lubrication are indicated by

line drawings and descriptive text. The symbols in the text indicate the following directions:

- O1 Apply one drop of oil.
- O2 Apply two drops of oil, etc.
- G Apply thin coat of grease.
- SAT Saturate with oil (felt washers, oilers, etc).

1.03 Use KS7470 oil at all locations where the use of oil is indicated. Use KS7471 grease on all surfaces where grease is indicated.

1.04 The unit should be thoroughly lubricated, but over-lubrication which allows oil to drip or grease to be thrown on other parts, must be avoided. Exercise special care to prevent lubricant from getting between armature and pole faces. Keep all electrical contacts free from oil or grease.

1.05 The following general instructions supplement the specific lubricating points illustrated in this section.

- (1) Apply one drop of oil to all spring hooks.
- (2) Apply a light film of oil to all cam surfaces.
- (3) Apply a coat of grease to all gears.
- (4) Saturate all felt washers, oilers, etc.
- (5) Apply oil to all pivot points.
- (6) Apply oil to all sliding surfaces.

1.06 The transmitter-distributor unit should be lubricated before being placed in service or prior to storage. After a few weeks of service, relubricate to make certain that all specified points have received lubricant. There-

after, the following schedule should be adhered to:


OPERATING SPEED	LUBRICATION INTERVAL
60 wpm	3000 hours or 1 year*
75 wpm	2400 hours or 9 months*
100 wpm	1500 hours or 6 months*

*Whichever occurs first.

1.07 For information pertaining to lubrication of associated parts - ie, motors, bases, etc, refer to the appropriate sections.


1.08 Instructions

- (1) Removing Cover Plate: Lift left end of plate to release the detent fasteners then slide cover plate toward the left. Replace cover in the reverse order.
- (2) Removing Top Plate: Loosen the front and rear mounting screws. Lift top plate upward.
- (3) Remaining Tape Guideplate: Loosen the tape guideplate mounting screws. Lift the tape guideplate.
- (4) Removing Transmitter-Distributor Assembly: Remove the screws which attach the unit to the base, and lift unit up to disengage the gears. Disconnect electrical plug.




2. BASIC UNIT

2.01 Transmitter Distributor




(Front Oblique View)




(Rear Oblique View)

2.02 Tape Guideplate



(Right End - Top View)

O1 Bearing Surface Tight Tape Bail



(Right End - Bottom View)

G Detent Teeth Control Lever

SAT Felt Washer Tape Lid Shaft


O1 Each Loop Start-Stop Detent Bail

O1 Bearing Surface Tape Lid Release Bail

G Latching Surface Tape Lid Latch

O1 Each Loop Tape Lid Latch Spring


2.03 Signal Contact Assembly




(Top View - Cover Plate Removed)

Note: The marking "DO NOT OIL" on the signal contact box should be interpreted literally. Portions of the mechanism should be greased as indicated, but no oil should be used.

2.04 Clutch Trip Assembly




(Front View)




(Right Side View)


2.05 Main Shaft, Oil Reservoir, and Center-Plate Assembly





2.06 Main Shaft




2.07 Oil Reservoir



2.08 Center-Plate Assembly




2.09 Front Plate Assembly, Sensing and Feed Mechanism, and Transfer Mechanism




(Rear Oblique View)

2.10 Front Plate Assembly




2.11 Sensing and Feed Assembly

- | | |
|-----------------|------------------------|
| Shaft | Feed Wheel |
| Felt Wicks | Feed Wheel Bearing |
| Felt Wicks | Sensing Pins |
| Sliding Surface | Sensing Pin Guide Post |
| Sliding Surface | Locking Bail |
| Both Loops | Locking Bail Spring |




(Bottom View)

2.12 Transfer Mechanism




- SAT Each Felt Washer Main Bail Pivots
- G Sliding Surface Bail Drive Post
- SAT Leather Pad Transfer Bail
- O1 Sliding Surfaces Transfer Levers
- O1 Each Loop Transfer Lever Springs
- O1 Each Loop Locking Bail Spring




- O1 Teeth Feed Pawl and Ratchet Wheel
- O1 Each Loop Transfer Lever Springs
- O1 Each Loop Feed Pawl Spring
- O1 Sliding Surface Feed Pawl Pivot
- O1 Engaging Surface Locking Bail
- SAT Felt Washer Locking Bail
- O1 Sliding Surface Transfer Levers

3. VARIABLE FEATURES


3.01 Tape Feed Assurance Mechanism




3.02 Tape-Out Sensing Mechanism



3.03 Code Reading Contacts




3.04 Tape Lid Sensing Lever




- | | | |
|----|------------------|----------------------|
| O1 | Protrusion | Sensing Lever |
| O2 | Pivot | Sensing Lever |
| O3 | Loops (Each End) | Sensing Lever Spring |

3.05 Tape Deflector



- | | | |
|----|----------------------------|------------------|
| O1 | Bearing Surface (Each End) | Tape Deflector |
| G | Thin Film Contact Surface | Deflector Spring |

3.06 Start-Stop Pulse Contact




Engaging Surface

Contact Lever

Engaging Surface

Contact Insulator

3.07 Rub-Out Deleter



Each Loop

Spring


Each Loop

Spring


Engaging Surface

Deflector Bail Guide


3.08 Transmitter Stop Mechanism



3.09 Tape-Withhold Mechanism



3.10 All Gears



MOTOR UNITS

LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. LUBRICATION	2
Motor bearings - standard motors . . .	2
Motor bearings - miniature motors . . .	2

1. GENERAL

1.01 This section has been revised to include additional information for lubricating miniature synchronous motors. Since this issue is a general revision, marginal arrows that indicate changes have been omitted.

1.02 For complete lubrication instructions refer also to the section covering teletypewriter apparatus general lubrication.

1.03 The motor should be lubricated initially, before being placed in service, as specified in the section covering the preparation of teletypewriter apparatus for installation. In the case of a new motor, the information supplied with it pertaining to the amount of lubricant should be used as a guide for further lubrication.

1.04 The suggested lubrication interval is indicated in the chart. However, because of varying conditions of application, the motor should be lubricated as often as specified by local instructions.

1.05 Before lubricating the motor, carefully and thoroughly clean the outer surfaces of the ball oilers with a clean cloth (KS2423)

dampened with petroleum spirits (KS7860). Avoid depressing the ball oilers so that grit, dirty grease, or contaminated petroleum spirits do not get into the motor bearings (Par. 2.01).

1.06 Whenever the motor is disassembled the bearings should be repacked with Beacon 325 grease or equivalent.

1.07 The exposed motor shaft should be covered with a thin film of grease to prevent rust.

1.08 Use KS7470 oil where oil is specified.

1.09 The miniature synchronous motor does not contain ball oilers, as in the larger type motors, but has only a single oil hole in each end shield as shown in Par. 2.02.

CAUTION: DO NOT USE GREASE GUN ON 28, 32, 33 & 37 MOTOR UNITS.


LUBRICATION INTERVAL

Motor Unit	Interval
Standard and heavy duty units	1500 consecutive operating hours or 6 months, whichever occurs first
Miniature units	750 consecutive operating hours or 3 months, whichever occurs first.


SECTION 570-220-701TC

2. LUBRICATION

2.01 Motor Bearings - Standard Motors
Lubrication of motor bearings with ball type oilers.



2.02 Motor Bearings - Miniature Motors



28 CABINET FOR AUTOMATIC SEND-RECEIVE

TELETYPEWRITER SETS

DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY . .	1
Front panel	1
Transmitter-distributor housing (fixed head, multi-contact)	2
Transmitter-distributor housing (fixed head, single contact)	2
Transmitter-distributor housing (pivoted head, multi-contact)	1
Transmitter-distributor housing (pivoted and fixed head, multi-contact)	1

1. GENERAL

1.01 This section contains specific routines for disassembling the 28 teletypewriter cabinet, and where necessary provides detailed reassembly information.

1.02 The technician should refer to the exploded views found in appropriate parts literature for an illustration of the mechanism to be disassembled, for location and visual identification of parts and detailed disassembly and reassembly features.

2. DISASSEMBLY AND REASSEMBLY

2.01 In removing a subassembly from the cabinet, the procedure followed and the location from which parts are removed must be carefully noted so that reassembly can be done correctly. Where no specific instructions are given for reassembly, reverse the procedure used in removing it.

2.02 To remove front panel, remove the typing unit in accordance with the section entitled "28 Typing Unit, Disassembly and Reassembly." Taking care not to damage the character counter, remove the front panel from the

teletypewriter cabinet by removing the two screws, lockwashers, and washers at the left end of the panel and loosening the thumbscrew (inside of cabinet) at the right end of the panel. Slide the panel out to the left.

2.03 To remove the transmitter-distributor housing (pivoted and fixed head, multi-contact) remove the two screws, lockwashers, and flat washers that mount it.

(a) Remove the screw, lockwasher and flat washer (inside of teletypewriter cabinet) that secure the lower right-hand corner of the crossbar to the teletypewriter cabinet.

CAUTION: DO NOT LOOSEN OR REMOVE THE SCREW, LOCKWASHER, AND FLAT WASHER THAT SECURE THE ADJUSTING PLATE, WHICH IS FACTORY POSITIONED.

(b) Loosen the two screws, lockwashers, and flat washers that secure the left edge of the crossbar (with nut plate) to the left panel of the teletypewriter cabinet.

(c) Remove the crossbar by sliding it out to the left.

2.04 To remove the transmitter-distributor housing (pivoted head, multi-contact), remove the screw, lockwasher, and flat washer (inside of teletypewriter cabinet) that secure the lower right-hand corner of the crossbar to the teletypewriter cabinet.

CAUTION: DO NOT LOOSEN OR REMOVE THE SCREW, LOCKWASHER, AND FLAT WASHERS, THAT SECURE THE ADJUSTING PLATE, WHICH IS FACTORY POSITIONED.

(a) Loosen the two screws, lockwashers, and flat washers that secure the left edge of the crossbar (with nut plate) to the left panel of the teletypewriter cabinet.

SECTION 573-134-705

- (b) Remove the crossbar by sliding it out toward the left.

2.05 To remove the transmitter-distributor housing (fixed head, single contact or fixed head, multi-contact), slide it forward to release it from the detent springs that hold it in place.

- (a) Remove the screw, lockwasher, and flat washer (inside of teletypewriter cabinet) that secure the lower right-hand corner of the crossbar to the teletypewriter cabinet.

CAUTION: DO NOT LOOSEN OR REMOVE THE SCREW, LOCKWASHER, AND FLAT WASHER THAT SECURE THE ADJUSTING PLATE, WHICH IS FACTORY POSITIONED.

- (b) Loosen the two screws, lockwashers, and flat washers that secure the left edge of the crossbar (with nut plate), to the left panel of the teletypewriter cabinet.

- (c) Remove the crossbar by sliding it toward the left and rear to disengage it from the slotted holes in the teletypewriter cabinet.

28 ELECTRICAL SERVICE UNITS
DISASSEMBLY AND REASSEMBLY

1. GENERAL

1.01 This section provides disassembly and reassembly instructions for 28 electrical service units used in teletypewriter sets. It is reissued to provide additional information in a standardized format. Since this is a general revision, marginal arrows ordinarily used to indicate changes and additions have been omitted.

1.02 When it is necessary to remove the various components from the electrical service unit, the appropriate wiring diagrams should be used as a reference.

1.03 After the disassembly procedure has been followed, reassembly procedure for most components is obviously a reversal of the disassembly procedure. Where necessary, reassembly information is given.

Note: Remove power from unit before starting disassembly procedure.

2. DISASSEMBLY AND REASSEMBLY

2.01 Removal of 28 Electrical Service Unit from 28 Teletypewriter Cabinet used with 28 Keyboard Send-Receive (28 KSR) or Receive-Only (28 RO) Teletypewriter.

- (1) Raise dome of cabinet and disconnect all plugs and receptacles from the typing unit.
- (2) Remove the typing unit in accordance with the section entitled "28 Typing Unit, Disassembly and Reassembly."
- (3) Disconnect all plugs and receptacles from the keyboard and remove the keyboard.
- (4) Remove the mounting studs from each end of the electrical service unit.

Note: The electrical service unit may now be turned upside down for servicing or unwiring components.

(5) The various components may be removed from the unit by removing their mounting screws on the top side of the unit and disconnecting cabling and wires.

(6) If it is desirable to remove the electrical service unit completely from the cabinet, disconnect the remaining wires and cables.

2.02 Removal of Electrical Service Unit from Skin-Tight KSR Sets (Located behind the typing unit cover):

- (1) Unlatch electrical service unit cover at each end and lift cover off.
- (2) Remove the mounting studs from each end of the electrical service unit and lift unit off base.
- (3) Remove various components from the electrical service unit by removing their mounting screws and disconnecting wire or cable connections as necessary.

2.03 Removal of 28 Electrical Service Unit from 28 Automatic Send-Receive Sets (28 ASR):

(a) Without auxiliary equipment

- (1) Raise the dome of the cabinet and disconnect all plugs and receptacles from the typing unit.
- (2) Remove the typing unit in accordance with the section entitled "28 Typing Unit, Disassembly and Reassembly."
- (3) Disconnect all plugs and receptacles from the perforator-transmitter base.
- (4) Remove the mounting studs from each end of the electrical service unit.
- (5) Remove the power control switch assembly bracket at the right end of the unit and the line-test-key control assembly at the left end.
- (6) Remove various components from the electrical service unit by removing their mounting screws and disconnecting wire or cable connections as necessary.

(7) If it is desirable to remove the electrical service unit completely from the cabinet, disconnect the remaining wires and cables.

Note: On some sets it may be necessary to remove the perforator transmitter in order to completely remove the electrical service unit. If necessary, refer to the appropriate section for removing the equipment from the cabinet.

(b) With auxiliary equipment

Note: When Automatic Send-Receive Sets include an auxiliary typing reperforator, an electrical service unit is used in the

lower compartment of the ASR cabinet. To disassemble these units, open the bottom compartment.

(1) Disconnect all plugs and receptacle connections between the electrical service unit and other components and from the cabinet terminal boards.

(2) Remove the studs securing it to the relay rack and lift unit out.

(3) Remove various components from the electrical service unit by removing their mounting screws and disconnecting wire and cable connections as necessary.

28 PERFORATOR-TRANSMITTER BASE

DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY . .	1
Auxiliary Electrical Switch	3
Character Counter	3
Codebar Extension Basket	3
Contact Box.	4
Keyboard	4
Keyboard Hood.	4
Keylever Guide Plate	5
Margin Indicator	3
Perforator (Typing and Nontyping) . .	3
Reset Cam Follower	3
Signal Generator	3
Signal Generator Shaft.	4
Tape Container	3
Transfer Lever Locking Bail	4

1. GENERAL

1.01 Disassembly, as outlined in this section, covers a procedure for removing the principle subassemblies which make up the unit.

1.02 The technician should refer to the exploded views found in the appropriate parts literature for an illustration of the mechanism to be disassembled, for location and visual identification of parts and detailed disassembly and reassembly features.

1.03 Most maintenance, lubrication and adjustments can be accomplished simply by removing the subject component from the cabinet. If possible, disassembly should be confined to subassemblies, which can, in some cases, be removed without disturbing adjustments. When reassembling the subassemblies, be sure to check all associated adjustments, clearances and spring tensions.

1.04 If a part that is mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that

the same shim pile-up can be replaced when the part is remounted.

1.05 Retaining rings are made of spring steel and have a tendency to release suddenly when being removed. Loss of these retainers can be minimized as follows: Hold the retainer with the left hand to prevent it from rotating. Place the blade of a suitable screwdriver in one of the slots of the retainer. Rotate the screwdriver in a direction to increase the diameter of the retainer for removal.

1.06 Avoid loss of springs in disassembly by holding one spring loop with the left hand while gently removing the opposite loop with a spring hook. Do not stretch or distort springs in removing them.

1.07 Raise cabinet lid or enclosure cover and remove the typing unit from its base by removing the four screws that secure it to its keyboard or base. Remove the cable plug connector from the side frame. Lift the typing unit off.

Note: On sets equipped with a form supply container on the rear of the cabinet, rearward foot extensions should be in position to prevent the cabinet from tilting when any of the components are removed.

1.08 Remove the four TP151549 screws that secure the base to the cradle or subbase. Disconnect the cable plug from the connector at the rear of the keyboard base. Remove the base with the motor unit, typing or nontyping perforator still in position.

2. DISASSEMBLY AND REASSEMBLY

2.01 In removing a subassembly from the unit, the procedure followed and the location from which parts are removed must be carefully noted so that reassembly can be done correctly. Where no specific instructions are given for reassembly, reverse the procedure used in removing it.




Figure 1 - 28 Perforator-Transmitter Base

CHARACTER COUNTER

2.02 To remove the character counter assembly, remove the two screws that hold the TP179279 character counter bracket to the keyboard base. Raise the character counter and remove the two screws that hold the TP158050 switch to its TP158021 bracket. Remove the character counter assembly.

TAPE CONTAINER

2.03 To remove the tape container assembly, remove the four screws which hold the TP158233 panel mounting bracket to the base.

PERFORATOR (TYPING AND NONTYPING)

2.04 To remove the perforator assembly, loosen the two set screws on the TP193565 coupling located on the TP144992 rear shaft and slide the coupling to the rear to disengage it.

(a) Remove the three screws which hold the TP158169 nontyping or the TP159861 typing perforator frames to the base, and remove the screw which holds the TP156184 bracket to the base. Raise the perforator slightly from the base being careful not to injure the codebar extension or associated springs.

(b) If unit is equipped with power backspace, unscrew the leads from under the magnet assembly before entirely removing the perforator.

MARGIN INDICATOR

2.05 To remove the margin indicator assembly, remove the two screws which hold the TP158162 switch mounting bracket to the TP158160 reset cam follower lever assembly bracket.

RESET CAM FOLLOWER

2.06 To remove the reset cam follower lever assembly, remove the screws which hold the TP158160 reset cam follower lever assembly bracket to the TP158113 basket frame.

(a) Remove the screws that hold bracket to base.

(b) Disengage the follower lever assembly from the selector lever assembly.

AUXILIARY ELECTRICAL SWITCH

2.07 To remove the auxiliary electrical switch and housing assembly, disconnect the cable leads from the TP158250 terminal board located just to the right of the perforator drive shafting.

(a) Remove the three screws which hold the TP158202 auxiliary switch housing to the base.

(b) Slide the housing to the rear and disengage the TP158208 gear from the TP158210 shaft and lift the housing out.

(c) Disengage the drive shaft from the TP158114 extension basket control cam.

CODEBAR EXTENSION BASKET

2.08 To remove the codebar extension basket assembly, remove the screw which holds the left end of the TP158113 extension basket to the base.

Note: For reassembly purposes, observe how the TP158061 link guide pin and the TP158060 trip bar link latch spring which encases it are engaged between the TP158135 clutch trip bar link and the TP158103 trip bar link latch.

Slide the extension basket to the left and disengage the TP158116 reset lever from the TP158099 keyboard control selection lever assembly.

Note: When reassembling, be sure that the selection lever assembly straddles the clutch trip bar extension lever, and that the selection lever fork engages its mating pin.

SIGNAL GENERATOR

2.09 To remove the signal generator assembly, remove the typing unit, if it is present, the TP154131 contact box cover, and disconnect the signal line leads from the TP154042, TP154043 contact terminals.

(a) Remove the two screws at the front of the TP154200 signal generator frame and screw at the right rear of the frame.

(b) Lift the signal generator carefully, while holding the TP154179 universal bail back so that the TP154237 nonrepeat lever clears and its spring will not be excessively stretched.

CAUTION: IF THE NONREPEAT LEVER IS PULLED DOWN APPROXIMATELY 90 DEGREES FROM THE NORMAL POSITION, ITS SPRING MIGHT BE STRETCHED BEYOND ELASTIC LIMITS WHICH WILL RESULT IN ASSEMBLY MALFUNCTION. MAKE SURE THE LEVER IS IN ITS SLOT BEFORE SETTING IT DOWN.

KEYBOARD HOOD

2.10 To remove the plastic windows and labels, hood, seals and seal plates, remove the four screws which secure the TP154198 windows and labels.

- (a) Remove the two screws underneath the TP154110 hood which hold the hood to the TP154203 hood mounting bracket; and remove the four screws on top of the hood which hold it to the TP154210, TP154211 left and right frame mounting brackets. Pull the hood forward to remove.
- (b) Stretch the TP154020 rubber keyboard seal off its TP154057, TP154058 plates.
- (c) Remove four screws and two TP154203 hood mounting brackets.
- (d) Remove the TP154058 upper seal plate by removing the three screws at its rear.
- (e) Remove the TP154057 lower seal plate by removing the screws at its front.

CONTACT BOX

2.11 To remove the contact box assembly, remove the TP154131 contact box cover and disconnect the signal line leads.

- (a) Unhook the TP86304 drive link spring.
- (b) Remove the two screws at the front of the TP154009 front plate which hold the contact box assembly.
- (c) Disengage the TP156644 drive link from the transfer bail and lift off the assembly. It is more economical to replace the entire contact assembly if the contacts need replacement.

KEYBOARD

2.12 Remove the typing unit, signal generator assembly and keyboard hood assembly.

Note: It is easier to disassemble and reassemble the keyboard assembly with the base standing on its rear.

- (a) Remove the four screws which hold the TP154210, TP154211 front frames to the front of the TP158000 base.
- (b) Remove the two screws which hold the TP154068, TP154069 right and left code-lever guide brackets at the top of the base, and the two screws at the extreme right and left of the TP154055 front bracket which hold it on the base.
- (c) When these four screws in front and four on top of the base have been removed, tip up the front of the keyboard assembly and pull it forward, disengaging the function levers.
- (d) Note that all function levers are under their corresponding function bails — except the keyboard lock function lever which fits on top of its function bail.
- (e) When reassembling, depress the keyboard lock keylever so that the lock function lever will go in over its bail instead of under as the other function levers should.

TRANSFER LEVER LOCKING BAIL

2.13 Remove the signal generator assembly from the keyboard (see 2.09).

- (a) Remove the contact assembly (see 2.11).
- (b) Remove the TP70388 transfer lever locking bail spring.
- (c) To remove the TP151140 locking bail, trip the clutch and rotate the shaft until the cam is positioned so that the bail can be unhooked and dropped from its guide post. Turn the locking bail clockwise until it is at right angles to the guide, and extract it from the bottom of the frame.

Note: It may be necessary to move the shaft back and forth to position the cam for maximum clearance.

SIGNAL GENERATOR SHAFT

2.14 Remove the transfer lever locking bail (see 2.13).

- (a) Remove the two screws which mount the TP154101 clutch shaft rear mounting plate to the TP154200 signal generator frame, and remove the nut which locks the shaft to the front of the frame.
- (b) Hold the TP154033 clutch latchlever and the TP154034 clutch stop lever away and pull back on the shaft rear mounting plate to disengage the shaft from the front plate.
- (c) Remove the entire cam, clutch, and shaft assembly by rotating it to clear the various transfer levers. The TP154019 code bar bail eccentric follower, the TP154138 felt washer and the TP154083 cam spacer will fall free. These must be repositioned before reassembly.
- (d) To take the cam (with clutch assembly) off the shaft, disengage the clutch by holding the clutch shoe lever against the stop lug and slide the cam and clutch off.

KEYLEVER GUIDE PLATE

- 2.15 Remove the keyboard hood assembly (see 2.10).
 - (a) Remove the TP151045 space bar by unscrewing the two shoulder screws that fasten it to the TP154117 space bar bail.
 - (b) Remove the screw on the keylever guide plate under the space bar and the two screws in the upper corners of the plate which hold the plate to the frame.
 - (c) Work the guide plate off the keytops and let them fall free.
 - (d) To replace the guide plate over the keylevers, flop all levers to the rear. Place the front end of the guide plate down on the frame; push the keylevers into their respective holes starting with the bottom row and proceeding upward to the top row.

1. The first paragraph of the report states that the data were obtained from a random sample of 1000 households in the city of New York. The sample was selected by means of a stratified random sampling procedure. The strata were defined on the basis of the number of persons in the household and the race of the head of the household. The results of the sampling are given in Table 1. The table shows that the sample is representative of the population with respect to the number of persons in the household and the race of the head of the household. The mean number of persons in the household is 3.2, and the mean race of the head of the household is 0.5 (white).

2. The second paragraph of the report states that the data were analyzed by means of a two-way analysis of variance. The two factors are the number of persons in the household and the race of the head of the household. The results of the analysis are given in Table 2. The table shows that there is a significant difference in the mean number of persons in the household between the two races of the head of the household. The mean number of persons in the household is 3.5 for white heads of households and 2.9 for non-white heads of households. This difference is significant at the 5% level of significance.

28 TYPING UNIT
 DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE	1. GENERAL
1. GENERAL	1	1.01 This section is issued to describe the disassembly and reassembly procedures for the 28 typing unit. Disassembly covers a procedure for removing the principal sub-assemblies which make up the unit.
2. DISASSEMBLY AND REASSEMBLY . .	2	
TYPE BOX	2	1.02 Reference should be made to the exploded views found in the appropriate parts literature for an illustration of the mechanism to be disassembled, for location and visual identification of parts, and detailed disassembly and reassembly features.
PRINTING CARRIAGE	2	
TYPE BOX CARRIAGE	2	1.03 Disassembly should be confined to sub-assemblies, which can, in some cases, be removed without disturbing adjustments. When reassembling the sub-assemblies, be sure to check all associated adjustments, clearances, and spring tensions.
FRONT PLATE	2	
STUNT BOX	3	1.04 If a part that is mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same shim pile-up can be replaced when the part is remounted.
STUNT BOX SWITCH	3	
FUNCTION BAR	4	1.05 Retaining rings are made of spring steel and have a tendency to release suddenly when attempting to remove them. Loss of these retainers can be minimized as follows: Hold the retainer with the left hand to prevent it from rotating. Place the blade of a suitable screwdriver in one of the slots of the retainer. Rotate the screwdriver in a direction to increase the diameter of the retainer for removal.
FUNCTION PAWL	4	
FUNCTION LEVER	4	1.06 Avoid loss of springs in disassembly by holding one spring loop with the left hand while gently removing the opposite loop with a spring hook. Do not stretch or distort springs when removing them.
FUNCTION LEVER SPRING PLATE	4	1.07 With cabinet lid raised or enclosure cover removed, loosen and remove the four screws that secure the typing unit to its base. Disconnect the cable plug connector from the side frame. Lift the typing unit off.
CODE BARS	4	
MAIN SHAFT	5	
UPPER DRAW WIRE ROPE	5	
LOWER DRAW WIRE ROPE	6	
PLATEN (FRICTION FEED)	6	
PLATEN (SPROCKET FEED)	6	
SELECTOR CAM-CLUTCH	7	
SELECTOR MECHANISM	7	
CODE BAR POSITIONING MECHANISM	7	
RANGE FINDER ASSEMBLY	7	
SELECTOR MAGNET ASSEMBLY	7	

SECTION 573-115-702

2. DISASSEMBLY AND REASSEMBLY

2.01 When removing a sub-assembly from the unit, the procedure followed and the location from which parts are removed must be carefully noted so that reassembly can be done correctly. Where no specific instructions are given for reassembly, reverse the procedure used in removing it.

TYPE BOX

2.02 To Remove: Trip the type box latch to the right. Lift the right end of the type box upward to an angle of approximately 45 degrees and pull toward the right to disengage it from the left hand bearing stud.

2.03 To disassemble the type box for replacing type pallet or spring, proceed as follows:

- (a) Remove both screws and nuts that secure the front plate to the rear plate assembly. Separate the two plates.
- (b) Remove the spring from the pallet by compressing it slightly and pulling the formed end out of the slot in the pallet.

Note: This spring should be discarded once it has been removed from its assembly.

- (c) When installing the new spring, make certain that the formed end extends through the slot in the pallet.
- (d) To reassemble the type box, line up the front plate with the rear plate assembly and draw the two plates together until the head of the pallet leaves the rear plate by approximately 1/16 inch. This may be accomplished by using two 6-40 screws (at least 11/32 inch long) and nuts in place of the two screws and nuts removed when disassembling, and tighten them only enough to hold the pallets as specified above. Do not clamp the plates together until all pallets have been moved into their correct position.
- (e) Manipulate the pallets until they fall into their respective openings in the front plate. Press the plates together.
- (f) Replace the screws and nuts used in step (d) with screws and nuts removed in step (a).

2.04 To Replace Type Box: Reverse the procedure used in removing it.

CAUTION: TO AVOID SPRINGING THE TYPE BOX LATCH, THE TYPE BOX SHOULD BE FIRMLY SEATED ON THE BEARING STUD AND THE POINT OF THE LATCH SHOULD BE PLACED IN THE NOTCH OF THE TYPE BOX PLATE BEFORE MOVING THE LATCH TO ITS LOCKED POSITION.

PRINTING CARRIAGE

2.05 To Remove: Loosen the two screws in the printing carriage clamp plate and disengage the carriage from the upper draw-wire rope. Move the carriage to the left of its track and tilt the power part forward to disengage the rollers from the track.

2.06 To Replace: Make certain that the printing arm is correctly re-engaged with the printing track. Position the carriage clamp on the upper draw-wire rope for the correct printing carriage position as specified in the adjustment section.

TYPE BOX CARRIAGE

2.07 To Remove: Move the type box carriage to its extreme right hand position.

- (a) Select any character in the bottom row of the type box and rotate the main shaft until the type box carriage is in the uppermost position.
- (b) Remove the ribbon from the ribbon guide.
- (c) Remove the retainer ring from the stud in the right hand end of the type box carriage link. Disengage the link from the carriage.
- (d) Hold the ribbon guide forward and the right ribbon reverse lever back. Pull the carriage toward the right to disengage it from the carriage track.

FRONT PLATE

2.08 To Remove: Manually move the type box carriage to the extreme right. Select any character in the bottom row of the type box and rotate the main shaft until the type box carriage is in its uppermost position.

- (a) Remove the retainer ring from the type box carriage link right hand stud and disengage the link from the carriage. (See instructions for removing the link retainer in 2.07(c).)
- (b) Remove the three screws which secure the main bail drive bracket to the rocker shaft.
- (c) Remove the spacing shaft gear.
- (d) Remove the four screws which secure the front plate assembly to the typing unit side frames.
- (e) Pull the front plate assembly forward to disengage it from its connecting parts in the typing unit.

2.09 To Replace Front Plate: Make certain that the TP150770 and TP150771 code bar bell cranks, the TP152596 letters-figures shift slide, the TP152522 reversing slide shift lever, the TP150438 automatic CR-LF bell crank, if so equipped, and the TP152545 carriage return lever extension are properly engaged with their mating parts before tightening the front plate mounting screws.

2.10 Replace the spacing shaft gear. See Section 573-115-700 for adjustment on phasing the spacing gears.

STUNT BOX

2.11 To Remove: The procedure for removing the stunt box is as follows:

- (a) Remove the TP151627 rear tie bar from the typing unit side frames.
- (b) Remove the line feed function pawl stripper from the stripper blade.
- (c) Remove the single-double line feed lever screw and disengage the lever from the notch in the stripper blade.
- (d) The stripper blade is either removed or disengaged from the typing unit, depending upon the design.
 - (1) For earlier design: Hold the stripper blade toward the right side of the typing unit and unhook the stripper blade left hand arm from the blade. Pull the stripper blade toward the left side of the typing unit to disengage the stripper blade from

the right hand arm. Remove the stripper blade from the typing unit.

- (2) For later design: Loosen the screw and remove the retaining ring from the TP153291 camshaft drive arm. Slide the drive arm out of engagement with the stripper blade drive arm.
- (e) Remove the screws which secure the stunt box assembly in the typing unit.
- (f) Lift the stunt box assembly upward to disengage it from its locating brackets and pull toward the rear to disengage all code bar forks from the code bars. Remove, if present, the contact assembly and cable clamp from the stunt box. Remove the stunt box.

Note: Proceed with 2.12 through 2.16 before replacing stunt box.

STUNT BOX SWITCH

2.12 To replace the contact arm in a stunt box switch, remove the two screws that hold the contact plate to the block.

- (a) Carefully unsolder the wire from the TP157889 contact arm spring. (It is not necessary to unsolder the contact arm spring wire from switches having the TP172591 contact spring.)
- (b) Remove the contact plate assembly from the contact block.
- (c) Remove the contact arm(s) from the contact plate assembly.
 - (1) For earlier design: Slip the TP157889 contact arm spring from the contact plate.
 - (2) For later design: Slip the TP172591 contact arm spring out of engagement with the center lug of the section being replaced.
- (d) Place the new spring in position on the contact plate.
- (e) Before mounting the contact plate on the block, make sure the end of the spring rests on top of the formed-over portion of the contact clip. There should be some clearance between the low end of the spring (front) and the upper edge of the contact arm to avoid in-

SECTION 573-115-702

terference with the normal movement of the contact arm.

(f) Replace the contact plate assembly, with the contact arms removed, into the contact block. Mount the contact block in the required location with the two screws friction tight.

(g) Carefully resolder any leads that may have been removed, being careful to avoid overheating.

(h) Insert the pointed end of the contact arm, notch downward, between the bent up end of the spring and the formed-over portion of the contact clip. Push the arm into its operating position in the contact block.

(i) Before tightening the contact plate screws, see Section 573-115-700 for adjusting information.

FUNCTION BAR

2.13 To remove a function bar, first unhook the function bar spring.

(a) Hold the function bar toward the rear of the stunt box and disengage its function pawl from the function bar.

(b) Pull the function bar toward the front to remove it from the stunt box.

FUNCTION PAWL

2.14 To remove a function pawl after the function bar has been removed:

(a) Remove the pawl spring.

(b) Hold associated function lever back.

(c) Remove the pawl from top of stunt box.

FUNCTION LEVER

2.15 To remove a function lever after the function bar and function pawl have been removed:

(a) Remove the TP152889 shaft retainer plate.

(b) Remove the TP150547 shaft nearest the front of the stunt box.

(c) Unhook the spring from the function lever and remove the lever through the top of the stunt box.

FUNCTION LEVER SPRING PLATE

2.16 To remove a function lever spring plate or latch after the function bar, function pawl, and function lever have been removed:

(a) Loosen the screws that fasten the three TP150689 guide blocks to the lower side of the guide bar.

(b) Remove the spring from the TP152660 spring plate or TP154613 latch.

(c) Pull downward on the function lever spring plate or latch to snap it out of engagement with the retainer shaft.

2.17 To replace the stunt box, push it forward in its guide rails to within 1/8 inch of its final position.

2.18 Manually disengage the function pawls from their function bars and push the stunt box assembly forward and downward until it is latched in place on its locating brackets.

2.19 Replace the stunt box mounting screws, receptacle, and selector magnet wires.

CODE BARS

2.20 To unblock the suppression code bar, loosen the TP151152 screw that mounts the TP154650 code bar clip and the retaining plate to the left hand code bar guide bracket, and rotate the code bar clip up out of engagement with the suppression code bar. Tighten the TP151152 screw.

2.21 To Remove the Code Bar Assembly: First, remove the stunt box assembly and the front plate assembly as previously described.

(a) Remove the screws and lock washers which secure the code bar assembly to the side frame.

(b) Remove the TP150301 code bar shift bar retainer plate from the right hand code bar guide bracket.

(c) Unblock the suppression code bar as instructed in 2.20. Remove the TP152548 and TP152255 code bar shift bars and springs

from the code bars and pull the code bar assembly forward and to the left.

2.22 To Reinstall Code Bar Assembly: Reverse the procedure used in removing it, except do not tighten the mounting screws.

(a) Hook the short extension of the TP152257 spring in the spring hole of the code bar. The short extension of the spring should be hooked from the bottom of the code bar, and the long extension should be hooked over the top of the code bar shift bar.

(b) Loosen the TP151630 code bar assembly tie bar screws and hold the code bar guide brackets back and downward firmly against their locating surfaces on the side frame and tighten the four mounting screws.

(c) Tighten the two tie bar screws.

MAIN SHAFT

2.23 To Remove Main Shaft: The selector cam-clutch assembly must be removed. See 2.35.

- (a) Set the typing unit upside down.
- (b) Return the carriage to its left hand position.
- (c) Remove the screw that secures the spacing shaft in the spacing collar.
- (d) Remove the spacing shaft with gear.
- (e) Remove the screw that secures the collar and the clamp to the right end of the main shaft.
- (f) Remove the TP152573 main shaft right hand bearing retainer plate.
- (g) Remove the TP150010 retainer plate at the TP150046 clutch bearing and remove the TP150244 link.
- (h) Remove the two screws from the TP152537 main shaft left hand bearing clamp.
- (i) Unhook the springs from the trip levers and latch levers associated with all clutches. Position the code bar clutch so that the low part of the clutch cam clears the spring arm on the cam follower. Unhook the code bar clutch cam follower spring.

(j) Remove the TP153300 function clutch arm by removing two screws and retainer ring if present.

(k) Unhook the spring from the TP153573 function bar reset bail.

(l) Move the main shaft assembly toward the left to disengage the code bar clutch and function clutch links from their connecting pins.

(m) Lift the left end of the shaft assembly out of the side frame. Position the shaft so that the function clutch link passes the suppression assembly bracket, then remove the shaft assembly from the typing unit.

Note: Disassembly of the main shaft and clutch assemblies can be accomplished by referring to the exploded views contained in the appropriate parts literature. It should be noted, that when assembling clutches having cams and discs marked "O" for identification, the marked side of the parts should face away from the clutch side of the assembly. Function and code bar clutches should have their driving links assembled so that the longer end of the hub faces away from the clutch side of the assembly.

2.24 To Reinstall Shaft Assembly: Reverse the procedure used in removing it. The line feed clutch spur gear should be positioned with its flat side toward the line feed clutch spacer and with the indentation in the gear toward the special washer between the gear and the main shaft ball bearing.

2.25 To phase the spacing gears, and remake the stripper blade drive cam position adjustment, refer to Section 573-115-700.

UPPER DRAW WIRE ROPE

2.26 To Remove Upper Draw Wire Rope: Return the carriage to the left hand position.

- (a) Loosen the nut on the front end of the spring drum stud. Operate the ratchet escapement lever to unwind the carriage return spring.
- (b) Remove the upper draw wire rope from the clamp plate on the printing carriage, and the clamp on the oscillator rail slide.

SECTION 573-115-702

(c) Loosen the clamp screw that secures the upper draw wire rope to the spring drum. Remove the wire rope from the drum.

(d) Remove the screw in the spacing drum that secures the ends of the wire rope. Remove the rope from the drum.

LOWER DRAW WIRE ROPE

2.27 To Remove Lower Draw Wire Rope: Remove the screw that secures the wire rope to the spacing drum. Remove the end of the rope from the drum.

(a) After loosening the screws that secure the TP150796 margin indicator cam disc on the spring drum, position the disc to expose the lower draw wire rope mounting screw.

(b) Remove the lower draw wire rope screw and rope from the spring drum.

(c) Loosen the screws in the pulley bearing studs that mount draw wire rope pulleys and move the studs toward the center of the typing unit.

2.28 To Replace Draw Wire Rope: Make certain that the lower draw wire rope is in front of the upper draw wire rope in the track around the drums.

2.29 Adjust the position of the type box, the printing carriage, and the wire rope tension as specified in Section 573-115-700.

PLATEN (FRICTION FEED)

2.30 To Remove Platen: Remove the line feed spur gear.

(a) Remove the TP150719 and TP150720 platen bearing retainers.

(b) Remove the TP152832 paper straightener shaft.

(c) Hold off the detent and lift the platen out of the side frame.

2.31 When replacing each platen bearing retainer, put its upper screw in first. Leave the screw slightly loose. Press the lower end of the retainer downward and hook it into the elongated hole in the side frame. Replace the lower screw. Tighten both screws.

PLATEN (SPROCKET FEED)

2.32 To Remove Platen: Remove the paper fingers or guide bracket assembly.

(a) Remove the spur gear from the left end.

(b) Remove the TP150719 and TP150720 platen bearing retainers.

(c) Hold off the detent bail and remove the platen.

(d) Remove the sprocket hub assembly from the platen assembly.

(e) Insert the TP153673 shaft tool into the hub and fasten it with the TP151346 screw.

(f) Remove the TP157286 clamp and TP153699 cam from the assembly.

(g) Insert the hub into the TP153797 retaining tool.

Note: These tools must be used when disassembling the TP153700 platen hub in order to hold the spring loaded pins in place when the feed cam is replaced.

2.33 To Replace a Pin: Rotate the hub assembly within the retaining tool, with a tommy wrench inserted in the shaft tool, until the desired pin is opposite the notch in the retaining tool. A pin may then be removed or replaced. Grease pin cylinder liberally before inserting new pin.

CAUTION: WHILE ROTATING THE HUB, THE NOTCH MUST BE COVERED TO PREVENT THE PINS FROM BEING RELEASED. SINCE THE PINS ARE SPRING LOADED, THEY CAN EJECT WITH CONSIDERABLE FORCE.

2.34 To Replace Platen: Reverse the procedure used in removing it. When replacing the TP153686 right sleeve bearing, the chamfer side or side marked "O" must face the end of the shaft and the wide part placed toward the front of the unit. When replacing each platen bearing retainer, put its upper screw in first. Leave the screw slightly loose. Press the lower end of the retainer downward, and hook it into the elongated hole in the side frame. Replace the lower screw. Tighten both screws.

SELECTOR CAM-CLUTCH

2.35 To Remove Selector-Cam Clutch: Facing the right end of the typing unit, lift the TP152410 push lever reset bail from its cam, and move the push lever reset bail to the rear, latching it in the raised position on the push lever guide. Push the marking lock lever (and the blocked selector levers) to the left until the selector magnet armature latches the marking lock lever.

- (a) Remove the screw which secures the selector clutch drum to the main shaft. Position the clutch cam disc so that the stop lug is in the uppermost position.
- (b) Hold the start lever and spacing lock lever away from the selector cam-clutch assembly; grasp the selector cam-clutch by the clutch cam disc (not by the drum) and pull forward by rotating the cam-clutch slowly.

CAUTION: THE CAM-CLUTCH SHOULD COME OFF THE MAIN SHAFT EASILY. DO NOT FORCE IT.

2.36 To Replace Cam-Clutch Assembly: Reverse the procedure used in removing it except as the cam-clutch approaches its fully installed position, move the trip shaft lever and the clutch latch lever so that they ride on their respective cams. Restore the push lever reset bail and the armature to their operating positions.

SELECTOR MECHANISM

2.37 To Remove Selector Mechanism: The cam-clutch assembly must first be removed from the main shaft. See 2.35.

- (a) Remove the TP151658 screw that secures the selector mechanism to the TP152546 intermediate bracket on the code bar positioning mechanism.
- (b) Remove from the selector mechanism the spring which connects with the common transfer lever on the code bar positioning mechanism.
- (c) Remove the remaining three selector mounting screws and lift the selector from the main shaft bearing housing.

CODE BAR POSITIONING MECHANISM

2.38 To Remove Code Bar Positioning Mechanism: Unhook from the selector the spring attached to the common transfer lever and restore any operating push levers to the spacing position by raising the TP152410 push lever reset bail.

- (a) Loosen the clamp screw on the TP150447 shift lever drive arm, and remove the two screws which mount the mechanism -- one to the side frame and one to the selector mounting plate.
- (b) Manipulate the transfer levers and TP152548 or TP152255 code bar shift bars while gently twisting the mechanism off the code bar shift bars.

2.39 To Replace Code Bar Positioning Mechanism on the typing unit: Rotate the main shaft to the stop position; push the code bar shift bars to the marking position. Manipulate the code bar shift bars and transfer levers so that the shift bars line up with their respective slots in the TP150525 bracket, and slide the shift bars through the slots, one at a time, leaving the bottom slot vacant.

RANGE FINDER ASSEMBLY

2.40 To Remove Range Finder Assembly: Remove the two screws and the nut that secure the range finder plate to the selector mounting plate. Move the TP152438 stop arm bail forward so that it disengages from the TP161342 start lever and clears the selector clutch disc, while rocking the range finder assembly back and forth as it is removed.

2.41 To Replace Range Finder Assembly: Reverse the disassembly procedure.

Note: For units equipped with the TP152897 bail lever guide, do not tighten the nut until the bail lever guide adjustment has been checked. See earlier design mechanisms in 573-115-700.

SELECTOR MAGNET ASSEMBLY

2.42 To Remove Selector Magnet Assembly: Remove the two screws and nut which mount the range finder to the selector.

- (a) Remove the selector magnet cable from the coil terminal screws.
- (b) Remove the two magnet assembly mounting screws and lift the assembly out.



28 TYPING AND NONTYPING PERFORATORS

DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY . .	3
MAIN SHAFT ASSEMBLY	4
MANUAL BACKSPACE MECHANISM .	5
POWER DRIVE BACKSPACE MECHANISM	5
PUNCH AND MAGNET ASSEMBLIES AND BACKSPACE MECHANISM	3
RIBBON FEED MECHANISM (TYPING PERFORATOR ONLY)	3
ROCKER BAIL ASSEMBLY	4
TRANSFER MECHANISM (TYPING PERFORATOR ONLY)	3
TYPING MECHANISM (TYPING PERFORATOR ONLY)	3

1. GENERAL

1.01 Disassembly as outlined in this section covers a procedure for removing the principal subassemblies which make up the unit.

1.02 The technician should refer to the exploded views found in the appropriate parts literature for an illustration of the mechanism to be disassembled, for location and visual identification of parts and detailed disassembly and reassembly features.

1.03 Most maintenance, lubrication and adjustments can be accomplished simply by removing the subject component from the cabinet. If possible, disassembly should be confined to subassemblies, which can, in some cases, be removed without disturbing adjust-

ments. When reassembling the subassemblies, be sure to check all associated adjustments, clearances and spring tensions.

1.04 If a part that is mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same shim pile-up can be replaced when the part is remounted.

1.05 Retaining rings are made of spring steel and have a tendency to release suddenly when being removed. Loss of these retainers can be minimized as follows: Hold the retainer with the left hand to prevent it from rotating. Place the blade of a suitable screwdriver in one of the slots of the retainer. Rotate the screwdriver in a direction to increase the diameter of the retainer for removal.

1.06 Avoid loss of springs in disassembly by holding one spring loop with the left hand while gently removing the opposite loop with a spring hook. Do not stretch or distort springs in removing them.

1.07 Raise cabinet lid or enclosure cover and remove the typing unit from its base by removing the four screws that secure it to its keyboard or base. Remove the cable plug connector from the side frame. Lift the typing unit off.

Note: On sets equipped with a form supply container on the rear of the cabinet, rearward foot extensions should be in position on the cabinet. This prevents the cabinet from tilting when the typing unit is removed.

1.08 Assuming that the typing unit and keyboard base have been removed from the cabinet, remove the perforator from the base as follows:

(a) Loosen the set screws on the TP193565 coupling located on the rear of the shaft. slide the coupling and/or short shaft so as to disengage it. Remove the screw which fas-




Figure 1 - 28 Non-Typing Perforator - Chadless Tape (With Code Reading Contacts, Timing Contacts and Backspace Mechanism)




Figure 2 - 28 Typing Perforator - Chadless Tape (With Backspace Mechanism)

tens the TP156184 anchor bracket to the base. Remove the three screws which secure the reperforator to the base. Carefully lift the reperforator upward and tilt to one side.

- (b) Disconnect the wires from the backspace magnet, and remove the unit from the base.

2. DISASSEMBLY AND REASSEMBLY

2.01 In removing a subassembly from the unit, the procedure followed and the location from which parts are removed must be carefully noted so that reassembly can be done correctly. Where no specific instructions are given for reassembly, reverse the procedure used in removing it.

PUNCH AND MAGNET ASSEMBLIES AND BACKSPACE MECHANISM

2.02 To remove the punch and magnet assemblies and backspace mechanism unhook the TP90573 perforator drive link spring and disengage the TP192709 link. Remove three mounting screws that fasten the TP156024 rear plate to the TP159472 main plate.

- (a) Remove the three screws which hold the TP159472 perforator main plate to either the TP158169, TP159861 nontyping or typing perforator frame, and one screw that anchors unit to base.
- (b) Disengage the TP159961 eccentric arm and the assemblies will come free as a unit.

RIBBON FEED MECHANISM (TYPING PERFORATOR ONLY)

2.03 Remove the ribbon and then remove the two mounting screws that hold the ribbon mechanism.

TRANSFER MECHANISM (TYPING PERFORATOR ONLY)

2.04 Remove the TP150241 main trip lever spring and two mounting screws.

TYPING MECHANISM (TYPING PERFORATOR ONLY)

2.05 Remove the TP156872 operating blade from the rocker bail assembly by removing the two mounting screws, lockwashers, washers and shims that hold the mechanism.

Disconnect the TP159512 printing trip link by removing the retaining ring that secures it to the hammer accelerator. Remove the nut, lock-washer, washer and TP156936 eccentric on the rocker bail assembly and disconnect the TP159526 oscillating drive link. Remove the TP95378 spring from the TP156478 accelerator and the TP90606 spring from the TP156252 lifter.

2.06 Remove the screw and washer that fasten the TP159434 lifter plate to the TP162862 bar on the frame. Remove the screw and lock-washer that secure the TP159525 axial bracket to the TP159404 post on the frame. Remove the screw, lockwasher and flat washer that fasten the TP159487 function box front plate to the TP159472 main plate. Remove the TP119653 retaining ring from the TP159659 eccentric shaft; and remove the TP151629 nut, TP159536 idler gear, TP159659 shaft and lockwasher by removing the TP159658 mounting screw. Remove the three screws, lockwashers and flat washers that secure the TP159535 front plate to the frame. Remove the typing mechanism from the frame assembly. To remount the typing mechanism, reverse the procedure used to remove it.

2.07 To remove function box mechanism, remove the mounting screw, lockwasher and flat washer from the TP159535 front plate. Remove the function box from the typing mechanism.

2.08 To remove the axial plate assembly, remove the TP3870 correcting drive link spring. Remove the TP156413 correcting drive link by removing the TP119651 retaining ring. Remove the TP119649 retaining ring and disconnect the TP156869 ribbon guide from the TP156870 ribbon oscillating lever.

- (a) Remove the three mounting screws and lockwashers from the axial plate assembly. Remove the axial plate assembly.

- (b) To remount the axial plate assembly reverse the procedure used to remove it. The rearmost tooth of the rack on the TP156332 typewheel shaft must mesh with the rearmost tooth space in the TP156294 axial sector, and the forward tooth on the sector must mesh with the second tooth space on the shaft; there is an extra tooth space on the forward portion of the shaft's rack.

2.09 After the function box mechanism and axial plate assembly have been removed, the remainder of the typing mechanism is the front plate assembly.

2.10 After the typing mechanism has been removed, the following remain on the frame assembly: The function clutch trip assembly, the two shaft assemblies and the rocker bail assembly (typing perforator only).

2.11 To remove pushbars after removing the typing mechanism, remove the function box mechanism from the typing mechanism. Remove the pushbar by disengaging the pushbar rack from its associated pinion.

2.12 The correct gear tooth engagement of racks for pushbars 1 through 5 is as follows: In assembling the pushbars to the various eccentric assemblies, great care must be exercised to assure the correct rack-pinion gear mesh. The correct mesh is such that the first tooth on the pinion and the first tooth space on the rack are meshed. On later units this is identified by a mark on the pushbar and a mark on the eccentric. The last tooth on the pinion and the last tooth space on the rack should therefore also mesh.

CAUTION: MISALIGNMENT OF THE MESH BY AS LITTLE AS ONE TOOTH WILL PRODUCE A JAM IN THE MACHINE AND CAUSE PART BREAKAGE IF THE MACHINE IS PUT UNDER POWER WHILE THIS CONDITION EXISTS.

2.13 The assembly of the "Letters" and "Figures" pushbars to the left eccentric assembly must follow the assembly of the detents on the same eccentric. Starting with the left eccentric in the lower detented position, locate the gear tooth of the pinion which is at top dead center. (Using the oil hole in the eccentric housing as a reference may help since it is located at top dead center.) The first tooth space of the rack of the "Letters" pushbar must engage the tooth located directly below. This requirement is met when the indicating mark on the pushbar and eccentric shaft are in the line. Pull the "Letters" pushbar all the way on the pinion. The eccentric shaft should now be in the upper detent position. Now locate the tooth at bottom dead center. The first tooth space of the "Figures" pushbar should engage the tooth just

located. The full travel of either pushbar should result in the eccentric shaft being rotated from one detented position to the other without jamming. As before, a misalignment of the mesh by one tooth will cause a jam and parts breakage if the machine is put under power while this condition exists.

ROCKER BAIL ASSEMBLY

2.14 Disconnect the TP156937 printing drive link by removing the retaining ring at its left end. Remove the nut, lockwasher, flat washer, felt washer, bushing and screw from the TP156871 operating blade mounting bail.

2.15 Remove the nut, lockwasher and remove the TP156366 rocker bail shaft. Remove the rocker bail.

MAIN SHAFT ASSEMBLY

2.16 Remove the spring from the TP158172 function clutch latchlever. Remove the retaining ring, spring washer and flat washers from the forward end of the TP154397 main shaft.

2.17 Remove the screw and lockwasher from the TP158184 function clutch drum. Remove the screw and lockwasher from the TP173340 collar. Remove the screw and lockwasher from the TP158745 bearing clamp.

2.18 Pull main shaft out of rear of unit, removing the cam-clutch and collar.

CAUTION: NOTE THE LOCATION OF THE MAIN SHAFT NEEDLE ROLLER BEARINGS AS SHOWN ON ILLUSTRATIONS OF PARTS IN APPROPRIATE SECTION. MOVE THE MAIN SHAFT TOWARD THE REAR OF THE UNIT A SMALL AMOUNT AT A TIME AND EXERCISE CARE NOT TO DROP OR CONTAMINATE THE 20 NEEDLE ROLLERS IN EACH RACE. A SMALL SPRING MAY BE STRETCHED AROUND THE SHAFT AND ROLLERS WITH THE ENDS OF THE SPRING HOOKED TOGETHER. THE GARTER SPRING IN CONJUNCTION WITH THE GREASE, WILL HOLD THE ROLLERS IN PLACE. WHEN REPLACING THE MAIN SHAFT, MAKE SURE THE ROLLERS ARE CLEAN. LUBRICATE THE RACE AND BEARINGS WITH TP88973 GREASE. APPLY A LIBERAL AMOUNT OF OIL AT EACH END OF THE BEARING SLEEVE.

Note: When the main shaft is inserted in the cam-clutch, hold the latter firmly so that the drum is not pushed off the clutch. Compress the drum and cam disc together so that holes in the drum and clutch bearings are aligned.

POWER DRIVE BACKSPACE MECHANISM

2.19 To remove the power drive backspace mechanism, unhook the TP84575 spring from the TP159958 drive link latch.

- (a) Loosen the screw on the TP159960 eccentric and pull the TP159961 eccentric arm off the TP159963 hub.
- (b) Disengage the eccentric arm from its guide between the TP159958 latch and TP159955 drive link.

- (c) Unscrew the TP159956 post from between the TP159954 adjusting link and the front punch frame, and remove the link and latch assembly.

- (d) Remove the two screws on the front punch frame and extract the magnet assembly.

MANUAL BACKSPACE MECHANISM

2.20 To remove the manual backspace mechanism, unscrew the two screws which hold the TP159900 plate to the rear punch frame and remove the TP159902 rake shaft. Remove the two screws and TP159916 eccentric from the TP159987 bracket on the left side of the punch front plate. Remove the TP159903 crank assembly.



28 TYPING REPERFORATOR AND TAPE PRINTER

DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY . .	1
Axial plate assembly	4
Function box assembly	4
Main shaft assembly	5
Perforator mechanism	4
Pushbars	5
Ribbon feed mechanism	4
Rocker bail assembly	4
Selector mechanism	1
Transfer mechanism	4
Typing mechanism	4

1. GENERAL

1.01 This section provides disassembly and reassembly for the 28 typing reperforator and tape printer units. It is revised to include recent engineering changes, additions, and to rearrange the text. Since this is an extensive revision, marginal arrows ordinarily used to indicate changes have been omitted.

1.02 Disassembly as outlined in this section covers a procedure for removing the principle subassemblies which make up the unit.

1.03 Refer to the exploded views found in the appropriate parts literature for illustrations of the mechanisms to be disassembled, for location and visual identification of parts and detailed disassembly and reassembly features.

1.04 Most maintenance, lubrication and adjustments can be accomplished simply by removing the unit from the base. If possible, disassembly should be confined to subassemblies, which can, in some cases, be removed without disturbing adjustments. When reassembling the subassemblies, be sure to check all associated adjustments, clearances and spring tensions.

1.05 If a part that is mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same shim pile-up can be replaced when the part is remounted.

1.06 Retaining rings are made of spring steel and have a tendency to release suddenly when being removed. Loss of these retainers can be minimized as follows: Hold the retainer with the left hand to prevent it from rotating. Place the blade of a suitable screwdriver in one of the slots of the retainer. Rotate the screwdriver in a direction to increase the diameter of the retainer for removal.

1.07 Avoid loss of springs in disassembly by holding one spring loop with the left hand while gently removing the opposite loop with a spring hook. Do not stretch or distort springs in removing them.

2. DISASSEMBLY AND REASSEMBLY

2.01 To remove the selector mechanism:

(a) Remove the screw, lockwasher, and nut from the TP150001 selector clutch drum. Place the TP152410 reset bail in its raised position. Holding the TP152432 stop arm and the TP152405 marking locklever to the left, grasp the cam-clutch by the cam disc (not by the drum) and pull forward rotating the cam-clutch slowly. The cam-clutch should come off easily.

CAUTION: DO NOT FORCE.

(b) Unhook the function clutch latchlever spring. Remove the TP156472 spring post by removing its nut and lockwasher. Remove the screw and lockwasher that pass through the TP156867 frame and the TP152400 selector mounting plate into the TP152402 selector lever guide. Remove the TP152457 oil wick, screw, lockwasher, and TP159467 wick holder. Remove the selecting mechanism.




Figure 1 - 28 Typing Reperforator Unit with Remote Control Blank Tape Feed-Out Mechanism (Fully Perforated Tape)




Figure 2 - 28 Tape Printer Unit With Manual Letters Tape Feed-Out Mechanism

SECTION 573-118-702

2.02 To remove ribbon feed mechanism:
Remove the ribbon, two mounting screws and lockwashers; remove the ribbon feed mechanism.

2.03 To remove perforator mechanism:

(a) Remove the TP90573 spring and disconnect the TP192709 perforator drive link from the TP156884 rocker arm.

(b) Remove the TP159621 shoulder screw with lockwasher from the TP159622 clamp. Remove the two mounting screws, lockwashers and flat washers, that fasten the TP156024 rear plate to the TP159472 main plate. Remove the perforator mechanism.

Note: When remounting the perforator mechanism, make certain that the TP156059 reset bail fits in the fork of the TP159430 reset bail trip lever and that the print hammer fits in its slot in the mechanism.

2.04 To remove transfer mechanism: Remove the TP49084 main trip lever spring. Remove the mounting screws, lockwashers and flat washers from the TP159488 transfer mounting bracket. Remove the transfer mechanism.

2.05 To remove the typing mechanism:

(a) Remove the TP156872 operating blade from the rocker bail assembly by removing the two mounting screws, lockwashers, flat washers and shims. Remove the retaining ring and disconnect the TP159512 printing trip link. Remove the nut, lockwasher and flat washer from the TP156396 eccentric on the TP156368 rocker bail and disconnect the TP159526 oscillating drive link. Remove the spring from the TP156478 accelerator and the spring from the TP156252 function blade lifter.

(b) Remove the screw with lockwasher that fastens the TP159434 lifter plate to the TP156474 mounting bar on the frame. Remove the screw and lockwasher that secure the TP159525 axial bracket to the TP159404 post on the frame. Remove the screw, lockwasher and flat washer that fasten the TP159487 function box front plate to the TP159472 main plate. Remove the retaining ring from the TP159659 idler gear eccentric shaft. Remove the eccentric shaft, the TP159536

idler gear, the TP151629 special nut and lockwasher by removing the TP159658 mounting screw. Remove the three screws, lockwashers and flat washers that secure the TP159535 front plate to the frame. Remove the typing mechanism from the frame assembly.

2.06 To remove the function box mechanism:
Remove the mounting screw, lockwasher, and flat washer, that pass through the TP156316 function box rear plate and the TP159483 spring bracket into the TP159535 front plate. Remove the function box from the typing mechanism.

2.07 To remove the axial plate assembly:

(a) Remove the TP3870 correcting drive link spring. Remove the TP156413 correcting drive link by removing the retaining ring from the TP156378 axial correcting plate. Remove the retaining ring and disconnect the TP156869 ribbon guide from the TP156870 ribbon oscillating lever. Remove the screw and lockwasher that fastens the TP159525 axial plate to the TP160943 typewheel shaft housing.

(b) Remove the three mounting screws and lockwashers from the TP159525 axial plate. Remove the axial plate assembly.

Note: To remount the axial plate assembly, reverse the procedure used to remove it. The last tooth on the typewheel shaft shall mesh with the last full (there may be a partial space at the rear of the sector, if so, disregard it) tooth space of the TP156294 gear sector. Also, the first tooth of the gear sector shall mesh with the second tooth space on the typewheel shaft. There is an extra tooth space on the forward portion of the typewheel shaft. The correct axial output rack sector engagement is when the last tooth on the TP156313 axial output rack and the last tooth space of the TP156294 gear sector shall mesh. Also, the first tooth of the axial output rack and the first tooth space on the gear sector shall mesh.

2.08 To remove the rocker bail assembly:

(a) Disconnect the TP156937 printing drive-link by removing the retaining ring at its left end. Remove the nut, lockwasher, flat washer, felt washer, bushing, and screw from the TP156871 operating blade mounting bail.

- (b) Remove the nut, lockwasher and the TP156921 adjusting lever guide, and remove the TP156366 rocker bail shaft. Remove the rocker bail.

2.09 To remove main shaft assembly:


- (a) Remove the spring from the TP150355 clutch latchlever. Remove the retaining ring, spring washer and flat washers from the forward end of the TP154397 main shaft.
- (b) Remove the screw and lockwasher (if present) from the TP150000 function clutch drum. Remove the screw and lockwasher from the TP173340 collar. Remove the screw and lockwasher from the TP158745 bearing clamp. Pull the main shaft out of rear of unit, removing the cam clutch and the collar.
- (c) Note the location of the main shaft TP154398 needle bearings as shown in the parts section. Move the main shaft toward the rear of the unit a small amount at a time and exercise care not to drop or contaminate the 20 needle bearings in each race. A rubber band, string, or spring may be stretched around the shaft and needle bearings with the ends of the spring hooked together. The spring in conjunction with the grease will hold the needle bearings in place.
- (d) To replace this type of main shaft assembly reverse the procedure used to remove it. Make sure the needle bearings are clean. Lubricate the race and bearings with TP195298 (Beacon 325) grease or its equivalent. Apply a liberal amount of KS7470 oil at each end of the bearing sleeve. When the main shaft is inserted into the cam clutch, hold the cam clutch firmly so that the drum is not pushed off the clutch, and compress the drum and cam disc together so that the holes in drum and clutch bearings are aligned.

2.10 To remove pushbars: Remove the typing mechanism. Remove the function box mechanism from the typing mechanism. Remove

the pushbar by disengaging the pushbar rack from its associated pinion.

2.11 The correct gear tooth engagement of racks on pushbars is as follows:

- (a) When assembling the pushbars (no. 1 to no. 5 inclusive) to the various eccentric assemblies, great care must be exercised to assure the correct rack-pinion gear mesh. The correct mesh is such that the first tooth space on the rack is meshed. On later units this is identified by a mark on the pushbar and a mark on the eccentric. The last tooth on the pinion and the last tooth space on the rack should therefore also mesh. Misalignment of the mesh by as little as one tooth will produce a jam in the machine and cause part breakage if the machine is put under power while this condition exists.
- (b) The assembly of the letters and figures pushbars to the left eccentric assembly must follow the assembly of the detents on the same eccentric. Starting with the left eccentric in the lower detented position, locate the gear tooth of the pinion which is at top dead center. (Using the oil hole in the eccentric housing as a reference may help since it also is located at top dead center.) The first tooth space of the rack of the letters pushbar must engage the tooth directly below. This requirement is met when the indicating mark on the pushbar and eccentric shaft are in line. Pull the letters pushbar all the way on the pinion. The eccentric shaft should now be in the upper detented position. Now locate the tooth at bottom dead center. The first tooth space of the rack on the figures pushbar should engage the tooth just located. The full travel of either pushbar should result in the eccentric shaft being rotated from one detented position to the other without jamming. As before, a misalignment of the mesh by one tooth will cause a jam and parts breakage if the machine is put under power while this condition exists.



28 TRANSMITTER DISTRIBUTOR UNIT (LXD)
DISASSEMBLY AND REASSEMBLY

CONTENTS	PAGE
1. GENERAL	1
2. DISASSEMBLY AND REASSEMBLY OF UNIT	1
COVERPLATE	1
TOP PLATE	3
TAPE GUIDEPLATE	3
OIL RESERVOIR	3
REAR PLATE ASSEMBLY	3
MAIN SHAFT ASSEMBLY	3
CENTER PLATE ASSEMBLY	3

1. GENERAL

1.01 This section provides instructions for disassembly and reassembly of the 5- and 6-level, single contact, 28 transmitter distributor unit (Figure 1). These instructions outline a procedure for removing from the unit components or subassemblies, ie, tape guideplate assembly, rear plate assembly, main shaft assembly, and center plate assembly.

1.02 Most maintenance, lubrication, and adjustments can be done by removing the transmitter distributor from its base. If possible disassembly should be confined to the components or subassemblies which can, in most cases, be removed without disturbing the adjustments. However, when reassembling the unit, check all associated adjustments, clearances, and spring tensions.

CAUTION: DISCONNECT EXTERNAL AC OR DC POWER SOURCE BEFORE WORKING ON TRANSMITTER DISTRIBUTOR UNIT.

1.03 To facilitate adjustments on earlier models, a generous length of cable is provided between the unit and its terminal block to allow rotation or inversion of the unit. The ac or dc potential must be disconnected from its power source. Later model units plug into position on their bases.

1.04 Exercise care when replacing the unit to keep the cable free of any moving parts. For a more detailed illustration of the units, refer to the appropriate 28 transmitter distributor parts section.

1.05 Retaining rings are of spring steel and have a tendency to release suddenly. The loss can be minimized by holding the ring with the left hand to prevent it from rotating. Place the blade of a suitable screwdriver in one of the slots of the ring. Rotate the screwdriver in a direction to increase the diameter of the ring. The retaining rings should come off easily without flying.

1.06 If a shim mounted part is removed, note the number of shims used at each mounting point so that the same shim pile-up can be replaced when the part is reassembled.

1.07 Avoid loss of springs in disassembly by holding one spring loop with the left hand while gently removing the opposite loop with a spring hook. Do not stretch or distort springs while removing them.

1.08 Remove three screws that secure the transmitter distributor unit to the base and lift unit free. On earlier models remove cable connections from the terminal board and cable clamps from the base.

2. DISASSEMBLY AND REASSEMBLY OF UNIT

COVERPLATE

2.01 To remove the coverplate assembly, lift the coverplate from its detented position.




Figure 1 - Typical Transmitter Distributor (Cover Plate Removed)





Figure 2 - Plate Assemblies

2.02 To replace the coverplate assembly, align the ends of the coverplate and top plate, slide the tips of the plate spring under the edge of the top plate, and snap the cover plate down into its detented position.

TOP PLATE

2.03 To remove top plate, loosen the front and rear mounting screws (Figure 2) and lift the plate upward.

2.04 To replace the top plate, guide the mounting screws into the notch of the front and rear plates. Align the sensing pins and feed wheel with their respective slots. Refer to TOP PLATE adjusting procedure if the plates do not align.

TAPE GUIDEPLATE

2.05 To remove the tape guideplate, loosen the front and rear mounting screws and slide the plate upward (Figure 2).

2.06 To replace the tape guideplate, guide the mounting screws into the respective notch of the front and rear plates while guiding the tape-out pin into its notch and locating the sensing pins against the left edge of the tape guideplate. Refer to TAPE GUIDEPLATE adjusting procedure.

OIL RESERVOIR

2.07 To remove the oil reservoir, remove the screws that secure the casting and lift the assembly upward and toward the right.

2.08 To replace the oil reservoir, reverse the procedure.

REAR PLATE ASSEMBLY

2.09 To remove the rear plate assembly:

- (a) Remove cable assembly leads from start-stop contact assembly and magnet assembly.
- (b) Remove hex nuts and lockwashers from bottom posts.

(c) Remove main shaft retaining ring.

(d) Remove screws TP151630 securing plate to post TP156622.

(e) Remove the two screws which secure the clutch trip magnet assembly bracket to the rear plate and remove clutch trip magnet assembly.

(f) Remove rear plate assembly from the remainder of the unit.

2.10 To replace the rear plate assembly, reverse the procedured steps.

MAIN SHAFT ASSEMBLY

2.11 To remove the main shaft assembly:

(a) Remove the clamp TP156831 and plate TP156832 from the front plate assembly.

(b) Remove the main shaft assembly.

2.12 To replace the main shaft assembly, replace in the reverse order.

CENTER PLATE ASSEMBLY

2.13 To remove the center plate:

(a) Remove the post TP156622.

(b) Remove the two nuts which secure the center plate to the two guide posts.

(c) Remove the spring TP7603.

(d) Remove the center plate assembly.

2.14 To replace the center plate assembly, reverse the procedured steps.

2.15 When reinstalling the transmitter or transmitter distributor unit on the base, adjust the gear backlash as outlined in the section, 28 Transmitter Distributor Unit (LXD) — Adjustments.

