

28E and 28H TRANSMITTER-DISTRIBUTOR UNIT
REQUIREMENTS AND ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	2	Main Bail Assembly	
2. REQUIREMENTS AND ADJUSTMENTS	3	Feed ratchet detent spring	15
A. Transmitter-Distributor Unit	3	Main bail	15
Clutch Mechanism		Main bail spring	15
Clutch shoe lever spring	4	Main Bail Trip Assembly	
Clutch shoe spring	4	Locking bail spring	18
Clutch Trip Magnet Assembly		Main bail trip lever	18
Armature bail spring	21	Signal Contact Assembly	
Clutch magnet	21	Signal contact	20
Main bail latch spring	21	Signal contact link spring	20
Clutch Trip Mechanism		Signal contact spring	20
Clutch latchlever spring	5	Signal Pulse Refinement	
Clutch shoe lever	5	Signal pulse (final adjustment)...	23
Clutch trip lever	5	Start-Stop Switch Assembly	
Clutch trip lever spring	5	Start-stop switch bracket	14
Code-sensing Fingers		Tight tape intermediate arm	14
Feed wheel detent	16	Tight tape intermediate arm	
Sensing finger spring	16	spring	14
Cover Assemblies		Tight tape and start-stop	
Instructions for removing cover		contact spring	14
plate	3	Tape Guide Plate	
Instructions for removing front		Tape guide	6
panel	3	Tape lid (for tape-lid assembly	
Instructions for removing tape		with tape-lid spring)	7
guide plate	3	Tape lid (for tape-lid assembly	
Instructions for removing top		without tape-lid spring)	6
plate	3	Tape Guide Plate Mounting	
Cover Plate		Instructions for replacing and	
Cover plate detent spring	22	positioning tape guide plate	10
Feed Pawl Mechanism		Tape-lid Assembly	
Feed pawl	17	(With Tape-lid Spring)	
Feed pawl spring	17	Start-stop detent bail spring	9
Transfer lever spring	17	Tape-lid release-plunger spring.	9
		Tape-lid spring	9

CONTENTS	PAGE	CONTENTS	PAGE
Tape-lid Assembly (Without Tape-lid Spring)		Spacing contact springs (preliminary).....	25
Start-stop detent bail spring	8	Swinger contact springs (preliminary).....	25
Tape-lid release-plunger spring	8	Code Reading Contacts	
Tape-out Contact Assembly		Auxiliary contact (final)	26
Tape-out contact assembly.....	12	Auxiliary contact (preliminary)..	26
Tape-out contact bracket	12	Contact sensing arm upstop.....	26
Tape-out sensing pin spring	12	Code Reading Contact Sensing Arm	
Tape-out Sensing Pin		Auxiliary contact operating bail spring.....	27
Depressor bail torsion spring ...	13	Sensing arm spring	27
Intermediate tape-out bail spring	13	Split bail eccentric	27
Tape-out sensing pin.....	13	Tabulator Control	28
Top-plate and Cover-plate Mounting		Transmitter-stop Mechanism	
Instructions for replacing and positioning cover plate	11	Start-stop contact gap.....	28
Instructions for replacing and positioning top plate	11	Timing bail spring.....	28
Transfer Bail Stabilizer		1. GENERAL	
Stabilizer spring	19	1.01 This section contains the requirements and adjusting procedures for the mainten- ance of the 28E and 28H transmitter-distributor units.	
Transfer bail stabilizer	19	1.02 This section is reissued to add adjustment information for modification kits which have been approved for use with these trans- mitter-distributor units and to bring all adjust- ment information up to date.	
B. Auxiliary Features	24	1.03 In this section, left or right, front or rear, and top or bottom apply to the apparatus in its normal operating position as viewed from the front.	
Modification Kit to Permit Use of 11/16-inch and 7/8-inch 5-level Tape Interchangeably	29	1.04 When the requirement calls for the clutch to be disengaged, the clutch-shoe lever must be fully latched between its triplerver and latchlever so that the clutch shoes release their tension on the clutch drum. When engaged, the clutch-shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum.	
Tape Guide		<u>Note:</u> When the main shaft is rotated by hand, the clutch does not fully disengage upon reaching its stop position. In order to relieve the drag on the clutch and permit the main shaft to rotate freely, apply pres- sure on a lug of the clutch disc with a screwdriver to cause it to engage its latch- lever and thus disengage the internal expansion clutch shoes from the clutch drum.	
Right and left guide adjustment.	29		
Modification Kit to Convert 28H to 28H-1 Transmitter-Distributor ...	30		
Tape-lid Sensing Lever			
Switch lever	30		
Tape-lid sensing lever spring..	30		
Multiple Wire Output Facilities	24		
Code Reading and Timing Contacts			
Marking contact backstops	24		
Marking contact springs (preliminary).....	24		
Spacing contact backstops (preliminary).....	25		

1.05 The covers may be removed for inspection and minor repair of the unit; however, when more extensive maintenance is to be undertaken, it is recommended that the unit be disconnected from its source of power as a safety precaution.

1.06 Requirements and adjustments for the timing mechanism required for the transmitter-distributor unit to operate in conjunction with horizontal or vertical tabulation of the typing unit are given in the section covering 28 typing unit requirements and adjustments.

2. REQUIREMENTS AND ADJUSTMENTS


2.01 The figures in this section show the adjusting tolerances, positions of moving parts, and spring tensions. The illustrations are arranged so that the adjustments are in the sequence that would be followed if a complete readjustment of the apparatus were being made. Where an illustration shows interrelated parts, the sequence that should be followed in checking the requirements and making the adjustments shown is indicated by the letters (A), (B), (C), etc.

A. Transmitter-Distributor Unit

2.02 Cover Assemblies

INSTRUCTIONS FOR



- (A) REMOVING FRONT PANEL----PULL OUTWARD ON LOWER RIGHT AND LEFT REAR CORNER OF FRONT PANEL AND SLIDE PANEL TOWARD THE FRONT. REPLACE IN REVERSE ORDER.
- (B) REMOVING COVER PLATE----LIFT LEFT END OF COVER PLATE TO DISENGAGE DETENTS, THEN SLIDE PLATE TOWARD THE LEFT TO DISENGAGE SPRING PLATE. REPLACE IN REVERSE ORDER.
- (C) REMOVING TOP PLATE----WITH FRONT AND REAR MOUNTING SCREWS LOOSENED (DO NOT DISTURB MOUNTING NUTS) AND TAPE LID RAISED, LIFT PLATE UPWARD. REFER TO TAPE-GUIDE PLATE REQUIREMENT WHEN REPLACING PLATE.
- (D) REMOVING TAPE GUIDE PLATE----WITH FRONT AND REAR MOUNTING SCREWS LOOSENED (DO NOT DISTURB MOUNTING NUTS) AND TAPE LID RAISED, LIFT PLATE UPWARD. REFER TO TAPE-GUIDE PLATE MOUNTING REQUIREMENT WHEN REPLACING THE PLATE.




2.03 Clutch Mechanism

NOTE 1----REQUIREMENTS (A)&(B) ARE ADJUSTED AT THE FACTORY AND SHOULD NOT BE DISTURBED UNLESS ASSOCIATED MECHANISMS HAVE BEEN REMOVED FOR SERVICING OR THERE IS REASON TO BELIEVE THAT THE REQUIREMENTS ARE NOT MET.

NOTE 2 -- WITH TRANSMITTER-DISTRIBUTOR UNIT REMOVED FROM BASE, INVERT UNIT AND ROTATE MAIN SHAFT UNTIL CLUTCH SHOE LEVER AND STOP LUG ARE UP.



2.04 Clutch Trip Mechanism



(C) CLUTCH LATCH LEVER SPRING REQUIREMENT


CLUTCH ENGAGED AND ROTATED UNTIL LATCHLEVER IS ON LOW PART OF DISC.
 MIN. 3 OZS. --- MAX. 5-1/2 OZS. TO START LATCH MOVING.

(B) CLUTCH SHOE LEVER

REQUIREMENT --- CLEARANCE AS SHOWN SHOULD BE 0.055 INCH TO 0.085 INCH GREATER WITH CLUTCH ENGAGED* THAN WITH CLUTCH DISENGAGED -
 * (PULL SHOE LEVER WITH FORCE OF 32 OZS. AND RELEASE SLOWLY TO ENGAGE CLUTCH SHOES.)
 TO ADJUST --- WITH CLUTCH DISK CLAMPING SCREWS LOOSENED, PLACE WRENCH OVER STOP LUG AND MOVE DISK.


CAUTION --- MAKE SURE THAT DRUM DOES NOT DRAG ON SHOES WHEN CLUTCH IS DISENGAGED AND DRUM IS ROTATED IN ITS NORMAL DIRECTION. REFINE ABOVE ADJUSTMENT TO CORRECT SHOE DRAG.

MAIN BAIL (FRONT VIEW)



(A) CLUTCH TRIP LEVER

REQUIREMENTS -- (REMOVE COVER PLATE) WITH CLUTCH DISK STOP LUG OPPOSITE CLUTCH TRIP LEVER, CLEARANCE BETWEEN INNER SURFACE OF LUG AND LEVER
 (1) PLAY TAKEN UP TO MAKE CLEARANCE MAX. MIN. 0.012 INCH --- MAX. 0.025 INCH. TO ADJUST -- LOOSEN CLAMP NUT ON CLUTCH TRIP BAIL ECCENTRIC (FRICTION TIGHT) AND ROTATE ECCENTRIC POST TO ITS LOWEST POINT. POSITION ECCENTRIC POST TO MEET REQUIREMENT.
 (2) PLAY TAKEN UP TO MAKE CLEARANCE MIN. SOME CLEARANCE.
 TO ADJUST -- REFINE REQUIREMENT (1).



(D) CLUTCH TRIP LEVER SPRING

REQUIREMENT --- WITH CLUTCH ENGAGED
 MIN. 7 OZS. --- MAX. 10-1/2 OZS. TO START CLUTCH TRIP LEVER MOVING.

2.05 Tape Guide Plate

(A) TAPE LID (FOR TAPE LID ASSEMBLY WITHOUT TAPE -LID SPRING)

REQUIREMENTS---(REMOVE TOP & TAPE GUIDE PLATES, LUBRICATE PRIOR TO ADJUSTMENT.)

(1) PRELIMINARY:

WITH TAPE LID HELD AGAINST NOTCH IN TAPE GUIDE PLATE

A FEED WHEEL GROOVE IN TAPE LID SHOULD ALIGN WITH SLOT IN PLATE.

B HOLE IN TAPE LID FOR TAPE-OUT PIN SHOULD ALIGN WITH HOLE IN PLATE. (GAUGE BY EYE)

C CLEARANCE BETWEEN PIVOT SHOULDER AND TAPE LID SOME _____ TO _____ 0.010 INCH MAX.

TO ADJUST---WITH TAPE LID BRACKET MOUNTING NUTS (2) FRICTION TIGHT (INSERT TIP OF TP156743 GAUGE THROUGH SLOT AND INTO GROOVE OF LID), POSITION TAPE LID BRACKET - RETIGHTEN NUTS.


(2) TAPE LID FRONT BEARING SURFACE (A) SHOULD TOUCH TAPE GUIDE PLATE. CLEARANCE (B) MEASURED AT FIN OF TAPE LID WHICH IS IN LINE WITH REAR TAPE GUIDE (SEE NOTE 2) MIN. 0.010 INCH _____ MAX. 0.018 INCH.

NOTE 1 -- WHEN BOTH PLATES ARE ASSEMBLED ON UNIT, LEFT EDGE OF LID MAY TOUCH TOP PLATE AND SOME CHANGE IN THIS CLEARANCE MAY BE EXPECTED.

TO ADJUST -- WITH TAPE LID BEARING BRACKET MOUNTING SCREWS FRICTION TIGHT AND TAPE LID PRESSED AGAINST TAPE GUIDE PLATE, POSITION BEARING BRACKET. RECHECK REQUIREMENT (1).

(3) RELEASE PLUNGER SHOULD HAVE SOME END PLAY WHEN LID IS LATCHED AGAINST TAPE GUIDE PLATE.

TO ADJUST -- WITH ECCENTRIC MOUNTING POST LOCK NUT FRICTION TIGHT AND TAPE LID RAISED, ROTATE HIGH PART OF ECCENTRIC TOWARD TAPE GUIDE PLATE. CLOSE LID AND ROTATE ECCENTRIC TOWARD BRACKET UNTIL LATCH JUST FALLS UNDER FLAT ON POST. RECHECK BY DEPRESSING PLUNGER --- WITH LID HELD DOWN, TIP OF LATCH SHOULD CLEAR POST AS PLUNGER IS OPERATED.




(B) TAPE GUIDE

REQUIREMENTS---WITH TAPE GAUGE POSITIONED AS SHOWN

1. CLEARANCE BETWEEN RIGHT AND LEFT TAPE GUIDE AND GAUGE SOME _____ TO _____ 0.003 INCH.

2. EDGE OF WEAR PLATE SHOULD BE FLUSH WITH EDGE OF TAPE GUIDE PLATE.

TO ADJUST---WITH EACH TAPE GUIDE MOUNTING NUT FRICTION TIGHT, MOVE WEAR PLATE UPWARD UNTIL IT OVERHANGS EDGE OF TAPE GUIDE PLATE. PLACE GAUGE IN POSITION AND MOVE GAUGE AND WEAR PLATE DOWNWARD UNTIL BOTH STUDS ENGAGE EDGE OF TAPE GUIDE PLATE TO ALIGN COMMON EDGES. HOLD GAUGE AND WEAR PLATE AND POSITION EACH GUIDE. (GAUGE MAY TOUCH BUT NOT BIND.) THE TAPE SHOULD NOT RIDE ON THE SIDE OF EITHER TAPE GUIDE.




2.06 Tape Guide Plate



(A) TAPE LID (FOR TAPE LID ASSEMBLY WITH TAPE-LID SPRING)
FOR REQUIREMENTS (1) AND (2), SEE PREVIOUS PARAGRAPH.

(3) REQUIREMENT---RELEASE PLUNGER SHOULD HAVE SOME ENDPLAY WHEN LID IS LATCHED AGAINST TAPE GUIDE PLATE. ECCENTRIC HIGH PART SHOULD BE TOWARD BRACKET.

TO ADJUST---WITH ECCENTRIC MOUNTING-POST LOCKNUT FRICTION TIGHT AND TAPE LID RAISED, ROTATE HIGH PART OF ECCENTRIC TOWARD TAPE-LID BEARING BRACKET. CLOSE TAPE LID AND ROTATE ECCENTRIC IN COUNTER-CLOCKWISE DIRECTION AS VIEWED FROM SLOTTED END OF ECCENTRIC UNTIL THE FLAT OF THE TAPE-LID POST IS FULLY ENGAGED BY THE FLAT OF THE LATCH BAIL. ROTATE ECCENTRIC IN CLOCKWISE DIRECTION TO TAKE UP PLAY IN PARTS SO AS TO FIRMLY SEAT TAPE LID AGAINST TAPE GUIDE PLATE. TIGHTEN NUT. RECHECK BY DEPRESSING PLUNGER - WITH LID HELD DOWN, TIP OF LATCH SHOULD CLEAR POST AS PLUNGER IS OPERATED. WITH THE TAPE LID LATCHED, ROUNDED TIP OF LATCH SHOULD PROJECT JUST BEYOND FLAT OF TAPE-LID POST AND RELEASE PLUNGER SHOULD HAVE SOME ENDPLAY. IF NECESSARY, REFINE THE ADJUSTMENT TO MEET THESE REQUIREMENTS.



2.07 Tape-lid Assembly (Without Tape-lid Spring)




2.08 Tape-lid Assembly (With Tape-lid Spring)

(A) FOR REQUIREMENT (A) START-STOP DETENT-BAIL SPRING, SEE PREVIOUS PARAGRAPH.

(B) TAPE-LID RELEASE-PLUNGER SPRING


REQUIREMENT---WITH TAPE GUIDE PLATE POSITIONED IN A HORIZONTAL PLANE AND TAPE LID IN ITS OPEN POSITION
 MIN. 28 OZS.-----MAX. 48 OZS.
 TO START TAPE-LID BAIL MOVING.



(C) TAPE-LID SPRING

REQUIREMENT---TAPE GUIDE PLATE POSITIONED IN A HORIZONTAL PLANE AND TAPE LID IN ITS OPEN POSITION. WITH RELEASE PLUNGER HELD FULLY DEPRESSED, APPLY SPRING SCALE AT TOP OF TAPE LID TO THE IMMEDIATE LEFT OF THE TAPE-OUT PIN HOLE AND PUSH VERTICALLY DOWNWARD.
 MIN. 3 OZS.-----MAX. 4-1/2 OZS.
 TO MOVE OPEN END OF TAPE LID AGAINST TAPE GUIDE PLATE.

2.09 Tape Guide Plate Mounting



INSTRUCTIONS FOR

REPLACING AND POSITIONING TAPE GUIDE PLATE

REQUIREMENTS----

- (1) SHOULDER OF FEED WHEEL POST SHOULD NOT INTERFERE WITH TOP PLATE OR TAPE GUIDE PLATE MOUNTING BRACKETS.
TO ADJUST---- SEE NOTE 1. WITH (FEED WHEEL) BEARING POST CLAMP NUT FRICTION TIGHT, POSITION THE POST.
- (2) TAPE GUIDE PLATE SHOULD REST FIRMLY AGAINST AT LEAST THREE PROJECTIONS OF FRONT AND REAR PLATE.
TO ADJUST---- SEE NOTE 1. WITH CLAMP NUT THAT SECURES TAPE GUIDE PLATE MOUNTING BRACKET (FRONT & REAR) FRICTION TIGHT, TRIP CLUTCH AND ROTATE SHAFT UNTIL SENSING PINS ARE IN THEIR UPPERMOST POSITION. WITH TAPE LID RAISED AND START-STOP LEVER IN RUN POSITION, PRESS GUIDE PLATE INTO POSITION WHILE GUIDING MOUNTING SCREWS INTO NOTCH OF FRONT AND REAR PLATE. ENGAGE TIP OF TAPE OUT PIN WITH HOLE IN TAPE GUIDE PLATE.
- (3) OUTER EDGE OF FRONT AND REAR MOUNTING BRACKET SHOULD BE LOCATED FLUSH WITH SHOULDER OF MOUNTING STUD SO THAT EDGE OF TAPE GUIDE PLATE PROJECTS OVER FRONT AND REAR PLATE BY AN EQUAL AMOUNT. (GAUGE BY EYE.) SEE COVER PLATE REQUIREMENT.
TO ADJUST----MOVE TAPE PLATE TOWARD THE FRONT OR REAR. TIGHTEN NUTS ONLY AFTER TOP PLATE IS ADJUSTED.


NOTE 1---POSITION TAPE-OUT SENSING PIN STOP ARM (SEE TAPE-OUT SENSING PIN REQUIREMENT.) IN ITS LOWEST POSITION AND HOLD START-STOP BAIL EXTENSION FROM RATCHET WHEEL.

2.10 Top Plate and Cover Plate Mounting

INSTRUCTIONS FOR


REPLACING AND POSITIONING TOP PLATE----LOOSEN NUTS (FRICTION TIGHT) THAT SECURE MOUNTING BRACKETS TO PLATE. PRESS TOP PLATE INTO POSITION WHILE GUIDING TOP PLATE MOUNTING SCREWS INTO NOTCH OF FRONT AND REAR PLATE. POSITION EACH SENSING PIN IN ITS SLOT. MAKE SURE THAT TOP PLATE SEATS FIRMLY AGAINST PROJECTIONS OF FRONT AND REAR PLATE (3 PROJECTIONS SHOULD ENGAGE) AND TIGHT TAPE ARM EXTENSION IS UNDER TOP PLATE. REQUIREMENTS----

1. MATING EDGE OF TOP PLATE SHOULD BE FLUSH TO 0.003 INCH UNDER FLUSH WITH EDGE OF TAPE GUIDE PLATE (WITHIN AREA OF TAPE LID) WHEN PLATE ENGAGES AT LEAST 3 PROJECTIONS TO ADJUST----POSITION TOP PLATE, TIGHTEN MOUNTING SCREWS AND THEN TIGHTEN NUTS THAT SECURE TAPE GUIDE PLATE MOUNTING BRACKETS.
2. FEEDWHEEL SLOT SHOULD ALIGN WITH SLOT IN TAPE GUIDE PLATE SO THAT FEED WHEEL ROTATES FREELY WITH DETENTS AND FEED PAWL DISENGAGED (FREEWHEELING). TO ADJUST----POSITION TOP PLATE TOWARD FRONT OR REAR TO ALIGN SLOT.
3. THE CLEARANCE BETWEEN THE TAPE-LID EXTENSION WHICH COVERS THE FEED-WHEEL SLOT AND THE TOP PLATE SHALL BE 0.010-TO-0.020 INCH AT THE CURVED PORTION AND 0.010-TO-0.025 INCH AT THE FLAT PORTION (PLAY TAKEN UP TOWARD TAPE-GUIDE PLATE). TO ADJUST --- IF NECESSARY, LOOSEN TAPE-LID BEARING BRACKET MOUNTING SCREWS AND POSITION TAPE LID. RETIGHTEN SCREWS AND RECHECK REQUIREMENTS.

INSTRUCTIONS FORREPLACING AND POSITIONING COVER PLATE

REQUIREMENT----

1. RIGHT EDGE OF COVER PLATE SHOULD BE HELD FLUSH AGAINST LEFT EDGE OF TOP PLATE BY THE COVER PLATE DETENTS.
2. COVER PLATE SHOULD REST AGAINST AT LEAST THREE OF THE FOUR PROJECTIONS (FRONT & REAR PLATE).
3. FRONT EDGE OF COVER PLATE AND TOP PLATE SHOULD ALIGN. TO ADJUST----WITH DETENTING NUT CLAMP SCREW (FRONT & REAR PLATE) FRICTION TIGHT, MOVE CLAMP SCREWS TO THEIR EXTREME LOWER RIGHT POSITION THEN TIGHTEN SCREWS. LOOSEN DETENT BRACKET AND SPRING PLATE MOUNTING NUTS. PLACE COVER ON UNIT AND POSITION HORIZONTALLY TO MEET THE REQUIREMENTS. RETIGHTEN MOUNTING NUTS.




2.11 Tape-out Contact Assembly

(A) TAPE-OUT CONTACT ASSEMBLY

REQUIREMENT --- (COVER PLATE AND TOP PLATE REMOVED; START-STOP SWITCH IN STOP POSITION; REMOVAL OF TAPE GUIDE PLATE OPTIONAL.) WITH TAPE-OUT SPRING BRACKET FRICTION TIGHT, MOVE BRACKET DOWNWARD UNTIL TAPE-OUT PIN EXTENSION CLEARS INSULATED PORTION OF CONTACT SWINGER.

1. WITH GRAM SCALE APPLIED AS SHOWN
MIN. 8 GRAMS _____ MAX. 15 GRAMS
TO SEPARATE NORMALLY CLOSED CONTACTS.
TO ADJUST---REMOVE BAIL SPRING AND CONTACT ASSEMBLY. FORM THE CONTACT SWINGER WITH TP110445 SPRING BENDER.

2. CLEARANCE BETWEEN NORMALLY OPEN CONTACTS
MIN. 0.008 INCH _____ MAX. 0.015 INCH.
TO ADJUST---FORM UPPER CONTACT SPRING USING THE TP110445 SPRING BENDER.
NOTE---REPLACE CONTACT ASSEMBLY WITH SWINGER OVER TAPE-OUT PIN EXTENSION. PLACE SPRING BRACKET SHOULDER BUSHING ON UPPER HOLE AND THE WASHER ON LOWER MOUNTING HOLE.


(B) TAPE-OUT CONTACT BRACKET

REQUIREMENT----WITH TAPE-OUT PIN DEPRESSED BY TAPE UNDER TAPE LID, CLEARANCE BETWEEN TAPE-OUT PIN EXTENSION AND INSULATOR ON SWINGER CONTACT
MIN. 0.006 INCH _____ MAX. 0.020 INCH.
TO ADJUST----POSITION TAPE-OUT CONTACT BRACKET WITH ITS MOUNTING SCREWS LOOSENED.

(C) TAPE-OUT SENSING PIN SPRING

REQUIREMENT----WITH START-STOP LEVER IN RUN POSITION
MIN. 38 GRAMS --- MAX. 45 GRAMS
TO MOVE PIN TO A POSITION FLUSH WITH TAPE GUIDE PLATE.
TO ADJUST --- WITH CONTACT BRACKET LOWER MOUNTING SCREW LOOSENED POSITION THE SPRING BRACKET.

2.12 Tape-out Sensing Pin



(A) TAPE-OUT SENSING PIN REQUIREMENTS

1. WITH START-STOP LEVER IN FREE WHEELING OR STOP POSITION, TIP OF TAPE-OUT PIN SHOULD BE FLUSH _____ TO _____ 0.010 INCH BELOW TOP SURFACE OF TAPE GUIDE PLATE. TO ADJUST----PLACE START-STOP LEVER IN STOP POSITION. WITH STOP ARM CLAMP SCREW FRICTION TIGHT, POSITION THE STOP ARM.
 2. WITH START-STOP LEVER IN RUN POSITION, CLEARANCE AS SHOWN SHOULD BE AT LEAST 0.055 INCH. TO ADJUST----PLACE START-STOP LEVER IN RUN POSITION AND LOOSEN TAPE-OUT BAIL CLAMP SCREW. POSITION EXTENSION ARM WITH TOMMY WRENCH OR SIMILAR TOOL.
- NOTE----RECHECK REQUIREMENT 1.

(B) DEPRESSOR BAIL TORSION SPRING REQUIREMENT

TAPE-OUT BAIL SPRING UNHOOKED START-STOP LEVER IN STOP POSITION. MIN. 3 OZS. --- MAX. 5-1/2 OZS. TO START INTERMEDIATE TAPE-OUT BAIL MOVING AWAY FROM TAPE-OUT PIN DEPRESSOR BAIL.

(C) INTERMEDIATE TAPE-OUT BAIL SPRING

REQUIREMENT --- WITH START-STOP LEVER IN ITS RUN POSITION, HOOK SPRING SCALE IN LOOP. MIN. 3 OZS. _____ MAX. 5 OZS. TO PULL SPRING TO ITS INSTALLED LENGTH.


2.13 Start-Stop Switch Assembly

(A) START - STOP SWITCH BRACKET
REQUIREMENTS ---

1. WITH START - STOP LEVER IN RUN POSITION AND CLUTCH IN ITS DISENGAGED POSITION, CLEARANCE BETWEEN START - STOP BAIL EXTENSION AND INSULATOR ON START - STOP SWITCH SWINGER
MIN. 0.006 INCH _____ MAX. 0.015 INCH.
TO ADJUST --- WITH SWITCH BRACKET MOUNTING SCREWS LOOSENED, POSITION THE BRACKET.
2. START - STOP BAIL EXTENSION SHOULD FULLY ENGAGE INSULATED PORTION OF SWITCH SWINGER.
TO ADJUST --- LOOSEN CONTACT PILE-UP MOUNTING SCREWS AND ALIGN CONTACT ASSEMBLY.

(B) TIGHT TAPE;
START-STOP CONTACT SPRING

REQUIREMENT----WITH START-STOP LEVER IN RUN POSITION
MIN. 3 OZS.
MAX. 4 OZS.
TO SEPARATE CONTACTS.
TO ADJUST----FORM SWINGER
WITH TP110445 SPRING BENDER,
NOTE----RECHECK REQUIREMENTS
(A) & (C).




(C) TIGHT TAPE
INTERMEDIATE ARM

REQUIREMENT----WITH START-STOP LEVER IN RUN POSITION, TIGHT TAPE; START-STOP CONTACTS SHOULD FUNCTION AS FOLLOWS:
1. REMAIN CLOSED WHEN TIGHT TAPE BAIL IS RAISED 0.045 INCH.
2. OPEN AS BAIL IS RAISED TO HEIGHT OF 0.075 INCH.


TO ADJUST----WITH TIGHT TAPE INTERMEDIATE ARM CLAMP SCREW LOOSENED, POSITION THE ARM AT ITS ADJUSTING SLOT.

(D) TIGHT TAPE INTERMEDIATE ARM SPRING

REQUIREMENT----WITH START-STOP LEVER IN RUN POSITION,
MIN. 20 GRAMS (3/4 OZ.) _____ MAX. 40 GRAMS (1-1/2 OZ.)
TO START INTERMEDIATE ARM MOVING AWAY FROM ITS YIELD ARM.



2.14 Main Bail Assembly



2.15 Code-sensing Fingers


SENSING FINGER SPRING.

REQUIREMENT

UNIT IN UPRIGHT POSITION, SENSING FINGERS IN THEIR UPPERMOST POSITION.

	<u>CHADLESS TAPE</u>	<u>FULLY PERFORATED TAPE</u>
MIN.	3 OZS.	2 OZS.
MAX.	5 OZS.	3 OZS.

TO MOVE A SENSING FINGER TO A POSITION FLUSH WITH THE TAPE GUIDE PLATE.



FEED WHEEL DETENT

REQUIREMENT



WITH TAPE LID RAISED, SENSING FINGERS DOWN, HIGH PART OF ECCENTRIC TOWARD THE RIGHT, LETTERS PERFORATED TAPE BETWEEN TAPE GUIDES, AND PLAY IN TAPE TAKEN LIGHTLY TOWARD THE RIGHT, TIP OF EACH SENSING FINGER SHOULD BE CENTRALLY LOCATED IN THE CODE HOLES. TO ADJUST

HOLD FEED PAWL AWAY AND ROTATE THE FEED WHEEL DETENT ECCENTRIC SCREW.

2.16 Feed Pawl Mechanism


(A) FEED PAWL
 REQUIREMENT----(TOP PLATE REMOVED) - WITH HIGH PART OF ECCENTRIC TOWARD THE RIGHT AND SENSING FINGERS IN THEIR LOWERMOST POSITION, CLEARANCE BETWEEN FEED PAWL AND RATCHET TOOTH JUST ENGAGED
 SOME _____ TO _____ 0.003 INCH.
 TO ADJUST----WITH ECCENTRIC SCREW LOCK NUT LOOSENED, POSITION THE SCREW. RE-CHECK REQUIREMENT AT FOUR POSITIONS OF RATCHET APPROXIMATELY 90 DEGREES APART.

(B) FEED PAWL SPRING
 REQUIREMENT----WITH UNIT TILTED TOWARD THE LEFT AND MAINSHAFT IN ITS STOP POSITION
 MIN. 2 OZS. _____ MAX. 3-1/2 OZS.
 TO START PAWL MOVING.



(C) TRANSFER LEVER SPRING
 REQUIREMENT----WITH UNIT RESTING ON ITS REAR PLATE AND MAINSHAFT IN ITS STOP POSITION
 MIN 1/2 OZ. _____ MAX. 1-1/2 OZS.
 TO START EACH LEVER MOVING.

2.17 Main Bail Trip Assembly




2.18 Transfer Bail Stabilizer

(A) TRANSFER BAIL STABILIZER


REQUIREMENT --- (1) WITH A LTRS COMBINATION SELECTED, ROTATE MAINSHAFT UNTIL #3 TRANSFER LEVER IS ON HIGH PART OF ITS CAM. CHECK CLEARANCE BETWEEN SIDE OF TRANSFER BAIL EXTENSION AND ITS LATCH. (2) REPEAT ABOVE PROCEDURE WITH A BLANKS COMBINATION SELECTED AND CHECK THE CLEARANCE ON OTHER LATCH. CLEARANCE IN MARKING AND SPACING POSITION SHOULD BE EQUAL WITHIN 0.002 INCH.
TO ADJUST --- WITH STABILIZER ASSEMBLY MOUNTING SCREWS FRICTION TIGHT, POSITION THE ASSEMBLY.

NOTE --- LATCHES SHOULD DROP IN PLACE AS OTHER TRANSFER LEVERS CAM THE TRANSFER BAIL.

(B) STABILIZER SPRING

REQUIREMENT----WITH UNIT UPRIGHT AND MAINSHAFT IN STOP POSITION
MIN. 2-1/2 OZS. ——— MAX. 5 OZS.
TO START STABILIZER LATCH MOVING.

2.19 Signal Contact Assembly




(A) SIGNAL CONTACT
 REQUIREMENT----(COVER PLATE AND CONTACT BOX COVER REMOVED) CONTACT GAP IN THE MARKING POSITION AND THE SPACING POSITION SHOULD BE EQUAL WHEN CLEARANCE BETWEEN RESPECTIVE CONTACTS IS MAXIMUM. (ENGAGE CLUTCH AND ROTATE MAINSHAFT SLOWLY.) TO ADJUST----WITH CONTACT BOX MOUNTING SCREWS FRICTION TIGHT, POSITION BOX WITH ITS ECCENTRIC.
 NOTE---- USE 1A TELETYPEWRITER TEST SET OR 28A STROBOSCOPIC TEST SET WHERE POSSIBLE TO REFINE ADJUSTMENT. REFER TO SIGNAL PULSE REFINEMENT.

(B) SIGNAL CONTACT SPRING
 REQUIREMENT----
 WITH MAINSHAFT IN STOP POSITION AND COVER OF CONTACT BOX REMOVED, UNHOOK TOGGLE LINK SPRING AND MOVE TRANSFER BAIL TO SPACING POSITION (RIGHT).
 MIN. 2 OZS. ----- MAX. 3-1/2 OZS.
 TO OPEN SPACING CONTACTS (LEFT).


(C) SIGNAL CONTACT LINK SPRING
 REQUIREMENT----WITH MAINSHAFT IN STOP POSITION AND STABILIZER SPRING UNHOOKED, MOVE LATCHES AWAY FROM TRANSFER BAIL EXTENSION.
 MIN. 6 OZS. ----- MAX. 12 OZS.
 TO START TRANSFER BAIL EXTENSION MOVING.

2.20 Clutch Trip Magnet Assembly



2.21 Cover Plate

COVER PLATE DETENT
(BOTTOM VIEW)



COVER PLATE DETENT SPRING
REQUIREMENT --- WITH SPRING
SCALE APPLIED TO CENTER OF
ONE DETENT
MIN. 28 OZS.—MAX. 48 OZS.
TO START PLUNGER MOVING.

NOTE

OUTER EDGE OF EACH
MOUNTING BRACKET SHOULD
BE APPROXIMATELY IN LINE
WITH SHOULDER OF ITS
MOUNTING STUD, SO THAT
PROJECTIONS OF FRONT AND
REAR BRACKETS ARE EQUAL
(GAUGE BY EYE).

2.22 Signal Pulse Refinement

SIGNAL PULSE (FINAL ADJUSTMENT WITH
1A TELETYPEWRITER TEST SET OR 28A STROBOSCOPIC TEST SET)

PROCEDURE --- PLUG TEST SET INTO SIGNAL

LINE TO VIEW PULSE IMAGE GENERATED BY THE MARKING AND SPACING CONTACTS. SYNCHRONIZE SIGNAL GENERATOR WITH TEST SET SO THAT END OF STOP PULSE IMAGE ALIGNS WITH THE 142 MARK ON TEST SET SCALE WHEN BOTH UNITS ARE OPERATED AT SAME SPEED AND TRANSMISSION IS CONTINUOUS.



NOTE 1--- END OF STOP PULSE IMAGE SHOULD NOT VARY FROM THE 142 MARK BY MORE THAN 1/2 SCALE DIVISION. IF A GREATER VARIATION OCCURS, MOVE THE SCALE UNTIL THE VARIATIONS EXTEND EQUALLY ON EITHER SIDE OF THE 142 MARK.

REQUIREMENTS (SPEEDS UP TO AND INCLUDING 100 W.P.M.)

1. EACH MARKING CODE PULSE SHOULD START NO LATER THAN THE 5TH MARK OF THE PULSE UNDER OBSERVATION AND START NO EARLIER THAN 95TH MARK OF THE PREVIOUS PULSE.
2. EACH MARKING CODE PULSE SHOULD END NO EARLIER THAN THE 95TH MARK OF THE PULSE UNDER OBSERVATION AND END NO LATER THAN THE 5TH MARK OF THE FOLLOWING PULSE.
3. EACH MARKING CODE PULSE MAY HAVE ONE BREAK PROVIDED THE BREAK IS NOT OVER ONE DIVISION WIDE AND PROVIDED THE BREAK OCCURS ONLY AT THE END OF CODE PULSE IMAGE BETWEEN THE 95TH MARK AND THE END OF THE IMAGE.
4. THE STOP PULSE SHOULD START NO EARLIER THAN THE 95TH MARK OF THE 5TH PULSE AND START NO LATER THAN THE 5TH MARK OF THE STOP POSITION. (See Note 2)

TO ADJUST --- WITH SIGNAL CONTACT BOX MOUNTING SCREWS FRICTION TIGHT, ROTATE THE ECCENTRIC (RIGHT OR LEFT). TIGHTEN MOUNTING SCREWS AND RECHECK ADJUSTMENT.

NOTE 2 ----- THE STOP IMAGE SHOULD NOT CHANGE IN LENGTH OR POSITION WHEN VIEWED ON TEST SET WHILE CHANGING FROM "R" TO "Y" SELECTION. TO ADJUST --- REPOSITION STABILIZER MECHANISM SO THAT END OF STOP IMAGE COINCIDES WITH THE 142 MARK ON THE SCALE. (DO NOT REMOVE THE SCALE.)



NOTE 3-- IF ABOVE REQUIREMENTS CANNOT BE MET REFINE TRANSFER-BAIL STABILIZER REQUIREMENT WITH SIGNAL VIEWED ON TEST SET.


B. Auxiliary Features

Multiple Wire Output Facilities

2.23 Code Reading and Timing Contacts


NOTE 1
UNLESS SPECIFICALLY STATED OTHERWISE, THE FOLLOWING CODE READING CONTACT ADJUSTMENTS APPLY TO BOTH THE TRANSFER (BREAK BEFORE MAKE) TYPE AND MAKE TYPE CONTACTS. WHEN AN ADJUSTMENT IS APPLICABLE TO BOTH TYPES, THE TRANSFER TYPE CONTACTS ARE USED IN THE ILLUSTRATIONS. WHEN TESTING THESE CONTACTS ON ASR SETS THE CONTROL KNOB SHOULD BE IN THE K-T POSITION.

NOTE 2
THE FOLLOWING ADJUSTMENTS SHALL BE MADE ONLY IF THE CODE READING CONTACT ASSEMBLY IS REMOVED FROM THE UNIT.




WHEN USING THE CONTACT SPRING BENDER, START WITH THE CONTACT PILE-UP FARTHEST FROM THE HANDLE OF THE TOOL AND WORK TOWARD THE HANDLE SO AS NOT TO DISTURB ADJUSTMENTS ALREADY MADE.

MARKING CONTACT BACKSTOPS
REQUIREMENT
AS GAUGED BY EYE, FIVE MARKING CONTACT SPRINGS SHOULD ALIGN WITH EACH OTHER AND BE PARALLEL WITH MOUNTING PLATE.
TO ADJUST
BEND MARKING CONTACT BACKSTOPS.



MARKING CONTACT SPRINGS-PRELIMINARY
REQUIREMENT
WITH SWINGER CONTACT SPRING HELD AWAY:
MIN. 2 OZS.
MAX. 6 OZS.
TO MOVE EACH SPRING AWAY FROM BACKSTOP.
TO ADJUST
BEND MARKING CONTACT SPRINGS.


NOTE:
TO INCREASE TENSION OF MARKING CONTACT SPRING, IT MAY BE NECESSARY TO BEND BACKSTOP AWAY FROM SPRING, BEND SPRING, AND THEN RE-BEND BACKSTOP TO MEET REQUIREMENT OF MARKING CONTACT BACKSTOPS ADJUSTMENT (ABOVE).



2.24 Code Reading and Timing Contacts

(A) SWINGER CONTACT SPRINGS-PRELIMINARY REQUIREMENT

MIN. 30 GRAMS
 MAX. 40 GRAMS
 TO OPEN MARKING CONTACTS.
 TO ADJUST
 BEND SWINGER CONTACT SPRINGS.




NOTE:

SPACING CONTACTS (ON TRANSFER TYPE CONTACT ASSEMBLIES ONLY) ARE NORMALLY OPEN WHEN CONTACT ASSEMBLY IS REMOVED FROM UNIT.


(B) SPACING CONTACT BACKSTOPS - PRELIMINARY (APPLIES TO TRANSFER TYPE CONTACTS ONLY) REQUIREMENT

GAP BETWEEN SPACING CONTACTS
 MIN. 0.025 INCH
 MAX. 0.030 INCH.
 TO ADJUST
 BEND SPACING CONTACT BACKSTOPS.



(C) SPACING CONTACT SPRINGS-PRELIMINARY (APPLIES TO TRANSFER TYPE CONTACTS ONLY) REQUIREMENT


MIN. 30 GRAMS
 MAX. 40 GRAMS
 TO MOVE EACH CONTACT SPRING AWAY FROM BACKSTOP.
 TO ADJUST
 BEND SPACING CONTACT SPRINGS.




NOTE

TO INCREASE TENSION OF SPRING, IT MAY BE NECESSARY TO BEND BACKSTOP AWAY FROM SPRING, BEND SPRING, AND THEN RE-BEND BACKSTOP TO MEET REQUIREMENT OF SPACING CONTACT BACKSTOPS ADJUSTMENT ABOVE.

2.25 Code Reading Contacts



2.26 Code Reading Contact Sensing Arm



Tabulator Control

2.27 Transmitter-stop Mechanism


START-STOP CONTACT GAP

REQUIREMENT

WITH THE TIMING BAIL ON THE LOW PART OF ITS CAM, THE START-STOP CONTACT GAP SHOULD BE
MIN. 0.008 INCH
MAX. 0.015 INCH.

TO ADJUST

POSITION THE TIMING ARM ON THE YIELD ARM
WITH ITS CLAMP SCREW FRICTION TIGHT.



TIMING BAIL SPRING REQUIREMENT
MIN. 5 1/2 OZS.
MAX. 8 OZS.
TO START THE BAIL MOVING.

Modification Kit to Permit Use of 11/16-inch and 7/8-inch
5-level Tape Interchangeably

2.28 Tape Guide


RIGHT AND LEFT GUIDE ADJUSTMENT

REQUIREMENT

WITH THE TP156743 GAUGE INSERTED BETWEEN THE RIGHT TAPE
GUIDE AND THE LEFT TAPE GUIDE,
THE GAUGE MAY TOUCH EITHER GUIDE BUT SHOULD NOT BIND.
CLEARANCE SHALL NOT EXCEED 0.003 INCH.

TO ADJUST

POSITION EACH TAPE GUIDE WITH THE TAPE-GUIDE MOUNTING
NUTS FRICTION TIGHT.




Modification Kit to Convert 28H to 28H-1 Transmitter-Distributor

2.29 Tape-lid Sensing Lever

TAPE LID SENSING LEVER SPRING REQUIREMENT

TAPE LID OPEN
MIN. 20 GRAMS
MAX. 35 GRAMS
TO SEPARATE SWITCH LEVER
FROM SWINGER.



SWITCH LEVER REQUIREMENT

TAPE LID OPEN, TAPE OUT PIN DEPRESSED,
GAP BETWEEN NORMALLY CLOSED CONTACTS
MIN. 0.005 INCH
MAX. 0.015 INCH.
TO ADJUST
POSITION THE TAPE LID SENSING LEVER WITH
ITS CLAMP SCREW LOOSENED.