

28E AND 28H TRANSMITTER DISTRIBUTOR UNIT

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	2	Tape Lid	
2. BASIC UNITS	4	Start-stop detent bail spring	9
Basic Gear Adjustments		Tape guide	8
Intermediate gear — transmitter distributor gear backlash	33	Tape guideplate	10
Clutch Mechanism		Tape lid	7
Armature bail spring	28	Tape lid release plunger spring	9
Clutch latchlever spring	6	Tape lid spring	9
Clutch magnet assembly (preliminary)	26-28	Tape-Out Switch Assembly	
Clutch shoe lever	5	Depressor bail torsion spring	14
Clutch shoe lever spring	4	Intermediate tape-out bail spring	14
Clutch shoe spring	4	Tape-out contact assembly	13
Clutch trip lever	6	Tape-out contact bracket	13
Clutch trip lever spring	6	Tape-out sensing pin	14
Main bail latch spring	28	Tape-out sensing pin (for units equipped with tape lid sensing lever)	15
Feed Wheel Mechanism		Tape-out sensing pin spring	13
Feed pawl	22	Top and Cover Plates	
Feed pawl spring	22	Cover plate	12
Feed ratchet detent spring	19	Cover plate detent spring	12
Feed wheel detent	21	Top plate	11
Main bail spring	19	Transfer Mechanism	
Main bail trip lever	19	Locking bail spring	23
Sensing pin spring	21	Stabilizer spring	24
Main Bail Mechanism		Transfer bail stabilizer	24
Main bail	20	Transfer lever spring	23
Signal Contacts		3. VARIABLE FEATURES	34
Drive link spring	25	Auxiliary Contacts	
Signal contact clearance	25	Auxiliary contact operating bail spring	43
Signal contacts — electrical	29	Contact sensing arm	43
Signal contact spring	25	Contact swinger — operating bail clearance	44
Start-Stop Switch Assembly and Tight-Tape Mechanism		Normally closed contacts	42
Start-stop switch bracket	16	Normally open contacts	42
Start-stop switch bracket (for units equipped with tape lid sensing lever)	17	Code Reading Contacts	
Tight-tape intermediate arm	18	Contact assembly positioning	39
Tight-tape intermediate arm spring	18	Contact sensing arm — upstop clearance	40
Tight-tape start-stop contact spring	16	Contact swinger — sensing arm clearance	39

CONTENTS	PAGE
Contact swinger — sensing arm clearance (strobing)	41
Normally closed contacts — backstop.	38
Normally closed contacts — spring	38
Normally open contacts — gap.	38
Normally open contacts — spring.	38
Sensing arm spring.	40
Sensing arm — transfer lever alignment	40
Split bail eccentric.	40
 Rub-Out Deleter	
Rub-out deleter bail guide	49
Rub-out deleter bail spring	49
Sensing pin spring	49
 Start-Stop Pulse Contact	
Contact bracket	47
Contact bracket (strobing)	48
Contact gap (start and stop contacts).	47
Contact lever.	47
 Tape Deflector	
Tape deflector bracket	46
Tape deflector spring	46
 Tape Feed Assurance Mechanism	
Detent lever spring.	35
Tape motion contact gap	35
Tape motion contact swinger	35
Tape sensing feed wheel phasing.	35
 Tape Lid Sensing Lever	
Switch lever	45
Switch lever spring.	45
 Tape Notch Sensing Mechanism	
Contact bracket (strobing)	51
Tape notch sensing contact.	50
Tape notch sensing pin spring.	50
 Tape-Out Mechanism	
Tape-out bail torsion spring.	36
Tape-out contact	36
Tape-out pin	37
Tape-out pin spring	37
 Tape Slack Arm	
Tape slack contacts	53
 Tape Withhold Mechanism	
Blocking bail arm eccentric.	54
Blocking bail eccentric pivot	54
Magnet armature gap	54

CONTENTS	PAGE
Tight-Tape and Tape Shoe Mechanism	
Tape shoe.	34
Tight-tape switch.	34
Torsion spring.	34
 Transmitter Stop Mechanism	
Start-stop contact gap (for tabulator control).	52
Timing bail spring	52
 4. EARLY MODELS.	55
 Tape Lid Mechanism	
Tape lid	55
Tape lid release plunger spring (for units without tape lid spring)	56

1. GENERAL

1.01 This section provides specific adjustments for the 5-level 28E and 28H transmitter distributor. This section is reissued to add recent engineering changes and additions, and to rearrange the order of adjustments. Arrows in the margin indicate changes and additions.

1.02 The adjustments are arranged in a sequence that should be followed if a complete readjustment is undertaken. The tools and spring scales required to perform these adjustments are found in tool Section 570-005-800. A complete adjusting procedure should be read before attempting to make the adjustment. After an adjustment is completed, be sure to tighten any nuts or screws that may have been loosened. Where an illustration shows interrelated parts, the sequence that should be followed in checking the requirements and making the adjustments is indicated by the letters, (A), (B), (C), etc.

1.03 The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions, and the angle at which scales should be applied. Coil springs which do not meet the requirements, and for which there are no adjusting procedures, should be discarded and replaced with new springs. If a part mounted on shims is removed, the number of shims used at each mounting screw should be noted so that the same number is replaced when the part is remounted.

Note: Remove power from unit before making adjustments.

1.04 When the requirement calls for the clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latchlever so that the clutch shoes release their tension on the clutch drum. When engaged, the clutch shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum. When the main shaft is rotated by hand, the clutch does not fully disengage upon reaching its stop position. In order to relieve the drag on the clutch and permit the main shaft to rotate freely, apply pressure on a lug of the clutch disc with a screwdriver to cause it to engage its latchlever and thus disengage the internal expansion clutch shoes from the clutch drum.

Note 1: After a few weeks (300 to 500 hours) of operation of a new unit, the unit should be relubricated to make sure all operating points have been properly lubricated.

Note 2: Recheck all clutch gaps to insure that the parts, after seating themselves, have not caused the clutch gaps to open up. Reset if necessary. Standard readjustment periods are to be maintained thereafter.

1.05 The covers may be removed for inspection and minor repair of the unit; however, when more extensive maintenance is to be undertaken, it is recommended that the unit be disconnected from its source of power as a safety precaution.

1.06 References made to left, right, up, down, front, or rear, apply to the set in its operating position, as viewed from the operator's position.

1.07 All electrical contact points should meet squarely. Contacts with the same diameter should not be out of alignment more than 25 percent of the contact diameter. Check contacts for pitting and corrosion and clean or burnish them before making specified adjustment or tolerance measurement. Avoid sharp kinks or bends in the contact springs.

CAUTION: KEEP ALL ELECTRICAL CONTACTS FREE OF OIL AND GREASE.

1.08 Units may have signal contacts made of either unplated or gold-plated tungsten. If in doubt as to the type of contacts, remove contact box cover and inspect contacts for gold

plating. Do not use burnishers, files, etc which will remove gold plating.

1.09 Use twill jean cloth (KS2423) (TP107162) to clean gold-plated contacts. Open contacts. Allow contacts to close on surface of twill jean. Draw twill jean part way through. Open contacts and withdraw twill jean.

1.10 This procedure prevents small fibers at edges of twill jean strip from becoming lodged between contacts.

1.11 Clean unplated tungsten contacts in accordance with standard procedures (Paragraph 1.07).

Servicing For Certain Low-Voltage Applications

1.12 For standard applications, including those with data sets, observe standard maintenance procedures and intervals. Certain low-voltage applications are covered below.

1.13 For optimum reliable operation in these low-voltage applications, clean gold-plated contacts with twill jean, as instructed above, at intervals of approximately 50 hours of actual contact operation. Since maintenance interval and life expectancy of the contacts are dependent on the signal circuit, maintenance interval may be lengthened for specific applications.

Note 1: Applying operating voltage of standard Distortion Test Set directly to contacts may damage gold plating and impair low-voltage operation. When electrically adjusting or testing contacts (2.22), use an intermediate device, keyed by the contacts, to interrupt current to stroboscopic lamp of test set. This intermediate device must be capable of being keyed by a 3 to 20 volt change at maximum of 20 milliamperes.

Note 2: Normally for low-voltage applications, contacts should be used in circuits operating between 3 and 20 volts dc at a current level not to exceed 60 milliamperes. Between 20 and 70 volts dc the current should be adjusted so as not to exceed a 120 milliwatt power level. The contacts are not normally intended for use with voltages above 70 volts dc. Exceeding this level for an appreciable length of time may result in damage to the gold plating and make them unfit for low-voltage applications.

2. BASIC UNITS

2.01 Clutch Mechanism

Note 1: Remove the transmitter distributor from its base before making a complete re-adjustment or spring tension checks.

Note 2: Adjustments (A) and (B) are made at the factory and should not be disturbed unless good reasons exist that the requirements are not met.

(A) CLUTCH SHOE LEVER SPRING

To Check


Invert unit and rotate main shaft until clutch shoe lever and stop lug are up. With clutch engaged, hold cam disc to prevent turning.

Requirement

Min 15 oz---Max 20 oz
to move shoe lever in contact with stop lug.

(Where set is equipped with tape slack mechanism)

Min 9 oz---Max 11 oz




(B) CLUTCH SHOE SPRING

To Check

Remove the clutch from the main shaft. With the clutch drum removed, hook spring scale as shown.

Requirement

Min 3 oz---Max 5 oz
to start primary shoe moving away from secondary shoe at point of contact.



2.02 Clutch Mechanism (continued)

Note: Remove transmitter distributor from base before making adjustments.

CLUTCH SHOE LEVER

To Check


Trip transmitter distributor clutch. Pull shoe lever opposite the stop-lug with a force of 32 oz. Release the force slowly to engage clutch shoes. Note clearance between clutch shoe lever and stop-lug. Disengage the clutch, and again pull the lever opposite the stop-lug with a force of 32 oz. Release the force slowly. Note clearance between the shoe lever and the stop-lug.

Requirement

Min 0.055 inch---Max 0.085 inch greater clearance with clutch engaged than with clutch disengaged.

To Adjust

Loosen clutch disc clampscrews. Place wrench over stop-lug and move disc. Retighten screws.



(Left Side View)

2.03 Clutch Mechanism (continued)

(C) CLUTCH LATCHLEVER SPRING

To Check
Trip clutch and rotate until latchlever is on low part of disc.

Requirement
Min 3 oz---Max 5-1/2 oz
to start clutch latchlever moving.

MAIN BAIL
(Front View)

CLAMP NUT


(A) CLUTCH TRIP LEVER

To Check
Trip transmitter distributor clutch.
With main bail in highest position,
rotate clutch until stop-lug is opposite
trip lever.

(1) Requirement
With trip bail play taken up to
make clearance maximum
Min 0.012 inch---Max 0.025 inch
between stop-lug and trip lever.

(2) Requirement
With trip bail play taken up to make
clearance minimum
some clearance
between stop-lug and trip lever.

To Adjust
Loosen clamp nut friction tight and
rotate trip bail eccentric post. Check
Requirement (1). Retighten clamp-
screw.



CLUTCH TRIP
BAIL
ECCENTRIC
POST

CLUTCH
TRIP LEVER

CLUTCH
LATCHLEVER

(Rear View)

(B) CLUTCH TRIP LEVER SPRING

Requirement
With clutch engaged
Min 7 oz---Max 10-1/2 oz
to start clutch trip lever moving.

2.04 Tape Lid

TAPE LID


To Check

Remove top plate and tape guideplate.
Lubricate before adjustment.

(1) Requirement

With tape lid held against notch in tape guideplate, feed wheel groove lined up with slot in tape guideplate, and tape-out pin holes lined up

Min some---Max 0.010 inch between tape lid and pivot shoulder.



To Adjust

Loosen bracket mounting nuts. Insert tip of appropriate gauge (Note 1) through slot in tape guideplate and into feed wheel groove. Position bracket. Tighten nuts.

Note 1: Use one of the following three gauges in making this adjustment:

TAPE	GAUGE
5-Level	TP156743
6-Level	TP170311 (In-Line Feed Hole)
6-Level	TP173503 (Advance Feed Hole)

(2) Requirement

With front bearing surface of tape lid touching tape guideplate


Min 0.010 inch---Max 0.018 inch between fin indicated and tape guideplate.

To Adjust

Loosen bearing bracket mounting screws. While pressing tape lid against tape guideplate, position bearing bracket. Recheck Requirement (1).

Note 2: If Requirement (2) cannot be met, position bearing bracket so that its mounting screws are located in centers of holes in bracket. Repeat Requirements (1) and (2).

Note 3: When tape guideplate and top plate are assembled to reader, tape lid may touch top plate, and a different clearance from that specified in Requirement (2) can be expected. However, with tape lid closed, there must always be at least 0.002 inch clearance between tape guideplate and heel pad.



(3) Requirement

With tape lid latched against tape guideplate, release plunger must have some endplay.

To Adjust

Loosen locknut. Raise tape lid and rotate high part of eccentric towards bearing bracket. Close tape lid and continue rotating high part of eccentric towards bearing bracket until latch bail just falls under flat on post. Recheck operation of latch bail by depressing release plunger with tape lid held down.

2.05 Tape Lid (continued)

TAPE GUIDE

To Check

Unlatch tape lid and position gauge as illustrated.

(1) Requirement

Min some---Max 0.003 inch between gauge and each tape guide.

(2) Requirement

Edge of wear plate flush with edge of tape guideplate.



(3) Requirement

Tape must not ride up the sides of the tape guides.

To Adjust


Loosen mounting nuts. Position wear plate until it overhangs tape guideplate. Push gauge down until top two studs butt up against tape guideplate thus positioning edge of wear plate flush with edge of tape guideplate. Hold gauge and wear plate and position each tape guide to meet Requirement (1). Tighten mounting nuts.

Note: Tape guides may touch gauge, but they must not bind against gauge when it is removed.



(Bottom View)

2.06 Tape Lid (continued)



(Rear View)

(A) START-STOP DETENT BAIL SPRING

To Check
Place control lever in run position.

Requirement
Min 14 oz---Max 22 oz
to start detent bail moving away from control lever.

(B) TAPE LID RELEASE PLUNGER SPRING


To Check
Unlatch tape lid. Place tape guideplate in a horizontal position and hold it there.

Requirement
Min 28 oz---Max 48 oz
to start tape lid bail moving.

(C) TAPE LID SPRING

To Check
Hold release plunger fully depressed.
Hold tape guideplate in horizontal position.


Requirement
Min 2-1/2 oz---Max 4-1/2 oz
to move open end of tape lid against tape guideplate.



(Right Side View)

SECTION 573-127-703

2.07 Tape Lid (continued)



(Front View)

Note 1: To prevent damage to the tape-out pin, position stop arm to its lowest position and hold control lever bail extension from feed wheel ratchet.

TAPE GUIDEPLATE

(1) Requirement

Feed wheel post is not to interfere with mounting brackets of top plate and tape guideplate.

To Adjust

Loosen clamp nut and rotate feed wheel post.

(2) Requirement

Tape guideplate to rest firmly against a minimum of three of the four projections on side plates.

To Adjust

Rotate unit clutch to its stop position. Trip clutch to put sensing pins in their highest positions. Unlatch tape lid and place control lever to run position. Loosen mounting screws and mounting nuts. Position tape guideplate on reader to meet Requirement (2). Position tape-out pin into hole in tape guideplate. Tighten mounting screws.

Note 2: Mounting nuts loosened in Requirement (2) are tightened after performing Requirement (3) and TOP PLATE (2.08) adjustment.

(3) Requirement

Edge of tape guideplate to project over side plates by equal amounts as gauged by eye.

To Adjust

Position tape guideplate.

Note 3: Tight-tape bail extension must be under top plate.

2.08 Top Plate

TOP PLATE

To Check

Remove cover plate and unlatch the tape lid.

(1) Requirement

Min flush---Max 0.003 inch below top surface of tape guideplate along width of tape lid when top plate is resting on a minimum of five of the six projections on side plates.

To Adjust

Loosen mounting screws and mounting nuts friction tight. Position top plate. Tighten mounting screws. Tighten tape guideplate mounting nuts left friction tight in TAPE GUIDEPLATE (2.07) adjustment.

Note: Mounting nuts loosened in Requirement (1) above are tightened after performing Requirement (2) below.

(2) Requirement

Feed wheel slot to align with slot in tape guideplate so that feed wheel rotates freely with control lever in free position.

To Adjust


Position top plate toward one side plate or the other. Tighten mounting nuts left friction tight in Requirement (1) above.

(3) Requirement

With tape lid latched
 Min 0.010 inch at end of extension covering feed wheel slot
 Min 0.010 inch---Max 0.018 at tape guideplate adjacent to sensing pins
 Min 0.010 inch---Max 0.025 at all other areas
 between tape lid projection and top plate with play taken up toward tape guideplate.

To Adjust

Loosen tape lid bearing bracket mounting screws. Position tape lid. Recheck TAPE LID (2.03) adjustment, Requirements (1) and (2).



2.09 Cover Plate


(A) COVER PLATE

- (1) Requirement
Right edge of cover plate holds flush against left edge of top plate by the cover plate detents.
- (2) Requirement
Cover plate rests against at least three of the four projections (front and rear plate).
- (3) Requirement
Front edge of cover plate and top plate align.

To Adjust

With detenting nut clampscrew (front and rear plate) friction tight, move clampscrews to their extreme lower right position, then tighten screws. Loosen detent bracket and spring plate mounting nuts. Place cover on unit and position horizontally to meet requirements. Retighten mounting nuts.


(Front View)



(B) COVER PLATE DETENT SPRING

Requirement

With spring scale applied to center of one detent
Min 28 oz---Max 48 oz
to start plunger moving.



Note: Outer edge of each mounting bracket should be approximately in line with shoulder of its mounting stud. Replace tape guideplate, tape-out tension spring, top plate, and cover plate.

(Bottom View)

2.10 Tape-Out Switch Assembly

(A) TAPE-OUT CONTACT ASSEMBLY

To Check

Loosen spring bracket and move downward until tape-out pin extension no longer touches insulation on contact swinger.

(1) Requirement


Min 8 grams---Max 15 grams to separate normally closed contacts.

(2) Requirement

Min 0.008 inch---Max 0.015 inch between normally open contacts.

To Adjust

Remove tape-out contact assembly from unit by unhooking tape-out pin spring and removing bracket mounting screws. Form contact swinger using TP110445 spring bender. Replace contact assembly with swinger over tape-out pin extension. Place spring bracket shoulder bushing on upper hole and the washer on lower mounting hole. Rehook tape-out pin spring.



(B) TAPE-OUT SENSING PIN SPRING

To Check


Place control lever in run position.

Requirement

Min 38 grams---Max 45 grams to move tape-out pin to a position flush with tape guideplate.

To Adjust

Loosen lower bracket mounting screw and position spring bracket to meet requirement. Retighten bracket mounting screw.



(C) TAPE-OUT CONTACT BRACKET

To Check


Insert tape under tape lid to hold tape-out pin down.

Requirement

Min 0.006 inch---Max 0.020 inch between tape-out pin upper extension and underside of insulation on swinger contact.

To Adjust

Loosen bracket mounting screws and adjust bracket. Retighten mounting bracket screws.



2.11 Tape-Out Switch Assembly (continued)

(B) DEPRESSOR BAIL TORSION SPRING

To Check

Place control lever in stop position.
Unhook one end of intermediate tape-out bail spring.

Requirement

Min 2-3/4 oz---Max 5-1/2 oz
to start tape-out bail moving away
from tape-out pin depressor bail.

(A) TAPE-OUT SENSING PIN

(1) To Check

Place control lever in stop position.

Requirement

Top of pin to be
Min flush---Max 0.010 inch
below surface of tape guideplate.

To Adjust

Loosen stop arm clampscrew.
friction tight. Position stop arm
to meet requirement. Retighten
clampscrew.

(C) INTERMEDIATE TAPE-OUT BAIL SPRING

To Check

Place control lever in run position.
Unhook intermediate tape-out bail
spring at post end.

Requirement

Min 3 oz---Max 5 oz
to pull intermediate tape-out bail
spring to its installed length.

(2) To Check


Place control lever in run position.

Requirement

Clearance as shown should be
Min 0.055 inch

To Adjust

Loosen tape-out bail clampscrew.
Position extension arm to meet
requirement. Retighten clamp
screw. Recheck requirement under
(1) To Check.



2.12 Tape-Out Switch Assembly (continued)

TAPE-OUT SENSING PIN (For Units Equipped with
Tape Lid Sensing Lever)**To Check**


Hold tape-out pin manually against stop arm.

Requirement

Top of pin to be
Min flush---Max 0.010 inch
below top surface of guideplate.

To Adjust

Loosen switch bracket mounting screws.
Position switch bracket to meet require-
ment. Retighten mounting screws.



(Front View)

2.13 Start-Stop Switch Assembly

(A) START-STOP SWITCH BRACKET

To Check
Place control lever in run position.
Disengage clutch.

(1) Requirement
Min 0.006 inch---Max 0.015 inch
between start-stop bail extension
and insulator on start-stop switch
swinger.

To Adjust
Loosen switch bracket mounting
screws. Position switch bracket
to meet requirement. Retighten
bracket mounting screws.

(2) Requirement
Start-stop bail extension and con-
tact arm to fully engage insulated
portion of start-stop switch
swinger.



To Adjust
Loosen mounting screws and
position start-stop switch swinger
to meet requirement. Retighten
mounting screw.

(B) TIGHT-TAPE START-STOP CONTACT SPRING

To Check
Place control lever in run position.

Requirement
Min 3 oz---Max 4 oz---
to separate contacts.

To Adjust
Bend break contact spring with
TP110445 bending tool. Recheck
START-STOP SWITCH BRACKET
adjustment.



2.14 Tight-Tape Mechanism

START-STOP SWITCH BRACKET (For Units Equipped with Tape Lid Sensing Lever)

To Check

Place intermediate tight-tape arm to center of its adjusting range with the contact arm.

(1) Requirement

Tight-tape start-stop contacts to:

- (a) Remain closed when tight-tape bail is raised 0.045 inch
- (b) Open as bail is raised to 0.075 inch.

To Adjust


- (a) Loosen tight-tape intermediate arm clampscrew. Position pry point midway in contact operating arm adjusting slot. Retighten clampscrew.
- (b) Loosen switch bracket screws friction tight. Position contact pile-up to meet requirement.

(2) Requirement


Contact arm to fully engage insulated part of switch swinger.

To Adjust

Loosen contact pile-up mounting screws. Position contact pile-up mounting bracket. Retighten mounting screws.



(Top View)



2.15 Tight-Tape Mechanism (continued)

(A) TIGHT-TAPE INTERMEDIATE ARM

To Check

Place control lever in run position.


Requirement

Start-stop contacts when tight-tape bail is raised away from tape guideplate:

- (a) Remain closed when bail is raised 0.045 inch.
- (b) Open as bail is raised to 0.075 inch.

To Adjust

Loosen clampscrew and position tight-tape intermediate arm using pry points. Retighten clampscrew.



(B) TIGHT-TAPE INTERMEDIATE ARM SPRING

To Check

Place control lever in run position.

Requirement

Min 20 grams (3/4 oz)---Max 40 grams (1-1/2 oz) to start yield arm moving.

2.16 Feed Wheel Mechanism

(B) FEED RATCHET DETENT SPRING

Requirement

With main shaft in stop position and feed pawl held away from its ratchet

Min 8 oz ---Max 13 oz to start roller moving away from ratchet.


(C) MAIN BAIL TRIP LEVER

Requirement (Replace top plate)

Unit in stop position, clearance between tip of highest sensing pin and top surface of tape guideplate should be flush to 0.005 inch below.

To Adjust

With clutch disengaged, loosen front and rear transfer lever guide eccentric post locknuts. Position highest point of eccentric post (as indicated by dot on end of post) toward left and rotate post so that its eccentric positions trip lever. Tighten locknuts.



(A) MAIN BAIL SPRING

Requirement (Top plate removed)

Clutch disengaged, unit on its back. Spring unhooked from main bail

Min 6 oz ---Max 10 oz to pull spring to installed length.

2.17 Main Bail Mechanism

MAIN BAIL

Requirement


Main bail in lowest position, horizontal clearance between main bail arm and main bail latchlever should be

Min some---Max 0.015 inch

To Adjust

Position main bail eccentric screw with nut on eccentric screw loosened (and high part of eccentric screw to the right). Tighten nut. Check and refine, if necessary,

MAIN BAIL TRIP LEVER (2.16).



2.18 Feed Wheel Mechanism (continued)


(A) SENSING PIN SPRING

To Check

Open tape lid, and disengage unit clutch. Then hold armature in the attracted position to unlatch main bail and place sensing pins in their uppermost position. Hold rub-out deleter bail (if present) away from the sensing pins.

Requirement

Min 3 oz---Max 5 oz
to move each sensing pin flush with tape guide plate.



(Front View)

(B) FEED WHEEL DETENT

To Check

Open tape lid. Disengage the unit clutch to place sensing pins in their lowest position. Place high part of feed wheel ratchet detent eccentric toward the right. With an all marking code combination punched into a new piece of tape, place the tape on the feed wheel and over the sensing pins. Take up play in tape lightly toward the right.


To Adjust

Loosen feed wheel ratchet detent eccentric friction tight and hold feed pawl away from feed wheel ratchet. Rotate feed wheel ratchet detent eccentric, keeping high part of eccentric towards the right.

Note: When unit is used to read chadless spliced tape, the sensing pins should be made to favor the trailing edge of the code hole.

Requirement

Tip of each sensing pin to be centrally located in its code hole.



(Top View)

2.19 Feed Wheel Mechanism (continued)

(A) FEED PAWL

To Check

Remove the top plate. With the high part of the feed pawl eccentric towards the right,* (viewed from rear plate) disengage the clutch to place the sensing pins in their lowest position.


*Left for units equipped with tape withhold mechanism.

Requirement

Min some---Max 0.003 inch between feed pawl and ratchet tooth just engaged.

To Adjust

Loosen feed pawl eccentric locknut, and position feed pawl eccentric. Re-check requirement at four positions on feed wheel ratchet approximately 90 degrees apart.



(B) FEED PAWL SPRING

To Check

Rotate unit clutch to stop position.

Requirement


Min 2 oz---Max 3-1/2 oz to start pawl moving.

2.20 Transfer Mechanism

(A) TRANSFER LEVER SPRING

To Check
Disengage unit clutch.


Requirement
Min 1/2 oz---Max 1-1/2 oz
to start each transfer lever spring
moving.



(Rear View)

(B) LOCKING BAIL SPRING

Requirement
Min 10 oz---Max 14 oz
to pull locking bail spring to its
installed length.



(Front View)

2.21 Transfer Bail

(A) TRANSFER BAIL STABILIZER

- (1) To Check
 Select a **LETTERS** combination.
 Rotate main shaft until #3 transfer lever is on high part of its cam.
 Check clearance between side of transfer bail extension and marking latch.
- (2) To Check
 Select a **BLANKS** combination.
 Rotate main shaft until #3 transfer lever is on high part of its cam.
 Check clearance between side of transfer bail extension and spacing latch.

Requirement
 Clearance in marking and spacing positions should be equal within 0.002 inch.


To Adjust
 Loosen stabilizer assembly mounting screws friction tight, and position the assembly. Retighten assembly mounting screws.

(B) STABILIZER SPRING

To Check
 Rotate clutch to stop position.

Requirement
 Min 2-1/2 oz ---Max 5 oz
 to start stabilizer latch moving.

Note: Latches should drop in place as other transfer levers cam the transfer bail.



2.22 Signal Contacts

(A) SIGNAL CONTACT CLEARANCE

To Check

Remove cover plate and signal contact box cover. Engage the unit clutch and rotate main shaft slowly until spacing contact is fully open. Measure the gap. Continue rotating the main shaft until marking contact is fully open. Measure the gap.

Requirement

Marking and spacing contact gaps measured in To Check to be equal within 0.001 inch.

To Adjust

Loosen mounting screws and position contact box using eccentric.

Note: Before operating, refine SIGNAL CONTACT CLEARANCE adjustment in accordance with Signal Contacts — Electrical.

CAUTION: IF CONTACTS ARE GOLD PLATED, CLEAN THEM BY PARTIALLY DRAWING A STRIP OF TP107162 TWILL JEAN BETWEEN THEM.

(B) DRIVE LINK SPRING

To Check

Trip clutch and rotate main shaft to stop position. Unhook stabilizer spring, and move latches away from transfer bail extension. Hold toggle firmly against spacing contact.

Requirement

Min 6 oz---Max 12 oz to start transfer bail extension moving.


(C) SIGNAL CONTACT SPRING (TRANSMITTER DISTRIBUTOR SETS ONLY)

To Check

Place transmitter in stop position. Remove contact box cover, and toggle drive link spring from its link end. Move transfer bail towards the right (spacing) position, so that both toggle contacts are closed. Hook an 8-oz scale over the pivot screw and pull horizontally to the left.

Requirement

Min 2 oz---Max 3-1/2 oz to open left-hand contact. Replace toggle drive link spring to its link.



(Top View - Right Side)

2.23 Clutch Mechanism (continued)

CLUTCH MAGNET ASSEMBLY (Preliminary)

(1) Requirement

In energized position armature should contact top core face and should have

Min some---Max 0.004 inch

clearance at bottom core face at point of least clearance when play is taken up to make clearance a maximum. (Sets with tape shoe and tape feed assurance mechanisms

Min 0.004 inch---Max 0.007 inch)

To Adjust

Remove magnet bracket mounting screws and magnet assembly from unit. Loosen two screws on bottom of magnet assembly and position mounting hinge until required condition is obtained. Tighten screws.


(2) Requirement

With high part of eccentric toward top of assembly, clearance between armature bail and eccentric backstop when armature is held in energized position should be

Min 0.045 inch---Max 0.055 inch

To Adjust

Loosen eccentric backstop screw clamp nut. With high part of eccentric toward top of assembly, position screw. Tighten clamp nut.



(Rear View)

2.24 Clutch Mechanism (continued)

CLUTCH MAGNET ASSEMBLY (Preliminary) (Continued)

(3) Requirement


With magnet assembly replaced and clutch disengaged, clearance between end of armature bail extension and main bail latch

Min 0.007 inch---Max 0.015 inch

To Adjust

With magnet bracket mounting screws friction tight, move bracket to its lowermost position, then position bracket by means of adjusting lug on bracket (visible through hole in rear plate). Tighten screws. Refine requirements if necessary.

Note: The above adjustments may be considered final unless ac power is used, a check should be made to insure that the chatter is at a minimum. If excessive chatter is present, Requirement (1) will have to be refined and Requirements (2) and (3) rechecked.



2.25 Clutch Mechanism (continued)

CLUTCH MAGNET ASSEMBLY (Preliminary) (Continued)


(4) Requirement

With armature electrically held against its magnet core, clearance between vertical surfaces of the main bail and its latchlever

Min some

To Adjust

With magnet bracket mounting screws friction tight, move bracket to its lowermost position, then position bracket by means of adjusting lug on bracket (visible through hole in rear plate). Tighten screws. Refine requirement if necessary.



MAIN BAIL LATCH SPRING

Requirement

With unit inverted and main bail latch released

Min 3/4 oz---Max 2 oz
to start main bail latch moving.

ARMATURE BAIL SPRING

Requirement

With armature in de-energized position and main bail latchlever held away from the armature bail extension

Min 1 oz---Max 2 oz
(Sets with tape shoe and tape feed assurance mechanisms only)
Min 3-3/4 oz---Max 4-3/4 oz)
to start bail moving.

Signal Contacts — Electrical

2.26 The strobing adjustment procedure is used for checking and adjusting signal contacts electrically, and at the same time, refining the mechanical adjustments for the transmitter distributor. The same procedure is used for checking both the marking and spacing pulses for both 5 and 6 level, and all unit codes. Differences exist, however, in the number, width, and tolerance of pulses, and in the allowable break width. The data appropriate to each level and unit code is tabulated on the associated Pulse Data Table. By following the general procedures given in Paragraphs 2.27 and 2.28 following, and using data from the appropriate table, the marking and spacing pulse adjustment can be made for all units. To illustrate the procedure further, the data appropriate to a 5-level, 7.42 unit code is added parenthetically as an example in the general adjustment procedure following.

Note: Gold-plated signal contacts should not be electrically adjusted unless there is an intermediate device available which, when keyed by the signal contacts, will interrupt the current to the stroboscopic test set. The intermediate device must be capable of being keyed by a 3- to 20-volt change in voltage at a current not in excess of 20 milliamperes. The standard stroboscopic test set operating voltage must not be applied directly to the signal contacts because of the possibility of damaging the contacts' gold plating and thus impairing their operating efficiency in this low-energy level application. (Refer to Paragraphs 1.08 through 1.13.)

2.27 Marking Pulse Adjustments

(a) Plug a signal distortion test set having the appropriate scale (eg, 7.42) into the signal line so that the marking contacts of the transmitter-distributor unit under test will interrupt the current to the stroboscopic lamp within the DXD. Have the transmitter-distributor transmitting "Y" or "R" continuously and the test set and transmitter-distributor operating at the same speed (100 wpm). Rotate the test scale to align the 0-scale mark of the START segment (end of STOP segment) with the end of the stop pulse image indicated by the rotating strobe light.


Note: The end of the stop pulse image should not vary more than one division in

either direction when the scale is positioned so that the variation is centered about the 0-scale mark of the START segment.

(b) Check the position of each of the pulses against the position tabulated. Each pulse should be in its designated segment on the test scale, within the specified tolerance figure (eg, 15 div).

Note: Each marking code pulse may have one break, provided the break is not longer than the allowable break width specified (eg, 1 div) and the break comes within the tolerance range (eg, 5 div) and the end of the pulse.

(c) To adjust, loosen the two contact box mounting screws until they are friction tight. Rotate the eccentric of the contact box mounting bracket toward the right or left until the requirements are met. Tighten the mounting screws and recheck the adjustment.



(Front View)

Note: If these signal requirements cannot be met, refine the TRANSMITTER DISTRIBUTOR GEAR BACKLASH (2.32) adjustment (See BASES) and the TRANSFER BAIL STABILIZER (2.21) adjustment, viewing the signal on the test set.

2.28 Spacing Pulse Adjustments: The general procedure for adjusting the spacing pulse is identical to that outlined for marking pulses. The tolerances for spacing pulses may not be the same as for marking pulses however. Refer to the appropriate Pulse Data Table when making adjustments.

Note: On units equipped with signal regenerators, remove regenerator circuit card before applying test set probes to contact access terminals.

THEM UNSUITABLE FOR LOW-VOLTAGE APPLICATIONS. REFER TO 1.12 FOR SERVICING INSTRUCTIONS.

CAUTION: APPLYING OPERATING VOLTAGE OF DISTORTION TEST SET DIRECTLY TO GOLD-PLATED CONTACTS MAY MAKE

2.29 Follow the general procedure outlined in Paragraphs 2.27 and 2.28 substituting the appropriate data from the following table.

PULSE DATA TABLE
FIVE-LEVEL UNITS, 7.00 UNIT CODE

PULSE	MARKING		SPACING	
	*NOMINAL	TOLERANCE	*NOMINAL	TOLERANCE
STOP PULSE	36 (STOP) TO 142 (STOP)	BEGIN ± 5 DIV END $\pm 1/2$ DIV	36 (STOP) TO 142 (START)	BEGIN ± 6 DIV END $\pm 1/2$ DIV
START PULSE	142 (STOP) TO 6 (ONE)	BEGIN ± 5 DIV END ± 5 DIV	142 (STOP) TO 6 (ONE)	BEGIN ± 6 DIV END -5, +6 DIV
PULSE 1	6 (ONE) TO 12 (TWO)	BEGIN ± 5 DIV END ± 5 DIV	6 (ONE) TO 12 (TWO)	BEGIN ± 6 DIV END -5, +6 DIV
PULSE 2	12 (TWO) TO 18 (THREE)	BEGIN ± 5 DIV END ± 5 DIV	12 (TWO) TO 18 (THREE)	BEGIN ± 6 DIV END -5, +6 DIV
PULSE 3	18 (THREE) TO 24 (FOUR)	BEGIN ± 5 DIV END ± 5 DIV	18 (THREE) TO 24 (FOUR)	BEGIN ± 6 DIV END -5, +6 DIV
PULSE 4	24 (FOUR) TO 30 (FIVE)	BEGIN ± 5 DIV END ± 5 DIV	24 (FOUR) TO 30 (FIVE)	BEGIN ± 6 DIV END -5, +6 DIV
PULSE 5	30 (FIVE) TO 36 (STOP)	BEGIN ± 5 DIV END ± 5 DIV	30 (FIVE) TO 36 (STOP)	BEGIN ± 6 DIV END -5, +6 DIV
ALLOWABLE BREAK WIDTH	1 DIV	MUST FALL WITHIN PULSE TOLERANCE	1 DIV	MUST FALL WITHIN PULSE TOLERANCE

*Ranges specified apply only for test sets (DXD) having a 7.42 unit code scale.

- 2.30 Follow the general provisions outlined in Paragraphs 2.27 and 2.28 substituting the appropriate data from the following table.

PULSE DATA TABLE
FIVE-LEVEL UNITS, 7.42 UNIT CODE


PULSE	MARKING		SPACING	
	NOMINAL	TOLERANCE	NOMINAL	TOLERANCE
STOP PULSE	0 (STOP) TO 0 (START)	BEGIN ± 5 DIV END $\pm 1/2$ DIV	0 (STOP) TO 0 (START)	BEGIN ± 6 DIV END $\pm 1/2$ DIV
START PULSE	0 (START) TO 0 (ONE)	BEGIN ± 5 DIV END ± 5 DIV	0 (START) TO 0 (ONE)	BEGIN ± 6 DIV END ± 6 DIV
PULSE 1	0 (ONE) TO 0 (TWO)	BEGIN ± 5 DIV END ± 5 DIV	0 (ONE) TO 0 (TWO)	BEGIN ± 6 DIV END $-5, +6$ DIV
PULSE 2	0 (TWO) TO 0 (THREE)	BEGIN ± 5 DIV END ± 5 DIV	0 (TWO) TO 0 (THREE)	BEGIN ± 6 DIV END $-5, +6$ DIV
PULSE 3	0 (THREE) TO 0 (FOUR)	BEGIN ± 5 DIV END ± 5 DIV	0 (THREE) TO 0 (FOUR)	BEGIN ± 6 DIV END $-5, +6$ DIV
PULSE 4	0 (FOUR) TO 0 (FIVE)	BEGIN ± 5 DIV END ± 5 DIV	0 (FOUR) TO 0 (FIVE)	BEGIN ± 6 DIV END $-5, +6$ DIV
PULSE 5	0 (FIVE) TO 0 (STOP)	BEGIN ± 5 DIV END ± 5 DIV	0 (FIVE) TO 0 (STOP)	BEGIN ± 6 DIV END $-5, +6$ DIV
ALLOWABLE BREAK WIDTH	± 1 DIV	MUST FALL WITHIN TOLERANCE LIMITS	± 1 DIV	MUST FALL WITHIN TOLERANCE LIMITS

2.31 Follow the general provisions outlined in Paragraphs 2.27 and 2.28 substituting the appropriate data from the following table.

PULSE DATA TABLE
SIX-LEVEL UNITS, 8.50 UNIT CODE

PULSE	MARKING		SPACING	
	RANGE	NOMINAL TOLERANCE	NOMINAL TOLERANCE	NOMINAL TOLERANCE
STOP PULSE	0 (STOP) TO 0 (START)	BEGIN ± 7 DIV END $\pm 1/2$ DIV	0 (STOP) TO 0 (START)	BEGIN ± 8 DIV END $\pm 1/2$ DIV
START PULSE	0 (START) TO 0 (ONE)	BEGIN ± 7 DIV END ± 7 DIV	0 (START) TO 0 (ONE)	BEGIN ± 8 DIV END ± 8 DIV
PULSE 1	0 (ONE) TO 0 (TWO)	BEGIN ± 7 DIV END ± 7 DIV	0 (ONE) TO 0 (TWO)	BEGIN ± 8 DIV END ± 8 DIV
PULSE 2	0 (TWO) TO 0 (THREE)	BEGIN ± 7 DIV END ± 7 DIV	0 (TWO) TO 0 (THREE)	BEGIN ± 8 DIV END ± 8 DIV
PULSE 3	0 (THREE) TO 0 (FOUR)	BEGIN ± 7 DIV END ± 7 DIV	0 (THREE) TO 0 (FOUR)	BEGIN ± 8 DIV END ± 8 DIV
PULSE 4	0 (FOUR) TO 0 (FIVE)	BEGIN ± 7 DIV END ± 7 DIV	0 (FOUR) TO 0 (FIVE)	BEGIN ± 8 DIV END ± 8 DIV
PULSE 5	0 (FIVE) TO 0 (SIX)	BEGIN ± 7 DIV END ± 7 DIV	0 (FIVE) TO 0 (SIX)	BEGIN ± 8 DIV END ± 8 DIV
PULSE 6	0 (SIX) TO 0 (STOP)	BEGIN ± 7 DIV END ± 7 DIV	0 (SIX) TO 0 (STOP)	BEGIN ± 8 DIV END ± 8 DIV
ALLOWABLE BREAK WIDTH	1 DIV	MUST LIE WITHIN TOLERANCE LIMITS	1 DIV	MUST LIE WITHIN TOLERANCE LIMITS

2.32 Basic Gear Adjustments



INTERMEDIATE GEAR — TRANSMITTER DISTRIBUTOR GEAR BACKLASH

(Left Side View)

To Check

With the MOTOR POSITION and TRANSMITTER DISTRIBUTOR POSITION adjustments completed, check the backlash between the gears.

(1) Requirement

Only a perceptible amount of backlash between the intermediate driving gear and the transmitter distributor gear.

To Adjust

Loosen three mounting screws that secure the transmitter distributor unit to its base. Position transmitter distributor to meet the requirement. Retighten the mounting screws.

(2) Requirement

Only a perceptible amount of backlash between the drive gear and the transmitter distributor gear.

To Adjust

Loosen three mounting screws that secure the transmitter distributor to its base. Position transmitter distributor to meet this requirement. Retighten the screws.

3. VARIABLE FEATURES

3.01 Tight-Tape and Tape Shoe Mechanism

(A) TIGHT-TAPE SWITCH

To Check


Place control lever in run position.

Requirement

Min $9/32$ inch---Max $13/32$ inch
to open contacts when tight-tape arm
is raised.

To Adjust


Loosen clampscrew. Using adjusting
slot, position tight-tape intermediate
arm to meet this requirement. Re-
tighten clampscrew.



(B) TORSION SPRING

Requirement

Min 2-1/2 oz
to lift tape shoe.



(C) TAPE SHOE

To Check

Latch tape lid in position. Check
clearance between tape guideplate and
tape shoe.

Requirement

Min 0.005 inch---Max 0.008 inch

To Adjust

Loosen locknut. Rotate adjusting screw
to meet the requirement. Retighten
locknut.

3.02 Tape Feed Assurance Mechanism

(A) TAPE SENSING FEED WHEEL PHASING

To Check
Place fresh, fully perforated tape (10 holes per inch) on tape guideplate across the feed wheel and tape feed assurance wheel. Set detent adjusting lever screw at midrange.

Requirement
Tape must lie flat on tape guideplate between feed wheel and tape feed assurance wheel.

To Adjust
Loosen bracket mounting screws friction tight. Position bracket to meet requirement. Retighten bracket mounting screws. Refine adjustment (if necessary) by rotating the detent lever adjusting screw.

Note: If tape is not available, use TP165800 gauge.

(D) DETENT LEVER SPRING

To Check
Hold contact lever away from detent lever.

Requirement
Min 3 oz---Max 4 oz
to move the roller from the ratchet.

(B) TAPE MOTION CONTACT GAP

To Check
Place detent lever in detented position.

Requirement
Min 0.005 inch---Max 0.010 inch
gap between the normally closed contacts.


To Adjust
Bend contact leaf and stiffener to meet requirement.

(C) TAPE MOTION CONTACT SWINGER

To Check
Hold detent lever from contact swinger.

Requirement
Min 15 grams---Max 25 grams
to separate contacts.

To Adjust
Bend swinger to meet requirement. Recheck TAPE MOTION CONTACT GAP.



(Rear View)

3.03 Tape-Out Mechanism

(A) TAPE-OUT CONTACT

(1) To Check

Loosen contact bracket mounting screws. Pivot contact assembly until pad on tape-out pin extension is not touching the swinger pad. Check gap between normally open (top) contact points.

To Adjust

Bend contact swinger. Recheck requirement under (1) To Check above.

Requirement

Min 0.015 inch---Max 0.025 inch between normally open (top) contacts.

(3) To Check

Hold tape-out pin down. With some clearance between tape-out pin extension and underside of contact swinger, without tape, tape lid closed, and unit in run position, check gap between normally closed contacts.

To Adjust

Bend upper contact spring to meet requirement.

Requirement

Min 0.008 inch---Max 0.018 inch gap between normally closed contacts.

(2) To Check

With assembly still in position, check force required to just separate normally closed (lower) contacts.

To Adjust

With contact bracket mounting screws loosened, adjust contact mounting bracket to meet requirement. Retighten contact bracket mounting screws.


Requirement

Min 8 grams---Max 15 grams to just separate normally closed (lower) contacts.

(B) TAPE-OUT BAIL TORSION SPRING

Requirement

Min 8 oz---Max 12 oz to separate bail from tape-out pin.



3.04 Tape-Out Mechanism (continued)

(C) TAPE-OUT PIN SPRING

To Check
Remove tape and open tape lid.

Requirement
Min 1/2 oz---Max 1 oz
to press pin flush with tape guideplate.


To Adjust
Loosen tape-out spring bracket mounting screw and position bracket to meet requirement. Retighten bracket mounting screw.

(D) TAPE-OUT PIN

To Check
Place control lever in free or stop position. Check position of tape-out pin in relation to tape guideplate.

Requirement
Tape-out pin should be
Min flush---Max 0.010 inch
below surface of tape guideplate.

To Adjust
With control lever in stop position, loosen screw which secures the stop arm to the bracket with posts. Adjust stop arm to meet requirement. Tighten screw.



3.05 Code Reading Contacts

Note 1: Remove code reading contact assembly from transmitter distributor unit before making initial adjustments.

Note 2: When using the contact spring bender, start with the contact pile-up farthest from the handle of the tool and work toward the handle so as not to disturb adjustments already made.

(A) NORMALLY CLOSED CONTACTS — BACKSTOP

Requirement

Lower contact leaves for all levels should be parallel with the mounting plate and in line with one another.

To Adjust

Bend backstop to meet the requirement.

(B) NORMALLY CLOSED CONTACTS — SPRING

(1) Requirement

With swinger held away
Min 2 oz---Max 6 oz
to move lower contact leaf from backstop.

To Adjust

Bend lower leaf.

(2) Requirement


Min 30 grams---Max 40 grams
to open normally closed contacts.

To Adjust

Bend swinger.




Note 3: If it is necessary to bend backstop to obtain required tension, reposition backstop to meet **NORMALLY CLOSED CONTACTS — BACKSTOP** requirement.

UPPER CONTACT LEAF



(Front Views)

MOUNTING PLATE



(C) NORMALLY OPEN CONTACTS — GAP

Requirement

Min 0.010 inch---Max 0.015 inch
gap between normally open contacts.

To Adjust

Bend associated backstop to meet requirement.

(D) NORMALLY OPEN CONTACTS — SPRING

Requirement

Min 30 grams---Max 40 grams
to move normally open contact away from backstop.

To Adjust

Bend upper contact leaf.

Note 4: If it is necessary to bend backstop to obtain required tension, reposition backstop to meet **NORMALLY OPEN CONTACTS — GAP** requirement.

3.06 Code Reading Contacts (continued)

Note: Secondary adjustments should be made with code reading contact assembly installed in the transmitter distributor and with the contact assembly bracket approximately centered in its adjustment range. (Remove contact box to facilitate adjustment.)

(A) CONTACT ASSEMBLY POSITIONING

To Check


Align each swinger with its associated sensing arm. (Gauge by eye.)

Requirement

Swinger to be aligned with its sensing arm.

To Adjust

Loosen screws which mount the contact assembly to the contact bracket. Position the assembly to meet the requirement.



(Front Views)

(B) CONTACT SWINGER — SENSING ARM CLEARANCE

To Check


Place up-stop post out of the way and sensing arms in their uppermost positions. Select a BLANK combination.

Requirement

Min 0.015 inch---Max 0.025 inch gap between contact assembly swinger and insulator on contact sensing arm.

To Adjust

Loosen contact bracket mounting screws. Position bracket to meet the requirement. Tighten contact bracket mounting screws.



3.07 Code Reading Contacts (continued)

(A) CONTACT SENSING ARM — UP-STOP CLEARANCE

To Check


Rotate main shaft until sensing arms are in their highest positions. Engage clutch. Select a LETTERS combination.

Requirement

Min some---Max 0.008 inch clearance between upper contact leaf and its backstop.

To Adjust

Loosen nut that secures the eccentric up-stop to the front plate. Turn the eccentric to meet requirement. (High part of the eccentric should be toward the left.) Retighten eccentric nut.



(B) SENSING ARM — TRANSFER LEVER ALIGNMENT

To Check


Trip clutch. Select BLANK combination.

Requirement

Sensing arms must engage a minimum of 2/3 of their respective transfer levers.

To Adjust

Add TP8896 shims between plate assembly and the split bail spacer to meet requirement. (Store remaining shims under flat washer at end of split bail eccentric screw.)



(C) SENSING ARM SPRING

To Check

Disengage clutch.

Requirement

Min 2-1/2 oz---Max 3-1/2 oz to start sensing arm moving.

(D) SPLIT BAIL ECCENTRIC

To Check

Trip clutch. Select BLANK combination. Check clearance between closest transfer lever and its associated sensing arm.

Requirement

Min 0.005 inch---Max 0.010 inch

To Adjust

Loosen split bail eccentric locknut. Rotate split bail eccentric to meet requirement. Retighten locknut.

3.08 Code Reading Contacts (continued)

CONTACT SWINGER — SENSING ARM
CLEARANCE (STROBING)

Note 1: When strobing the code reading contacts, use a DXD scale whose unit corresponds to that of the unit being checked. Refer to Contact Operating Requirements Table. The signal generator on the transmitter distributor must be synchronized with the DXD so that the end of the stop pulse image is in line with the end of the stop pulse on the DXD scale when transmission is continuous. Use a normal signal line direct current of 60 ma $\pm 10\%$ or 20 ma $\pm 10\%$ to strobe the contacts.

(1) Requirement

Contacts must open and close within the range specified on the Contact Operating Requirements Table.

(2) Requirement

Breaks in the pulses must be confined to the first and last 10 divisions of the trace.

CONTACT OPERATING REQUIREMENTS TABLE

Levels	Unit Code	Beginning Pulse			End of Pulse			Max. Pulse Length Osc (Div)
		Scale Segment	Scale Division	Tolerance (Div)	Scale Segment	Scale Division	Tolerance (Div)	
5	7.00	Pulse 1	25	± 20	Pulse 5	15	± 20	3
5	7.42	Pulse 1	30	± 20	Pulse 5	40	± 20	3
6	8.50	Pulse 0	45	± 25	Pulse 5	5	± 25	4

To Adjust

Loosen contact bracket mounting screws.
Position bracket to meet requirements.
Retighten contact bracket mounting screws.

Note 2: After making the adjustment, check clearance between contact swinger and insulator on the contact sensing arm when a BLANK combination has been selected and the main shaft rotated to place the sensing arms in their highest position. There must be some clearance. If the requirements cannot be met, recheck initial mechanical adjustments.

3.09 Auxiliary Contacts

Note: Make initial adjustments with the auxiliary contacts removed from the transmitter distributor unit.


(A) NORMALLY OPEN CONTACTS

(1) Requirement
Min 5-1/2 oz --- Max 6 oz
to move normally open contact
away from stiffener.

To Adjust
Bend normally open contact leaf
to meet requirement.

(2) Requirement
Min 0.015 inch --- Max 0.020 inch
gap between normally open contacts.

To Adjust
Bend contact stiffener to meet
requirements.



(Front View)

(B) NORMALLY CLOSED CONTACTS

Requirement
Min 4 oz --- Max 5 oz
to open normally closed contact.

To Adjust
Bend swinger contact to meet re-
quirement.

3.10 Auxiliary Contacts (continued)


Note: Make secondary adjustments with the auxiliary contacts installed in the transmitter distributor.

(A) CONTACT SENSING ARM

- (1) To Check
Disengage and latch clutch. Check clearance between insulator on swinger and bail.

Requirement
Swinger insulator should be centrally located with respect to its operating bail.

To Adjust
Loosen contact assembly screws. Position swinger and contact springs. Retighten contact assembly screws.



(Front View)

- (2) To Check
Check position of swinger with respect to its bail.

Requirement
Min 0.040 inch — Max 0.050 inch between insulator on swinger and its bail.

To Adjust
Loosen contact bracket mounting screws. Position contact bracket to meet requirement. Retighten contact bracket mounting screws.

(B) AUXILIARY CONTACT OPERATING BAIL SPRING

- To Check
Disengage clutch.

Requirement
Min 5 oz --- Max 7 oz to pull spring to its installed length.

3.11 Auxiliary Contacts (continued)

CONTACT SWINGER — OPERATING BAIL
CLEARANCE

Note: When strobing the auxiliary contacts, use a DXD scale whose unit code corresponds to that of the unit being checked. (Refer to Contact Operating Requirements Table.) Synchronize the signal generator of the transmitter distributor with the DXD so that the end of the stop pulse image is in line with the end of the stop pulse on the DXD scale when transmission is continuous. Use normal direct current line signal of 60 ma $\pm 10\%$ or 20 ma $\pm 10\%$ to strobe the contacts.

Requirement

The contacts must open and close within the range specified in the Contact Operating Requirements Table.


To Adjust

Loosen the contact bracket mounting screws. Position the contacts to meet the requirements. Retighten contact bracket mounting screws.

CONTACT OPERATING REQUIREMENTS TABLE

Levels	Unit Code	Start of Pulse			End of Pulse		
		Scale Segment	Scale Division	Tolerance (Div)	Scale Segment	Scale Division	Tolerance (Div)
5	7.00	Pulse 1	65	± 15	Pulse 4	65	± 15
5	7.42	Pulse 1	75	± 15	Pulse 4	90	± 15
6	8.50	Pulse 1	0	± 20	Pulse 4	60	± 20

3.12 Tape Lid Sensing Lever



(A) SWITCH LEVER SPRING

To Check
Open tape lid.

Requirement
Min 20 grams---Max 35 grams
to separate the switch lever from the
contact swinger pad.

(B) SWITCH LEVER

To Check
Open tape lid. Depress the tape-out
sensing pin.

Requirement
Min 0.005 inch---Max 0.015 inch
between the normally closed tape-out
switch contacts.

To Adjust
Loosen the adjustment screw. With the
tape lid sensing lever seated firmly
against the tape guideplate, rotate the
switch lever clockwise or counter-
clockwise to meet requirement. Re-
tighten adjustment screw.

3.13 Tape Deflector

(A) TAPE DEFLECTOR BRACKET

To Check


Check position of deflector tang in relation to its hole in top plate when the unit is in its operating position.

Requirement

Deflector tang should be located centrally in its hole in the top plate.

To Adjust

Remove rear screw which secures tape deflector spring to the cover plate. Loosen forward screw. Position tape deflector. Replace rear screw, and tighten both forward and rear screws.



(B) TAPE DEFLECTOR SPRING

Requirement

Min 1-1/2 oz---Max 4 oz
to start the deflector moving from its operating position.

To Adjust

Loosen mounting screw. Position the spring using the enlarged mounting slot. Retighten mounting screw.

3.14 Start-Stop Pulse Contact

(A) CONTACT LEVER

To Check


Remove contact assembly from unit.
 Insure that no clearance exists between the contact lever and insulator.

Requirement

Min 20 grams---Max 30 grams to move insulator from contact operating lever.

To Adjust

Bend lower contact spring.



(B) CONTACT GAP (START AND STOP CONTACTS)

Requirement

Min 0.012 inch---Max 0.018 inch

To Adjust

Bend upper contact spring.

(Front Views)

(C) CONTACT BRACKET

To Check


Place unit in stop position. Latch clutch. Check clearance between contact operating lever and transfer lever.

Requirement

Min 0.012 inch---Max 0.018 inch

To Adjust

Loosen mounting bracket screws. Position contact assembly to meet requirement. Retighten mounting bracket screws. Replace contact assembly in unit.



3.15 Start-Stop Pulse Contact (continued)

CONTACT BRACKET (STROBING)

Note 1: When strobing auxiliary contacts, use a 7.42 unit DXD scale. Synchronize the signal generator of the transmitter distributor with the DXD so that the end of the stop pulse image is in line with the end of the stop pulse on the DXD scale when transmission is continuous. Use normal signal line direct current of 60 ma \pm 10% or 20 ma \pm 10% to strobe the contacts.

Requirement
 Contacts must close within the following range.


	MIN CLOSURE	CLOSURE RANGE
STOP CONTACT	95 DIV	0 DIV OF STOP SEGMENT TO 142ND DIV OF STOP SEGMENT
START CONTACT	60 DIV	122ND DIV OF STOP SEGMENT TO 95TH DIV OF START SEGMENT

Note 2: Breaks are permissible within 5 divisions of the beginning or end of a trace.

To Adjust
 Loosen contact bracket mounting screws. Position the contact bracket to meet requirements. Retighten contact bracket mounting screws.

3.16 Rub-Out Deleter

(A) RUB-OUT DELETER BAIL GUIDE



To Check

Place sensing pins in their highest position. Check that deleter bail moves freely in its guide.

Requirement

When the rub-out permutation code is present, the rub-out deleter bail should rest against the lower projection of the sensing pin.

To Adjust

Loosen mounting screws friction tight. Position deleter bail guide. Retighten mounting screws.


(B) SENSING PIN SPRING

To Check

Place sensing pin in its highest position. Hold rub-out deleter bail away from the pin.

Requirement

Min 3 oz---Max 5 oz
to move pin flush with tape guide.



(C) RUB-OUT DELETER BAIL SPRING

To Check

Place sensing pin in highest position.

Requirement

Min 1 oz---Max 2-1/2 oz
to move bail away from the sensing pin.

3.17 Tape Notch Sensing Mechanism

(A) TAPE NOTCH SENSING PIN SPRING

To Check

Place sensing pin in highest position.

Requirement

Min 1 oz --- Max 3 oz
to push sensing pin flush with surface
of top plate.

(B) TAPE NOTCH SENSING CONTACT

(1) To Check

Check the location of the insulator
with relation to the extension on
sensing pin.

Requirement

Insulator on swinger should be
centrally located with respect to
the extension on sensing pin.

To Adjust

Loosen contact assembly mounting
screws. Position contact assem-
bly to meet requirement. Re-
tighten mounting screws.

(2) To Check

Place sensing pin flush with top
plate. Check clearance between
sensing pin extension and insula-
tor of contact swinger. Check
gap between normally open contacts.

Requirement

Min 0.008 inch --- Max 0.015 inch

To Adjust

Bend swinger to meet require-
ment.

(3) To Check


Hold sensing pin extension away
from swinger.

Requirement

Min 8 grams --- Max 15 grams
to just separate normally closed
contacts.

To Adjust

Bend lower contact spring to
meet requirement.



3.18 Tape Notch Sensing Mechanism (continued)

CONTACT BRACKET (STROBING)

Note: When using the tape notch sensing contacts, use a 7.42 unit DXD scale. Synchronize the transmitter distributor so that the end of the stop pulse image is in line with the end of the stop pulse on the DXD scale when transmission is continuous. Use a normal direct current line signal of 60 ma $\pm 10\%$ or 20 ma $\pm 10\%$ to strobe these contacts.

(FOR UNITS WITH TAPE SLACK ARM)

(1) Requirement

The contact should open no earlier than the 15 mark of the first pulse and open no later than the 55 mark of the first pulse.

(2) Requirement

The contact should close no earlier than the 15 mark of the fifth pulse and close no later than the 55 mark of the fifth pulse.

(3) Requirement

Contact breaks will be permitted between the 15 mark and the 55 mark of the fifth pulse. The magnitude of the breaks must not extend beyond these limits.

To Adjust

Loosen bracket contact mounting screws. Position contact bracket to meet requirements. Retighten mounting screws.

(FOR UNITS WITHOUT TAPE SLACK ARM)

(1) Requirement

The contact should close no earlier than the 15 mark of the first pulse and close no later than the 55 mark of the first pulse.

(2) Requirement

The contact should open no earlier than the 15 mark of the fifth pulse and open no later than the 55 mark of the fifth pulse.

(3) Requirement

Contact breaks will be permitted between the 15 and 55 marks of the first pulse. The magnitude of the breaks must not extend beyond these limits.

To Adjust

Loosen bracket contact mounting screws. Position contact bracket to meet requirements. Retighten mounting screws.

3.19 Transmitter Stop Mechanism

(A) START-STOP CONTACT GAP (FOR TABULATOR CONTROL)

To Check


Place timing bail on lower part of its cam. Check start-stop contact gap.

Requirement

Min 0.018 inch---Max 0.025 inch

To Adjust

Loosen clampscrew securing yield arm to timing arm friction tight. Position timing arm to meet requirement. Retighten clampscrew.



(Rear View)

(B) TIMING BAIL SPRING

Requirement

Min 5-1/2 oz---Max 8 oz
to start the bail moving.

3.20 Tape Slack Arm

TAPE SLACK CONTACTS

To Check


Close tape lid. Place control lever in run position. Check clearance between contacts when tape slack arm is raised to its maximum height.

Requirement

Min 0.010 inch---Max 0.020 inch

To Adjust

Loosen clampscrew. Set contact gap by positioning pry points. Retighten clampscrew.



(Rear View)

3.21 Tape Withhold Mechanism

(A) MAGNET ARMATURE GAP

To Check


With the armature attracted, check the gap between the end of the armature adjusting screw and the plate.

Requirement

Min 0.025 inch---Max 0.035 inch

To Adjust

Loosen armature adjusting screw locknut friction tight. Rotate adjusting screw to meet requirement. Retighten locknut.



(B) BLOCKING BAIL ARM ECCENTRIC

To Check

Place sensing pins in their lowest position. Place high part of block bail arm eccentric pivot to right at approximately the same angular position as the feed pawl eccentric.

Requirement

some clearance between the extension on the blocking bail and the tail of the feed pawl.

To Adjust

Loosen arm eccentric clampscrew. Rotate arm eccentric to meet requirement. Retighten clampscrew.

(C) BLOCKING BAIL ECCENTRIC PIVOT

To Check

Trip clutch. Hold armature attracted. Hold main shaft latched in stop position. Check clearance between blocking bail extension and feed pawl at closest point.

Requirement

Min 0.002 inch---Max 0.035 inch


To Adjust

Loosen eccentric pivot clampscrew friction tight. Rotate eccentric pivot to meet requirement. Retighten clampscrew.

Note 1: Check BLOCKING BAIL ARM ECCENTRIC adjustment, and refine if necessary.

Note 2: As a final check on this adjustment there should be some---to---0.015 inch clearance between the feed pawl and the feed ratchet at the closest point, as the feed pawl is cammed out of the ratchet during the blocking operation (magnet armature attracted). If necessary, refine BLOCKING BAIL ARM ECCENTRIC and BLOCKING BAIL ECCENTRIC PIVOT adjustments to meet this requirement.

(Front Views)



4. EARLY MODELS

4.01 Tape Lid Mechanism

Note: Remove top and tape guideplate. Lubricate before adjustment.

TAPE LID

(1) To Check

Hold tape against notch in tape guideplate. Align feed wheel groove in tape lid with slot in plate. Align tape-out pin hole in plate tape lid with hole in plate. Check clearance between tape lid and pivot shoulder.

Requirement

Min some---Max 0.010 inch clearance between tape lid and pivot shoulder.

To Adjust

Loosen tape lid mounting nuts friction tight. Insert tip of TP156743 gauge through slot and into groove of lid. Position tape lid bracket. Retighten nuts.

(2) To Check

Tape lid front bearing surface should rest squarely against tape guideplate. Check rear bearing surface clearance.

Note: When both plates are assembled on unit, left edge of lid may touch top plate and some change in this clearance may be expected.

Requirement

Min some---Max 0.003 inch clearance between rear bearing surface and tape guideplate.

To Adjust

Loosen tape lid bracket mounting screws friction tight. Press tape lid against tape guideplate. Position bracket. Recheck requirement. Retighten bracket mounting screws.

(3) To Check


Latch tape lid against tape guideplate. Check release plunger for endplay.

Requirement

Some endplay when lid is latched against tape guideplate.

To Adjust

Loosen eccentric mounting post lock-nut friction tight. Raise tape lid. Rotate high part of eccentric toward tape guideplate. Close lid and rotate eccentric toward bracket until latch just falls under flat on post. Recheck by depressing plunger. With lid held down operate plunger. Tip of latch should clear post.



4.02 Tape Lid (continued)


TAPE LID RELEASE PLUNGER SPRING (For Units without
Tape Lid Spring)

To Check

Hold tape guideplate horizontally. Unlatch
tape lid.

Requirement

Min 28 oz---Max 48 oz
to start tape lid bail moving.



(Right Side View)