

ADDITION TO BULLETINS

Bulletin 127, Issue 3, Type Bar Tape Printer (Model 14) , Page 36
Bulletin 137, Issue 2, Typewheel Tape Printer (Ticker), Page 29
Bulletin 138, Issue 5, Type Bar Page Printer (Model 15), Page 50
Bulletin 141, Issue 3, Transmitter, Page 18
Bulletin 147, Issue 2, Single Magnet Reperforator, Page 14
Bulletin 159, Issue 2, Typewheel Page Printer (Model 26), Page 36
Bulletin 160, Issue 1, Type Bar Printer (Model 20), Page 38
Bulletin 170, Issue 1, Multiple Transmitter Distributor and Base, Page 9
Bulletin 171, Issue 2, Typing Reperforator, Page 22
Bulletin 175, Issue 1, Single Unit Transmitter and Base, Page 8
Bulletin 176, Issue 1, Translator Unit, Receiving Distributor and Pane, Page 8
Bulletin 178, Issue 1, Reperforator Transmitter Distributor, Page 36
Bulletin 182, Issue 1, Multiplex, Start-Stop Extensor Set, Page 22
Bulletin 183, Issue 1, Portable Signal Distortion Test Set, Page 5
Bulletin 185, Issue 1, Multiple Transmitter Distributors and Base, Page 12
Bulletin 186, Issue 1, Two Channel Start-Stop Transmitter Distributor, Page 20
Bulletin 189, Issue 1 XD79 and XD95 Distributors, Page 15
Bulletin 192, Issue 1, Teletype Automatic Wheatstone Perforator Set, Page 19
Bulletin 193, Issue 1, Reperforator Transmitter Distributor (Model 14), Page 9
Bulletin 197, Issue 1, Multiple Reperforator Set, Page 25

Add the following adjustment immediately preceding the "SPEED
ADJUSTING WHEEL FRICTION WASHER SPRING TENSION ADJUSTMENT":

ADJUSTMENTS FOR ALIGNMENT AND SQUARENESS OF GOVERNOR CONTACTS

All governor contacts can be adjusted for alignment of edges; only those governor shells which provide elongated mounting holes for the fixed contact bracket permit adjustment of the contact for height by positioning the contact bracket.

The governor contacts should be in line and meet squarely so that maximum contact surface is provided. (Check with the retractile spring tension Adjusted so that the contacts just make, or the the limit of the adjusting screw).

- (a) Line up edges of contacts by means of the floating contact hinge mounting screw.
- (b) Adjust contacts for squareness from right to left by positioning the height of the fixed contact bracket using the elongated mounting holes in the governor shell.
- (c) To adjust from front to back, twist the floating contact hinge, applying pressure to the arm near the contact.

NOTE: Check by use of a .002" gauge (smaller if available). Check with gauge between edges of contacts to see that the gauge enters (or does not enter equally on all sides.

* * *