



- NOTES**
- FOR ACTUAL WIRING DIAGRAMS AND REQUIRED PARTS LIST, REFER TO THE POLAR ADAPTER MANUAL, FORM NO. 4403 WD.
 - IN ORDER TO USE THE POLAR ADAPTER, DISCONNECT THE INTERFERENCE AND INSERT THE POLAR ADAPTER CONTACT. SEE SECTION FOR TYPICAL ARRANGEMENT.
 - FOR MOUNTING TO THE UNIT, INSERT THE 182447 CONNECTOR OF THE MOTOR CABLE ASSEMBLY INTO THE MOTOR CABLE ASSEMBLY IN PLACE OF THE MOTOR CABLE ASSEMBLY. NORMALLY, THE MOTOR CABLE ASSEMBLY IS USED WITH THE MOTOR. TO THE MOTOR.
 - CONNECT THE 181730 ASSEMBLY IN PLACE OF THE 181730 CONNECTOR AND THE 181730 AUXILIARY POWER SUPPLY IS NOT USED.
 - USE THE FOLLOWING FUSES:

| MOTOR | NEUTRAL | POLAR |
|-------------|-------------|-------------|
| 181730 (1A) | 181730 (1A) | 181730 (1A) |
| 181730 (1A) | 181730 (1A) | 181730 (1A) |
 - ON MACHINES EQUIPPED WITH FEED OFF USE FEED CABLE ASSEMBLY (MOTOR HOLD AND FEED CABLE ASSEMBLY (LOW FORM)).
 - INDICATES COMMON RETURN WIRE.
 - ALL VOLTAGES D.C. UNLESS OTHERWISE SPECIFIED.
 - ALL RESISTOR VALUES IN OHMS UNLESS OTHERWISE SPECIFIED.
 - ALL CAPACITOR VALUES IN MICROGRAMS UNLESS OTHERWISE SPECIFIED.
 - APPROPRIATE FUSE IN FEED FUSE HOLDER NOT INCLUDED IN EARLY SETS.
 - READER TRIP MAGNET RESISTANCE CHANGED FROM 330 Ω TO 750 Ω FOR IMPROVED OPERATION.

7083 WD

| ISSUE | DATE | AUTH. NO. |
|-------|----------|-----------|
| 1 | 6-2-64 | 18773-R |
| 2 | 12-15-64 | 18773-R |
| 3 | 6-21-65 | 67341 |
| 4 | 1-13-66 | 188473 |
| 5 | 3-9-66 | 18773-2 |
| 6 | 7-12-67 | 194237 |
| 7 | 1-23-69 | 18773 |
| 8 | 9-1-70 | 928-RC |

DATE 3-23-64
 P.D. FILE NO 1-96133 AA
 DRAWN L.J.F. CHKD
 ENGR. W.J. KAPPE
 TELETYPE CORPORATION
7083WD