

INSTRUCTIONS FOR INSTALLING THE 197941 MODIFICATION  
KIT TO PROVIDE OVER-LOAD SUPPORT TO THE ACCUMULATING  
SHELF IN LAC CABINETS

1. GENERAL

a. The 197941 Modification Kit, when installed on an LAC Cabinet equipped with a suspended form accumulating shelf will prevent the unit from tipping backwards under certain cabinet conditions and when a large amount of paper is present on the form accumulating shelf.

b. The 197941 Modification Kit consists of:

1 197915 Support, Accum. Shelf    2 197940 Nut, Lock

c. For parts ordering information see Teletype Model 28 Parts Bulletin 1149B.

2. INSTALLATION

a. Remove the two rear leveling bolts from the cabinet.

b. Assemble the 197915 Support to the two leveling bolts using the two 197940 Lock Nuts. The head of the leveling bolt must be located on the outside of the "U" form of the support as viewed from the side.

c. Assemble the overload support, with leveling legs and lock nuts, to the cabinet, adjust the leveling bolts and lock the support with the lock nut.

\*

\*

\*

**RTTY ELECTRONICS**  
**TELETYPE=Sales-Service-Parts**  
**PO Box 20101 El Sobrante, Ca.**  
**94820. (510)222-3102**  
**mr\_rtty@pacbell.net**

Printed in U.S.A.