## INSIDE WIRING CABLE CLAMPS

## 1. GENERAL

**1.01** Inside wiring cable clamps (Fig. 1) are used to support inside wiring cables and station wires.




Fig. 1 - Inside Wiring Cable Clamps

- **1.02** Cable clamps are secured by means of a fastener placed through a centrally located mounting hole. The recommended fastener for securing cable clamps to various surfaces is covered in Plant Series Section 461-200-210.
- **1.03** Table A contains clamp size, finish, wire capacity, and diameter of mounting hole.

TABIFE A

Size No.	Finish	Diameter of Mounting Hole (in.)	For Cable Capacity (pr)
3	Ivory or Light olive gray	5/32	For Station Wire
5	Ivory or Light olive gray	5/32	6-16
6	Light olive gray	7/32	21-25
8	Light olive gray	7/32	50
10	Light olive gray	7/32	75
12	Light olive gray	7/32	100