

CHANGES AND ADDITIONS
BULLETIN NO. 1094 (ISSUE 2)
PARTS - TYPE BAR PAGE PRINTER (MODEL 15)

THE INFORMATION CONTAINED IN THIS CORRECTION SHEET APPLIES TO
PRINTERS USED FOR SHIPBOARD OPERATION ONLY

Page 13

The 74504 base and the 74618 base plate have been replaced by a 103378 base and a 103163 base plate respectively. These latter parts have additional mounting holes to secure the unit on rubber mountings that are fastened to a metal table.

The 103378 base is wired in accordance with wiring diagram W.D.-1481 (For BB43) and W.D.2143 (For BB51).

The four 6745 screws and four 2669 lock washers, used to mount the base plate to the base, have been replaced by eight 6035 screws and eight 2449 lock washers.

A 103746 resistor (5 ohms) has been added to the top left side of the base near the terminal block and is mounted by means of an 81596 screw, 2669 lock washer, 3438 washer and two 81836 washer-bakelite.

Page 14

The two 6810 screws, two 2669 lock washers and two 3438 washers shown at the top of the 99816 relay base and the two 74014 screws, shown at the bottom of the 99816 relay base have been replaced by four 104077 studs.

Two 104078 relay clamp brackets have been added to the 99816 relay base, and are slipped over the protruding ends of the afore-mentioned 104077 studs, and held in place by two 84354 washers - large (bottom only), four 7002 washers - small, four 2191 lock washers and four 3598 nuts.

Page 20

The C105 cover (assembly) - black wrinkle has been replaced by a C148 cover (assembly) - black wrinkle. The C148 cover (assembly) has a 97911 knob, 34432 washer and an 80516 cotter pin added on each side, which are used to secure the cover to a metal table.