

Flesher Corporation

507 Jackson • P.O. Box 976 • Topeka, Kansas 66601 •

T U - 3 0 0 A F S K

INSTALLATION INSTRUCTIONS

- () Remove the two 8-32 X 3/8" screws on each side of rear chassis sides.
- () Remove the inter-chassis from the outer cover and lay cover aside.
- () Remove the two 6-32 X 1/4" flat head screws on each side of the inter-chassis that secure the circuit board bracket.
- () Install the AFSK board onto the MAIN CIRCUIT board position marked 'AFSK'.
- () The AFSK is factory tested and requires no alignment. Final adjustment of the AFSK GAIN trimer must be made according to your transmitter audio input requirements (and VOX requirements if used). Make this adjustment with your transmitter microphone gain set at either its normal setting or at mid-range. Adjust the AFSK gain for normal transmitter output.

CAUTION: Make sure you do not lay the chassis on a metal surface, or have metal objects laying under the unit during these adjustments.

- () After alignment, re-assemble in reverse order.

*CHECK THIS SETTING FOR
YOUR REQUIREMENTS*