

How did you fix it ? ?

**Let the CEMB hear from
YOU!!! NOW!!**



We like to think of the C.E.M.B. as a cooperative enterprise of all its readers. We make this statement because the best and most useful information we can publish is the news which our readers send in. When you think of the thousands of skilled Naval technicians who are working on electronic maintenance problems all over the world, you can readily imagine what a tremendous source of practical experience this is.

Every day someone is thinking of a new trick which makes his job easier, a new procedure which prevents breakdowns, or a stubborn trouble which was finally licked. Don't keep this to yourself but send it in, so that others can benefit by your ideas. If it will make things simpler, just tear out the form on the next page and jot down your ideas in longhand. Don't forget to include sketches and photographs if possible, but however you send it in, let the C.E.M.B. hear from you.

4/8/54
Complete except
for JAG:101
a. Bolter

RESTRICTED

COMMUNICATION EQUIPMENT MAINTENANCE BULLETIN

SUPPLEMENT No. 38

JULY 1952

WASHINGTON, D. C.

IMPORTANT NOTICE.—This Bulletin contains information essential for the proper maintenance of communication equipment. **This Bulletin should therefore be placed in the hands of maintenance personnel** for immediate action, information, and for use as a reference book.

This is the **thirty-eighth** supplement to the **Communication Equipment Maintenance Bulletin (Navships 900,020A)**.

BUREAU OF SHIPS • NAVY DEPARTMENT

RESTRICTED
SECURITY INFORMATION

Restricted

INSTRUCTIONS FOR INSERTING THIS SUPPLEMENT IN THE CEMB

1. Replace introductory pages v through viii. (Includes title page, list of effective pages, and these instructions.)
2. Replace Table of Contents (pages ix through xxviii).
3. Replace pages:
 GEN: 171-172
4. Insert new page:
 AN/URA: 1
5. Replace pages:
 MISC: 49-50
6. Insert new pages:
 MISC: 51-56

Restricted

LIST OF EFFECTIVE PAGES

Page number	Issue	Page number	Issue	Page number	Issue
Title page	B	DAS:		RAS:	
Promulgating letter ii	B	1-20	5	1-4	B
Cartoon iii	B	21-22	29	5-6	4
Sample form letter iv	B	23-28	31	101	6
Supplement title page	38	101-102	6	RAU:	
Instr. for inserting suppl. vi	38	103	25	1-2	10
List of effective pages vii-viii	38	DAU:		3-4	14
Table of contents ix-xxvii	38	1	26	5-8	13
Gen:		101	B	101	14
1 and 2	3	DBE: 1	22	RBA:	
3-4	36	DBM:		1-3	7
5-6	35	1-2	21	101-102	14
6A	29	3-4	35	RBB:	
7-10	22	5	36	1-3	7
11-14	35	101	14	101-102	28
15-44	B	LM:		RBC:	
45-46	33	1-2	13	1-2	7
47-48	32	101	13	3-4	28
49-52	B	LP: 1	9	101	28
53-54	18	LR:		RBG: 101	B
55	35	1-3	1	RBH:	
56-58	Deleted	101-102	B	1-2	2
59-60	35	103	14	101	14
61-64	1	LAF: 1	27	RBL: 1	31
65-66	2	LRN: 1	B	RBL:	
67-70	3	MN: 101-102	18	1	10
71-72	4	MO: 1	B	101	3
73-74	5	MR: 1-2	B	RBM: 1-2	24
75-76	20	MS: 1	B	RBO:	
77-78	19	MAA: 1	B	1-2	28
79-90	14	MAK: 1	B	101-102	27
91-92	17	MAM: 1	B	RBS: 1	18
93-94	35	MAN: 1-2	3	101	14
95-96	19	MAN: 101	6	RBU: 1	B
97-98	20	MAR:		RCF: 1	B
99-104	22	1-2	19	RCH:	
105-108	28	3-4	21	1	8
109-110	35	5-6	23	101	14
111-114a	34	7	34	RCK:	
115-122	29	MBF:		1-2	31
123-132	30	1-2	12	3-4	8
133-134	32	3-4	19	5-7	27
135-136	30	MBK: 1	B	101	28
137-140	31	OD:		RDC: 1	31
141-156	30	1	B	RDJ:	
157-166	31	101	B	1-3	10
167-168	32	OF:		101	14
169-170	33	1-2	B	RDM: 1	33
171-172	38	3-4	32	RDO: 1-2	37
ANT:		101	B	RDP: 1-2	9
1-4	B	OQ: 1	31	RDR: 1	21
5-6	11	OZ:		RDZ:	
7-10	B	1	34	1-2	17
11-12	25	101	B	3-4	28
13	34	OAL: 1	B	5-7	37
INT: 1-15	B	OCL: 1	21	101	33
DP:		RU: 1	B	REA: 1	9
1	B	RAH: 101	14	REK: 1	19
101	3	RAH: 101	B	REM: 1-2	31
DAB: 1	B	RAK/RAL:		TU: 101	B
DAE:		1-2	8	TAB: 1	25
1-2	B	3-4	27	TAJ:	
101	B	101-102	5	1	27
DAK/DAQ:		RAK/RAL: 103	20	101-102	14
1-3	26	RAQ:			
101-102	B	1	31		
103-104	11	101-102	14		

¹ Letters reversed in page number.

Restricted

LIST OF EFFECTIVE PAGES—Continued

Page number	Issue	Page number	Issue	Page number	Issue
TAQ: 101	<i>DONT HAVE</i>	TDE:		AN/ARC—Continued	
TBA:		1-2		17-21	37
1-3	8	3 (4 is blank)	B	101	17
101	B	5-6		AN/FGC: 1-2	32
TBK:		7-9		AN/FMQ: 1	11
1-4	20	101-102	B	AN/GMQ: 1	25
5-6	8	103-104		AN/SGC: 1	37
7-10	12	105-107		AN/SPA:	
11-12	28	TDG: 1	29	1	1
101-102	31	TDH:		101	4
TBL:		1-2		AN/SPR: 1-2	31
1-2	33	3-4		AN/TRC: 1	B
3	34	5		AN/CPM: 1	22
101-102	B	TDN: 1-2	32	AN/URA: 1	38
103-106	28	TDO: 1	18	AN/URD: 1	32
107	31	TDP: 1	20	AN/URM: 1	37
TBM:		TDQ:		AN/URR: 1	36
1-2	9	1-4	9	BA: 1	22
3	28	5-6	27	BC: 1-3	29
101-102	2	7	32	BC: 101	29
103	27	101	4	ME-11/U: 1	25
TBP: 1	B	TDT: 1-3	10	SCR: 1-7	29
TBS:		TDU: 1	B	SCR: 101-102	29
1-6	11	TDY:		MISC:	
7-8	13	1-2	17	1-8	B
101-106	B	3-4	24	9-10	3
107-109	28	5-6	20	11-12	28
TBW: 101	B	TDZ:		13-16	13
TBX: 1-3	B	1-2	19	17-18	15
TBY:		3-4	22	19-22	22
1-2	16	5-6	27	23-24	26
3	B	7-8	32	25-26	31
101	2	9-13	37	27-28	27
TCC: 1	B	101	25	29-32	28
TCE:		TEB: 1-2	36	33-34	29
1-2	B	TEC: 1	32	35-44	32
3	28	TEF: 1-2	32	45-46	33
101	28	TEP: 1-2	32	47-48	34
TCJ: 1	B	TPA: 1-2	27	49-56	38
TCK:		YE:		101	B
1-2	9	1-2	7	TYPE:	
3-4	13	3-4	1	1-2	6
5-6	33	5-6	3	2a	B
7	34	7-10	7	3-4	9
101	27	101-102	B	5-10	3
TCN: 1	B	103-104	31	11-12	13
TCO: 101	B	YG:		13-14	20
TCP: 101	28	1-4	7	15-16	22
TCS:		5	14	17-18	27
1-2	8	101	18	19	28
3-4	11	YR: 1	14	101	13
5-6	23	AM-215/U: 1-3	25	DRAW:	
7-8	34	AN/APN: 1	24	1-17	15
9	35	AN/APR: 1	36	18-19	28
101-102	28	AN/ARC:		NJ:	
103-104	30	1-2	5	1-2	28
TCY: 101	B	3-10	B	3-7	27
TCZ:		11-12	12	NK: 1-2	27
1-3	27	13-14	20	NM:	
101	19	15-16	29	1-4	28
TDD: 1	B			5-8	29
				9	34
				SONAR MISC: 1	28

Restricted

TABLE OF CONTENTS

SECTION 1—GENERAL

	Page
<i>Reports, publications, and forms:</i>	
Books, electronics and other technical.....	GEN:108
Capacitor and resistor chart.....	GEN:170
CEMB binder, maintenance of.....	GEN:1
Electronics failure reports, envelopes for.....	GEN:172
Electronic field changes, reporting of.....	GEN:73
Final instruction books.....	GEN:76
Final instruction bodies, addendum to list of.....	GEN:96
Distribution of NavShips 4110 increased.....	GEN:110
Loran equipment (Shipboard), classification reduced.....	GEN:72
Loran handbook for shipboard operators, correction to.....	GEN:96
Loran transmitting station manual, replacement drawings.....	GEN:68
Loran transmitting station manual, short title.....	GEN:68
Monthly performance and operational report.....	GEN:112
Navships 383 revised, Failure report form.....	GEN:5
NavShips 383—lost, strayed, or stolen.....	GEN:107
New Navy type number book distributed.....	GEN:111
Publications to individuals, issue of.....	GEN:5
Quartz crystals (Piezo Electric), standard procedure for ordering.....	GEN:66
Quartz crystal records, submission of.....	GEN:7
Report, monthly performance and operational.....	GEN:112
Test equipment allowance.....	GEN:109
Transmitter tuning records, submission of.....	GEN:7
KY-44 (XN-2) FX Instruction books and parts lists, availability of.....	GEN:172
<i>Components:</i>	
Antenna disconnect switches.....	GEN: 169
Arc-overs, emergency treatment of.....	GEN:38
Ball bearings, care of.....	GEN:40
Battery (Radio) charging facilities in landing craft.....	GEN:28
Batteries, collection of explosive gases.....	GEN:27
Batteries (Dry), prolonging life.....	GEN:27
Capacitors (Bypass), failure of in army equipment.....	GEN:73
Capacitors (Tuning), wiping contacts.....	GEN:30
Capacitors, current leakage in electrolytic.....	GEN:107
Copper oxide rectifier stacks, test of.....	GEN:113
Fuse holders (Post Type), failure of.....	GEN:41
Fuses, notes on use of.....	GEN:41
Loudspeakers, measuring the impedance.....	GEN:71
Motors and generators, symptoms and causes of trouble.....	GEN:94
Nitrogen flasks, nonshatterable.....	GEN:27
RF cables and connectors, protection of.....	GEN:169
Relay maintenance.....	GEN:28
Relays, keying.....	GEN:93
Slip rings and brushes, service and maintenance information in type A AM and AS ABI indicator units.....	GEN:54
Switches (Start-Stop), operation of.....	GEN:39
Transformers (Power), failure of.....	GEN:4
Volume controls, maintenance of.....	GEN:38
<i>Electronic tube information:</i>	
Cross Index of electron tube types.....	GEN:171
Radioactive tubes—DANGER.....	GEN:114
Tubes (Acorn), notes on installing.....	GEN:1
Tubes (Cathode Ray), precautions for handling.....	GEN:96
Tubes (Electron), practical facts about testing.....	GEN:70

Restricted

SECTION 1—GENERAL—Continued

Electronic tube information—Continued

	Page
Tube (Electron) types, catalogue.....	GEN:1
Tubes (Mercury Vapor), care of.....	GEN:1
Tubes, removal of from equipments.....	GEN:2
Tubes (Stored), treatment of.....	GEN:1
Tubes (Transmitting Spares), maintenance of.....	GEN:3
Type CWL-861 tubes, testing of.....	GEN:2

Receivers:

Entertainment receivers for naval vessels.....	GEN:47
Oscillator radiation—A summary of safe and unsafe receivers.....	GEN:47
Radio receiving equipment (Commercial), aboard U. S. vessels.....	GEN:49
Receiver security.....	GEN:47
Tuning wand (Alignment of Receivers).....	GEN:45
Unauthorized receivers.....	GEN:48

Transmitters:

Emergency frequency control.....	GEN:36
Key-control tester panel.....	GEN:97
Master oscillators for advanced bases.....	GEN:36
Neutralizing tests.....	GEN:16
Time delay relay modification kit of radio telegraph transmitting equipment.....	GEN:71
Transmitter control circuits.....	GEN:67
Transmitter, failure to load.....	GEN:38
Transmitter, loading of.....	GEN:37
Transmitter meters (Low Frequency AC and DC), failure of.....	GEN:30
Transmitters, spurious radiations while tuning.....	GEN:51
Transmitting and receiving equipment, adjustment of.....	GEN:91

Direction finders:

Direction finders (Shipboard), calibration of.....	GEN:79
Direction finding equipment (Medium Frequency), calibration and compensation of.....	GEN:13
Direction finding equipment, sense determination.....	GEN:29
Direction finding equipment, treatment of rigging on ships.....	GEN:52

Spare parts:

Class 16 material, instructions for obtaining.....	GEN:8
Class 16 material, importance of proper description on requisitions for.....	GEN:10
Distribution and allocation of material, correspondence concerning.....	GEN:10
Spare parts for nonstandard types of radio equipment.....	GEN:7
Spare parts, preparation of requests (NavSanda Form 302).....	GEN:68

Miscellaneous:

Additional indicators.....	GEN:121
Alterations, CNO policy.....	GEN:96
"AN" type numbers, examples of.....	GEN:120
Articles from Naval Communications Bulletin, reprinted.....	GEN:99
Cable (Types TTHFA and TTHFWA), stripping insulation from unit conductors.....	GEN:78
Cable and wire marking, revised system.....	GEN:18
Coaxial lines, insulation resistance of.....	GEN:171
Control links (Radio), new name and Navy model designation.....	GEN:18
Date markings on electronic equipment.....	GEN:11
Emergency tricks.....	GEN:44
Equipment indicates letters, table of.....	GEN:120
Field change index, electronic.....	GEN:123
Frequency meters, use of standard frequency broadcasts for checking.....	GEN:100
Frequency (v-h-f) measurement methods.....	GEN:12
Frequency (Radio) classification.....	GEN:12a
Frequency tolerance of radio communication equipment.....	GEN:66
Fungus growth, removal of, in radio equipments.....	GEN:73

Restricted

SECTION 1—GENERAL—Continued

Miscellaneous—Continued

	Page
Fungus growths.....	GEN:30
Fungus proofed wire, precautions in handling.....	GEN:73
Ground connections.....	GEN:170
Handset cables in radiophone units, failure of.....	GEN:71
High-voltage measurements.....	GEN:111
Insulation (Copalene and Rubber), construction of a "heat stripper" for.....	GEN:43
Joint nomenclature system ("AN" system) for communication-electronic equipment, summary of.....	GEN:117
Litz wire.....	GEN:35
Loudspeakers (Navy Type), summary of.....	GEN:31
Loudspeakers, reduction in number of.....	GEN:11
Lubricants, electronic equipment.....	GEN:96
Modification letters.....	GEN:121
New section added to CEMB.....	GEN:91
Nomenclature policy.....	GEN:122
Notes.....	GEN:121
Nuts in tight places, starting of.....	GEN:40
Plastic adhesive tape for electronics use.....	GEN:111
Power cords, preventative maintenance.....	GEN:95
Power supplies (General Purpose for Electronic Equipment), status of.....	GEN:75
Radioactive samples, handling and stowage of.....	GEN:167
Radio interference and cable replacement.....	GEN:168
Record players, connection to shipboard broadcast reception systems.....	GEN:20
Repair shop antennas, caution when using.....	GEN:51
Resistors, RMA preferred values.....	GEN:29
RMO's get new title.....	GEN:66
Security hazard of electric razors.....	GEN:51
Soldered joints (Cold) in equipments.....	GEN:42
Soldering.....	GEN:42
Soldering iron, care of.....	GEN:42
Sonar Section added to CEMB.....	GEN:113
Standard frequency broadcasts, use for checking frequency meters.....	GEN:100
Stroboscope disc, instructions for using.....	GEN:24
Teletype letter to all ships and stations.....	GEN:77
Tester (Electronic) for cord and cables.....	GEN:39
Tools (Hand), notes on care of.....	GEN:43
Transfer panel patchcords, color code.....	GEN:19
Transformers (Output), identification.....	GEN:73
Treatment of radio equipment after salt-water immersion.....	GEN:39
Tropicalization, checking.....	GEN:72
V-H-F equipment, erratic performance.....	GEN:30
Wiring diagrams (Radio), protection of.....	GEN:29
(Workbenches), Grounding of.....	GEN:3
Work Lists, Overhaul, check your shipyard.....	GEN:116
Spare armatures for radio motor-generators, inspection of.....	GEN:172

SECTION 2—ANTENNAS AND TRANSMISSION LINES

Cleaning insulators.....	ANT:1
Proper treatment of radio antenna systems.....	ANT:1
Interchangeability of insulators.....	ANT:1
Bowl insulators.....	ANT:1
Antenna leakage resistance.....	ANT:1
Construction of a standard dummy antenna.....	ANT:1
What does antenna current mean.....	ANT:3
Tuning transmitters under conditions of radio silence.....	ANT:5

July 1952

Communication Equipment Maintenance Bulletin

Supplement No. 38

XI

Restricted

SECURITY INFORMATION

Restricted

SECTION 2—ANTENNAS AND TRANSMISSION LINES—Continued

	Page
New receiving antenna transmission line system.....	ANT:8
Receiving antennas.....	ANT:9
Antenna wire for shore use.....	ANT:9
Improved method of assembling coupling unit #49529 used with RG-18/U cable.....	ANT:10
Connecting cables to "AN" Connectors.....	ANT:10
Maintenance of stand-off antenna insulators.....	ANT:11
Submarine dual-purpose periscope antenna, instruction pamphlet distribution for.....	ANT:11
Megger adapter for testing coaxial cables.....	ANT:11
Painting of antennae.....	ANT:13
Substitute material for xtmr trunks.....	ANT:13

SECTION 3—INTERFERENCE

Radio interference elimination in PT boats.....	INT:1
Radio shielding of gasoline engines.....	INT:1
Local noise reduction at air control towers.....	INT:3
Elimination of radar interference.....	INT:4
Radio interference elimination.....	INT:5

SECTION 4—DIRECTION FINDING EQUIPMENT—D SERIES

DP SERIES:	
Reduction of oscillator radiation in model DP equipments.....	DP:1
Faulty shield continuity in model DP equipments.....	DP:1
Model DP series trouble shooting notes.....	DP:101
DAB SERIES:	
The effect of line voltage variations on the model DAB direction-finding equipments.....	DAB:1
Discriminating filters and new commutators for model DAB direction-finding equipments.....	DAB:1
DAE SERIES:	
Modification of the model DAE direction-finding equipments.....	DAE:1
Model DAE series trouble shooting notes.....	DAE:101
DAK SERIES AND DAQ SERIES:	
Lubrication of the ABI unit of model DAK series equipments.....	DAK/DAQ:1
Defects in model DAQ antenna installations.....	DAK/DAQ:1
Effect of demountable whip antennas on model DAQ and model DAU operation.....	DAK/DAQ:1
DAQ/DAU field change no. 1—installation of improved loop antenna.....	DAK/DAQ:2
DAK field change no. 1—modulator balancer kit.....	DAK/DAQ:2
Antenna cable for model DAK, DAQ, and DAU series equipment, cutting.....	DAK/DAQ:2
Models DAK/DAQ series trouble shooting notes.....	DAK/DAQ:101
DAS SERIES:	
Defective model DAS-1 receiver countertest jacks.....	DAS:1
Removable hood for model DAS series equipment.....	DAS:28
Replacement lever-type switches for models DAS-1, LRN-1, and LRN-1A equipments.....	DAS:1
Installation of loran antennas and loading coils on models DAS and LRN series equipments.....	DAS:1
Removing models DAS-1, -3, -4, and LRN-1, -1A equipment from its case.....	DAS:3
Loran, pointers on.....	DAS:22
Loran receiving equipment—model LRN-series and DAS-series.....	DAS:3
Navy field changes for models LRN-1 and LRN-1A.....	DAS:10
Navy field changes for models DAS-1 and DAS-3.....	DAS:13
Navy field changes for model DAS-4.....	DAS:17
Navy field changes for models DAS and DAS-2.....	DAS:19

Restricted

SECTION 4—DIRECTION FINDING EQUIPMENT—D SERIES—Continued

DAS SERIES—Continued	Page
Oscillator frequency control knob of DAS series equipment, adjustment of drive mechanism for.....	DAS:22
Models DAS-1/-3 antenna input chassis connector.....	DAS:22
Models DAS-1, -3, -4 indicator alignment.....	DAS:23
TS-251/UP.....	DAS:2
Model DAS series trouble shooting notes.....	DAS: 101
DAU SERIES:	
Effect of demountable whip antennas on DAU operation.....	DAU:1
DAU field change no. 1—installation of improved loop antenna.....	DAU:1
DAU field change no. 2—scanning selectivity kit.....	DAU:1
Antenna cable for model DAU series equipment, cutting.....	DAU:1
Model DAU series trouble shooting notes.....	DAU: 101
DBE SERIES:	
DBE field change no. 1—increase wattage rating of R-209 and R-211 (no kit)....	DBE:1
Corrections to model DBE loran equipment instruction book.....	DBE:1
DBM SERIES	
DBM field change no. 1—changing wiring of S-107.....	DBM:1
DBM field change no. 2—changing scanning capacitor coupling.....	DBM:1
DBM field change no. 3—changing bullet in antenna r-f rotary joint.....	DBM:1
DBM field change no. 4—installing an equalizer in the low-frequency antenna....	DBM:2
Model MX-833/SL modification kit switching arrangement for use with DBM-1..	DBM:2
Antenna coupling failures.....	DBM:2
Maintenance of model DBM/1 antennas.....	DBM:3
Electronic countermeasures equipment.....	DBM:3
Improper maintenance of model DBM/1 antennas.....	DBM:4
Pinion gear for DBM-1 antennas.....	DBM:5
Rotation failures of model DBM/1 antenna.....	DBM:4
DBM series trouble shooting notes.....	DBM:101

SECTION 5—CALIBRATING EQUIPMENT—L SERIES

LM SERIES:	
Interchangeability of LM-7, LM-10, LM-13, and SCR-211 frequency meter crystals.....	LM:1
Rectifier 20104-A for LM frequency meter.....	LM:1
Use of the LM frequency meter as a variable frequency oscillator for emergency frequency control.....	LM:1
LM field change no. 1—addition of adjustment lever for corrector dial.....	LM:1
Discrepancy in the LM-18 instruction book.....	LM: 2
Model LM series trouble shooting notes.....	LM:101
LP SERIES:	
Correction to the model LP-5 instruction book.....	LP:1
LR SERIES:	
Model LR series interpolator difficulties.....	LR:1
Frequency measurements using model LR-1 frequency meter.....	LR:1
Error in the instruction book for models LR and LR-1 heterodyne frequency meters..	LR:2
Defective dials in model LR-2 equipments.....	LR:2
Model LR series trouble shooting notes.....	LR: 101
Instruction book for models LAF and LAF-3 r-f signal generator equipments.....	LAF:1
Error in Models LAF/-3 instruction books.....	LAF:1
LRN SERIES:	
Information on model LRN series equipments.....	LRN:1

Restricted

SECTION 6—COMBINATION TRANSMITTING AND RECEIVING EQUIPMENT—M SERIES

	Page
MN SERIES:	
Model MN series trouble shooting notes.....	MN:101
MO SERIES:	
Operating precautions for the models MO-1/MAK equipments.....	MO: 1
MR SERIES:	
Modification to prevent radiation from the model MR equipments.....	MR:1
MS SERIES:	
Modification of model MS (Abbott TR-4) equipments.....	MS : 1
MAA SERIES:	
Prevention of ammeter burnouts in the models MAA and MZ equipments.....	MAA:1
MAK SERIES:	
Operating precautions for the model MAK equipments.....	MAK:1
MAM SERIES:	
Model MAM whip antenna modification.....	MAM:1
MAN SERIES:	
NYPEARL MAN modification to permit operation on 115 volt AC.....	MAN:1
Model MAN series trouble shooting notes.....	MAN:101
MAR SERIES:	
Crystal ovens for model MAR radio equipment.....	MAR:1
Model MAR radio equipment panel meter.....	MAR:1
Type 2C39 tubes in model MAR radio equipment.....	MAR:1
MAR field change No. 1—additional shockmounts for shipboard installation kits.....	MAR:1
MAR field change No. 2—adding ballast resistor (R-530) to operating spares.....	MAR:1
Crystal oven extractor.....	MAR:2
MAR/RDR service information.....	MAR:2
MAR/RDR service hints.....	MAR:3
MAR field change No. 3—replacement of the time delay relay in universal power supply unit, type 20379.....	MAR:5
MAR field change no. 4—addition to allowance of equipment spare parts for a-c/d-c universal power supply unit.....	MAR:5
Additional information on crystal ovens for model MAR radio equipment.....	MAR:6
Obtaining crystals for models MAR, RDR, RDZ and TDZ.....	MAR:6
MAR field change No. 5—addition of noise-suppression kit for dynamotor and blower motor.....	MAR:6
MAR notes on component failures.....	MAR:7
Crystal contacts, shorting of in model MAR equipment.....	MAR:7
MBF SERIES:	
Halyard type antennas of model MBF equipments.....	MBF:1
Shorting of coaxial cable in the model MBF equipment.....	MBF:1
Correction to the MBF preliminary instruction book.....	MBF:1
Alternate method for tuning the MBF transmitter.....	MBF:1
MBF field change no. 1—improving the squelch sensitivity (no kit).....	MBF:1
MBF field change no. 2—improving the intelligibility (no kit).....	MBF:2
Deficiencies of model MBF radio transmitting receiving-equipment.....	MBF:2
Excessive receiver radiation in the model MBF radio equipments.....	MBF:4
Handsets for model MBF radio equipments.....	MBF:4
MBK SERIES:	
Frequency meter connections for model TDN equipment installed in the model MBK trailer.....	MBK:1

SECTION 7—MEASURING EQUIPMENT—O SERIES

OD SERIES:	
A modification for testing 807 tubes in the model OD equipments.....	OD:1
Model OD series trouble shooting notes.....	OD:101

Restricted

SECTION 7—MEASURING EQUIPMENT—O SERIES—Continued

OF SERIES:	Page
Field modification of model OF-1 equipments to obtain usable operating characteristics.....	OF:1
Choice of tubes for models OF, OF-1, and OF-2 interference locators.....	OF:4
Note on OF-2 instruction book.....	OF:4
Model OF series trouble shooting notes.....	OF:101
OQ SERIES:	
Model OQ series trouble shooting notes.....	OQ:1
OZ SERIES:	
Field change kit for OZ series tube tester.....	OZ:1
Model OZ series trouble shooting notes.....	OZ:101
OAL SERIES:	
Model OAL tube chart.....	OAL:1
OCL Series:	
Model OCL vacuum-tube testing equipment.....	OCL:1

SECTION 8—RECEIVING EQUIPMENT—R SERIES

RU SERIES:	
Installation of RU receivers and a-c power packs.....	RU:1
RAG SERIES:	
Model RAG series trouble shooting notes.....	RAG:101
RAH SERIES:	
Model RAH series trouble shooting notes.....	RAH:101
RAK/RAL SERIES:	
High hum level in models RAK/RAL series receiving equipments.....	RAK/RAL:1
60-watt operation of model RAK receiving equipments.....	RAK/RAL:1
RAK field change no. 1 and RAL field change no. 1—providing concentric antenna jack.....	RAK/RAL:1
RAK field change no. 2 and RAL field change no. 2—replacing power supply resistors R-202, R-203, and R-204 (no kit).....	RAK/RAL:2
RAK field change no. 3 and RAL field change no. 3—fusing of the equipments (no kit).....	RAK/RAL:2
RAK field change no. 4—modification for use with Navy type 66097 loop antenna.....	RAK/RAL:3
Field change No. 4—RAK-6/-7/-8 kits not available for.....	RAK/RAL:4
Models RAK/RAL series trouble shooting notes.....	RAK/RAL:101
RAO SERIES:	
Audio output connection, model RAO-9.....	RAO:1
Modification of models RAO-0 and RBK-14 countermeasures receivers for use with the model REM dual pan adaptor.....	RAO:1
Model RAO series trouble shooting notes.....	RAO:101
RAS SERIES:	
Modification to broaden the tuning of model RAS receiving equipments.....	RAS:1
Modification to improve the tuning condensers of model RAS receiving equipments.....	RAS:2
Increasing the audio output of model RAS equipments when using head-telephones.....	RAS:4
Installation of type CME 50063 preselector on model RAS equipments.....	RAS:4
Failure of output terminal strip in model RAS series equipments.....	RAS:5
Replacing tubes in model RAS series receivers.....	RAS:6
Changing coils in model RAS series receivers.....	RAS:6
Error in model RAS-3 nameplates.....	RAS:6
Model RAS series trouble shooting notes.....	RAS:101
RAU SERIES:	
Type CABL-74039 portable frequency standard for calibration at audio frequencies of RAU or AN/FMQ-1A radiosonde receiving and recording equipment.....	RAU:1

Restricted

SECTION 8—RECEIVING EQUIPMENT—R SERIES—Continued

	Page
RAU SERIES—Continued	
Reporting of failure of model RAU series and AN/FMQ-1A radiosonde equipments.....	RAU:3
Lubrication of radiosonde recording equipment.....	RAU:5
Interference in radiosonde equipments.....	RAU:4
Model RUA series trouble shooting notes.....	RAU:101
RBA SERIES:	
Tender spare parts for the power packs of models RBA, RBB, and RBC equipments.....	RBA:1
RBA field change no. 1—installation of type 49509 plug adapters.....	RBA:1
RBA field change no. 2—inversion of power supply filter choke (no kit).....	RBA:2
Model RBA series trouble shooting notes.....	RBA:101
RBB SERIES:	
Tender spare parts for the power packs of model RBB equipments.....	RBB:1
Error in installation instructions for panoramic coupling kits for models RBU/RBV panoramic adapters for use with models RBB/RBC receivers.....	RBB:1
RBB field change no. 1—installation of type 49509 plug adapters.....	RBB:1
RBB field change no. 2—inversion of power supply filter choke (no kit).....	RBB:2
RBB field change no. 3—improvement of band switch.....	RBB:3
Model RBB series trouble shooting notes.....	RBB:101
RBC SERIES:	
Tender spare parts for the power packs of model RBC equipments.....	RBC:1
Error in installation instructions for panoramic coupling kits for models RBU/RBV panoramic adapters for use with model RBC receivers.....	RBC:1
RBC field change no. 1—installation of type 49509 plug adapters.....	RBC:1
RBC field change no. 2—inversion of power supply filter choke (no kit).....	RBC:2
RBC field change no. 3—improvement of band switch.....	RBC:3
Improved method of installing cathode follower adapter type 10563 in model RBC receiver.....	RBC: 4
Model RBC series trouble shooting notes.....	RBC:101
RBG SERIES:	
Model RBG series trouble shooting notes.....	RBG:101
RBH SERIES:	
Modification to simplify operation of model RBH equipments.....	RBH:1
Modification of model RBH-1 equipments to provide carrier control noise suppressor action.....	RBH:1
Model RBH series trouble shooting notes.....	RBH:101
RBK SERIES:	
Antenna connection to model RBK series receivers.....	RBK:1
Interference between models RDC-1 and RBK-14 receivers.....	RBK:1
Modification of Models RAO-0 and RVK-14 countermeasures receivers for use with the Model REM dual pan adaptor.....	RBK:1
RBL SERIES:	
Correction of instruction books for models RBL-5 and RBL-6 radio receivers.....	RBL:1
Model RBL series trouble shooting notes.....	RBL:101
RBM SERIES:	
RBM field change no. 1—shock mounting.....	RBM:1
Field change No. 1—RBM, distribution of kits for.....	RBM:1
RBO SERIES:	
Burnout of cathode bias resistor in model RBO series equipments.....	RBO:1
RBO field change no. 1—modification of the audio-circuit (no kit).....	RBO:1
RBO field change no. 2—replacing power transformer and rectifier tubes.....	RBO:1
RBO field change no. 3—connecting for balanced line speaker connection.....	RBO:1
Addenda to field change no. 2 for model RBO radio equipment.....	RBO:2
Tube type 6V6GT/G used as power amplifier in model RBO series equipments.....	RBO:2
Further addition to field change no. 2 for model RBO radio receivers.....	RBO:2
Model RBO series trouble shooting notes.....	RBO:101

Restricted

SECTION 8—RECEIVING EQUIPMENT—R SERIES—Continued

	Page
RBS SERIES:	
Failure of band switch in model RBS receiving equipment.....	RBS: 1
Rigid cabinets and hinged covers used with model RBS series receiving equipments...	RBS: 1
Model RBS series trouble shooting notes.....	RBS: 101
RBU SERIES:	
Defective coils in model RBU-1 panoramic adaptors.....	RBU: 1
RCF SERIES:	
Radiation suppressors for RCF receiving equipments.....	RCF: 1
RCH SERIES:	
Reports of unsatisfactory performance of model RCH receiving equipments.....	RCH: 1
Failure of phone control switch S-103.....	RCH: 1
Model RCH series trouble shooting notes.....	RCH: 101
RCK SERIES:	
Crystal failures in models RCK and TDQ series equipments.....	RCK: 1
C-113 ceramic shaft, model RCK.....	RCK: 1
Installation notes covering model RCK series receiving equipments.....	RCK: 1
Operation of loudspeakers with model RCK series receiving equipments.....	RCK: 2
Proper connections between model RCK equipments and type 49155 loudspeaker units.....	RCK: 2
Incorrect value of resistor R-246 in model RCK equipments.....	RCK: 2
RCK field change no. 1—additional tuning set-up system (no kit).....	RCK: 3
RCK field change no. 2—noise suppressor wiring correction (no kit).....	RCK: 4
RCK field change no. 3—installation of type 49509 plug adapters.....	RCK: 4
Crystals for alignment of the model RCK radio receiving equipment.....	RCK: 5
Crystal failures in models RCK and TDQ radio equipments.....	RCK: 5
Adapting Models RCK and TDQ for CCL service at shore stations.....	RCK: 5
Model RCK series trouble shooting notes.....	RCK: 101
RDC SERIES:	
Interference between models RDC-1 and RBK-14 receivers.....	RDC: 1
RDJ SERIES:	
X-RDJ field change no. 1—incorporating changes to improve operation of model X-RDJ pulse analyzer equipment (no kit).....	RDJ: 1
RDJ field change no. 1—incorporating changes to improve operation of model RDJ pulse analyzer equipment (no kit).....	RDJ: 2
Model RDJ series trouble shooting notes.....	RDJ: 101
RDM SERIES:	
RDM receiver burnout.....	RDM: 1
RDO SERIES:	
RDO field change no. 1—replacement of 28-volt input receptacle J-305.....	RDO: 1
Revised schematics available.....	RDO: 1
Sensitivity measurements on equipment modified by field charge No. 2-RDO.....	RDO: 2
RDP SERIES:	
RDP field change no. 1—extension of swept oscillator shaft (no kit).....	RDP: 1
RDR SERIES:	
RDR field change No. 1.—shockmount replacement.....	RDR: 1
Crystal oven replacement.....	RDR: 1
RDR service information.....	RDR: 1
RDR service hints.....	RDR: 1
Obtaining crystals.....	RDR: 1
RDZ SERIES:	
RDZ field change no. 1—removal of C-149 capacitors (no kit).....	RDZ: 1
Crystal ovens for models RDZ, MAR, and TDZ radio equipments.....	RDZ: 1
RDZ field change no. 2—adjustment of tuning inductance.....	RDZ: 2
Crystal oven extractor.....	RDZ: 2
RDZ field change no. 3—bonding for auto-tune unit.....	RDZ: 3
Distribution of crystal oven extractors for models RDZ and TDZ equipments.....	RDZ: 3

Restricted

SECTION 8—RECEIVING EQUIPMENT—R SERIES—Continued

RDZ SERIES—Continued	Page
Additional information on crystal ovens for models RDZ radio equipment.....	RDZ:3
Obtaining crystals.....	RDZ:3
Field change No. 4—RDZ, modification to improve stability of i-f amplifier.....	RDZ:3
Elimination of spurious oscillations in RDZ receivers.....	RDZ:4
RDZ and TDZ crystal oven failure.....	RDZ:4
Capacitor, tuning, end plate adjustment of.....	RDZ:4
UHF case histories.....	RDZ:5
RDZ receivers.....	RDZ:6
Model RDZ trouble-shooting notes.....	RDZ:6
REA SERIES:	RDZ:101
REA field change no. 1—receiver output line connections (no kit).....	REA:1
REA field change no. 2—AVC circuit modification.....	REA:1
REK SERIES:	
REK field change no. 1—installation of automatic record player.....	REK:1
REM SERIES:	
Modification of Models RAO-9 and RBK-14 countermeasures receivers for use with the Model REM dual pan adaptor.....	REM:1
T-104 high voltage transformer, failure of.....	REM:1

SECTION 9—TRANSMITTING EQUIPMENT—T SERIES

TU SERIES:	
Model TU series trouble shooting notes.....	TU:101
Installation instructions for Models TAB-6/7 radio transmitting equipments.....	TAB:1
TAJ SERIES:	
Error in TAJ-11 instruction book.....	TAJ:1
Control circuits for the models TAJ-11 through TAJ-18 transmitters.....	TAJ:1
Shipalts requiring removal of Model TAJ and TBL equipments from active vessels deferred.....	TAJ:1
Model TAJ series trouble shooting notes.....	TAJ:101
TAQ SERIES:	
Model TAQ series trouble shooting notes.....	TAQ:101
TBA SERIES:	
Power-amplifier grid leak resistor for model TBA-10 equipments.....	TBA:1
Failure of potentiometer R-130 in model TBA-6 transmitting equipment.....	TBA:1
TBA field change no. 1—modification of meter M-111 bypass circuit (no kit).....	TBA:1
TBA field change no. 2—balanced output operation.....	TBA:1
TBA field change no. 3—high speed keying (no kit).....	TBA:2
TBA field change no. 4—modification on the O-5/FR exciter unit (no kit).....	TBA:3
Model TBA series trouble shooting notes.....	TBA:101
TBK SERIES:	
Marking of motor-generator sets shipped with models TBK-13 and TBM-7 equipments.....	TBK:1
Conversion of models TBK and TBM series equipments to a two-wire output.....	TBK:1
Error in TBK instruction book.....	TBK:1
Addenda in IB-38235-P1 instruction books for model TBK-17 (Also applicable to models TBK-8, 10, 12, 14).....	TBK:1
Model TBK cathode modulator.....	TBK:2
Correction to model TBK cathode modulator circuit diagram.....	TBK:2
Lubrication of blower motors in model TBK-17.....	TBK:4
Tuning procedure in TBK-17 (TBK-8, -10, -12, -14) when using Westinghouse 861 tubes.....	TBK:4
Control circuits for the models TBK-5 and TBK-6 and TBK-13 transmitters.....	TBK:4
TBK field change no. 1—meter M-107 erroneously labeled.....	TBK:5
TBK field change no. 2—parallel high speed keying.....	TBK:6
TBK field change no. 3—modification of the O-5/FR exciter unit (no kit).....	TBK:6

Restricted

SECTION 9—TRANSMITTING EQUIPMENT—T SERIES—Continued

	Page
TBK SERIES—Continued	
Vacuum tube keying for TBK transmitting equipment.....	TBK: 7
Oven compartments, master oscillator, overheating in, on model TBK transmitters.....	TBK: 11
Model TBK series trouble shooting notes.....	TBK: 101
TBL SERIES:	
Error in TBL-13 preliminary instruction book.....	TBL: 1
TBL field change no. 1—modification of labeling of band change switch.....	TBL: 1
TBL field change no. 2—wiring correction to audio output jack J-101.....	TBL: 1
Correction to model TBL-13 preliminary instruction book and models TBL-5/6/7/12/13.....	TBL: 2
Instruction book correction for models TBL-5; -6, -7, -12, -13 transmitters.....	TBL: 2
Warning of high d-c potential on antenna circuits of model TBL radio transmitting equipments.....	TBL: 2
Damage to type -49309 tube sockets of the model TBL series transmitters.....	TBL: 2
Shipalts requiring removal of model TBL and TAJ equipments from active vessels deferred.....	TBL: 2
Motor-generator shafts, shortening of.....	TBL: 3
Model TBL series trouble shooting notes.....	TBL: 101
TBM SERIES:	
Marking of motor-generator sets shipped with model TBM-7 equipments.....	TBM: 1
Emergency part replacements for models TBM and TCM equipments.....	TBM: 1
Converting model TBM to a two-wire transmission line system.....	TBM: 1
Remote control of model TBM-8 radio transmitting equipments.....	TBM: 1
TBM field change no. 1—installation of peak limiting thyrityte units.....	TBM: 2
TBM field change no. 2—parallel high speed keying (no kit).....	TBM: 2
TBM field change no. 3—modification of the O-5/FR exciter unit (no kit).....	TBM: 2
Failure of capacitors in TBM-5 through TBM-9 series radio equipment.....	TBM: 3
Fuses, faulty, for model TBM transmitting equipment.....	TBM: 3
Model TBM series trouble shooting notes.....	TBM: 1 01
TBP SERIES:	
Increasing sensitivity of model TBP equipments.....	TBP: 1
TBS SERIES:	
Oscillator failure in model TBS series receivers.....	TBS: 1
Antenna fitting for destroyer type TBS antennas.....	TBS: 1
Modification of TBS antenna support.....	TBS: 1
Tuning of TBS receivers.....	TBS: 1
Keying of model TBS series equipments.....	TBS: 2
Servicing of the transmitter units of the TBS series equipments.....	TBS: 2
Corrections to the preliminary instruction book for the TBS-8 equipments.....	TBS: 3
TBS field change no. 1—providing standby circuit (no kit).....	TBS: 3
TBS field change no. 2—installation of transmission line filter CHW-53155.....	TBS: 5
TBS field change no. 3—improving reliability of relay K-101 (no kit).....	TBS: 7
TBS series r-f filter chokes L-407 and L-408.....	TBS: 8
Model TBS series trouble shooting notes.....	TBS: 101
TBW SERIES:	
Model TBW series trouble shooting notes.....	TBW: 101
TBX SERIES:	
Modification of model TBX-2 portable radio equipments having serial numbers 509 to 800, inclusive.....	TBX: 1
Extension of the frequency range of model TBX series equipments.....	TBX: 1
TBY SERIES:	
Modification to improve the sensitivity of model TBY equipments.....	TBY: 1
Extending life of TBY batteries.....	TBY: 1
Battery power for model TBY equipments.....	TBY: 2
Antennas for TBY series equipments employed aboard ship.....	TBY: 2
Model TBY series trouble shooting notes.....	TBY: 101

Restricted

SECTION 9—TRANSMITTING EQUIPMENT—T SERIES—Continued

	Page
TCC SERIES:	
Revision of model TCC-3 equipment for parallel high speed keying.....	TCC:1
TCE SERIES:	
Modification of model TCE series antenna tuning unit.....	TCE:1
Maintenance of motor-generator sets for models TCE, TCE-1, and TCE-2 transmitters.....	TCE:2
Frequency shift in TCE-1 and TCE-2 transmitters.....	TCE:3
Tuning unit gaskets for model TCE series transmitters.....	TCE:3
Model TCE series trouble shooting notes.....	TCE:101
TCJ SERIES:	
Models TCJ and TCJ-1 instruction book changes.....	TCJ:1
TCK SERIES:	
Preliminary instruction books for model TCK-4 transmitters.....	TCK:1
Changes to model TCK instruction books.....	TCK:1
Interconnection of model TCK series transmitters with standard radiophone unit.....	TCK:1
Blower motor failures in model TCK equipment.....	TCK:1
Correction to instruction book for model TCK-4 transmitting equipment.....	TCK:1
Instructions for the mechanical alignment of the tuning mechanism in the model TCK series transmitters.....	TCK:2
TCK field change no. 1—TCK replacement brush kits.....	TCK:2
TCK field change no. 2—replacement of TCK: 4 filament transformers.....	TCK:3
Maintenance of the blower motor in model TCK series equipments.....	TCK:4
Mounting of voltage regulator for model TCK-4 radio equipment.....	TCK:4
Maintenance of the reset capacitor C-103 used in the model TCK series transmitters.....	TCK:5
Maintenance of the filament rheostat used in the model TCK transmitter.....	TCK:5
Bearing-puller for Model TCK motor-generator.....	TCK:5
Brush kits, replacement for model TCK radio equipment.....	TCK:5
Transformer connections in power supply of model TCK-4 and TCK-6.....	TCK:6
Mechanical alignment of tuning mechanism.....	TCK:6
Model TCK series trouble shooting notes.....	TCK:101
TCN SERIES:	
Installation material for model TCN-1 equipments.....	TCN:1
TCO SERIES:	
Model TCO series trouble shooting notes.....	TCO:101
TCP SERIES:	
Model TCP series trouble shooting notes.....	TCP:101
TCS SERIES:	
Temporary modification of model TCS crystal circuit.....	TCS:1
Failure of gain controls in model TCS series equipments.....	TCS:1
Improvement of model TCS radio receiving equipment's sensitivity.....	TCS:1
TCS field change no. 1—modification of model TCS relay circuit (no kit).....	TCS:1
TCS field change no. 2—modification of tap switches (no kit).....	TCS:2
TCS field change no. 3—modification of the loading coil (no kit).....	TCS:3
TCS field change no. 4—replacement of motors and generators.....	TCS:3
TCS field change no. 5—installation of power supply filter CTD-53173 or CTD-53174.....	TCS:3
TCS field change no. 6—type 50159 noise limiter adapter units.....	TCS:3
TCS field change no. 7—installation of TCS noise limiter.....	TCS:4
TCS field change no. 8—replacement of resistors R-303 and R-304 (no kit).....	TCS:4
TCS field change no. 9—installation of radio interference elimination kit.....	TCS:4
TCS crystals in error.....	TCS:5
Addendum to field change No. 6 on model TCS radio equipments.....	TCS:5
Adapter units for model TCS series radio receiving and transmitting equipments.....	TCS:6
Power supply PP-380/U modification of.....	TCS:7

Restricted

SECTION 9—TRANSMITTING EQUIPMENT—T SERIES—Continued

	Page
TCS SERIES—Continued	
Antenna lead modification.....	TCS:8
Interlock, improving the effect of.....	TCS:9
Antenna connections.....	TCS:9
Model TCS series trouble shooting notes.....	TCS:101
TCY SERIES:	
Model TCY series trouble shooting notes.....	TCY:101
TCZ SERIES:	
Recommended tuning procedure for TCZ equipments.....	TCZ:1
Operation of TCZ-1 at extreme low temperatures.....	TCZ:1
TCZ field change no. 1—replacement of 28-volt generator brushes.....	TCZ:1
TCZ field change no. 2—removing of audio input ground of type COL-23410 remote control unit (no kit).....	TCZ:1
Keying relays for model TCZ radio transmitting equipments.....	TCZ:2
Improving operation of Model TCZ transmitter.....	TCA:2
Model TCZ series trouble shooting notes.....	TCZ:101
TDD SERIES:	
Failure of the r-f antenna current meter in the model TDD transmitters.....	TDD:1
TDE SERIES:	
TDE field change no. 1—microphone modification kit.....	TDE:1
Failure of the lifting eyes during the installation of model TDE transmitters.....	TDE:2
Correction of TDE-1/2 instruction books.....	TDE:2
Modification of model TDE-1 for use with type CAY-23005 four-wire control.....	TDE:2
Discrepancy in tuning curves for model TDE series equipments.....	TDE:2
Control circuits for the model TDE-2 transmitters.....	TDE:5
TDE field change no. 2—installation of filament warm-up circuit.....	TDE:6
TDE field change no. 3—installation of improved range switch S-307B.....	TDE:7
Model TDE radio transmitting equipment—addendum to field change no. 2.....	TDE:7
Power Supply PP-338/U, relocation of relay.....	TDE:8
Model TDE series trouble shooting notes.....	TDE:101
TDG SERIES:	
Carrier-off alarm for model TDG transmitters.....	TDG:1
Tubes, fused modulator in TDG transmitter.....	TDG:1
TDH SERIES:	
Time delay relays in models TDH and TDO transmitters.....	TDH:1
Model TDH transmitter keying conversions.....	TDH:1
Field reports on tuning difficulties of the model TDH.....	TDH:2
Model TDH-4 transmitter discrepancies.....	TDH:2
Collins autotune systems in TDH-3 radio equipments.....	TDH:4
Modification of model TDH transmitter for frequency shift keying.....	TDH:3
Reversing relay failure.....	TDH:5
Shock hazard elimination in model TDH transmitter.....	TDH:5
TDN SERIES:	
Frequency meter connections for model TDN equipment installed in the MBK trailer.....	TDN:1
Model TDN transmitter blower motors.....	TDN:1
Oscillator control capacitor C-1, relocation of.....	TDN:1
TDO SERIES:	
Time delay relay in model TDO transmitters.....	TDO:1
Heater spares for model TDO transmitters.....	TDO:1
Reversing relay failure.....	TDO:1
TDP SERIES:	
Correction to instruction book for model TDP-1 loran transmitting equipment, Nav Ships 900, 263-A.....	TDP:1
TDQ SERIES:	
Crystal failures in model TDQ series equipments.....	TDQ:1
Length of TDQ antenna transmission line.....	TDQ:1

July 1952

Communication Equipment Maintenance Bulletin

Supplement No. 38

XXI

Restricted
SECURITY INFORMATION

Restricted

SECTION 9—TRANSMITTING EQUIPMENT—T SERIES—Continued

TDQ SERIES—Continued	Page
Failure of model TDQ transmitters.....	TDQ:1
Failure of model TDQ antenna connectors.....	TDQ:1
Damaging the keying relays of model TDQ equipments.....	TDQ:1
Control circuits for the model TDQ transmitter.....	TDQ:2
TDQ field change no. 1—overload relay K-303 change (no kit).....	TDQ:3
TDQ field change no. 2—model TDQ transmission line filter type CRV-53232.....	TDQ:3
TDQ field change no. 3—caution nameplates for TDQ transmitter.....	TDQ:4
Caution nameplates for model TDQ transmitter.....	TDQ:5
Antenna failures in model TDQ v-h-f radio transmitting equipment.....	TDQ:5
Crystal failures in model TDQ radio transmitting equipments.....	TDQ:5
Adapting models TDQ and RCK for CCL service at shore stations.....	TDQ:6
Alignment tool, contact.....	TDQ:7
Model TDQ series trouble shooting notes.....	TDQ:101
TDT SERIES:	
Tuning procedure for model TDT equipments.....	TDT:1
TDT field change no. 1—addition of a send-receive relay (no kit).....	TDT:1
TDT field change no. 2—reducing voltage surges on rectifier tubes (no kit).....	TDT:1
TDT field change no. 3—replacement of resistors R-10, R-11 and R-13 (no kit).....	TDT:3
TDT field change no. 4—installation of blower motor reactor (no kit).....	TDT:3
TDU SERIES:	
Maintenance notes for the model TDU equipments.....	TDU:1
TDY SERIES:	
Removal of the model TDYa/1a receiving Antenna CRP66ALK.....	TDY:1
Additional notes on removal of the TDYa/1a receiving antenna.....	TDY:2
Field changes for model TDY series countermeasures equipment.....	TDY:2
TDY field change no. 5—conversion of model TDY to TDYa and model TDY-1 to TDY-1a.....	TDY:2
TDY field change no. 8—replacement of two reflectors for models TDYa and TDY-1a antenna systems.....	TDY:4
TDY field change no. 12—addition of second magnetron seal assembly.....	TDY:4
TDY field change no. 15—replacement of pump seal assembly.....	TDY:5
TDY field change no. 16—improved conversion of model TDY to TDYa and model TDY-1 to TDY-1a.....	TDY:5
Model MX-833/SL modification kit switching arrangement for use with TDY-1 and DBM-1.....	TDY:5
TDZ SERIES:	
Type 2C39 tubes in models TDZ and MAR radio equipments.....	TDZ:1
TDZ field change no. 1—modification to automatic tuning system and drawer mechanism.....	TDZ:1
TDZ field change no. 2—modification to allowance of tender spare parts.....	TDZ:2
TDZ field change no. 3—installation of protective guard on telephone type dial.....	TDZ:3
TDZ field change no. 4—addition of drawer fasteners to equipment spare parts.....	TDZ:3
Distribution of crystal oven extractors for model TDZ equipment.....	TDZ:3
Correct crystals for use with model TDZ equipments.....	TDZ:4
Crystal ovens for model TDZ radio equipments.....	TDZ:4
Crystal oven extractor.....	TDZ:4
Additional information on crystal ovens for models RDZ, MAR, and TDZ radio equipment.....	TDZ:4
Obtaining crystals.....	TDZ:5
TDZ tuning hints.....	TDZ:5
Model TDZ tuning procedure.....	TDZ:5
Model ME-11/U r-f wattmeter used with TDZ equipments.....	TDZ:6
Instruction book correction.....	TDZ:8
Crystal oven failure.....	TDZ:8

Restricted

SECTION 9—TRANSMITTING EQUIPMENT—T SERIES—Continued

	Page
TDZ SERIES—Continued	
Antenna transfer switches, failure of.....	TDZ:8
UHF case histories.....	TDZ:8
Filament voltage adjustment of 2C39 tubes.....	TDZ:9
TDZ transmitters.....	TDZ:9
Model TDZ trouble-shooting notes.....	TDZ:101
TEB SERIES:	
Field service note on the model TEB transmitter.....	TEB:1
IPA band change switch replacement.....	TEB:1
Reduced filament voltage on type 889RA electron tubes in TEB equipment.....	TEB:1
Bias circuit modification.....	TEB:1
Shaper control circuit.....	TEB:2
Failure of the TEB time interlock mechanism.....	TEB:2
TEC SERIES:	
F. C. No. 1—TEC—change of 3 kv plate contactor K-1122.....	TEC:1
Bias circuit modification.....	TEC:1
TEF SERIES:	
Installation of the distortion measuring voice frequency testing and line bay equipment.....	TEF:1
Transmitter monitor.....	TEF:1
Filament connectors, modification of.....	TEF:1
TPA SERIES:	
Modification of tap-changing timing relay K-249 of Model TPA power amplifier..	TPA:1

SECTION 10—AIRCRAFT NAVIGATION EQUIPMENT—Y SERIES

YE SERIES:	
Instructions for adjustment of the monitor relay circuit of model YE-1 equipments.....	YE:1
Lubrication of the antenna array of model YE series homing equipments.....	YE:1
Model YE-1 coaxial line guard.....	YE:2
Unintentional operation of model YE equipments.....	YE:2
Failure of type 826 tubes in model YE equipments.....	YE:2
Tune-up procedure for the YE homing beacon equipment.....	YE:3
Reconditioning YE antenna and drive mechanism.....	YE:6
Improper monitor signal light operation in the YE beacon transmitter.....	YE:7
YE field change no. 1—installation of matching transformer type CRV-47194 (no kit).....	YE:7
YE field change no. 2—modification to antenna assembly drive unit heater circuit (no kit).....	YE:8
YE field change no. 3—addition of capacitors to gyro selsyn system (no kit).....	YE:9
YE field change no. 4—shorting of interlock switch S-114 (no kit).....	YE:10
YE field change no. 5—change in value of spark absorbing resistor R-503 (no kit).....	YE:10
YE field change no. 6—elimination of interference in radio and radar equipments (no kit).....	YE:10
Model YE-1 series trouble shooting notes.....	YE:101
YG SERIES:	
Disassembly of the model YG equipments.....	YG:1
Antenna control difficulties in model YG radio beacons.....	YG:1
Cautions with model YG equipments.....	YG:1
Errata in model YG final instruction books.....	YG:1
Loss of synchronism causes momentary inoperation of model YG transmitters.....	YG:1
YG field change no. 1—change in over-the-bow keying circuit (no kit).....	YG:2
YG field change no. 2—hood for Barco joint.....	YG:3
YG field change no. 3—installation of improved contacts for relay K-101 (no kit).....	YG:3
YG field change no. 4—elimination of keying relay K-101.....	YG:3
YG field change no. 5—addition of true bearing control unit type CAIH-23408.....	YG:4
YG field change no. 6—improved insulation for resistors R-109 to R-112 (no kit).....	YG:5
YG addendum to field change no. 4.....	YG:5
Model YG series trouble shooting notes.....	YG:101

Restricted

SECTION 10—AIRCRAFT NAVIGATION EQUIPMENT—Y SERIES—Continued

YR SERIES:

Page

YR radio telephone beacon—failure of audio transformer..... YR:1

SECTION 11—"AN" AND ARMY EQUIPMENT

Type AM-215A/U a-f amplifier.....	AM-215/U:1
Types AM-215/U and AM-215A/U audio-frequency amplifier, rack mounting for.....	AM-215/U:1
AN/APN-9 loran equipment—field change no. 1—improved crystal clamp (no kit).....	AN/APN:1
Error in the instruction book for the AN/APR-5AX equipment.....	AN/APR:1
AN/APR-9A Field Change No. 1.....	AN/APR:1
AN/ARC-1 capacitor failure.....	AN/ARC:1
Replacement of 6AK5 tubes in the AN/ARC-1.....	AN/ARC:2
AN/ARC-1 circuit changes.....	AN/ARC:2
AN/ARC-1 test hint.....	AN/ARC:2
Loading AN/ARC-1 transmitters.....	AN/ARC:2
Service notes and checks for the AN/ARC-1 equipments.....	AN/ARC:3
Suggestions for isolating trouble in AN/ARC-1 equipments.....	AN/ARC:5
Plug and receptacle for use in servicing AN/ARC-1 equipments.....	AN/ARC:6
General information on the adjustment of the receiver of model AN/ARC-1 equipment.....	AN/ARC:6
Adjustment of the AN/ARC-1 receiver's sensitivity control.....	AN/ARC:7
I-f amplifier change in AN/ARC-1 VHF receiving equipment.....	AN/ARC:7
Parasitics in the AN/ARC-1 equipments.....	AN/ARC:7
Elimination of r-f "hash" produced by AN/ARC-1 dynamotor in associated equipments.....	AN/ARC:8
Improved crystal sockets for AN/ARC-1 equipments.....	AN/ARC:8
AN/ARC-1 tuning difficulties due to old style National Union 832A tubes.....	AN/ARC:8
AN/ARC-1 mistracking.....	AN/ARC:8
Defective autotune locking bars in AN/ARC-1 equipments.....	AN/ARC:9
Burning out of model AN/ARC-1 tuning motors.....	AN/ARC:9
Removal and replacement of model AN/ARC-1 autotune motors.....	AN/ARC:10
Slo-Blo fusing of AN/ARC-4 equipments.....	AN/ARC:10
Hex wrenches for AN/ARC-5 equipments.....	AN/ARC:10
AN/ARC-5 failure due to positioning of shelf supporting h-f generator tubes.....	AN/ARC:10
Poor sensitivity in m-f and h-f receivers of AN/ARC-5 due to 12K8 mixer tubes.....	AN/ARC:11
Tuning precautions when using test equipment with the AN/ARC-5.....	AN/ARC:11
Replacement screws in selector unit of AN/ARC-5 VHF receiver.....	AN/ARC:11
Band switching motors for AN/ARC-5 equipments.....	AN/ARC:11
Error in volume 1 of the instruction book for AN/ARC-5 equipments.....	AN/ARC:11
Resonance indicator for the AN/ARC-1 receiver tuning.....	AN/ARC:12
Slippage of AN/ARC-1 tuning controls due to backlash.....	AN/ARC:12
Force draft ventilation for AN/ARC-1.....	AN/ARC:12
Design of dummy antenna for AN/ARC-1.....	AN/ARC:12
Rotary test rack for model AN/ARC-1 equipment.....	AN/ARC:12
Lubrication data for aircraft radio equipment AN/ARC-1 and for radio set AN/ARC-1A.....	AN/ARC:14
AN/ARC-1 lubrication preventative maintenance.....	AN/ARC:14
AN/ARC-1 field change no. 1—reducing radio interference caused by dynamotors.....	AN/ARC:15
Output transformers for models AN/ARC-1 and SCR series radio sets.....	AN/ARC:16
Turn switch off when replacing model AN/ARC-1 radio sets.....	AN/ARC:17
Wrench, locking, AN/ARC-1.....	AN/ARC:17
Roller coil tie rods, repair of, in model AN/ARC-1.....	AN/ARC:17
Auto-tune adjustment, aid to, in AN/ARC-1.....	AN/ARC:17
Multimeter TS-297/U, use of in place of test meter TS-80/U.....	AN/ARC:18
Model AN/ARC series trouble shooting notes.....	AN/ARC:101
Replacement coaxial cables and connectors for the AN/FGC-1A keyer.....	AN/FGC:1
Modifications to AN/FGC-1A and AN/FGC-1B equipments.....	AN/FGC:1
Replacement of electronic timers in navy models AN/FGC-1, AN/FGC-1A, AN/FGC-1B, and UF teletype and tone equipments.....	AN/FGC:1
Polar output from receiving code converter, modification for.....	AN/FGC:2

Restricted

SECTION 11—"AN" AND ARMY EQUIPMENT—Continued

	Page
Reporting of failures of model AN/FMQ-1A radiosonde equipments.....	AN/FMQ:1
AN/GMQ-2 ceilometer, moisture condensation in.....	AN/GMQ:1
AN/SGC-1A radio teletype terminal set.....	AN/SGC:1
Excessive power supply failures in models AN/SPA-6A and AN/APA-1 pulse analyzers.....	AN/SPA :1
Model AN/SPA series trouble shooting notes.....	AN/SPA:101
Coaxial coupler for AS-45A/SPR-2 antenna.....	AN/SPR:1
Tuning units for AN/SPR-2 receiver.....	AN/SPR:1
Crystal information on model AN/SPR-2 receiver.....	AN/SPR:1
AN/TRC-1A now available for model UF radio carrier equipment.....	AN/TRC:1
AN/UPM-2 field change no. 1—replacement of crystals.....	AN/UPM:1
2 uses in AN/URA-8A frequency shift converter comparator equipment.....	AN/URA:1
AN/URD-2 VHF/ADF installation suggestion.....	AN/URD:1
Defective wiring in AN/URM-25.....	AN/URM:1
AN/URM-17 instruction book correction.....	AN/URM:1
Alignment tool-proper, use of.....	AN/URR:1
Availability of test cables for AN/URR-13 receivers.....	AN/URR:1
Performance of RM and conventional dry batteries.....	BA:1
Description of BC-638-A frequency meter and signal generator.....	BC:1
Modification to add noise limiter in BC-639-A.....	BC:1
Wiring modification of BC-640-A VHF transmitter to permit remote control operation.....	BC:2
BC series trouble-shooting notes.....	BC:101
Model ME-11/U r-f wattmeter.....	ME-11/U:1
Output transformers for certain model SCR series radio sets.....	SCR:1
Models SCR-508 and SCR-608 radio transmitting-receiving equipments.....	SCR:1
Interference between Army models SCR-508, SCR-608, SCR-610, and SCR-808 equipments.....	SCR:2
Modification of Signal Corps models SCR-508, SCR-608, and SCR-808 radio equipments to adapt the sets to shipboard mounting for amphibious operation.....	SCR:2
Installation of resistors in model SCR-508.....	SCR:5
Models SCR-509, SCR-510, SCR-609, and SCR-610 radio transmitting-receiving equipments.....	SCR:5
Elimination of noise and poor operation in SCR-522 equipments.....	SCR:6
Receiver tube protection.....	SCR:6
Failure of capacitors in model SCR-624 radio equipment.....	SCR:7
SCR series trouble shooting notes.....	SCR:101

SECTION 12—MISCELLANEOUS EQUIPMENT AND COMPONENTS

Revision of AVT-22B equipment for high speed keying.....	MISC:1
Conversion of Mackay receivers models 117-A and 117-B to model 117-C.....	MISC:1
Aligning the WE-233A transceiver with the Hickok 19X signal generator.....	MISC:2
Modification of Dumont 241 cathode-ray oscilloscope.....	MISC:2
Placement of rectifier units for the Wilcox 96C transmitter.....	MISC:2
Multi-channel radiotelegraph systems over-all operation.....	MISC:3
How to use the tuning fork and stroboscopic target to adjust teletypewriter motor speeds.....	MISC:4
Teletypewriter equipment maintenance and spare parts.....	MISC:7
Extension cords for model 15 teletypewriters.....	MISC:8
Teletypewriter manual distributed.....	MISC:8
Modification of Hickok model RFO-5 cathode-ray oscilloscope.....	MISC:8
Servicing data for Supreme model 542 multimeter.....	MISC:9
Noise and feedback in the WE-233A equipments.....	MISC:9
Modification to the transmitter connector panel used for frequency shift keying.....	MISC:10
Radio teletype notes.....	MISC:10
Failure of WE-323A tubes in the model 19 teletypewriter.....	MISC:11
Spare 323A's for TTY equipments.....	MISC:11
Aligning model FRA.....	MISC:46
FRA field change no. 1—installation of capacitor C-120.....	MISC:12

Restricted

SECTION 12—MISCELLANEOUS EQUIPMENT AND COMPONENTS—Continued

	Page
FRA instruction book, correction to.....	MISC:12
FSA frequency shift keyer, modification of.....	MISC:46
Model 15 teletypewriter trouble shooting chart.....	MISC:12
Modification of telegraph terminal TH-1/TCC-1 for use with MAR and RDZ equip- ments.....	MISC:14
Modification of BD-100 switchboards and typing reperforators.....	MISC:17
Teletype letter.....	MISC:17
Procurement source of teletypewriter spare parts.....	MISC:18
Telephone handset holders.....	MISC:19
Replacement of grid-bias battery in model UP equipment.....	MISC:20
Replacement of obsolete amplifier in transmission measuring set.....	MISC:20
Performance of RM and conventional dry batteries.....	MISC:20
Defective dry batteries.....	MISC:21
FRF field change no. 1—addition of shockmounts for shipboard installation.....	MISC:21
Replacement of electronic timers for, in navy teletype equipment.....	MISC:22
Radio-teletype repeater.....	MISC:22
Model UN or Western Electric type 42-A-1 carrier control system resistors.....	MISC:23
Model 14 transmitter-distributor—field change no. 1—replacement of motor-governor resistor.....	MISC:23
Navy field change No. 1—TT-23/SG, replacement of jack washers and nuts and rewiring of meter circuit.....	MISC:23
“Hispeed B” ditto paper for radiophoto use.....	MISC:24
Modification of model KY-43/URT frequency-shift keyer.....	MISC:24
UP field change No. 1—single sideband voice frequency terminal equipment, twinning of teletype channels.....	MISC:25
UP field change No. 2—switching telephone terminating circuit from two-wire to four-wire operation.....	MISC:26
Alignment and maintenance of Link 11UF/12UF FM receivers.....	MISC:26
Model YA-1/YA-2 radio localizer modification kit MX-850/UR.....	MISC:28
Wire replacement in Models 15 and 19 teletypewriters.....	MISC:28
Batteries of stocked electronic equipment.....	MISC:29
Availability of “Timefax” paper for radio-photo use.....	MISC:29
Field change No. 1—MX-802/MRC, correction to.....	MISC:29
Field change No. 1—TT-41/TXC-1B.....	MISC:29
Field change No. 1—UN, information on.....	MISC:36
Modification of model UN carrier control system.....	MISC:30
Model UN carrier control system, modification of demodulator types 50103 and 50103-A.....	MISC:36
Maintenance parts for Electric Sprayit Co. motors, nonavailability of.....	MISC:32
RCU/RCT series radio-phonograph, schematics for.....	MISC:33
Facsimile transceivers . . . —modification . . . to ensure safety of personnel.....	MISC:33
Test tool set AN/USM-3.....	MISC:33
Noise generator SG-23/U, failure of.....	MISC:33
Noise generator SG-23/U, adjustment of.....	MISC:36
Teletype motor removal suggestion.....	MISC:34
Teletype test adaptor.....	MISC:34
Teletype Cover pad retaining springs.....	MISC:36
Automatic teletype carriage return and line-feed attachment.....	MISC:35
New switch shafts for SB-82/SRR receiver transfer switchboards.....	MISC:35
Model UO equipment, switching of to SSB radio circuit.....	MISC:43
Tone mixing on UHF teletype.....	MISC:44
End-seal socket wrench.....	MISC:45
Power supply PP-380/U, error in instruction book for.....	MISC:46
Facsimile recording paper, stock status and dimensions of.....	MISC:49
Model TU-3/U tube tester hazard.....	MISC:49
Repair of time stamps.....	MISC:49
Teletype panel TT-23()/SG.....	MISC:50

Restricted

SECTION 12—MISCELLANEOUS EQUIPMENT AND COMPONENTS—Continued	Page
A. C. governed motor PD-18/U on teletypewriters TT-48/UG and TT-70/UG.....	MISC:50
Facsimile transceiver TT-41()/TXC-IB.....	MISC:50
JAN designations for teletype and terminal equipment.....	MISC:51
Miscellaneous equipments trouble shooting notes.....	MISC:101

SECTION 13—NAVY TYPE NUMBERED COMPONENTS

Type CAY-20167 copper oxide rectifiers.....	TYPE:1
Field change no. 1 to Leland motor-generator sets, Navy type CLL-21806.....	TYPE:1
Use of line units, type COQ-23403.....	TYPE:3
Installation of 49120 jacks in type 29017 attenuator units.....	TYPE:3
Modification to type 49131 speaker-amplifiers.....	TYPE:5
Type 49131 series speaker-amplifier units.....	TYPE:5
Schematic drawing of Navy type CMX-49131C speaker-amplifier units.....	TYPE:7
Type 49620 speaker-amplifier units.....	TYPE:7
Type 50153 transmission line coupling units.....	TYPE:10
Improvement in type COA-66089 antenna systems.....	TYPE:10
Failure of type 27172 radiophone units.....	TYPE:10
Altering cable clamp on type 23972 radiophone unit.....	TYPE:10
Field change no. 2 to Leland motor generators, Navy type CLL 21806.....	TYPE:11
Installation of jumpers across input terminal strip of type 49131 speaker-amplifiers... ..	TYPE:11
Elimination of feedback in type 49131 speaker-amplifiers.....	TYPE:11
Type CME-60069 signal generator—field change no. 1—addition of output control... ..	TYPE:12
Potentiometer failures in type 49131 series speaker-amplifier units.....	TYPE:12
Reporting failures of type CABL-74039 portable frequency standard.....	TYPE:13
Volume control for 49546 type speakers.....	TYPE:13
Improving performance of type CAGW-66132 antenna.....	TYPE:14
Type 23496 control indicator unit—modified for handset extension.....	TYPE:14
Spare parts for type -49546 loudspeakers.....	TYPE:15
Terminal strip markings on type -23496 remote-control indicator units.....	TYPE:16
Drainage hole for types 66046 and 66047 whip antennas.....	TYPE:16
Additional procurement of type 49546 loudspeakers.....	TYPE:17
Type-49545 speaker-amplifiers, loudspeaker, cones for.....	TYPE:17
Type-49546 loudspeakers, water-tight covers on.....	TYPE:17
Type-10695 soldering guns, distribution of.....	TYPE:17
Type-23497 selector control units, operation of on 400 cps.....	TYPE:18
Type-51085 handset cradle assemblies, installation of.....	TYPE:18
Navy type 49992 adapter kits.....	TYPE:18
Navy type 23500 radiophone units, volume control operation.....	TYPE:19
Navy type 19695 soldering gun, new tips for.....	TYPE:19
Type numbered components trouble shooting notes.....	TYPE:101

SECTION 14—SCHEMATIC WIRING DIAGRAMS

TAJ transmitting equipment.....	DRAW:1
TAJ-14 control circuit.....	DRAW:2
TBK-13 control circuit.....	DRAW:3
TBK-13 transmitter.....	DRAW:4
TBL modulator.....	DRAW:5
TBL-7 control circuit 6 wire.....	DRAW:6
TBL-7 and speech input equipment cont. cir.....	DRAW:7
Radiophone unit connected for remote operation of TBM equipment.....	DRAW:8
TBM modulator unit.....	DRAW:9
TBM-8 carrier control.....	DRAW:10
TBS-5 control circuit.....	DRAW:11
TBS-5 power supply, remote control, and loudspeaker.....	DRAW:12
TBS-5 transmitter.....	DRAW:13
TBW-3 (MM) control circuit.....	DRAW:14

Restricted

SECTION 14—SCHEMATIC WIRING DIAGRAMS—Continued

	Page
TDE-2 transmitter.....	DRAW:15
TDQ equipment.....	DRAW:16
TDZ equipment.....	DRAW:17
Model RCT, RCU, RCU-1 radio-phonograph schematic diagram.....	DRAW:18
Model RCU-2 radio-phonograph schematic diagram.....	DRAW:19

SECTION 15—SONAR SOUNDING EQUIPMENT

Model NJ-General.....	NJ:1
NJ-3/-9 field change No. 1—addition of isolation transformer to index stylus circuit.....	NJ:1
NJ-3/-9 field change No. 2—addition of R-119 to protect C-126.....	NJ:1
Model NJ-6 Bludworth EC-2 commercial sounding equipment.....	NJ:1
NJ-6 field change No. 1—stabilization of amplifiers.....	NJ:2
NJ-7 field change No. 1—same as F. C. No. 2—NJ-3/-9.....	NJ:2
Model NJ-8 indicator switch adjustments.....	NJ:2
Model NJ-8 wiring change.....	NJ:2
NJ-8 field change No. 1—resistor across C-210 in receiver-amplifier.....	NJ:3
NJ-8 field change No. 2—change to permit operation from 115-volt a-c ship's supply.....	NJ:3
NJ-8 field change No. 3—circuit change to improve dept range and recorder trace.....	NJ:5
Repolarizing models NJ and NK receiving projectors.....	NJ:5
Resistance-to-ground readings on models NJ-3 and NJ-9 transmitting and receiving projectors.....	NJ:6
Use of transmitting projectors for receiving on models NJ-3, NJ-4, NJ-6, NJ-7, and NJ-9 equipments.....	NJ:6
Corrections and additions in models NJ-3 and NJ-9 instruction books.....	NJ:7
Model NK—general.....	NK:1
Model NK-2 maintenance and operation.....	NK:1
NK-2 field change No. 1—R-303 connected in series with R-301 and R-302.....	NK:2
Model NM—general.....	NM:1
Installation, adjustment, and care of indicator belts on models NMB-1 and NMC equipments.....	NM:1
NMB-1 field changes No. 1—change to recorder-indicator.....	NM:2
NMB-1 field change No. 2—C421B disconnected.....	NM:2
NMB-1 field change No. 3—keying contact replacements.....	NM:3
Model NMC equipment.....	NM:3
Model NMC keying contact adjustment.....	NM:3
NMC field change No. 1—correction of factory wiring error.....	NM:4
NMC field change No. 2—C-453B replacement.....	NM:4
NMC field change No. 3—spring brake for idler gear O-422.....	NM:4
NMC field change No. 4—pantograph idler gear.....	NM:5
NMC field change No. 5—new chromium stylus needle.....	NM:5
NMC field change No. 6—addition of resistors.....	NM:5
NMC field change No. 7—installation of watertight filter junction box.....	NM:5
NMC field change No. 8—replacement of transducer diaphragms.....	NM:6
NMC sonar transducer diaphragms, repair of.....	NM:7
Model NMC-1 equipment.....	NM:7
Model NMC-1 projectors.....	NM:8
Model NMC-1 Pass characteristics of receiver-amplifier CBM-48082-A.....	NM:8
NMC-1 field change No. 1—addition of parasitic suppressors.....	NM:8
NMC-1 field change No. 2—replacement of resistors.....	NM:9
Model NMC-1/-2 interference of phone jack with receiver removal.....	NM:9
AT-229/SQ replacements for NMC-1/-2 transducers.....	NM:9
Model NMC-2 equipment.....	NM:9
Error in model NMC-2 instruction book.....	NM:9
AN/BQN top and bottom echo sounder.....	MISC:1
AN/SQN-1, contour scanning set.....	MISC:1
AN/UQN-1, sonar sounding set.....	MISC:1